



www.norwin.dk

DATA SHEET

Item: PEAS 4290.4

Document №: NWX-111-10-1-(03)

Revision №: (01)

Made by: KN

Approved by: NPK

Date: 01.07.2011


Scope of supply:

A. PEAS 4290.4 – 50HZ
Or
B. PEAS 4290.4 – 60HZ

Weight:

5500 kg without oil.

Sketch / picture:



Technical requirements:

According to documentation attached from supplier.

Surface treatment:

Color: RAL 5010
Corrosion class: C3H

Documentation requirements:

Noise and vibration test

Additional notes:

Gear box 50Hz or 60Hz must be based on local requirements.

Supplier information:

Supplier mandatory

Supplier optional

Supplier 1:

Name: Winergy

Link: www.winergy-group.com

Supplier`s reference:

A. Norwin PEAS 4290.4 – 50HZ

B. Norwin PEAS 4290.4 – 60HZ

Supplier documentation attached (page 2 to 105)

Supplier 2:

Name:

Link:

Supplier`s reference:

-

Supplier documentation attached (page - to -)

1	Technical data PEAS 4290.4 – 50Hz and 60Hz	3
1.1	Overview mass/drawing Norwin PEAS 4290.4 – 50Hz and 60Hz – 5-6175 462-b	10
1.1.1	A. Assembly drawing Norwin PEAS 4290.4 – 50HZ – 6 180 695	11
1.1.1.1	Partlist Norwin PEAS 4290.4 – 50HZ – drawing 6 180 695.....	12
1.1.2	B. Assembly drawing Norwin PEAS 4290.4 – 60HZ – 6-180 695	14
1.1.2.1	Partlist Norwin PEAS 4290.4 – 60HZ – drawing 6-180 695	15
1.1.3	List of equipment PEAS 4290.4-50Hz and 60Hz	17
1.1.3.1	Technical data oil level control (equipment list)	19
1.1.3.2	Technical data F6100-3 temperature gear oil (equipment list).....	27
1.1.3.3	Technical data level switch (equipment list)	32
1.1.3.4	Technical data ball valve (equipment list).....	56
1.1.3.5	Technical data F6100-2 temperature HSS bearings (equipment list).....	57
1.1.3.6	Technical data breather filter (equipment list).....	62
1.1.3.7	Technical data vane pump (equipment list).....	63
1.1.3.8	Technical data 3/2 way valve (equipment list)	67
1.1.3.9	Technical data non return valve (equipment list)	71
1.1.3.10	Technical data coarse filter (equipment list)	74
1.1.3.11	Technical data shrink disk HSD 420-81 (equipment list)	83
1.2	Assembly and operation instructions	84

1 Technical data PEAS 4290.4 – 50Hz and 60Hz

Getriebe
Gear units

Antriebssysteme für Windturbinen
Drive systems for wind turbines

winergy
Get the power of wind.

Overview of the revisions

Revision	Date	Page	Description of the modifications
0	08.05.2008	-	issue
1	24.01.2011	-	Update 60 Hz version

General:

Customer Code	:	Norwin NW 46/47
Customer specification	:	S-NWB-1-2-3-1-(01)-03 08-05-09: Specification MAIN GEAR for : NW 46/47; 750 kW / 50 Hz Grid ; Nominal Rotor RPM/Generator RPM (25.26 /1500) S-NWB-1-2-3-1-(01)-Addendum 01.07.2010: Specification MAIN GEAR for: NWB 46/47; 825 kW / 750 kW electrical / 60 Hz Grid ; Nominal Rotor RPM / Generator RPM (25.2/1815)
Valid loads for gearbox design	:	Load-Result-NWB-IEC-1B-2A-Mar-31-07-Gearbox New, dated 10.12.2007

Wind turbine NW 47/ 750 kW:

Turbine type	:	upwind
Installation	:	on shore
Drive	:	wind rotor with 3 blades, Ø47 Meter
Regulation	:	active stall regulation
Driven machine	:	asynchronous generator
Direction of rotation		(view on shaft end)
Actuation (rotor shaft)	:	clockwise cw
Power take-off (generator shaft)	:	counter-clockwise ccw
Inclination of rotor shaft	:	4° (rotor side on top)
Main brake	:	active stall regulation of the blades
Auxiliary brake	:	mech. disk brake on generator side

Gear box :

Helical-Planetary Gearbox	:	2 helical stages 1 planetary stage incl. torque arm
Nom. rotor power rating (mech.)	:	825 kW
Nom. electrical power rating	:	750 kW
Nom. rotor torque	:	309 000 Nm (50 Hz) 311 896 Nm (60 Hz)
Actual ratio	:	59,385 (50 Hz) 71,203 (60 Hz)
Nom. rotor speed	:	25,5 min ⁻¹ (50 Hz) 25,28 min ⁻¹ (60 Hz)
Nom. generator speed	:	1519 min ⁻¹ (50 Hz) 1800,0 min ⁻¹ (60 Hz);
Max. loads	:	acc. to customer specification
Weight (without oil filling, coupling a. shrink disk)	:	≈ 5500 kg
Weight shrink disk	:	≈ 300 kg
<u>Lubricants</u>		
Quantity	:	≈ 105 l
Viscosity	:	ISO VG 320 / 460
Type	:	Mobilgear SHC XMP 320 / 460 Mobilgear XMP 320 / 460 Optimol Optigear Synthetic A 320 / 460
Connection rotor shaft – hollow shaft	:	shrink disk HSD 420-81 / Stüwe
Lubrication	:	combined splash / forced lubrication
Oil heating	:	none
Temperature control	:	temperature sensors
Noise power level	:	LW(A) = 98 dB(A), P = 825 [kW]
Ambient survival temperature	:	-25°C up to + 55°C
Nacelle temperature during operation	:	+10°C up to + 50°C
Main dimensions	:	≈ length x width x height ≈ 1650 mm x 1750 mm x 1350 mm
Dimension sheet	:	6175462
Assembly drawing	:	6180453 (50 Hz) 6245914 (60 Hz)
Spare part drawing	:	6180695
Piping drawing main system	:	6180454
Piping drawing auxiliary system	:	6180455
Painting drawing	:	6180481
Spare part list	:	EL 4835519-020 DE/EN
List of equipment	:	EGE-GL PEAS 4290,4 EN
Standard operating manual	:	EGE-BA-ST-001 EN 11.09

Operating values of the gear box:

Temperature

<ul style="list-style-type: none"> • Minimal operating temperatures in nacelle • Maximal operating temperatures in nacelle 	<p>+ 10 °C</p> <p>+ 50 °C</p>
<ul style="list-style-type: none"> • oil sump temperatures: <ul style="list-style-type: none"> – during operation – operation not allowed – start up temperature – shut down 	<p>≤ + 70 °C</p> <p>< + 10 °C</p> <p>≥ + 10 °C</p> <p>> + 70 °C</p>
<p>or</p> <ul style="list-style-type: none"> • bearing temperatures: <ul style="list-style-type: none"> – long term HSS bearings – shut down HSS bearings <p>After a shut down an inspection of bearings and oil supply is necessary.</p>	<p>≤ + 90 °C</p> <p>> + 90 °C</p>
<ul style="list-style-type: none"> • maximum temperature difference between oil sump and bearing at high speed shaft during operation (to be controlled during normal operation and not during start up procedure) 	<p>ΔT= 25 K</p>
<ul style="list-style-type: none"> • Required oil-flow of the main oil supply system 	<p>54 l/min</p>

Logic structure

operation mode	sensor / switches			
	oil sump temperature [°C]	bearing temperature (HSS) [°C]	oil pressure at gear unit inlet [bar]	mech. pump valve (Part No. 752)
idling without grid connection *	≤ + 70	≤ + 90		on
idling *	≤ + 70	≤ + 90	> 0,8	off
production	< + 55	≤ + 90	> 0,8	off
production	55 ≤ T ≤ 65 (increasing)		> 0,8	off
production	> + 65	≤ + 90	> 0,8	off
production	55 ≤ T ≤ 65 (falling)		> 0,8	off
stop		> + 90		
stop	> + 70			
stop			≤ 0,8	

The pump of the cooling system which is not scope of supply Winergy has to assure, that the oil pressure at the gear unit inlet is at least minimum 0,8 bar.

***Idling**

- a) with grid:
If the turbine idles for more than 3 days the lubrication system has to be switched on for 2 minutes every 12 hours.
The operating dates have to be considered generally.
- b) without grid
idling recommended


Oil level

Static oil level at marking of the oil glass: please look at the dimension sheet
At still stand, up to ≈ 40°C oil sump temperature
For more information please look at the operating manual EGE-BA-ST-001-EN 11.09, chapter 10.9



Oil filtration

Recommended fineness : 10 µm (absolute)

Recommended rate of filter reserve : $\beta_{10} \geq 200$



1.1 Overview mass/drawing Norwin PEAS 4290.4 – 50Hz and 60Hz – 5-6175 462-b



Stirnflächen des Außen- und des Innenringes müssen in einer Ebene liegen. Auf Abschlag angezeigte Drehrichtungen sind zu beachten.
 Surfaces of outer and inner ring have to be in the same level. Torque the inner ring until blocked. (Bolt torque per K27 screw 145 Nm.)

Belauende Teile müssen von Käufer gegen unbedeutendes Berühren gesichert werden.
 Belauende Teile müssen von Käufer gegen unbedeutendes Berühren gesichert werden.




Vor Erstarten sind die Ölkanäle unbedingt mit Öl zu füllen.
 Before first start it's necessary to fill all into the oilpockets.

Belauende Teile müssen von Käufer gegen unbedeutendes Berühren gesichert werden.
 Belauende Teile müssen von Käufer gegen unbedeutendes Berühren gesichert werden.

Bezeichnung / Type	PEAS 4290,4	PEAS 4290,4
Größe / Size	4290,4	4290,4
Leistung / Power	825	825
n / Rev/min	1519	1799
n ₁ / Exact ratio	25.50	25.259
Ölviskosität / Oilviscosity (VG)	320	320
Ölfüllmenge / Oil Filling (L)	ca.120	ca.120
Gewicht ohne Öl / Weight without oil (kg)	5500	5500


Order No.	Part No.	Description	Quantity	Unit
420 17	0-100	...	1	...
350 10	0-100	...	1	...
345 17	0-100	...	1	...
100 06	0-100	...	1	...
90 18	0-100	...	1	...
80 111	0-100	...	1	...
55 E3	0-100	...	1	...


1.1.1 A. Assembly drawing Norwin PEAS 4290.4 – 50HZ – 6 180 695

	WINERGY AG - Zahnradgetriebe Gear unit Ersatzteilzeichnung / Spare part drawing	Bauart Type PEAS Größe Size 4290,4	D/EN Ausführung Design	
	<p>M 1:20</p>  <p>M 1:15</p> 			
Winergy AG, Postfach 201160, 46553 Voerde, Tel.+49(0)2871/92-1700 Fax+49(0)2871/92-2596, http://www.winergy-ag.com		Datum/ Date 2008-03-18	Name: Fikus Y 6 180 695	EGE .



Dieses technische Unterlagere hat gesetzlichen Schutz (DIN 34)

1.1.1.1 Partlist Norwin PEAS 4290.4 – 50HZ – drawing 6 180 695

		Ersatzteilliste (EL) Spare parts list		Bauart PEAS Type Größe 4290,4 Size Übersetzung 59,385 ratio		Seite Page 1/2	
				Bei Korrespondenz bitte angeben Please quote in correspondence		GWL/MP/10-11/035 EL 4821533-020 DE/EN	
Hierzu gehört Zeichnungs-Nr. Please refer to DWG No.		6180695					
Teil-Nr.	Menge	Benennung	Zeichnungs-Nr.	Material-Nr.	Gw(kg)		
Part No.	No. off	Description	Drawings No.	Ident no.	Weight		
E 0010	1	ST OELSTANDANZEIGER OIL LEVEL INDICATOR		000.000.464.054	0,2		
E 0044	1	ST WIDERSTANDSTHERMOMETER RESISTANCE THERMOMETER		000.001.157.931	0,3		
E 0045	1	ST NIVEAUSCHALTER LEVEL SWITCH		000.000.800.609	0,3		
E 0052	1	ST DICHTUNG SEAL		000.000.342.287	0,0		
E 0054	1	ST WIDERSTANDSTHERMOMETER RESISTANCE THERMOMETER		000.000.649.506	0,2		
E 0056	1	ST WIDERSTANDSTHERMOMETER RESISTANCE THERMOMETER		000.000.649.506	0,2		
E 0087	1	ST NILOSRING NILLOS RING		000.000.649.773	0,1		
E 0100	1	ST STIRNRADWELLE PINION SHAFT	6040954/D	000.001.277.258	73,9		
E 0132	1	ST V-RING V-100A 98-105 PERBUNAN		000.000.775.102	0,1		
E 0150	1	ST WÄRLZLAGER ROLLING CONTACT BEARING		000.000.380.433	6,4		
E 0151	1	ST WÄRLZLAGER ROLLING CONTACT BEARING		000.000.380.185	13,6		
E 0152	1	ST WÄRLZLAGER ROLLING CONTACT BEARING		000.000.380.682	12,5		
E 0206	1	ST STIRNRAD (INNENVERZÄHNUNG) INTERNALLY TOOTHED GEAR WHEEL	6008292/E	000.001.217.035	520,0		
E 0227	1	ST PLANETSTIRNRADWELLE PLANETARY CYLINDRICAL WHEEL SHAFT	6129859/-	000.001.368.456	128,0		
E 0241	3	ST PLANETSTIRNRAD PLANET PINION	6125967/C	000.001.368.460	125,0		
E 0248	6	ST WÄRLZLAGER ROLLING CONTACT BEARING		000.001.157.486	16,2		
E 0253	1	ST PLANETTRÄGER PLANETARY CARRIER	6105117/F	000.001.336.064	925,0		
E 0255	1	ST WÄRLZLAGER ROLLING CONTACT BEARING		000.001.151.641	18,9		
E 0256	1	ST WÄRLZLAGER ROLLING CONTACT BEARING		000.001.156.873	33,2		
E 0259	1	ST V-RING V-450L 440-480 PERBUNAN		000.000.342.292	0,1		
E 0300	1	ST HOHLWELLE HOLLOW SHAFT	6081378/G	000.001.286.706	120,0		
E 0302	1	ST STIRNRAD GEAR WHEEL	8114841/H	000.000.653.536	383,0		
E 0332	1	ST V-RING V- 80A 78- 83 PERBUNAN		000.000.776.525	0,1		
Die mit * gekennzeichneten Teile gehören zu einer Baugruppe (G). Die Baugruppe ist nur komplett auszutauschen. The parts marked with * belong to a subassembly (G). The subassembly must be replaced complete.							
Winergy AG, Postfach 201160, 46553 Voerde, Tel.+49(0)2871/92-1700 Fax+49(0)2871/922596, http://www.winergy-ag.com				Datum Date 01.07.2011		KRETSCHMANN, FRANK 1727 Rev.: EGEFR	


	Ersatzteilliste (EL) Spare parts list		Bauart PEAS Type Größe 4290,4 Size Übersetzung 59,385 ratio	Seite Page 2/2	
	Bei Korrespondenz bitte angeben Please quote in correspondence		GWL/MP/10-11/035 EL 4821533-020 DE/EN		
Hierzu gehört Zeichnungs-Nr. Please refer to DWG No.		6180695			
Teil-Nr.	Menge	Benennung	Zeichnungs-Nr.	Material-Nr.	Gw(kg)
Part No.	No. off	Description	Drawings No.	Ident no.	Weight
E 0350	1	ST WÄRLZLAGER ROLLING CONTACT BEARING		000.000.650.820	18,5
E 0351	1	ST WÄRLZLAGER ROLLING CONTACT BEARING		000.000.380.681	10,6
E 0357	1	ST WÄRLZLAGER ROLLING CONTACT BEARING		000.000.772.699	1,4
E 0360	2	ST O-RING O-RING		000.000.306.603	0,1
E 0400	1	ST STIRNRADWELLE PINION SHAFT	6081485/B	000.001.286.721	105,0
E 0402	1	ST STIRNRAD GEAR WHEEL	6040960/E	000.001.277.290	133,0
E 0450	1	ST WÄRLZLAGER ROLLING CONTACT BEARING		000.000.380.670	29,2
E 0451	1	ST WÄRLZLAGER ROLLING CONTACT BEARING		000.000.899.109	13,5
E 0751	1	ST PUMPE PUMP		000.000.651.891	8,0
E 0752	1	ST WEGEVENTIL DIRECTIONAL VALVE		000.000.651.893	2,2
E 0753	1	ST RÜCKSCHLAGVENTIL NON-RETURN VALVE		000.000.651.892	0,5
E 0754	1	ST TEIL PART	6037960/A	000.001.250.297	1,0
E 0775	1	ST FILTER FILTER		000.001.152.512	0,2
E* 0131	330,00	MM STREIFEN STRIP		000.000.243.209	0,1
E* 0220	1.440,00	MM STREIFEN STRIP		000.000.243.209	0,1
E* 0331	270,00	MM STREIFEN STRIP		000.000.243.209	0,1
Winergy AG, Postfach 201160, 46553 Voerde, Tel.+49(0)2871/92-1700 Fax+49(0)2871/922596,http://www.winergy-ag.com			Datum Date 01.07.2011	KRETSCHMANN, FRANK 1727 Rev.:	EGE.FR


1.1.2 B. Assembly drawing Norwin PEAS 4290.4 – 60HZ – 6-180 695

	WINERGY AG - Zahnradgetriebe Gear unit Ersatzteilzeichnung / Spare part drawing	Bauart Type PEAS Größe Size 4290,4	D/EN Ausführung Design
	M 1:20		
			
M 1:15			
Winergy AG, Postfach 201160, 46553 Voerde, Tel. +49 (0) 2871/92-1700 Fax +49 (0) 2871/92-2586, http://www.winergy-ag.com		Datum/ Date 2008-03-18	Name: Fikus Y 6 180 695 EGE

Diese technische Unterlage hat gesetzlichen Schutz (DIN 34)

1.1.2.1 Partlist Norwin PEAS 4290.4 – 60HZ – drawing 6-180 695

		Ersatzteilliste (EL) Spare parts list		Bauart PEAS Type Größe 4290,4 Size Übersetzung 71,203 ratio	Seite Page 1/2
		Bei Korrespondenz bitte angeben Please quote in correspondence		5213675 EL 4835519-020 DE/EN	
Hierzu gehört Zeichnungs-Nr. Please refer to DWG No.		6180695			
Teil-Nr.	Menge	Benennung	Zeichnungs-Nr.	Material-Nr.	Gw(kg)
Part No.	No. off	Description	Drawings No.	Ident no.	Weight
E 0044	1	ST WIDERSTANDSTHERMOMETER RESISTANCE THERMOMETER		000.001.159.981	0,3
E 0045	1	ST NIVEAUSCHALTER LEVEL SWITCH		000.000.800.609	0,3
E 0052	1	ST DICHTUNG SEAL		000.000.342.287	0,0
E 0054	1	ST WIDERSTANDSTHERMOMETER RESISTANCE THERMOMETER		000.000.649.506	0,2
E 0056	1	ST WIDERSTANDSTHERMOMETER RESISTANCE THERMOMETER		000.000.649.506	0,2
E 0087	1	ST NILOSRING NILOS RING		000.000.649.773	0,1
E 0100	1	ST STIRNRADWELLE PINION SHAFT	6182128/A	000.001.475.543	71,0
E 0132	1	ST V-RING V-100A 98-105 PERBUNAN		000.000.775.102	0,1
E 0150	1	ST WÄELZLAGER ROLLING CONTACT BEARING		000.000.380.433	6,4
E 0151	1	ST WÄELZLAGER ROLLING CONTACT BEARING		000.000.380.185	13,6
E 0152	1	ST WÄELZLAGER ROLLING CONTACT BEARING		000.000.380.682	12,5
E 0206	1	ST STIRNRAD (INNENVERZÄHNUNG) INTERNALLY TOOTHED GEAR WHEEL	6008292/E	000.001.217.035	520,0
E 0227	1	ST PLANETSTIRNRADWELLE PLANETARY CYLINDRICAL WHEEL SHAFT	6129859/-	000.001.368.456	128,0
E 0241	3	ST PLANETSTIRNRAD PLANET PINION	6125967/C	000.001.368.460	125,0
E 0248	6	ST WÄELZLAGER ROLLING CONTACT BEARING		000.001.157.486	16,2
E 0255	1	ST WÄELZLAGER ROLLING CONTACT BEARING		000.001.151.641	18,9
E 0256	1	ST WÄELZLAGER ROLLING CONTACT BEARING		000.001.156.873	33,2
E 0259	1	ST V-RING V-450L 440-480 PERBUNAN		000.000.342.292	0,1
E 0300	1	ST HOHLWELLE HOLLOW SHAFT	6245911/-	000.001.506.845	118,7
E 0302	1	ST STIRNRAD GEAR WHEEL	6216041/A	000.001.476.018	380,0
E 0332	1	ST V-RING V- 80A 78- 83 PERBUNAN		000.000.776.525	0,1
E 0350	1	ST WÄELZLAGER ROLLING CONTACT BEARING		000.000.650.820	18,5
E 0351	1	ST WÄELZLAGER ROLLING CONTACT BEARING		000.000.380.681	10,6
Die mit * gekennzeichneten Teile gehören zu einer Baugruppe (G). Die Baugruppe ist nur komplett auszutauschen. The parts marked with * belong to a subassembly (G). The subassembly must be replaced complete.					
Winergy AG, Postfach 201160, 46553 Voerde, Tel.+49(0)2871/92-1700 Fax+49(0)2871/922596,http://www.winergy-ag.com			Datum Date 01.07.2011	BIEDER, CHRISTIAN Rev.:	1568 EGE.FR

		Ersatzteilliste (EL) Spare parts list		Bauart PEAS Type Größe 4290,4 Size Übersetzung 71,203 ratio		Seite Page 2/2	
		Bei Korrespondenz bitte angeben Please quote in correspondence				5213675 EL 4835519-020 DE/EN	
Hierzu gehört Zeichnungs-Nr. Please refer to DWG No.				6180695			
Teil-Nr.	Menge	Benennung	Zeichnungs-Nr.	Material-Nr.	Gw(kg)		
Part No.	No. off	Description	Drawings No.	Ident no.	Weight		
E 0357	1	ST WÄRLZLAGER ROLLING CONTACT BEARING		000.000.772.699	1,4		
E 0360	2	ST O-RING O-RING		000.000.306.603	0,1		
E 0400	1	ST STIRNRADWELLE PINION SHAFT	6241633/-	000.001.476.035	78,0		
E 0402	1	ST STIRNRAD GEAR WHEEL	6196809/B	000.001.475.562	136,0		
E 0450	1	ST WÄRLZLAGER ROLLING CONTACT BEARING		000.000.380.670	29,2		
E 0451	1	ST WÄRLZLAGER ROLLING CONTACT BEARING		000.000.899.109	13,5		
E 0751	1	ST PUMPE PUMP		000.000.651.891	8,0		
E 0752	1	ST WEGEVENTIL DIRECTIONAL VALVE		000.000.651.893	2,2		
E 0753	1	ST RUECKSCHLAGVENTIL NON-RETURN VALVE		000.000.651.892	0,5		
E 0754	1	ST TEIL PART	6037960/A	000.001.250.297	1,0		
E 0775	1	ST FILTER FILTER		000.001.152.512	0,2		
E* 0131	330,00	MM STREIFEN STRIP		000.000.243.209	0,1		
E* 0220	1.440,00	MM STREIFEN STRIP		000.000.243.209	0,1		
E* 0331	270,00	MM STREIFEN STRIP		000.000.243.209	0,1		
Winergy AG, Postfach 201160, 46553 Voerde, Tel.+49(0)2871/92-1700 Fax+49(0)2871/922596,http://www.winergy-ag.com			Datum Date 01.07.2011	BIEDER, CHRISTIAN Rev.:	1568 EGE.FR		

1.1.3 List of equipment PEAS 4290.4-50Hz and 60Hz



List of equipment
Code: NW 47

Type **PEAS**
Size **4290,4**

Page
1 of 2

Please quote in correspondance		EGE-GL PEAS4290,4 EN	
Part No.	Qty.	Description	Manufacturer Operating instructions

10	1	oil level control type FSA 127-2.0/-/12 as per Flender Works Standard F 5302	HYDAC / FLUTEC BA HYC.ANZ.000 EN
44	1	resistance thermometer as per Flender Works Standard F 6100-3 mounting length EL 100 mm precision resistor 2 x PT 100 DIN IEC cl. B two-wire circuit immersion tube length 100 mm connection immersion tube G 1/2 thread degree of protection: IP 65	JUMO FLENDER B 6100 EN
45	1	level switch type liquiphant T-FTL 260-0020 mounting length EL 130 mm screw connection G 1	ENDRESS-HAUSER
47	1	ball tap as per Flender Works Standard F 5102 nominal width DN 20 srew connection G 3/4	FLENDER B 5102 EN
54	1	resistance thermometer as per Flender Works Standard F 6100-2 mounting length EL 130 mm precision resistor 2 x PT 100 DIN IEC cl. B two-wire circuit connection immersion tube G 1/2 thread degree of protection: IP 54	JUMO FLENDER B 6100 EN
55	1	breather filter as per Flender Works Standard W 5122 screw connection R 3/4	NIROSTA FLENDER B 5122 EN
56	1	resistance thermometer as per Flender Works Standard F 6100-2 mounting length EL 130 mm precision resistor 2 x PT 100 DIN IEC cl. B two-wire circuit connection immersion tube G 1/2 thread degree of protection: IP 54	JUMO FLENDER B 6100 EN

Winergy AG, Postfach 201160, D 46553 Voerde, Tel. 02871/92-1700, Fax 02871/921 490, http://www.winergy-ag.com	Date 08.05.2008	Name: Kortz	EGE.FR
		REV.: 0	



List of equipment
Code: NW 47

Type **PEAS**
Size **4290,4**

Page
2 of 2

Please quote in correspondance		EGE-GL PEAS4290,4 EN	
Part No.	Qty.	Description	Manufacturer Operating instructions

751	1	vane pump type KSW-3	STOZ
752	1	3/2 way valve type MK 10DR-NO	COAX
753	1	non-return valve GR3 G1	STOZ
775	1	coarse filter as per Flender Works Standard W 5911 standard design type 1NI connection size R 1/2 nominal pressure PN 25 bar material MS ident No. 375 050	FLENDER B 5911 EN
	1	shrink disk HSD 420-81	Stüwe HSD EN

Winergy AG, Postfach 201160, D 46553 Voerde, Tel. 02871/92-1700, Fax 02871/921 490, http://www.winergy-ag.com	Date 08.05.2008	Name: Kortz REV.: 0	EGE.FR
--	--------------------	------------------------	--------


1.1.3.1 Technical data oil level control (equipment list)

HYDAC

BA HYC.ANZ.000 EN

INTERNATIONAL

FLUTEC
Fluid Level Gauge
Fluid Level Sensor
Temperature Switch
FSA / FSK / TSE



1. DESCRIPTION

1.1. GENERAL

FLUTEC fluid level gauges FSA, fluid level sensors FSK and temperature switches TSE are units which serve to monitor and control the level of operating fluid.

The flexible product range means that many combinations are possible:

– FSA: five sizes.

Visual thermometer with °C and °F scale.

Temperature gauge which records the temperature of the operating fluid in the tank; display in °C. Dual scale in °C and °F is available on request.

Simple, standardised mounting conditions (FSA/K).

– FSK: four sizes.

Switching contact can be either type O (opens when fluid is at low level) or type C (closes when fluid is at low level) or type W (dual switching unit)

Temperature gauge which records the temperature of the operating fluid in the tank; display in °C. Dual scale in °C and °F is available on request.

Simple, standardised mounting conditions (FSA/K).

– TSE: three nominal temperatures possible: 60 °C, 70 °C and 80 °C.

Can be easily fitted into the FSA and FSK.

Simple, standardised mounting conditions (FSA/K).

Non-corroding surfaces.

1.2. FUNCTION OF THE FSA

By using a FLUTEC FSA, the fluid level can be easily seen on the outside of the tank. The fluid enters the unit via the lower connection bore and is clearly visible in the tube. Selection of the correct size allows the respective level of the fluid to be monitored.

FUNCTION OF THE FSK

By using a FLUTEC FSK, the fluid level is monitored via an electrical switching signal. This switching signal can be used as a warning message or to regulate the fluid level. The fluid enters the unit via the lower connection bore and pushes up a float in the tube. The float now shows the level of the fluid in the tank. If the level of fluid drops again, the float activates a switching contact.

On type C the circuit is then closed and on type O the circuit is then open.

The special dual switching model (type W) offers two possibilities. It can either be used to close on contact or to open on contact.

FUNCTION OF THE TSE

The FLUTEC TSE is a very useful additional option to the FSA and FSK products. However, it also has a useful application as a separate build-on unit on systems.

The temperature sensor of the TSE, when fitted, is surrounded by operating fluid. When the nominal temperature is reached, a contact opens and the circuit is broken.

This switching process can be used either as a warning message or to monitor the temperature.

When the temperature of the fluid drops by approx. 20K, the circuit closes again.

1.3. APPLICATION

FLUTEC fluid level gauges FSA, fluid level sensors FSK and temperature switches TSE are used to monitor and control levels of operating fluid.

Areas of application are for example:

Machine tools, system engineering, hydraulic oil, lubricating oil and cutting oil tanks as well as gearboxes.

1.4. NOTES

The upper viscosity limit is 2,000 mm²/s.

It is not possible to combine a temperature switch TSE with an FT temperature gauge.


FSA/FSK

Not suitable for use with glycol or fluids containing glycol.

To ensure correct functioning, pressure, viscosity and temperature specifications must be observed.

FSK

Depending on the fluid level of the tank the following switching logic applies.



In the FSK type O the switching contact opens when the fluid level drops below the switching level. Correspondingly, in the FSK type C, the switching contact closes when the fluid level drops below the switching level.

2. TECHNICAL SPECIFICATIONS


2.1. GENERAL

2.1.1 Designation and symbol

Fluid level gauge FSA



Fluid level sensor FSK



O - N/C contact




C - N/O contact



W - N/O or
N/C contact

Temperature switch TSE



2.1.2 Model code for FSA (also order example)

FSA - 076 - 2 . X / FT200 / 12

Fluid level gauge

Size

≡ centre distance of bolts

076

127

176

254

381

Material of seals

2 = Viton (FKM)

1 = Perbunan (NBR)

Series

(determined by manufacturer)

Additional thermometer function

- = no additional function

T = thermometer in display tube

FT 200 = temperature gauge 200 mm

FT 300 = temperature gauge 300 mm

TSE 60 = temperature switch nominal temperature 60 °C

TSE 70 = temperature switch nominal temperature 70 °C

TSE 80 = temperature switch nominal temperature 80 °C

Mounting

Banjo bolt thread

M 12 (standard)

M 10 (not on TSE)

Model code for FSK (also order example)

FSK - 127 - 2 . X / C / FT200 / 12

Fluid level sensor

Size

≡ centre distance of bolts

127

176

254

381

Material of seals

2 = Viton (FKM)

Series

(determined by manufacturer)

Switching function

O = opens at the switching level

C = closes at the switching level

W = opens or closes at the switching level
(form B plug)

Additional thermometer function

- = no additional function

FT 200 = temperature gauge 200 mm

FT 300 = temperature gauge 300 mm

TSE 60 = temperature switch nominal temperature 60 °C

TSE 70 = temperature switch nominal temperature 70 °C

TSE 80 = temperature switch nominal temperature 80 °C


Mounting

Banjo bolt thread

M 12 (standard)

M 10 (not on TSE)

Model code for TSE
(also order example)



2.1.3 Standard models

Type	Size = centre distance of bolts	Order no. = stock no.	Weight [kg]
FSA-076-1.XI-/12	076	700 000	0.17
FSA-076-2.XI-/12	076	700 002	0.17
FSA-127-1.XI-/12	127	700 036	0.19
FSA-127-2.XI-/12	127	700 038	0.19
FSA-254-1.XI-/12	254	700 072	0.22
FSA-254-2.XI-/12	254	700 074	0.22
FSK-127-2.XI-/12	127	718 030	0.22
FSK-127-2.XI/OI-/12	127	718 031	0.22
FSK-254-2.XI-/12	254	718 050	0.28
FSK-254-2.XI/OI-/12	254	718 051	0.28
TSE-60/X/12	–	703 724	0.11
TSE-70/X/12	–	703 714	0.11
TSE-80/X/12	–	551 481	0.11
FT 200 0 - 100 °C / M12	200	700 154	0.03
FT 300 0 - 100 °C / M12	300	700 155	0.04

2.1.4 Type of construction

The units are designed to be mounted directly on to the operating fluid tank.

2.1.5 Type of connection

FSA / FSK

The unit is mounted using two banjo bolts. The connection bores can either be threaded holes or clearance holes (Ø 13, Ø 11).

TSE

The temperature switch can be fitted to the FSA / FSK in place of the lower banjo bolt.

2.1.6 Mounting position

FSA – vertically on the tank wall

FSK – vertically on the tank wall (connection plug at the bottom of the tank)

TSE – optional

2.1.7 Weight

(See table 2.1.3)

2.1.8 Flow direction

Optional

2.1.9 Ambient temperature

- 20 °C to + 80 °C

2.1.10 Materials

FSA / FSK

- End caps and tube in high quality synthetic material
 - Housing in aluminium
 - Soft seals in Viton (FKM) or Perbunan (NBR)
 - Bolts, nuts and washers in steel (plated)
 - Plug connections in high quality synthetic material (FSK)
- TSE
- Housing with temperature sensor, washer and nut in steel (zinc-plated)
 - Plug connections in high quality synthetic material

2.2. HYDRAULIC DETAILS

2.2.1 Nominal pressure
Max. 1 bar

2.2.2 Operating fluids
Mineral oil to DIN 51524, Part 1 and 2, water-oil emulsions and synthetic fluids, such as hydraulic fluids based on phosphate ester (NOT water glycol).

For other fluids, please contact our technical sales department.

2.2.3 Temperature of operating fluid
- 20 °C to + 80 °C

2.2.4 Scale range of thermometer

FSA / FSK

Thermometer T for FSA:
+ 20 °C to + 80 °C


Thermometer FT for FSA / FSK:
0 °C to + 100 °C

2.3. ELECTRICAL DETAILS OF FSK


2.3.1 Electrical functions

Type O

when fluid is at low level, contact opens
when supplied, contact is open




when fluid is at working level, contact is closed




Terminal 3 is not connected

Type C

when fluid is at low level, contact closes
when supplied, contact is closed



when fluid is at working level, contact is open




Terminal 3 is not connected

Type W / form B plug

Dual switching unit

When supplied, switching points correspond to the diagram below



2.3.2 Contact load
Max. 8 W


2.3.3 Switching voltage
50 V AC / DC

2.3.4 Switching current
0.2 A

2.4. ELECTRICAL DETAILS OF TSE

2.4.1 Electrical function

opens on contact



2.4.2 Switching power
2.5 A/50 V -

10,000 switching operations

0.5 A/50 V -


100,000 switching operations

2.4.3 Minimum switching current
50 mA

2.4.4 Switching tolerance
± 5 K


3. DIMENSIONS

3.1 FLUID LEVEL GAUGE FSA




Size ≡ centre distance of bolts	L0	L1	L2
076	108	34	76
127	159	76	127
176	208	125	176
254	286	203	254
381	413	330	381

3.2 FLUID LEVEL SENSOR FSK



Size ≡ centre distance of bolts	L0	L2
127	201	127
176	250	176
254	328	254
381	455	381


3.3. SCALE RANGE FSA / FSK



3.4. TEMPERATURE SWITCH TSE See FSA with TSE fitted

4. SPARE PARTS

4.1. SEAL KIT



Seal kit	Order no. = stock no.
FSA-076/127-1.X/	704 616
FSA-076/127-2.X/	704 627
FSA-176-1.X/	555 599
FSA-176-2.X/	555 600
FSA-254-1.X/	700 037
FSA-254-2.X/	704 649
FSA-381-1.X/	860 008
FSA-381-2.X/	860 009

5. NOTE

All details in this brochure are subject to technical modifications.

1.1.3.2 Technical data F6100-3 temperature gear oil (equipment list)

FLENDER	Operating Instructions	Edition: March 2002	
	Resistance Thermometer Pt 100	B 6100 EN	
		Page 1 of 5	
<p>General</p> <p>The electric resistance in the resistance thermometer sensor changes as the temperature fluctuates. This change of resistance on the PT 100 or the converted output signal of the measuring transducer (4 to 20 mA) can be used to measure temperature with an evaluating instrument or to define a switch point by means of limit switches.</p> <p>Operation</p> <p>Pt 100 measuring thermometer sensor</p> <p>The electrical conductivity of metal (here platinum) is based on the mobility of conduction electrons. As the temperature rises, the movement of the atoms in the metal lattice about their rest position intensifies and so obstructs the electrons flowing to the plus pole of a power source. This obstruction sets up a resistance in linear proportion to the temperature.</p> <p>To generate the output signal a constant test current (approx. 1 mA) is applied to the Pt 100. The resistance in the Pt 100 causes a drop in voltage ($U = R \cdot I$), which can be evaluated.</p> <p>Measuring transducer</p> <p>The two-wire measuring transducer is mounted in the J-head only if requested by the customer. It should be noted that here only a single connection is possible.</p> <p>The measuring transducer converts the temperature-dependent resistance to a standard uniform signal of 4 to 20 mA. This signal can be transmitted over long distances without interference.</p> <p>Technical Data - Pt 100</p> <ul style="list-style-type: none"> - Type of protection Terminal head: IP 65 - Tolerance class: DIN IEC 60751 Class B (at 0 °C ±0.3 K, at 100 °C ±0.8 K) - Ambient temperature range for J head: -20 °C to +100 °C - Ambient temperature range for protective tube: -50 °C to +200 °C - Test temperature range: -50 °C to +150 °C <p>Material</p> <ul style="list-style-type: none"> - Terminal head: GD-AISI9Cu3 - Protective sleeve for measuring thermometer sensor: 1.4571 - Spring: wire DIN 2076-A-0.8 (stainless steel) - Guide tube: 1.4571 - Terminal base: ceramic - Adapter: 1.4301 - Gasket: NBR (Perbunan) 			
A. Friedr. Flender AG, D 46393 Bocholt, Tel. 02871/92-0, Telefax 02871/922596, http://www.flender.com		Datum 2002-03-26	Name: Hesselmann ENDD
		Rev.:	


Diese technische Unterlage hat gesetzlichen Schutz (DIN 34)

FLENDER	Operating Instructions	Edition: March 2002	
	Resistance Thermometer Pt 100	B 6100 EN	
		Page 2 of 5	
Technical data - Measuring transducer			
- Measuring input:	Pt 100 (DIN EN 60751)		
- Measuring range:	-50 °C to +150 °C		
- Ambient temperature:	-20 °C to +85 °C		
- Terminal type:	two-wire		
- Minimum measuring range:	25 K		
- Maximum measuring range:	1050 K		
- Sensor line resistance with three-wire connection:	≤ 11 Ω per line		
- Sensor line resistance with two-wire connection:	0 Ω per line resistance		
- Sensor current:	≤ 0,5 mA		
- Measuring rate:	continuous measurement, as signal path analog		
Measuring circuit monitoring system			
- Drop below range:	falling to ≤ 3.6 mA		
- Rise over range:	rising to ≥ 22 mA ... < 28 mA (typical 24 mA)		
- Probe short circuit:	≤ 3,6 mA		
- Probe and line break:	positive: ≥ 22 mA ... < 28 mA (typical 24 mA) negative: ≤ 3,6 mA		
Output			
- Output signal:	impressed DC 4 ... 20 mA		
- Transient response:	temperature-linear		
- Transmission accuracy:	≤ ± 0.1 %		
- Attenuation of residual ripple of feed voltage:	40 dB		
- Working resistance (R _b):	$R_B = \frac{U_B - 7.5 V}{22 mA}$		
- Influence of working resistance:	≤ ± 0,02 % / 100 Ω relative to measuring range final value of 20 mA		
- Adjustment time with temperature change:	≤ 10 ms		
- Balancing conditions:	DC 24 V / approx. 22 °C		
- Balancing accuracy:	≤ ± 0.2 % relative to measuring range final value of 20 mA		
Voltage supply			
- Voltage supply (U _b):	DC 7.5 ... 30 V		
- Pole confusion protection:	yes		
- Voltage supply influence:	≤ 0.01 % / V deviation of 24 V relative to measuring range final value of 20 mA		
Environmental influences			
- Operating temperature range:	-40 to +85 °C		
- Temperature influence:	≤ 0.01 % / K deviation of 22 °C relative to measuring range final value of 20 mA		
- Climate resistance:	rel. humidity ≤ 95 % on annual average without dew contact		
- Vibration strength:	acc. to GL characteristic 2		
- EMV:	EN 61326		
Housing			
- Material:	Polycarbonate (encapsulated)		
- Screw connection:	≤ 1.5 mm ²		
- Assembly:	in terminal head Form J		
- Mounting position:	any		
- Weight:	approx. 12 g		
A. Friedr. Flender AG, D 46393 Bocholt, Tel. 02871/92-0, Telefax 02871/922596, http://www.flender.com		Datum 2002-03-26	Name: Hesselmann ENDD Rev.:


Diese technische Unterlage hat gesetzlichen Schutz (DIN 34)

Connection


The customer can minimise measuring inaccuracies by using multiple wires. At Flender, as a rule, a 3- or 4-wire arrangement from an additional terminal box is provided for (Fig. 1, 2). At the customer's specific request, the 3/4-wire arrangement can be used from the J-head (Figure 4, 5). Through lack of space, however, the 4-wire arrangement is possible only with a single connection (Fig. 5).




Resistance thermometer
Fig. 1: 3-wire arrangement from terminal box




Resistance thermometer
Fig. 2: 4-wire arrangement from terminal box



Resistance thermometer
Fig. 3: 2-wire circuit from terminal head of Pt 100



Resistance thermometer
Fig. 4: 3-wire circuit from terminal head of Pt 100



Resistance thermometer
Fig. 5: 4-wire circuit from terminal head of Pt 100

Connection for measuring transducer

Setup	Connection for		Connection values	
		 Voltage supply DC 7.5 ... 30 V Current output 4 ... 20 mA	+1 -2	$R_B = \frac{U_b - 7.5 V}{22 mA}$ $R_B =$ Working resistance $U_b =$ Voltage supply
Analog inputs				
	 Resistance thermometer in two-wire circuit	3 4	series $R_L = 0 \Omega$	

Diese technische Unterlage hat gesetzlichen Schutz (DIN 34)

Types




Fig. 6: Resistance thermometer F 6100-1




Fig. 7: Resistance thermometer F 6100-2




Fig. 8: Resistance thermometer F 6100-3

Diese technische Unterlage hat gesetzlichen Schutz (DIN 34)





Fig. 9: Resistance thermometer F 6100-4

Adjustment by means of sprung screw connection




- a) Insert guide tube "A" into hole in housing until the measuring tip of the resistance thermometer makes contact.
- b) Screw screw connection "B" into the housing as far as it will go.
- c) Pull out screw connection "C" approx. 5 mm towards the terminal head. Then lock nut "D" with screw connection "C". This ensures that the pretensioned spring keeps the measuring tip permanently in contact with the part to be measured.

Diese technische Unterlage hat gesetzlichen Schutz (DIN 34)

1.1.3.3 Technical data level switch (equipment list)

KA 035F/00/a6/11.99 (a)
016757-0000



liquiphant T FTL 260

- d** Füllstandgrenzschalter
- e** Level Limit Switch
- f** Détecteur de niveau
- es** Detector de nivel
- i** Interruttore di livello
- nl** Niveauschakelaar

Endress + Hauser

The Power of Know How



d Inhalt

Sicherheitshinweise	4
Geräte-Identifikation	6
Behandlung	7
Einbaubeispiele	9
Einbau	11
Anschluß	13
Funktion	18
Test	19
Wartung	20
Technische Daten	21
Zubehör, Ersatzteile	23
Ergänzende Dokumentation	24

e Contents

Notes on Safety	4
Device Identification	6
Handling	7
Mounting examples	9
Installation	11
Connection	13
Function	18
Test	19
Maintenance	20
Technical data	21
Accessories, spare parts	23
Supplementary documentation	24

f Sommaire

Conseils de sécurité	4
Dénomination	6
Manipulation	7
Exemples d'implantation	9
Montage	11
Raccordement	13
Fonction	18
Test	19
Maintenance	20
Caractéristiques techniques	21
Accessoires, pièces de rechange	23
Documentation complémentaire	24

Sicherheitshinweise



Achtung!

X = verboten; führt zu fehlerhaftem Betrieb oder Zerstörung.

Notes on Safety



Caution!

X = forbidden; leads to incorrect operation or destruction.

Conseils de sécurité



Attention !

X = interdit - peut provoquer des dysfonctionnements ou la destruction.

es Índice

Nota sobre seguridad	5
Identificación del equipo	6
Modo de empleo	7
Ejemplos de montaje	9
Montaje	11
Conexiones	13
Funcionamiento	18
Comprobación	19
Mantenimiento	20
Datos técnicos	21
Accesorios, repuestos	23
Documentación suplementaria	24

i Índice

Note sulla sicurezza	5
Identificazione dello strumento	6
Accorgimenti	7
Esempi di montaggio	9
Montaggio	11
Collegamenti	13
Funzionamento	18
Test	19
Manutenzione	20
Dati tecnici	21
Accessori, ricambi	23
Documentazione supplementare	24

nl Inhoud

Veiligheidsinstructies	5
Instrument-identificatie	6
Behandeling	7
Inbouwvoorbeelden	9
Inbouw	11
Aansluitingen	13
Functie	18
Test	19
Onderhoud	20
Technische gegevens	21
Toebehoren, reserve-onderdelen	23
Aanvullende documentatie	24

Notas sobre seguridad

¡Atención!
= Prohibido, peligro de mal funcionamiento o de destrucción.

Note sulla sicurezza

Attenzione!
= Vietato, pericolo di malfunzionamento o di distruzione.

Veiligheidsinstructies

Opgelet!
= verboden; leidt tot foutieve werking of storing.

d Sicherheitshinweise

Der Liquiphant FTL 260 darf nur als Füllstandgrenzschalter für Flüssigkeiten in nicht explosionsgefährdeten Bereichen verwendet werden. Bei unsachgemäßem Einsatz können Gefahren von ihm ausgehen. Das Gerät darf **nur von qualifiziertem und autorisiertem Fachpersonal** unter besonderer Beachtung dieser Betriebsanleitung, der einschlägigen Normen, der gesetzlichen Vorschriften und der Zertifikate (je nach Anwendung) eingebaut, angeschlossen, in Betrieb genommen und gewartet werden. In der Gebäudeinstallation ist ein Netzschalter für das Gerät leicht erreichbar in dessen Nähe zu installieren. Der Schalter ist als Trennvorrichtung für das Gerät zu kennzeichnen.

e Notes on Safety

The Liquiphant FTL 260 is a level limit switch designed for use in non-hazardous areas. If used incorrectly it is possible that application-related dangers may arise. The level limit switch Liquiphant FTL 260 may be installed, connected, commissioned, operated and maintained **by qualified and authorised personnel only**, under strict observance of these operating instructions, any relevant standards, legal requirements, and, where appropriate, the certificate. Install an easily accessible power switch in the proximity of the device. Mark the power switch as a disconnect for the device.

f Conseils de sécurité

Le Liquiphant FTL 260 doit être exclusivement utilisé comme détecteur de niveau pour liquides en zones non explosibles. Il peut être source de danger en cas d'utilisation non conforme aux prescriptions. L'appareil ne doit être installé, raccordé, mis en service et maintenu **que par un personnel qualifié et autorisé**, qui tiendra compte des indications contenues dans la présente mise en service, des normes en vigueur et des certificats disponibles (selon l'application). Installer un commutateur réseau à proximité immédiate de l'appareil, en veillant à ce qu'il soit facilement accessible. Marquer ce commutateur comme prise de coupure de l'appareil

es Notas sobre seguridad

El Liquiphant FTL 260 debe emplearse única y exclusivamente como detector de nivel con fluidos en zonas sin peligro de explosión. Su empleo inapropiado puede resultar peligroso. El equipo deberá ser montado, conectado, instalado y mantenido **única y exclusivamente por personal cualificado y autorizado**, bajo rigurosa observación de las presentes instrucciones de servicio, de las normativas y legislaciones vigentes, así como de los certificados (dependiendo de la aplicación).
Instalar un interruptor de fácil acceso en las proximidades del equipo.
Identificar el interruptor como desconector del equipo.


i Note sulla sicurezza

Il Liquiphant FTL 260 può essere utilizzato come sicurezza di troppo pieno, solo in aree sicure.
Un'installazione non corretta può determinare una situazione di pericolo determinata dall'applicazione. Lo strumento deve essere montato, connesso, messo in funzione ed operato **solamente da personale qualificato ed autorizzato**, sotto la stretta osservazione delle presenti norme di installazione e di manutenzione e delle ulteriori norme, regolamenti, disposizioni legali vigenti e, dove richiesto, dei certificati appropriati.
Installare un interuttore per l'alimentazione in prossimità del dispositivo.
Marcare l'interuttore come disconnessione del dispositivo.


nl Veiligheidsinstructies

Gebruik de Liquiphant FTL 260 alléén als niveauschakelaar voor vloeistoffen in niet explosiegevaarlijke gebieden. Het instrument **alleen door gekwalificeerd en geautoriseerd personeel** laten inbouwen, aansluiten, in bedrijf nemen en onderhouden. Neem de instructies in deze Inbedrijfstellingsvoorschriften, de desbetreffende normen, de wettelijke voorschriften en eventuele certificaten in acht. Installeer een makkelijk bereikbare voedingschakelaar in de nabijheid van het instrument. Kenmerk de voedingschakelaar specifiek voor het instrument.

- d** Geräte-Identifikation
- e** Device Identification
- f** Dénomination
- es** Identificación del equipo
- i** Identificazione dello strumento
- nl** Instrument-identificatie



*¹ = ohne / without / sans / sin / senza / zonder



Endress+Hauser

d **Behandlung**

Am Gehäuse anfassen,
nicht an der Schwinggabel

e **Handling**

Hold by the housing,
not by the sensor forks

f **Manipulation**

Tenir par le boîtier,
et **non** par la fourche

es **Modo de empleo**

Coger por el cabezal,
no por las horquillas


i **Accorgimenti**


Afferrare la custodia,
non i rebbi

nl **Behandeling**


De behuizing vastpakken,
niet de trilvork

- d** **Nicht** verbiegen
Nicht kürzen
Nicht verlängern
- e** Do **not** bend
Do **not** shorten
Do **not** lengthen
- f** **Ne pas** tordre
Ne pas raccourcir
Ne pas rallonger
- es** **No** torcer
No acortar
No alargar
- i** **Non** stringere o allargare
Non accorciare o allungare
Non piegare
- nl** **Niet** verbuigen
Niet inkorten
Niet verlengen





Endress+Hauser



- d** Einbaubeispiele
- e** Mounting examples
- f** Exemples d'implantation
- es** Ejemplos de montaje
- i** Esempi di montaggio
- nl** Inbouwvoorbeelden






- d** Schaltpunkt
- e** Switchpoint
- f** Point de commutation
- es** Punto de conmutación
- i** Punto di commutazione
- nl** Schakelpunt



- d** Schalthysterese
- e** Switching hysteresis
- f** Hystérésis
- es** Histerésis de conmutación
- i** Isteresi
- nl** Schakelhysterese

- d** Viskosität und Ansatzbildung berücksichtigen
- e** Take account of viscosity and build-up
- f** Tenir compte de la viscosité et du colmatage
- es** Tener en cuenta la viscosidad y la formación de adherencias
- i** Attenzione alla viscosità e ai depositi
- nl** Houdt rekening met de viscositeit en de vorming van aangroei





d Einbau

Liquiphant einschrauben

e Installation

Screw Liquiphant into process connection

f Montage

Visser le Liquiphant

es Montaje

Atornillar el Liquiphant


i Montaggio



Avvitare il Liquiphant

nl Inbouw

Liquiphant vastschroeven

- d** Schwinggabel ausrichten
Markierung ▼ beachten
- e** Align sensor forks
Note mark ▼
- f** Orienter la fourche
Tenir compte du repère ▼
- es** Orientación de las horquillas
Atención a la marca ▼
- i** Orientare la forcella.
Osservare il contrassegno ▼
- nl** Trilvork uitrichten
Let op de markering ▼





d	Nummer	=	Farbe	
e	Number	=	Colour	
f	Numéro	=	Couleur	
es	Número	=	Color	
i	Numero	=	Colore	
nl	Nummer	=	Kleur	
	1	=	BU	blau, blue, bleu, azul, blu, blauw
	2	=	BK	schwarz, black, noir, negro, nero, zwart
	3	=	BN	braun, brown, brun, marron, marrone, bruin
	 (PE)	=	GNYE	grün/gelb, green/yellow, vert/jaune, verde/amarillo, verde/giallo, groen/geel

d Anschluß

Stecker oder Kabel

e Connection

Plug or cable

f Raccordement

Connecteur ou câble

es Conexiones

Conector o cable


i Collegamenti


Connettore o cavo

nl Aansluiting

Connector of kabel

- d** Spannung beachten
Leitung in Kabeldose
einführen
- e** Note voltage rating
Insert cable into plug housing
- f** Tenir compte de la tension
Insérer le câble dans le
boîtier de raccordement
- es** Observar el voltaje
Introducir los hilos en la caja
de conexiones
- i** Attenzione all'alimentazione.
Inserire il cavo nel vano
conessioni
- nl** Let op de voedingsspanning
Bedrading in connector
invoeren





d Wechselstromvariante anschließen

Max. = Maximum-
Min. = Minimum-
Sicherheitschaltung

e Connection AC version

Max. = max. fail-safe mode
Min. = min. fail-safe mode

f Raccordement variante tension alternative

Max. = sécurité maximum
Min. = sécurité minimum

es Conectar las variantes de corriente alterna

Máx. = Conexión de seguridad máxima
Mín. = Conexión de seguridad mínima

i Collegamento della versione in corrente alternata

Max. = Sicurezza di massimo
Min. = Sicurezza di minimo

nl Wisselstroomvarianten aansluiten

Max. = max. veiligheidsschakeling
Min. = min. veiligheidsschakeling (ruststroomprincipe)

d Gleichstromvariante anschließen

Max. = Maximum-
Min. = Minimum-
Sicherheitschaltung

e Connection DC version

Max. = max. fail-safe mode
Min. = min. fail-safe mode

f Raccordement variante tension continue

Max. = sécurité maximum
Min. = sécurité minimum

es Conectar las variantes de corriente continua


Máx. = Conexión de seguridad máxima
Mín. = Conexión de seguridad mínima


i Collegamento della versione in corrente continua

Max. = Sicurezza di massimo
Min. = Sicurezza di minimo

nl Gelijkstroomvarianten aansluiten

Max. = max. veiligheidsschakeling
Min. = min. veiligheidsschakeling (ruststroomprincipe)





d Kabeldose zusammenbauen und festschrauben

e Assemble plug and screw tight

f Assembler et visser le boîtier de raccordement

es Ensamblar y atornillar las cajas de conexiones

i Montare il vano connessioni avvitandolo a fondo

nl Connector samenbouwen en vastschroeven

d Funktion

Max. und Min. =
Sicherheitsschaltung

e Function

Max. and Min. =
fail-safe mode

f Fonction

Max. et Min. =
commutation de sécurité

es Funcionamiento


Conexión de seguridad
máxima y mínima


i Funzionamento

Sicurezza di massimo e di
minimo

nl Functie

Max. en Min. =
veiligheidsschakeling
(ruststroomprincipe)





- d Test**
mit Prüfmagnet
- e Test**
with test magnet
- f Test**
avec aimant de contrôle
- es Comprobación**
Prueba magnética
- i Test**
Test magnetico
- nl Test**
met testmagneet

d **Wartung**

Dicke Krusten entfernen

e **Maintenance**

Removal of thick encrustation

f **Maintenance**

Enlever les dépôts importants

es **Mantenimiento**



Eliminación de adherencias


i **Manutenzione**

Rimozione di scarsi depositi

nl **Onderhoud**

Aangroei verwijderen





d Technische Daten

Abmessungen in mm
und Werkstoffe

e Technical data

Dimensions in mm
and materials

f Caractéristiques techniques

Dimensions en mm
et matériaux

es Datos técnicos

Dimensiones en mm
y materiales

i Dati tecnici


Dimensioni in mm
e materiali

nl Technische gegevens

Afmetingen in mm
en materialen

- d** Umgebungstemperatur T_U
Betriebstemperatur T_B
Betriebsdruck p_e
- e** Ambient temperature T_U
Operating temperature T_B
Operating pressure p_e
- f** Température ambiante T_U
Température de service T_B
Pression de service p_e
- es** Temperatura ambiente T_U
Temperatura de trabajo T_B
Presión de trabajo p_e
- i** Temperatura ambiente T_U
Temperatura d'esercizio T_B
Pressione d'esercizio p_e
- nl** Omgevingstemperatuur T_U
Procestemperatuur T_B
Procesdruk p_e


$x \text{ } ^\circ\text{C} = (1.8x + 32) \text{ } ^\circ\text{F}$
1 bar = 14.5 psi






E+H 942667-0000

- d** Steckschlüssel SW 41
- e** Socket spanner 41 AF
- f** Clé de 41
- es** Llave de fijación SW 41
- i** Chiave a tubo SW 41
- nl** Pijpsleutel SW 41



E+H 016920-0000

- d** Prüfmagnet
- e** Test magnet
- f** Aimant de contrôle
- es** Imán
- i** Magnete di controllo
- nl** Testmagneet



E+H 003579-0000

- d** Dichtung für G 1 A
- e** Seal for G 1 A
- f** Joint pour G 1 A
- es** Junta para 1" G (G 1 A)
- i** Guarnizione per G 1 A
- nl** Afdichting voor G 1 A

d Zubehör, Ersatzteile

e Accessories, spare parts

f Accessoires
Pièces de rechange

es Accesorios y repuestos

i Accessori e ricambi

nl Toebehoren
Reserve-onderdelen

d **Ergänzende Dokumentation**

e **Supplementary Documentation**

f **Documentation complémentaire**

es **Documentación suplementaria**

i **Documentazione supplementare**

nl **Aanvullende documentatie**

d TI 244F/00/de Technische Information für den Füllstandgrenzscharter Liquiphant T FTL 260

e TI 244F/00/en Technical Information for level limit switch Liquiphant T FTL 260

f TI 244F/14/fr Information technique Détecteur de niveau Liquiphant T FTL 260

es TI 244F/23/es Información técnica sobre el detector límite Liquiphant T FTL 260

i TI 244F/16/it Informazioni Tecniche per l'interruttore di livello Liquiphant T FTL 260

nl TI 244F/15/nl Technische Informatie voor de niveauschakelaar Liquiphant T FTL 260

Endress+Hauser Sales Centers

AT Tel. (01) 88056-0, Fax (01) 88056-35

BE Tel. (02) 2480600, Fax (02) 2480553

CAN Tel. (905) 6819292, Fax (905) 6819444

CH Tel. (061) 7 157575, Fax (061) 7 11 1650

DE Tel. (07621) 97501, Fax (07621) 975555

DK Tel. (70) 131132, Fax (70) 132133

ES Tel. (93) 4803366, Fax (93) 4733839

FI Tel. (0204) 83160, Fax (0204) 83161

FR Tel. (389) 696768, Fax (389) 694802

GB Tel. (0161) 2865000, Fax (0161) 9981841

HK Tel. 25283120, Fax 28654171

IT Tel. (02) 92192-1, Fax (02) 92192-362

JP Tel. (0422) 540613, Fax (0422) 550275

MAL Tel. (03) 7334848, Fax (03) 7338800

NO Tel. (032) 859850, Fax (032) 859851

NL Tel. (035) 6958611, Fax (035) 6958825

SE Tel. (08) 55511600, Fax (08) 55511655

SGP Tel. 5668222, Fax 5666848

THA Tel. (2) 9967811-20, Fax (2) 9967810

USA Tel. (317) 5357138, Fax (317) 5358498

ZA Tel. (011) 2628000, Fax(011) 2628062

INTERNATIONAL Tel. + Fax: see DE

<http://www.endress.com> 05.01/PT



016757-0000


KA 035F/00/a6/11.99 (a), 016757-0000, GW/CV5


1.1.3.4 Technical data ball valve (equipment list)

FLENDER	Operating Instructions	Edition: November 2002	
	Ball valve	B 5102 EN	
	direction-adjustable version	Page 1 of 1	

These Operating Instructions are binding for ball valves (direction-adjustable version) to Flender Works Standard F 5102.

The ball valves are to be mounted without liquid plastic, because there is an appropriate sealing ring on each sealing place. The ball valve can be placed in any position due to the Schott bolting /counter nut combination.





Material:

- Housing : nickel-plated brass
- Ball : chromium-plated brass
- Valve key : galvanized steel with yellow plastic sheathing
- Ball seal : Teflon (PTFE)
- Sealing ring : NBR
- Double nipple : GTW35-V
- Plug : GTW35-V

Operable temperature range:
from -20 °C to max. +170 °C

Nominal width of connection	Pipe thread	LW	Rated pressure PN bar max.									Threaded length	Weight kg approx.
				DN	d ₂	d ₃	h ₁	h ₂	h ₁ ±2	l ₂	l ₃		
6	G 1/4	8	65	28	29	33	50	17	17	12	83	22	0,16
10	G 3/8	10	65	32	29	36	60	19	19	12	85	22	0,17
15	G 1/2	15	65	34	32	39	75	22	23	15	89	27	0,19
20	G 3/4	20	40	44	37	42	80	23	24	17	122	32	0,37
25	G 1	25	40	53	40	48	90	25	26	19,5	122	41	0,58
32	G 1 1/4	32	30	64	56	66	110	27	28	22,5	156	50	0,92
40	G 1 1/2	40	30	80	58	68	120	29	30	24,5	160	55	1,35
50	G 2	50	30	96	67	72	140	32	33	24,5	160	70	2,32

A. Friedr. Flender AG, D 46393 Bocholt, Tel. 02871/92-0, Telefax 02871/922596, http://www.flender.com	Datum 2002-11-08	Name: Hesselmann	QMND
		Rev.:	

Diese technische Unterlage hat gesetzlichen Schutz (DIN 34)

1.1.3.5 Technical data F6100-2 temperature HSS bearings (equipment list)

FLENDER	Operating Instructions	Edition: March 2002	
	Resistance Thermometer Pt 100	B 6100 EN	Page 1 of 5
<p>General</p> <p>The electric resistance in the resistance thermometer sensor changes as the temperature fluctuates. This change of resistance on the PT 100 or the converted output signal of the measuring transducer (4 to 20 mA) can be used to measure temperature with an evaluating instrument or to define a switch point by means of limit switches.</p> <p>Operation</p> <p>Pt 100 measuring thermometer sensor</p> <p>The electrical conductivity of metal (here platinum) is based on the mobility of conduction electrons. As the temperature rises, the movement of the atoms in the metal lattice about their rest position intensifies and so obstructs the electrons flowing to the plus pole of a power source. This obstruction sets up a resistance in linear proportion to the temperature.</p> <p>To generate the output signal a constant test current (approx. 1 mA) is applied to the Pt 100. The resistance in the Pt 100 causes a drop in voltage ($U = R \cdot I$), which can be evaluated.</p> <p>Measuring transducer</p> <p>The two-wire measuring transducer is mounted in the J-head only if requested by the customer. It should be noted that here only a single connection is possible.</p> <p>The measuring transducer converts the temperature-dependent resistance to a standard uniform signal of 4 to 20 mA. This signal can be transmitted over long distances without interference.</p> <p>Technical Data - Pt 100</p> <ul style="list-style-type: none"> - Type of protection Terminal head: IP 65 - Tolerance class: DIN IEC 60751 Class B (at 0 °C ±0.3 K, at 100 °C ±0.8 K) - Ambient temperature range for J head: -20 °C to +100 °C - Ambient temperature range for protective tube: -50 °C to +200 °C - Test temperature range: -50 °C to +150 °C <p>Material</p> <ul style="list-style-type: none"> - Terminal head: GD-AISI9Cu3 - Protective sleeve for measuring thermometer sensor: 1.4571 - Spring: wire DIN 2076-A-0.8 (stainless steel) - Guide tube: 1.4571 - Terminal base: ceramic - Adapter: 1.4301 - Gasket: NBR (Perbunan) 			
A. Friedr. Flender AG, D 46393 Bocholt, Tel. 02871/92-0, Telefax 02871/922596, http://www.flender.com		Datum 2002-03-26	Name: Hesselmann Rev.:
		ENDD	


Diese technische Unterlage hat gesetzlichen Schutz (DIN 34)

FLENDER	Operating Instructions	Edition: March 2002	
	Resistance Thermometer Pt 100	B 6100 EN	
		Page 2 of 5	
Technical data - Measuring transducer			
- Measuring input:		Pt 100 (DIN EN 60751)	
- Measuring range:		-50 °C to +150 °C	
- Ambient temperature:		-20 °C to +85 °C	
- Terminal type:		two-wire	
- Minimum measuring range:		25 K	
- Maximum measuring range:		1050 K	
- Sensor line resistance with three-wire connection:		≤ 11 Ω per line	
- Sensor line resistance with two-wire connection:		0 Ω per line resistance	
- Sensor current:		≤ 0,5 mA	
- Measuring rate:		continuous measurement, as signal path analog	
Measuring circuit monitoring system			
- Drop below range:		falling to ≤ 3.6 mA	
- Rise over range:		rising to ≥ 22 mA ... < 28 mA (typical 24 mA)	
- Probe short circuit:		≤ 3,6 mA	
- Probe and line break:		positive: ≥ 22 mA ... < 28 mA (typical 24 mA) negative: ≤ 3,6 mA	
Output			
- Output signal:		impressed DC 4 ... 20 mA	
- Transient response:		temperature-linear	
- Transmission accuracy:		≤ ± 0.1 %	
- Attenuation of residual ripple of feed voltage:		40 dB	
- Working resistance (R _b):		$R_B = \frac{U_B - 7,5 V}{22 mA}$	
- Influence of working resistance:		≤ ± 0,02 % / 100 Ω relative to measuring range final value of 20 mA	
- Adjustment time with temperature change:		≤ 10 ms	
- Balancing conditions:		DC 24 V / approx. 22 °C	
- Balancing accuracy:		≤ ± 0.2 % relative to measuring range final value of 20 mA	
Voltage supply			
- Voltage supply (U _b):		DC 7.5 ... 30 V	
- Pole confusion protection:		yes	
- Voltage supply influence:		≤ 0.01 % / V deviation of 24 V relative to measuring range final value of 20 mA	
Environmental influences			
- Operating temperature range:		-40 to +85 °C	
- Temperature influence:		≤ 0.01 % / K deviation of 22 °C relative to measuring range final value of 20 mA	
- Climate resistance:		rel. humidity ≤ 95 % on annual average without dew contact	
- Vibration strength:		acc. to GL characteristic 2	
- EMV:		EN 61326	
Housing			
- Material:		Polycarbonate (encapsulated)	
- Screw connection:		≤ 1.5 mm ²	
- Assembly:		in terminal head Form J	
- Mounting position:		any	
- Weight:		approx. 12 g	
A. Friedr. Flender AG, D 46393 Bocholt, Tel. 02871/92-0, Telefax 02871/922596, http://www.flender.com		Datum 2002-03-26	Name: Hesselmann ENDD Rev.:

Diese technische Unterlage hat gesetzlichen Schutz (DIN 34)


Connection

The customer can minimise measuring inaccuracies by using multiple wires. At Flender, as a rule, a 3- or 4-wire arrangement from an additional terminal box is provided for (Fig. 1, 2). At the customer's specific request, the 3/4-wire arrangement can be used from the J-head (Figure 4, 5). Through lack of space, however, the 4-wire arrangement is possible only with a single connection (Fig. 5).




Resistance thermometer

Fig. 1: 3-wire arrangement from terminal box




Resistance thermometer

Fig. 2: 4-wire arrangement from terminal box




Resistance thermometer

Fig. 3: 2-wire circuit from terminal head of Pt 100



Resistance thermometer

Fig. 4: 3-wire circuit from terminal head of Pt 100



Resistance thermometer




Fig. 5: 4-wire circuit from terminal head of Pt 100

Connection for measuring transducer

Setup	Connection for		Connection values	
		Voltage supply DC 7.5 ... 30 V	+1	$R_B = \frac{U_b - 7.5 V}{22 mA}$
	Current output 4 ... 20 mA	-2	$R_B = \text{Working resistance}$ $U_b = \text{Voltage supply}$	
Analog inputs				
	Resistance thermometer in two-wire circuit	3 4	series $R_L = 0 \Omega$	

Diese technische Unterlage hat gesetzlichen Schutz (DIN 34)

Types



Diese technische Unterlage hat gesetzlichen Schutz (DIN 34)

A. Friedr. Flender AG, D 46393 Bocholt,
Tel. 02871/92-0, Telefax 02871/922596, <http://www.flender.com>

Datum
2002-03-26

Name: Hesselmann ENDD
Rev.:





Fig. 9: Resistance thermometer F 6100-4

Adjustment by means of sprung screw connection



- a) Insert guide tube "A" into hole in housing until the measuring tip of the resistance thermometer makes contact.
- b) Screw screw connection "B" into the housing as far as it will go.
- c) Pull out screw connection "C" approx. 5 mm towards the terminal head. Then lock nut "D" with screw connection "C". This ensures that the pretensioned spring keeps the measuring tip permanently in contact with the part to be measured.

Diese technische Unterlage hat gesetzlichen Schutz (DIN 34)

1.1.3.6 Technical data breather filter (equipment list)

FLENDER	Operating Instructions	Edition: May 1995	
	Breather	B 5122 EN	
		Page 1 of 1	

These operating instructions are binding for breathers according to FLENDER works standard W 5122.

Mounting

The thread of the filter has to be coated with sealing compound LOCTITE 572 before screwing it into the female thread.

D	SW	L	K	H	A	F	R	S
R 1/4	22	8	23	35	19	28	8	16.5
R 1/2	22	12	26	38	19	28	10	17
R 3/4	27	14	32	46	25	32	18	23

Material: Stainless steel
Tubes made out of oil-resistant plastics


Temperature resistance: up to 120 °C


Design: Tapered thread acc. to DIN 2999 (Taper 1 : 16)


A. Friedr. Flender AG, D 46393 Bocholt, Tel. 02871/92-0, Telefax 02871/922596, http://www.flender.com	Datum 24.05.1995	Name: Paul	DOA
		Rev.:	

Diese technische Unterlage hat gesetzlichen Schutz (DIN 34)

1.1.3.7 Technical data vane pump (equipment list)



item	part position	denomination	drawing number	unit	quantity
10.	3.4749.010	housing	4749.010	ST	1
20.	3.0380.081	reversing box	2.0380.081	ST	1
30.	SK 4.1175-3	stop pin	SK 4.1175	ST	1
30.10	D1475/010X036-ST	toggle grooved dowel pin -----	DIN 1475	ST	1
40.	D3771/099X003/VI	o-ring	DIN 3771	ST	1
50.	MB1520DU	bearing bush		ST	1
60.	D0908/G3/8-ST	lock screw	DIN 908	ST	1
70.	D7603/018X022-CU	packing ring	DIN 7603	ST	1
80.	3.4749.050	shaft	4749.050	ST	1
90.	D6885/005X005X025	feather key	DIN 6885	ST	1
100.	3.4749.060	rotor	4749.060	ST	1
110.	D1472/005X026-ST	notch pin	DIN 1472	ST	1
120.	4.0130.070	steel vane	4.0130.070	ST	4
130.	4.0030.223	pressure spring	4.0030.223	ST	4
140.	3.4749.090	flange cover	4749.090	ST	1
150.	D0912/008X030-10.9	fillister head cap screw	DIN 912	ST	4
160.	D3760/15X30X10BAUM/V	rotary shaft seal	DIN 3760	ST	1
170.	MB1515DU	bearing bush		ST	1
This technical document is our property. Copying or disclosure to a third party is subject to penalty under civil and criminal law.		denomination: KSW - 3 - flange			
 <p>STOZ PUMPENFABRIK Ettishofer Straße 3 88250 Weingarten</p>	date: 20.03.01	viton-seals			
	drawing-nr.: 4749 / A2	part-nr.: ZB 3.4749	sheet: 1		

item	part position	denomination	drawing number	unit	quantity
40.	D3771/099X003/VI	o-ring	DIN 3771	ST	1
120.	4.0130.070	steel vane	4.0130.070	ST	4
130.	4.0030.223	pressure spring	4.0030.223	ST	4
160.	D3760/15X30X10BAUM/V	rotary shaft seal	DIN 3760	ST	1
<p>This technical document is our property. Copying or disclosure to a third party is subject to penalty under civil and criminal law.</p>  <p>Stozer Pumpenfabrik Ettishofer Straße 3 88250 Weingarten</p>		denomination: wearing part set KSW - 3 - flange viton seals			sheet: 1
date: 20.03.01 drawing-nr.: 4749 / A2		part-nr.: BG 3.4749/001			

Connection:

the suction end is marked „S“
the pipelines must be connected oil and airtight

Direction of flow:

direction of flow remains the same when sense of
rotation is reversed

Design:

self-priming roller vane pump
valveless reversal by means of reversing box

Installation:

„horizontal“ and „vertical, shaft downward“

Erstinbetriebnahme:

Before the pump is started for the first time, it must
be filled with oil.

Herefore a lock screw is wounted at the front face of
the pump.

Maintenance:

Not required as the pump is designed for lubrication
by the liquids to be transportet.

We recommend to change the attrition and seal parts
after a time of 45.000 working hours.

This technical document is our property. Copying or disclosure
to a third party is subject to penalty under civil and criminal law.

Denomination:

short description/operating procedures
KSW - 3 - flange
viton-seals



date: 20.03.01

drawing-nr.: 4749 / A2

part-nr.: ZB 3.4749

sheet: 1

1.1.3.8 Technical data 3/2 way valve (equipment list)

http://www.co-ax.de


COAX data sheet

E4.01-09/2003

coaxial valve
type MK 10 DR



3/2 way valve direct acting
pressure range PN 0-25 bar
orifice DN 10 mm
connection thread
function valve normally closed symbol **NC**
 valve normally open symbol **NO**



design pressure balanced, with spring return, intersecting switch-over
body materials The materials refer to parts in contact with the media
 ① brass ②
 ③ brass, nickel plated ⑤
 ④ ⑥ stainless steel
valve seat synthetic resin on metal
seal materials NBR FPM, CR, EPDM

- details needed:**
- orifice
 - port
 - function NC/NO
 - operating pressure
 - inlet pressure at A, B or C
 - flow rate
 - media
 - media temperature
 - ambient temperature
 - nominal voltage


general specifications		options
ports	MK threads G 1/4 - G 3/4	special threads
function	NC	NO
pressure range	bar 0-16 / 0-25	
	A ↔ B max. 25 / B ↔ A max. 16 / A ↔ C max. 25 / C ↔ A max. 25	
K _v value	m ³ /h 2,6	
vacuum	leak rate	< 10 ⁻⁴ mbar·l/s
pressure-vacuum	P ₁ ↔ P ₂	upon request
back pressure	P ₂ > P ₁ see pressure range	
media	gaseous - liquid - contaminated	
abrasive media		
damping	opening	
	closing	
flow direction	see pressure range	
switching cycles	1/min 200	
switching time	ms opening 40 closing 25	
media temperature	°C DC: -10 to +80	-30 to +120
	AC: -10 to +80	-30 to +120
ambient temperature	°C DC: -10 to +80	
	AC: -10 to +80	
limit switches		
manual override		
approvals		LR/GL/WAZ
mounting		mounting brackets
weight	kg MK 2,2	
additional equipment		upon request

electrical specifications		options
nominal voltage	U _n 24 V DC	special voltages upon request
	U _n 230 V 40-60 Hz AC	special voltages upon request
	U ₁	
	U ₂	
actuation	DC direct-current magnet	
	AC direct-current magnet with integrated rectifier	
insulation rating	H 180°C	
protection	IP65	
energized duty rating	ED 100%	
connection	plug acc. DIN EN 175301-803 form A 4 positions x 90° / wire diameter 6-8 mm	connector M12x1
additional equipment	illuminated plug, with varistor	
current consumption	N-coil 24 V DC 1,00 A	
	230 V 40-60 Hz AC 0,13 A	
	H-coil 24 V DC 1,29 A	
	230 V 40-60 Hz AC 0,16 A	
explosion proof		
limit switches		


■ Specifications not highlighted are standard.
 ■ Specifications highlighted in grey are optional.

müller co-ax ag · Gottfried-Müller-Str. 1 · D-74670 Forchtenberg · Germany · fon +49(0)7947/828-0 · fax +49(0)7947/828-11 · Email info@co-ax.de


type **MK 10 DR**




function: NC
closed when not energized



type **MK 10 DR**





function: NO
open when not energized





The application-specific layout relating to temperature, pressure conditions, switching behavior, media and its consistency may restrict the range of use or necessitate relevant modifications to materials used and seal arrangements.

Rights reserved to make technical alterations • Not responsible for printing errors • Detailed drawings can be obtained upon request

1.1.3.9 Technical data non return valve (equipment list)



scale:	1:1	date:	17.04.01	sheet:	1/1	This technical document is our property. Copying or disclosure to a third party is subject to penalty under civil and criminal law.	
orig-format:	A3	date:	17.04.01	name:			
plot-format:	A3	date:		name:			
 Stoiz Pumpenfabrik 5822 Kuppenferke West Ettihofer Str. 3 88250 Murgarten						description: non return valve size 3 drawing nr: 4753	sheet: 1/1

item	part position	denomination	drawing number	unit	quantity
10.	3.4753.010	housing	4753.010	ST	1
20.	D5401/1, III	ball	DIN 5401	ST	1
30.	3.4753.090	cover	4753.090	ST	1
40.	D0007/006X045	cylinder pin	DIN 7	ST	1
50.	D3771/048X002/VE	O-ring	DIN 3771	ST	1
<p>This technical document is our property. Copying or disclosure to a third party is subject to penalty under civil and criminal law.</p>		<p>denomination: non return valve size 3</p>			
 <p>Etischefer Straße 3</p>		<p>date: 17.04.01</p>	<p>part-nr.: ZB 3.4753</p>	<p>sheet: 1</p>	
		<p>drawing-nr.: 1753 / 23</p>			

Installation:

At any chosen point in the suction line

Installation position:

direction of flow remains the same when sense of rotation is reversed

Maintenance:

Not necessary

This technical document is our property. Copying or disclosure to a third party is subject to penalty under civil and criminal law.

Denomination:

short description/operating procedures
Stoz SUGO non return valve size J

stoz
PUMPENFABRIK
Ettcherhof Straße 3
88250 Weingarten

date: 17.04.01

drawing-nr.: 4753 / A3

part-nr.: 28 3.4753


sheet: 1

1.1.3.10 Technical data coarse filter (equipment list)

FLENDER	Operating Instructions	Edition: May 1995	
		B 5911 EN	
Coarse mesh filters		Page 1 of 2	
<p>These operating instructions are binding for coarse mesh filters according to FLENDER works standard W 5911.</p> <p>Configuration and principle of operation</p> <p>Coarse mesh filters protect load-side systems, units, measurement and control devices from impurities.</p> <p>The coarse mesh filters consist of a housing with threaded connections (1), a strainer (2) and a drain plug (4). The mesh insert itself consists of a coarse-mesh screen with an additional fine-mesh inner screen. The medium flows through the housing, the entrained dirt particles in the line being retained by the mesh insert and collected in the filter bowl.</p> <p>Installation</p> <p>The coarse filters should be installed so that the direction of flow corresponds with the arrow cast on the housing. The filter bowl must be underneath at all times. Sufficient space should be provided for filter cleaning and filter change (see dimension H₂). For vertically running pipes with an upwards flow direction, the coarse mesh filter is exceptionally to be installed with the drain plug pointing upward.</p> <p>Maintenance</p> <p>Check from time to time, whether large quantities of dirt particles have collected which are adversely affecting the volume flow. For this purpose, the drain plug (4) is loosened and the strainer (2) is pulled out after the respective part of the plant has been put out of service. Damaged mesh screens (2) and seal rings (3) must be replaced.</p>			
A. Friedr. Flender AG, D 46393 Bocholt, Tel. 02871/92-0, Telefax 02871/922596, http://www.flender.com		Datum 24.05.1995	Name: Paul Rev.: DOA

Diese technische Unterlage hat gesetzlichen Schutz (DIN 34)

Type 1 NI



- 1. Housing material: brass
- 2. Mesh insert (coarse and fine-mesh screens) material: CrNiMo (1.4401)
- 3. Sealing ring material: graphite with metallic support
- 4. Drain plug material: brass

Connection thread size	G 1/2	G 3/4	G 1	G 1 1/2	G 2
Installation length L	64	74	90	120	150
Overall height H ₁	40	45	84	84	108
Overall height H ₂ (mesh insert withdrawn)	61	75	134	134	158
Mesh size (μm)	250				
Oil rate of flow K _{VS} (m ³ /h)	5.1	9.1	14.3	36.6	57
Screen discharge area (cm ²)	2.5 x cross section of pipe				
Weight (kg)	0.2	0.3	0.47	1.35	1.9
Nominal pressure PN (bar)	25				
Max. medium temperature (°C)	200				

Diese technische Unterlage hat gesetzlichen Schutz (DIN 34)

Operating Instructions

B 5911 EN 02.08

Coarse filter



FLENDER

A. Friedr. Flender AG • D-46393 Bocholt • Tel. 02871/92-0 • Telefax 02871/92-2596 • www.flender.com

FLENDER

Contents

1.	General	3
1.1	Proper use	3
2.	Warnings and symbols used in these Operating Instructions	4
3.	Safety instructions	4
4.	Fitting	5
5.	Types and technical data	6
5.1	Type 1 NI	6
6.	Maintenance	7
6.1	Environmental protection	7

FLENDER

1. General


These Operating Instructions are binding for coarse filters according to FLENDER standard F 5911.

Caution!

Installation and start-up must be carried out by properly trained specialist personnel. Please read these operating instructions carefully before starting up. We accept no liability for personal injury or damage due to incorrect handling.

The coarse filters can be used for mineral oil, synthetic oil and water.

Coarse filters comprise a housing with threaded connections (1), a filter element (2) and a drain plug (4) with a seal (3). The filter element consists of a bearer filter element with an additional fine-mesh inner filter element. The medium flows through the housing, the dirt particles carried in the line being retained by the filter element and collected in the filter basket.



- | | | | |
|---|-----------------------------------|---|------------|
| 1 | Housing with threaded connections | 3 | Seal |
| 2 | Filter element | 4 | Drain plug |

1.1 Proper use

Coarse filters filter only coarse dirt particles from the fluid flow, preventing spray nozzles, conduits and lines from becoming blocked. Similarly, systems, units and measuring and regulating equipment are protected against contamination.

Note: Any use other than that specified here is regarded as incorrect.

FLENDER

2. Warnings and symbols used in these Operating Instructions



This symbol indicates safety measures which must be observed to avoid **personal injury**.

Caution!

This symbol refers to safety measures which must be observed to avoid **damage to the oil-supply system and gear unit**.

Note:

This symbol indicates general **operating instructions** which are of particular importance.

3. Safety instructions

Caution!

Installation and start-up must be carried out by properly trained specialist personnel. Please read these operating instructions carefully before starting up. We accept no liability for personal injury or damage due to incorrect handling.



**During operation the coarse filter is under pressure!
Work should be done on the coarse filter only when it is in a pressure-free condition.**



Before work is carried out on the coarse filter or the system, the system must be taken out of operation!



**Failure to observe the safety instructions may lead to serious injury from escaping hot operating media!
When working on the coarse filter, personal safety equipment (safety gloves and safety glasses) must be worn!**

FLENDER


4. Fitting

Caution!

Installation and start-up must be carried out by properly trained specialist personnel. Please read these operating instructions carefully before starting up. We accept no liability for personal injury or damage due to incorrect handling.

Coarse filters must be fitted so that the direction of flow corresponds to the arrow on the housing. The filter basket must always point downwards. Sufficient fitting space must be provided for cleaning or changing the filter element (see dimension H₂ in section 5.1).

Exceptionally, in the case of perpendicular lines with an upward flow the coarse filter must be fitted with the drain plug pointing upwards.



- | | | | |
|---|-----------------------------------|---|------------|
| 1 | Housing with threaded connections | 3 | Seal |
| 2 | Filter element | 4 | Drain plug |

Caution!

The threads, sealing surfaces and any gaskets or O-ring seals must not be damaged!

Caution!

The coarse filter must be allowed to heat up above 200 °C!



Remove any oil spillage immediately with an oil-binding agent. Oil leaks occurring during filling must be stopped immediately! The local environmental protection requirements of the country concerned must be observed.




Failure to observe the safety instructions may lead to serious injury from escaping hot operating media! When working on the coarse filter, personal safety equipment (safety gloves and safety glasses) must be worn!

FLENDER

5. Types and technical data

5.1 Type 1 NI



Connection size	G in inches	G 1/2	G 3/4	G 1	G 1 1/2	G 2
Overall length	L	65	75	90	120	150
Threaded length	Lg	11+1	12+1	14+1	18+1	20+1
Overall height	H ₁	40	45	56	84	108
Overall height with filter element extended	H ₂	61	75	90	134	158
Mesh opening	µm	250				
Flow rate	K _{vs} (m ³ /h)	5.1	9.1	14.3	36.6	57
Free filter surface	cm ²	approx. 2.5 x pipe cross-section				
Weight	kg	0.2	0.3	0.47	1.35	1.9

FLENDER

6. Maintenance



**During operation the coarse filter is under pressure!
Work should be done on the coarse filter only when it is in a pressure-free condition.**




Before work is carried out on the coarse filter or the system, the system must be taken out of operation!

Note: Appropriate measures must be taken to prevent the lines from emptying!

After regular maintenance work has been carried out, coarse filters must be checked for contamination which could impair the flow of medium and, if necessary, cleaned with benzine or compressed air. For this, the system part affected must first be taken out of operation, then the drain plug (4) undone and the filter element (2) pulled out. Damaged filter elements (2) and seals (3) must be replaced.



**Failure to observe the safety instructions may lead to serious injury from escaping hot operating media!
When working on the coarse filter, personal safety equipment (safety gloves and safety glasses) must be worn!**



- | | | | |
|---|-----------------------------------|---|------------|
| 1 | Housing with threaded connections | 3 | Seal |
| 2 | Filter element | 4 | Drain plug |

6.1 Environmental protection


- Any oil escaping while the oil is being changed or work is being done on the coarse filter must be caught in suitable receptacles. Any spillage of oil must be removed immediately.
- Used oil, preservative agent, oil-binding agents and oil-soaked cloths must be disposed of in accordance with environmental legislation.
- When changing oil, take care to prevent scalding by hot oil.



**Remove any oil spillage immediately with an oil-binding agent.
Oil leaks occurring during filling must be stopped immediately!
The local environmental protection requirements of the country concerned must be observed.**

1.1.3.11 Technical data shrink disk HSD 420-81 (equipment list)

STÜWE Frictional Connections	Mounting and Removal Instructions for Shrink Discs of Type HSD	HSD	
		Ausgabe 10/01 EDITION	Page 1



Mounting

The shrink discs are supplied ready to be installed. Therefore they should not be dismantled prior to employing the unit for the first time.

1. Degrease shaft and hub bore.
2. Push shrink disc on hub. The outer surface of the hub may be greased in the area of the shrink disc fit.

CAUTION !

Do not tighten the tightening bolts before attaching the shaft.

3. Mount hub on the shaft.
4. Tighten all tightening bolts uniformly, one by one, over several revolutions until the outer ring and inner ring are in line and the full tightening torque is reached.

Demounting

1. Loosen all locking bolts uniformly one by one, initially not more than a quarter turn per bolt, until it is observed that the outer ring has released from the inner ring.

CAUTION !

Under no circumstances should the locking bolts be completely removed as this could be dangerous and result in injury.

2. Should the outer ring not self release from the inner ring, this can be assisted by removing those locking bolts adjacent to the tapped holes provided for jacking purposes and screwing them into these tapped holes. The jacking procedure must continue until release of the outer ring is achieved.
3. Dismount shaft or draw off hub. Remove rust which may have formed on the shaft in front of the hub.
4. Remove shrink disc from hub.

Cleaning and greasing

Dismantled shrink discs do not have to be taken apart and regreased before remounting. The shrink disc has to be cleaned and regreased only if employed in dirty environment. Use a solid lubricant with a coefficient of friction of $\mu = 0,04$ for the conical surfaces as well as bolts.

Example:

Molykote 321 R Dow Corning	spray (varnish)
Molykote G Rapid Dow Corning	spray or paste
Molykote Spray Dow Corning	Spray (powder)
Aemasol MO 19 P A.C.Matthes	spray or paste
Unimoly P5 Klüber Lubric.	powder

Subject to modification

STÜWE
GmbH & Co. KG

Postfach 800557
D-45505 Hattingen

☎ (02324) *394-0
Telefax (02324) 39430

1.2 Assembly and operation instructions



Notes and symbols in these assembly and operating instructions



WARNING! Imminent personal injury!

The information indicated by this symbol is given to prevent **personal injury**.



WARNING! Imminent damage to the product!

The information indicated by this symbol is given to prevent **damage to the product**.



WARNING! Hot surfaces!


The information indicated by this symbol is given to prevent **risk of burns due to hot surfaces** and must always be observed.




NOTE!

The information indicated by this symbol must be treated as **general operating information**.

Earth connection point:		Air relief point:		yellow
Oil filling point:		Oil drain point:		white
Oil level:		Oil level:		red
Lubrication point:		Apply grease:		
Lifting eye:		Eye bolt:		
Do not unscrew:		Connection for vibration monitoring device:		
Alignment surfaces:				
Horizontal:		Vertical:		



These symbols indicate the oil-level checking procedure using the oil dipstick.



These symbols indicate that the oil dipstick must always be firmly screwed in.

Note:

The term "Assembly and operating instructions" will in the following also be shortened to "instructions" or "manual".

Contents

1.	Technical data	5
1.1	General technical data	5
2.	General notes	5
2.1	Introduction	5
2.2	Copyright	5
3.	Safety instructions	6
3.1	Proper use	6
3.2	Obligations of the user	6
3.3	Environmental protection	7
3.4	Special dangers and personal protective equipment	7
4.	Transport and storage	8
4.1	Scope of supply	8
4.2	Transport	8
4.3	Storing the gear unit	9
4.4	Standard coating and preservation	9
5.	Technical description	10
5.1	General description	10
5.2	Housing	10
5.3	Shaft seal	10
5.4	Oil supply to the gear unit	10
6.	Fitting	11
6.1	General information on fitting	11
6.2	Foundation	11
6.3	Description of installation work	11
6.3.1	Unpacking	11
6.3.2	Removing corrosion-preventive agent	12
6.3.3	Fitting coupling elements	12
6.3.4	Fitting the gear unit	13
6.3.5	Gear unit with oil-supply system	13
6.3.6	Gear unit with heating element	13
6.3.7	Gear units with flow heater	13
6.3.8	Gear unit with oil-level monitoring	13
6.3.9	Final work	13
6.4	Fastening bolts	14
6.4.1	Tightening procedure	14
6.4.2	Fastening bolts without specified tightening torque	14
7.	Start-up	15
7.1	Procedure before start-up	15
7.1.1	Gear unit with oil-supply system	15
7.1.2	Filling with lubricant	15
7.2	Start-up	16
7.2.1	Gear unit with oil-supply system	16
7.3	Checks during start-up	16
8.	Operation	16
8.1	Working values	16
8.2	Removal from service	16



9.	Faults	17
9.1	General	17
9.2	Possible faults	17
10.	Maintenance and repair	18
10.1	General	18
10.2	Service schedule	18
10.3	Maintenance schedule for gear unit	18
10.4	Change oil	19
10.5	Check oil filter	19
10.6	Cleaning the air filter	19
10.7	Fastening bolts	19
10.8	Oil-supply system	19
10.9	Oil level / refill oil	20
10.10	General inspection of the gear unit	20
10.11	Checking hose lines	20
10.12	Lubricants	20
11.	Spare parts, customer-service addresses	20
11.1	Stocking spare parts	20
11.2	Contact	20
12.	Declaration by the manufacturer, declaration of incorporation	21

1. Technical data

1.1 General technical data

The most important technical data (such as ident no., type, size, output data, speeds, lubricants) are shown on the rating plate. Refer to the separate data sheet "Technical data" for further details.

These data and the contractual agreements between Winergy and the customer for the gear unit determine the limits of its correct use.

2. General notes

2.1 Introduction

The present manual is an essential component of the gear unit delivery and the technical documentation and must always be kept safe in the vicinity of the gear unit.



All persons carrying out work on the gear unit must have read and understood these instructions and must adhere to them. Winergy accepts no responsibility for damage or disruption caused by disregard of these instructions.

The "**Winergy gear unit**" dealt with in these instructions has been developed for driving electricity generators in wind-energy conversion systems.

The gear unit is designed only for the application specified in section 1, "Technical data".

The gear unit described in these operating instructions reflects the state of technical development at the time these instructions went to print.

In the interest of technical progress we reserve the right to make changes to the individual assemblies and accessories which we regard as necessary to preserve their essential characteristics and improve their efficiency and safety.

2.2 Copyright

The copyright to these instructions is held by **Winergy AG**.

These instructions must not be wholly or partly reproduced for competitive purposes, used in any unauthorised way or made available to third parties without our agreement.

Technical enquiries should be addressed to the following works or to one of our customer services:

Winergy AG
Am Industriepark 2
D - 46562 Voerde-Friedrichsfeld

Tel.: +49 (0) 2871 / 92 0
Fax: +49 (0) 2871 / 92 2487
Internet: www.winergy-ag.com

3. Safety instructions

3.1 Proper use

- The gear unit has been manufactured in accordance with the state of the art and is delivered in a condition for safe and reliable use.
- The gear unit must be used and operated strictly in accordance with the conditions laid down in the contract governing performance and supply agreed by Winergy and the customer.



**Entry to the gear unit is not permitted during operation!
Entry for maintenance and repair work is only permitted when the gear unit is at a stillstand!
Caution! Danger of dropping!**



Any changes on the part of the user are not permitted. This applies equally to safety features designed to prevent accidental contact.

3.2 Obligations of the user

- The operator must ensure that everyone carrying out work on the gear unit has read and understood these instructions and is adhering to them in every point in order to:
 - avoid injury or damage.
 - ensure the safety and reliability of the unit.
 - avoid disruptions and environmental damage through incorrect use.
- During transport, assembly, installation, dismantling, operation and maintenance of the unit, the relevant safety and environmental regulations must be complied with at all times.
- The gear unit must be operated, maintained and/or repaired only by authorised, properly trained and qualified personnel.
- The outside of the gear unit must not be cleaned with high-pressure cleaning equipment.
- All work must be carried out with great care and with due regard to safety.



**All work on the gear unit must be carried out only when it is secured to be at a standstill.
The drive unit must be secured against being switched on accidentally (e.g. by locking the key switch or removing the fuses from the power supply). A notice should be attached to the start switch stating clearly that work is in progress.**

- No welding work must be done at all on the drive.
The drives must not be used as an earthing point for welding operations. Toothed parts and bearings may be irreparably damaged by welding.
- A potential equalisation in accordance with the applying regulations and directives must be carried out! If no threaded holes for earth connection are available on the gear unit, other appropriate measures must be taken. This work must always be done by electrotechnical specialists.



If any inexplicable changes are noticed during operation of the gear unit, such as an important increase in temperature or unusual noises, the drive assembly must be switched off immediately.



Rotating and/or movable drive components must be fitted with suitable safeguards to prevent contact.



When the gear unit is incorporated in plant or machinery, the manufacturer of such plant or machinery must ensure that the contents of these instructions are incorporated in his own instructions.

- When removing the safety equipment the fixation means should be stored for later use. Removed safety equipment must be re-installed prior to starting up.
- Notices attached to the gear unit, e.g. rating plate, direction arrows etc., must always be observed. They must be kept free from dirt and paint at all times. Missing plates must be replaced.
- Screws which have been damaged during assembly or disassembly work must be replaced with new ones of the same strength class and type.
- Spare parts should always be obtained from Winergy (refer to section 11, "Spare parts, customer-service addresses").

3.3 Environmental protection

- Dispose of any packing material in accordance with regulations or separate it for recycling.
- When changing oil, the used oil must be collected in suitable containers. Any pools of oil which may have collected should be removed at once with an oil binding agent.
- Preservative agents should be stored separately from used oil.
- Used oil, preservative agents, oil-binding agents and oil-soaked cloths must be disposed of in accordance with environmental legislation.
- Disposal of the gear unit after its useful life:
 - Drain all the operating oil, preservative agent and/or cooling agent from the gear unit and dispose of in accordance with regulations.
 - Depending on national regulations, gear-unit components and/or add-on parts may have to be disposed of or sent for recycling separately.

3.4 Special dangers and personal protective equipment

- Depending on operating conditions, the surface of the gear unit may heat up or cool down to extreme temperatures.



In the case of hot surfaces (> 55 °C) there is a risk of burns!



In the case of cold surfaces (< 0 °C) there is a risk of frost injury (pain, numbness, frostbite)!



During oil changes there is a risk of scalding from escaping oil!



**Small foreign matter such as sand, dust, etc. can get into the cover plates of the rotating parts and be thrown back by these.
Risk of eye injury!**



In addition to any generally prescribed personal safety equipment (such as safety shoes, safety clothing, helmet) handling the gear unit requires wearing **suitable safety gloves** and **suitable safety glasses**!



The gear unit is not suitable for operation in explosion hazard locations. When operating in explosion hazard locations special additional safety procedures must be observed.



Before beginning work on oil-pressure lines and/or electrical systems the following must be ensured:

- pressure lines must not be under pressure
- electrical systems must have been disconnected from the power mains.

4. Transport and storage

Observe the instructions in section 3, "Safety instructions"!

4.1 Scope of supply

The products supplied are listed in the despatch papers. Check immediately on receipt to ensure that all the products listed have actually been delivered. Parts damaged and/or missing parts must be reported to Winergy in writing immediately.



If there is any visible damage, the gear unit must not be put into operation.

4.2 Transport



**When handling these products, use only lifting and handling equipment of sufficient load-bearing capacity!
Observe the notes regarding load distribution on the packing.**

The gear unit is delivered in the fully assembled condition. Additional items (such as shrink disks, couplings, oil cooler, pipes and fittings) can be delivered separately packaged.

Different forms of packaging may be used, depending on the size of the unit and method of transport. Unless otherwise agreed, the packaging complies with the **HPE Packaging Guidelines**.

The symbols marked on the packing must be observed at all times. These have the following meanings:




Fig. 1: Transport symbols



**Transport of the gear unit must be carried out so as to avoid personal damage and damage to the gear unit.
If, for example, the free shaft ends are knocked, this may damage the gear unit. The gear unit must be moved only with the shaft in a horizontal position, as otherwise oil may escape by the labyrinth seals.**



**Use only the eyes provided to attach lifting equipment to the unit.
Handling of the gear unit by attaching it to the piping is not permitted.
The pipework must not be damaged.
Slings equipment must be adequate for the weight of the gear unit.**



For the position of the attachment points, see the gear-unit drawing in the separate "Technical data" data sheet.

4.3 Storing the gear unit

The gear unit must be stored in the position of use in a sheltered place; it must be placed on a vibration-free, dry base and covered over.



When temporarily storing the gear unit and any single components supplied with it, the preservative agent should be left on them. It must not be damaged, otherwise there is a risk of corrosion.



Do not stack gear units on top of one another.



If the gear unit is being stored out of doors, it must be particularly carefully covered, and care must be taken that neither moisture nor foreign material can collect on the unit. Waterlogging should be avoided.



Unless otherwise agreed by contract, the gear units must not be exposed to harmful environmental factors such as chemically aggressive products.

Provision for special environmental conditions during transport (e.g. transport by ship) and intermediate storage (climate, termites, etc.) must be contractually agreed.

4.4 Standard coating and preservation

The gear unit is provided with an interior preservative agent; the free shaft ends are painted for protection.

The characteristics of the external coat depend on the ambient conditions stipulated in the order relating to method of transport and area of application.



Gear units are normally delivered completely ready, with a priming and finish coat.



Ensure that the coat is not damaged!

Any damage may cause failure of the external protective coating and corrosion. Visible damages to the coating must be repaired immediately.

Unless otherwise contractually agreed, the interior preservation is guaranteed for 24 months, and the preservation of the free shaft ends for 36 months, provided that storage is in dry, frostfree sheds.

The period of validity of the guarantee starts on the date of delivery of the gear unit.

The interior protection should be checked in case of protracted intermediate storage (> 6 months). If the corrosion protection is not renewed, the inspection is to be repeated every 3 months.

The exterior protection should be checked in case of protracted intermediate storage (> 12 months). If the external preservation is not renewed, the inspection should be repeated every 6 months.

5. Technical description

Observe the instructions in section 3, "Safety instructions"!

5.1 General description

The Winergy gear unit is normally fitted with the drive train of the wind-energy conversion system slightly inclined (rotor side pointing upward; for mounting position, see separate "Technical data" data sheet). The drive is effected via the rotor shaft (flange or shrink-disk connection), the output via the shaft to the generator.

5.2 Housing

The gear-unit housing comes with the following equipment:

- Lifting eyes (adequately dimensioned for transporting the gear unit)
- Inspection and/or assembly cover (for oil filling and/or inspection)
- Oil sight glass (for oil-level check)
- Oil-draining point (for changing the oil)
- Air filter (for venting)

Colour coding and symbols for identification of venting point, oil inlet, oil level and oil draining:

Air relief point:	yellow		Oil-draining point:	white	
Oil-filling point:	yellow		Lubrication:	red	
Oil level:	red				



For the graphic representation of the gear unit, see the sketch of the gear unit (in the separate "Technical data" data sheet).

5.3 Shaft seal

The gear unit can be provided with contactless labyrinth, gap seals or radial-shaft rings.



The labyrinth or gap seals are effective only in the specified mounting position with the specified oil filling. During transport and assembly the gear units must be moved only with the shaft continually in the horizontal position.

V-rings and/or felt rings protect the labyrinth or gap seals against dirt.

5.4 Oil supply to the gear unit

The oil supply to the various gear-unit components can be secured by means of:

- dip and splash lubrication system.
- pressure lubrication.

Also a combination of both versions is possible.

6. Fitting

Observe the instructions in section 3, "Safety instructions"!

6.1 General information on fitting

When transporting the gear unit observe the notes in section 4, "Transport and storage".

Fitting work must be done with great care by authorised, trained and qualified personnel. The manufacturer cannot be held liable for damage caused by incorrect assembly and installation.

During the planning phase sufficient space must be allowed around the gear unit for later care and maintenance work.

Adequate lifting equipment must be available before beginning the fitting work.



**Use only the eyes provided to attach lifting equipment to the unit.
Handling of the gear unit by attaching it to the piping is not permitted.
The pipework must not be damaged.
Do not use the front threads at the shaft ends to attach slinging equipment for the transport.
Slinging equipment must be adequate for the weight of the gear unit.**

**No welding work must be done at all on the drive.
The drives must not be used as an earthing point for welding operations.
Toothed parts and bearings may be irreparably damaged by welding.**

**All the fastening points provided by the design of the unit must be used.
Screws which have been damaged during assembly or disassembly work must be replaced with new ones of the same strength class and type.**



For the position of the attachment points, see the sketch of the gear unit (in the separate "Technical data" data sheet).

To ensure proper lubrication during operation, the mounting position specified on the drawings must always be observed.

6.2 Foundation

The foundation must be sufficiently stable and distortion-resistant. The foundation must be designed so that reactive forces from the gear unit can be supported and no sympathetic vibrations can occur.

6.3 Description of installation work

6.3.1 Unpacking

The products supplied are listed in the despatch papers. Check immediately on receipt to ensure that all the products listed have actually been delivered. Parts damaged and/or missing parts must be reported to Winergy in writing immediately.

- Remove packaging material and transporting equipment and dispose of in accordance with regulations.
- Perform a visual check for any damage and contamination.



If there is any visible damage, the gear unit must not be put into operation. The instructions in section 4, "Transport and storage", must be observed.

6.3.2 Removing corrosion-preventive agent

- Remove the corrosion-preventive agent from the marked surfaces using a suitable cleaning agent.



For the surfaces treated with preservative agent, refer to the preservation drawing (see the separate "Technical data" data sheet). Other surfaces must not come into contact with the solvent.



The cleaner must not be allowed to come into contact with the shaft-seals.



**Ensure adequate ventilation. Do not smoke!
Danger of explosion.**

Avoid burns when working with corrosive cleaning agents. Always observe the manufacturers' instructions for safety and use.

6.3.3 Fitting coupling elements

- Couplings and/or coupling parts must be fitted with suitable pulling-on devices.



The parts must not be driven on by abrupt force, as this may damage the gear unit.

The shaft-sealing rings and running surfaces of the shaft must not be damaged when pulling in the coupling parts.

When pulling on couplings and/or coupling parts hot, the joining temperature must not exceed 100 °C.



For maintenance and operation of the couplings, refer to the specific operating instructions for the couplings.



**Take precautions to avoid burns from hot components!
Wear suitable protective gloves!**



Protect shaft seals from damage and heating to over + 100 °C (use heat-protective screens to protect against radiant heat).

Flange surfaces can be coated with friction modifier. These surfaces are specified on the dimension drawing (for drawing numbers see the separate "Technical data" data sheet).



**The safety equipment for surfaces with friction modifier must only be removed just before assembly. If this surface is damaged or contaminated with oil and/or grease, always contact Winergy first.
In such cases the gear unit must not be put into operation.**

Depending on the order, the gear unit may be fitted with a shrink disk. Information about this is contained in the separate "Technical data" data sheet and the list of equipment. The fitting dimension of the shrink disk is specified on the dimensioned drawing (see separate "Technical data" data sheet).



Observe the operating instructions to the oil-supply system.

6.3.4 Fitting the gear unit

The gear unit must be so aligned in the wind-energy conversion system that no axial load from the axial thrust of the rotor can act on the gear unit.

For a precise gear mounting position the gear unit input shaft (drive shaft) must be precisely aligned with the rotor shaft. Deformation of the gear unit relative to the rotor shaft and/or the foundation is not permissible in the load-free condition.

For specifications and instructions for aligning the gear unit output shaft (drive shaft) relative to the generator shaft, please refer to the system manufacturer's operating instructions.



If a shrink disk is used, the shrink-disk operating instructions must be observed.

6.3.5 Gear unit with oil-supply system

- Remove the closing sockets of the suction and delivery lines prior to connecting the system.
- Fit the system to the gear unit or install it separately in accordance with the drawings supplied in the gear-unit documentation.



The pipework and flexible hose connections must not be overstressed during the mounting procedure. No additional stresses must occur, even during operation.



Consult operating instructions for oil-supply system.



For technical specification of the oil-supply system, refer to separate "Technical data" data sheet.

6.3.6 Gear unit with heating element

- Connect heating element electrically.

6.3.7 Gear units with flow heater

- Connect the flow heater to the gear unit.

6.3.8 Gear unit with oil-level monitoring

- Connect oil-level monitor electrically.



When filling the gear unit with oil, the oil-level monitor must be checked for correct function!

6.3.9 Final work

- After installation of the gear unit check all screw connections for tight fit.
- Check the alignment after tightening the fastening elements (the alignment must not be changed).
- Check that all the devices which have been demounted for transport reasons have been refitted.
 - To this purpose refer to the details in the separate "Technical data" data sheet and the associated drawings.
- Observe the operating instructions to the add-on parts.
- Check the tightness of the gear-unit.
- Check the opening condition of the stop valves.
 - Oil drain cock **closed**.
 - All other stop valves **open**.

6.4 Fastening bolts

For the tightening-torque values, see the assembly drawing (in the separate "Technical data" data sheet). Observe the tightening procedure detailed in item 6.4.1!

Lightly oiled steel bolts, black-annealed or phosphatised should be used with this gear unit. The mating threads must have dry, cut threads with untreated surface (black phosphatised), not or slightly oiled, of steel or cast iron. Lubricants must not be used, because they may overload the screw connection.

6.4.1 Tightening procedure

One of the following tightening procedures must be applied to fastening bolts with specified tightening torque:

- hydraulic tightening with mechanical screwdriver
- torque-controlled tightening with torque wrench or signal-emitting torque wrench
- Tightening with precision mechanical screwdriver with dynamic torque measuring



Usually the specified tightening processes lie within the stated tool distribution of $\pm 10\%$.
The distribution range must not be exceeded!

6.4.2 Fastening bolts without specified tightening torque



The tightening torques specified in table 1 apply to the generally usual fastening bolts (eg. inspection-hole bolts).
The tool distribution must here be max. 50% of the specified tightening torque.

Table 1: Tightening torques applying to bolts without specified tightening torque

Thread size	Tightening torque per bolt Strength class 8.8 Nm
M 10	34.3
M 12	59
M 16	143
M 20	280
M 24	470
M 30	930
M 36	1600



Damaged bolts must be replaced with new bolts of the same type and strength class.

7. Start-up

Observe the instructions in section 3, "Safety instructions"!

7.1 Procedure before start-up



The gear unit must not be started up if the required instructions are not to hand.

7.1.1 Gear unit with oil-supply system

- Observe the operating instructions for the oil-supply system (see separate "Technical data" data sheet).
- Check the correct function of oil-supply system.

7.1.2 Filling with lubricant



The opening of the lubricant orifice is indicated on the dimensioned drawing (see separate "Technical data" data sheet).



Before the inspection cover and the seal are lifted, dirt and paint particles must be removed to prevent them falling into the interior of the gear unit. Screws and tools must be kept in a safe place before lifting the inspection cover.

- Undo and remove the fastening bolts of the inspection cover, and keep them safe for later use.
- Remove the inspection cover with seal from the housing (seal will be used again).
- Fill the gear unit with cleaned oil (for purity class, see separate "Technical data" data sheet).



If no oil-purity class has been specified, the oil to be filled in should have at least purity class -/14/11 to ISO 4406.

- Record the purity class.



If oil pockets are provided (see separate "Technical data" data sheet) they must be filled with oil. The teeth must also be lubricated with oil.



Remove any oil spillage immediately with an oil-binding agent.



On gear units with add-on flange pump, the flange pump, incl. suction line must be filled with oil by way of the filling screw.

- Check oil level.



The oil level must be checked while the oil is foam-free.



The oil level should be at the top mark of the oil-sight glass during gear-unit standstill.

- Ensure that the gear unit and all the components of the oil-supply system are filled with oil.
- Place the inspection cover and seal on the housing again and thus cover the inspection hole.
- Screw the fastening bolts in and tighten them to the specified torque (for tightening torque, see item 6.4).

7.2 Start-up

- Check the oil level (see item 7.1.2) and, if necessary, top up oil.

7.2.1 Gear unit with oil-supply system

Pre-lubrication phase:

- Prior to start-up, the gear unit should be prelubricated for approx. 3 minutes by means of the oil-supply system.
- During this time, rolling bearings and gear teeth will be adequately supplied with oil for start-up. It must also be ensured that the all the pipings and components are filled with oil.
- Check the opening condition of the stop valves:
 - Oil drain cock **closed**.
 - All other stop valves **open**.

7.3 Checks during start-up

The following visual checks must be conducted during operation:

- Tightness of the oil-supply system.
- Opening condition of the stop valves.
- Leaktightness of the shaft seal on the gear unit.
- Freedom of the rotating parts from contact.
- The gear unit must be checked for leaks before starting it up and leaks must be prevented during operation.
- Leaktightness and oil level must be checked once again no later than 14 days after start-up.

8. Operation

Observe the instructions in section 3, "Safety instructions"!

8.1 Working values

To ensure that the system runs correctly and faultlessly, the operating values must be adhered to (see separate "Technical data" data sheet).

8.2 Removal from service

When the wind-energy conversion system is shut down, the drive train must be allowed to spin freely. For further information on the free-spin operation, refer to the separate "Technical data" data sheet.



Fastening on the generator shaft must be avoided and is not permitted for longer than 1 week. If the system nevertheless has to be fastened, this must preferably be done via the rotor locking system.



Fastening on the generator shaft can cause damage to the tooth flanks in the form of standstill marks.

The following requirements additionally apply to start-up after long periods at a standstill with fastening on the rotor shaft:

Table 2: Procedure before re-start-up

Period	Measures
up to 3 months	none
3 to 12 months	Maintenance instructions in accordance with section 10. Start-up instructions in accordance with section 7.
more than 12 months	Preservation procedure in accordance with section 10. Maintenance instructions in accordance with section 10. Start-up instructions in accordance with section 7.

9. Faults

Observe the instructions in section 3, "Safety instructions", and in section 10, "Maintenance and repair"!

9.1 General

The following irregularities can serve as a guide for fault tracing. Where the system is a complex one, all the other component units must be included when tracing faults. We therefore recommend that, in case of a fault, the manufacturer of the wind-energy conversion system be consulted when tracing possible causes.



Faults occurring within the fault limitation period must be notified to the manufacturer of the wind-energy conversion system.

9.2 Possible faults



To rectify faults, the customer service of the manufacturer of the wind-energy conversion system must be consulted.

Table 3: Faults, causes and remedies

Possible faults	Possible causes	Possible remedy
Noise.	Bearing defective. Teeth defective. Loose add-on parts. Loose gear unit fastening. Pump defective. Coolers defective.	Replace defective bearings. Check teeth for damage and, if necessary, replace. Check fastening of add-on parts and, if necessary, fasten or repair. Check fastening of the gear unit and, if necessary, fasten or repair. Replace defective pump. Replace defective coolers.
Temperatures.	Oil level outside the permitted range. Oil-supply system defective. Bearing defective. Teeth defective. Ambient temperature beyond the permitted range.	Adjust oil level in accordance with section 7. Check oil-supply system and, if necessary, repair. Replace defective bearings. Check teeth for damage and, if necessary, replace. Shut down gear unit (note limit values of permitted temperature).
Leaks.	Oil level outside the permitted range. Oil-supply system leaky. Shaft exit holes leaky. Part joints leaky. Valves and screw plugs leaky.	Adjust oil level in accordance with section 7. Check oil-supply system and, if necessary, repair. Check oil level and, if necessary, adjust in accordance with section 7. Check bolt tightening torques and, if necessary, adjust. (See item 6.4). Inspect valves and, if necessary, reseal.

10. Maintenance and repair

Observe the instructions in section 3, "Safety instructions"

10.1 General



All maintenance and servicing work must be recorded in the separate service schedule specially provided.

10.2 Service schedule

Each gear unit is assigned a separate service schedule. In the interest of further development we reserve the right to make changes to this service schedule.

Complete proof of inspection and maintenance work carried out is essential for fault liability claims.

This service schedule is an essential component of the gear unit delivery and the technical documentation and must always be kept safe in the vicinity of the gear unit.

Inspection and maintenance work must be carried out only by Winergy or by service personnel authorised by Winergy.

On completion of the order the inspection and maintenance work must be confirmed in the service schedule provided. This must be documented with the stamp and signature of the authorised service workshop.

10.3 Maintenance schedule for gear unit

Table 4: Maintenance and repair work

Interval	Measures	Remarks
permanent	Check the oil temperature (oil sump, bearings and, if provided, sensors)	For operating values, see separate "Technical data" data sheet
	Check oil pressure (if pressure lubrication provided)	For operating values, see separate "Technical data" data sheet
14 days after start-up	Check leaktightness	see item 7.3
	Check oil level.	see item 7.1.2
Every 6 months	Check leaktightness	see item 7.3
	Check oil level	see item 7.1.2.
	Check oil filter	see item 10.5
	Cleaning air filter	see item 10.6
	Check gear unit internals	see item 10.10
Every 12 months	Check oil	
	Cleaning air filter	see item 10.6
	Checking hose lines	see item 10.11
Every 2 years	Change oil in case of mineral oil	Oil check yearly. If the necessary oil values (viscosity, ageing, fouling, water content, etc.) are not met, an oil change more frequently than every 2 years is necessary; see item 10.4
Every 3 years	Change oil in case of synthetic oil	Oil check yearly. If the necessary oil values (viscosity, ageing, fouling, water content, etc.) are not met, an oil change more frequently than every 3 years is necessary; see item 10.4

10.4 Change oil



Observe the instructions in item 7.1.2.



When changing the oil, always re-fill the gear unit with the same type of oil. Never mix different types of oil and/or oils made by different manufacturers. Never mix synthetic oils with mineral-based oils or with other synthetic oils. If changing to a different oil grade, please consult Winergy first.



Drain the oil while it the gear unit is still warm, immediately after shutting down the machinery.

When changing the oil, the housing must be thoroughly flushed with oil to remove sludge, metal particles and oil residue. Use the same type of oil as is used for normal operation. High-viscosity oils must be heated beforehand using suitable means. Ensure that all residues have been removed before filling with fresh oil.



There is a danger of scalding from the hot oil emerging from the housing. Wear protective gloves.

- Place a suitable container under the oil-draining point of the gear-unit housing.
- Unscrew oil drain plug or open oil drain cock and drain the oil into the collecting container.
- Drain the oil from the oil-supply system (see operating instructions to the oil-supply system).



Check the condition of the sealing ring (the sealing ring is vulcanised onto the oil drain plug). If necessary, use a new oil drain plug.

- Clean the permanent magnet of the oil-drain plug (if available) thoroughly.
- Screw in the oil drain plug or close oil drain cock again.
- Clean the oil filter in the oil-cooling system (see item 10.5).
- Fill fresh oil into the gear unit (see item 7.1.2).

10.5 Check oil filter



The operating instructions for the respective type of oil filter used must be observed.

10.6 Cleaning the air filter



The operating instructions for the respective type of air filter used must be observed.

10.7 Fastening bolts

- Check tightness of all fastening bolts.



Damaged bolts must be replaced with new bolts of the same type and strength class (for tightening torques, see item 6.4).

10.8 Oil-supply system



Observe the operating instructions of the oil-supply system and its components.

10.9 Oil level / refill oil

Observe item 7.1.2 when checking the oil level and topping up the oil.

10.10 General inspection of the gear unit



Observe the instructions in item 7.1.2.

The visual check of the interior of the gear unit is carried out through the opened inspection cover(s).

10.11 Checking hose lines

Even when adequately stored and subjected to permissible loads, hoses and hose lines are subject to a natural ageing process. This limits their period of use.



The period of use of the hose lines must not exceed 6 years from the manufacturing date stamped on them.

The period of use can be determined using available test and empirical values, taking into account the conditions of use.



The operator of the system must ensure that hose lines are replaced at suitable intervals of time, even if no defects which may affect their safe operation are identifiable on them.

Hose lines must be inspected for safe working condition by an expert before the wind-energy conversion system is first put into operation and thereafter at least once a year.



If during inspections faults are found, these must be rectified immediately or suitable countermeasures taken.

10.12 Lubricants

Only the lubricants specified in the separate "Technical data" data sheet have been approved for the gear unit.

11. Spare parts, customer-service addresses

11.1 Stocking spare parts

To order spare parts, refer to the spare-parts list.

Use only genuine Winergy spare parts as replacement parts.



We guarantee only the original spare parts supplied by us. Non-original spare parts have not been tested or approved by us. They may alter technical characteristics of the gear unit, thereby posing an active or passive risk to safety. Winergy will assume no liability or guarantee for damage caused by spare parts not supplied by Winergy. The same applies to any accessories not supplied by Winergy.

When ordering spare parts, always state the following:

Order No. (see rating plate)
Part number
Quantity

11.2 Contact

Winergy AG
Am Industriepark 2
D - 46562 Voerde - Friedrichsfeld
Internet:

Tel.: +49 (0) 2871 / 92 0
Fax: +49 (0) 2871 / 92 2487
www.winergy-ag.com

12. Declaration by the manufacturer, declaration of incorporation

Declaration by the manufacturer

in accordance with EC Machinery Directive 98/37/EC, Appendix II B

We hereby declare that the components described in these assembly and operating instructions:

Winergy gear unit

are intended for incorporation in a machine, and that it is prohibited to put them into service before verifying that the machine into which they are incorporated complies with the EC Directive (original edition 98/37/EC including any subsequent amendments thereto).

This Declaration by the Manufacturer takes into account all the unified standards (inasmuch as they apply to our products) published by the European Commission in the Official Journal of the European Community.

This Declaration by the manufacturer is valid until 28.12.2009. The new Directive 2006/42/EC takes effect on 29.12.09. At this date this Declaration by the manufacturer will be superseded by the Declaration of incorporation attached as Annex II 1 B to this new directive.



Bocholt, 2009-11-24

Dr. Ralf Martin Dinter (Director Engineering Winergy)

Declaration of Incorporation

in accordance with Directive 2006/42/EC, Annex II 1 B

The manufacturer, A. Friedr. FLENDER AG, D - 46393 Bocholt, declares with regard to the partly completed machinery,

Winergy gear unit

developed for driving electricity generators in wind-energy conversion systems:

- The special technical documents described in Annex VII B have been prepared.
- The following basic health and safety requirements set out in Directive 2006/42/EC, Annex I, are applied and are satisfied:
1.1, 1.1.2, 1.1.3, 1.1.5; 1.2.4.4, 1.2.6; 1.3.1 - 1.3.4, 1.3.6 - 1.3.8.1; 1.4.1, 1.4.2.1
1.5.1 - 1.5.6, 1.5.8 - 1.5.11, 1.5.13, 1.5.15, 1.5.16; 1.6.1 - 1.6.3; 1.7.1, 1.7.1.1, 1.7.2, 1.7.3 - 1.7.4.3
- The partly completed machinery must not be put into service until it has been established that the machinery into which the partly completed machinery is to be incorporated has been declared in conformity with the provisions of Directive 2006/42/EC, as appropriate..
- The manufacturer undertakes, in response to a reasoned request by the national authorities, to transmit in electronic form relevant information about the partly completed machinery.
- The person authorised to compile the relevant technical documentation is:
Dr. Ralf Martin Dinter (Director Engineering Winergy)


This Declaration of incorporation takes effect on 29.12.09. It supersedes the Declaration by the manufacturer made in accordance with Directive 98/37/EC, Appendix II B.

Bocholt, 2009-11-24



Dr. Ralf Martin Dinter (Director Engineering Winergy)

Bocholt, 2009-11-24



Dr. Volker Kreidler (Director Business Segment Wind)