

Part Number	Part Description	Condition
00624-NH1006443-10	NET TORQUE	AS REMOVED
01-0770666-00	HORN	AS REMOVED
01N65900	ELT	AS REMOVED
02311-0208-0001	Electric motor wiper	AS REMOVED
064-50000-0110	VHF DATA RADIO	AS REMOVED
066-50002-8102	TCAS/IVS INDICATOR	AS REMOVED
066-50002-8102	TCAS/IVS INDICATOR	AS REMOVED
07-2450-9-0001	BUS PROTECTION PANEL	AS REMOVED
07294-GF2671	R. F. FILTER	AS REMOVED
09-3421-9-0008	INDICADOR COMPASS	AS REMOVED
10-319647	RIGID HOSE	AS REMOVED
10-319647-1F	IGNITION LEAD	AS REMOVED
10-319648-1 G	RIGID HOSE	AS REMOVED
10-3208-1	VALVULA SELECTORA TRENES	AS REMOVED
10-3257-5	TRANSFORMER RECTIFIER	AS REMOVED
10-33324-11	BUS PROTECTOR PANEL	AS REMOVED
10-333875-4	CAJA EXITADORA	AS REMOVED
10-381175-2	COIL	AS REMOVED
1050-800/375-6	ELEMENT SENSOR FIRE	AS REMOVED
1050-800/375-6	ELEMENT SENSOR FIRE	AS REMOVED
1058V0400-2	VALVULA DE SANGRADO	AS REMOVED
10-60133-5	OVERHEAT	AS REMOVED
10-60133-5	OVERHEAT	AS REMOVED
10-60133-5	OVERHEAT	AS REMOVED
10-60450-1	RELEVO	AS REMOVED
10-60450-1	RELEVO	AS REMOVED
10-60450-1	RELEVO	AS REMOVED
10-60464-8	GEN CONT PANEL	AS REMOVED
10-60464-8	GEN CONT PANEL	AS REMOVED
10-60464-8	GEN CONT PANEL	AS REMOVED
10-60464-8	GEN CONT PANEL	AS REMOVED
10-60479-35	TOMA ELECTRICA	AS REMOVED
10-60506-7	TERMOSTATOS	AS REMOVED
10-60508-1	VALVE CHECK	AS REMOVED
10-60517-46	AFT CONE BOLT	AS REMOVED
10-60517-46	AFT CONE BOLT	AS REMOVED
10-60517-5	ISOLATOR	AS REMOVED
10-60517-53	PERNO BOTELLA	AS REMOVED
10-60517-53	PERNO BOTELLA	AS REMOVED
10-60517-53	PERNO BOTELLA	AS REMOVED
10-60517-53	PERNO BOTELLA	AS REMOVED

Part Number	Part Description	Condition
10-60926	UNIDAD DE POTENCIA ELEVADOR	AS REMOVED
10-60927-2	PRESSURE SWITCH	AS REMOVED
10-60927-2	PRESSURE SWITCH	AS REMOVED
10-61096-125	SONDA PROTECTORA	AS REMOVED
10-61096-125	SONDA PROTECTORA	AS REMOVED
10-61317-15	FLAP POSITION TX	AS REMOVED
10-61329-23	LIGHT PLATE-INTERIOR	AS REMOVED
10-614500-1 G	EXCITER IGNITION	AS REMOVED
10-614500-1 G	EXCITER IGNITION	AS REMOVED
10-61890-4	INDICATOR EGT	AS REMOVED
10-61890-4	INDICATOR EGT	AS REMOVED
10-62047-5	ANGLE OF AIRFLOW SENSOR	AS REMOVED
10-62439-20	FLEXIBLE TUBING	AS REMOVED
106788A144	APU FUEL SHUTOFF VALVE APU	AS REMOVED
10-7000335-F	LEAD IGNITION	AS REMOVED
10-700335-1	IGNITER LEAD	AS REMOVED
10-700335-1F	IGNITION LEAD	AS REMOVED
10-700336-1F	IGNITION LEAD	AS REMOVED
10-939	WHEEL HALF INNER	AS REMOVED
10-939	WHEEL HALF INNER	AS REMOVED
10-939	WHEEL HALF INNER	AS REMOVED
10-939	WHEEL HALF INNER	AS REMOVED
10-940	WHEEL HALF OUTER	AS REMOVED
10-940	WHEEL HALF OUTER	AS REMOVED
10-940	WHEEL HALF OUTER	AS REMOVED
10-940	WHEEL HALF OUTER	AS REMOVED
10DU200AB	CLAMP	AS REMOVED
10DU450T	CLAMP	AS REMOVED
10DU450X	CLAMP	AS REMOVED
10DU-500Y	CLAMP	AS REMOVED
10GY400E	CLAMP	AS REMOVED
11-0444-1	Mounting plate	AS REMOVED
124536-19-1	APU FUEL CONTROL	AS REMOVED
124536-19-1	APU FUEL CONTROL	AS REMOVED
124-838	GEN DRIVE OIL TEMP	AS REMOVED
13636-19-9469-02	BOLT-CONE	AS REMOVED
137847-1	FILTER	AS REMOVED
162BL704N	OIL TEMP INDICATOR	AS REMOVED
162BL704N	OIL TEMP INDICATOR	AS REMOVED
163356-84-01	PERFORMANCE DATA COMPUTER	AS REMOVED
163BL511	IND. PACK TEMPERATURA	AS REMOVED
165W01007-3	PUMP HYDRAULIC	AS REMOVED
1732945-01	FILTER ASSY-APU ENG FUEL	AS REMOVED
175497-01-01	CVR	AS REMOVED
1-8032-9-1	AIR EARCH	AS REMOVED
1825-2800-375-25	SONDA PROTECTORA	AS REMOVED

Part Number	Part Description	Condition
182936	INDICATOR PRESSURE O2	AS REMOVED
1-899-29	PROXIMITY SENSOR	AS REMOVED
1910A	CONTACTEUR TRIPOLAIRE INVERSEUR	AS REMOVED
1963943	CIRCUIT BREAKER	AS REMOVED
1F-464443A7	BASE	AS REMOVED
1U1065-2	COMPENSATOR - ASSY	AS REMOVED
1U1065-2	COMPENSATOR - ASSY	AS REMOVED
1U1065-2	COMPENSATOR - ASSY	AS REMOVED
1U1065-2	COMPENSATOR - ASSY	AS REMOVED
1U1065-2	COMPENSATOR - ASSY	AS REMOVED
1U1065-2	COMPENSATOR - ASSY	AS REMOVED
1U1065-2A	AILERON HYDRAULIC COMPENSATOR CARTRIDGE	AS REMOVED
1U1065-2A	AILERON HYDRAULIC COMPENSATOR CARTRIDGE	AS REMOVED
20086	FLASHER 2 POLE	AS REMOVED
2045-05-01	INDICATOR EPR	AS REMOVED
2054-01-1	ALTIMETER STAND BY	AS REMOVED
2061-12-1	IND FLAPS POSITION	AS REMOVED
2061-12-1	IND FLAPS POSITION	AS REMOVED
2061-12-1	IND FLAPS POSITION	AS REMOVED
2083-08-1	MACH AIR SPEED INDICATOR STAND BY	AS REMOVED
2083-08-1	MACH AIR SPEED INDICATOR STAND BY	AS REMOVED
2087179-0501	ANTENNA	AS REMOVED
2087179-0501	ANTENNA	AS REMOVED
22504-7	ELECTRO NEUMA CONTINU FLOW CON UNIT	AS REMOVED
22890-2	VALVE - LOCK SEQUENCE HYDRAULIC	AS REMOVED
2300-01-1	FUEL QTY INDICATOR	AS REMOVED
2300-07-1	FUE QTY INDICADOR	AS REMOVED
2300-07-1	FUE QTY INDICADOR	AS REMOVED
2300-07-1	FUE QTY INDICADOR	AS REMOVED
2300-07-1	FUE QTY INDICADOR	AS REMOVED
2300-07-1	FUE QTY INDICADOR	AS REMOVED
2-3141-43	SWITCH	AS REMOVED
24376-A1	CONTACTEUR TRIPOLAIRE INVERSEUR	AS REMOVED
2585800-1	YAW DAMPER COUPLER	AS REMOVED
2585800-1	YAW DAMPER COUPLER	AS REMOVED
2585800-1	YAW DAMPER COUPLER	AS REMOVED
2585800-1	YAW DAMPER COUPLER	AS REMOVED
2585800-1	YAW DAMPER COUPLER	AS REMOVED
2585800-1	YAW DAMPER COUPLER	AS REMOVED
2585800-2	YAW DAMPER COUPLER	AS REMOVED
2585800-2	YAW DAMPER COUPLER	AS REMOVED
2585805	RADIO CONTRO CHANNEL	AS REMOVED

Part Number	Part Description	Condition
2586232	SERVO DRIVE	AS REMOVED
2586232	SERVO DRIVE	AS REMOVED
2586232	SERVO DRIVE	AS REMOVED
2586232	SERVO DRIVE	AS REMOVED
2588424-902	RATE OP TURN BACK	AS REMOVED
2588838	POSITION SENSOR	AS REMOVED
2588838	POSITION SENSOR	AS REMOVED
2588838	POSITION SENSOR	AS REMOVED
2588838	POSITION SENSOR	AS REMOVED
2588838	POSITION SENSOR	AS REMOVED
2588838	POSITION SENSOR	AS REMOVED
2588838	POSITION SENSOR	AS REMOVED
2588838	POSITION SENSOR	AS REMOVED
2589210-902	COMPASS SYSTEM RACK	AS REMOVED
2589210-902	COMPASS SYSTEM RACK	AS REMOVED
259-0002-505	COWL ASSY - NOSE	AS REMOVED
2593564-918	ALTITUDE SELECT CONTROLLER	AS REMOVED
2605759A	INNER RING MLG WHEEL	AS REMOVED
2605759D	INNER RIN MLG	AS REMOVED
2605759J	INNER RING MLG WHEEL	AS REMOVED
2605761K	OUTTER RIN MLG	AS REMOVED
2605761K	OUTTER RIN MLG	AS REMOVED
2605761K	OUTTER RIN MLG	AS REMOVED
2605761K	OUTTER RIN MLG	AS REMOVED
2605761K	OUTTER RIN MLG	AS REMOVED
2605761K	OUTTER RIN MLG	AS REMOVED
2607948H	INBOARD WHEEL HALF	AS REMOVED
2608023	WHEEL HALF ASSEMBLY (INBOARD)	AS REMOVED
2608023	WHEEL HALF ASSEMBLY (INBOARD)	AS REMOVED
2608024	WHEEL HALF ASSEMBLY (OUTBOARD)	AS REMOVED
2608024A	WHEEL HALF ASSEMBLY (OUTBOARD)	AS REMOVED
26HB91-15	CONTACTEUR TRIPOLAIRE INVERSEUR	AS REMOVED
2CM9ABH-7	GENERATOR TACHOMETER	AS REMOVED
2CM9ABH-7	GENERATOR TACHOMETER	AS REMOVED
30-0906-1	LIGHT	AS REMOVED
30-0906-1	LIGHT	AS REMOVED
3-1070	NOSE WHEEL ASSY	AS REMOVED
3-1070	NOSE WHEEL ASSY	AS REMOVED
3-1070	NOSE WHEEL ASSY	AS REMOVED
310A1028-8	AFT ENGINE MOUNT HANGER ASSEMBLY	AS REMOVED
310A1041-5	BOLT-CONE (FWD)	AS REMOVED
310A1041-5	BOLT-CONE (FWD)	AS REMOVED
310A1041-5	BOLT-CONE (FWD)	AS REMOVED
310A1041-5	BOLT-CONE (FWD)	AS REMOVED

Part Number	Part Description	Condition
315A1701-110	FAN DUCT COWL AND THRUST-REVERSER ASSY-ENG NO. 1 VAR (THRUST REVERSER ONLY)	AS REMOVED
315A1801-23	ACTUATOR ASSY-LOCKING	AS REMOVED
321404-1-1	VALVE BUTTERFLY	AS REMOVED
321942-1-1	VALVE, ANTI-ICING	AS REMOVED
33921-100	AIR EQUIPMENT	AS REMOVED
35918/56B17	CONECTOR	AS REMOVED
3604524-2	COMB ASSY	AS REMOVED
3605812-14-1	STARTER - ELEC - APU	AS REMOVED
371380	EDP	AS REMOVED
371380	EDP	AS REMOVED
391046-169	GAGE FUEL TANK TRANSM	AS REMOVED
391046-254	TANK UNIT	AS REMOVED
392914-1-1	VALVE	AS REMOVED
393020-003	INDICATOR LIQUID QTY	AS REMOVED
393020-003	INDICATOR LIQUID QTY	AS REMOVED
393020-01789	ENGINE OIL QTY IND	AS REMOVED
393020-01789	ENGINE OIL QTY IND	AS REMOVED
393020-01789	ENGINE OIL QTY IND	AS REMOVED
393020-01789	ENGINE OIL QTY IND	AS REMOVED
393026-071	FUEL QUANTITY INDICATOR	AS REMOVED
393086-01508	FUEL QTY INDICATOR	AS REMOVED
393086-01508	FUEL QTY INDICATOR	AS REMOVED
393086-01508	FUEL QTY INDICATOR	AS REMOVED
398116-1-1	MIXING VALVE	AS REMOVED
398116-1-1	MIXING VALVE	AS REMOVED
398444-2-1	AIR MIXING VALVE	AS REMOVED
40-0070-4	LIGHT ASSEMBLY	AS REMOVED
401-602-71-4	UNIT CONTROL FEEL ELEVATOR	AS REMOVED
4030949-906	AUTOPILOT CONTROL PANEL	AS REMOVED
4030949-906	AUTOPILOT CONTROL PANEL	AS REMOVED
4030949-906	AUTOPILOT CONTROL PANEL	AS REMOVED
4030949-906	AUTOPILOT CONTROL PANEL	AS REMOVED
4030949-906	AUTOPILOT CONTROL PANEL	AS REMOVED
4030949-906	AUTOPILOT CONTROL PANEL	AS REMOVED
4030949-906	AUTOPILOT CONTROL PANEL	AS REMOVED
4030951-901	ROLL CHANNEL	AS REMOVED
4030951-901	ROLL CHANNEL	AS REMOVED
4061400-905	MODE "S" TRANSPONDER	AS REMOVED
4061400-905	MODE "S" TRANSPONDER	AS REMOVED

Part Number	Part Description	Condition
4061400-905	MODE "S" TRANSPONDER	AS REMOVED
4061400-905	MODE "S" TRANSPONDER	AS REMOVED
42-307-1	ANTISKID CONTROL UNIT	AS REMOVED
42-307-1	ANTISKID CONTROL UNIT	AS REMOVED
424244	PUMP	AS REMOVED
42585	CABLE BUJIA	AS REMOVED
436-2	GROUND FAULT DETECTOR UNIT	AS REMOVED
44376	CUP-ALTERNADOR	AS REMOVED
449-205-102	CIRCUIT BREAKER	AS REMOVED
44-9277-01	ENGINE MOUNT	AS REMOVED
473977-1	FIRE EXTINGUISHER (473977-2)	AS REMOVED
473977-1	FIRE EXTINGUISHER (473977-2)	AS REMOVED
48282	BEARING ROLLER	AS REMOVED
48580	FILTER ASSY HIDRÁULIC	AS REMOVED
49-0075-507	NO SE IDENTIFICA	AS REMOVED
491591AI	ASSY	AS REMOVED
5000501-01	1st Stage Compressor, Hub (Disk)	AS REMOVED
5000947-01	Rear Compressor, Shaft	AS REMOVED
5005613-01	13th Stage Compressor, Disk	AS REMOVED
50086-003	CIRCUIT BREAKER	AS REMOVED
50086-003	CIRCUIT BREAKER	AS REMOVED
50086-003	CIRCUIT BREAKER	AS REMOVED
50086-003	CIRCUIT BREAKER	AS REMOVED
50086-003	CIRCUIT BREAKER	AS REMOVED
50086-003	CIRCUIT BREAKER	AS REMOVED
50086-003	CIRCUIT BREAKER	AS REMOVED
50086-003	CIRCUIT BREAKER	AS REMOVED
50086-003	CIRCUIT BREAKER	AS REMOVED
50086-003	CIRCUIT BREAKER	AS REMOVED
50086-003	CIRCUIT BREAKER	AS REMOVED
50086-003	CIRCUIT BREAKER	AS REMOVED
50086-003	CIRCUIT BREAKER	AS REMOVED
50086-003	CIRCUIT BREAKER	AS REMOVED
50086-003	CIRCUIT BREAKER	AS REMOVED
50086-003	CIRCUIT BREAKER	AS REMOVED
50086-003	CIRCUIT BREAKER	AS REMOVED
50086-003	CIRCUIT BREAKER	AS REMOVED
50104-503	SEAT	AS REMOVED
501FAD1-1	AIR DATA COMPUTER	AS REMOVED
5068-10	TRIPOD JACK 50 TON	AS REMOVED
515	CONTACTEUR TRIPOLAIRE INVERSEUR	AS REMOVED
51735-2	FILTER ASSY FLUID	AS REMOVED
522-2450-115	VOR/ILS	AS REMOVED
522-3949-001	COMPARATOR WARNING MONITOR	AS REMOVED

Part Number	Part Description	Condition
522933	SOPORTE	AS REMOVED
52-875-1	Latch actuator	AS REMOVED
540930-3-3	MECHANISM- AIL. SERVO STOP	AS REMOVED
544494-1-1	ACTUADOR	AS REMOVED
565762-6301	PLACA BASE	AS REMOVED
56B17D	TEMPERATURE BULB	AS REMOVED
56B17D	TEMPERATURE BULB	AS REMOVED
56B17D	TEMPERATURE BULB	AS REMOVED
56B17D	TEMPERATURE BULB	AS REMOVED
57186-05	HYD PUMP	AS REMOVED
57727	FILTER ASSY	AS REMOVED
5-89357-34	VIDRIO FRONTAL #4	AS REMOVED
5-89357-34	VIDRIO FRONTAL #4	AS REMOVED
5T400/C17D87	CLAMP	AS REMOVED
602EN195-B	SWICH START	AS REMOVED
60600-5007	LOWER POWER UNIT	AS REMOVED
61-46-1	BALLAST	AS REMOVED
61-47-1	BALLAST -FLUOR	AS REMOVED
61-48-2	BALLAST	AS REMOVED
61-48-2	BALLAST	AS REMOVED
61-48-2	BALLAST	AS REMOVED
614937-101	COMPASS RACK	AS REMOVED
614937-101	COMPASS RACK	AS REMOVED
614937-101	COMPASS RACK	AS REMOVED
614937-101	COMPASS RACK	AS REMOVED
622-3255-005	RECEIVER	AS REMOVED
622-3257-001	VOR RECEIVER	AS REMOVED
622-3257-001	VOR RECEIVER	AS REMOVED
622-7998-013	INDICATOR - ELECT. (EADI)	AS REMOVED
622-7998-013	INDICATOR - ELECT. (EADI)	AS REMOVED
624116-1	RAM AIR CONTROLLER	AS REMOVED
624116-1	RAM AIR CONTROLLER	AS REMOVED
624116-1	RAM AIR CONTROLLER	AS REMOVED
6298A5	EPR	AS REMOVED
6324	Glenair	AS REMOVED
63600-101	LIFE VEST	AS REMOVED
64236-3	ESCAPE SLIDE BOTTLE	AS REMOVED
65-16364-31	NOSE LANDING GEAR	AS REMOVED
65-17809-1	ACTUATOR ASSY CARGO DOOR	AS REMOVED
65-17820-4	ACTUADOR	AS REMOVED
65-17820-4	ACTUADOR	AS REMOVED
65-17823-5	MODULAR PACKAGE ASSY - FLIGHT CONTROL	AS REMOVED
65-17826-8	MODULAR PACKAGE STANDBY	AS REMOVED
65-17830-13	MAIN GEAR ACTUADOR ASSEMBLY	AS REMOVED
65-17978-3	SWIVEL ASSY	AS REMOVED

Part Number	Part Description	Condition
65-17978-3	SWIVEL ASSY	AS REMOVED
65-17979-6	MODULAR UNIT SYSTEM B	AS REMOVED
65-17986-2	SOPORTE DE LÍNEAS HIDRÁULICAS	AS REMOVED
65-19208-14	TRACK	AS REMOVED
65-19208-14	TRACK	AS REMOVED
65-20757-54	PANEL ASSY (INFERIOR SEGUNDO OBSERVADOR)	AS REMOVED
65-20758-51	POWER ASSY LOWER LATERAL LH	AS REMOVED
65-20758-84	PANEL ASSY LOWER RH (BISEL LATERAL WINDOW #3)	AS REMOVED
65-20759-1	AFT CENTER SAILY PANEL 259.5 TO 302	AS REMOVED
65-20774-73	LOWER AFT PANEL LH	AS REMOVED
65-21622-17	CONTROL ASSEMBLY	AS REMOVED
65-21622-34	FITTING	AS REMOVED
65-21634-32	FLAP ASSY - INBOARD AFT RH	AS REMOVED
65-22272-3	DUCT ASSY	AS REMOVED
65-26613-30	INBOARD FLAP TRANSMITION	AS REMOVED
65-26613-30	INBOARD FLAP TRANSMITION	AS REMOVED
65-26761-32	BRAZO COMPUERTA PRINCIPAL	AS REMOVED
65-26762	SOPORT COMPUERTA	AS REMOVED
65-28276-44	PANEL ASSY COVER (CIRCUIT BREAKER)	AS REMOVED
65-39521-10	CONECTOR	AS REMOVED
65-44610-4	ACTUATOR NOSE GEAR	AS REMOVED
65-53204-4	SEGUIDOR DE POLEAS	AS REMOVED
65-58635-18	PANEL UP	AS REMOVED
6562	SHUTOFF FUEL VALVE	AS REMOVED
6562	SHUTOFF FUEL VALVE	AS REMOVED
65-72762-35	ACTUATOR ASSY-SECT. 62 NOSE GEAR HYDRAULIC	AS REMOVED
65-73294-7/A1	RADOME	AS REMOVED
6575	ADAPTER ASSY	AS REMOVED
65-84209-21	AUTO SPEED BRAKE	AS REMOVED
65-88195-1	COLLAR ASSY - NOSE GR STEERING	AS REMOVED
65-98491-1	FLAP POSITION	AS REMOVED
65C26864-3	GROUND SPLR ACTUATOR	AS REMOVED
6752-304-10	CIRCUIT BRAKER	AS REMOVED
6752-304-20	CIRCUIT BREAKER	AS REMOVED
6752-304-20	CIRCUIT BREAKER	AS REMOVED
6752-304-25	CIRCUIT BREAKER	AS REMOVED
6752-304-25	CIRCUIT BREAKER	AS REMOVED
6752-304-25	CIRCUIT BREAKER	AS REMOVED
6752-304-25	CIRCUIT BREAKER	AS REMOVED
6752-304-35	CIRCUIT BREAKER	AS REMOVED
6752-304-35	CIRCUIT BREAKER	AS REMOVED
6752-304-35	CIRCUIT BREAKER	AS REMOVED

Part Number	Part Description	Condition
6752-304-35	CIRCUIT BREAKER	AS REMOVED
6752-304-35	CIRCUIT BREAKER	AS REMOVED
6752-304-50	BREAKERS-CIRCUIT	AS REMOVED
6752-304-50	BREAKERS-CIRCUIT	AS REMOVED
6752-304-50	BREAKERS-CIRCUIT	AS REMOVED
6752-304-7	CIRCUIT BREAKER	AS REMOVED
6752-304-7	CIRCUIT BREAKER	AS REMOVED
6752-311-10	CIRCUIT BREAKER	AS REMOVED
6752-311-40	CIRCUIT BREAKER	AS REMOVED
6752-311-40	CIRCUIT BREAKER	AS REMOVED
68000-5003	CONJUNTO ELEVADOR	AS REMOVED
69-14100-1	BUNGEE ASSY	AS REMOVED
69-14100-1	BUNGEE ASSY	AS REMOVED
69-17270-14	ENGINE PANEL	AS REMOVED
69325A2	LUZ BEACON	AS REMOVED
69-48598-32	AIR CONDITION MODULE	AS REMOVED
698192-4	ASPA DE TURBINA	AS REMOVED
71234	HAND PUMP	AS REMOVED
71234	HAND PUMP	AS REMOVED
714810 AI	VALVE FUEL PRESS & DUMP	AS REMOVED
714810 AI	VALVE FUEL PRESS & DUMP	AS REMOVED
714810 AI	VALVE FUEL PRESS & DUMP	AS REMOVED
7164-0748	BLOWER INSTRUMENTOS	AS REMOVED
724827-2	SAFETY RELIEF VALVE	AS REMOVED
724827-2	SAFETY RELIEF VALVE	AS REMOVED
724827-2	SAFETY RELIEF VALVE	AS REMOVED
724827-2	SAFETY RELIEF VALVE	AS REMOVED
7276-13-7 1/2	CIRCUIT BREAKER	AS REMOVED
7-3141-1	ACTUATOR ASSY	AS REMOVED
7350023	VIBRADOR	AS REMOVED
7500278	FILTER FLUID PRESSURE	AS REMOVED
75130	TRANSFER VALVE	AS REMOVED
7551868	FILTER HYDRAULIC LINE	AS REMOVED
7551868	FILTER HYDRAULIC LINE	AS REMOVED
7551901	FILTER ELEMENT	AS REMOVED
7581418	LINE OIL FILTER	AS REMOVED
7581418	LINE OIL FILTER	AS REMOVED
7581418	LINE OIL FILTER	AS REMOVED
769606-15	FUEL CONTROL	AS REMOVED
772402	2nd Stage Compressor, Disk	AS REMOVED
772510-001	10th Stage Compressor, Disk	AS REMOVED
772803	3rd Stage Compressor, Disk	AS REMOVED
772806	6th Stage Compressor, Disk	AS REMOVED
77445SOCN487238 P	SPARK	AS REMOVED
777603	3rd Stage Turbine, Disk	AS REMOVED
777704	4th Stage Compressor, Disk	AS REMOVED

Part Number	Part Description	Condition
9390150-2	VOLTAGE REGULATOR	AS REMOVED
965-0476-088	GPWS COMPUTER	AS REMOVED
965-0476-088	GPWS COMPUTER	AS REMOVED
976J498-1	AC GENERATOR	AS REMOVED
976J498-1	AC GENERATOR	AS REMOVED
976J498-1	AC GENERATOR	AS REMOVED
976J498-1	AC GENERATOR	AS REMOVED
976J498-1	AC GENERATOR	AS REMOVED
976J498-1	AC GENERATOR	AS REMOVED
976J498-1	AC GENERATOR	AS REMOVED
976J498-1	AC GENERATOR	AS REMOVED
976J498-1	AC GENERATOR	AS REMOVED
976J498-1	AC GENERATOR	AS REMOVED
976J498-1	AC GENERATOR	AS REMOVED
976J498-1	AC GENERATOR	AS REMOVED
976J498-1	AC GENERATOR	AS REMOVED
976J498-1	AC GENERATOR	AS REMOVED
976J498-1	AC GENERATOR	AS REMOVED
976J498-1	AC GENERATOR	AS REMOVED
976J498-1	AC GENERATOR	AS REMOVED
976J498-1	AC GENERATOR	AS REMOVED
976J598-1	AC GENERATOR	AS REMOVED
976J598-1	AC GENERATOR	AS REMOVED
976J598-1	AC GENERATOR	AS REMOVED
980-4100-GQUS	FLIGHT DATA	AS REMOVED
980-4100-GQUS	FLIGHT DATA	AS REMOVED
9844886G1	PUERTO STACTIC	AS REMOVED
9844886G1	PUERTO STACTIC	AS REMOVED
99-1931-9-9004	SWITCH PRESION DE ACEITE	AS REMOVED
99193-698198	AIR gsc	AS REMOVED
A12SA	MEGÁFONO	AS REMOVED
AC-7031H-8KI	FILTER HYDRAULIC AIRCRAFT 3000 P.S.I	AS REMOVED
AC-7031H-8KI	FILTER HYDRAULIC AIRCRAFT 3000 P.S.I	AS REMOVED
AE805300-45	CARTRIDGE FIRE	AS REMOVED
AN737TW-107	CLAMP	AS REMOVED
B0707-10007	OVER SPEED	AS REMOVED
B-102F	GROUND POWER	AS REMOVED
B-102F	GROUND POWER	AS REMOVED
B-102F	GROUND POWER	AS REMOVED
B-102F	GROUND POWER	AS REMOVED
B-102F	GROUND POWER	AS REMOVED
B13-944.42.05.1.EO	CLOCK-AIRCRAFT	AS REMOVED
B18D18	FILTER	AS REMOVED
BAC-0169108	CIRCUIT BREAKER	AS REMOVED
BAC10-61426-9	AIR CYCLE- MACHINES	AS REMOVED
BAC27DCA0467	LIGHT	AS REMOVED

Part Number	Part Description	Condition
BAC-C-18G-701	CIRCUIT BREAKER	AS REMOVED
BAC-C18G-703	CIRCUIT BREAKER	AS REMOVED
BAC-C18G-704	CIRCUIT BREAKER	AS REMOVED
BAC-C18R-10B	CIRCUIT BREAKER	AS REMOVED
BAC-C18R-15B	CIRCUIT BREAKER	AS REMOVED
BAC-C18R-25B	CIRCUIT BREAKER	AS REMOVED
BAC-C18R-25B	CIRCUIT BREAKER	AS REMOVED
BAC-C18R-35D	CIRCUIT BREAKER	AS REMOVED
BAC-C18R-7B	CIRCUIT BREAKER	AS REMOVED
BACC18U-5	CIRCUIT BREAKER	AS REMOVED
BACC18U-7	CIRCUIT BREAKER	AS REMOVED
BACC18W7	CIRCUIT BREAKER	AS REMOVED
BACC18W7	CIRCUIT BREAKER	AS REMOVED
BAC-C18X7	CIRCUIT BREAKER	AS REMOVED
BACC18Z1R	CIRCUIT BREAKER	AS REMOVED
BACC18Z-38	CIRCUIT BREAKER	AS REMOVED
BACC63BN12-3SNH	CONECTOR	AS REMOVED
BACC63BN18-8SN	CINCH	AS REMOVED
BOTIQUIN DE PRIMEROS AUXILIOS	BOTIQUIN DE PRIMEROS AUXILIOS	AS REMOVED
BZ-3YT	MICRO SWITCH	AS REMOVED
C5C	STANDBY COMPASS	AS REMOVED
CCIODU-35OY	CLAMP	AS REMOVED
D6760-17-5	CIRCUIT BREAKER	AS REMOVED
D6760-17-5	CIRCUIT BREAKER	AS REMOVED
D6760-17-7	CIRCUIT BREAKER	AS REMOVED
DH-7BC	CONTACTEUR TRIPOLAIRE INVERSEUR	AS REMOVED
DH-7MN	CONTACTEUR TRIPOLAIRE INVERSEUR	AS REMOVED
DM1601354-001	ATC ANTENNA	AS REMOVED
DMC50-17	VHF COM ANTENNA	AS REMOVED
DOT3AA-1800	BOTELLA DE OXIGENO	AS REMOVED
DOT-3AA-1800	BOTELLA OXIGENO	AS REMOVED
DOT-3AA-1800	BOTELLA OXIGENO	AS REMOVED
DOT-3AA-1800	BOTELLA OXIGENO	AS REMOVED
DOT-3AA-1800	BOTELLA OXIGENO	AS REMOVED
DOT-3AA-2100	BOTTLE OXIGENO PORTATIL	AS REMOVED
DOT-3AA-2100	BOTTLE OXIGENO PORTATIL	AS REMOVED
DOT-3HT-1850	OXIGEN BOTTLE	AS REMOVED
EA1093A-2408-1	TRANSMITTER - QTY IND	AS REMOVED
F61C0058M1	VALVE AIR SHUTOFF	AS REMOVED
F61C0058M1	VALVE AIR SHUTOFF	AS REMOVED
F61C0058M1	VALVE AIR SHUTOFF	AS REMOVED
F61C0058M1	VALVE AIR SHUTOFF	AS REMOVED
F72706	SLING ASSEMBLY- STABILIZER HOISTING	AS REMOVED
G-1162E	Cables engineerring	AS REMOVED

Part Number	Part Description	Condition
G12. 68	AUXILEC	AS REMOVED
G12.68	AUXILEC	AS REMOVED
G-2910	VHF CONTROL PANEL	AS REMOVED
G-2910	VHF CONTROL PANEL	AS REMOVED
G-2910	VHF CONTROL PANEL	AS REMOVED
G-2910	VHF CONTROL PANEL	AS REMOVED
G-2910	VHF CONTROL PANEL	AS REMOVED
G-2910	VHF CONTROL PANEL	AS REMOVED
G-2910	VHF CONTROL PANEL	AS REMOVED
G61111	RELAY	AS REMOVED
G6210-02	AUDIO CONTROL PANEL	AS REMOVED
G6210-02	AUDIO CONTROL PANEL	AS REMOVED
HG480B100	COMPUTER-AIR DATA	AS REMOVED
HG480B100	COMPUTER-AIR DATA	AS REMOVED
ICC-3AA-2100	PORTABLE OXYGEN CYLINDER	AS REMOVED
LM120749-1	RODAMIENTO	AS REMOVED
M-3112-101	SURVIVAL KIT	AS REMOVED
MP-1005	CIRCUIT BREAKER	AS REMOVED
MP-1503	CIRCUIT BREAKER	AS REMOVED
MS 26574-5	CIRCUIT BREAKER	AS REMOVED
MS22073-2	CIRCUIT BREAKER	AS REMOVED
MS25011-2	CIRCUIT BREAKER	AS REMOVED
MS25244-10	CIRCUIT BREAKER	AS REMOVED
MS25383-1	CIRCUIT BREAKER	AS REMOVED
MS28034-1	BULBS, TEMPERATURE, ELECTRICAL RESISTANC	AS REMOVED
MS9-3911-30ZE	MOTOR HYDRAULIC	AS REMOVED
MS9-3911-30ZE	MOTOR HYDRAULIC	AS REMOVED
MVB69282-600	CLAMP	AS REMOVED
N4203S1-1103S	CLAMP	AS REMOVED
NA2110	RODAMIENTO	AS REMOVED
NM102619-0450	BRIDA	AS REMOVED
P0723E105P	LIFE VEST	AS REMOVED
P0723E105P	LIFE VEST	AS REMOVED
P0723E105P	LIFE VEST	AS REMOVED
P0723E105P	LIFE VEST	AS REMOVED
P0723E105P	LIFE VEST	AS REMOVED
P0723E105P	LIFE VEST	AS REMOVED
P0723E105P	LIFE VEST	AS REMOVED
P0723E105P	LIFE VEST	AS REMOVED
P0723E105P	LIFE VEST	AS REMOVED
P0723E105P	LIFE VEST	AS REMOVED
P0723E105P	LIFE VEST	AS REMOVED
PL1058V0400-1	START BLEED CONTROL VALVE	AS REMOVED
R18423-53	BOLT	AS REMOVED
R5303-51	ACTUATOR	AS REMOVED
RE1115-5	RATION PACKAGE	AS REMOVED

Part Number	Part Description	Condition
RE1115-5K	SURVIVAL KIT	AS REMOVED
SOLKAFLAM123	EXTINTOR PORTATIL	AS REMOVED
SOLKAFLAM123	EXTINTOR PORTATIL	AS REMOVED
SOLKAFLAM123	EXTINTOR PORTATIL	AS REMOVED
SOLKAFLAM123	EXTINTOR PORTATIL	AS REMOVED
SOLKAFLAM123	EXTINTOR PORTATIL	AS REMOVED
VAL4141	BASE VALVE	AS REMOVED
W-33-7535-30	AIRCRAFT CLOCK	AS REMOVED
W-33-7535-30	AIRCRAFT CLOCK	AS REMOVED
Y-28918-30-1	AFT ENGINE MOUNT CONE BOLT ASSEMBLY	AS REMOVED
10-61226-15	SENSOR SWITCH	AS REMOVED
321464-5-1	BLEED VALVE	AS REMOVED
321464-5-1	BLEED VALVE	AS REMOVED
321464-5-1	BLEED VALVE	AS REMOVED
123558-1-3	AIR CHECK VALVE	AS REMOVED
123558-1-3	AIR CHECK VALVE	AS REMOVED
2070410-0101	T/R RADAR	AS REMOVED
2070410-0101	T/R RADAR	AS REMOVED
2070410-0101	T/R RADAR	AS REMOVED
MI-585161	T/R RADAR	AS REMOVED
10-3207-1	VALVE ASSEMBLY BREAK METERING	AS REMOVED
162BL701	FUEL TEMP IND.	AS REMOVED
162BL701	FUEL TEMP IND.	AS REMOVED
162BL701	FUEL TEMP IND.	AS REMOVED
700662A	LOAD CONTROLLER	AS REMOVED
700662A	LOAD CONTROLLER	AS REMOVED
8315-G-250-20R	PRESSURE TRANSMITTER	AS REMOVED
8315-G-250-20R	CREW OXYGEN PRESSURE TRANSDUCER	AS REMOVED
8315-G-250-20R	CREW OXYGEN PRESSURE TRANSDUCER	AS REMOVED
8315-G-250-20R	CREW OXYGEN PRESSURE TRANSDUCER	AS REMOVED
A4186910021	ALTIMETER	AS REMOVED
BAC 10-60710-2	VALVE 3-WAY, ELECTRIC MOTOR OPERATED	AS REMOVED
BAC10-60710-2	VALVE 3 WAY ELECTRICAL OPERATE	AS REMOVED
BAC10-60710-2	VALVE 3 WAY ELECTRICAL OPERATE	AS REMOVED
BAC10-60710-2	VALVE 3 WAY ELECTRICAL OPERATE	AS REMOVED
BAC10-60710-2	VALVE 3 WAY ELECTRICAL OPERATE	AS REMOVED
BAC10-60710-2	VALVE 3 WAY ELECTRICAL OPERATE	AS REMOVED
EA1065A-3675	FUEL QUANTITY INDICATOR	AS REMOVED
2586322-1	TURN INDICATOR AMPLIFIER	AS REMOVED
393084-04408	TRNSISTOR	AS REMOVED
10-61826-6	ALTIMETER INDICATOR	AS REMOVED

Part Number	Part Description	Condition
10-61826-6	ALTIMETER INDICATOR	AS REMOVED
65-22819-9	OFFSET LH	AS REMOVED
MA11A1061B	ACTUADOR ELECTRO MECHANISM	AS REMOVED
845601	Fan blade	AS REMOVED
845601	Fan blade	AS REMOVED
845601	Fan blade	AS REMOVED
845601	Fan blade	AS REMOVED
845601	Fan blade	AS REMOVED
845601	Fan blade	AS REMOVED
845601	Fan blade	AS REMOVED
845601	Fan blade	AS REMOVED
845601	Fan blade	AS REMOVED
845601	Fan blade	AS REMOVED
845601	Fan blade	AS REMOVED
845601	Fan blade	AS REMOVED
845601	Fan blade	AS REMOVED
845601	Fan blade	AS REMOVED
845601	Fan blade	AS REMOVED
845601	Fan blade	AS REMOVED
2586220	ELEV POSITION SENSOR	AS REMOVED
001052-101	FLT REC/COMM UNIT	AS REMOVED
1U1065	COMPENSATOR ASSY- CARTRIDGE	AS REMOVED
1U1065	COMPENSATOR ASSY- CARTRIDGE	AS REMOVED
1U1065	COMPENSATOR ASSY- CARTRIDGE	AS REMOVED
1U1065	COMPENSATOR ASSY- CARTRIDGE	AS REMOVED
1U1077	COMPENSATOR ASSY CARTRIDGE	AS REMOVED
522-1660-031	TRANSCIEVER	AS REMOVED
98087-1173T4-1	TERMOSTATO	AS REMOVED
45D16	DIFF PRESSURE SWITCH	AS REMOVED
F61b0132 m1	Fuel Shutt Of Valve	AS REMOVED
F61B0132M1	FUEL SHUTOFF	AS REMOVED
BSXD-1416-D73	TORQUE MOTOR	AS REMOVED
24109	FAN	AS REMOVED
5003534-01D	FAN	AS REMOVED
715469	FAN	AS REMOVED
808240	FAN	AS REMOVED
JF0825S1H	FAN	AS REMOVED
1U1147	VALVE DUAL SOLENOIDE	AS REMOVED
MA1A1062B	ACTUATOR ELECTROMECHANICAL	AS REMOVED
313990	INDUCTION MOTOR AC	AS REMOVED
3932-1AG-1A-1	INDICATOR ELECTRICAL TURN AND SLIP	AS REMOVED
3932-1AG-A1-1	INDICATOR ELECTRICAL TURN AND SLIP	AS REMOVED
3932-1AG-A1-1	INDICATOR ELECTRICAL TURN AND SLIP	AS REMOVED
3932-1AG-A1-1	INDICATOR ELECTRICAL TURN AND SLIP	AS REMOVED

Part Number	Part Description	Condition
3932-1AG-A1-1	INDICATOR ELECTRICAL TURN AND SLIP	AS REMOVED
80GAA	POWER SUPPLY	AS REMOVED
8TJ95GAA1	POWER SUPPLY	AS REMOVED
B914F567-4	POWER RELAY AC	AS REMOVED
106932-1-1	ANTI ICE VALVE	AS REMOVED
162B1-504	INDICATOR TEMP	AS REMOVED
1777518-7	INDICATOR VIB	AS REMOVED
1777518-7	INDICATOR VIB	AS REMOVED
1777518-7	INDICATOR VIB	AS REMOVED
540594-2-1	ACTUADOR ROTARY	AS REMOVED
540742-4-1	ACTUATOR ROTARY	AS REMOVED
540742-4-1	ACTUATOR ROTARY	AS REMOVED
540930-3-1	ACTUATOR ROTARY	AS REMOVED
540930-3-1	ACTUATOR ROTARY	AS REMOVED
65-17819	LOCK ACTUATOR ASSY MAIN GEAR	AS REMOVED
65-17978 3	SWIVEL ASSY	AS REMOVED
714810 I	VALVE FUEL PRESS & DUMP	AS REMOVED
714810-A1	VALVE FUEL PRESS & DUMP	AS REMOVED
ASSY714810-All	VALVE FUEL PRESS & DUMP	AS REMOVED
60857-4	ACCUMULA	AS REMOVED
65-37558-1	ACTUADOR SPOILER	AS REMOVED
123550-1-4	VALVULA CHECK	AS REMOVED
29-1529-101	VALVULA CHECK	AS REMOVED
29-1529-101	VALVULA CHECK	AS REMOVED
548296-1	CONTROL TEMPERATURE	AS REMOVED
548296-1	CONTROL TEMPERATURE	AS REMOVED
526447	FUEL INYECTOR	AS REMOVED
141987-0001	Omega acu model	AS REMOVED
62647	FUEL INYECTOR	AS REMOVED
PROCOLDEXT	EXTINTOR	AS REMOVED
SOLKAFLAM 123	EXTINTOR	AS REMOVED
H10-1015-45	SWITCH ROTARY	AS REMOVED
10-60819-18	FLAP SWITCH	AS REMOVED
40174CHG	FLAP SWITCH	AS REMOVED
10-	OUTER RIN	AS REMOVED
2601056	INNER RIN	AS REMOVED
2601308F	OUTER RIN	AS REMOVED
2605761A	MAIN WHEEL HALF OUTER (2605761)	AS REMOVED
2605761A	MAIN WHEEL HALF OUTER (2605761)	AS REMOVED
98087-1173T10-1	SWITCH TEMPERATURE	AS REMOVED
98087-1173T10-1	SWITCH TEMPERATURE	AS REMOVED
10-60737-8	IND PRESSURE RATIO	AS REMOVED

Part Number	Part Description	Condition
HP-317-A	INDICATOR PRESSURE	AS REMOVED
320270-01-01	OVER SPEED LIMIT SENSOR	AS REMOVED
320315-01-01	OVER SPEED LIMIT SENSOR	AS REMOVED
B0707 10025	OVERSPEED LIMIT SENSOR	AS REMOVED
69-16268-8	HYD PANEL	AS REMOVED
69-16268-8	HYD PANEL	AS REMOVED
SRL-07P	IND, PRESSURE HYD	AS REMOVED
634825	ACTUADOR PUERTA PRINCIPAL	AS REMOVED
522-4280-005	NAVIGATION RECIVER	AS REMOVED
782299	FUEL NOZZLE	AS REMOVED
42637 A	IGNITION UNIT	AS REMOVED
622-3699-001	ADAPTER RCVR-XMTR	AS REMOVED
17823-1	MODULAR PACKAGE ASSY - FLIGHT CONTROL	AS REMOVED
3280-7	FLASHER	AS REMOVED
5500C1A-BF23BA	OXIGEN REGULATOR AND CYLINDER	AS REMOVED
65-17823-32	MODULAR PACKAGE ASSY - FLIGHT CONTROL	AS REMOVED
M22/04-00192F D	POTENCIOMETRO	AS REMOVED
MFR-0AFL4-CHAMPION	AIRPLANE IGNITER	AS REMOVED
MFR-0AFL4-CHAMPION	AIRPLANE IGNITER	AS REMOVED
MFR-0AFL4-CHAMPION	AIRPLANE IGNITER	AS REMOVED
ST-104Y	TRANSMISOR PRESIÓN ACEITE	AS REMOVED
71742	VALVE DISCONNECTED HYDRAULIC SHUTTLE	AS REMOVED
71742	VALVE DISCONNECTED HYDRAULIC SHUTTLE	AS REMOVED
71742	VALVE DISCONNECTED HYDRAULIC SHUTTLE	AS REMOVED
71742-2	VALVE DISCONNECTED HYDRAULIC SHUTTLE	AS REMOVED
435645	RELAY, 10 AMP, 4PDT	AS REMOVED
8195-20	SNUBBER HYDRAULIC GAGE	AS REMOVED
8195-20	SNUBBER HYDRAULIC GAGE	AS REMOVED
10-3223-23	INDICATOR HYD OIL	AS REMOVED
10-3223-31	INDICATOR HYD OIL	AS REMOVED
10-60534-4	INDICATOR HYD OIL	AS REMOVED
3932-1AG-81-1	INDICATOR ELECTRICAL TURN AND SLIP	AS REMOVED
622-3890-006	RADIO ALTIMETER	AS REMOVED
G-5515	COCKPIT SPEAKER	AS REMOVED
59100-50I3	RUDDER CONTROL PACKAGE	AS REMOVED
3194B4	OIL VALVE	AS REMOVED
NP-316-M	OIL PRESSURE INDICATOR	AS REMOVED
258000-2	FUEP BOOSTER PUMP-SELF PRIMING	AS REMOVED
258000-2	FUEP BOOSTER PUMP-SELF PRIMING	AS REMOVED

Part Number	Part Description	Condition
443224A1	TAPA	AS REMOVED
064-1005-01	VHF COMM TRANSCEIVER	AS REMOVED
064-1005-08	KTR 9100A VHF COMM TRANCEIVER	AS REMOVED
10-1376	RIN INTERIOR	AS REMOVED
10-1376	RIN INTERIOR	AS REMOVED
10-1376	RIN INTERIOR	AS REMOVED
10-1376	RIN INTERIOR	AS REMOVED
10-1377	RIN EXTERIOR	AS REMOVED
10-1377	RIN EXTERIOR	AS REMOVED
2605759M	INNER RIN MLG	AS REMOVED
2605759M	INNER RIN MLG	AS REMOVED
2605759M	INNER RIN MLG	AS REMOVED
2605759M	INNER RIN MLG	AS REMOVED
2605759M	INNER RIN MLG	AS REMOVED
2605759M	INNER RIN MLG	AS REMOVED
10-60554-5	INDICATOR HYDRAULIC OIL	AS REMOVED
10-60575-4	LEADING EDGE SHTTLE VALVE	AS REMOVED
152BL702A	EGT INDICATOR	AS REMOVED
152BL706	INDICATOR EXHAUST GAS TEMPERATURE	AS REMOVED
152BL706	INDICATOR EXHAUST GAS TEMPERATURE	AS REMOVED
182938	INDICATOR OXYGEN PRESSURE	AS REMOVED
19912-2C	VERTICAL SPEED INDICATOR	AS REMOVED
231-0092-00	DYNAMOTOR	AS REMOVED
322716-1-1	VALVE SHUTOFF NEUMATIC	AS REMOVED
5073	LEADING EDGE SHTTLE VALVE	AS REMOVED
5073	LEADING EDGE SHTTLE VALVE	AS REMOVED
56024-0034	ACTUATOR ROTARY SERVO	AS REMOVED
65-37827-9	DUCTO RECUBRIMIENTO SALIDA APU	AS REMOVED
LKCC-8031	INDICATOR OIL TEMPERATURE GENERATOR	AS REMOVED
LU529545	DUCTOS AIR COOLER	AS REMOVED
10-60529-10	VALVE FUEL SHUTOFF	AS REMOVED
607096-2	TEMPERATURE SENSOR	AS REMOVED
355048	FUEL FILTER	AS REMOVED
2586220	ELEV POSITION SENSOR	AS REMOVED
0AFL4-CHAMPION	ENCENDEDOR	AS REMOVED
0AFL4-CHAMPION	ENCENDEDOR	AS REMOVED
BAC 10-60710-6	VALVE 3-WAY, ELECTRIC MOTOR OPERATED	AS REMOVED
10-60828-10	TRANSFORMADOR	AS REMOVED
123658-1-3	CHECK VALVE	AS REMOVED
123992-1-1	CHECK VALVE	AS REMOVED
2640081	CHECK VALVE	AS REMOVED

Part Number	Part Description	Condition
7579846	CHECK VALVE	AS REMOVED
B070410004	OVER SPEED SENSOR	AS REMOVED
21450	ACTUADOR SPOILER	AS REMOVED
21450-(14-13)	Actuador HYD	AS REMOVED
10-60757-26	INDICATOR KW/KVAR	AS REMOVED
10-60757-26	INDICATOR KW/KVAR	AS REMOVED
10-60757-26	INDICATOR KW/KVAR	AS REMOVED
10-60757-26	INDICATOR KW/KVAR	AS REMOVED
10-60757-26	INDICATOR KW/KVAR	AS REMOVED
S65-5366-7L	ANTENNA ATC/DME	AS REMOVED
10-3257-3	TRANSFOMER RECTIFIER POWER SUPPLY	AS REMOVED
10-3257-3	TRANSFOMER RECTIFIER POWER SUPPLY	AS REMOVED
129700-06	MAIN ACTUADOR	AS REMOVED
180L-2	ANTI TUNER	AS REMOVED
18-1293-3	FLAP POSITION INDICATOR	AS REMOVED
18-1299-3	FLAP POSITION INDICATOR	AS REMOVED
18-1299-3	FLAP POSITION INDICATOR	AS REMOVED
18-1299-3	FLAP POSITION INDICATOR	AS REMOVED
18-1299-3	FLAP POSITION INDICATOR	AS REMOVED
18-1299-3	FLAP POSITION INDICATOR	AS REMOVED
18-1299-3	FLAP POSITION INDICATOR	AS REMOVED
18-1299-3	FLAP POSITION INDICATOR	AS REMOVED
522-2703-000	ATC TRANSPONDER MODE S	AS REMOVED
787-6211-A001	ATC TRANSPONDER	AS REMOVED
86090-61183	VALVE FUEL SHUTOFF	AS REMOVED
8DJ81 WAG	INDICATOR ELECTRICAL TACHOMETER	AS REMOVED
8DJ81LWN-2	INDICATOR ELECTRICAL TACHOMETER	AS REMOVED
8TJ80GAA-1	FUEL POWER SUPPLY FLOWMETER	AS REMOVED
9844886GI	STATIC PORT	AS REMOVED
BAC-094A	WINDOW	AS REMOVED
65-40449-1	VALVULA CONTROL FLAP	AS REMOVED
G-1964	PANEL RADAR	AS REMOVED
G-1964	PANEL RADAR	AS REMOVED
102-10000	TEMPERATURE SENSOR	AS REMOVED
2-94210	TABLERO DE SEÑALIZACIÓN	AS REMOVED
87001-20	SPEAKER ASSY	AS REMOVED
59100-5009	CONTROL PACKAGE (PWR UNIT)	AS REMOVED
59100-5009	CONTROL PACKAGE (PWR UNIT)	AS REMOVED
59100-5009	CONTROL PACKAGE (PWR UNIT)	AS REMOVED
59100-5009	CONTROL PACKAGE (PWR UNIT)	AS REMOVED
642777A	CAJA DE ACCESORIOS	AS REMOVED
642777J	CAJA DE ACCESORIOS	AS REMOVED
642777M	CAJA DE ACCESORIOS	AS REMOVED
G-1980B	CAJA DE AUDIO	AS REMOVED
731422	INDUCTION MOTOR AC AIRCRAFT	AS REMOVED

Part Number	Part Description	Condition
300029-0100	COMPENSATOR LIQUIT GAGE	AS REMOVED
391043-6509	COMPENSATOR LIQUIT GAGE	AS REMOVED
61-1AB	SWITCH TEMP	AS REMOVED
61-1AB	SWITCH TEMP	AS REMOVED
61-1AB	SWITCH TEMP	AS REMOVED
522-2702-064	DIST MEASURING EQUIP	AS REMOVED
26647	WINDSHIELD	AS REMOVED
DG120A2-3	AIR DATA COMPUTER	AS REMOVED
HG180U 316	AIR DATA COMPUTER	AS REMOVED
162BL503	TEMP IND	AS REMOVED
522-3375-004	CONTRO ANTENA COUPLIER	AS REMOVED
6RS 992 F6	POWER SUPPLY	AS REMOVED
976150-1-1	SW MULTIPLE CENTRIFUGO	AS REMOVED
976150-1-1-069	SWITCH MULTIPLE CENTRIFUGAL	AS REMOVED
522-1859003	INDICATOR DISTANCE	AS REMOVED
162BL704C	OIL TEMPERATURE IND	AS REMOVED
162BL704C	OIL TEMPERATURE IND	AS REMOVED
AN6245A4	DIVISORA	AS REMOVED
AN6245-A4	RELIEV VALVE	AS REMOVED
10-60498-8	PARTICIPATOR TEAM	AS REMOVED
10-60554-4	INDICATOR SYS (A)	AS REMOVED
10-60822-1	STABILIZER TRIM BRAKE ASSEMBLY	AS REMOVED
10-60822-1	STABILIZER TRIM BRAKE ASSEMBLY	AS REMOVED
82402-4472R180	STABILIZER TRIM BRAKE ASSEMBLY	AS REMOVED
G-1571	AUDIO SELECTOR	AS REMOVED
G-1571	AUDIO SELECTOR	AS REMOVED
G-1571	AUDIO SELECTOR	AS REMOVED
G-1574	VHF COMM	AS REMOVED
9700-F1A-BF23AN	PORTABLE OXYGEN CYLINDERS (3AA TYPE BOTTLES) BULKHEAD	AS REMOVED
MFR59501-10-381750-14 A	EXITER IGNITION	AS REMOVED
10-61825-2	SERVOED VERTICAL SPEED	AS REMOVED
981-3088	ACCELEROMETER	AS REMOVED
902F242 -5	PANEL PROTECTION ELECTRICAL SYSTEM	AS REMOVED
902F242 -5	PANEL PROTECTION ELECTRICAL SYSTEM	AS REMOVED
618T-1	TRANSCCIVER	AS REMOVED
3086	SENSOR DE TEMPERATURA	AS REMOVED
411200 B	SENSOR HYDRAULIC	AS REMOVED
548044-2-1	SENSOR TEMPERATURE	AS REMOVED
624118-1	SENSOR	AS REMOVED
MFR6067856B17D	SENSOR	AS REMOVED
MR35263-563	SENSOR	AS REMOVED
1U1087	AUXILIARY RUDDER POWER CONTROL PACKAGE	AS REMOVED

Part Number	Part Description	Condition
1U1087	AUXILIARY RUDDER POWER CONTROL PACKAGE	AS REMOVED
1U1087	AUXILIARY RUDDER POWER CONTROL PACKAGE	AS REMOVED
101095-9-2	L.E. ACTUATOR SLAT	AS REMOVED
40442	SLAT SWITCH	AS REMOVED
152BCL4	TEMPERATURE INDICATOR	AS REMOVED
393086-01235	FUEL QTY INDICATOR	AS REMOVED
393086-01235	FUEL QTY INDICATOR	AS REMOVED
393086-01236	FUEL QTY INDICATOR	AS REMOVED
393086-01236	FUEL QTY INDICATOR	AS REMOVED
162BL704	OIL TEMP INDICATOR	AS REMOVED
162BL704	OIL TEMP INDICATOR	AS REMOVED
162BL704	OIL TEMP INDICATOR	AS REMOVED
162BL704	OIL TEMP INDICATOR	AS REMOVED
1825-2-800/325-25	SONDA MOTOR N3	AS REMOVED
1825-2-800/375-25	SONDA MOTOR N4	AS REMOVED
129H	SENSOR OAT	AS REMOVED
705-2	HORIZON GYRO	AS REMOVED
B118-244	INDICATOR,POWER UNIT FUEL QUANTITY	AS REMOVED
548030	FUEL OIL COOLER	AS REMOVED
10-60011-1	EXT PWR T/R	AS REMOVED
391097-16004	GAGE FUEL TANK UNIT CAPACITOR TYPE	AS REMOVED
391097-16004	GAGE FUEL TANK UNIT CAPACITOR TYPE	AS REMOVED
391097-16006	GAGE FUEL TANK UNIT CAPACITOR TYPE	AS REMOVED
391097-16011	GAGE FUEL TANK UNIT CAPACITOR TYPE	AS REMOVED
391097-16011	GAGE FUEL TANK UNIT CAPACITOR TYPE	AS REMOVED
B1177-3072	TANK UNIT FUEL QUANTITY	AS REMOVED
B1177-3073	TANK UNIT FUEL QUANTITY	AS REMOVED
B1177-3074	TANK UNIT FUEL QUANTITY	AS REMOVED
B1177-3075	TANK UNIT	AS REMOVED
16426	TRANSFORMER VARIABLE POWER	AS REMOVED
129525	VALVE MOTOR ACTUATED BUTTERFLY SHUTOFF	AS REMOVED
522-3177-004	COMPENSATOR RF INDUNTANCE	AS REMOVED
522-3177-004	COMPENSATOR RF INDUNTANCE	AS REMOVED
56B4A	TEMPERATURE SENSOR	AS REMOVED
6307	TRANSFORMADOR	AS REMOVED
6307	TRANSFORMADOR	AS REMOVED
6307	TRANSFORMADOR	AS REMOVED

Part Number	Part Description	Condition
6307	TRANSFORMADOR	AS REMOVED
9274-3643	RELEVO	AS REMOVED
G-515B	SPEAKER COCKPIT	AS REMOVED
J6298A4	PRESS RATIO INDICATOR	AS REMOVED
178050-2-1	SEPARADOR DE AGUA	AS REMOVED
178050-2-1	SEPARADOR DE AGUA	AS REMOVED
178050-2-1	SEPARADOR DE AGUA	AS REMOVED
548376-3	CONTROL TEMPERATURE	AS REMOVED
548376-3	CONTROL TEMPERATURE	AS REMOVED
548376-3	CONTROL TEMPERATURE	AS REMOVED
65-17820-2	AYD ACTUATOR ASSY	AS REMOVED
163BL501	PACK TEMP. INDICATOR	AS REMOVED
163BL501	PACK TEMP. INDICATOR	AS REMOVED
163BL501	PACK TEMP. INDICATOR	AS REMOVED
HG180V3	AIR DATA COMPUTER	AS REMOVED
10-3224-2	PNEUMATIC BRAKE BOTTLE	AS REMOVED
10-6059-7	VALVE FUEL SHUTOFF	AS REMOVED
106892-1	VENTURI FLOW	AS REMOVED
106892-1-1	VENTURY TUBE VALVE	AS REMOVED
303640-02	AUTO PILOT	AS REMOVED
33-50-149	Hon 33g50-149	AS REMOVED
401-60272-3	ELEVATOR FEEL SYSTEM	AS REMOVED
65-17821-74	PRESSURE SYSTEM HYDRAULIC	AS REMOVED
65-24917	AUTO PILOT ACCESORY	AS REMOVED
65-24917-18	AUTO-PILOT ACCESORY	AS REMOVED
65-7822-1	PRESSURE SYSTEM B HYDRAULIC	AS REMOVED
7276-13-8	CIRCUIT BREAKER	AS REMOVED
7276-13-8	CIRCUIT BREAKER	AS REMOVED
7276-13-8	CIRCUIT BREAKER	AS REMOVED
DIO-60011-2	TRANSFORMER RECTIFIED	AS REMOVED
EA102ANH-149H	OÍL HYD INDICATOR QTY	AS REMOVED
G-2661	PANEL COMPARADOR	AS REMOVED
G-5650	PANEL COMM VHF	AS REMOVED
401-60272-2	COMPUTER ELEVATOR FEEL SYSTEM	AS REMOVED
425418	GLIDE SLOPE ANTENA	AS REMOVED
07-3239-9-9001	ACTUADOR	AS REMOVED
109382-32-1	VÁLVULA DE CONTROL DE CARGA DE APU	AS REMOVED
IP-695	VALVULA DE AIRE	AS REMOVED
10-60877-7	HEAT DETECTOR	AS REMOVED
63999-000	HAND MIC	AS REMOVED
157500-0002-009	NAVEGATION PROCESSOR UNIT	AS REMOVED
65-17830-4	HYDRAULIC ACTUATOR ASSEMBLY	AS REMOVED
792-6216-001	Receiver adf	AS REMOVED
622-222A-001	TRANSPONDER ATS	AS REMOVED
965-0376-087	COMPUTER GPWS MARK 0	AS REMOVED

Part Number	Part Description	Condition
MS24525-26	SWITH MASTER PANEL TANQUEO	AS REMOVED
1U1085	VALVE ASSY LOCK OPERATED DOOR SEQUENCE	AS REMOVED
152BL803A	EGT IND	AS REMOVED
G-1278	SPEAKER	AS REMOVED
2067157-0103	RADAR TRANS RECEIVER	AS REMOVED
G298A5	INDICATOR,PRESSURE RATIO	AS REMOVED
2813373	ALTITUDE SENSOR	AS REMOVED
2893484	ALTITUDE DATA COMP	AS REMOVED
H10-1015-4	SWITCH ROTARY	AS REMOVED
1783993-725	HSI	AS REMOVED
40144	FLAP SWITCH	AS REMOVED
548382-2	TEMPERATURE SELECTOR	AS REMOVED
548382-2	TEMPERATURE SELECTOR	AS REMOVED
548382-2	TEMPERATURE SELECTOR	AS REMOVED
548382-2	TEMPERATURE SELECTOR	AS REMOVED
593764AIII	PRESSURE RATIO BLEED CONTROL	AS REMOVED
65-28441-2	MCD DRIFT CAM ACTIATOR	AS REMOVED
07-7930-9-0004	INDICATOR OIL PRESSURE	AS REMOVED
093-2000	INDICATOR PRESS RATIO	AS REMOVED
200-002-002	INDICATOR MATER FUEL QUANTITY	AS REMOVED
303008-36406	INDICATOR GAGE FUEL	AS REMOVED
39B168-1-B	STATIC INVERTER	AS REMOVED
39B168-1-B	STATIC INVERTER	AS REMOVED
45080	VALVE SELENOIDE	AS REMOVED
2-520	TEST POWER UNIT	AS REMOVED
2-520	TEST POWER UNIT	AS REMOVED
2087786-7302	RECEIVER, ADF	AS REMOVED
2087786-7302	RECEIVER, ADF	AS REMOVED
65-17814-12	CILINDRO ACTUADOR DIREC	AS REMOVED
65-17814-12	CILINDRO ACTUADOR DIREC	AS REMOVED
65-27999-3	MCD PRESSURE DOOR ACTUATOR	AS REMOVED
65-27999-3	MCD PRESSURE DOOR ACTUATOR	AS REMOVED
65-37558-2	ASSY ACTUADOR GROUND	AS REMOVED
G-1341	WARMING	AS REMOVED
G-3718	VHF PANEL	AS REMOVED
SRL-04G	OIL PRESS INDICATOR	AS REMOVED
SRL-04G	OIL PRESS INDICATOR	AS REMOVED
624217	SYSTEM B ELECTRIC MOTOR DRIVEN PUMP	AS REMOVED
H10-1026-2	CONTROL SWITCH	AS REMOVED
H10-1026-2	CONTROL SWITCH	AS REMOVED
H10-1026-2	CONTROL SWITCH	AS REMOVED

Part Number	Part Description	Condition
H10-1026-2	CONTROL SWITCH	AS REMOVED
H10-1026-2	CONTROL SWITCH	AS REMOVED
H10-1026-2	CONTROL SWITCH	AS REMOVED
8DJ81LXG2	INDICATOR N1	AS REMOVED
391041-06008	GAGE FUEL TANK	AS REMOVED
391041-06008	GAGE FUEL TANK	AS REMOVED
8DJ81LWM	INDICATOR ELECTRICAL TACHOMETER	AS REMOVED
8DJ81LXG	INDICATOR ELECTRICAL TACHOMETER	AS REMOVED
8DJ81LXG	INDICATOR ELECTRICAL TACHOMETER	AS REMOVED
8DJ81LXG	INDICATOR ELECTRICAL TACHOMETER	AS REMOVED
8DJ81LXG	INDICATOR ELECTRICAL TACHOMETER	AS REMOVED
8DJ81LYV	IND. ELECTRICAL TACHOM	AS REMOVED
8DJ81LYV	IND. ELECTRICAL TACHOM	AS REMOVED
8DJ81LYV	IND. ELECTRICAL TACHOM	AS REMOVED
A-30	DIGITIZER	AS REMOVED
A-30	DIGITIZER	AS REMOVED
WL/118AMA/JA/1/RG1	MACH AIRSPEED INDICATOR	AS REMOVED
21450-11	ACTUADOR SPOILER	AS REMOVED
21450-11	ACTUADOR SPOILER	AS REMOVED
2585802-9	CONTROL PANEL SP-50	AS REMOVED
G-3981A	ADF CONTROL	AS REMOVED
G-4104	CONTROL PANEL, RADAR	AS REMOVED
49-0075-503	SWITCH CENTRIFUGO	AS REMOVED
49-0075-503	SWITCH CENTRIFUGO	AS REMOVED
65-24482-94	UNLOCK ASSY	AS REMOVED
A-61446-0	VALVE BY-PASS	AS REMOVED
A-61446-1	VALVE BY-PASS	AS REMOVED
65-23557-7RG	CAJA REDUCTORA	AS REMOVED
522-3178-004	COMPENSATOR RF INDUNTANCE	AS REMOVED
522-3178-004	COMPENSATOR RF INDUNTANCE	AS REMOVED
522-3178-004	COMPENSATOR RF INDUNTANCE	AS REMOVED
522-3178-004	COMPENSATOR RF INDUNTANCE	AS REMOVED
522-3178-004	COMPENSATOR RF INDUNTANCE	AS REMOVED
D4515J	NAV RADIO	AS REMOVED
S6025-2	VÁLVULA SELECTORA	AS REMOVED
G-3721	INDICATOR PRESSURE	AS REMOVED
10-60011-2	TRANSFORMER RECTIFIED	AS REMOVED
07-2160-9-0009	INDICATOR CABIN TEMP	AS REMOVED
1-6100-11-MA	INDICATOR DE PRESIÓN	AS REMOVED
182769	INDICATOR AND ELERON AND ELEVATOR	AS REMOVED
35918/147LC10	INDICATOR CSD OIL TEMP	AS REMOVED
44-10-0	INDICATOR	AS REMOVED
M07-2	COCKPIT INDICATOR LIGHT	AS REMOVED
STB260-DE	COCKPIT INDICATOR LIGHT	AS REMOVED
B0704 10004	OVERSPEED LIMIT SENSOR	AS REMOVED

Part Number	Part Description	Condition
364-1	PHASE CONVERTER	AS REMOVED
10-61818-151	AIR SPEED INDICATOR	AS REMOVED
CA-DP-10-ILB	INDICADOR DE ALTITUD	AS REMOVED
CA-DP-10-ILB	INDICADOR DE ALTITUD	AS REMOVED
CA-DP-10-ILB	INDICADOR DE ALTITUD	AS REMOVED
CA-DP-10-ILB	INDICADOR DE ALTITUD	AS REMOVED
162BL504	OIL TEMPERATURE INDICATOR	AS REMOVED
162BL504	OIL TEMPERATURE INDICATOR	AS REMOVED
G-1161E-1	CAJA DE AUDIO	AS REMOVED
G-1161E-1	CAJA DE AUDIO	AS REMOVED
857-1	ALTITUD ALERT WARNING GENERATOR	AS REMOVED
300029-01001	QTY COMPENSADOR	AS REMOVED
300029-01001	QTY COMPENSADOR	AS REMOVED
300029-01001	QTY COMPENSADOR	AS REMOVED
300029-01001	QTY COMPENSADOR	AS REMOVED
300029-01001	QTY COMPENSADOR	AS REMOVED
SRL-07BZ	HYD PRESSURE INDICATOR	AS REMOVED
SRL-07BZ	HYD PRESSURE INDICATOR	AS REMOVED
65-40171-20	PUBLIC ADDRES UNIT	AS REMOVED
65-40171-20	PUBLIC ADDRES UNIT	AS REMOVED
65-40173-1	INTERPHONE UNIT	AS REMOVED
65-40173-1	INTERPHONE UNIT	AS REMOVED
161BL501	INDICATOR TEMPERATURE ELECTRICAL RESISTANCE	AS REMOVED
AK-350	ALTITUD ENCORDER	AS REMOVED
AK-350	ALTITUD ENCORDER	AS REMOVED
AK-350	ALTITUD ENCORDER	AS REMOVED
AK-350	ALTITUD ENCORDER	AS REMOVED
AK-350	ALTITUD ENCORDER	AS REMOVED
AK-350	ALTITUD ENCORDER	AS REMOVED
AK-350	ALTITUD ENCORDER	AS REMOVED
10-60529-7	FUELING SHUTOFF VALVE	AS REMOVED
G-1166E	GABLES ENGINEERING	AS REMOVED
G-1861	GABLES ENGINEERING	AS REMOVED
G-2384ARG	GABLES ENGINEERING	AS REMOVED
G-2384ARG	GABLES ENGINEERING	AS REMOVED
G-2384ARG	GABLES ENGINEERING	AS REMOVED
A-113	COCKPIT VOICE RECORDER	AS REMOVED
31848	OÍL PRESSURE INDICATOR	AS REMOVED
69-48593-8	MODULE ASSY - STALL WARNING	AS REMOVED
69-48593-8	MODULE ASSY - STALL WARNING	AS REMOVED
69-48593-8	MODULE ASSY - STALL WARNING	AS REMOVED
69-48593-8	MODULE ASSY - STALL WARNING	AS REMOVED
129150-2-1	PNEUMATIC THERMOSTAT	AS REMOVED
129150-2-1	PNEUMATIC THERMOSTAT	AS REMOVED
129150-2-1	PNEUMATIC THERMOSTAT	AS REMOVED

Part Number	Part Description	Condition
3S2060DV108B1	STATIC INVERTER	AS REMOVED
3S2060DV108B1	STATIC INVERTER	AS REMOVED
65-21939-3	POLEA CONTROLES DE VUELO	AS REMOVED
65-22537-8	POLEA CONTROLES DE VUELO	AS REMOVED
4A36-33544	VALVE CHECK	AS REMOVED
4A36-33544	VALVE CHECK	AS REMOVED
392704-3-1	REGULATOR AIR FLOW	AS REMOVED
392708-1-1	REGULATOR AIRFLOW	AS REMOVED
392708-1-1	REGULATOR AIRFLOW	AS REMOVED
65-21636-2	COMPUERTA SEGUIDORA	AS REMOVED
65-57904-29	TRUNNION LINK	AS REMOVED
21450-113	CYLINDER HYD POWER CONTROL	AS REMOVED
21450-14A	CYLINDER HYD POWER CONTROL	AS REMOVED
60600-5005	CYLINDER SUB-ASSY	AS REMOVED
60600-5005	CYLINDER SUB-ASSY	AS REMOVED
65-17814-10	CYLINDER ASSEMBLY NOSE WHEEL	AS REMOVED
65-37559-7	CYLINDER HYD POWER CONTROL	AS REMOVED
AE4378-200	CYLINDER ASSEMBLY	AS REMOVED
10-3223-30	INDICATO, PRESSURE,0-4000PSI	AS REMOVED
65-40180-1N	PUBLIC ADDRESS ASSESORY	AS REMOVED
815305	PUMP	AS REMOVED
65-17819-15	MAIN GEAR LOCK ACTUATOR	AS REMOVED
65-17819-15	MAIN GEAR LOCK ACTUATOR	AS REMOVED
65-17819-15	MAIN GEAR LOCK ACTUATOR	AS REMOVED
G-1575	GABLES ENGINEERING	AS REMOVED
10-61826-5	SERVOED ALTITUD INDICATOR	AS REMOVED
380678-1-7	ENGINE GAS TURBINE	AS REMOVED
10-3223-19	PNEUMATIC BRAKE PRESS IND.	AS REMOVED
10-3223-19	PNEUMATIC BRAKE PRESS IND.	AS REMOVED
10-3223-19	PNEUMATIC BRAKE PRESS IND.	AS REMOVED
10-3223-19	PNEUMATIC BRAKE PRESS IND.	AS REMOVED
10-3223-19	PNEUMATIC BRAKE PRESS IND.	AS REMOVED
10-3223-19	PNEUMATIC BRAKE PRESS IND.	AS REMOVED
10-60747-2	MACH-AIRSPEED WARNING SWITCH	AS REMOVED
10-60772-4	AURAL WORNING BOX	AS REMOVED
10-60772-4	AURAL WORNING BOX	AS REMOVED
10-60772-4	AURAL WORNING BOX	AS REMOVED
21450-13	FLIGHT SPOILER ACTUATOR	AS REMOVED
21450-13	FLIGHT SPOILER ACTUATOR	AS REMOVED
21450-13	FLIGHT SPOILER ACTUATOR	AS REMOVED
2586373	POTENTIOMETER - AUTO STAB. TRIM	AS REMOVED
2586373	POTENTIOMETER - AUTO STAB. TRIM	AS REMOVED
260582	Y/D INDICATOR	AS REMOVED
260582	Y/D INDICATOR	AS REMOVED
260582	Y/D INDICATOR	AS REMOVED
260582	Y/D INDICATOR	AS REMOVED

Part Number	Part Description	Condition
260582	Y/D INDICATOR	AS REMOVED
28000-1	OXYGEN REGULATOR PANEL	AS REMOVED
28000-1	OXYGEN REGULATOR PANEL	AS REMOVED
28000-1	OXYGEN REGULATOR PANEL	AS REMOVED
28000-1	OXYGEN REGULATOR PANEL	AS REMOVED
28000-1	OXYGEN REGULATOR PANEL	AS REMOVED
28000-1	OXYGEN REGULATOR PANEL	AS REMOVED
40-533	TRANSDUCER	AS REMOVED
511000	VALVULA SELECTORA	AS REMOVED
511000	VALVULA SELECTORA	AS REMOVED
511000	VALVULA SELECTORA	AS REMOVED
511000	VALVULA SELECTORA	AS REMOVED
511000	VALVULA SELECTORA	AS REMOVED
511000	VALVULA SELECTORA	AS REMOVED
511000	VALVULA SELECTORA	AS REMOVED
511000	VALVULA SELECTORA	AS REMOVED
607510-2	BOX - TEMP CONTROL	AS REMOVED
65-60209-11	CONTROL UNIT ASSY	AS REMOVED
6568	PANEL PLANO RH FUEL SHUT OFF V/V	AS REMOVED
65C16300-1	PCU ASSY	AS REMOVED
65C16300-1	PCU ASSY	AS REMOVED
65C16300-1	PCU ASSY	AS REMOVED
65C16300-1	PCU ASSY	AS REMOVED
700662B	GENERATOR	AS REMOVED
8DJ81LWN	INDICATOR ELECTRICAL TACHOMETER	AS REMOVED
8DJ8-1LWN	INDICATOR ELECTRICAL TACHOMETER	AS REMOVED
G-610-11	INTERPHONE AMP	AS REMOVED
LG80A6	TRANSMISOR EPR	AS REMOVED
LG80A6	TRANSMISOR EPR	AS REMOVED
LG80A6	TRANSMISOR EPR	AS REMOVED
LIBB-E32	POSITION INDICATOR	AS REMOVED
LIBB-E32	POSITION INDICATOR	AS REMOVED
NA134D2	COMPUTER	AS REMOVED
NA134D2	COMPUTER	AS REMOVED

Part Number	Part Description	Condition
SRL-04L	OIL PRESS INDICATOR	AS REMOVED
SRL-04L	OIL PRESS INDICATOR	AS REMOVED
SRL-04L	OIL PRESS INDICATOR	AS REMOVED
SRL-04L	OIL PRESS INDICATOR	AS REMOVED
SRL-04L	OIL PRESS INDICATOR	AS REMOVED
SRL-04L	OIL PRESS INDICATOR	AS REMOVED
SRL-04L	OIL PRESS INDICATOR	AS REMOVED
10-60755-2	IND RATE OF CLIMB	AS REMOVED
8TJ124GGR1	FUEL FLOW INDICATOR	AS REMOVED
2021134-2	PACK VALVE	AS REMOVED
2021134-2	PACK VALVE	AS REMOVED
2021134-2	PACK VALVE	AS REMOVED
2021134-2	PACK VALVE	AS REMOVED
2070412-0106	RADAR CONTROL PANEL	AS REMOVED
10-3340-1	VALVE	AS REMOVED
110-337	ANTENA DE ELT	AS REMOVED
110-337	ANTENA DE ELT	AS REMOVED
246880	RELEVO	AS REMOVED
246880	RELEVO	AS REMOVED
246880	RELEVO	AS REMOVED
3-4/A	ANTENNA	AS REMOVED
36057	ANTENNA	AS REMOVED
714810-I	FUEL PRESS DAUM	AS REMOVED
AD969-LZH	ANTENA LIGHTHING ARRESTER	AS REMOVED
10-61093-201	CONTROL VALVE	AS REMOVED
2605761E	OUTER WHEEL MLG	AS REMOVED
2605761E	OUTER WHEEL MLG	AS REMOVED
2605761E	OUTER WHEEL MLG	AS REMOVED
2588302-1	GYROSCOPE DIRECTIONAL	AS REMOVED
2588302-4	GYROSCOPE DIRECTIONAL	AS REMOVED
2588302-4	GYROSCOPE DIRECTIONAL	AS REMOVED
2588302-4	GYROSCOPE DIRECTIONAL	AS REMOVED
2588302-4	GYROSCOPE DIRECTIONAL	AS REMOVED
231-5	WINDOW HEAT CONTROL	AS REMOVED
231-5	WINDOW HEAT CONTROL	AS REMOVED
68030-5001	AUTOPILOT ELEVATOR POWER	AS REMOVED
68030-5001	AUTOPILOT ELEVATOR POWER	AS REMOVED
10-60768-8	ALTIMETER	AS REMOVED
276J498-1	GENERATOR AC AIRCRAFT	AS REMOVED
WL/708AM/FA/2	ALTIMETER	AS REMOVED
8TJ85GBA2	TRANSMITTER RATE OF FLOW	AS REMOVED
8TJ85GBA2	TRANSMITTER RATE OF FLOW	AS REMOVED
10-60515-11	ACTUATOR HYDRAULIC	AS REMOVED
10-60562-5	ACTUATOR MAIN LANDING GEAR	AS REMOVED
2021134-1	ACTUATOR ROTARY	AS REMOVED
2021136-1	ACTUATOR ROTARY	AS REMOVED

Part Number	Part Description	Condition
235A106-10	MOTOR DC	AS REMOVED
65-38515-2	ACTUATOR PNEUMATIC	AS REMOVED
SB 32-001	ACTUATOR HYDRAULIC	AS REMOVED
905D968-3	CURRENT TRANSFORMER ASSEMBLY	AS REMOVED
905D968-3	CURRENT TRANSFORMER ASSEMBLY	AS REMOVED
905D968-3	CURRENT TRANSFORMER ASSEMBLY	AS REMOVED
905D968-3	CURRENT TRANSFORMER ASSEMBLY	AS REMOVED
G-1133-1	FLAP SLAT DISP	AS REMOVED
G-1133-1	FLAP SLAT DISP	AS REMOVED
G-1133-1	FLAP SLAT DISP	AS REMOVED
61183	CROOSFED VALVE	AS REMOVED
61183	CROOSFED VALVE	AS REMOVED
75-0149-77	GRIMES DIVISION	AS REMOVED
75-0149-77	GRIMES DIVISION	AS REMOVED
AV13J5100	CONTROL VALVE	AS REMOVED
BACR13CF-2AB	RELAY 10 AMP	AS REMOVED
10-3204-3	VALVE HYD FLOW REGULATOR	AS REMOVED
10-60710-R	VALVE HYDRAULIC	AS REMOVED
65-17989-7B	VALVE HYDRAULIC	AS REMOVED
A-61446	VALVE HYDRAULIC BYPASS	AS REMOVED
S-6025-2	VALVE LANDING GEAR SELECTOR	AS REMOVED
S-6025-2	VALVE LANDING GEAR SELECTOR	AS REMOVED
10-60554-7	IND,HYD OIL QTY	AS REMOVED
10-60554-7	IND,HYD OIL QTY	AS REMOVED
10-60554-7	IND,HYD OIL QTY	AS REMOVED
10-60554-7	IND,HYD OIL QTY	AS REMOVED
3721A	MAGNÉTIC AMPLIFIER	AS REMOVED
391041-009	GAGE FUEL TANK	AS REMOVED
391041-009	GAGE FUEL TANK	AS REMOVED
2588880-901	YAW DAMPER COUPLER	AS REMOVED
2588880-901	YAW DAMPER COUPLER	AS REMOVED
393026-036	BRIDGE INDICATOR	AS REMOVED
204185-3	COMPRESSOR CENTRIFUGAL TURB. DRIVE	AS REMOVED
59100-5013	RUDDER CONTROL PACKAGE	AS REMOVED
225485	VALVE MOTOR - OPERATED AIR SHUTOFF	AS REMOVED
10-60450-2	RELEVO	AS REMOVED
258000-3	BOMBA BOSTER	AS REMOVED
258000-3	BOMBA BOSTER	AS REMOVED
42-527-D	CONTROL SHIELD	AS REMOVED
6291	TRANSFORMER POWER	AS REMOVED
6291	TRANSFORMER POWER	AS REMOVED
6291	TRANSFORMER POWER	AS REMOVED
72909	REGULADOR DE PRESIÓN	AS REMOVED

Part Number	Part Description	Condition
10-60757-25	FREQUENCY METER	AS REMOVED
10-60757-25	FREQUENCY METER	AS REMOVED
10-60791-6	FLAP POSITION INDICATOR	AS REMOVED
10-60887-2	REGULADOR DILUTER OHG	AS REMOVED
10-60887-2	REGULADOR DILUTER OHG	AS REMOVED
10-60887-2	REGULADOR DILUTER OHG	AS REMOVED
10-60887-2	REGULADOR DILUTER OHG	AS REMOVED
129150-5-1	TERMOSTATO NEUMATIC	AS REMOVED
129150-5-1	TERMOSTATO NEUMATIC	AS REMOVED
1356-603399	ACCUMULATOR HYDRAULIC	AS REMOVED
1356-603399	ACCUMULATOR HYDRAULIC	AS REMOVED
1356-603399	ACCUMULATOR HYDRAULIC	AS REMOVED
1356-603399	ACCUMULATOR HYDRAULIC	AS REMOVED
1692RA-11	VALVE ASSEMBLY NOSE WHEEL	AS REMOVED
221CH54-RB	MICRO SWITCH	AS REMOVED
2-299	POWER TRANSFORMER RECTIFI	AS REMOVED
2-299	POWER TRANSFORMER RECTIFI	AS REMOVED
2-299	POWER TRANSFORMER RECTIFI	AS REMOVED
2-299	POWER TRANSFORMER RECTIFI	AS REMOVED
2-299	POWER TRANSFORMER RECTIFI	AS REMOVED
2-299	POWER TRANSFORMER RECTIFI	AS REMOVED
2-299	POWER TRANSFORMER RECTIFI	AS REMOVED
2-299	POWER TRANSFORMER RECTIFI	AS REMOVED
2-299	POWER TRANSFORMER RECTIFI	AS REMOVED
522-2213-036	CONTROL	AS REMOVED
522-2213-036	CONTROL	AS REMOVED
531831	RETENEDOR	AS REMOVED
531831	RETENEDOR	AS REMOVED
531831	RETENEDOR	AS REMOVED
605675-1	FAN VANE	AS REMOVED
605675-1	FAN VANE	AS REMOVED
605675-1	FAN VANE	AS REMOVED
605675-1	FAN VANE	AS REMOVED
6332	TRANSFORMADOR	AS REMOVED
858720	BUTERFLY VALVE	AS REMOVED
A152(A)	CONTROL UNIT	AS REMOVED
A152(A)	CONTROL UNIT	AS REMOVED
AC-7680-6	FILTER ASSEMBLY HYDRAULIC SYSTEM FILLING	AS REMOVED
AT575-126UAW-TNCF-000-RG-30-NM	AEROANTENNA TECHNOLOGY	AS REMOVED

Part Number	Part Description	Condition
G6075-05	PANEL AUDIO	AS REMOVED
G6075-05	PANEL AUDIO	AS REMOVED
PNV11-3-25	SWITCH ACTUATOR	AS REMOVED
ST104Z	OIL PRESSURE TRANS	AS REMOVED
ST104Z	OIL PRESSURE TRANS	AS REMOVED
ST104Z	OIL PRESSURE TRANS	AS REMOVED
AD43011-02C	ALTIMETER ANTENA	AS REMOVED
AD43011-02C	ALTIMETER ANTENA	AS REMOVED
AD43011-02C	ALTIMETER ANTENA	AS REMOVED
AD43011-02C	ALTIMETER ANTENA	AS REMOVED
65-22819-4	OFFSET GEAR BOX RH	AS REMOVED
1U1169	ACTUATOR ASSY - TAIL SKID	AS REMOVED
A4304910004	ALTIMETER SERVOED INDICATOR	AS REMOVED
UA526276-24	AIR TO LIQUID COOLER	AS REMOVED
UA526276-24	AIR TO LIQUID COOLER	AS REMOVED
UA526276-5	AIR TO LIQUID COOLER	AS REMOVED
UA526276-5	AIR TO LIQUID COOLER	AS REMOVED
UA526276-5	AIR TO LIQUID COOLER	AS REMOVED
UA526276-5	AIR TO LIQUID COOLER	AS REMOVED
E229165	V/V ANTI - ICE	AS REMOVED
G60668	TIME DELAY RELAY	AS REMOVED
G60668	TIME DELAY RELAY	AS REMOVED
5-89358-22	WINDOW	AS REMOVED
5-89358-22	WINDOW	AS REMOVED
384300	FUEL PUMP	AS REMOVED
384300	FUEL PUMP	AS REMOVED
384300	FUEL PUMP	AS REMOVED
384300	FUEL PUMP	AS REMOVED
384300	FUEL PUMP	AS REMOVED
384300	FUEL PUMP	AS REMOVED
384300	FUEL PUMP	AS REMOVED
384300	FUEL PUMP	AS REMOVED
384300	FUEL PUMP	AS REMOVED
MS24659-21L	MICRO SWITCH	AS REMOVED
10-60715-6	CLOCK	AS REMOVED
G-1010E	WARNING NAV	AS REMOVED
10-60517-7	INSOLOATOR ASSY	AS REMOVED
4030950-904	PITCH CONTROL	AS REMOVED
R-1549-1	ACTUATOR ELECTRO MECH LINEAR	AS REMOVED
G-1081C	ANNUCUATOR NAV	AS REMOVED
G-1081C	ANNUCUATOR NAV	AS REMOVED
G-1885	PANEL SELECTOR	AS REMOVED
2067635-0701	INA INDICATOR	AS REMOVED
614937-51	INTEGRATED INST RACK	AS REMOVED
614937-51	INTEGRATED INST RACK	AS REMOVED
614937-51	INTEGRATED INST RACK	AS REMOVED
10-60582-1	HIDRAULIC MOTOR PACK	AS REMOVED

Part Number	Part Description	Condition
9390148-1	MOTOR STAND BY HYD	AS REMOVED
10-61209-17	CONTROLLER PRESSURE	AS REMOVED
10-61209-17	CONTROLLER PRESSURE	AS REMOVED
U2637	MEDIDOR DE GASES DE PRESIÓN	AS REMOVED
10-3094-39	SEAT	AS REMOVED
10-60757-24	DC AMMETER	AS REMOVED
182936	INDICATOR PRESSURE O2	AS REMOVED
182936	INDICATOR PRESSURE O2	AS REMOVED
182936	INDICATOR PRESSURE O2	AS REMOVED
2-301-3	BATTERY CHARGER	AS REMOVED
2-301-3	BATTERY CHARGER	AS REMOVED
2-301-3	BATTERY CHARGER	AS REMOVED
2-301-3	BATTERY CHARGER	AS REMOVED
2-301-3	BATTERY CHARGER	AS REMOVED
2-301-3	BATTERY CHARGER	AS REMOVED
522-1836-00	ADF RECEIVER	AS REMOVED
522-1836-00	ADF RECEIVER	AS REMOVED
522-1836-00	ADF RECEIVER	AS REMOVED
548384-1	ANTICIPATOR SENSOR	AS REMOVED
7579078	EDP FILTER ASSY	AS REMOVED
98087-1163P18-2	DIFFERENTIAL PRESS SWITCH	AS REMOVED
98087-1163P18-2	DIFFERENTIAL PRESS SWITCH	AS REMOVED
011-00134-00	ANTENNA GPS	AS REMOVED
CMA-73D-90	ANTENNA COUPLER	AS REMOVED
384453-001	TRANSISTORIZED VOLUMETRIC TOP-OFF DEVICE	AS REMOVED
384453-001	TRANSISTORIZED VOLUMETRIC TOP-OFF DEVICE	AS REMOVED
384453-001	TRANSISTORIZED VOLUMETRIC TOP-OFF DEVICE	AS REMOVED
384453-001	TRANSISTORIZED VOLUMETRIC TOP-OFF DEVICE	AS REMOVED
384453-001	TRANSISTORIZED VOLUMETRIC TOP-OFF DEVICE	AS REMOVED
384453-001	TRANSISTORIZED VOLUMETRIC TOP-OFF DEVICE	AS REMOVED
384453-001	TRANSISTORIZED VOLUMETRIC TOP-OFF DEVICE	AS REMOVED
384453-001	TRANSISTORIZED VOLUMETRIC TOP-OFF DEVICE	AS REMOVED
398542-2-1	VALVE-SHUTOFF AIR	AS REMOVED
398542-2-1	VALVE-SHUTOFF AIR	AS REMOVED
398542-2-1	VALVE-SHUTOFF AIR	AS REMOVED
5669-7	AEROMATIC VALVE	AS REMOVED
5669-7	AEROMATIC VALVE	AS REMOVED
5669-7	AEROMATIC VALVE	AS REMOVED
6114-3	REGULATOR HYDRAULIC	AS REMOVED

Part Number	Part Description	Condition
1776365924	HORIZON FLIGHT DIRECTOR INDICATOR	AS REMOVED
1776365-924	HORIZONT FLIGHT IND.	AS REMOVED
1776365-924	HORIZONT FLIGHT IND.	AS REMOVED
1776365-924	HORIZONT FLIGHT IND.	AS REMOVED
10-60552-16	SW PRESSURE	AS REMOVED
98087-1225P6-2	SWITCH PRESSURE	AS REMOVED
65-58508-11	PANEL ASSY LH	AS REMOVED
65-58508-12	PANEL ASSY RH	AS REMOVED
69-17380-4	PANEL CABIN	AS REMOVED
10-60533-3	FUEL BOOSTER PUMP	AS REMOVED
10-60533-3	FUEL BOOSTER PUMP	AS REMOVED
700742	LOAD CONTROL	AS REMOVED
700742	LOAD CONTROL	AS REMOVED
700742	LOAD CONTROL	AS REMOVED
700742	LOAD CONTROL	AS REMOVED
700742	LOAD CONTROL	AS REMOVED
700742	LOAD CONTROL	AS REMOVED
A-60087-CD6	VALVE RELIEF HYDRAULIC PRESSURE	AS REMOVED
G6992-51	PANEL CONTROL ATC	AS REMOVED
H10-1027-2	SWITCH ROTARY	AS REMOVED
H10-1027-2	SWITCH ROTARY	AS REMOVED
H10-1027-2	SWITCH ROTARY	AS REMOVED
37-231	ELECTRO HYR SERVO VALVE	AS REMOVED
65-17825-1	VALVULA SLANDS ONDULAR	AS REMOVED
10276N01T00	EGT INDICATOR	AS REMOVED
18-1570-15	X-MITTER-FLAP POS	AS REMOVED
BA51015-5	PORTABLE FIRE EXTINGUISHER	AS REMOVED
ICC-3AA	PORTABLE FIRE EXTINGUISHER	AS REMOVED
DOT-3AA1800	OXIGEN BOTTLE	AS REMOVED
DOT-3AA1800	OXIGEN BOTTLE	AS REMOVED
DOT-3AA1800	OXIGEN BOTTLE	AS REMOVED
772-5025-002	IND HORIZONTAL	AS REMOVED
1060554-4	IND HYD QTY	AS REMOVED
124838	INDICATOR OIL TEMPERATURE GENERATOR	AS REMOVED
129700-03	ACTUATOR ROTARY SERVO	AS REMOVED
152BL801D	EGT IND	AS REMOVED
152BL801D	EGT IND	AS REMOVED
152BL801D	EGT IND	AS REMOVED
152BL801D	EGT IND	AS REMOVED
1775EA	VALVULA CONTROL LANDING	AS REMOVED
1775EA	VALVULA CONTROL LANDING	AS REMOVED
3059103-1	ACUMULADOR HIDRAULICO	AS REMOVED
321674-3-1	VALVE SHUT OFF	AS REMOVED
321674-3-1	VALVE SHUT OFF	AS REMOVED

Part Number	Part Description	Condition
H10-1026	SWITCH ROTARY	AS REMOVED
NA135	PANEL COMPUTER	AS REMOVED
SLZ9145	VERTICAL SPEED INDICATOR	AS REMOVED
SLZ9145	VERTICAL SPEED INDICATOR	AS REMOVED
ST106AB	PRESS TRANSMITTER	AS REMOVED
ST-106AB	DUCT PX TRANSMITTER	AS REMOVED
ST-106AB	DUCT PX TRANSMITTER	AS REMOVED
XW20544-1	ALCO VALVE	AS REMOVED
XW20544-1	ALCO VALVE	AS REMOVED
10-60757-55	ELECTRICAL INDICATING POSITION	AS REMOVED
10704	GPS ANTENNA	AS REMOVED
10704	GPS ANTENNA	AS REMOVED
AT575-43	GPS ANTENNA	AS REMOVED
AT575-43	GPS ANTENNA	AS REMOVED
S67-1575-52	GPS ANTENNA	AS REMOVED
S67-1575-52	GPS ANTENNA	AS REMOVED
S67-1575-52	GPS ANTENNA	AS REMOVED
S67-1575-52	GPS ANTENNA	AS REMOVED
Mka-7a-1	MARKER RECEIVER	AS REMOVED
A30-4-1-C3N	VARIABLE RESISTOR	AS REMOVED
65W01025	DRIVER	AS REMOVED
10-60737-14	engine pressure ratio ind.	AS REMOVED
10C10B	TESTED	AS REMOVED
10-60529-1	VALVE FUEL SHUTOFF	AS REMOVED
10-60529-1	VALVE FUEL SHUTOFF	AS REMOVED
10-60529-1	VALVE FUEL SHUTOFF	AS REMOVED
10-60529-1	VALVE FUEL SHUTOFF	AS REMOVED
10-60529-1	VALVE FUEL SHUTOFF	AS REMOVED
10-60529-1	VALVE FUEL SHUTOFF	AS REMOVED
56B17C	TEMPERATURE BULB	AS REMOVED
56B17C	TEMPERATURE BULB	AS REMOVED
56B17C	TEMPERATURE BULB	AS REMOVED
56D17C	TEMPERATURE BULB	AS REMOVED
522-3752-001	FLIGHT DIRECTOR IND.	AS REMOVED
522-3752-001	FLIGHT DIRECTOR IND.	AS REMOVED
69-16267-1	HYD SYS PANEL	AS REMOVED
AV13J5144	VALVE ASSY, DC MOTOR OPERATED	AS REMOVED
AV13J5144	VALVE ASSY, DC MOTOR OPERATED	AS REMOVED
AV13J5144	VALVE ASSY, DC MOTOR OPERATED	AS REMOVED
AV13J5144	VALVE ASSY, DC MOTOR OPERATED	AS REMOVED
4038930-901	HORIZ SIT IND	AS REMOVED
4038930-901	HORIZ SIT IND	AS REMOVED
33 MO 480	PANEL FUEL QUANTITY	AS REMOVED
63-30656	PANEL ENGINE START	AS REMOVED
6926418-16	PANEL MEASURE DIRECTOR CURRENT	AS REMOVED
65-24920-3	ACCESSORY UNIT ASSY	AS REMOVED

Part Number	Part Description	Condition
65-24920-3	ACCESSORY UNIT ASSY	AS REMOVED
65-24920-3	ACCESSORY UNIT ASSY	AS REMOVED
65-24920-3	ACCESSORY UNIT ASSY	AS REMOVED
65-24920-3	ACCESSORY UNIT ASSY	AS REMOVED
979-0223-001	ACCELEROMETER BIAxIAL	AS REMOVED
707835	TRANSMISSION CONSTANT SPEED A. C GENERATOR	AS REMOVED
G-1965A	NAV CONTROL	AS REMOVED
G-1965A	NAV CONTROL	AS REMOVED
548376-6	TEMP CONTROL	AS REMOVED
1697EA	CONTROL VALV HYD	AS REMOVED
1697EA	CONTROL VALV HYD	AS REMOVED
75-0038-17	PANEL ANUNCIATOR	AS REMOVED
20548-m1a-3	ELECTRIC MOTOR	AS REMOVED
BAC10-3096-3	ELECTRIC MOTOR	AS REMOVED
BAC-10-61329-13	ELECTRIC MOTOR	AS REMOVED
XW20173-MI	ELECTRIC MOTOR	AS REMOVED
XW20548-M1	ELECTRICAL MOTOR WIPER	AS REMOVED
XW20548-M1A	ELECTRICAL MOTOR	AS REMOVED
M-931-1	VALVULA DE ACEITE (M-931-1)	AS REMOVED
65-17823-1	MODULO DE ALERON	AS REMOVED
65-17823-1	MODULO DE ALERON	AS REMOVED
65-17823-1	MODULO DE ALERON	AS REMOVED
65-17823-1	MODULO DE ALERON	AS REMOVED
65-17823-1	MODULO DE ALERON	AS REMOVED
65-17823-1	MODULO DE ALERON	AS REMOVED
65-17823-1	MODULO DE ALERON	AS REMOVED
65-17823-1	MODULO DE ALERON	AS REMOVED
65-17823-1	MODULO DE ALERON	AS REMOVED
65-17823-1	MODULO DE ALERON	AS REMOVED
65-17823-1	MODULO DE ALERON	AS REMOVED
65-17823-1	MODULO DE ALERON	AS REMOVED
65-17823-1	MODULO DE ALERON	AS REMOVED
65-17823-1	MODULO DE ALERON	AS REMOVED
65-17823-1	MODULO DE ALERON	AS REMOVED
65-17823-1	MODULO DE ALERON	AS REMOVED
65-23598-6	ESTRUCTURAL PART	AS REMOVED
65-60472-1	ESTRUCTURAL PART	AS REMOVED
10-3349-5	FIRE SWITCH ENGINE	AS REMOVED
10-3349-5	FIRE SWITCH ENGINE	AS REMOVED
109644-3-1	LOAD CONTROLLER GENERATOR DRIVE	AS REMOVED
622-1405-001	FLIGHT DIRECTOR PANEL	AS REMOVED
65-40178-86	FLIGHT INSTRUMENTS ACCS	AS REMOVED
65-40178-86	FLIGHT INSTRUMENTS ACCS	AS REMOVED
MS9-3911-30ZE-4C	MOTOR HIDRULICO	AS REMOVED
MS9-3911-30ZE-4C	MOTOR HIDRULICO	AS REMOVED
MS9-3911-30ZE-4C	MOTOR HIDRULICO	AS REMOVED
40174	SWITCH	AS REMOVED
40174	SWITCH	AS REMOVED

Part Number	Part Description	Condition
321464-2-1	VÁLVULA MODULADORA PRECOOLER	AS REMOVED
321464-2-1	VÁLVULA MODULADORA PRECOOLER	AS REMOVED
321464-2-1	VÁLVULA MODULADORA PRECOOLER	AS REMOVED
321464-2-1	VÁLVULA MODULADORA PRECOOLER	AS REMOVED
321464-2-1	VÁLVULA MODULADORA PRECOOLER	AS REMOVED
3S2060DV109B1	STATIC INVERTER	AS REMOVED
3S2060DV109B1	STATIC INVERTER	AS REMOVED
3S2060DV109B1	STATIC INVERTER	AS REMOVED
40574	VALVE FUEL SHUTOFF	AS REMOVED
40574	VALVE FUEL SHUTOFF	AS REMOVED
40574	VALVE FUEL SHUTOFF	AS REMOVED
40574	VALVE FUEL SHUTOFF	AS REMOVED
418-00044	PRESSURE OIL	AS REMOVED
42-089-5	HYDRO-AIRE DIVISION	AS REMOVED
522-2703-011	ATC TRANSPONDER	AS REMOVED
522-2703-011	ATC TRANSPONDER	AS REMOVED
522-2703-011	ATC TRANSPONDER	AS REMOVED
522-2703-011	ATC TRANSPONDER	AS REMOVED
522-3120-004	INSTRUMENT AMPLIFIER	AS REMOVED
522-3120-004	INSTRUMENT AMPLIFIER	AS REMOVED
522-3120-005	INSTRUMENTO AMPLIFICADOR	AS REMOVED
522-3120-005	INSTRUMENTO AMPLIFICADOR	AS REMOVED
522-3120-005	INSTRUMENTO AMPLIFICADOR	AS REMOVED
522-4538-002	PASSENGER ADDRES	AS REMOVED
541248-3	ACTUATOR ROTARY	AS REMOVED
541248-3	ACTUATOR ROTARY	AS REMOVED
5-89357-21	WINDOW # 4	AS REMOVED
65-28943-2	LOOK ACTUATOR ASSEMBLY	AS REMOVED
65-28943-2	LOOK ACTUATOR ASSEMBLY	AS REMOVED
65-28943-2	LOOK ACTUATOR ASSEMBLY	AS REMOVED
65-28943-2	LOOK ACTUATOR ASSEMBLY	AS REMOVED
65-28943-2	LOOK ACTUATOR ASSEMBLY	AS REMOVED
65-28943-2	LOOK ACTUATOR ASSEMBLY	AS REMOVED
65-28943-2	LOOK ACTUATOR ASSEMBLY	AS REMOVED
8TJ80GAA	POWER FUELFLOW	AS REMOVED
8TJ80GAA	POWER FUELFLOW	AS REMOVED
8TJ80GAA	POWER FUELFLOW	AS REMOVED
98087	COMPRESSOR DISCHARGE OVERHEAT SWITCH	AS REMOVED
EBC-502	BATTERY	AS REMOVED
V3900-11	VALVULA SOLENOIDE	AS REMOVED
V3900-11	VALVULA SOLENOIDE	AS REMOVED
V3900-11	VALVULA SOLENOIDE	AS REMOVED
V3900-11	VALVULA SOLENOIDE	AS REMOVED
V3900-11	VALVULA SOLENOIDE	AS REMOVED
651-12-24-15	CLOCK	AS REMOVED

Part Number	Part Description	Condition
65-21890-1	VALVULA CONTROL EXTENSO	AS REMOVED
65-24482-86	MLG LOCK MECHANISM	AS REMOVED
231-3	WINDOW HEAT CONTROL UNIT	AS REMOVED
231-3	WINDOW HEAT CONTROL UNIT	AS REMOVED
231-3	WINDOW HEAT CONTROL UNIT	AS REMOVED
231-3	WINDOW HEAT CONTROL UNIT	AS REMOVED
806000-11	BOTTLE EXTINGER	AS REMOVED
65-52803-8	ACCESSORY UNIT ASSY - WINDOW CONTROL	AS REMOVED
65-52803-8	ACCESSORY UNIT ASSY - WINDOW CONTROL	AS REMOVED
39-047	VÁLVULA ANTI-SKID	AS REMOVED
658385 B111	PRESSURE RATIO BLEED CONTROL	AS REMOVED
658385 BI	PRESSURE RATIO BLEED CONTROL	AS REMOVED
658385 BI	PRESSURE RATIO BLEED CONTROL	AS REMOVED
658385 BIII	PRESSURE RATIO BLEED CONTROL	AS REMOVED
658385 II	PRESSURE RATIO BLEED CONTROL	AS REMOVED
658385 II	PRESSURE RATIO BLEED CONTROL	AS REMOVED
658385 SB2268	PRESSURE RATIO BLEED CONTROL	AS REMOVED
658385-BIII	PRESSURE RATIO BLEED CONTROL	AS REMOVED
658490	PRESSURE RATIO BLEED CONTROL	AS REMOVED
69-14103-1	PRESSURE OPERATED VALVE ASSEMBLY	AS REMOVED
3079	FUEL PRESS SWITCH	AS REMOVED
0.2514-ID	TRANSMITTER POSITION AND STALL WARNING	AS REMOVED
10-3223-2	TRANSMITTER HYDRAULIC	AS REMOVED
13TX0115A	TRANSMITTER	AS REMOVED
391046-177	TRANSMITTER	AS REMOVED
65-23560-41	TRANSMISSION SYSTEM HYDRAULIC	AS REMOVED
65-23577-3	TRANSMISSION	AS REMOVED
8TJ92GAA2	TRANSMITER OIL PRESSURE	AS REMOVED
S250N104-1	TRANSMITTER CONTROL SURFACE POSITION TYPE H505B	AS REMOVED
ST 7R	TRANSMITER PRESSURE	AS REMOVED
ST-104-Z	TRANSMITTER OIL PRESSURE	AS REMOVED
ST-104Z-M1	TRANSMITTER OIL PRESSURE	AS REMOVED
16419	TRANSFORMER VARIABLE POWER	AS REMOVED
1U1095-9-2	SLAT ACTUATOR	AS REMOVED
1U1095-9-2	SLAT ACTUATOR	AS REMOVED
1U1095-9-2	SLAT ACTUATOR	AS REMOVED
8TJ50 G B Z	TRANSMITTER RATE OF FLOW FUEL	AS REMOVED
8TJ50GB7	TRANSMITTER RATE OF FLOW FUEL	AS REMOVED
8TJ50GB7	TRANSMITTER RATE OF FLOW FUEL	AS REMOVED
8TJ50GB7	TRANSMITTER RATE OF FLOW FUEL	AS REMOVED
8TJ50GBZ	TRANSMITTER RATE OF FLOW FUEL	AS REMOVED

Part Number	Part Description	Condition
8TJ50GBZ	TRANSMITTER RATE OF FLOW FUEL	AS REMOVED
8TJ50GBZ	TRANSMITTER RATE OF FLOW FUEL	AS REMOVED
8TJ50GBZ	TRANSMITTER RATE OF FLOW FUEL	AS REMOVED
8TJ50GBZ	TRANSMITTER RATE OF FLOW FUEL	AS REMOVED
8TJ50GBZ	TRANSMITTER RATE OF FLOW FUEL	AS REMOVED
8TJ50GBZ	TRANSMITTER RATE OF FLOW FUEL	AS REMOVED
8TJ50GBZ	TRANSMITTER RATE OF FLOW FUEL	AS REMOVED
8TJ50GBZ	TRANSMITTER RATE OF FLOW FUEL	AS REMOVED
8TJ50GBZ	TRANSMITTER RATE OF FLOW FUEL	AS REMOVED
78169-02	AUTO BREAKE PRESSURE	AS REMOVED
78169-02	AUTO BREAKE PRESSURE	AS REMOVED
607510-3	BOX - TEMP CONTROL	AS REMOVED
607510-3	BOX - TEMP CONTROL	AS REMOVED
777-1492-004	RECEIVER ADF (777-1492-004)	AS REMOVED
10-331750-10	EXCITER IGNITION	AS REMOVED
10-353275-4	EXCITER IGNITION	AS REMOVED
10-353875-3	EXCITER IGNITION	AS REMOVED
10-381175-4	EXCITER IGNITION	AS REMOVED
10-381200-2	EXCITER IGNITION	AS REMOVED
49986-C	EXCITER IGNITION	AS REMOVED
2607948L	INBOARD WHEEL HALF	AS REMOVED
522-2213-043	PANEL CONTROL	AS REMOVED
6A47-000	CSD OIL COOLER	AS REMOVED
10-61317-13	TRASNMISOR DE POSICION	AS REMOVED
1U1084	SECUENCE VALVE MAIN GEAR	AS REMOVED
522-1501-00	TRANSCEIVER	AS REMOVED
522-1501-000	TRANSCEIVER	AS REMOVED
522-3394-005	INSTRUMENT COMPTR	AS REMOVED
S315A110-3	LEVER ANGLE SYNCHRO	AS REMOVED
522-4323-002	FLY DIRECTOR CONTROL	AS REMOVED
APE909-0043	AIR PRECISION	AS REMOVED
69-61197-13	MEIN GEAR ANTISKID PANEL	AS REMOVED
69-61197-13	MEIN GEAR ANTISKID PANEL	AS REMOVED
103286-5	VALVE SAFETY	AS REMOVED
22960-70	VALVE PRESSURE	AS REMOVED
73760	VALVE SHUTOFF GAGE	AS REMOVED
TBC10-60531-1	VALVE SHUT OFF	AS REMOVED
V5000-43	VALVE SHUT OFF	AS REMOVED
V8500-40	VALVE SHUT OFF	AS REMOVED
40141	SWITCH POSITION	AS REMOVED
392220-1-1	VALVULA MODULADORA	AS REMOVED
392220-1-1	VALVULA MODULADORA	AS REMOVED
10-60558-2	ACTUADOR LE FLAP	AS REMOVED
82402-42129R422	Actuador de estabilizador Trim	AS REMOVED
3601030-9-1	SPEED SWITCH	AS REMOVED
65-17823-2	MODULO FLIHT CONTROL	AS REMOVED
65-17823-2	MODULO FLIHT CONTROL	AS REMOVED

Part Number	Part Description	Condition
65-17823-2	MODULO FLIHT CONTROL	AS REMOVED
65-17823-3	MODULO FLIGHT CONTROL	AS REMOVED
65-21622-19	FITTINGS	AS REMOVED
10-61233-1	CSD OIL COOLER	AS REMOVED
204050-10	TURBINE COOLING	AS REMOVED
101014	Panel flight recorder	AS REMOVED
1784460-655	COMPASS INDICATOR	AS REMOVED
1784460-655	COMPASS INDICATOR	AS REMOVED
1784460-655	COMPASS INDICATOR	AS REMOVED
1U1103-2	EDGE SLAT ACTUATOR	AS REMOVED
1U1103-2	EDGE SLAT ACTUATOR	AS REMOVED
1U1103-2	EDGE SLAT ACTUATOR	AS REMOVED
1U1103-2	EDGE SLAT ACTUATOR	AS REMOVED
1U1103-2	EDGE SLAT ACTUATOR	AS REMOVED
1U1103-2	EDGE SLAT ACTUATOR	AS REMOVED
1U1103-2	EDGE SLAT ACTUATOR	AS REMOVED
1U1103-2	EDGE SLAT ACTUATOR	AS REMOVED
2070058-0701	ANTENA RADIO	AS REMOVED
2087821-2811	MARKER BEACON RCVR	AS REMOVED
522-2357-014	ADF CONTROL	AS REMOVED
522-2357-014	ADF CONTROL	AS REMOVED
522-2782-004	INDICADOR DE CURSO	AS REMOVED
522-2782-004	INDICADOR DE CURSO	AS REMOVED
522-2782-004	INDICADOR DE CURSO	AS REMOVED
522-3700-004	FLIGHT DIRECTOR INDICATOR	AS REMOVED
522-3700-004	FLIGHT DIRECTOR INDICATOR	AS REMOVED
522-3700-004	FLIGHT DIRECTOR INDICATOR	AS REMOVED
548376-5	CONTROL TEMP	AS REMOVED
548376-5	CONTROL TEMP	AS REMOVED
548376-5	CONTROL TEMP	AS REMOVED
5-89354-3109	WINDSHIELD	AS REMOVED
61349-PN	OIL PRESSURE TRANSMITTER	AS REMOVED
65-21945-8	UNIDAD BALANZAS FLAP	AS REMOVED
714810	P & D VALVE	AS REMOVED
714810	P & D VALVE	AS REMOVED
714810	P & D VALVE	AS REMOVED
714810	P & D VALVE	AS REMOVED
714810	P & D VALVE	AS REMOVED
934500-01	ARING429	AS REMOVED
934500-01	ARING429	AS REMOVED
HG180U321	AIR DATA COMPUTER	AS REMOVED
939D150-2	VOLTAGE REGULATOR AC	AS REMOVED
939D150-2	VOLTAGE REGULATOR AC	AS REMOVED
939D150-2	VOLTAGE REGULATOR AC	AS REMOVED
939D150-2	VOLTAGE REGULATOR AC	AS REMOVED
939D150-2	VOLTAGE REGULATOR AC	AS REMOVED
939D150-2	VOLTAGE REGULATOR AC	AS REMOVED

Part Number	Part Description	Condition
65-56298-1	ACTUATOR ASSY CARGO DOOR	AS REMOVED
10-0067-7	SWITCH	AS REMOVED
10-0067-7	SWITCH	AS REMOVED
10-3349-2	SWITCH	AS REMOVED
10-60436-3	VALVE ASSEMBLY	AS REMOVED
306-4305	SWITCH	AS REMOVED
32TS1-3	SWITCH	AS REMOVED
40143	SWITCH	AS REMOVED
40143	SWITCH	AS REMOVED
40143	SWITCH	AS REMOVED
40173	SWITCH	AS REMOVED
40173	SWITCH	AS REMOVED
426EN10-8	SWITCH	AS REMOVED
42d87	SWITCH	AS REMOVED
8905K935	SWITCH	AS REMOVED
97564	SWITCH	AS REMOVED
BAC-C18R15B	SWITCH	AS REMOVED
BACS30AN1	SWITCH	AS REMOVED
8DJ81WAG	INDICADOR N1	AS REMOVED
8DJ81WAG	INDICADOR N1	AS REMOVED
8DJ81WAG	INDICADOR N1	AS REMOVED
805506	FIRE BOTTLE	AS REMOVED
2585803-1	AIR DATA SENSOR	AS REMOVED
382300-1	FUEL BOOSTER PUMP-SELF PRIMING	AS REMOVED
AG113C1	LIGHT ASSEMBLY	AS REMOVED
G-1966B	ATC PANEL	AS REMOVED
96487	PNEUMATIC SENSOR	AS REMOVED
96487	PNEUMATIC SENSOR	AS REMOVED
96487	PNEUMATIC SENSOR	AS REMOVED
96487	PNEUMATIC SENSOR	AS REMOVED
96487	PNEUMATIC SENSOR	AS REMOVED
07-3010-9-0002	ANTI-ICE	AS REMOVED
898126-2-1	REGULATOR - DIFERENTIAL PRESSURE	AS REMOVED
898126-2-1	REGULATOR - DIFERENTIAL PRESSURE	AS REMOVED
04050-10-1	TURBINE COOLING	AS REMOVED
A41869-10-021	IND. SERVOED ALTIMETER	AS REMOVED
2223574	FLIGHT DATA PANEL	AS REMOVED
G-4773	PANEL DE NAVEGACION	AS REMOVED
10-60552-11	HYDRAULIC PRESSURE SWITCH	AS REMOVED
10-60552-11	HYDRAULIC PRESSURE SWITCH	AS REMOVED
10-60722-4	TANK UNIT INDICATION	AS REMOVED
12505A	CONTACTEUR TRIPOLAIRE INVERSEUR	AS REMOVED
2585805-2	ROLL CONTROL CHANNEL	AS REMOVED
371900	ENGINE FUEL PUMP	AS REMOVED
371900	ENGINE FUEL PUMP	AS REMOVED
522-4088-003	VHF TRANCEIVER	AS REMOVED

Part Number	Part Description	Condition
522-4088-203	TRANSCEIVER VHF	AS REMOVED
522-4088-203	TRANSCEIVER VHF	AS REMOVED
525374	ACTUATOR ROTARY	AS REMOVED
525374	ACTUATOR ROTARY	AS REMOVED
525374	ACTUATOR ROTARY	AS REMOVED
525374	ACTUATOR ROTARY	AS REMOVED
525374	ACTUATOR ROTARY	AS REMOVED
525374	ACTUATOR ROTARY	AS REMOVED
525374	ACTUATOR ROTARY	AS REMOVED
525374	ACTUATOR ROTARY	AS REMOVED
525374	ACTUATOR ROTARY	AS REMOVED
541932-1-1	ACTUADOR VALVULA MARIPOSA	AS REMOVED
6042H152	RELAY 200 AMP	AS REMOVED
A-61499	VALVE - PRESSURE	AS REMOVED
4034559-901	VOR/DME INDICATOR	AS REMOVED
4034559-901	VOR/DME INDICATOR	AS REMOVED
231-2	CONTROL-WINDOW HEAT	AS REMOVED
231-2	CONTROL-WINDOW HEAT	AS REMOVED
H10-1027-1	SWITCH-FLAP,SLAT IND	AS REMOVED
H10-1027-1	SWITCH-FLAP,SLAT IND	AS REMOVED
H10-1027-1	SWITCH-FLAP,SLAT IND	AS REMOVED
14-013022	AMPLIFIER DIRECTION	AS REMOVED
10-60552-35	SWITCH ASSY	AS REMOVED
10-60552-35	SWITCH ASSY	AS REMOVED
243600	MAIN GEAR FUEL PUMP	AS REMOVED
243600	MAIN GEAR FUEL PUMP	AS REMOVED
243600	MAIN GEAR FUEL PUMP	AS REMOVED
614937-10	COMPASS SYSTEM RACK	AS REMOVED
614937-10	COMPASS SYSTEM RACK	AS REMOVED
10-3223-7	TRANSMITTER PRESSURE HYD	AS REMOVED
10-3269-8	PRESSURE SWITCH	AS REMOVED
10-3269-8	PRESSURE SWITCH	AS REMOVED
42D107A1	PRESSURE SWITCH	AS REMOVED
42D107A1	PRESSURE SWITCH	AS REMOVED
42D107A1	PRESSURE SWITCH	AS REMOVED
42D107A1	PRESSURE SWITCH	AS REMOVED
42D107A1	PRESSURE SWITCH	AS REMOVED
42D107A1	PRESSURE SWITCH	AS REMOVED
42D107A1	PRESSURE SWITCH	AS REMOVED
42D107A1	PRESSURE SWITCH	AS REMOVED
42D122	PRESSURE SWITCH	AS REMOVED
42D122	PRESSURE SWITCH	AS REMOVED
42D122	PRESSURE SWITCH	AS REMOVED
98087-1106P12	PRESSURE SWITCH	AS REMOVED
98087-1106P12	PRESSURE SWITCH	AS REMOVED
350020	BARRY ENGINE MOUNT	AS REMOVED
R18207-47BR	BARRY	AS REMOVED

Part Number	Part Description	Condition
2585981-2	AIR DATA CALIBRATOR SP-50 FLIGHT CONTROL SYSTEM	AS REMOVED
512776	AURAL WARNING DEVICE	AS REMOVED
88000-4102	CLOCK	AS REMOVED
961-5023-001	WIND SHIELD TEPERATURE CONTOL	AS REMOVED
961-5023-001	WIND SHIELD TEPERATURE CONTOL	AS REMOVED
961-5023-001	WIND SHIELD TEPERATURE CONTOL	AS REMOVED
961-5023-001	WIND SHIELD TEPERATURE CONTOL	AS REMOVED
961-5023-001	WIND SHIELD TEPERATURE CONTOL	AS REMOVED
915F213-4	PANEL BUS PROTECTION	AS REMOVED
066-1019-23	DME	AS REMOVED
705-7V9	HORIZON STANDBYE	AS REMOVED
705-7-V9	HORIZON GYRO	AS REMOVED
894120	SONDA DETECTORA DE INCENDIO	AS REMOVED
894120	SONDA DETECTORA DE INCENDIO	AS REMOVED
42668-9	GAGE PRESSURE SWITCH	AS REMOVED
162BL704D	INDICADOR TEMP OIL	AS REMOVED
162BL704D	INDICADOR TEMP OIL	AS REMOVED
893927	PNEUMATIC BRAKE CONTROL BOTTLE	AS REMOVED
901-212-2026	PANEL VHF NAV	AS REMOVED
901-212-2026	PANEL VHF NAV	AS REMOVED
901-212-2026	PANEL VHF NAV	AS REMOVED
522-4089-004	TRANS/AVE VHF	AS REMOVED
65-23467-6	CAJA DE ENGRANAJE	AS REMOVED
65-2661-30	CAJA DE ENGRANAJES	AS REMOVED
50234	HYDRAULIC PRESSURE SWITCH	AS REMOVED
066-1060-00	VOR	AS REMOVED
10-3205-1	VALVE	AS REMOVED
321674-4-1	VALVE	AS REMOVED
321674-4-1	VALVE	AS REMOVED
4057	VALVE	AS REMOVED
ASSY 714810 All	VALVE	AS REMOVED
B-2700-14	VALVE	AS REMOVED
B-2700-14	VALVE	AS REMOVED
705-7V4	HORIZON STANDBY	AS REMOVED
705-7V4	HORIZON STANDBY	AS REMOVED
172934-001	RELAY, FMCS TRANSFER	AS REMOVED
172934-001	RELAY, FMCS TRANSFER	AS REMOVED
172934-001	RELAY, FMCS TRANSFER	AS REMOVED
172934-001	RELAY, FMCS TRANSFER	AS REMOVED
172934-001	RELAY, FMCS TRANSFER	AS REMOVED
172938-001	RELEVO	AS REMOVED
172938-001	RELEVO	AS REMOVED

Part Number	Part Description	Condition
32-2861-001	VALVULA DE PURGA AIR CONDITION	AS REMOVED
32-2861-001	VALVULA DE PURGA AIR CONDITION	AS REMOVED
396088-3-1	VALVULA CONTROL FLUJO	AS REMOVED
396088-3-1	VALVULA CONTROL FLUJO	AS REMOVED
40142	SLAT SWITCH	AS REMOVED
49988	IGNITOR EXCITER	AS REMOVED
49988	IGNITOR EXCITER	AS REMOVED
49988	IGNITOR EXCITER	AS REMOVED
743522-1	ENGINE CONTROL	AS REMOVED
959960712303	RADIOALTIMETRE ANTENNA	AS REMOVED
9599-607-12303	RADIOALTIMETRE ANTENNA	AS REMOVED
430531	COOLING EFFECT DETECTOR	AS REMOVED
ST-7R	OIL PRESS TRANSMITTER	AS REMOVED
ST-7R	OIL PRESS TRANSMITTER	AS REMOVED
ST-7R	OIL PRESS TRANSMITTER	AS REMOVED
ST-7R	OIL PRESS TRANSMITTER	AS REMOVED
ST-7R	OIL PRESS TRANSMITTER	AS REMOVED
ST-7R	OIL PRESS TRANSMITTER	AS REMOVED
ST-7R	OIL PRESS TRANSMITTER	AS REMOVED
ST-7R	OIL PRESS TRANSMITTER	AS REMOVED
522-4114-003	IND-RADIO ALTIMETER	AS REMOVED
522-4114-003	IND-RADIO ALTIMETER	AS REMOVED
522-4114-003	IND-RADIO ALTIMETER	AS REMOVED
522-4114-003	IND-RADIO ALTIMETER	AS REMOVED
522-4114-003	IND-RADIO ALTIMETER	AS REMOVED
522-4114-003	IND-RADIO ALTIMETER	AS REMOVED
1780607-5	FLIGHT DIRECTOR	AS REMOVED
1780607-5	FLIGHT DIRECTOR	AS REMOVED
1780607-5	FLIGHT DIRECTOR	AS REMOVED
777-1253-001	FLIGHT DIRECTOR	AS REMOVED
G-1080	NAV WARN ANNUCIATOR	AS REMOVED
G-1080	NAV WARN ANNUCIATOR	AS REMOVED
G-1080	NAV WARN ANNUCIATOR	AS REMOVED
G-1080	NAV WARN ANNUCIATOR	AS REMOVED
G-2915	FLIGHT DIRECTOR	AS REMOVED
G-5651	NAV-DME CONTROL PANEL	AS REMOVED
42D377	DEIFFERENTIAL PRESS SWITCH	AS REMOVED
453-5000-730	ELT	AS REMOVED
453-5000-730	ELT	AS REMOVED
391097-16007	GAGE FUEL TANK UNIT CAPACITOR TYPE	AS REMOVED
391097-16012	GAGE FUEL TANK UNIT CAPACITOR TYPE	AS REMOVED
391097-16013	GAGE FUEL TANK	AS REMOVED
391097-16015	GAGE FUEL TANK UNIT CAPACITOR TYPE	AS REMOVED

Part Number	Part Description	Condition
391097-16015	GAGE FUEL TANK UNIT CAPACITOR TYPE	AS REMOVED
391097-16016	GAGE FUEL TANK UNIT CAPACITOR TYPE	AS REMOVED
391097-16017	GAGE FUEL TANK UNIT CAPACITOR TYPE	AS REMOVED
391097-16017	GAGE FUEL TANK UNIT CAPACITOR TYPE	AS REMOVED
1372-579788	SAFETY VALVE DOOR	AS REMOVED
1372-579788	SAFETY VALVE DOOR	AS REMOVED
1372-579788	SAFETY VALVE DOOR	AS REMOVED
3601030-5	SWITCH CENTRIFUGAL	AS REMOVED
3601030-5-1	SWITCH CENTRIFUGAL	AS REMOVED
3601030-5-1	SWITCH CENTRIFUGAL	AS REMOVED
3609480-5-1	SWITCH CENTRIFUGAL	AS REMOVED
3609480-5-1	SWITCH CENTRIFUGAL	AS REMOVED
3609480-5-1	SWITCH CENTRIFUGAL	AS REMOVED
2566A-21	ANGLE OF AIRFLOW SENSOR	AS REMOVED
2566A-21	ANGLE OF AIRFLOW SENSOR	AS REMOVED
2566A-21	ANGLE OF AIRFLOW SENSOR	AS REMOVED
2566A-21	ANGLE OF AIRFLOW SENSOR	AS REMOVED
2566A-21	ANGLE OF AIRFLOW SENSOR	AS REMOVED
391012-01001	TRANSMITTER QTY OIL	AS REMOVED
391012-01001	TRANSMITTER QTY OIL	AS REMOVED
391012-01001	TRANSMITTER QTY OIL	AS REMOVED
391012-01001	TRANSMITTER QTY OIL	AS REMOVED
391012-01001	TRANSMITTER QTY OIL	AS REMOVED
391012-01001	TRANSMITTER QTY OIL	AS REMOVED
391012-01001	TRANSMITTER QTY OIL	AS REMOVED
391012-01001	TRANSMITTER QTY OIL	AS REMOVED
391012-01001	TRANSMITTER QTY OIL	AS REMOVED
391012-01001	TRANSMITTER QTY OIL	AS REMOVED
391012-01001	TRANSMITTER QTY OIL	AS REMOVED
391012-01001	TRANSMITTER QTY OIL	AS REMOVED
391012-01001	TRANSMITTER QTY OIL	AS REMOVED
391012-01001	TRANSMITTER QTY OIL	AS REMOVED
391012-01001	TRANSMITTER QTY OIL	AS REMOVED
391012-01001	TRANSMITTER QTY OIL	AS REMOVED
214C50-2	SWITCH-PRESSURE	AS REMOVED
H14-1000	SWITCH HERMETIC	AS REMOVED
ID-998	INDICATOR RADIO	AS REMOVED
642775J	CAJA DE ACCESORIOS	AS REMOVED
65-23559-42	GEAR BOX TRANSMISSION FLAP	AS REMOVED
MAS671517VI	GEARBOX	AS REMOVED
10-614500-1	EXCITER	AS REMOVED
10-614500-1	EXCITER	AS REMOVED

Part Number	Part Description	Condition
2087821-2815	MARKER RECEIVER	AS REMOVED
2CM9 ABH7	GENERATOR TACHOMETER TWO POLE	AS REMOVED
2CM9ABH7	GENERATOR TACHOMETER	AS REMOVED
2CM9ABH7	GENERATOR TACHOMETER	AS REMOVED
2CM9ABH7	GENERATOR TACHOMETER	AS REMOVED
2CM9ABH7	GENERATOR TACHOMETER	AS REMOVED
2CM9ABH7	GENERATOR TACHOMETER	AS REMOVED
2CM9ABH7	GENERATOR TACHOMETER	AS REMOVED
2CM9ABH7	GENERATOR TACHOMETER	AS REMOVED
365-502-9001	GENERATOR TACHOMETER	AS REMOVED
365-502-9001	GENERATOR TACHOMETER	AS REMOVED
473049	FUEL UNIT	AS REMOVED
473925	CARGO ELECTRONIC UNIT	AS REMOVED
65-57910-1	VALVE ASSY BRAKE	AS REMOVED
65-60212-11	ANNUNCIATOR ASSY	AS REMOVED
705-7-V4	HORIZON GYRO	AS REMOVED
749965	CYLINDER	AS REMOVED
749965	CYLINDER	AS REMOVED
FT1141	1500 VA AUTOTRANSFORMER	AS REMOVED
65-57910-2	VALVULA DE FRENADO	AS REMOVED
108032-9	AIR PRESSURE REGULATOR	AS REMOVED
108032-9	AIR PRESSURE REGULATOR	AS REMOVED
61606	CAP PRESSURE FUEL SERVICING	AS REMOVED
61606	CAP PRESSURE FUEL SERVICING	AS REMOVED
ED47F109	DIGITAL FLIGHT	AS REMOVED
548003	FUEL OIL COOLER	AS REMOVED
548003	FUEL OIL COOLER	AS REMOVED
548003	FUEL OIL COOLER	AS REMOVED
B0247 81107	MATCH AIRSPEED INDICATOR	AS REMOVED
522-4255-001	LRRA ANTENNA	AS REMOVED
522-4255-001	LRRA ANTENNA	AS REMOVED
522-4255-007	LRRA ANTENNA	AS REMOVED
066-1060-48	NAVIGATION UNIT VHF	AS REMOVED
066-1060-48	NAVIGATION UNIT VHF	AS REMOVED
066-1060-48	NAVIGATION UNIT VHF	AS REMOVED
066-1060-48	NAVIGATION UNIT VHF	AS REMOVED
066-1060-48	NAVIGATION UNIT VHF	AS REMOVED
066-1060-48	NAVIGATION UNIT VHF	AS REMOVED
066-1060-48	NAVIGATION UNIT VHF	AS REMOVED
894128	PROTECTOR CABLE	AS REMOVED
10-60895-1	Estático inverter	AS REMOVED
6574	Actuating haddle. Assy	AS REMOVED
A61446-4	VALVE BY-PASS	AS REMOVED
129475	VALVULA ANTI ICE	AS REMOVED
129475	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED

Part Number	Part Description	Condition
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
320115	VALVULA ANTI ICE	AS REMOVED
39-043A	ANTI-SKID-MAIN	AS REMOVED
39-043A	ANTI-SKID-MAIN	AS REMOVED
976065-6	CONTROL HYDRAULIC VALVE	AS REMOVED
064-1005-02	VHF TRANS	AS REMOVED
064-1005-02	VHF TRANS	AS REMOVED
064-1005-02	VHF TRANS	AS REMOVED
745608	HEATER	AS REMOVED
10-381750-1	UNIDAD DE INGNIVION	AS REMOVED
S65-8262-2A	ANTENNA VHF COMM	AS REMOVED
S65-8262-2A	ANTENNA VHF COMM	AS REMOVED
S65-8262-2A	ANTENNA VHF COMM	AS REMOVED
S65-8262-2A	ANTENNA VHF COMM	AS REMOVED
S65-8262-2A	ANTENNA VHF COMM	AS REMOVED
622-1181-008	TRANSCEIVER VHF	AS REMOVED
24142-D2	RELAY	AS REMOVED
6042H156	RELAY	AS REMOVED
6042H22	RELAY	AS REMOVED
6042H91	RELAY	AS REMOVED
91248073	RELAY	AS REMOVED
9124-8075	RELAY	AS REMOVED
9124-8075	RELAY	AS REMOVED

Part Number	Part Description	Condition
378200	BOMBA COMBUSTIBLE	AS REMOVED
378200	BOMBA COMBUSTIBLE	AS REMOVED
378200	BOMBA COMBUSTIBLE	AS REMOVED
378200	BOMBA COMBUSTIBLE	AS REMOVED
378200	BOMBA COMBUSTIBLE	AS REMOVED
401-60272-8A	ELEVADOR FEED	AS REMOVED
40TP13-5	NEWBURG PACK	AS REMOVED
40TP13-5	NEWBURG PACK	AS REMOVED
40TP13-5	NEWBURG PACK	AS REMOVED
40TP13-5	NEWBURG PACK	AS REMOVED
40TP13-5	NEWBURG PACK	AS REMOVED
522-4058-001	CONTROL	AS REMOVED
522-4058-001	CONTROL	AS REMOVED
522-4088-001	VHF TRANCEIVER	AS REMOVED
5-89357-33	WINDOW N4 ASSY	AS REMOVED
5-89357-33	WINDOW N4 ASSY	AS REMOVED
5-89357-33	WINDOW N4 ASSY	AS REMOVED
59100-5015	LOWER RUDER CONTROL PACKAGE	AS REMOVED
65-17821-14	MODULO SYS A HYD	AS REMOVED
65-17821-14	MODULO SYS A HYD	AS REMOVED
65-17826-4	STMBY HYD	AS REMOVED
87521-3	OIL COOLER	AS REMOVED
90G183	SWITCH, HYD PRESSURE	AS REMOVED
90G183	SWITCH, HYD PRESSURE	AS REMOVED
ELP-362D	ULB	AS REMOVED
G-6076	PANEL COMM CONTROL	AS REMOVED
69-14106-1	ACUMULADOR HYD	AS REMOVED
60-1321-1	BATTERY POWER SUPPLY	AS REMOVED
60-1321-1	BATTERY POWER SUPPLY	AS REMOVED
52-617-501	ACTUADOR	AS REMOVED
1056350	ANTI SKID VALVE	AS REMOVED
1056350	ANTI SKID VALVE	AS REMOVED
10-60495-3	AIR SHUTOFF - VALVE ASSY	AS REMOVED
10-60495-3	AIR SHUTOFF - VALVE ASSY	AS REMOVED
8DJ81LWN2	N2 INDICATOR	AS REMOVED
8DJ81LYV4	N2 INDICATOR	AS REMOVED
65-23467-5	CAJA DE FLAP DRIVE	AS REMOVED
750056-1	EMEGERCY LOCATION TRANSMITER	AS REMOVED
787-6366-005	PANEL, ADF CONTROL	AS REMOVED
A25B8904	AIRCRAFT TRANSFORMER	AS REMOVED
18-1738-9	FLAPS POS TRANSMITTR	AS REMOVED
658385	PRBC	AS REMOVED

Part Number	Part Description	Condition
658385	PRBC	AS REMOVED
658385	PRBC	AS REMOVED
658385B	PRBC	AS REMOVED
790312	CONTROL ASSY	AS REMOVED
790312	CONTROL ASSY	AS REMOVED
804-1212	miniQAR unit	AS REMOVED
KN53	NAVEGATION GLIDESLOPE RECEIVER	AS REMOVED
10500-1	MOTOR PUMP	AS REMOVED
65-17830-12	HYDRAULIC ACTUATOR ASSEMBLY MAIN GEAR	AS REMOVED
71300-5009	VALVE ASSY-LOCKOUT	AS REMOVED
71300-5009	VALVE ASSY-LOCKOUT	AS REMOVED
71-300-5009	SOPORTE BUSTER	AS REMOVED
743802-3	FUEL CONTROL UNIT	AS REMOVED
21520-1	FAN GASPER	AS REMOVED
21520-1	FAN GASPER	AS REMOVED
522-3698-003	R/T UNIT	AS REMOVED
522-3698-003	R/T UNIT	AS REMOVED
522-3698-003	R/T UNIT	AS REMOVED
522-3698-003	R/T UNIT	AS REMOVED
522-3698-003	R/T UNIT	AS REMOVED
522-3698-003	R/T UNIT	AS REMOVED
522-3698-003	R/T UNIT	AS REMOVED
522-3698-003	R/T UNIT	AS REMOVED
10-60522-25	MEASURING STICK	AS REMOVED
1783180-7	AMPL RACK	AS REMOVED
1783180-7	AMPL RACK	AS REMOVED
011-00280-10	GPS	AS REMOVED
011-00280-10	GPS	AS REMOVED
011-00280-10	GPS	AS REMOVED
622-2921-002	DME TRANSCEIVER	AS REMOVED
011-00054-00	GPS	AS REMOVED
233145	VALVE MOTOR	AS REMOVED
522-2357-016	ADF CONTROL	AS REMOVED
522-2357-016	ADF CONTROL	AS REMOVED
522-2357-016	ADF CONTROL	AS REMOVED
522-2357-016	ADF CONTROL	AS REMOVED
714810AI	VALVE FUEL PRESSURIZING	AS REMOVED
965-0376-070	COMPUTER GPWS MARK 1	AS REMOVED
MS9 391130ZE	HYDRAULIC MOTOR	AS REMOVED
452-0133	BATTERY PACK	AS REMOVED
452-0133	BATTERY PACK	AS REMOVED
452-0133	BATTERY PACK	AS REMOVED

Part Number	Part Description	Condition
AV13J5145	VALVE-ASSY, MOTORED	AS REMOVED
68040-5001	ELEVADOR POWER UNIT	AS REMOVED
7350000	ISOLATOR-ENGINE	AS REMOVED
65-3756817	LANDING GEAR ACCESSORY UNIT	AS REMOVED
10-3324-11	BUS PROTECTION PANEL	AS REMOVED
10-60954-1	BUS PROTECTION PANEL	AS REMOVED
902F283-2	BUS PROTECTION PANEL	AS REMOVED
013-00235-00	GPS ANTENA	AS REMOVED
1550	DC MOTOR	AS REMOVED
4038930-902	HORIZ SITUATION IND MODEL RD 700A	AS REMOVED
1-899-15	PROXIMITY SENSOR	AS REMOVED
522-2450-014	VOR/ILS	AS REMOVED
522-2450-014	VOR/ILS	AS REMOVED
3581050a	Mask crew o2	AS REMOVED
320362-2-1	BLEED VALVE	AS REMOVED
622-2883-001	POWER AMPL PWR-200	AS REMOVED
BAC10-60954-1	BUS PROTECTION PANEL	AS REMOVED
P10-0090002	FLAP+SLATS ANNCTR	AS REMOVED
10-60579-1	VALVE ASSY DOOR	AS REMOVED
2291542	SPINNER	AS REMOVED
60-2388-101	POWER UNIT	AS REMOVED
60-2388-101	POWER UNIT	AS REMOVED
60-2388-101	POWER UNIT	AS REMOVED
60-2388-101	POWER UNIT	AS REMOVED
60-2388-101	POWER UNIT	AS REMOVED
7505639	FILTER ASSEMBLY	AS REMOVED
153460	ROTARY SELECTOR	AS REMOVED
108032-8	VALVULA REGULADORA	AS REMOVED
392704-1-1	VALVULA REGULADORA	AS REMOVED
892809-0400-01	CONTROL UNIT DETECT	AS REMOVED
892809-0400-01F	CONTROL UNIT DETECT	AS REMOVED
ST-104Z	TRANSMITTER PRESSURE	AS REMOVED
ST-104Z	TRANSMITTER PRESSURE	AS REMOVED
ST-104Z	TRANSMITTER PRESSURE	AS REMOVED
ST-104Z	TRANSMITTER PRESSURE	AS REMOVED
ST-104Z	TRANSMITTER PRESSURE	AS REMOVED
ST-104Z	TRANSMITTER PRESSURE	AS REMOVED
10-60554-2	FUEL HYDRAULIC QUANTITY	AS REMOVED
65-60211-32	ACCESSORY UNIT ASSY LG	AS REMOVED
65-60211-32	ACCESSORY UNIT ASSY LG	AS REMOVED
65-60211-32	ACCESSORY UNIT ASSY LG	AS REMOVED
8TJ95GAB3	FLOW METER FUEL	AS REMOVED
65-17978-2	VÁLVULA GIRATORIA	AS REMOVED
56024-003	ACTUATOR AUTO PILOT (ELECTRIC)	AS REMOVED
56024-003	ACTUATOR AUTO PILOT (ELECTRIC)	AS REMOVED

Part Number	Part Description	Condition
56024-003	ACTUATOR AUTO PILOT (ELECTRIC)	AS REMOVED
79039145	ACTUATOR DC	AS REMOVED
SEL-0C19D	EGT INDICATOR	AS REMOVED
SEL-0C19D	EGT INDICATOR	AS REMOVED
SEL-0C19D	EGT INDICATOR	AS REMOVED
SEL-0C19D	EGT INDICATOR	AS REMOVED
40-835	TRASDUCER ANTI SKID	AS REMOVED
40-835	TRASDUCER ANTI SKID	AS REMOVED
2607949G	OUTBOARD WHEEL HALF	AS REMOVED
2607949G	OUTBOARD WHEEL HALF	AS REMOVED
75130 A	SERVO VALVE	AS REMOVED
75130 A4080	SERVO VALVE	AS REMOVED
75130A2080	SERVO VALVE	AS REMOVED
75130-A4090	SERVO VALVE	AS REMOVED
522-1837-000	ADF ANTENNA	AS REMOVED
522-1837-000	ADF ANTENNA	AS REMOVED
522-3761-001	ADF ANTENNA	AS REMOVED
2585805-1	ROLL CONTROL CHANNEL	AS REMOVED
2585805-1	ROLL CONTROL CHANNEL	AS REMOVED
593764	PRESSURE RATIO BLEED CONTROL	AS REMOVED
2601182	BREAKER ASSY	AS REMOVED
82402-4472R170	BRAKE STABILIZER TRIM SYSTEM	AS REMOVED
82402-4472R170	BRAKE STABILIZER TRIM SYSTEM	AS REMOVED
10-3068-4	SHUTOFF VALVE	AS REMOVED
10-3068-4	SHUTOFF VALVE	AS REMOVED
10-3068-4	SHUTOFF VALVE	AS REMOVED
10-3068-4	SHUTOFF VALVE	AS REMOVED
10-3068-4	SHUTOFF VALVE	AS REMOVED
10-3068-4	SHUTOFF VALVE	AS REMOVED
10-3068-4	SHUTOFF VALVE	AS REMOVED
10-3068-4	SHUTOFF VALVE	AS REMOVED
129115	SHUTOFF VALVE	AS REMOVED
1U1136	SHUTOFF VALVE	AS REMOVED
1U1136	SHUTOFF VALVE	AS REMOVED
1U1136	SHUTOFF VALVE	AS REMOVED
392716-1-1	SHUTOFF VALVE	AS REMOVED
392716-1-1	SHUTOFF VALVE	AS REMOVED
392716-1-1	SHUTOFF VALVE	AS REMOVED
392716-1-1	SHUTOFF VALVE	AS REMOVED
392716-1-1	SHUTOFF VALVE	AS REMOVED
392716-1-1	SHUTOFF VALVE	AS REMOVED
392716-1-1	SHUTOFF VALVE	AS REMOVED
392716-1-1	SHUTOFF VALVE	AS REMOVED
392716-3-1	VALVE SHUTOFF	AS REMOVED
392716-3-1	VALVE SHUTOFF	AS REMOVED
4890509	VALVE SHUTT OFF	AS REMOVED
979414-1-1	SHUTOFF VALVE	AS REMOVED

Part Number	Part Description	Condition
AVI6B1330D	VALVE SHUTT OFF	AS REMOVED
V5000-40	VALVE SHUTOFF	AS REMOVED
V5000-40	VALVE SHUTOFF	AS REMOVED
V5000-40	VALVE SHUTOFF	AS REMOVED
V5000-40	VALVE SHUTOFF	AS REMOVED
73016	VALVE ASSY-SERVO	AS REMOVED
522-2996-011	MARKER BEACON RECEIVER	AS REMOVED
522-2996-011	MARKER BEACON RECEIVER	AS REMOVED
522-2996-011	MARKER BEACON RECEIVER	AS REMOVED
522-2996-018	MARKER BEACON RECEIVER	AS REMOVED
10-319647-1	IGNITER	AS REMOVED
314160-2	AIR PRESSURE	AS REMOVED
344C-1K	INSTRUMENT AMPLIFIER	AS REMOVED
7500203	FILTER FLUID PRESSURE	AS REMOVED
7500203	FILTER FLUID PRESSURE	AS REMOVED
522-2450-114	VOR/ILS RECEIVER	AS REMOVED
522-2450-114	VOR/ILS RECEIVER	AS REMOVED
522-2450-114	VOR/ILS RECEIVER	AS REMOVED
522-2450-114	VOR/ILS RECEIVER	AS REMOVED
522-2450-114	VOR/ILS RECEIVER	AS REMOVED
522-2450-114	VOR/ILS RECEIVER	AS REMOVED
522-2450-114	VOR/ILS RECEIVER	AS REMOVED
522-2450-114	VOR/ILS RECEIVER	AS REMOVED
080-20325-01	TRANSFORMER RECTIFIER	AS REMOVED
080-20325-01	TRANSFORMER RECTIFIER	AS REMOVED
10-60554-13	IND,HYD OIL QTY	AS REMOVED
10-60554-13	IND,HYD OIL QTY	AS REMOVED
10-60554-13	IND,HYD OIL QTY	AS REMOVED
123562-2-1	CHECK VALVE	AS REMOVED
123562-2-1	CHECK VALVE	AS REMOVED
259-0050-501	NOSE DOWN	AS REMOVED
65-17810-9	NLG HYD LOCK	AS REMOVED
69-17379-18	NOSE GEAR BRAKE PANEL	AS REMOVED
976498-1	ASSY GENERATOR	AS REMOVED
22-3100-4-0074	CONTROL PANEL PITOT STATIC	AS REMOVED
066-1060-50	VOR/ILS	AS REMOVED
320115 C	VALVE AIR SHUT OFF	AS REMOVED
320115 C	VALVE AIR SHUT OFF	AS REMOVED
320115 C	VALVE AIR SHUT OFF	AS REMOVED
320115CAL	VALVE AIR SHUT OFF	AS REMOVED
52-2861-001	VALVE AIR SHUT OFF	AS REMOVED
2587335-113	VERTICAL GYRO	AS REMOVED
2587335-12	VERTICAL GYRO	AS REMOVED
2587335-12	VERTICAL GYRO	AS REMOVED
147265	MOTOR VALVE ASSEMBLY	AS REMOVED
53114	EPR INDICATOR	AS REMOVED

Part Number	Part Description	Condition
JG298A4	EPR INDICATOR	AS REMOVED
JG298A5	EPR INDICATION	AS REMOVED
JG298A5	EPR INDICATION	AS REMOVED
JG298A5	EPR INDICATION	AS REMOVED
522-3867-003	INDICATOR FLIGHT DIRECTOR	AS REMOVED
772-5005-005	INDICATOR FLIGHT DIRECTOR	AS REMOVED
40-836	ROTATORY WHEEL SPEED ANTI SKID	AS REMOVED
321402-1-1	MIXING VALVE	AS REMOVED
321402-1-1	MIXING VALVE	AS REMOVED
522-4057-010	VOICE RECORDER	AS REMOVED
2593564-919	ALTITUDE SELECTOR CONTROLLER	AS REMOVED
10-60841-10	SPOILER MIXER	AS REMOVED
10-60841-8	SPOILER MIXER	AS REMOVED
41400-600	SPOILER MIXER	AS REMOVED
1783662-015	PICTORIAL DEVIATION INDICATOR	AS REMOVED
DAC7611925	AUTOTRANSFORMER ASSY	AS REMOVED
066-01127-1301	ATC TRANSPONDER	AS REMOVED
2087821-2801	MARKER RECEIVER	AS REMOVED
393026-03236	FUEL QTY INDICATOR	AS REMOVED
393026-03236	FUEL QTY INDICATOR	AS REMOVED
393026-03236	FUEL QTY INDICATOR	AS REMOVED
393026-03236	FUEL QTY INDICATOR	AS REMOVED
393026-03236	FUEL QTY INDICATOR	AS REMOVED
393026-03236	FUEL QTY INDICATOR	AS REMOVED
393026-03236	FUEL QTY INDICATOR	AS REMOVED
393026-03236	FUEL QTY INDICATOR	AS REMOVED
393026-03236	FUEL QTY INDICATOR	AS REMOVED
393026-03236	FUEL QTY INDICATOR	AS REMOVED
5-89358-42	WINDOW N5 ASSY	AS REMOVED
633758	FRONT ACCESORY DRIVE COVER	AS REMOVED
633758	FRONT ACCESORY DRIVE COVER	AS REMOVED
65-24482-93	UPLOCK ASSY	AS REMOVED
965-0876-030	WARNING COMPUTER	AS REMOVED
AV24E1144	VALVE BYPASS	AS REMOVED
522-2702-054	DME INTERROGATOR	AS REMOVED
30-0906-101	STROBE LIGHT	AS REMOVED
30-0906-101	STROBE LIGHT	AS REMOVED
30-0906-101	STROBE LIGHT	AS REMOVED
30-0906-101	STROBE LIGHT	AS REMOVED
30-0906-101	STROBE LIGHT	AS REMOVED
30-0906-101	STROBE LIGHT	AS REMOVED
1U1110	ACTUADOR FLAP	AS REMOVED
1U1110	ACTUADOR FLAP	AS REMOVED
1U1110	ACTUADOR FLAP	AS REMOVED
1U1110	ACTUADOR FLAP	AS REMOVED
1U1110	ACTUADOR FLAP	AS REMOVED
1U1110	ACTUADOR FLAP	AS REMOVED
1U1110	ACTUADOR FLAP	AS REMOVED

Part Number	Part Description	Condition
1U1110	ACTUADOR FLAP	AS REMOVED
1U1110	ACTUADOR FLAP	AS REMOVED
1U1110	ACTUADOR FLAP	AS REMOVED
1U1110	ACTUADOR FLAP	AS REMOVED
522-2703-00	ATC TRANSPONDER	AS REMOVED
69-37316-14	MODULO AUTO PILOT WALLER	AS REMOVED
717000	Main Accessory Gearbox	AS REMOVED
717000	Main Accessory Gearbox	AS REMOVED
182770	RUDER TRIM POSITION	AS REMOVED
21450-14	SPOILER ACTUATOR	AS REMOVED
21450-14	SPOILER ACTUATOR	AS REMOVED
21450-14	SPOILER ACTUATOR	AS REMOVED
21450-14	SPOILER ACTUATOR	AS REMOVED
21450-14	SPOILER ACTUATOR	AS REMOVED
21450-14	SPOILER ACTUATOR	AS REMOVED
21450-14	SPOILER ACTUATOR	AS REMOVED
21450-14	SPOILER ACTUATOR	AS REMOVED
21450-14	SPOILER ACTUATOR	AS REMOVED
21450-14	SPOILER ACTUATOR	AS REMOVED
21450-14	SPOILER ACTUATOR	AS REMOVED
65-45314-7	VHF/SEL CAL	AS REMOVED
65-45314-7	VHF/SEL CAL	AS REMOVED
10-60922-3	AIR SPEED INDICATOR	AS REMOVED
152BL801C	INDICATOR EXHAUST GAS TEMPERATURE	AS REMOVED
30-0837-5	ANTI-COLLISION LIGHT	AS REMOVED
10-60091-101	EMERGENCY EXIT POWER SUPPLY	AS REMOVED
761260-8	ELEC PRESSURE CONTROLLER	AS REMOVED
761260-8	ELEC PRESSURE CONTROLLER	AS REMOVED
93 A 100-30	COCKPIT VOICE RECORDER	AS REMOVED
93-A100-30	COCKPIT VOICE RECORDER	AS REMOVED
93-A100-30	COCKPIT VOICE RECORDER	AS REMOVED
071-01480-0017	ATC CONTROL PANEL	AS REMOVED
071-01480-0017	ATC CONTROL PANEL	AS REMOVED
071-01480-0017	ATC CONTROL PANEL	AS REMOVED
10114-C	OPERATING POWER UNIT	AS REMOVED
691962A	LOAD CONTROLLER GENERATOR DRIVE	AS REMOVED
805500-12	FIRE EXTINGUISHER BOTTLE	AS REMOVED
805500-12	FIRE EXTINGUISHER BOTTLE	AS REMOVED
805500-12	FIRE EXTINGUISHER BOTTLE	AS REMOVED
805500-12	FIRE EXTINGUISHER BOTTLE	AS REMOVED
805500-12	FIRE EXTINGUISHER BOTTLE	AS REMOVED
805500-12	FIRE EXTINGUISHER BOTTLE	AS REMOVED
805500-12	FIRE EXTINGUISHER BOTTLE	AS REMOVED
805500-12	FIRE EXTINGUISHER BOTTLE	AS REMOVED
805500-12	FIRE EXTINGUISHER BOTTLE	AS REMOVED
806800-26	FIRE EXTINGUISHER BOTTLE	AS REMOVED
743602-3	ENGINE CONTROL	AS REMOVED

Part Number	Part Description	Condition
743602-3	ENGINE CONTROL	AS REMOVED
8900	ALTITUD ALERT SYS	AS REMOVED
8900	ALTITUD ALERT SYS	AS REMOVED
1732945	APU FUEL FILTER	AS REMOVED
75-0037-3	PANEL ANNUNCIATOR FLIGHT CONTROLS	AS REMOVED
766342	P&BVALVE	AS REMOVED
8DJ81WDK4	TACHOMETER INDICATOR N2	AS REMOVED
07-2780-9-000-3	ACTUATOR	AS REMOVED
2021136-2	ACTUATOR	AS REMOVED
311549	ACTUATOR	AS REMOVED
32-0260-4	ACTUATOR	AS REMOVED
355155A	ACTUATOR	AS REMOVED
541248-2-1	ACTUATOR	AS REMOVED
541248-7	ACTUATOR	AS REMOVED
541248-7	ACTUATOR	AS REMOVED
541248-7	ACTUATOR	AS REMOVED
65-37809-3	ACTUATOR	AS REMOVED
65-71680-2	ACTUATOR ASSY	AS REMOVED
65-71680-2	ACTUATOR ASSY	AS REMOVED
65-71680-2	ACTUATOR ASSY	AS REMOVED
65-71680-2	ACTUATOR ASSY	AS REMOVED
65-71680-2	ACTUATOR ASSY	AS REMOVED
AE727-1-025-2	ACTUATOR	AS REMOVED
EAL30724-C	ACTUATOR	AS REMOVED
204075-1	AIR CYCLE-MACHINE	AS REMOVED
204075-1	AIR CYCLE-MACHINE	AS REMOVED
965-0389-004	BARO RATE COMPUTER	AS REMOVED
568-1-26713-005	FUEL BOOST PUMP	AS REMOVED
3041692-3	COMPUTER STALL WARNING	AS REMOVED
3041692-3	COMPUTER STALL WARNING	AS REMOVED
3041692-3	COMPUTER STALL WARNING	AS REMOVED
3041692-3	COMPUTER STALL WARNING	AS REMOVED
30244-0201	ISOLATED FUEL QUANTITY TRANSMITTER	AS REMOVED
515105	OIL ENGINE PUMP	AS REMOVED
65075-06	PUMP AXIAL PISTON	AS REMOVED
65-52804-38	AUDIO ACESORY UNIT	AS REMOVED
398540-2-1	VALVULA MARIPOSA	AS REMOVED
65-40449-3	VALVE ASSY	AS REMOVED

Part Number	Part Description	Condition
65-40449-3	VALVE ASSY	AS REMOVED
65-40449-3	VALVE ASSY	AS REMOVED
AB13J5100	VALVE ASSY	AS REMOVED
AV16E1167C	VALVE ASSY	AS REMOVED
AV16E1167C	VALVE ASSY	AS REMOVED
65-60209-7	CONTROL UNIT ASSY	AS REMOVED
65-60209-7	CONTROL UNIT ASSY	AS REMOVED
3164828	STAR VALVE	AS REMOVED
979070-4-1	START VALVE	AS REMOVED
296 MK1	FEEL SIMULATOR JACK	AS REMOVED
492112-1-4227	INTERCAMBIADOR DE CALOR	AS REMOVED
10-60725-1238	PANEL	AS REMOVED
3041692-2	STALL WARNING MODULE (3041692-2)	AS REMOVED
40-0014	LIGHT ASSEMBLY	AS REMOVED
65-39524-25	PANEL	AS REMOVED
69-15972-6RG	PANEL	AS REMOVED
69-17528-10	PANEL	AS REMOVED
69-61482-1	PANEL	AS REMOVED
G-1661	GABLES ENGINEERING	AS REMOVED
G-2675	PANEL	AS REMOVED
G-4578	PANEL	AS REMOVED
G-4578	PANEL	AS REMOVED
G-1133A-1	FLAP -SLAT POSITION	AS REMOVED
69-17379-43	MODULE ASSY	AS REMOVED
123558-1-4	CHECK VALVE	AS REMOVED
123558-1-4	CHECK VALVE	AS REMOVED
123558-1-4	CHECK VALVE	AS REMOVED
123558-1-4	CHECK VALVE	AS REMOVED
123558-1-4	CHECK VALVE	AS REMOVED
123558-1-4	CHECK VALVE	AS REMOVED
622-6514-205	INDICATOR RADAR	AS REMOVED
75-0148-11	PANEL ANUNCIATOR - EXTERNAL DOOR WARNING	AS REMOVED
75-0149-53	INDICATOR LIGHT ASSY	AS REMOVED
965-0412-001	COMPUTER	AS REMOVED
80247 81107	MATCH AIRSPEED INDICATOR	AS REMOVED
A4144910005	AIRSPEED INDICATOR	AS REMOVED
2587335-11	VERTICAL GYRO	AS REMOVED
2587335-11	VERTICAL GYRO	AS REMOVED
2587335-11	VERTICAL GYRO	AS REMOVED
2587335-11	VERTICAL GYRO	AS REMOVED

Part Number	Part Description	Condition
2587335-11	VERTICAL GYRO	AS REMOVED
2587335-11	VERTICAL GYRO	AS REMOVED
2587335-11	VERTICAL GYRO	AS REMOVED
2587335-11	VERTICAL GYRO	AS REMOVED
42D185	DIFF PRESSURE SWITCH	AS REMOVED
42D185	DIFF PRESSURE SWITCH	AS REMOVED
522-3949-002	COMPARATOR MONITOR	AS REMOVED
5-89358-41	WINDOW N5 ASSY	AS REMOVED
6577-1	JET ACCESORY CENTER GASPER FAN	AS REMOVED
65C13014-3	STARTER DEFLECTOR	AS REMOVED
8DJ81LXH2U	INDICATOR ELECTRICAL TACHOMETER	AS REMOVED
93-A100-80	COCKPIT VOICE RECORDER	AS REMOVED
G-877	PANEL VHF COMM	AS REMOVED
MI-585164-1	ANTENA RADAR	AS REMOVED
4030951-902	ROLL CHANNELL	AS REMOVED
4030951-902	ROLL CHANNELL	AS REMOVED
4030951-902	ROLL CHANNELL	AS REMOVED
10-60517-39	BARRY CONTROLS	AS REMOVED
10-60517-39	BARRY CONTROLS	AS REMOVED
10-60517-39	BARRY CONTROLS	AS REMOVED
562A-5F4	STEERING COMPUTER	AS REMOVED
562A-5F4	STEERING COMPUTER	AS REMOVED
2587335-211	VERTICAL GYRO	AS REMOVED
2587335-211	VERTICAL GYRO	AS REMOVED
562A-5F-4	STEERING COMPUTER	AS REMOVED
H10-1026-1	SWITCH-FLAP, SLAT IND	AS REMOVED
H10-1026-1	SWITCH-FLAP, SLAT IND	AS REMOVED
H10-1026-1	SWITCH-FLAP, SLAT IND	AS REMOVED
H10-1026-1	SWITCH-FLAP, SLAT IND	AS REMOVED
10-60810-1	LINEAR TRANSDUCER	AS REMOVED
10-60810-1	LINEAR TRANSDUCER	AS REMOVED
59600-5003	VALVE ASSY	AS REMOVED
59600-5003	VALVE ASSY	AS REMOVED
59600-5003	VALVE ASSY	AS REMOVED
59600-5003	VALVE ASSY	AS REMOVED
69-17270-25	PANEL	AS REMOVED
1783662-315	INDICATOR-COURSE	AS REMOVED
1783662-315	INDICATOR-COURSE	AS REMOVED
622-5337-001	HF TRANSCEIVER	AS REMOVED
622-5337-001	HF TRANSCEIVER	AS REMOVED
976J252-6	GENERATOR AC AIRCRAFT	AS REMOVED
522-3698-014	ALTIMETER RADIO	AS REMOVED
522-3698-014	ALTIMETER RADIO	AS REMOVED
522-3698-014	ALTIMETER RADIO	AS REMOVED
522-3698-014	ALTIMETER RADIO	AS REMOVED
522-3698-014	ALTIMETER RADIO	AS REMOVED

Part Number	Part Description	Condition
642777	GEAR BOX ASSY	AS REMOVED
642777	GEAR BOX ASSY	AS REMOVED
642777	GEAR BOX ASSY	AS REMOVED
642777	GEAR BOX ASSY	AS REMOVED
667486P	GEAR BOX ASSY	AS REMOVED
804784	GEAR BOX ASSY	AS REMOVED
JT8D	GEAR BOX ASSY	AS REMOVED
522-2702-014	DME	AS REMOVED
976J119-012	AC GENERATOR	AS REMOVED
976J119-12	AC GENERATOR	AS REMOVED
976J119-12	AC GENERATOR	AS REMOVED
379580-250	OIL PUMP	AS REMOVED
H321AKM1	STANDBY HORIZONT	AS REMOVED
H321AKM1	STANDBY HORIZONT	AS REMOVED
1014A	POWER UNIT-FIRE	AS REMOVED
1014A	POWER UNIT-FIRE	AS REMOVED
1014A	POWER UNIT-FIRE	AS REMOVED
1014A	POWER UNIT-FIRE	AS REMOVED
1014A	POWER UNIT-FIRE	AS REMOVED
1014A	POWER UNIT-FIRE	AS REMOVED
1014A	POWER UNIT-FIRE	AS REMOVED
1014A	POWER UNIT-FIRE	AS REMOVED
1014A	POWER UNIT-FIRE	AS REMOVED
1014A	POWER UNIT-FIRE	AS REMOVED
2045-06-1	ENGINE PRESSURE RATIO INDICATOR	AS REMOVED
2045-06-1	ENGINE PRESSURE RATIO INDICATOR	AS REMOVED
75-0036-1	PANEL ANUNCIATOR FLAP	AS REMOVED
75-0036-1	PANEL ANUNCIATOR FLAP	AS REMOVED
G6993-09	ATC/TCAS CONTROL PANEL	AS REMOVED
G6993-09	ATC/TCAS CONTROL PANEL	AS REMOVED
3609480-5	SWITCH ASSY CENTRIFUGAL	AS REMOVED
3609480-5	SWITCH ASSY CENTRIFUGAL	AS REMOVED
3609480-5	SWITCH ASSY CENTRIFUGAL	AS REMOVED
10-3307-3	ANTENA	AS REMOVED
622-5135-201	DRIVE UNIT - PEDESTAL ANTENNA-	AS REMOVED
AT-640A	ANTENA	AS REMOVED
2-690029-10	ACTUATOR ASSY	AS REMOVED
65-23971-2	ACTUATOR ASSY	AS REMOVED
65-23971-3	RAM AIR ACTUATOR	AS REMOVED
65-57925-2	ACTUATOR TAIL SKID	AS REMOVED
65-71680-1	ACTUATOR ASSY	AS REMOVED
128775	VALVE MOTOR ACTUATED BUTTERFLY SHUTOFF	AS REMOVED

Part Number	Part Description	Condition
128775	VALVE MOTOR ACTUATED BUTTERFLY SHUTOFF	AS REMOVED
128775	VALVE MOTOR ACTUATED BUTTERFLY SHUTOFF	AS REMOVED
65-37568-46	ACCS UNIT LANDING GEAR	AS REMOVED
777-1492-005	RECEIVER ADF	AS REMOVED
65-17819-7	ACTUADOR LOCK	AS REMOVED
65-17819-7	ACTUADOR LOCK	AS REMOVED
65-17819-7	ACTUADOR LOCK	AS REMOVED
G-1980A	AUDIO SELECTOR	AS REMOVED
G-1980A	AUDIO SELECTOR	AS REMOVED
G-1980A	AUDIO SELECTOR	AS REMOVED
G-1980A	AUDIO SELECTOR	AS REMOVED
622-5132-101	RT Radar	AS REMOVED
10-61096-98	CONTROL MODULE ASSY - FIRE Y OVERHEAT DETECTOR SYSTEM	AS REMOVED
064-1004-00	VHF COMM TRANSCEIVER	AS REMOVED
3810056-106	TR MODULE VALVE	AS REMOVED
3810056-106	TR MODULE VALVE	AS REMOVED
103280-5-1	OUTFLOW VALVE	AS REMOVED
103280-5-1	OUTFLOW VALVE	AS REMOVED
103280-5-1	OUTFLOW VALVE	AS REMOVED
2601182-6	BRAKE ASSY	AS REMOVED
16432	TRANSFORMER	AS REMOVED
16432	TRANSFORMER	AS REMOVED
5-1216	TRANSFORMER	AS REMOVED
5-1216	TRANSFORMER	AS REMOVED
5-1216	TRANSFORMER	AS REMOVED
58-0106-3	AUTO TRANSFORMER	AS REMOVED
BAC 10-60828-2	TRANSFORMER	AS REMOVED
BAC 10-60828-2	TRANSFORMER	AS REMOVED
BAC 10-60828-2	TRANSFORMER	AS REMOVED
BAC 10-60828-2	TRANSFORMER	AS REMOVED
10-60713-1	MACHMETER	AS REMOVED
522649	FUEL HEATER	AS REMOVED
65-23559-34	SISTEMA HYD "A"	AS REMOVED
980-4100-GOUS	FLY DATA RECORDER	AS REMOVED
980-4100-GOUS	FLY DATA RECORDER	AS REMOVED
421495	ENGINE A/I VALVE	AS REMOVED
421495	ENGINE A/I VALVE	AS REMOVED
421495	ENGINE A/I VALVE	AS REMOVED
10-3200-1	VALVE, SHUT OFF	AS REMOVED
10-3200-1	VALVE, SHUT OFF	AS REMOVED
10-3200-1	VALVE, SHUT OFF	AS REMOVED
10-3200-1	VALVE, SHUT OFF	AS REMOVED
AV16B1350	VALVE, SHUT OFF	AS REMOVED

Part Number	Part Description	Condition
AV16B1350	VALVE, SHUT OFF	AS REMOVED
30-0801-3	LIGHT ASSY	AS REMOVED
30-0801-3	LIGHT ASSY	AS REMOVED
743602-4	FUEL CONTROL UNIT	AS REMOVED
743602-4	FUEL CONTROL UNIT	AS REMOVED
743602-4	FUEL CONTROL UNIT	AS REMOVED
743602-4	FUEL CONTROL UNIT	AS REMOVED
743602-4	FUEL CONTROL UNIT	AS REMOVED
743602-4	FUEL CONTROL UNIT	AS REMOVED
743602-4	FUEL CONTROL UNIT	AS REMOVED
743602-4	FUEL CONTROL UNIT	AS REMOVED
743602-4	FUEL CONTROL UNIT	AS REMOVED
743602-5	FUEL CONTROL UNIT	AS REMOVED
743602-5	FUEL CONTROL UNIT	AS REMOVED
743602-5	FUEL CONTROL UNIT	AS REMOVED
743602-5	FUEL CONTROL UNIT	AS REMOVED
743602-5	FUEL CONTROL UNIT	AS REMOVED
743602-5	FUEL CONTROL UNIT	AS REMOVED
743602-5	FUEL CONTROL UNIT	AS REMOVED
743602-5	FUEL CONTROL UNIT	AS REMOVED
743602-5	FUEL CONTROL UNIT	AS REMOVED
743602-5	FUEL CONTROL UNIT	AS REMOVED
743602-5	FUEL CONTROL UNIT	AS REMOVED
65-37890-79	APU	AS REMOVED
10-60734-2	CREW OXYGEN PRESSURE TRANSDUCER	AS REMOVED
68000-5007	ELEVATOR CONTROL	AS REMOVED
10-61964-79	PITCH CONTROL CHANNEL	AS REMOVED
2585804-4	PITCH CONTROL CHANNEL	AS REMOVED
4030950-979	PITCH CONTROL CHANNEL	AS REMOVED
4030950-979	PITCH CONTROL CHANNEL	AS REMOVED
383152-1-2	STARTER	AS REMOVED
383152-1-2	STARTER	AS REMOVED
383152-1-2	STARTER	AS REMOVED
383152-19-1	STARTER	AS REMOVED
383222-2-1	STARTER	AS REMOVED
69-18154-8	READING LIGHT	AS REMOVED
163393-01-01	PERFORMANCE DATA COMPUTER	AS REMOVED
56024-004	ACTUATOR AUTOPILOT (ELECTRIC)	AS REMOVED
56024-004	ACTUATOR AUTOPILOT (ELECTRIC)	AS REMOVED
112-5025-009	HORIZONTAL SITUATION INDICATOR	AS REMOVED
75-0039-1	PANEL ANUNCIADOR	AS REMOVED
17M800-261	FDR	AS REMOVED
2067157-0153	RCVR/XMTR	AS REMOVED
622-4545-001	Control hf	AS REMOVED
A-62028-1	VALVE-HYDRAULIC-PRIORITY	AS REMOVED
901-2312-901	VHF COMM	AS REMOVED
901-2312-901	VHF COMM	AS REMOVED

Part Number	Part Description	Condition
2604561-1	MLG WHEEL ASSY BENDIX	AS REMOVED
2604561-1	MLG WHEEL ASSY BENDIX	AS REMOVED
2604561-1	MLG WHEEL ASSY BENDIX	AS REMOVED
2604561-1	MLG WHEEL ASSY BENDIX	AS REMOVED
2604561-1	MLG WHEEL ASSY BENDIX	AS REMOVED
2604561-1	MLG WHEEL ASSY BENDIX	AS REMOVED
2604561-1	MLG WHEEL ASSY BENDIX	AS REMOVED
129700-08	ACTUADOR ELECTRICO	AS REMOVED
129700-08	ACTUADOR ELECTRICO	AS REMOVED
TPR-720	TRANSPONDER ATC	AS REMOVED
2585802-4	CONTROL PANEL	AS REMOVED
69-15971-25	PANEL	AS REMOVED
ST3400-001	TAWS	AS REMOVED
65-17823-4	PACKAGE ASSY	AS REMOVED
65-17823-4	PACKAGE ASSY	AS REMOVED
0004-00321121005	DATA COMPUTER	AS REMOVED
622-1396-101	VHF	AS REMOVED
10-60564-1	GROUND SPOILER	AS REMOVED
1058V0400B-1	UNIT PLYMOUTH CT	AS REMOVED
76-0572-161	GRIMES	AS REMOVED
ASSY69-23695-3	GRIMES	AS REMOVED
184380-1	EXCHANGER HEAT	AS REMOVED
184380-1	EXCHANGER HEAT	AS REMOVED
184380-1	EXCHANGER HEAT	AS REMOVED
184380-1	EXCHANGER HEAT	AS REMOVED
20173-M1	MOTOR ELECTRICO	AS REMOVED
48364-1-5	MOTOR DC	AS REMOVED
48364-1-5	MOTOR DC	AS REMOVED
3311586-1	SPERICAL ACCUMULATOR	AS REMOVED
75-0039-3	PANEL, ANNUNCIATOR - GENERATOR SYSTEM	AS REMOVED
75-0039-7	PANEL, ANNUNCIATOR - GENERATOR SYSTEM	AS REMOVED
65-72798-2	TIP HORIZONTAL STABILIZER RH	AS REMOVED
109486-6-1	LOAD CONTROLLER GENERATOR DRIVE	AS REMOVED
109644-6-1	CONTROL VALVE	AS REMOVED
109644-6-1	CONTROL VALVE	AS REMOVED
109644-6-1	CONTROL VALVE	AS REMOVED
15897-1-4	GYRO VERTICAL	AS REMOVED
15897-1A	GYRO VERTICAL	AS REMOVED
A4289910016	ALTIMETER SERVOED INDICATOR	AS REMOVED
1978191-1	ATTITUDE INDICATOR	AS REMOVED
2591092-904	ATTITUDE INDICATOR	AS REMOVED

Part Number	Part Description	Condition
2591092-904	ATTITUDE INDICATOR	AS REMOVED
2591092-904	ATTITUDE INDICATOR	AS REMOVED
10-60552-1	SW PRESSURE	AS REMOVED
10-60552-1	SW PRESSURE	AS REMOVED
10-60552-1	SW PRESSURE	AS REMOVED
10-60552-1	SW PRESSURE	AS REMOVED
4030952-901	YAW DAMPER COUPLER	AS REMOVED
5-89357-22	VENTANILLA #4	AS REMOVED
8TJ50GBZ3	FLUJOMETRO TRANSMITTER	AS REMOVED
1018-2-113	DISPLAY	AS REMOVED
1018-2-113	DISPLAY	AS REMOVED
2067631-5323	RADAR ALTIMETER	AS REMOVED
10-3091-18	CÓ-PILOT SEAT	AS REMOVED
30-284-2	SMOKE DETECTOR	AS REMOVED
30-284R-9B	SMOKE DETECTOR	AS REMOVED
74800	SMOKE DETECTOR	AS REMOVED
75-0035-5	PANEL ANNUNCIATOR LANDING GEAR	AS REMOVED
75-0035-5	PANEL ANNUNCIATOR LANDING GEAR	AS REMOVED
75-0035-5	PANEL ANNUNCIATOR LANDING GEAR	AS REMOVED
901-4312-902	PANEL VHF NAV	AS REMOVED
108-3569	MOTOR AC	AS REMOVED
110-4273	MOTOR AC	AS REMOVED
407F13-5	A.C MOTOR	AS REMOVED
48363-1	MOTOR DC	AS REMOVED
75250-62735	MOTOR BOOST PUMP ELECTRIC	AS REMOVED
939D148-1	MOTOR AIRCRAFT	AS REMOVED
AA00-01-12	MOTOR AC	AS REMOVED
E6430M17	AC AIRCRAFT MOTOR	AS REMOVED
65-57153-13	MLG ACTUATOR WALKING BEAM	AS REMOVED
65-57153-13	MLG ACTUATOR WALKING BEAM	AS REMOVED
65-57153-13	MLG ACTUATOR WALKING BEAM	AS REMOVED
622-4563-006	RADIO ALTIMETER INDICATOR	AS REMOVED
473977-3	CARGO COMPARTMENT FIRE EXTINGUISHER BOTTLE	AS REMOVED
10-60828-2	TRANSFORMER VARIABLE POWER	AS REMOVED
10-60828-2	TRANSFORMER VARIABLE POWER	AS REMOVED
10-60828-2	TRANSFORMER VARIABLE POWER	AS REMOVED
10-60828-2	TRANSFORMER VARIABLE POWER	AS REMOVED
10-60828-2	TRANSFORMER VARIABLE POWER	AS REMOVED
10-60828-2	TRANSFORMER VARIABLE POWER	AS REMOVED
622-2920-001	DME INTERROGATOR	AS REMOVED
622-2920-001	DME INTERROGATOR	AS REMOVED
258000-5	FUEL BOOST PUMP	AS REMOVED
623337	SYSTEM A ENGINE DRIVEN PUMP	AS REMOVED
8DJ81WAG4	INDICATOR - N1 TACH	AS REMOVED
8DJ81WDL4	INDICATOR ELECTRICAL TACHOMETER	AS REMOVED

Part Number	Part Description	Condition
102JE2FG	PROBE TOTAL TEMP	AS REMOVED
R18424-3	CONE BOLT	AS REMOVED
1013-41-011	FMS	AS REMOVED
40057-1	FUEL PRESS SW	AS REMOVED
40057-1	FUEL PRESS SW	AS REMOVED
40057-1	FUEL PRESS SW	AS REMOVED
40057-1	FUEL PRESS SW	AS REMOVED
40057-1	FUEL PRESS SW	AS REMOVED
40057-1	FUEL PRESS SW	AS REMOVED
40057-1	FUEL PRESS SW	AS REMOVED
40057-1	FUEL PRESS SW	AS REMOVED
40057-1	FUEL PRESS SW	AS REMOVED
40057-1	FUEL PRESS SW	AS REMOVED
40057-1	FUEL PRESS SW	AS REMOVED
695227-23	FAN ASSEMBLY	AS REMOVED
15-0188-11	DOME LIGHT	AS REMOVED
2041234-3434	VHF NAV TRACEIVER	AS REMOVED
2041234-3434	VHF NAV TRACEIVER	AS REMOVED
979078-2-1	START VALVE	AS REMOVED
979078-2-1	START VALVE	AS REMOVED
4067644-901	DISPLAY VSI/TRA	AS REMOVED
457400PB1901	IVSI	AS REMOVED
457400PB1901	IVSI	AS REMOVED
10-353875-4	EXCITER	AS REMOVED
534094	FUEL OIL COOLER	AS REMOVED
851CM	PITOT TUBE	AS REMOVED
851CM	PITOT TUBE	AS REMOVED
851CM	PITOT TUBE	AS REMOVED
851CM	PITOT TUBE	AS REMOVED
851CM	PITOT TUBE	AS REMOVED
851T	PITOT TUBE	AS REMOVED
10-60552-22	PRESSURE SWITCH	AS REMOVED

Part Number	Part Description	Condition
10-60552-22	PRESSURE SWITCH	AS REMOVED
15625	TRIP & DATE ENCODER	AS REMOVED
15625	TRIP & DATE ENCODER	AS REMOVED
15625	TRIP & DATE ENCODER	AS REMOVED
2041215-1101	RADAR INDICATOR	AS REMOVED
277-177	TERMOCUPLER	AS REMOVED
695753-1C	CONJUNTO RODAMIENTO	AS REMOVED
698195-10	TAPA MOTORES	AS REMOVED
4038930-904	HORIZONTAL SITUATION INDICATOR	AS REMOVED
4038930-904	HORIZONTAL SITUATION INDICATOR	AS REMOVED
772-5005-006	FLIGHT DIRECT IND.	AS REMOVED
ST-104Y-M1	TRANSMISOR DE PRESION	AS REMOVED
59100-5017	RUDDER CONTROL PACKAGE	AS REMOVED
622-5135-001	ANTENNA PEDESTAL	AS REMOVED
207562-1	COOLING FAN	AS REMOVED
207562-1	COOLING FAN	AS REMOVED
207562-1	COOLING FAN	AS REMOVED
207562-1	COOLING FAN	AS REMOVED
207562-1	COOLING FAN	AS REMOVED
207562-1	COOLING FAN	AS REMOVED
207562-1	COOLING FAN	AS REMOVED
207562-1	COOLING FAN	AS REMOVED
207562-1	COOLING FAN	AS REMOVED
207562-1	COOLING FAN	AS REMOVED
207682-1	MOTOR DRIVEN	AS REMOVED
2-1147-3	BRAKE ASSY	AS REMOVED
2-1147-3	BRAKE ASSY	AS REMOVED
81840-03-007B	PROCESSO	AS REMOVED
81840-03-007B	PROCESSO	AS REMOVED
81840-03-007B	PROCESSO	AS REMOVED
522-3121	STEERING COMPUTER	AS REMOVED
562A-5F	STEERING COMPUTER	AS REMOVED
562A-5F5	STEERING COMPUTER	AS REMOVED
562A-5F5	STEERING COMPUTER	AS REMOVED
4030949-908	CONTROL PANEL	AS REMOVED
4030949-908	CONTROL PANEL	AS REMOVED
4030949-908	CONTROL PANEL	AS REMOVED
55098-01	PUMP AXIAL PISTÓN	AS REMOVED
50179-3A	CONTROL LEVER	AS REMOVED
176840-1	EXCHANGER HEAT	AS REMOVED
176840-1	EXCHANGER HEAT	AS REMOVED
42D107A2	DIFF PRESSURE SWITCH	AS REMOVED
42D107A2	DIFF PRESSURE SWITCH	AS REMOVED
1222-5-3600	VALVE-RELIEF, HYDRAULIC	AS REMOVED
519-22702-532	ENCODING ALTIMETER	AS REMOVED
65-27935-3	MCD DRIFT PIN ACTIATOR	AS REMOVED
375322-9	ARRANQUE APU	AS REMOVED

Part Number	Part Description	Condition
380678-1-1	APU (POWER GAS TURBINE ENGINE)	AS REMOVED
F73001-103	TAIL JACK CARGO LOADING	AS REMOVED
2601182-5	BRAKE	AS REMOVED
383342-1-1	STARTER ENGINE AIR TURBINE	AS REMOVED
383152-16-1	STARTE ENGINE	AS REMOVED
383152-16-1	STARTE ENGINE	AS REMOVED
383222-1-1	STARTER ENGINE	AS REMOVED
383222-1-1	STARTER ENGINE	AS REMOVED
383222-1-1	STARTER ENGINE	AS REMOVED
383222-1-1	STARTER ENGINE	AS REMOVED
383222-1-1	STARTER ENGINE	AS REMOVED
383222-1-1	STARTER ENGINE	AS REMOVED
383222-1-1	STARTER ENGINE	AS REMOVED
383222-1-1	STARTER ENGINE	AS REMOVED
383222-1-1	STARTER ENGINE	AS REMOVED
383222-1-1	STARTER ENGINE	AS REMOVED
383222-1-1	STARTER ENGINE	AS REMOVED
82165-00-004	MCDU	AS REMOVED
82165-00-004	MCDU	AS REMOVED
769606-12	FUEL CONTROL	AS REMOVED
696233B	TRAMMISSION	AS REMOVED
622-3374-002	IND-HORIZON (ADI)	AS REMOVED
622-3374-002	IND-HORIZON (ADI)	AS REMOVED
622-3374-002	IND-HORIZON (ADI)	AS REMOVED
9300-218-03 D	SERVOMOTOR	AS REMOVED
69-37346-2309	MODULE ASSY WINDOW HEAT P5-9	AS REMOVED
1777213-653	GYRO INDICATOR	AS REMOVED
1777213-653	GYRO INDICATOR	AS REMOVED
6282	TRANSFORMER CURRENT	AS REMOVED
6282	TRANSFORMER CURRENT	AS REMOVED
JT8D-217C	ENGINE	AS REMOVED
066-50000-2120	TCAS PROCESSOR	AS REMOVED
65C37625-19	TRUMION SUPPORT FITTING	AS REMOVED
65C37625-18	TRUMION SUPPORT FITTING	AS REMOVED
65-72762-8	Nose Landing Gear	AS REMOVED
65-17650-37	LH Main Landing Gear	AS REMOVED
65-17650-38	RH Main Landing Gear	AS REMOVED
AS66411-L-S666	ENGINE DRIVE PUMP	AS REMOVED
10-353875-4	IGNITER EXCITER	AS REMOVED
976J498-1	AC GENERATOR	AS REMOVED
976J498-1	AC GENERATOR	AS REMOVED
734602-5	FUEL CONTROL UNIT	AS REMOVED
743602-3	FUEL CONTROL UNIT	AS REMOVED

Part Number	Part Description	Condition
743602-5	FUEL CONTROL UNIT	AS REMOVED
743602-4	FUEL CONTROL UNIT	AS REMOVED
522649	FUEL EXCHANGER	AS REMOVED
HEA5231	FUEL EXCHANGER	AS REMOVED
371900	FUEL PUMP	AS REMOVED
371900	FUEL PUMP	AS REMOVED