

Part Number	Part Description	Engine Type	Condition	Quantity
00106-8-0120	HOSE ASSY - HYDRAULIC	CF6-50 (LMCO)	OH	1
08748-9-114-06	TRANSMITTER - FUEL FLOW	CF6-50 (LMCO)	AR	1
08748-9-114-06	TRANSMITTER - FUEL FLOW	CF6-50 (LMCO)	AR	1
10-383900-16	EXCITER - IGNITION	CF6-50 (LMCO)	SV	1
10-383900-16	EXCITER - IGNITION	CF6-50 (LMCO)	AR	1
10-383900-16	EXCITER - IGNITION	CF6-50 (LMCO)	OH	1
10-395402-1	LEAD ASSY - IGNITION	CF6-50	AR	1
10-395402-1	LEAD ASSY - IGNITION	CF6-50	AR	1
10-617665-1	LEAD ASSY - IGNITION	CF6-80A	OH	1
10-617665-1	LEAD ASSY - IGNITION	CF6-80A	AR	1
10-617665-1	LEAD ASSY - IGNITION	CF6-80A	SV	1
10-630390-3	PLUG - IGNITER (TYPE IV)	CF6-80C2	AR	1
10-630390-3	PLUG - IGNITER (TYPE IV)	CF6-80C2	AR	1
10-631045-1	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
10-631045-1	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
10-631045-1	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
10-631045-1	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
10-631045-1	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
10-631045-1	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
10-631045-1	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
10-631045-1	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
10-631045-2	EXCITER - IGNITION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
10-631045-3	EXCITER - IGNITION	CF6-50 (LMCO)	OH	1
10-631045-3	EXCITER - IGNITION	CF6-50 (LMCO)	SV	1
10-631045-3	EXCITER - IGNITION	CF6-50 (LMCO)	SV	1
10-700494-1	LEAD ASSY - IGNITION	CF6-50 (LMCO)	AR	1
10-700494-1	LEAD ASSY - IGNITION	CF6-50 (LMCO)	OH	1
10-700494-1	LEAD ASSY - IGNITION	CF6-50 (LMCO)	OH	1
10-700494-1	LEAD ASSY - IGNITION	CF6-50 (LMCO)	AR	1
10-700494-1	LEAD ASSY - IGNITION	CF6-50 (LMCO)	AR	1
10-700494-1	LEAD ASSY - IGNITION	CF6-50 (LMCO)	AR	1
102705	ELEMENT - STRAINER	CF6-50	NS	1
102705	ELEMENT - STRAINER	CF6-50	NS	1
102A345P02	PLATE - ENG AND TURB	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
102A345P03	PLATE - ENG AND TURB	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	5
102A345P04	PLATE - IDENTIFICATION	CF6-80C2, CF6-80A	NE	2
102A349P01	PLATE - IDENTIFICATION	CF6-80C2	NS	1
102A349P01	PLATE - IDENTIFICATION	CF6-80C2	NS	1
102A398P01	PLATE - IDENTIFICATION	CF6-50	NE	1
102A398P01	PLATE - IDENTIFICATION	CF6-50	NE	2
102A489P01	PLATE - PATENT	CF6-80C2	NS	1
102A491P01	PLATE - ENG TURB REVERSER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	3
102A545P01	PLATE - PATENT	CF6-80C2	NS	6
102A546P01	PLATE - IDENTIFICATION	CF6-80A	NE	3
102A547P01	PLATE - ENG TURB REVERSER	CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
106062-25	HOSE ASSY - NO 16 TEFLON	CF6-80A	AR	1
106062-25	HOSE ASSY - NO 16 TEFLON	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
106062-27	HOSE ASSY	CF6-80A	AR	1
106383-4	TUBE - ROD END FUEL HOSE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
106383-4	TUBE - ROD END FUEL HOSE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
106383-4	TUBE - ROD END FUEL HOSE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
106383-4	TUBE - ROD END FUEL HOSE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
106933-23	TUBE ASSY	CF6-80A	AR	1
108034-11	HOSE - MAIN FUEL	CF6-80A	OH	1
108062-21	DISCONNECT	CF6-80C2	AR	1
108088-8	TUBE - HOSE	CF6-80A	AR	1
108088-8	TUBE - HOSE	CF6-80A	AR	1
108088-8	TUBE - HOSE	CF6-80A	AR	1
108167-2	HOSE ASSY	CF6-50 (Boeing)	SV	1
108170-1	HOSE ASSY - CRIMPED HIGH	CF6-80A	AR	1
108170-1	HOSE ASSY - CRIMPED HIGH	CF6-80A	AR	1
108170-3	HOSE ASSY - CRIMPED HIGH	CF6-80A	AR	1
108280-17	HOSE ASSY - FLEX	CF6-80A	AR	1
108280-17	HOSE ASSY - FLEX	CF6-80A	AR	1
108280-19	HOSE ASSY - FLEX	CF6-80A	AR	1
108280-19	HOSE ASSY - FLEX	CF6-80A	AR	1
108280-21	HOSE ASSY	CF6-80A	AR	1
108280-21	HOSE ASSY	CF6-80A	AR	1
108280-83	HOSE ASSY	CF6-80C2	OH	1
109657	TUBE AND HOSE - VBV	CF6-80C2	NS	1
109900-12	TUBE AND HOSE - TURB	CF6-80C2	NE	1
109900-12	TUBE AND HOSE - TURB	CF6-80C2	NE	2
109900-12	TUBE AND HOSE - TURB	CF6-80C2	NE	1
1099M37G01	TUBE ASSY - FLTR TO CLR OIL	CF6-50 (Boeing)	OH	1
1099M37G01	TUBE ASSY - FLTR TO CLR OIL	CF6-50 (Boeing)	OH	1
1099M37G01	TUBE ASSY - FLTR TO CLR OIL	CF6-50 (Boeing)	OH	1
1099M37G01	TUBE ASSY - FLTR TO CLR OIL	CF6-50 (Boeing)	OH	1
1099M58G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1099M58G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1099M58G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1099M58G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
1099M58G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1099M58G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1099M58G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1099M58G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1099M58G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1099M58G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1099M58G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1099M58G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1099M58G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1099M58G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1099M60G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1099M60G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1099M60G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1099M60G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1099M60G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1099M60G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1099M60G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1099M60G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1099M60G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1099M63P001A	BRACKET - ANGLE	CF6-50 (LMCO)	SV	1
11-118-00	ACCELEROMETER ASSY - NO. 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
11-118-00	ACCELEROMETER ASSY - NO. 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1100M20G01	BRACKET	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
1100M21G01	BRACKET - ANGLE	CF6-50	NS	1
1100M21G01	BRACKET - ANGLE	CF6-50	SV	1
1100M25G01	BRACKET - ANGLE	CF6-50 (LMCO)	OH	1
1100M25G01	BRACKET - ANGLE	CF6-50 (LMCO)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
1100M25G01	BRACKET - ANGLE	CF6-50 (LMCO)	OH	1
1100M37G01	BELLCRANK ASSY - STTR FDBK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1100M37G01	BELLCRANK ASSY - STTR FDBK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1100M37G01	BELLCRANK ASSY - STTR FDBK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1100M60P01	PLUG - MAG MACH THD	CF6-50	AR	1
1100M61G02	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1100M61G02	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1100M61G02	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
1100M61G02	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
1100M61G02	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
1100M63P001A	BRACKET	CF6-50 (LMCO)	SV	1
1100M63P001A	BRACKET	CF6-50 (LMCO)	SV	1
1100M63P001A	BRACKET	CF6-50 (LMCO)	SV	1
1100M63P001A	BRACKET	CF6-50 (LMCO)	SV	1
1100M77G01	BRACKET - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
1101M52G01	MANIFOLD ASSY - AIR LH	CF6-50	OH	1
1101M52G01	MANIFOLD ASSY - AIR LH	CF6-50	AR	1
1101M52G01	MANIFOLD ASSY - AIR LH	CF6-50	AR	1
1101M78G01	TUBE ASSY - TANK VENT	CF6-50 (Boeing)	AR	1
1101M78G01	TUBE ASSY - TANK VENT	CF6-50 (Boeing)	AR	1
1101M80G01	TUBE ASSY - OIL TANK VENT	CF6-50 (LMCO)	AR	1
1101M80G01	TUBE ASSY - OIL TANK VENT	CF6-50 (LMCO)	AR	1
1102M47P01	SPACER - COUPLING	CF6-50 (LMCO)	NE	1
1102M66G01	MANIFOLD ASSY - AIR RH	CF6-50 (Boeing)	SV	1
1102M66G01	MANIFOLD ASSY - AIR RH	CF6-50 (Boeing)	OH	1
1102M66G01	MANIFOLD ASSY - AIR RH	CF6-50 (Boeing)	OH	1
1102M66G01	MANIFOLD ASSY - AIR RH	CF6-50 (Boeing)	OH	1
1102M66G01	MANIFOLD ASSY - AIR RH	CF6-50 (Boeing)	OH	1
1102M66G01	MANIFOLD ASSY - AIR RH	CF6-50 (Boeing)	AR	1
1102M66G01	MANIFOLD ASSY - AIR RH	CF6-50 (Boeing)	SV	1
1102M66G01	MANIFOLD ASSY - AIR RH	CF6-50 (Boeing)	OH	1
1102M66G01	MANIFOLD ASSY - AIR RH	CF6-50 (Boeing)	OH	1
1102M66G01	MANIFOLD ASSY - AIR RH	CF6-50 (Boeing)	OH	1
1102M66G01	MANIFOLD ASSY - AIR RH	CF6-50 (Boeing)	OH	1
1102M66G01	MANIFOLD ASSY - AIR RH	CF6-50 (Boeing)	OH	1
1102M66G01	MANIFOLD ASSY - AIR RH	CF6-50 (Boeing)	AR	1
1102M66G01	MANIFOLD ASSY - AIR RH	CF6-50 (Boeing)	AR	1
1102M66G01	MANIFOLD ASSY - AIR RH	CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
1102M66G01	MANIFOLD ASSY - AIR RH	CF6-50 (Boeing)	AR	1
1102M66G02	MANIFOLD ASSY - AIR RH	CF6-50	AR	1
1102M68G01	MANIFOLD ASSY - AIR RH	CF6-50 (Boeing)	OH	1
1103M48P01	COVER - STG 8 PORT	CF6-50 (LMCO)	NS	1
1122507	SENSOR - OIL TEMP	CF6-80A	NE	1
1122507	SENSOR - OIL TEMP	CF6-80A	SV	1
11307-2	VALVE - LATCHING PRESS RLF	CF6-80A	AR	1
113254-2	TUBE/HOSE - FUEL VBV ACTR	CF6-80C2	OH	1
113255	TUBE/HOSE - FUEL VBV ACTR	CF6-80C2	NS	1
113717-505	HOSE ASSY	CF6-50 (LMCO)	OH	1
113717-507	HOSE ASSY	CF6-50 (LMCO)	NE	1
114309	TUBE - FUEL HOSE	CF6-80C2	OH	1
114311	TUBE/HOSE - FUEL VSV ACTR	CF6-80C2	NS	1
115207-1	TUBE - FUEL SERVO HEATER	CF6-80C2	AR	1
1153P4-28	SWITCH - LOW PRESS	CF6-80A	SV	1
1153P4-28	SWITCH - LOW PRESS	CF6-80A	SV	1
115758	TUBE AND HOSE - FUEL	CF6-80C2	OH	1
118-10413-19	PLUG - BLEED	CF6-50 (LMCO)	NS	2
12100AA6	SEAL	CF6-80A	NE	7
1211131-6	ACTUATOR - FDBK CABLE RESET	CF6-50 (Boeing)	SV	1
1211227-001	ACTUATOR - FDBK CABLE RESET	CF6-50 (LMCO)	AR	1
1211227-001	ACTUATOR - FDBK CABLE RESET	CF6-50 (LMCO)	AR	1
1211245-010	ACTUATOR - VAR STTR VANE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-010	ACTUATOR - VAR STTR VANE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-010	ACTUATOR - VAR STTR VANE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-010	ACTUATOR - VAR STTR VANE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-010	ACTUATOR - VAR STTR VANE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-010	ACTUATOR - VAR STTR VANE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-010	ACTUATOR - VAR STTR VANE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-010	ACTUATOR - VAR STTR VANE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1211245-010	ACTUATOR - VAR STTR VANE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
1211245-010	ACTUATOR - VAR STTR VANE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-010	ACTUATOR - VAR STTR VANE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-010	ACTUATOR - VAR STTR VANE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-010	ACTUATOR - VAR STTR VANE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
1211245-011	ACTUATOR - VAR STTR VANE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
1211245-016	ACTUATOR - VAR STTR	CF6-80C2	SV	1
1211245-016	ACTUATOR - VAR STTR	CF6-80C2	SV	1
1211245-016	ACTUATOR - VAR STTR	CF6-80C2	SV	1
1211245-016	ACTUATOR - VAR STTR	CF6-80C2	AR	1
1211245-025	ACTUATOR - VAR STTR	CF6-80C2	AR	1
1211245-202	NAMEPLATE	CF6-80A	NS	1
1211246-001	ACTUATOR - RESET VSV	CF6-80A	SV	1
1211268-001	ACTUATOR - RESET	CF6-80A	AR	1
1211268-001	ACTUATOR - RESET	CF6-80A	AR	1
1211285-008	ACTUATOR - VBV	CF6-80C2	AR	1
1211285-008	ACTUATOR - VBV	CF6-80C2	SV	1
1211285-008	ACTUATOR - VBV	CF6-80C2	SV	1
1211285-008	ACTUATOR - VBV	CF6-80C2	OH	1
1211285-008	ACTUATOR - VBV	CF6-80C2	OH	1
1211285-008	ACTUATOR - VBV	CF6-80C2	OH	1
1211318-003	ACTUATOR - VBV	CF6-80C2	SV	1
1211318-003	ACTUATOR - VBV	CF6-80C2	SV	1
1211318-004	ACTUATOR - VBV	CF6-80C2	OH	1
1211318-004	ACTUATOR - VBV	CF6-80C2	OH	1
1211342-004	ACTUATOR - VSV	CF6-80C2	SV	1
1211342-005	ACTUATOR - VSV	CF6-80C2	SV	1
1211342-005	ACTUATOR - VSV	CF6-80C2	OH	1
1211342-005	ACTUATOR - VSV	CF6-80C2	SV	1
123848-1	VALVE - THRUST REV CHECK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
123848-1	VALVE - THRUST REV CHECK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
123848-1	VALVE - THRUST REV CHECK	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
123848-1	VALVE - THRUST REV CHECK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
123848-1	VALVE - THRUST REV CHECK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
123848-1	VALVE - THRUST REV CHECK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1277M66P01	SEAL - RING	CF6-80C2	SV	1
12811-11	DUCT	CF6-50	AR	1
1288M33G01	OIL NOZZLE	CF6-80C2	SV	1
1288M36G15	INLET GEARBOX ASSEMBLY	CF6-80C2	AR	1
1288M40G02	RING - IMPINGEMENT STG 1	CF6-80A	AR	1
1288M40G02	RING - IMPINGEMENT STG 1	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
1288M40G02	RING - IMPINGEMENT STG 1	CF6-80A	AR	1
1288M41G05	HOUSING - BRG NO. 5R	CF6-80C2	OH	1
1288M41G08	HOUSING - BRG NO. 5R	CF6-80C2	OH	1
1288M41G08	HOUSING - BRG NO. 5R	CF6-80C2	OH	1
1288M42P04	#5R BEARING OIL SHIELD	CF6-80C2, CF6-80A	AR	1
1288M42P04	#5R BEARING OIL SHIELD	CF6-80C2, CF6-80A	NS	1
1288M42P04	#5R BEARING OIL SHIELD	CF6-80C2, CF6-80A	AR	1
1288M53G01	NOZZLE - OIL BRG NO. 5R	CF6-80C2, CF6-80A	NS	2
1288M53G01	NOZZLE - OIL BRG NO. 5R	CF6-80C2, CF6-80A	AR	1
1288M53G01	NOZZLE - OIL BRG NO. 5R	CF6-80C2, CF6-80A	AR	1
1288M54G01	HOUSING - BRG NO. 5R	CF6-80A	AR	1
1288M55G01	HOUSING - BRG NO. 5R	CF6-80A	SV	1
1288M55G01	HOUSING - BRG NO. 5R	CF6-80A	SV	1
1288M55G02	HOUSING - BRG NO. 5R	CF6-80A	AR	1
1288M55G02	HOUSING - BRG NO. 5R	CF6-80A	AR	1
1288M55G02	HOUSING - BRG NO. 5R	CF6-80A	NS	1
1288M55G02	HOUSING - BRG NO. 5R	CF6-80A	NS	1
1288M55G02	HOUSING - BRG NO. 5R	CF6-80A	NS	1
1288M55G02	HOUSING - BRG NO. 5R	CF6-80A	OH	1
1288M55G02	HOUSING - BRG NO. 5R	CF6-80A	AR	1
1288M55G02	HOUSING - BRG NO. 5R	CF6-80A	AR	1
1288M55G02	HOUSING - BRG NO. 5R	CF6-80A	AR	1
1288M55G02	HOUSING - BRG NO. 5R	CF6-80A	AR	1
1288M55G02	HOUSING - BRG NO. 5R	CF6-80A	AR	1
1288M65P01	HPT NOZZLE STG 1 INNR FWD SEAL	CF6-80C2	NE	2
1288M65P01	HPT NOZZLE STG 1 INNR FWD SEAL	CF6-80C2	NE	18
1288M65P01	HPT NOZZLE STG 1 INNR FWD SEAL	CF6-80C2	NE	56
1288M65P01	HPT NOZZLE STG 1 INNR FWD SEAL	CF6-80C2	NS	14
1288M65P01	HPT NOZZLE STG 1 INNR FWD SEAL	CF6-80C2	NS	4
1288M65P01	HPT NOZZLE STG 1 INNR FWD SEAL	CF6-80C2	NE	100
1288M65P01	HPT NOZZLE STG 1 INNR FWD SEAL	CF6-80C2	NE	2
1288M65P02	HPT NOZZLE STG 1 INNR FWD SEAL	CF6-80C2	NE	1
1288M65P02	HPT NOZZLE STG 1 INNR FWD SEAL	CF6-80C2	NS	8

Part Number	Part Description	Engine Type	Condition	Quantity
1288M65P02	HPT NOZZLE STG 1 INNR FWD SEAL	CF6-80C2	NS	2
1288M65P02	HPT NOZZLE STG 1 INNR FWD SEAL	CF6-80C2	NE	2
1288M65P02	HPT NOZZLE STG 1 INNR FWD SEAL	CF6-80C2	NE	2
1288M65P02	HPT NOZZLE STG 1 INNR FWD SEAL	CF6-80C2	NE	100
1288M65P02	HPT NOZZLE STG 1 INNR FWD SEAL	CF6-80C2	NE	2
1288M65P02	HPT NOZZLE STG 1 INNR FWD SEAL	CF6-80C2	NE	2
1288M65P02	HPT NOZZLE STG 1 INNR FWD SEAL	CF6-80C2	NE	2
1288M66P04	HPT NOZZLE STG 1 STATOR SEAL	CF6-80C2	NE	85
1288M66P04	HPT NOZZLE STG 1 STATOR SEAL	CF6-80C2	NE	100
1288M66P04	HPT NOZZLE STG 1 STATOR SEAL	CF6-80C2	NS	2
1288M66P04	HPT NOZZLE STG 1 STATOR SEAL	CF6-80C2	NS	2
1288M66P04	HPT NOZZLE STG 1 STATOR SEAL	CF6-80C2	NS	2
1288M67P01	HEATSHIELD	CF6-80C2	SV	1
1288M68P02	SHIELD - HEAT	CF6-80C2	SV	2
1288M68P04	SHIELD - HEAT	CF6-80C2	SV	2
1288M68P05	TRF OIL TUBE HEAT SHIELD	CF6-80C2	SV	1
1288M68P06	TRF OIL TUBE HEAT SHIELD	CF6-80C2	NE	4
1288M68P06	TRF OIL TUBE HEAT SHIELD	CF6-80C2	SV	1
1288M81G01	TUBE - OIL SUPPLY	CF6-80C2	SV	1
1288M86P001A	BRACKET - NUT YOKE LINK	CF6-80C2	NS	1
1288M86P001A	BRACKET - NUT YOKE LINK	CF6-80C2	NS	6
1288M88P03	SPACER	CF6-80C2	NE	2
1288M90P01	SEAL - FAN STATOR	CF6-80C2	AR	1
1288M99G08	SEGMENT - FWD OUTER LINER	CF6-80C2	OH	1
1288M99G08	SEGMENT - FWD OUTER LINER	CF6-80C2	OH	1
1288M99G08	SEGMENT - FWD OUTER LINER	CF6-80C2	OH	1
1288M99G08	SEGMENT - FWD OUTER LINER	CF6-80C2	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
1288M99G09	SEGMENT - FWD OUTER LINER	CF6-80C2	OH	1
1288M99G11	SEGMENT - FWD OUTER LINER	CF6-80C2	REP	1
1288M99G12	SEGMENT - FWD OUTER LINER	CF6-80C2	REP	1
1288M99G12	SEGMENT - FWD OUTER LINER	CF6-80C2	REP	1
1288M99G14	SEGMENT - FWD OUTER LINER	CF6-80C2, CF6-80A	REP	1
1289M42P03	JOINT - SLIDE FLEX	CF6-80C2	NS	1
1289M55G01	RETAINER - SEAL	CF6-80C2	SV	2
1289M55G01	RETAINER - SEAL	CF6-80C2	AR	2
1289M55G01	RETAINER - SEAL	CF6-80C2	NS	1
1289M55G01	RETAINER - SEAL	CF6-80C2	SV	4
1289M55G01	RETAINER - SEAL	CF6-80C2	SV	2
1289M55G01	RETAINER - SEAL	CF6-80C2	NS	1
1289M55G01	RETAINER - SEAL	CF6-80C2	NS	1
1289M76G01	TUBE - H/M N1 SENSOR FUEL	CF6-80C2	SV	1
1290M16P02	SEAL	CF6-80C2	NE	1
1290M16P02	SEAL	CF6-80C2	NS	5
1290M21G01	DUCT - AIR LP RECOUP AFT	CF6-80C2	OH	1
1290M21G01	DUCT - AIR LP RECOUP AFT	CF6-80C2	OH	1
1290M39G09	TUBE - AIR HP RECOUP	CF6-80C2	SV	1
1290M43G01	SHROUD - FUEL	CF6-80C2	AR	11
1290M43G01	SHROUD - FUEL	CF6-80C2	SV	2
1290M43G01	SHROUD - FUEL	CF6-80C2	SV	5
1290M43G01	SHROUD - FUEL	CF6-80C2	OH	10
1290M43G01	SHROUD - FUEL	CF6-80C2	OH	1
1290M44G01	SHROUD - FUEL	CF6-80C2	AR	2
1290M44G01	SHROUD - FUEL	CF6-80C2	OH	1
1290M96P04	CABLE - VSV FEEDBACK	CF6-80C2	SV	1
1291M56P01	PLUG - DISCONNECT	CF6-80C2	SV	1
1292M24P04	BRACKET	CF6-80C2	NE	1
1292M24P05	BRACKET	CF6-80C2	NE	2
1292M24P05	BRACKET	CF6-80C2	NE	1
1292M24P05	BRACKET	CF6-80C2	NE	3
1292M32P02	SEAL - INNER	CF6-80C2	AR	1
1292M32P02	SEAL - INNER	CF6-80C2	AR	1
1292M32P02	SEAL - INNER	CF6-80C2	OH	1
1292M34P01	SPACER	CF6-80C2	NS	3
1292M34P01	SPACER	CF6-80C2	NE	12
1292M34P01	SPACER	CF6-80C2	NE	8
1292M43P04	HPT ROTOR HEATSHIELD	CF6-80C2	OH	1
1292M57P01	SCOOP	CF6-80C2	NE	8

Part Number	Part Description	Engine Type	Condition	Quantity
1292M60P01	PLUG - PROBE	CF6-80A	AR	1
1292M64G02	SEAL - STA OIL BRG NO. 3	CF6-50	AR	1
1292M64G06	SEAL - STA BRG NO. 3	CF6-80A	OH	1
1292M64G06	SEAL - STA BRG NO. 3	CF6-80A	AR	1
1292M64G06	SEAL - STA BRG NO. 3	CF6-80A	OH	1
1292M81P01	HPT NOZZLE STG 2 SEAL RING	CF6-80C2	AR	1
1292M81P01	HPT NOZZLE STG 2 SEAL RING	CF6-80C2	AR	1
1292M86P04	BRACKET - YOKE	CF6-80C2	SV	1
1292M86P04	BRACKET - YOKE	CF6-80C2	OH	1
1292M86P04	BRACKET - YOKE	CF6-80C2	OH	1
1292M86P04	BRACKET - YOKE	CF6-80C2	OH	1
1292M86P04	BRACKET - YOKE	CF6-80C2	SV	1
1292M86P05	BRACKET - YOKE	CF6-80C2	SV	1
1292M86P05	BRACKET - YOKE	CF6-80C2	SV	1
1292M86P05	BRACKET - YOKE	CF6-80C2	OH	1
1292M86P05	BRACKET - YOKE	CF6-80C2	OH	1
1292M86P05	BRACKET - YOKE	CF6-80C2	OH	1
1292M86P05	BRACKET - YOKE	CF6-80C2	OH	1
1292M86P06	BRACKET - YOKE	CF6-80C2	SV	1
1292M86P07	BRACKET - YOKE	CF6-80C2	AR	1
1292M86P07	BRACKET - YOKE	CF6-80C2	OH	1
1293M30G01	TUBE - UPR SCUPPER DRN	CF6-80C2	AR	1
1293M30G01	TUBE - UPR SCUPPER DRN	CF6-80C2	AR	1
1293M30G01	TUBE - UPR SCUPPER DRN	CF6-80C2	AR	1
1293M30G01	TUBE - UPR SCUPPER DRN	CF6-80C2	NS	1
1293M65G01	TUBE - COOLING SIGNAL	CF6-80C2	AR	1
1293M67G01	TUBE - COOLING ACCESSORY	CF6-80C2	AR	1
1293M73P001A	BRACKET	CF6-80C2	SV	1
1293M73P001A	BRACKET	CF6-80C2	SV	1
1293M73P001B	BRACKET	CF6-80C2	SV	1
1297M10P001A	BRACKET	CF6-80C2	NS	1
1297M10P001A	BRACKET	CF6-80C2	NS	2
1297M10P001A	BRACKET	CF6-80C2	SV	1
1297M10P001A	BRACKET	CF6-80C2	SV	1
1297M13P02	JOINT - FLEXIBLE	CF6-80C2	NS	1
1297M13P02	JOINT - FLEXIBLE	CF6-80C2	NE	1
1297M13P02	JOINT - FLEXIBLE	CF6-80C2	NE	2
1297M13P09	JOINT - FLEXIBLE	CF6-80C2	AR	3
1297M16G03	BRACKET - IGNITION	CF6-80C2	OH	1
1297M16G04	BRACKET - IGNITION	CF6-80C2	OH	1
1297M40G01	BRACKET - TUBE T12 SNSR	CF6-80C2	SV	1
1297M50G03	BRACKET	CF6-80C2	NE	1
1297M64G07	BRACKET	CF6-80C2	AR	1
1297M64G07	BRACKET	CF6-80C2	AR	1
1297M64G07	BRACKET	CF6-80C2	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
12A092-003	ACTUATOR	CF6-80A	AR	1
12A092-003	ACTUATOR	CF6-80A	AR	1
12A092-003	ACTUATOR	CF6-80A	AR	1
12A092-003	ACTUATOR	CF6-80A	AR	1
12A092-004	ACTUATOR ASSY - VBV	CF6-50 (Boeing)	AR	1
12A092-004	ACTUATOR ASSY - VBV	CF6-50 (Boeing)	AR	1
12A092-004	ACTUATOR ASSY - VBV	CF6-50 (Boeing)	AR	1
12A092-004	ACTUATOR ASSY - VBV	CF6-50 (Boeing)	AR	1
12A092-004	ACTUATOR ASSY - VBV	CF6-50 (Boeing)	AR	1
12A092-004	ACTUATOR ASSY - VBV	CF6-50 (Boeing)	AR	1
12A092-3	ACTUATOR ASSY - VBV	CF6-80A, CF6-50 (Boeing)	AR	1
12A092-3	ACTUATOR ASSY - VBV	CF6-80A, CF6-50 (Boeing)	AR	1
12A092-3	ACTUATOR ASSY - VBV	CF6-80A, CF6-50 (Boeing)	AR	1
12A092-3	ACTUATOR ASSY - VBV	CF6-80A, CF6-50 (Boeing)	AR	1
12A092-3	ACTUATOR ASSY - VBV	CF6-80A, CF6-50 (Boeing)	AR	1
12A092-3	ACTUATOR ASSY - VBV	CF6-80A, CF6-50 (Boeing)	AR	1
12A092-3	ACTUATOR ASSY - VBV	CF6-80A, CF6-50 (Boeing)	AR	1
12A092-3	ACTUATOR ASSY - VBV	CF6-80A, CF6-50 (Boeing)	AR	1
12A092-3	ACTUATOR ASSY - VBV	CF6-80A, CF6-50 (Boeing)	SV	1
12A092-3	ACTUATOR ASSY - VBV	CF6-80A, CF6-50 (Boeing)	SV	1
12A092-3	ACTUATOR ASSY - VBV	CF6-80A, CF6-50 (Boeing)	SV	1
12A092-3	ACTUATOR ASSY - VBV	CF6-80A, CF6-50 (Boeing)	SV	1
12A092-3	ACTUATOR ASSY - VBV	CF6-80A, CF6-50 (Boeing)	SV	1
12A092-3	ACTUATOR ASSY - VBV	CF6-80A, CF6-50 (Boeing)	SV	1
12A092-3	ACTUATOR ASSY - VBV	CF6-80A, CF6-50 (Boeing)	AR	1
12A092-3	ACTUATOR ASSY - VBV	CF6-80A, CF6-50 (Boeing)	AR	1
12A092-3	ACTUATOR ASSY - VBV	CF6-80A, CF6-50 (Boeing)	AR	1
12A092-3	ACTUATOR ASSY - VBV	CF6-80A, CF6-50 (Boeing)	OH	1
12A092-4	ACTUATOR ASSY - VBV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
12A092-4	ACTUATOR ASSY - VBV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
12A092-4	ACTUATOR ASSY - VBV	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
12A092-4	ACTUATOR ASSY - VBV	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
12A092-4	ACTUATOR ASSY - VBV	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
12A092-4	ACTUATOR ASSY - VBV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
12A092-4	ACTUATOR ASSY - VBV	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
12A092-4	ACTUATOR ASSY - VBV	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
13000205-0065H	HOSE - P3G	CF6-80C2	SV	1
13000205-0065H	HOSE - P3G	CF6-80C2	SV	1
13000205-0065H	HOSE - P3G	CF6-80C2	SV	1
1301M14G04	HOUSING - HORIZONTAL	CF6-80C2	OH	1
1301M15G02	LINK - MOUNT FORWARD	CF6-80C2	SV	1
1301M16G01	MOUNT - FRAME	CF6-80C2	OH	1
1301M16G01	MOUNT - FRAME	CF6-80C2	OH	1
1301M16G01	MOUNT - FRAME	CF6-80C2	OH	1
1301M16G01	MOUNT - FRAME	CF6-80C2	OH	1
1301M16G01	MOUNT - FRAME	CF6-80C2	OH	1
1301M17P02	SLEEVE - WEAR HORIZ DR SFT	CF6-80C2	NS	1
1301M17P02	SLEEVE - WEAR HORIZ DR SFT	CF6-80C2	NS	1
1301M35P001A	PLATE - LOCK	CF6-80C2	SV	1
1301M35P001A	PLATE - LOCK	CF6-80C2	OH	1
1301M35P001A	PLATE - LOCK	CF6-80C2	SV	1
1301M59G05	DAMPER ASSY - HPTR STG 2	CF6-80C2	NE	6
1301M59G05	DAMPER ASSY - HPTR STG 2	CF6-80C2	NE	2
1301M59G05	DAMPER ASSY - HPTR STG 2	CF6-80C2	NE	1
1301M59G05	DAMPER ASSY - HPTR STG 2	CF6-80C2	NE	15
1301M70P01	RING - DAMPER	CF6-80C2	NS	1
1301M70P02	TGB DAMPER RING	CF6-80C2	NS	4
1302M13P001A	SHIELD - OIL SPLY	CF6-80C2	NE	3
1302M13P001A	SHIELD - OIL SPLY	CF6-80C2	NS	2
1302M13P001A	SHIELD - OIL SPLY	CF6-80C2	SV	1
1302M13P001A	SHIELD - OIL SPLY	CF6-80C2	SV	1
1302M13P001A	SHIELD - OIL SPLY	CF6-80C2	SV	1
1302M50G07	BRACKET	CF6-80C2	SV	1
1302M50G07	BRACKET	CF6-80C2	SV	1
1302M50G07	BRACKET	CF6-80C2	SV	1
1302M50G07	BRACKET	CF6-80C2	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
1303M32G10	MANIFOLD - FUEL RIGHT SIDE	CF6-80C2	OH	1
1303M33G04	MANIFOLD - FUEL DRAIN L/S	CF6-80C2	OH	1
1303M33G06	MANIFOLD - FUEL DRAIN L/S	CF6-80C2	SV	1
1303M33G06	MANIFOLD - FUEL DRAIN L/S	CF6-80C2	OH	1
1303M33G06	MANIFOLD - FUEL DRAIN L/S	CF6-80C2	OH	1
1303M35P01	COUPLING - FLANGED	CF6-80C2	NS	1
1303M39G01	BRACKET	CF6-80C2	NE	1
1303M39G01	BRACKET	CF6-80C2	NE	1
1303M50P001A	BRACKET	CF6-80C2	NE	1
1303M50P001A	BRACKET	CF6-80C2	SV	1
1304M11G01	RETAINER - NUT	CF6-80C2	SV	1
1304M11G01	RETAINER - NUT	CF6-80C2	SV	1
1304M11G02	RETAINER - NUT	CF6-80C2	NS	5
1304M20P01	SEAL - HPT STATOR	CF6-80C2	NS	10
1304M20P01	SEAL - HPT STATOR	CF6-80C2	NS	16
1304M20P01	SEAL - HPT STATOR	CF6-80C2	NS	25
1304M20P03	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2	NE	300
1304M20P03	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2	NE	2
1304M20P03	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2	NE	292
1304M20P04	SEAL - HPT NOZ OUT	CF6-80C2	NE	1
1304M20P04	SEAL - HPT NOZ OUT	CF6-80C2	NE	5
1304M20P04	SEAL - HPT NOZ OUT	CF6-80C2	NE	14
1304M20P04	SEAL - HPT NOZ OUT	CF6-80C2	NE	2
1304M20P04	SEAL - HPT NOZ OUT	CF6-80C2	NE	9
1304M20P04	SEAL - HPT NOZ OUT	CF6-80C2	NS	11
1304M20P04	SEAL - HPT NOZ OUT	CF6-80C2	NS	2
1304M20P04	SEAL - HPT NOZ OUT	CF6-80C2	NS	12
1304M20P04	SEAL - HPT NOZ OUT	CF6-80C2	NE	10
1304M20P04	SEAL - HPT NOZ OUT	CF6-80C2	NE	134
1304M20P04	SEAL - HPT NOZ OUT	CF6-80C2	NE	1
1304M20P04	SEAL - HPT NOZ OUT	CF6-80C2	NE	2
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	2
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	21
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	4
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	21
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	6

Part Number	Part Description	Engine Type	Condition	Quantity
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	1
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	2
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	12
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	9
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	1
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	10
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	1
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	2
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	1
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	1
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	25
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	25
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	24
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	11
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	4
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	4
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	8
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	15
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	8
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	24
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	25
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	25
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	23
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	25
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	20

Part Number	Part Description	Engine Type	Condition	Quantity
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	3
1304M20P06	HPT NOZZLE STG 1 OUTER SEAL	CF6-80C2, CF6-80A	NE	2
1304M22G01	SEAL - PRESS BAL	CF6-80C2	AR	1
1304M25P01	SPACER	CF6-80C2	AR	7
1304M25P01	SPACER	CF6-80C2	OH	2
1304M25P01	SPACER	CF6-80C2	OH	3
1304M28P02	RETAINER	CF6-80C2	SV	2
1304M28P02	RETAINER	CF6-80C2	OH	11
1304M28P02	RETAINER	CF6-80C2	AR	11
1304M28P03	RETAINER	CF6-80C2	NS	6
1304M37P01	PLUG - SEALING	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
1304M37P01	PLUG - SEALING	CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
1304M38P06	SPACER - FLAT	CF6-80C2	NE	1
1304M38P06	SPACER - FLAT	CF6-80C2	NE	1
1304M38P06	SPACER - FLAT	CF6-80C2	NE	1
1304M38P06	SPACER - FLAT	CF6-80C2	NE	1
1304M80P04	RING - DAMPER	CF6-80A	AR	1
1304M80P04	RING - DAMPER	CF6-80A	SV	1
1304M80P04	RING - DAMPER	CF6-80A	NS	1
1305M15P04	LINK - SUPPORT	CF6-80A	NE	2
1305M17G02	LINK - SUPPORT	CF6-80A	SV	1
1305M17G02	LINK - SUPPORT	CF6-80A	NE	1
1305M17G02	LINK - SUPPORT	CF6-80A	NE	1
1305M17G02	LINK - SUPPORT	CF6-80A	NE	2
1305M19G02	LINK - SUPPORT	CF6-80A	NS	1
1305M19G02	LINK - SUPPORT	CF6-80A	NS	1
1305M19G02	LINK - SUPPORT	CF6-80A	NS	1
1305M20G02	LINK - SUPPORT	CF6-80A	NS	1
1305M52P08	PLUG - MAIN IGNITER	CF6-80A	AR	1
1305M52P08	PLUG - MAIN IGNITER	CF6-80A	AR	1
1305M52P08	PLUG - MAIN IGNITER	CF6-80A	AR	1
1305M52P09	PLUG - MAIN IGNITER	CF6-80A, CF6-50 (Boeing)	AR	1
1305M70P03	CONTROL - POWER MANAGEMENT	CF6-80A	SV	1
1305M70P03	CONTROL - POWER MANAGEMENT	CF6-80A	AR	1
1305M73G01	MANIFOLD - AIR COOLING	CF6-80A	AR	1
1305M73G01	MANIFOLD - AIR COOLING	CF6-80A	AR	1
1305M73G01	MANIFOLD - AIR COOLING	CF6-80A	AR	1
1305M73G01	MANIFOLD - AIR COOLING	CF6-80A	OH	1
1305M73G01	MANIFOLD - AIR COOLING	CF6-80A	AR	1
1305M73G01	MANIFOLD - AIR COOLING	CF6-80A	AR	1
13061508-0260S	HOSE ASSY	CF6-80A	NE	1

Part Number	Part Description	Engine Type	Condition	Quantity
1306M10G01	MANIFOLD - AIR LPT RH	CF6-50 (Boeing)	AR	1
1306M10G01	MANIFOLD - AIR LPT RH	CF6-50 (Boeing)	OH	1
1306M16G01	TUBE - AIR IGNITION LEAD	CF6-80A	AR	1
1306M16G01	TUBE - AIR IGNITION LEAD	CF6-80A	AR	1
1306M18G01	TUBE - AIR	CF6-80A	AR	1
1306M18G01	TUBE - AIR	CF6-80A	AR	1
1306M24P001A	BRACKET - IGNITION LEAD	CF6-80A	AR	1
1306M24P001A	BRACKET - IGNITION LEAD	CF6-80A	AR	1
1306M24P001A	BRACKET - IGNITION LEAD	CF6-80A	NS	1
1306M24P001A	BRACKET - IGNITION LEAD	CF6-80A	NS	1
1306M30P02	PLUG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1306M51P01	RETAINER - LH ELECTRICAL	CF6-80A	NE	1
1306M51P01	RETAINER - LH ELECTRICAL	CF6-80A	NS	1
1306M54P001A	RETAINER - SEAL HEATSHIELD	CF6-80A	SV	1
1306M60G01	RETAINER	CF6-80A	OH	1
1306M60G01	RETAINER	CF6-80A	OH	1
1306M62P001A	BRACKET - CLAMP	CF6-80A	NE	1
1306M62P001A	BRACKET - CLAMP	CF6-80A	SV	1
1306M67G01	TUBE - COMBUSTOR DRAIN	CF6-80A	AR	1
1306M67G01	TUBE - COMBUSTOR DRAIN	CF6-80A	AR	1
1306M73G01	TUBE - COMBUSTOR DRAIN	CF6-80A	AR	1
1306M73G01	TUBE - COMBUSTOR DRAIN	CF6-80A	AR	1
1307M38G03	BRACKET	CF6-80C2	NE	1
1307M51G01	BRACKET	CF6-80C2	OH	1
1307M74P03	DAMPER	CF6-80C2	NS	1
1307M74P03	DAMPER	CF6-80C2	NS	1
1307M74P06	DAMPER	CF6-80C2	NE	1
1307M74P06	DAMPER	CF6-80C2	NE	3
1307M74P06	DAMPER	CF6-80C2	NS	3
1307M74P06	DAMPER	CF6-80C2	NE	1
1307M74P06	DAMPER	CF6-80C2	NE	19
1307M76G03	BRACKET	CF6-80C2	OH	1
1308M31P001A	BRACKET	CF6-80C2	SV	1
1308M32G01	LINK - SUPPORT	CF6-80C2	SV	1
1308M32G02	LINK - SUPPORT	CF6-80C2	OH	1
1308M32G02	LINK - SUPPORT	CF6-80C2	SV	1
1308M32G05	LINK - SUPPORT	CF6-80C2	NE	1
1308M32G06	LINK - SUPPORT	CF6-80C2	NE	1
1308M32G11	LINK - SUPPORT	CF6-80C2	SV	1
1308M32G12	LINK - SUPPORT	CF6-80C2	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
1308M32G21	LINK - SUPPORT	CF6-80C2	OH	1
1308M32G21	LINK - SUPPORT	CF6-80C2	OH	1
1308M32G21	LINK - SUPPORT	CF6-80C2	SV	1
1308M32G22	LINK - SUPPORT	CF6-80C2	SV	1
1308M32G23	LINK - SUPPORT	CF6-80C2	NS	1
1308M32G24	LINK - SUPPORT	CF6-80C2	NE	1
1308M32G34	LINK - SUPPORT	CF6-80C2	OH	1
1308M58G01	TUBE - MAST MANF TO MDL OIL	CF6-80C2	SV	1
1308M58G02	TUBE - MAST MANF TO MDL OIL	CF6-80C2	OH	1
1308M82G02	TUBE - STARTER DRAIN OIL	CF6-80C2	NS	4
1309M24G03	BRACKET	CF6-80C2	AR	1
1309M24G03	BRACKET	CF6-80C2	SV	1
1309M37G01	BRACKET	CF6-80C2	AR	1
1309M57P001A	BRACKET	CF6-80C2	SV	1
1309M58P001A	BRACKET	CF6-80C2	NS	1
1309M58P001A	BRACKET	CF6-80C2	SV	1
1309M78G06	DUCT - AIR WYE	CF6-80C2	SV	1
1309M89P001A	BRACKET	CF6-80C2	NS	2
1309M89P001A	BRACKET	CF6-80C2	NS	1
1309M89P001A	BRACKET	CF6-80C2	NS	1
13100-400	SEAL	CF6-80C2, CF6-80A, PW2000	NE	2
13100-500	SEAL	CF6-80C2	NE	1
13100-500	SEAL	CF6-80C2	NS	1
13100-500	SEAL	CF6-80C2	NE	1
13100-550	SEAL	CF6-80C2	AR	2
13100-600-PMA	SEAL	CF6-80C2	NE	2
1310M21G07	TUBE - AIR ACCESSORY	CF6-80C2	AR	1
1310M54P001A	BRACKET	CF6-80C2	NS	1
1310M84G04	TUBE - IDG PRESS RLF DR	CF6-80C2	OH	1
1310M91G03	BRACKET	CF6-80C2	OH	1
1311-126	SOLENOID - IDLE RESET	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1313M25G03	BRACKET	CF6-80C2	NE	1
1313M44P01	RETAINER - SEAL	CF6-80C2	AR	1
1313M44P01	RETAINER - SEAL	CF6-80C2	AR	1
1313M44P01	RETAINER - SEAL	CF6-80C2	SV	1
1313M44P01	RETAINER - SEAL	CF6-80C2	NS	1
1313M44P01	RETAINER - SEAL	CF6-80C2	NS	2
1313M45P01	SEAL - HEATSHIELD	CF6-80C2	NE	4
1314M47G03	BRACKET - POWER PACK	CF6-80C2	NE	1
1314M47G03	BRACKET - POWER PACK	CF6-80C2	SV	1
1314M54G05	SHIELD - CA AFT	CF6-80C2	SV	1
1314M62P003A	BRACKET - RETENTION	CF6-50 (Boeing)	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
1314M63P01	SPACER	CF6-50 (Boeing)	NE	4
1314M63P01	SPACER	CF6-50 (Boeing)	NE	1
1314M63P01	SPACER	CF6-50 (Boeing)	NS	3
1314M63P01	SPACER	CF6-50 (Boeing)	NS	1
1314M63P01	SPACER	CF6-50 (Boeing)	NS	1
1314M63P01	SPACER	CF6-50 (Boeing)	AR	4
1315M18G02	MAST - LOWER DRAIN	CF6-80C2	NE	1
1315M18G04	MAST - LOWER DRAIN	CF6-80C2	AR	1
1315M20G01	BRACKET	CF6-80C2	AR	1
1315M56G03	TUBE - AIR HPT COOLING	CF6-80C2	SV	1
1315M72P001A	BRACKET	CF6-80C2	SV	1
1315M96G03	BRACKET - CLEVIS ACC DUCT	CF6-80C2	SV	1
1315M96G05	BRACKET - CLEVIS ACC DUCT	CF6-80C2	NE	1
1320M38G01	CHANNEL - RIGHT SIDE	CF6-50	AR	1
1320M69P001A	BRACKET - SUPPLY TUBE AFT	CF6-50 (Boeing)	NS	1
1320M91G07	BRACKET - SUPPORT	CF6-50 (LMCO)	SV	1
1320M91G07	BRACKET - SUPPORT	CF6-50 (LMCO)	SV	1
1320M95G02	TUBE - AIR IGN LEAD COOLING	CF6-50 (Boeing)	OH	1
1320M95G02	TUBE - AIR IGN LEAD COOLING	CF6-50 (Boeing)	OH	1
1320M95G02	TUBE - AIR IGN LEAD COOLING	CF6-50 (Boeing)	OH	1
1320M98G01	TUBE - HP RECOUP STRUT 5	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1320M98G01	TUBE - HP RECOUP STRUT 5	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1320M98G01	TUBE - HP RECOUP STRUT 5	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1320M98G01	TUBE - HP RECOUP STRUT 5	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1321M32P20	BRACKET - LINK	CF6-80C2	NS	1
1321M32P20	BRACKET - LINK	CF6-80C2	NS	1
1321M42G04	TUBE - FLOWMETER TO IDG	CF6-80C2	OH	1
1321M42G04	TUBE - FLOWMETER TO IDG	CF6-80C2	SV	1
1321M73G02	TUBE - COOLING	CF6-80C2	AR	1
1321M77P01	SPACER	CF6-80C2	SV	1
1321M77P01	SPACER	CF6-80C2	NE	3
1321M77P01	SPACER	CF6-80C2	SV	1
1321M86G01	BRACKET	CF6-80C2	NE	1
1321M89G01	TUBE - SIGNAL VALVE DRAIN	CF6-80C2	AR	1
1321M93G01	TUBE - OIL HYDR DRAIN LWR	CF6-80C2	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
1321M93G01	TUBE - OIL HYDR DRAIN LWR	CF6-80C2	OH	1
1322M32G03	PLUG ASSY - BS PORT LPT	CF6-80C2	NE	1
1322M32G03	PLUG ASSY - BS PORT LPT	CF6-80C2	SV	1
1322M34P01	#4R BEARING OUTER SPANNER NUT	CF6-80C2	OH	1
1322M35G01	NOZZLE - FWD 4R	CF6-80C2	OH	1
1322M35G01	NOZZLE - FWD 4R	CF6-80C2	OH	1
1322M51G01	BAFFLE ASSY - HPT STG 1	CF6-80C2	OH	11
1322M51G01	BAFFLE ASSY - HPT STG 1	CF6-80C2	OH	6
1322M51G01	BAFFLE ASSY - HPT STG 1	CF6-80C2	OH	11
1322M51G02	BAFFLE - AIR	CF6-80C2	AR	1
1322M51G02	BAFFLE - AIR	CF6-80C2	AR	1
1322M51G02	BAFFLE - AIR	CF6-80C2	AR	1
1322M51G02	BAFFLE - AIR	CF6-80C2	AR	1
1322M51G02	BAFFLE - AIR	CF6-80C2	SV	1
1322M91G01	BRACKET - MOUNTING	CF6-80C2	AR	1
1322M99G02	SEAL - STATIONARY VENT	CF6-80C2	OH	1
1324M95P01	SHROUD - CLG MAIN IGNTR	CF6-80C2, CF6-80A, CF6-50 (Boeing)	AR	4
1324M95P01	SHROUD - CLG MAIN IGNTR	CF6-80C2, CF6-80A, CF6-50 (Boeing)	AR	4
1324M95P01	SHROUD - CLG MAIN IGNTR	CF6-80C2, CF6-80A, CF6-50 (Boeing)	AR	4
1324M95P01	SHROUD - CLG MAIN IGNTR	CF6-80C2, CF6-80A, CF6-50 (Boeing)	AR	2
1324M95P02	SHROUD - CLG MAIN IGNTR	CF6-80C2, CF6-50 (Boeing)	SV	4
1325M30G05	BRACKET - FUEL FLTR	CF6-80C2	NS	1
1325M55G01	TUBE - N1 DRAIN FUEL	CF6-80C2	NE	1
1325M81P001A	BRACKET - TUBE	CF6-80C2	NE	3
1326-162	FITTING - FILTER	CF6-50 (LMCO)	NS	2
1326M30G01	RETAINER - PLATE	CF6-80C2	NS	3
1326M30G01	RETAINER - PLATE	CF6-80C2	NE	5
1326M30G01	RETAINER - PLATE	CF6-80C2	NE	1
1326M31P01	PLATE - COVER	CF6-80C2	NS	3
1326M31P01	PLATE - COVER	CF6-80C2	NS	1
1326M31P01	PLATE - COVER	CF6-80C2	NS	3
1326M37G01	SEAL	CF6-80C2	AR	2
1326M38G01	SEAL	CF6-80C2	AR	1
1326M38G01	SEAL	CF6-80C2	AR	1
1326M38G01	SEAL	CF6-80C2	AR	1
1326M46G02	TUBE - T2 SENSOR LOWER	CF6-80C2	NS	1
1326M84G07	BRACKET	CF6-80C2	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
1326M91G01	TUBE	CF6-80C2	NE	1
1326M91G01	TUBE	CF6-80C2	NE	1
1327M13P001A	SEAL - FWD	CF6-80C2	NE	1
1327M14P001A	SEAL - FWD	CF6-80C2	NE	1
1327M15P001A	SEAL - FWD	CF6-80C2	NE	1
1327M16P001A	SEAL - FWD	CF6-80C2	NE	1
1327M73P02	SEAL - ROT AIR BRG NO. 5R	CF6-80C2	OH	1
1327M73P02	SEAL - ROT AIR BRG NO. 5R	CF6-80C2	OH	1
1327M74P01	#5R BEARING SPACER	CF6-80C2	AR	1
1327M75P01	SLEEVE - DAMPER	CF6-80C2	OH	1
1327M75P01	SLEEVE - DAMPER	CF6-80C2	NE	2
1327M75P01	SLEEVE - DAMPER	CF6-80C2	NE	1
1327M75P01	SLEEVE - DAMPER	CF6-80C2	NE	1
1327M75P02	HPT ROTOR DAMPER SLEEVE	CF6-80C2	OH	1
1327M77P04	#5 MAIN ROLLER BEARING	CF6-80C2, CF6-80A	AR	1
1327M82G01	BRACKET	CF6-80C2	OH	5
1327M82G01	BRACKET	CF6-80C2	OH	1
1327M98P01	BEARING - SPHERICAL	CF6-80C2	NS	10
1327M98P01	BEARING - SPHERICAL	CF6-80C2	NS	1
1327M98P02	BEARING - SPHERICAL	CF6-80C2	NE	2
1327M99G01	SHROUD - SUPPORT HPT	CF6-80A	OH	1
1327M99G01	SHROUD - SUPPORT HPT	CF6-80A	OH	1
1327M99G01	SHROUD - SUPPORT HPT	CF6-80A	OH	1
1327M99G01	SHROUD - SUPPORT HPT	CF6-80A	OH	1
1327M99G01	SHROUD - SUPPORT HPT	CF6-80A	OH	1
13304-501	DUCT ASSY - AIR MOTOR SUPPLY	CF6-50	SV	1
13304-501	DUCT ASSY - AIR MOTOR SUPPLY	CF6-50	AR	1
13304-501	DUCT ASSY - AIR MOTOR SUPPLY	CF6-50	AR	1
1332M30G02	TUBE - AIR PS3 FWD	CF6-80C2	SV	1
1332M37G01	MANIFOLD - TEE HP RECOUP	CF6-80A	NE	4
1332M37G01	MANIFOLD - TEE HP RECOUP	CF6-80A	SV	2
1332M37G01	MANIFOLD - TEE HP RECOUP	CF6-80A	SV	2
1332M37G01	MANIFOLD - TEE HP RECOUP	CF6-80A	SV	1
1332M37G01	MANIFOLD - TEE HP RECOUP	CF6-80A	SV	1
1332M37G01	MANIFOLD - TEE HP RECOUP	CF6-80A	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
1332M37G01	MANIFOLD - TEE HP RECOUP	CF6-80A	SV	1
1332M37G01	MANIFOLD - TEE HP RECOUP	CF6-80A	SV	1
1332M37G01	MANIFOLD - TEE HP RECOUP	CF6-80A	SV	1
1332M37G01	MANIFOLD - TEE HP RECOUP	CF6-80A	SV	1
1332M37G01	MANIFOLD - TEE HP RECOUP	CF6-80A	SV	1
1332M37G01	MANIFOLD - TEE HP RECOUP	CF6-80A	SV	1
1332M37G01	MANIFOLD - TEE HP RECOUP	CF6-80A	SV	1
1332M37G01	MANIFOLD - TEE HP RECOUP	CF6-80A	SV	1
1332M37G01	MANIFOLD - TEE HP RECOUP	CF6-80A	SV	1
1332M37G01	MANIFOLD - TEE HP RECOUP	CF6-80A	SV	1
1332M37G01	MANIFOLD - TEE HP RECOUP	CF6-80A	SV	1
1332M37G01	MANIFOLD - TEE HP RECOUP	CF6-80A	SV	1
1332M37G01	MANIFOLD - TEE HP RECOUP	CF6-80A	SV	1
1332M37G01	MANIFOLD - TEE HP RECOUP	CF6-80A	SV	1
1332M37G01	MANIFOLD - TEE HP RECOUP	CF6-80A	OH	1
1332M37G01	MANIFOLD - TEE HP RECOUP	CF6-80A	AR	2
1332M37G01	MANIFOLD - TEE HP RECOUP	CF6-80A	NE	1
1332M59G01	TUBE - OIL TANK	CF6-80C2	OH	1
1332M59G01	TUBE - OIL TANK	CF6-80C2	AR	1
1332M59G01	TUBE - OIL TANK	CF6-80C2	AR	1
1332M59G01	TUBE - OIL TANK	CF6-80C2	OH	1
1332M59G03	TUBE - OIL TANK	CF6-80C2	SV	1
1332M88P001B	BRACKET	CF6-80C2	SV	1
1332M88P001B	BRACKET	CF6-80C2	SV	1
1333M38G03	LINK ASSY - MOUNT	CF6-80A	AR	1
1333M60P02	SPACER - ACTUATION LEVER	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
1333M65G01	HPC STATOR ACT RING SEGMT STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
1333M65G01	HPC STATOR ACT RING SEGMT STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
1333M65G01	HPC STATOR ACT RING SEGMT STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
1333M65G01	HPC STATOR ACT RING SEGMT STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1333M65G02	HPC STATOR ACT RING SEGMT STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1333M65G02	HPC STATOR ACT RING SEGMT STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
1333M65G02	HPC STATOR ACT RING SEGMT STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1333M65G02	HPC STATOR ACT RING SEGMT STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
1333M65G02	HPC STATOR ACT RING SEGMT STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1333M65G03	HPC STATOR ACT RING SEGMT STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1333M65G03	HPC STATOR ACT RING SEGMT STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1333M65G03	HPC STATOR ACT RING SEGMT STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1333M65G03	HPC STATOR ACT RING SEGMT STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
1333M65G03	HPC STATOR ACT RING SEGMT STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1333M65G03	HPC STATOR ACT RING SEGMT STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1333M65G03	HPC STATOR ACT RING SEGMT STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1333M65G03	HPC STATOR ACT RING SEGMT STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1333M65G03	HPC STATOR ACT RING SEGMT STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1333M65G03	HPC STATOR ACT RING SEGMT STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
1333M65G03	HPC STATOR ACT RING SEGMT STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1333M65G03	HPC STATOR ACT RING SEGMT STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1333M65G03	HPC STATOR ACT RING SEGMT STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1333M65G03	HPC STATOR ACT RING SEGMT STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1333M65G03	HPC STATOR ACT RING SEGMT STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1333M65G03	HPC STATOR ACT RING SEGMT STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
1333M65G03	HPC STATOR ACT RING SEGMT STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1333M65G03	HPC STATOR ACT RING SEGMT STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1333M65G03	HPC STATOR ACT RING SEGMT STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
1333M65G03	HPC STATOR ACT RING SEGMT STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
1333M65G03	HPC STATOR ACT RING SEGMT STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1333M72P02	RING - RETAINING INTERNAL	CF6-80C2, CF6-80A	AR	1
1333M75P13	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1
1333M75P13	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1
1333M75P13	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1
1333M75P13	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1
1333M75P13	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1
1333M75P13	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1
1333M75P13	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1
1333M75P13	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1
1333M75P13	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1
1333M75P13	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1
1333M75P13	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1
1333M75P13	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1
1333M75P13	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1
1333M75P13	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
1333M75P15	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1
1333M75P15	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1
1333M75P15	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1
1333M76G11	LINK - SUPPORT	CF6-80C2	AR	3
1333M76G11	LINK - SUPPORT	CF6-80C2	NS	1
1333M76G11	LINK - SUPPORT	CF6-80C2	NS	1
1333M76G11	LINK - SUPPORT	CF6-80C2	NE	1
1333M76G11	LINK - SUPPORT	CF6-80C2	OH	6
1333M76G11	LINK - SUPPORT	CF6-80C2	NE	1
1333M76G11	LINK - SUPPORT	CF6-80C2	NE	4
1333M76G11	LINK - SUPPORT	CF6-80C2	NE	2
1334M44P001A	BRACKET - ANGLE	CF6-80C2	SV	1
1334M63G02	TUBE - AIR	CF6-80C2	NS	1
1334M76G05	TUBE - AIR LPT SUPPLY	CF6-80C2	NS	1
1334M78P001A	BRACKET	CF6-80C2	SV	1
1334M82P001B	BRACKET - PMUX	CF6-80C2	NE	1
1334M95G02	TUBE - AIR PS3 CORE MID	CF6-80C2	OH	1
1335M10G01	TUBE - 11TH STAGE	CF6-80C2	AR	1
1335M10G01	TUBE - 11TH STAGE	CF6-80C2	AR	1
1335M10G01	TUBE - 11TH STAGE	CF6-80C2	AR	1
1335M10G01	TUBE - 11TH STAGE	CF6-80C2	AR	1
1335M12G01	TUBE - 11TH STAGE	CF6-80C2	NE	1
1335M12G01	TUBE - 11TH STAGE	CF6-80C2	NE	1
1335M25G01	BRACKET - UPPER PYLON DRAIN	CF6-80C2	SV	1
1335M25G01	BRACKET - UPPER PYLON DRAIN	CF6-80C2	SV	1
1335M75G01	TUBE - OIL SCAVENGE	CF6-80C2	NS	1
1336M92P01	BLADE - FAN STG 2 (NARROW)	CF6-80C2	AR	28
1336M92P01	BLADE - FAN STG 2 (NARROW)	CF6-80C2	AR	26
1336M92P01	BLADE - FAN STG 2 (NARROW)	CF6-80C2	OH	3
1336M92P01	BLADE - FAN STG 2 (NARROW)	CF6-80C2	OH	4
1336M92P01	BLADE - FAN STG 2 (NARROW)	CF6-80C2	OH	8
1336M92P01	BLADE - FAN STG 2 (NARROW)	CF6-80C2	OH	12
1336M92P01	BLADE - FAN STG 2 (NARROW)	CF6-80C2	OH	9
1336M92P01	BLADE - FAN STG 2 (NARROW)	CF6-80C2	OH	8
1336M92P01	BLADE - FAN STG 2 (NARROW)	CF6-80C2	OH	16

Part Number	Part Description	Engine Type	Condition	Quantity
1336M92P02	BLADE - FAN STG 2 (WIDE)	CF6-80C2	AR	28
1336M92P02	BLADE - FAN STG 2 (WIDE)	CF6-80C2	AR	32
1336M92P02	BLADE - FAN STG 2 (WIDE)	CF6-80C2	AR	3
1336M93P01	BLADE - FAN STG 3 (NARROW)	CF6-80C2	OH	1
1336M93P01	BLADE - FAN STG 3 (NARROW)	CF6-80C2	OH	12
1336M93P01	BLADE - FAN STG 3 (NARROW)	CF6-80C2	OH	5
1336M93P02	BLADE - FAN STG 3 (WIDE)	CF6-80C2	AR	30
1336M94P01	BLADE - FAN STG 4 (NARROW)	CF6-80C2	OH	5
1336M94P01	BLADE - FAN STG 4 (NARROW)	CF6-80C2	OH	3
1336M94P01	BLADE - FAN STG 4 (NARROW)	CF6-80C2	OH	11
1336M94P01	BLADE - FAN STG 4 (NARROW)	CF6-80C2	SV	16
1336M94P01	BLADE - FAN STG 4 (NARROW)	CF6-80C2	OH	4
1336M94P01	BLADE - FAN STG 4 (NARROW)	CF6-80C2	OH	12
1336M94P01	BLADE - FAN STG 4 (NARROW)	CF6-80C2	OH	5
1336M94P01	BLADE - FAN STG 4 (NARROW)	CF6-80C2	OH	5
1336M94P02	BLADE - FAN STG 4 (WIDE)	CF6-80C2	OH	25
1336M94P02	BLADE - FAN STG 4 (WIDE)	CF6-80C2	OH	10
1336M95P01	BLADE - FAN STG 5 (NARROW)	CF6-80C2	OH	1
1336M95P01	BLADE - FAN STG 5 (NARROW)	CF6-80C2	AR	34
1336M95P01	BLADE - FAN STG 5 (NARROW)	CF6-80C2	AR	31
1336M95P01	BLADE - FAN STG 5 (NARROW)	CF6-80C2	OH	7
1336M95P01	BLADE - FAN STG 5 (NARROW)	CF6-80C2	OH	3
1336M95P02	BLADE - FAN STG 5 (WIDE)	CF6-80C2	AR	1
1336M95P02	BLADE - FAN STG 5 (WIDE)	CF6-80C2	AR	27
1336M95P02	BLADE - FAN STG 5 (WIDE)	CF6-80C2	AR	32
1336M95P02	BLADE - FAN STG 5 (WIDE)	CF6-80C2	AR	4
1336M95P02	BLADE - FAN STG 5 (WIDE)	CF6-80C2	AR	39
1336M95P02	BLADE - FAN STG 5 (WIDE)	CF6-80C2	OH	2
1336M95P03	BLADE - FAN STG 5 (LOCKING)	CF6-80C2	AR	2
1336M95P03	BLADE - FAN STG 5 (LOCKING)	CF6-80C2	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
1336M95P03	BLADE - FAN STG 5 (LOCKING)	CF6-80C2	AR	2
1336M95P04	BLADE - FAN STG 5 (LOCKING)	CF6-80C2	AR	2
1336M95P04	BLADE - FAN STG 5 (LOCKING)	CF6-80C2	AR	2
1336M95P04	BLADE - FAN STG 5 (LOCKING)	CF6-80C2	AR	2
1336M95P04	BLADE - FAN STG 5 (LOCKING)	CF6-80C2	AR	2
1336M99G04	CASE - LOW PRESSURE TURBINE	CF6-80C2	AR	1
1337M13G03	TUBE - AIR HP RECOUP	CF6-80C2	OH	1
1337M83G05	BRACKET - IDG	CF6-80C2	SV	1
1338M17G02	BRACKET - LPT RS	CF6-80A	SV	1
1338M22P01	BEARING - PLAIN SPHERICAL	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
1338M22P01	BEARING - PLAIN SPHERICAL	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	NS	12
1338M24P01	BEARING - PLAIN SPHERICAL	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
1338M28G01	PLATE	CF6-80A	NS	1
1338M28G01	PLATE	CF6-80A	NS	1
1338M30G01	MANIFOLD - COOLING LPT	CF6-80A	SV	1
1338M30G01	MANIFOLD - COOLING LPT	CF6-80A	OH	1
1338M51P01	BLADE - FAN STG 1	CF6-80C2	OH	1
1338M51P01	BLADE - FAN STG 1	CF6-80C2	OH	1
1338M51P01	BLADE - FAN STG 1	CF6-80C2	OH	1
1338M51P02	BLADE - FAN STG 1	CF6-80C2	OH	1
1338M51P03	BLADE - FAN STG 1	CF6-80C2, CF6-80A	SV	1
1338M51P03	BLADE - FAN STG 1	CF6-80C2, CF6-80A	SV	1
1338M51P03	BLADE - FAN STG 1	CF6-80C2, CF6-80A	SV	1
1338M51P03	BLADE - FAN STG 1	CF6-80C2, CF6-80A	OH	1
1338M51P03	BLADE - FAN STG 1	CF6-80C2, CF6-80A	OH	1
1338M51P05	BLADE - FAN STG 1	CF6-80C2	OH	1
1338M74P001A	BRACKET - COOLING	CF6-80A	AR	1
1338M74P001A	BRACKET - COOLING	CF6-80A	SV	1
1338M74P001A	BRACKET - COOLING	CF6-80A	SV	1
1338M74P001A	BRACKET - COOLING	CF6-80A	NE	3
1338M74P001A	BRACKET - COOLING	CF6-80A	NE	1

Part Number	Part Description	Engine Type	Condition	Quantity
1338M75G01	BRACKET - LPT RS	CF6-80A	OH	1
1339M65G03	TUBE - AGB	CF6-80C2	SV	1
1339M67G01	MANIFOLD - PUMP DISCHARGE	CF6-80C2	SV	1
1339M69G01	TUBE - OIL LUBE PUMP	CF6-80C2	NS	1
1339M74G02	BRACKET - TRANSMITTER	CF6-80C2	SV	1
1339M80P04	ACTUATOR - VBV	CF6-80C2	AR	1
1339M80P06	ACTUATOR - VBV	CF6-80C2	AR	1
133A1624P43	SPACER - WASHER	CF6-50 (Boeing)	NS	4
1340M24P01	SEAL - BOOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	26
1340M24P01	SEAL - BOOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	5
1340M24P01	SEAL - BOOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	15
1340M24P01	SEAL - BOOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	8
1340M24P01	SEAL - BOOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
1340M24P02	SEAL - BOOT	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	SV	6
1340M24P02	SEAL - BOOT	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
1340M24P02	SEAL - BOOT	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	NE	4
1340M24P07	SEAL - BOOT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
1340M24P07	SEAL - BOOT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	8
1340M24P07	SEAL - BOOT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	5
1340M24P07	SEAL - BOOT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	20

Part Number	Part Description	Engine Type	Condition	Quantity
1340M24P07	SEAL - BOOT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	17
1340M24P07	SEAL - BOOT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
1340M24P07	SEAL - BOOT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
1340M24P07	SEAL - BOOT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	3
1340M24P07	SEAL - BOOT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
1340M24P07	SEAL - BOOT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	175
1340M24P07	SEAL - BOOT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	5
1340M24P07	SEAL - BOOT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	4
1340M24P07	SEAL - BOOT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
1340M24P07	SEAL - BOOT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	12
1340M49P01	SHIELD - HEAT TURB REAR	CF6-80C2	AR	1
1340M49P01	SHIELD - HEAT TURB REAR	CF6-80C2	AR	1
1340M49P01	SHIELD - HEAT TURB REAR	CF6-80C2	AR	1
1340M49P01	SHIELD - HEAT TURB REAR	CF6-80C2	OH	1
1340M76P01	TGB BALL BEARING	CF6-80C2	AR	1
1340M76P01	TGB BALL BEARING	CF6-80C2	AR	1
1340M76P01	TGB BALL BEARING	CF6-80C2	AR	1
1340M76P01	TGB BALL BEARING	CF6-80C2	AR	1
1340M76P01	TGB BALL BEARING	CF6-80C2	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
1340M76P01	TGB BALL BEARING	CF6-80C2	OH	1
1340M79P01	BEARING - BALL	CF6-80C2	SV	1
1345M22G01	CABLE	CF6-80C2	SV	1
1345M65P01	MOUNT - OIL TANK LOWER FWD	CF6-80C2	SV	1
1346M17G03	MANIFOLD - AIR CORE COWL	CF6-80C2	OH	1
1346M17G03	MANIFOLD - AIR CORE COWL	CF6-80C2	OH	1
1346M17G03	MANIFOLD - AIR CORE COWL	CF6-80C2	AR	1
1346M33G01	MANIFOLD - OIL LUBE SUPPLY	CF6-80C2	AR	1
1346M41P01	RING - EXTERNAL THREAD	CF6-80C2	NS	1
1346M44P001E	BRACKET - OIL TANK TUBE	CF6-80C2	NS	1
1346M44P001E	BRACKET - OIL TANK TUBE	CF6-80C2	OH	1
1346M50P001A	BRACKET	CF6-80C2	SV	1
1346M60G05	BRACKET	CF6-80C2	NS	1
1346M74G03	BRACKET - EBU	CF6-80C2	SV	1
1346M74G03	BRACKET - EBU	CF6-80C2	SV	1
1346M97G07	BRACKET - UPPER IDG	CF6-80C2	NS	1
1347M15G04	VANE - OUTLET GUIDE TYPE 2	CF6-80C2	OH	1
1347M28G02	#4R BEARING STATIONARY CDP SEAL	CF6-80C2	OH	1
1347M28G02	#4R BEARING STATIONARY CDP SEAL	CF6-80C2	OH	1
1347M28G02	#4R BEARING STATIONARY CDP SEAL	CF6-80C2	OH	1
1347M31P01	SEAL - BRG NO. 4	CF6-80C2	SV	1
1347M31P01	SEAL - BRG NO. 4	CF6-80C2	OH	1
1347M31P02	SEAL - BRG NO. 4	CF6-80C2	OH	1
1347M32G08	CARBON ASSY - SEAL AND RING	CF6-80C2	OH	1
1347M47P05	DOUBLER - FWD FAN CASE	CF6-80C2	NE	1
1347M47P05	DOUBLER - FWD FAN CASE	CF6-80C2	NE	2
1347M56G01	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G01	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G01	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G01	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G01	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
1347M56G01	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G01	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G01	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G01	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G01	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G01	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G01	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G01	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G01	VANE SEG - FAN BSTR STG 5	CF6-80C2	SV	1
1347M56G01	VANE SEG - FAN BSTR STG 5	CF6-80C2	OH	1
1347M56G01	VANE SEG - FAN BSTR STG 5	CF6-80C2	OH	1
1347M56G01	VANE SEG - FAN BSTR STG 5	CF6-80C2	OH	1
1347M56G01	VANE SEG - FAN BSTR STG 5	CF6-80C2	OH	1
1347M56G01	VANE SEG - FAN BSTR STG 5	CF6-80C2	OH	1
1347M56G01	VANE SEG - FAN BSTR STG 5	CF6-80C2	OH	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	AR	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	OH	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	OH	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	OH	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	OH	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	OH	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	OH	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	OH	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	OH	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	OH	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	OH	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	OH	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	OH	1
1347M56G02	VANE SEG - FAN BSTR STG 5	CF6-80C2	OH	1
1347M57P02	SEAL - STG 5	CF6-80C2	NE	1

[illegible]

[illegible]

Part Number	Part Description	Engine Type	Condition	Quantity
1347M95G08	BAFFLE - SHROUD STG 1	CF6-50 (LMCO)	AR	1
1347M95G08	BAFFLE - SHROUD STG 1	CF6-50 (LMCO)	AR	1
1347M95G08	BAFFLE - SHROUD STG 1	CF6-50 (LMCO)	AR	1
1347M95G08	BAFFLE - SHROUD STG 1	CF6-50 (LMCO)	AR	1
1347M95G08	BAFFLE - SHROUD STG 1	CF6-50 (LMCO)	AR	1
1347M95G08	BAFFLE - SHROUD STG 1	CF6-50 (LMCO)	AR	1
1347M95G08	BAFFLE - SHROUD STG 1	CF6-50 (LMCO)	AR	1
1347M95G08	BAFFLE - SHROUD STG 1	CF6-50 (LMCO)	AR	1
1347M95G08	BAFFLE - SHROUD STG 1	CF6-50 (LMCO)	AR	1
1347M95G08	BAFFLE - SHROUD STG 1	CF6-50 (LMCO)	AR	1
1347M95G08	BAFFLE - SHROUD STG 1	CF6-50 (LMCO)	AR	1
1347M95G08	BAFFLE - SHROUD STG 1	CF6-50 (LMCO)	AR	1
1347M95G08	BAFFLE - SHROUD STG 1	CF6-50 (LMCO)	AR	1
1347M95G08	BAFFLE - SHROUD STG 1	CF6-50 (LMCO)	AR	1
1349M35P001B	BRACKET	CF6-80C2	OH	1
1349M43G02	TUBE - B OIL SUMP SCAV	CF6-80C2	SV	1
1349M43G02	TUBE - B OIL SUMP SCAV	CF6-80C2	SV	1
1349M64P001A	BRACKET - TUBE	CF6-80C2	NE	2
1349M66G01	BRACKET - SUPPORT	CF6-80C2	OH	1
1349M73P001A	BRACKET	CF6-80C2	NE	1
1349M85G01	TUBE - AIR PS3 CORE AFT	CF6-80C2	NE	1
1349M87G01	TUBE - AIR R/S VALVE	CF6-80C2	OH	1
1350M16P001A	BRACKET	CF6-80C2	NS	1
1350M16P001A	BRACKET	CF6-80C2	NS	2
1350M16P001A	BRACKET	CF6-80C2	NS	2
1350M41P001A	BRACKET	CF6-80C2	NE	1
1350M45P01	JOINT - FLEXIBLE WYE	CF6-80C2, CF6-80A	NE	1
1350M93G01	TUBE - OIL TANK	CF6-80C2	OH	1
1350M97G05	BRACKET - EBU	CF6-80C2	NE	1
1370M16G17	LINER ASSY - INNER OGV	CF6-80C2	OH	1
1370M54G01	#4R BEARING STATIONARY AIR/OIL SEAL	CF6-80C2	OH	1
1370M54G01	#4R BEARING STATIONARY AIR/OIL SEAL	CF6-80C2	OH	1
1370M73G01	SUPPORT - SHROUD HPT STATOR	CF6-80A	OH	1
1370M75G02	TUBE - SCAVENGE	CF6-80C2	SV	1
1370M93G01	CASE ASSY - FR CPRSR STTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1370M93G01	CASE ASSY - FR CPRSR STTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1374M25P003A	BRACKET - IGNITION LEAD	CF6-80A	NE	4
1374M27G01	ADAPTER - PL TUBE	CF6-80C2	NE	1
1374M42P001A	BRACKET	CF6-80C2	SV	1
1374M57P001B	BRACKET	CF6-80C2	NS	1
1374M57P001B	BRACKET	CF6-80C2	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
1374M82G01	BRACKET - EBU	CF6-80C2	SV	1
1374M88G01	TUBE - AIR P14	CF6-80C2	OH	1
1374M98P05	ACTUATOR - VSV	CF6-80C2	OH	1
1375M10P03	#4 BEARING VENT SEAL	CF6-80C2	SV	1
1375M12P01	HPC ROTOR CDP SEAL DAMP RING	CF6-80C2	NE	1
1375M12P01	HPC ROTOR CDP SEAL DAMP RING	CF6-80C2	NE	2
1375M12P02	HPC ROTOR ROTATING CDP SEAL	CF6-80C2	OH	1
1375M12P02	HPC ROTOR ROTATING CDP SEAL	CF6-80C2	NE	2
1375M37G01	LINER - SEG FAN CASE MID OUT	CF6-80C2	SV	1
1375M37G02	LINER - SEG FAN CASE MID OUT	CF6-80C2	SV	1
1375M50P23	SEAL - O-RING	CF6-80C2	NS	1
1375M62P01	#6 BEARING ROTAT OIL SEAL	CF6-80C2	OH	1
1375M62P01	#6 BEARING ROTAT OIL SEAL	CF6-80C2	OH	1
1378M50P037A	MOUNT	CF6-80C2	NE	1
1378M50P037A	MOUNT	CF6-80C2	NS	1
1378M50P039A	MOUNT	CF6-80C2	NE	1
1378M50P039A	MOUNT	CF6-80C2	NE	1
1378M50P039A	MOUNT	CF6-80C2	NE	1
1378M50P039A	MOUNT	CF6-80C2	NE	1
1378M50P039A	MOUNT	CF6-80C2	OH	1
1378M88P001A	COVER - DISHED HEAT SHIELD	CF6-80C2	OH	1
1378M88P001A	COVER - DISHED HEAT SHIELD	CF6-80C2	OH	1
1378M88P001A	COVER - DISHED HEAT SHIELD	CF6-80C2	SV	1
13796-521	DUCT ASSY - 14TH STAGE	CF6-80A	AR	1
13797-527	DUCT ASSY - 8TH STAGE JOINT	CF6-80A	AR	1
1379M24P003A	BRACKET - SUPPORT	CF6-50 (Boeing)	SV	1
1379M50G05	TUBE ASSY - AIR STG 7	CF6-50 (Boeing)	SV	1
1379M50G05	TUBE ASSY - AIR STG 7	CF6-50 (Boeing)	OH	1
1379M50G05	TUBE ASSY - AIR STG 7	CF6-50 (Boeing)	OH	1
1379M50G05	TUBE ASSY - AIR STG 7	CF6-50 (Boeing)	OH	1
1379M50G05	TUBE ASSY - AIR STG 7	CF6-50 (Boeing)	OH	1
1379M50G05	TUBE ASSY - AIR STG 7	CF6-50 (Boeing)	OH	1
1379M50G05	TUBE ASSY - AIR STG 7	CF6-50 (Boeing)	OH	1
1379M50G05	TUBE ASSY - AIR STG 7	CF6-50 (Boeing)	SV	1
1379M50G05	TUBE ASSY - AIR STG 7	CF6-50 (Boeing)	AR	1
1379M50G05	TUBE ASSY - AIR STG 7	CF6-50 (Boeing)	OH	1
1379M50G05	TUBE ASSY - AIR STG 7	CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
1379M50G05	TUBE ASSY - AIR STG 7	CF6-50 (Boeing)	OH	1
1379M50G05	TUBE ASSY - AIR STG 7	CF6-50 (Boeing)	AR	1
1379M50G05	TUBE ASSY - AIR STG 7	CF6-50 (Boeing)	AR	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	AR	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	SV	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	AR	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	AR	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	AR	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	AR	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	AR	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	SV	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	OH	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	OH	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	OH	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	AR	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	OH	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	SV	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	AR	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	OH	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	SV	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	AR	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	AR	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	AR	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	AR	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	OH	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	AR	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	AR	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	OH	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	AR	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	SV	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	AR	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	AR	1
1379M51G05	TUBE - AIR COOLING LPT	CF6-50 (Boeing)	NS	3
1379M52G05	TUBE ASSY - AIR STRUT NO. 6	CF6-50 (Boeing)	OH	1
1379M52G05	TUBE ASSY - AIR STRUT NO. 6	CF6-50 (Boeing)	OH	1
1379M52G05	TUBE ASSY - AIR STRUT NO. 6	CF6-50 (Boeing)	OH	1
1379M52G05	TUBE ASSY - AIR STRUT NO. 6	CF6-50 (Boeing)	OH	1
1379M52G05	TUBE ASSY - AIR STRUT NO. 6	CF6-50 (Boeing)	OH	1
1379M52G05	TUBE ASSY - AIR STRUT NO. 6	CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
1379M52G05	TUBE ASSY - AIR STRUT NO. 6	CF6-50 (Boeing)	OH	1
1379M52G05	TUBE ASSY - AIR STRUT NO. 6	CF6-50 (Boeing)	AR	1
1379M52G05	TUBE ASSY - AIR STRUT NO. 6	CF6-50 (Boeing)	OH	1
1379M52G05	TUBE ASSY - AIR STRUT NO. 6	CF6-50 (Boeing)	OH	1
1379M52G05	TUBE ASSY - AIR STRUT NO. 6	CF6-50 (Boeing)	AR	1
1379M52G05	TUBE ASSY - AIR STRUT NO. 6	CF6-50 (Boeing)	OH	1
1379M52G05	TUBE ASSY - AIR STRUT NO. 6	CF6-50 (Boeing)	OH	1
1379M52G05	TUBE ASSY - AIR STRUT NO. 6	CF6-50 (Boeing)	AR	1
1379M52G05	TUBE ASSY - AIR STRUT NO. 6	CF6-50 (Boeing)	AR	1
1379M52G05	TUBE ASSY - AIR STRUT NO. 6	CF6-50 (Boeing)	AR	1
1379M52G05	TUBE ASSY - AIR STRUT NO. 6	CF6-50 (Boeing)	AR	1
1379M52G05	TUBE ASSY - AIR STRUT NO. 6	CF6-50 (Boeing)	AR	1
1379M53G05	TUBE ASSY - AIR STRUT NO. 7	CF6-50 (Boeing)	SV	1
1379M53G05	TUBE ASSY - AIR STRUT NO. 7	CF6-50 (Boeing)	OH	1
1379M53G05	TUBE ASSY - AIR STRUT NO. 7	CF6-50 (Boeing)	OH	1
1379M53G05	TUBE ASSY - AIR STRUT NO. 7	CF6-50 (Boeing)	OH	1
1379M53G05	TUBE ASSY - AIR STRUT NO. 7	CF6-50 (Boeing)	OH	1
1379M53G05	TUBE ASSY - AIR STRUT NO. 7	CF6-50 (Boeing)	OH	1
1379M53G05	TUBE ASSY - AIR STRUT NO. 7	CF6-50 (Boeing)	OH	1
1379M53G05	TUBE ASSY - AIR STRUT NO. 7	CF6-50 (Boeing)	OH	1
1379M53G05	TUBE ASSY - AIR STRUT NO. 7	CF6-50 (Boeing)	AR	1
1379M53G05	TUBE ASSY - AIR STRUT NO. 7	CF6-50 (Boeing)	OH	1
1379M53G05	TUBE ASSY - AIR STRUT NO. 7	CF6-50 (Boeing)	AR	1
1379M53G05	TUBE ASSY - AIR STRUT NO. 7	CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
1379M53G05	TUBE ASSY - AIR STRUT NO. 7	CF6-50 (Boeing)	OH	1
1379M53G05	TUBE ASSY - AIR STRUT NO. 7	CF6-50 (Boeing)	AR	1
1379M53G05	TUBE ASSY - AIR STRUT NO. 7	CF6-50 (Boeing)	OH	1
1379M53G05	TUBE ASSY - AIR STRUT NO. 7	CF6-50 (Boeing)	AR	1
1379M53G05	TUBE ASSY - AIR STRUT NO. 7	CF6-50 (Boeing)	AR	1
1379M53G05	TUBE ASSY - AIR STRUT NO. 7	CF6-50 (Boeing)	AR	1
1379M53G05	TUBE ASSY - AIR STRUT NO. 7	CF6-50 (Boeing)	AR	1
1379M54G05	TUBE ASSY - AIR STRUT NO. 8	CF6-50 (Boeing)	OH	1
1379M54G05	TUBE ASSY - AIR STRUT NO. 8	CF6-50 (Boeing)	OH	1
1379M54G05	TUBE ASSY - AIR STRUT NO. 8	CF6-50 (Boeing)	OH	1
1379M54G05	TUBE ASSY - AIR STRUT NO. 8	CF6-50 (Boeing)	OH	1
1379M54G05	TUBE ASSY - AIR STRUT NO. 8	CF6-50 (Boeing)	OH	1
1379M54G05	TUBE ASSY - AIR STRUT NO. 8	CF6-50 (Boeing)	OH	1
1379M54G05	TUBE ASSY - AIR STRUT NO. 8	CF6-50 (Boeing)	OH	1
1379M54G05	TUBE ASSY - AIR STRUT NO. 8	CF6-50 (Boeing)	OH	1
1379M54G05	TUBE ASSY - AIR STRUT NO. 8	CF6-50 (Boeing)	SV	1
1379M54G05	TUBE ASSY - AIR STRUT NO. 8	CF6-50 (Boeing)	OH	1
1379M54G05	TUBE ASSY - AIR STRUT NO. 8	CF6-50 (Boeing)	OH	1
1379M54G05	TUBE ASSY - AIR STRUT NO. 8	CF6-50 (Boeing)	OH	1
1379M54G05	TUBE ASSY - AIR STRUT NO. 8	CF6-50 (Boeing)	AR	1
1379M54G05	TUBE ASSY - AIR STRUT NO. 8	CF6-50 (Boeing)	OH	1
1379M54G05	TUBE ASSY - AIR STRUT NO. 8	CF6-50 (Boeing)	AR	1
1379M54G05	TUBE ASSY - AIR STRUT NO. 8	CF6-50 (Boeing)	AR	1
1379M54G05	TUBE ASSY - AIR STRUT NO. 8	CF6-50 (Boeing)	AR	1
1379M67P01	MANIFOLD - AIR LPT RH	CF6-50 (LMCO)	OH	1
1379M87P02	SEAL - GASKET HEATSHIELD	CF6-80A	NS	5

Part Number	Part Description	Engine Type	Condition	Quantity
1379M87P03	SEAL - GASKET HEATSHIELD	CF6-80A	NE	5
1379M88P001A	RETAINER - SEAL HEATSHIELD	CF6-80A	SV	1
1379M89P001A	RETAINER - SEAL HEATSHIELD	CF6-80A	NE	3
1379M90P001A	BRACKET - IGNITION LEAD	CF6-80A	NS	2
1380M14G09	LINK ASSY - PLATFORM	CF6-80C2	OH	1
1380M14G09	LINK ASSY - PLATFORM	CF6-80C2	OH	1
1380M14G10	LINK ASSY - PLATFORM	CF6-80C2	OH	1
1380M14G11	LINK ASSY - PLATFORM	CF6-80C2	OH	1
1380M14G12	LINK ASSY - PLATFORM	CF6-80C2	OH	1
1380M28P02	BUMPER (SPD)	CF6-80A	NE	5
1380M28P02	BUMPER (SPD)	CF6-80A	NE	2
1380M28P02	BUMPER (SPD)	CF6-80A	NE	6
1380M28P02	BUMPER (SPD)	CF6-80A	NE	9
1380M28P02	BUMPER (SPD)	CF6-80A	NE	3
1380M28P02	BUMPER (SPD)	CF6-80A	NE	5
1380M29P01	BUMPER (SPD)	CF6-80A	NE	44
1380M29P01	BUMPER (SPD)	CF6-80A	NE	45
1380M42G09	LINK ASSY - FRAME	CF6-80C2	SV	1
1380M42G09	LINK ASSY - FRAME	CF6-80C2	OH	1
1380M42G10	LINK ASSY - FRAME	CF6-80C2	OH	1
1380M42G11	LINK ASSY - FRAME	CF6-80C2	OH	1
1380M42G12	LINK ASSY - FRAME	CF6-80C2	OH	1
1380M46P01	HPT NOZZLE STG 2 COOLING AIR TUBE	CF6-80C2	NE	64
1380M46P01	HPT NOZZLE STG 2 COOLING AIR TUBE	CF6-80C2	NE	50
1380M53G19	FAIRING - OUTER	CF6-80A	NS	3
1380M53G19	FAIRING - OUTER	CF6-80A	OH	3
1380M53G21	FAIRING - OUTER	CF6-80A	AR	3
1380M56G10	MANIFOLD - COOLING LPT	CF6-80C2	OH	1
1380M56G10	MANIFOLD - COOLING LPT	CF6-80C2	OH	1
1380M56G10	MANIFOLD - COOLING LPT	CF6-80C2	OH	1
1380M56G10	MANIFOLD - COOLING LPT	CF6-80C2	OH	1
1380M56G10	MANIFOLD - COOLING LPT	CF6-80C2	OH	1
1380M56G10	MANIFOLD - COOLING LPT	CF6-80C2	OH	1
1380M56G10	MANIFOLD - COOLING LPT	CF6-80C2	OH	1
1380M56G10	MANIFOLD - COOLING LPT	CF6-80C2	OH	1
1380M56G10	MANIFOLD - COOLING LPT	CF6-80C2	OH	1
1380M56G10	MANIFOLD - COOLING LPT	CF6-80C2	AR	1
1380M56G12	MANIFOLD - COOLING LPT	CF6-80C2	AR	1
1380M56G12	MANIFOLD - COOLING LPT	CF6-80C2	OH	1
1380M56G15	MANIFOLD - COOLING LPT	CF6-80C2	OH	1
1380M56G15	MANIFOLD - COOLING LPT	CF6-80C2	OH	1
1380M56G17	MANIFOLD - COOLING LPT	CF6-80C2	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
1380M56G19	MANIFOLD - COOLING LPT	CF6-80C2	OH	1
1380M71G22	NOZZLE - LPT STG 1	CF6-80C2	OH	1
1380M71G22	NOZZLE - LPT STG 1	CF6-80C2	OH	1
1380M72G04	NOZZLE - LPT STG 2	CF6-80C2	AR	1
1380M72G04	NOZZLE - LPT STG 2	CF6-80C2	OH	1
1380M79G09	SEAL - HPTS INTERSTAGE AIR	CF6-50	OH	1
1380M79G09	SEAL - HPTS INTERSTAGE AIR	CF6-50	OH	1
1380M80P01	SPACER (.176-.178)	CF6-50	NE	2
1380M80P02	SPACER (.191-.193)	CF6-50	NE	2
1380M80P03	SPACER (.206-.208)	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
1380M80P05	SPACER (.236-.238)	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
1380M80P05	SPACER (.236-.238)	CF6-50 (LMCO), CF6-50 (Boeing)	NS	7
1380M80P06	SPACER (.251-.253)	CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
1380M80P06	SPACER (.251-.253)	CF6-50 (LMCO), CF6-50 (Boeing)	NS	10
1380M80P06	SPACER (.251-.253)	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
1380M80P07	SPACER (.266-.268)	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
1380M80P07	SPACER (.266-.268)	CF6-50 (LMCO), CF6-50 (Boeing)	NS	6
1380M80P07	SPACER (.266-.268)	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
1380M80P08	SPACER (.281-.283)	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
1380M80P08	SPACER (.281-.283)	CF6-50 (LMCO), CF6-50 (Boeing)	NS	8
1380M80P09	SPACER (.296-.298)	CF6-50	NS	8
1380M80P10	SPACER (.311-.313)	CF6-50 (LMCO)	NS	8
1380M80P10	SPACER (.311-.313)	CF6-50 (LMCO)	NS	25
1380M85G01	#2 BEARING FAN SPEED SENSOR	CF6-80C2	AR	1
1380M85G01	#2 BEARING FAN SPEED SENSOR	CF6-80C2	AR	1
1380M85G01	#2 BEARING FAN SPEED SENSOR	CF6-80C2	AR	1
1383M12G02	TUBE - HMU TO FLOWMETER	CF6-80C2	SV	1
1383M18P02	SENSOR N1	CF6-80C2	SV	1
1383M20P001C	BRACKET - EBU	CF6-80C2	OH	1
1383M33G01	BRACKET - HPT AND CORE	CF6-80C2	AR	1
1383M47P001A	BRACKET	CF6-80C2	NE	1
1383M47P001A	BRACKET	CF6-80C2	NE	1

Part Number	Part Description	Engine Type	Condition	Quantity
1383M54G02	TUBE - MEC SERVO DRAIN FUEL	CF6-80C2	OH	1
1383M54G02	TUBE - MEC SERVO DRAIN FUEL	CF6-80C2	OH	1
1383M65G02	TUBE - IDG OIL DRAIN	CF6-80C2	OH	1
1383M65G03	TUBE - IDG OIL DRAIN	CF6-80C2	OH	1
1383M65G03	TUBE - IDG OIL DRAIN	CF6-80C2	OH	1
1383M76G01	BRACKET	CF6-80C2	SV	1
1383M77P001A	BRACKET	CF6-80C2	OH	1
1383M77P001A	BRACKET	CF6-80C2	SV	1
140900-243	SEAL - O-RING	CF6-50	NS	4
1440M41P01	SPACER - FLOW BLEED BIAS	CF6-80C2	AR	1
1440M41P01	SPACER - FLOW BLEED BIAS	CF6-80C2	AR	1
1440M64G02	SENSOR - FLOW BLEED BIAS	CF6-80C2	NE	1
1442M21G01	TUBE - UNDER COWL COOLING	CF6-80C2	SV	1
1442M25G01	TUBE - LWR H/X TO OIL TANK	CF6-80C2	OH	1
1442M27G03	TUBE - MAST MANF TO MDL PT	CF6-80C2	NS	1
1442M68G01	TUBE - AIR ADAPTER	CF6-80C2	NS	1
1442M77P01	BRACKET - LINK SHORT	CF6-80C2	NS	1
1442M80G02	TUBE - LUBE	CF6-80C2	OH	1
1442M91G03	BRACKET ASSY - CLEVIS	CF6-80C2	SV	1
1446M19G07	TUBE - AIR LPT SUPPLY	CF6-80C2	OH	1
1446M70G01	MANIFOLD - FUEL VSV	CF6-80C2	OH	1
1446M76P01	CAP - EXT THD	CF6-80C2	NS	1
1447M16G01	TUBE - OIL SERVO HEATER	CF6-80C2	NS	1
1447M87G02	SHIELD - SPRAY	CF6-80C2	AR	1
1453M10G02	TUBE - 11TH STAGE	CF6-80C2	NS	1
1453M14P01	SEAL - IGNITION WIRES	CF6-80C2, CF6-80A	NS	2
1453M17P01	SEAL	CF6-80C2	AR	1
1453M17P01	SEAL	CF6-80C2	NE	3
1453M20P001A	BRACKET - PYLON DRAIN	CF6-80C2	NE	1
1453M25G01	TUBE - N1 DRAIN FUEL	CF6-80C2	OH	1
1453M27G01	TUBE - N1 DRAIN FUEL	CF6-80C2	OH	1
1453M33G02	BRACKET - ACCELEROMETER	CF6-80C2, CF6-80A	NE	1
1453M55G01	BRACKET - HP RECOUP	CF6-80C2	NE	1
1453M55G01	BRACKET - HP RECOUP	CF6-80C2	NE	1
1453M58G01	BRACKET	CF6-80C2	OH	1
1453M75G01	TUBE - FUEL (NEUTRAL)	CF6-80C2	AR	1
1453M75G01	TUBE - FUEL (NEUTRAL)	CF6-80C2	NS	1
1453M80P001A	BRACKET - CLEAR SIG	CF6-80C2	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
1453M87G02	ELBOW - HP RECOUP	CF6-80C2	OH	2
1453M87G02	ELBOW - HP RECOUP	CF6-80C2	OH	1
1454M35G01	TUBE - CDP	CF6-80C2	OH	1
1454M35G01	TUBE - CDP	CF6-80C2	OH	1
1454M42G01	PLATE - BASE	CF6-80C2	OH	4
1454M54G02	TUBE - AIR PS3	CF6-80C2	OH	1
1454M54G02	TUBE - AIR PS3	CF6-80C2	SV	1
1454M58G06	PYLON ASSY - BARRIER	CF6-80C2	OH	1
1454M58G06	PYLON ASSY - BARRIER	CF6-80C2	SV	1
1454M59G02	NOZZLE - AIR CURTAIN	CF6-80C2	SV	1
1454M72G01	BRACKET - SUPPORT	CF6-80C2	NE	1
1454M82P03	PLATE - CTR	CF6-80C2	NS	1
1455M10P001A	BRACKET - ANGLE	CF6-80C2	NS	1
1455M20P003A	BRACKET - ANGLE	CF6-80C2	NS	3
1455M20P003A	BRACKET - ANGLE	CF6-80C2	NS	1
1455M51P001A	BRACKET - TUBE IDG	CF6-80C2	NS	1
1455M76G01	TUBE - IDG FUEL/OIL	CF6-80C2	OH	1
1455M91G01	TUBE - D OIL SCAV FWD	CF6-80C2	SV	1
1455M91G01	TUBE - D OIL SCAV FWD	CF6-80C2	AR	1
1456M25G01	TUBE - CDP AIR	CF6-80C2	OH	1
1456M54G03	BRACKET	CF6-80C2	SV	1
1456M63G01	TUBE - AIR BORE	CF6-80C2	AR	1
1456M83G01	TUBE - OIL IDG CLG	CF6-80C2	OH	1
1456M83G01	TUBE - OIL IDG CLG	CF6-80C2	OH	1
1456M85G01	BRACKET - BORE CLG	CF6-80C2	AR	1
1456M86G01	BRACKET - BORE CLG	CF6-80C2	AR	1
1456M87G01	BRACKET - BORE CLG FLEX	CF6-80C2	AR	1
1456M88G01	BRACKET - TUBES BORE CLG	CF6-80C2	AR	1
1456M91G01	BRACKET - BORE CLG FLEX	CF6-80C2	AR	1
1456M97G05	TUBE - AIR LPT CLG LS	CF6-80C2	SV	1
1456M97G06	TUBE - AIR LPT CLG LS	CF6-80C2	AR	1
1459M42P01	#4 MAIN BALL BEARING	CF6-80C2, CF6-80A	OH	1
1459M66P01	SLEEVE - OGV	CF6-80C2	NE	15
1459M66P01	SLEEVE - OGV	CF6-80C2	NE	18
1459M66P02	SLEEVE - OGV	CF6-80C2	NE	3
1459M66P02	SLEEVE - OGV	CF6-80C2	NE	2
1459M66P03	SLEEVE - OGV	CF6-80C2	NE	2
1459M66P03	SLEEVE - OGV	CF6-80C2	NE	28
1465M46G09	LINER - COMB CHMBR OUT	CF6-80C2	AR	1
1468M14G01	TUBE - FUEL DRAIN	CF6-80C2	SV	1
1468M14G01	TUBE - FUEL DRAIN	CF6-80C2	NS	2
1468M14G01	TUBE - FUEL DRAIN	CF6-80C2	SV	1
1468M24P001A	BRACKET - TUBE	CF6-80C2	AR	1
1468M53G01	TUBE - AIR BORE	CF6-80C2	NE	3

Part Number	Part Description	Engine Type	Condition	Quantity
1468M57G02	TUBE - FUEL DRAIN VALVE	CF6-80C2	SV	1
1468M57G02	TUBE - FUEL DRAIN VALVE	CF6-80C2	OH	1
1469M28G03	TUBE - LP RECOUP	CF6-80C2	SV	1
1469M31G01	BRACKET - V BORE CLG	CF6-80C2	AR	1
1469M51P001A	BRACKET - ANGLE	CF6-80C2	NS	1
1469M51P001A	BRACKET - ANGLE	CF6-80C2	NS	1
1469M62G01	TUBE - FUEL HMU	CF6-80C2	SV	1
1469M74G02	TUBE - AIR BORE	CF6-80C2	OH	1
1469M88G01	BRACKET - BORE CLG V LH	CF6-80C2	AR	1
1470M11P03	BRACKET	CF6-80C2	NE	1
1470M12P01	BRACKET	CF6-80C2	NE	1
1470M15P01	BRACKET - MANIFOLD HPT	CF6-80C2	NS	1
1470M15P01	BRACKET - MANIFOLD HPT	CF6-80C2	NS	1
1470M30G01	BRACKET - AIR TUBE	CF6-80C2	SV	1
1470M52P001A	BRACKET - ELEC LEAD	CF6-80C2	NE	3
1470M52P001A	BRACKET - ELEC LEAD	CF6-80C2	SV	1
1470M53G01	BRACKET - ELECTRIC FAN	CF6-80C2	SV	1
1470M55G01	BRACKET - ELECTRIC	CF6-80C2	SV	1
1470M55G01	BRACKET - ELECTRIC	CF6-80C2	SV	1
1470M61P001A	BRACKET - FIRE DETECTOR	CF6-80C2	NE	1
1470M61P001A	BRACKET - FIRE DETECTOR	CF6-80C2	NE	1
1470M61P001A	BRACKET - FIRE DETECTOR	CF6-80C2	NE	1
1470M63G01	BRACKET	CF6-80C2	OH	1
1470M67G01	BRACKET	CF6-80C2	AR	1
1470M79P001B	BRACKET - MANIFOLD	CF6-80C2	SV	1
1470M84P001A	BRACKET - ELECTRICAL	CF6-80C2	NE	1
1471M60G03	LINER ASSY - INNER OGV	CF6-80C2	OH	1
1471M60G03	LINER ASSY - INNER OGV	CF6-80C2	OH	1
1471M60G04	LINER ASSY - INNER OGV	CF6-80C2	REP	1
1471M60G05	LINER ASSY - INNER OGV	CF6-80C2	OH	1
1471M60G05	LINER ASSY - INNER OGV	CF6-80C2	OH	1
1471M60G07	LINER ASSY - INNER OGV	CF6-80C2	OH	1
1472M32G02	HOUSING - BRG NO. 1	CF6-80C2	AR	1
1472M40G01	BRACKET ASSY - ABG	CF6-80A	AR	1
1472M63G01	LINK - SIDE	CF6-80C2	OH	2
1472M64P01	BRACKET - RH MOUNT AGB	CF6-80C2	SV	1
1472M64P01	BRACKET - RH MOUNT AGB	CF6-80C2	OH	1
1472M64P01	BRACKET - RH MOUNT AGB	CF6-80C2	OH	1
1472M65P02	BRACKET - LH MOUNT AGB	CF6-80C2	AR	1
1472M65P02	BRACKET - LH MOUNT AGB	CF6-80C2	REP	1

Part Number	Part Description	Engine Type	Condition	Quantity
1472M66P01	SPACER - RESIL TOP	CF6-80C2	AR	4
1472M66P03	SPACER - RESIL TOP	CF6-80C2	NS	2
1472M66P03	SPACER - RESIL TOP	CF6-80C2	NE	1
1472M68P01	SPACER - RESIL SIDE	CF6-80C2	NS	1
1472M68P01	SPACER - RESIL SIDE	CF6-80C2	AR	8
1472M68P02	SPACER - RESIL SIDE	CF6-80C2	NE	4
1472M68P02	SPACER - RESIL SIDE	CF6-80C2	NE	4
1472M68P02	SPACER - RESIL SIDE	CF6-80C2	NE	2
1472M68P02	SPACER - RESIL SIDE	CF6-80C2	NE	4
1472M70G01	SPACER ASSY - MT AGB	CF6-80C2	AR	1
1472M70G01	SPACER ASSY - MT AGB	CF6-80C2	AR	1
1472M70G01	SPACER ASSY - MT AGB	CF6-80C2	AR	1
1472M70G01	SPACER ASSY - MT AGB	CF6-80C2	AR	1
1472M70G02	SPACER ASSY - MT AGB	CF6-80C2	OH	2
1472M70G02	SPACER ASSY - MT AGB	CF6-80C2	NE	1
1472M70G02	SPACER ASSY - MT AGB	CF6-80C2	NE	2
1472M70G02	SPACER ASSY - MT AGB	CF6-80C2	NE	1
1472M92G01	BRACKET - AFT INNER LINER	CF6-80C2	NS	1
1472M92G01	BRACKET - AFT INNER LINER	CF6-80C2	NS	1
1473M19P01JA	COUPLING - TUBE	CF6-80C2	NE	1
1473M19P01JA	COUPLING - TUBE	CF6-80C2	NE	4
1473M19P01JA	COUPLING - TUBE	CF6-80C2	NE	2
1473M20G01	BRACKET - AIR MANIFOLD HPT	CF6-80C2	NS	3
1473M21G02	BRACKET - AIR MANIFOLD	CF6-80C2	OH	5
1473M21G02	BRACKET - AIR MANIFOLD	CF6-80C2	OH	1
1473M21G02	BRACKET - AIR MANIFOLD	CF6-80C2	SV	1
1473M22G01	BRACKET - AIR MANIFOLD HPT	CF6-80C2	SV	1
1473M23P01	PLATE - LOCKING STG 2	CF6-80C2	NS	2
1473M23P01	PLATE - LOCKING STG 2	CF6-80C2	AR	1
1473M23P01	PLATE - LOCKING STG 2	CF6-80C2	SV	1
1473M23P01	PLATE - LOCKING STG 2	CF6-80C2	NE	1
1473M24G01	DUCT - AIR INLET HP TURB	CF6-80C2	OH	1
1473M24G01	DUCT - AIR INLET HP TURB	CF6-80C2	OH	1
1473M25G05	MANIFOLD - HPT ACC	CF6-80C2	OH	1
1473M25G05	MANIFOLD - HPT ACC	CF6-80C2	OH	1
1473M25G12	MANIFOLD - HPT ACC	CF6-80C2	OH	1
1473M25G18	MANIFOLD - AIR HPT ACC	CF6-80C2	OH	1
1473M25G18	MANIFOLD - AIR HPT ACC	CF6-80C2	OH	1
1473M25G18	MANIFOLD - AIR HPT ACC	CF6-80C2	OH	1
1473M25G19	MANIFOLD - HPT ACC	CF6-80C2	OH	1
1473M25G19	MANIFOLD - HPT ACC	CF6-80C2	OH	1
1473M26G01	MANIFOLD - AIR HPT ACC	CF6-80C2	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
1473M26G03	MANIFOLD - AIR HPT ACC	CF6-80C2	OH	1
1473M38G18	MANIFOLD - HIGH PRESSURE	CF6-80C2	OH	1
1473M44P01	FLANGE - AFT SUPP HPT	CF6-50	NE	1
1473M46P04	RING - SPRING PISTON	CF6-80C2	NE	14
1473M51P04	JOINT - FLEX	CF6-80C2	NE	4
1473M51P04	JOINT - FLEX	CF6-80C2	NE	1
1473M51P04	JOINT - FLEX	CF6-80C2	SV	6
1473M51P04	JOINT - FLEX	CF6-80C2	NE	1
1473M53G01	SEAL - STAT AIR LPT STG 2	CF6-80C2	SV	5
1473M53G01	SEAL - STAT AIR LPT STG 2	CF6-80C2	AR	6
1473M53G01	SEAL - STAT AIR LPT STG 2	CF6-80C2	OH	5
1473M53G01	SEAL - STAT AIR LPT STG 2	CF6-80C2	AR	6
1473M53G01	SEAL - STAT AIR LPT STG 2	CF6-80C2	OH	8
1473M53G01	SEAL - STAT AIR LPT STG 2	CF6-80C2	OH	8
1473M54G01	SEAL - STAT AIR LPT STG 3	CF6-80C2	SV	3
1473M54G01	SEAL - STAT AIR LPT STG 3	CF6-80C2	OH	1
1473M54G01	SEAL - STAT AIR LPT STG 3	CF6-80C2	OH	1
1473M54G01	SEAL - STAT AIR LPT STG 3	CF6-80C2	OH	4
1473M54G01	SEAL - STAT AIR LPT STG 3	CF6-80C2	OH	5
1473M54G01	SEAL - STAT AIR LPT STG 3	CF6-80C2	OH	3
1473M55G01	SEAL - STAT AIR LPT STG 4	CF6-80C2	AR	5
1473M55G01	SEAL - STAT AIR LPT STG 4	CF6-80C2	AR	5
1473M55G01	SEAL - STAT AIR LPT STG 4	CF6-80C2	OH	1
1473M56G01	LPT STATOR INTRSTG SEAL STG 5	CF6-80C2	SV	1
1473M56G01	LPT STATOR INTRSTG SEAL STG 5	CF6-80C2	SV	5
1473M56G01	LPT STATOR INTRSTG SEAL STG 5	CF6-80C2	OH	6
1473M56G01	LPT STATOR INTRSTG SEAL STG 5	CF6-80C2	OH	1
1473M56G01	LPT STATOR INTRSTG SEAL STG 5	CF6-80C2	OH	3
1473M56G01	LPT STATOR INTRSTG SEAL STG 5	CF6-80C2	OH	6
1473M65P02	DISK - HPTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1473M65P02	DISK - HPTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1473M65P02	DISK - HPTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1473M65P02	DISK - HPTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1473M65P02	DISK - HPTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1473M65P02	DISK - HPTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
1473M65P02	DISK - HPTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1473M65P02	DISK - HPTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1473M65P02	DISK - HPTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1473M65P02	DISK - HPTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1473M80P01	SEAL - STRIP STA AIR	CF6-80C2	NE	3
1473M90P04	DISK - LPT STG 3	CF6-50	AR	1
1473M90P04	DISK - LPT STG 3	CF6-50	AR	1
1473M93P02	LPT STATOR INTRSTG SEAL RETAINER STG 5	CF6-80C2	AR	8
1473M93P02	LPT STATOR INTRSTG SEAL RETAINER STG 5	CF6-80C2	AR	15
1473M93P02	LPT STATOR INTRSTG SEAL RETAINER STG 5	CF6-80C2	AR	18
1473M93P02	LPT STATOR INTRSTG SEAL RETAINER STG 5	CF6-80C2	AR	15
1473M93P02	LPT STATOR INTRSTG SEAL RETAINER STG 5	CF6-80C2	AR	18
1473M93P02	LPT STATOR INTRSTG SEAL RETAINER STG 5	CF6-80C2	AR	15
1473M93P02	LPT STATOR INTRSTG SEAL RETAINER STG 5	CF6-80C2	AR	15
1473M93P02	LPT STATOR INTRSTG SEAL RETAINER STG 5	CF6-80C2	AR	8
1473M93P02	LPT STATOR INTRSTG SEAL RETAINER STG 5	CF6-80C2	AR	37
1473M93P02	LPT STATOR INTRSTG SEAL RETAINER STG 5	CF6-80C2	OH	15
1474M24G01	BRACKET ASSY	CF6-80C2	OH	5
1474M24G01	BRACKET ASSY	CF6-80C2	OH	6
1474M25P01	PLUG - CPRSR SEAL STG 5	CF6-80C2	NS	45
1474M31G01	KEY - STG 1	CF6-80C2, CF6-80A	AR	2
1474M31G01	KEY - STG 1	CF6-80C2, CF6-80A	AR	4
1474M31G01	KEY - STG 1	CF6-80C2, CF6-80A	AR	1
1474M31G01	KEY - STG 1	CF6-80C2, CF6-80A	AR	5
1474M31G01	KEY - STG 1	CF6-80C2, CF6-80A	AR	8
1474M31G01	KEY - STG 1	CF6-80C2, CF6-80A	AR	2
1474M31G01	KEY - STG 1	CF6-80C2, CF6-80A	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
1474M31G01	KEY - STG 1	CF6-80C2, CF6-80A	OH	5
1474M31G02	KEY - STG 1	CF6-80C2, CF6-80A	AR	30
1474M31G02	KEY - STG 1	CF6-80C2, CF6-80A	AR	6
1474M31G02	KEY - STG 1	CF6-80C2, CF6-80A	AR	38
1474M31G02	KEY - STG 1	CF6-80C2, CF6-80A	OH	1
1474M31G02	KEY - STG 1	CF6-80C2, CF6-80A	OH	1
1474M31G02	KEY - STG 1	CF6-80C2, CF6-80A	OH	1
1474M31G02	KEY - STG 1	CF6-80C2, CF6-80A	OH	2
1474M31G02	KEY - STG 1	CF6-80C2, CF6-80A	OH	5
1474M31G02	KEY - STG 1	CF6-80C2, CF6-80A	OH	1
1474M31G02	KEY - STG 1	CF6-80C2, CF6-80A	OH	38
1474M31G02	KEY - STG 1	CF6-80C2, CF6-80A	OH	1
1474M31G02	KEY - STG 1	CF6-80C2, CF6-80A	OH	1
1474M31G02	KEY - STG 1	CF6-80C2, CF6-80A	NS	6
1474M52G38	NOZZLE - HPT STG 1	CF6-80C2	OH	1
1474M52G53	NOZZLE - HPT STG 1	CF6-80C2	NS	1
1474M52G53	NOZZLE - HPT STG 1	CF6-80C2	NS	1
1474M52G53	NOZZLE - HPT STG 1	CF6-80C2	NS	1
1474M52G53	NOZZLE - HPT STG 1	CF6-80C2	NS	1
1474M52G53	NOZZLE - HPT STG 1	CF6-80C2	NS	1
1474M75P24	SHIELD - JOINT	CF6-80C2	NE	1
1474M75P32	SHIELD - JOINT	CF6-80C2	NE	1
1474M76G02	SHROUD - LPT STATOR STG 1	CF6-80C2	OH	1
1474M80G05	SHROUD - LPT STATOR STG 5	CF6-80C2	SV	24
1474M80G05	SHROUD - LPT STATOR STG 5	CF6-80C2	AR	24
1474M80G05	SHROUD - LPT STATOR STG 5	CF6-80C2	OH	1
1474M80G05	SHROUD - LPT STATOR STG 5	CF6-80C2	OH	1
1477M47P02	SPACER - SPRING	CF6-80C2	NS	1
1477M47P02	SPACER - SPRING	CF6-80C2	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
1479M59G01	LPT STATOR COOLING MANIFOLD BRACKET	CF6-80C2	OH	1
1479M59G01	LPT STATOR COOLING MANIFOLD BRACKET	CF6-80C2	OH	4
1479M75P09	DISK - LPT STG 3	CF6-50	AR	1
1491M17G02	TUBE - FWD OIL LUBE/SCAV	CF6-80C2	SV	1
1491M20G02	TUBE - ACCY GRBX OIL SCAV	CF6-80C2	OH	1
1491M38G01	BRACKET	CF6-80C2	SV	1
1491M41P001A	BRACKET - TUBE	CF6-80C2	NS	8
1491M42P001B	BRACKET - PYLON DRAIN	CF6-80C2	SV	1
1491M48G01	TUBE - OIL H/X	CF6-80C2	OH	1
1491M53G01	BRACKET	CF6-80C2	NS	1
1491M59P001A	BRACKET - TUBE AIR	CF6-80C2	SV	1
1491M59P001A	BRACKET - TUBE AIR	CF6-80C2	SV	1
1492M31G01	TUBE - FUEL HPT/LPT CC RTN	CF6-80C2	SV	1
1492M31G01	TUBE - FUEL HPT/LPT CC RTN	CF6-80C2	SV	1
1492M31G02	TUBE - FUEL HPT/LPT CC RTN	CF6-80C2	SV	1
1492M56G05	TUBE - AIR HP TURB ACC	CF6-80C2	OH	1
1492M68P001A	BRACKET - TUBE AIR	CF6-80C2	NS	1
1492M68P001A	BRACKET - TUBE AIR	CF6-80C2	NS	7
1492M68P001A	BRACKET - TUBE AIR	CF6-80C2	SV	1
1492M96G01	TUBE - FUEL LPT CC SPLY	CF6-80C2	SV	1
1492M96G01	TUBE - FUEL LPT CC SPLY	CF6-80C2	SV	1
1492M96G02	TUBE - FUEL LPT CC SPLY	CF6-80C2	OH	1
1492M98G01	TUBE - FUEL DRAIN VALVE	CF6-80C2	SV	1
14J63-550	COUPLING ASSEMBLY	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
14J63-600	COUPLING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
14J63-600	COUPLING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
14J63-600	COUPLING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
14J63-600	COUPLING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1507M33P24	RING - EXTERNAL THREADED	CF6-80C2	NS	2
1508M32P08	ELBOW - TUBE	CF6-80C2	NE	1
1508M32P08	ELBOW - TUBE	CF6-80C2	NE	1
1509M45P01	HPC ROTOR BUMBER BRG RETAIN RING	CF6-80C2	NE	1
1509M46P01	HPC ROTOR BUMPER BRG RETAINER	CF6-80C2	NS	1
1509M53P01	SEAL - STG 13	CF6-80C2	NE	8

Part Number	Part Description	Engine Type	Condition	Quantity
1509M53P01	SEAL - STG 13	CF6-80C2	NE	3
1509M53P02	SEAL - STG 13	CF6-80C2	NE	8
1509M53P02	SEAL - STG 13	CF6-80C2	NE	3
1509M53P03	SEAL - STG 13	CF6-80C2	NE	8
1509M53P03	SEAL - STG 13	CF6-80C2	NE	8
1509M53P03	SEAL - STG 13	CF6-80C2	NS	4
1509M82P01	HPC STATOR VANE SLEEVE STG 1-2	CF6-80C2	OH	1
1509M82P01	HPC STATOR VANE SLEEVE STG 1-2	CF6-80C2	NE	12
1509M82P01	HPC STATOR VANE SLEEVE STG 1-2	CF6-80C2	NE	2
1509M82P01	HPC STATOR VANE SLEEVE STG 1-2	CF6-80C2	OH	2
1509M82P01	HPC STATOR VANE SLEEVE STG 1-2	CF6-80C2	NE	3
1509M83P01	HPC STATOR VANE SLEEVE STG 3-4	CF6-80C2	AR	96
1509M83P01	HPC STATOR VANE SLEEVE STG 3-4	CF6-80C2	NS	8
1509M83P01	HPC STATOR VANE SLEEVE STG 3-4	CF6-80C2	NS	9
1509M83P01	HPC STATOR VANE SLEEVE STG 3-4	CF6-80C2	NS	1
1509M93G01	VANE - OUTLET GUIDE TYPE 1	CF6-80C2	OH	1
1509M93G01	VANE - OUTLET GUIDE TYPE 1	CF6-80C2	OH	1
1509M93G01	VANE - OUTLET GUIDE TYPE 1	CF6-80C2	OH	1
1509M93G01	VANE - OUTLET GUIDE TYPE 1	CF6-80C2	OH	1
1509M93G01	VANE - OUTLET GUIDE TYPE 1	CF6-80C2	OH	1
1509M93G01	VANE - OUTLET GUIDE TYPE 1	CF6-80C2	OH	1
1509M93G01	VANE - OUTLET GUIDE TYPE 1	CF6-80C2	OH	1
1509M93G01	VANE - OUTLET GUIDE TYPE 1	CF6-80C2	OH	1
1509M93G01	VANE - OUTLET GUIDE TYPE 1	CF6-80C2	OH	1
1509M93G01	VANE - OUTLET GUIDE TYPE 1	CF6-80C2	OH	1
1509M93G01	VANE - OUTLET GUIDE TYPE 1	CF6-80C2	OH	1
1509M93G01	VANE - OUTLET GUIDE TYPE 1	CF6-80C2	OH	1

[illegible]

Part Number	Part Description	Engine Type	Condition	Quantity
1509M93G03	VANE - OUTLET GUIDE TYPE 3	CF6-80C2	SV	1
1509M93G03	VANE - OUTLET GUIDE TYPE 3	CF6-80C2	SV	1
1509M93G03	VANE - OUTLET GUIDE TYPE 3	CF6-80C2	SV	1
1509M93G03	VANE - OUTLET GUIDE TYPE 3	CF6-80C2	OH	1
1509M93G03	VANE - OUTLET GUIDE TYPE 3	CF6-80C2	OH	1
1509M93G03	VANE - OUTLET GUIDE TYPE 3	CF6-80C2	OH	1
1509M93G03	VANE - OUTLET GUIDE TYPE 3	CF6-80C2	OH	1
1509M93G03	VANE - OUTLET GUIDE TYPE 3	CF6-80C2	OH	1
1509M93G03	VANE - OUTLET GUIDE TYPE 3	CF6-80C2	OH	1
1509M93G03	VANE - OUTLET GUIDE TYPE 3	CF6-80C2	OH	1
1509M93G03	VANE - OUTLET GUIDE TYPE 3	CF6-80C2	OH	1
1509M93G03	VANE - OUTLET GUIDE TYPE 3	CF6-80C2	OH	1
1509M93G09	VANE - OUTLET GUIDE TYPE 3	CF6-80C2	OH	1
1509M93G09	VANE - OUTLET GUIDE TYPE 3	CF6-80C2	OH	1
1509M93G09	VANE - OUTLET GUIDE TYPE 3	CF6-80C2	OH	1
1509M93G09	VANE - OUTLET GUIDE TYPE 3	CF6-80C2	OH	1
1509M93G11	VANE - OUTLET GUIDE TYPE 2	CF6-80C2	OH	1
1516M32G01	BRACKET - TUBE	CF6-80C2	NE	1
1516M52G01	BRACKET - ECU	CF6-80C2	NE	1
1516M52G02	BRACKET - ECU	CF6-80C2	NE	1
1516M58G01	BRACKET - TUBE INTEGRATED	CF6-80C2	AR	1
1516M58G01	BRACKET - TUBE INTEGRATED	CF6-80C2	NS	1
1516M64P001A	BRACKET - TUBE FUEL	CF6-80C2	NS	1
1516M67P001A	BRACKET	CF6-80C2	NS	1
1516M67P001A	BRACKET	CF6-80C2	NS	5
1517M11G01	TUBE - FUEL DRAIN VALVE L/S	CF6-80C2	SV	1
1517M13G02	TUBE - FUEL MANF DRAIN	CF6-80C2	OH	1
1517M20P001A	BRACKET - TUBE IDG	CF6-80C2	NE	1
1517M20P001A	BRACKET - TUBE IDG	CF6-80C2	NE	1
1517M22G03	SHIELD - SPRAY	CF6-80C2	SV	1
1517M22G03	SHIELD - SPRAY	CF6-80C2	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
1517M55P01	PLATE - BACKING	CF6-80C2	NE	4
1517M55P01	PLATE - BACKING	CF6-80C2	NE	1
1517M55P01	PLATE - BACKING	CF6-80C2	NE	4
1517M55P01	PLATE - BACKING	CF6-80C2	NE	1
1517M65G04	MANIFOLD - DRAIN MAST	CF6-80C2	SV	1
1517M70G01	TUBE - FUEL LOWER T2	CF6-80C2	NE	1
1517M80P001A	BRACKET - ELECTRIC CABLE	CF6-80C2	SV	1
1517M84P001A	BRACKET	CF6-80C2	SV	1
1517M91P001A	BRACKET - TUBE IDG SIGNAL	CF6-80C2	NS	1
1517M91P001A	BRACKET - TUBE IDG SIGNAL	CF6-80C2	SV	1
1518M37P10	BEARING - PLAIN	CF6-80C2	NE	1
1518M37P10	BEARING - PLAIN	CF6-80C2	NS	1
1518M91G02	SHIELD - CONTAINMENT FAN	CF6-50	SV	1
1519M59P02	BRACKET - CONTAINMENT	CF6-50	NE	4
1519M61G01	RETAINER - NUT	CF6-80C2	NE	1
1519M78G01	FAIRING - STRUT FAN DUCT	CF6-80C2	SV	1
1520M10G04	EXTENSION - FLOWPATH	CF6-80C2	AR	1
1520M11G01	EXTENSION - FLOWPATH	CF6-80C2	AR	1
1520M12G42	EXTENSION - FLOWPATH	CF6-80C2	NE	1
1521M75P02	FLANGE - AFT CASE	CF6-50	NE	1
1531M20G01	RETAINER - NUT	CF6-80C2	SV	1
1531M23G01	RETAINER - NUT	CF6-80C2	SV	1
1531M23G01	RETAINER - NUT	CF6-80C2	OH	1
1531M23G01	RETAINER - NUT	CF6-80C2	SV	1
1531M23G01	RETAINER - NUT	CF6-80C2	OH	1
1531M24G01	RETAINER - NUT	CF6-80C2	AR	1
1531M24G01	RETAINER - NUT	CF6-80C2	AR	1
1531M24G01	RETAINER - NUT	CF6-80C2	OH	1
1531M24G01	RETAINER - NUT	CF6-80C2	SV	1
1531M24G01	RETAINER - NUT	CF6-80C2	AR	1
1531M24G01	RETAINER - NUT	CF6-80C2	OH	1
1531M25G01	RETAINER - BOLT YOKE	CF6-80C2	AR	1
1531M25G01	RETAINER - BOLT YOKE	CF6-80C2	AR	1
1531M25G01	RETAINER - BOLT YOKE	CF6-80C2	SV	1
1531M25G01	RETAINER - BOLT YOKE	CF6-80C2	AR	1
1531M25G01	RETAINER - BOLT YOKE	CF6-80C2	AR	1
1531M26G01	RETAINER - BOLT YOKE LINK	CF6-80C2	SV	1
1531M26G01	RETAINER - BOLT YOKE LINK	CF6-80C2	OH	1
1531M26G01	RETAINER - BOLT YOKE LINK	CF6-80C2	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
1531M26G01	RETAINER - BOLT YOKE LINK	CF6-80C2	OH	1
1531M49P05	BEARING - PLAIN	CF6-80C2	NE	2
1531M49P05	BEARING - PLAIN	CF6-80C2	NE	2
1531M63P01	PLUG - CPRSR SEAL STG 3	CF6-80C2	NS	39
1531M64P01	PLUG - CPRSR SEAL STG 4	CF6-80C2	NS	42
1531M86P06	RETAINER - STG 1	CF6-80C2	AR	1
1531M87G02	VALVE - CHECK 7TH STAGE	CF6-80A	OH	1
1531M87G02	VALVE - CHECK 7TH STAGE	CF6-80A	REP	1
1531M87G03	VALVE - CHECK 7TH STAGE	CF6-80A	OH	1
1531M87G03	VALVE - CHECK 7TH STAGE	CF6-80A	OH	1
1536M21P03	BLADE - LPTR STG 1	CF6-80C2	OH	30
1536M21P03	BLADE - LPTR STG 1	CF6-80C2	OH	30
1536M21P03	BLADE - LPTR STG 1	CF6-80C2	OH	23
1536M22P02	BLADE - LPTR STG 2	CF6-80C2	OH	15
1536M22P02	BLADE - LPTR STG 2	CF6-80C2	OH	30
1536M22P03	BLADE - LPTR STG 2	CF6-80C2	OH	3
1536M22P03	BLADE - LPTR STG 2	CF6-80C2	OH	11
1536M22P03	BLADE - LPTR STG 2	CF6-80C2	OH	30
1536M22P03	BLADE - LPTR STG 2	CF6-80C2	OH	30
1536M22P03	BLADE - LPTR STG 2	CF6-80C2	OH	12
1536M22P03	BLADE - LPTR STG 2	CF6-80C2	OH	1
1536M22P03	BLADE - LPTR STG 2	CF6-80C2	OH	15
1536M22P03	BLADE - LPTR STG 2	CF6-80C2	OH	30
1536M22P03	BLADE - LPTR STG 2	CF6-80C2	OH	30
1536M22P03	BLADE - LPTR STG 2	CF6-80C2	OH	15
1536M22P03	BLADE - LPTR STG 2	CF6-80C2	OH	30
1536M22P03	BLADE - LPTR STG 2	CF6-80C2	OH	9
1536M41G01	VANE - OUTLET GUIDE TYPE 1	CF6-80C2	OH	1
1536M42G01	VANE - OUTLET GUIDE TYPE 2	CF6-80C2	OH	1
1536M43G01	VANE - OUTLET GUIDE TYPE 3	CF6-80C2	OH	1
1536M43G01	VANE - OUTLET GUIDE TYPE 3	CF6-80C2	OH	1
1536M43G01	VANE - OUTLET GUIDE TYPE 3	CF6-80C2	OH	1
1536M67P02	SPACER - COOLING MANIFOLD	CF6-80C2	NE	2
1536M67P02	SPACER - COOLING MANIFOLD	CF6-80C2	SV	22
1536M67P02	SPACER - COOLING MANIFOLD	CF6-80C2	NE	3

Part Number	Part Description	Engine Type	Condition	Quantity
1536M67P02	SPACER - COOLING MANIFOLD	CF6-80C2	NE	10
1536M67P02	SPACER - COOLING MANIFOLD	CF6-80C2	NE	15
1536M80P01	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P01	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P01	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P01	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P01	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P01	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P01	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P01	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P01	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P01	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P01	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P01	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P01	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P01	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1536M80P01	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P01	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P01	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P01	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	REP	1
1536M80P01	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P01	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P01	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P01	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P01	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
1536M80P01	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P01	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P01	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P01	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P02	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P02	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P02	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P02	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P02	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1536M80P02	SPACER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1537M24P001A	BRACKET - NUT	CF6-80C2	SV	1
1537M24P001A	BRACKET - NUT	CF6-80C2	SV	2
1537M24P001A	BRACKET - NUT	CF6-80C2	SV	2
1537M26P001A	RETAINER - BOLT	CF6-80C2	NE	1
1537M26P001A	RETAINER - BOLT	CF6-80C2	NE	1
1537M26P001A	RETAINER - BOLT	CF6-80C2	NE	1
1537M26P001A	RETAINER - BOLT	CF6-80C2	SV	1
1537M26P001A	RETAINER - BOLT	CF6-80C2	SV	2
1537M27P001A	BRACKET - NUT	CF6-80C2	SV	1
1537M27P001A	BRACKET - NUT	CF6-80C2	SV	1
1537M27P001A	BRACKET - NUT	CF6-80C2	OH	2
1537M27P001A	BRACKET - NUT	CF6-80C2	SV	2
1537M27P001A	BRACKET - NUT	CF6-80C2	OH	2
1537M27P001A	BRACKET - NUT	CF6-80C2	SV	1
1537M27P001A	BRACKET - NUT	CF6-80C2	SV	1
1537M28P001A	RETAINER - BOLT	CF6-80C2	SV	2
1537M28P001A	RETAINER - BOLT	CF6-80C2	SV	2
1537M28P001A	RETAINER - BOLT	CF6-80C2	SV	2
1537M28P001A	RETAINER - BOLT	CF6-80C2	SV	2
1537M28P001A	RETAINER - BOLT	CF6-80C2	SV	2
1537M29P001A	PLATE - LOCK	CF6-80C2	SV	2
1537M30P001A	BRACKET - NUT	CF6-80C2	SV	2
1537M30P001A	BRACKET - NUT	CF6-80C2	SV	2
1537M30P001A	BRACKET - NUT	CF6-80C2	SV	2
1537M30P001A	BRACKET - NUT	CF6-80C2	SV	2
1537M30P001A	BRACKET - NUT	CF6-80C2	SV	2
1537M78P02	SLEEVE - WEAR (SPD)	CF6-80A	NE	1
1537M87G01	BRACKET	CF6-80C2	SV	1
1537M87G03	BRACKET	CF6-80C2	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
1538M29P05	RING - PISTON	CF6-80C2	NS	3
1538M29P05	RING - PISTON	CF6-80C2	NE	1
1538M29P06	RING - PISTON	CF6-80C2	NE	1
1538M29P06	RING - PISTON	CF6-80C2	NS	9
1538M29P06	RING - PISTON	CF6-80C2	NS	24
1538M29P06	RING - PISTON	CF6-80C2	NS	23
1538M29P06	RING - PISTON	CF6-80C2	NE	2
1538M29P06	RING - PISTON	CF6-80C2	NS	3
1538M29P06	RING - PISTON	CF6-80C2	NS	50
1538M29P06	RING - PISTON	CF6-80C2	NS	32
1538M29P06	RING - PISTON	CF6-80C2	NS	52
1538M29P08	RING - PISTON	CF6-80C2	NS	8
1538M29P08	RING - PISTON	CF6-80C2	NS	12
1538M29P09	RING - PISTON	CF6-80C2	NE	1
1538M29P09	RING - PISTON	CF6-80C2	NS	1
1538M30P07	LINK - MT	CF6-50 (Boeing)	OH	1
1538M35G01	LINER - OUTER AFT SEG	CF6-80A	OH	1
1538M35G03	LINER - OUTER MID SEG	CF6-80A	AR	1
1538M35G03	LINER - OUTER MID SEG	CF6-80A	AR	1
1538M35G03	LINER - OUTER MID SEG	CF6-80A	AR	1
1538M35G03	LINER - OUTER MID SEG	CF6-80A	AR	1
1538M35G03	LINER - OUTER MID SEG	CF6-80A	AR	1
1538M35G03	LINER - OUTER MID SEG	CF6-80A	AR	1
1538M44G01	BRACKET - AFT INNER LINER	CF6-80C2	NE	1
1538M44G01	BRACKET - AFT INNER LINER	CF6-80C2	SV	1
1538M44G02	BRACKET - AFT INNER LINER	CF6-80C2	SV	1
1538M45G01	BRACKET - AFT INNER LINER	CF6-80C2	SV	1
1538M45G02	BRACKET - AFT INNER LINER	CF6-80C2	SV	1
1538M46G01	BRACKET - AFT INNER LINER	CF6-80C2	NE	1
1538M46G01	BRACKET - AFT INNER LINER	CF6-80C2	SV	2
1538M46G02	BRACKET - AFT INNER LINER	CF6-80C2	NS	1
1538M46G02	BRACKET - AFT INNER LINER	CF6-80C2	SV	2
1538M47G01	BRACKET - AFT INNER LINER	CF6-80C2	SV	1
1538M47G02	BRACKET - AFT INNER LINER	CF6-80C2	SV	1
1538M48G01	BRACKET - AFT INNER LINER	CF6-80C2	SV	1
1538M48G02	BRACKET - AFT INNER LINER	CF6-80C2	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
1538M49G01	BRACKET - AFT INNER LINER	CF6-80C2	SV	4
1538M49G02	BRACKET - AFT INNER LINER	CF6-80C2	NE	1
1538M49G02	BRACKET - AFT INNER LINER	CF6-80C2	NE	1
1538M49G02	BRACKET - AFT INNER LINER	CF6-80C2	SV	4
1538M50G01	BRACKET - AFT INNER LINER	CF6-80C2	SV	1
1538M50G02	BRACKET - AFT INNER LINER	CF6-80C2	SV	1
1538M51G01	BRACKET - AFT INNER LINER	CF6-80C2	SV	1
1538M51G02	BRACKET - AFT INNER LINER	CF6-80C2	SV	1
1538M55G02	CASE ASSY - CPRSR STTR REAR	CF6-50 (LMCO)	AR	1
1538M55G02	CASE ASSY - CPRSR STTR REAR	CF6-50 (LMCO)	AR	1
1538M55G03	CASE ASSY - CPRSR STTR REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1538M55G03	CASE ASSY - CPRSR STTR REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1538M55G04	CASE ASSY - CPRSR STTR REAR	CF6-50	OH	1
1538M55G08	CASE ASSY - CPRSR STTR REAR	CF6-50	AR	1
1538M67P01	RING - WIRE (SPD)	CF6-80A	NE	1
1538M67P01	RING - WIRE (SPD)	CF6-80A	NE	1
1538M70G03	MANIFOLD - INLET	CF6-80C2	SV	1
1538M78G01	PAD - AIR SUPPLY	CF6-80C2	AR	1
1538M78G03	PAD - AIR SUPPLY	CF6-80C2	AR	1
1538M78G04	PAD - AIR SUPPLY	CF6-80C2	AR	1
1538M78G05	PAD - AIR SUPPLY	CF6-80C2	AR	1
1538M78G06	PAD - AIR SUPPLY	CF6-80C2	AR	1
1538M78G07	PAD - AIR SUPPLY	CF6-80C2	AR	1
1538M83P01	KEY - LINER (SPD)	CF6-80C2, CF6-80A	NE	1
1539M26G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	REP	1
1539M26G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
1539M27G01	SEGMENT ASSY - FAN CS LINER	CF6-50 (Boeing)	AR	1
1539M31G01	LINER ASSY - FAN FR	CF6-50 (Boeing)	AR	1
1539M31G01	LINER ASSY - FAN FR	CF6-50 (Boeing)	AR	1
1539M31G01	LINER ASSY - FAN FR	CF6-50 (Boeing)	OH	1
1539M31G02	LINER ASSY - FAN FR	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
1539M31G04	LINER ASSY - FAN FR	CF6-50	AR	1
1539M31G04	LINER ASSY - FAN FR	CF6-50	AR	1
1539M32G01	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
1539M32G01	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1539M33G02	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1539M66P01	BEARING - RLR NO. 4R	CF6-80A	AR	1
1539M66P02	BEARING - RLR NO. 4R	CF6-80A	AR	1
1539M72G06	SEAL - STA BRG NO. 3	CF6-80A	AR	1
1539M72G06	SEAL - STA BRG NO. 3	CF6-80A	OH	1
1539M73G01	#3 BEARING STATIONARY OIL SEAL	CF6-80C2	OH	1
1539M75P01	BRACKET	CF6-80C2	SV	1
1539M75P01	BRACKET	CF6-80C2	SV	1
1539M78P03	FAN THRUST REVERSER CHANNEL	CF6-80C2	REP	1
1539M78P03	FAN THRUST REVERSER CHANNEL	CF6-80C2	SV	1
1539M78P03	FAN THRUST REVERSER CHANNEL	CF6-80C2	SV	1
1539M78P04	FAN THRUST REVERSER CHANNEL	CF6-80C2	SV	1
1539M78P04	FAN THRUST REVERSER CHANNEL	CF6-80C2	SV	1
1539M78P04	FAN THRUST REVERSER CHANNEL	CF6-80C2	SV	1
1539M96P01	HPT NOZZLE STG 1 FWD SEAL	CF6-80C2	NE	2
1539M96P01	HPT NOZZLE STG 1 FWD SEAL	CF6-80C2	NS	46
1539M96P01	HPT NOZZLE STG 1 FWD SEAL	CF6-80C2	NS	10
1539M96P01	HPT NOZZLE STG 1 FWD SEAL	CF6-80C2	NE	100
1539M96P01	HPT NOZZLE STG 1 FWD SEAL	CF6-80C2	NS	2
1539M96P01	HPT NOZZLE STG 1 FWD SEAL	CF6-80C2	NE	2
1539M96P01	HPT NOZZLE STG 1 FWD SEAL	CF6-80C2	NE	2
1539M97G07	MANIFOLD - HIGH PRESSURE	CF6-80C2	OH	1
15434-1	SOLENOID - IDLE RESET	CF6-50 (LMCO)	NE	1
154DA	SENSOR - INLET	CF6-80A	AR	1
154DA	SENSOR - INLET	CF6-80A	AR	1
154DA	SENSOR - INLET	CF6-80A	AR	1
154DA	SENSOR - INLET	CF6-80A	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
154DA	SENSOR - INLET	CF6-80A	SV	1
154DA	SENSOR - INLET	CF6-80A	AR	1
1554M42G01	BRACKET	CF6-50 (LMCO)	SV	1
1554M43G01	BRACKET	CF6-50 (LMCO)	SV	1
1554M56G01	BRACKET	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1554M68G01	TUBE - AIR	CF6-80A	AR	1
1554M68G01	TUBE - AIR	CF6-80A	AR	1
1555M14G04	MANIFOLD ASSY - STG 14 LH	CF6-50	OH	1
1555M21G02	TUBE ASSY HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1555M21G02	TUBE ASSY HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1555M23G01	TUBE ASSY - STG 14 CDP AIR	CF6-50	SV	1
1555M23G02	TUBE ASSY - STG 14 CDP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1555M23G02	TUBE ASSY - STG 14 CDP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1555M23G02	TUBE ASSY - STG 14 CDP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1555M23G02	TUBE ASSY - STG 14 CDP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1555M27P02	ROD END LH	CF6-50	NE	1
1555M48P001A	BRACKET	CF6-80A	NS	1
1555M49P001A	BRACKET	CF6-80A	NS	1
1555M49P001A	BRACKET	CF6-80A	SV	1
1555M49P001A	BRACKET	CF6-80A	SV	1
1555M50G01	BRACKET	CF6-80A	NE	1
1555M50G01	BRACKET	CF6-80A	SV	1
1555M86P01	FLANGE - TUBE	CF6-50	NS	1
1555M99G01	BRACKET - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
1561M25G08	DOME - COMB CHAMBER	CF6-80A	AR	1
1577M31G02	TUBE - T2 SENSOR LOWER P7	CF6-80C2	SV	1
1577M53G01	PLATE - BASE	CF6-80C2	OH	2
1577M53G01	PLATE - BASE	CF6-80C2	OH	1
1577M53G01	PLATE - BASE	CF6-80C2	NE	4
1577M53G01	PLATE - BASE	CF6-80C2	NS	1
1577M53G01	PLATE - BASE	CF6-80C2	NS	1
1577M53G01	PLATE - BASE	CF6-80C2	NE	1
1577M53G01	PLATE - BASE	CF6-80C2	OH	1
1577M58P01	SEAL - FIREWALL	CF6-80C2	NS	1
1577M59G01	RETAINER - SEAL	CF6-80C2	NS	3
1577M63P001A	BRACKET - LOWER FAN	CF6-80C2	NE	1
1577M69G01	TUBE - AIR STG 11 VALVE CNTRL	CF6-80C2	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
1577M71G01	TUBE - AIR STG 11 VALVE CNTRL	CF6-80C2	OH	1
1577M81G02	TUBE - FUEL LPT VALVE SPLY	CF6-80C2	SV	1
1577M83G02	TUBE - FUEL LPT VALVE RTN	CF6-80C2	SV	1
1578M19P001A	BRACKET - TUBE	CF6-80C2	NE	1
1578M21P001B	BRACKET - SPRT FIRE DET	CF6-80C2	SV	1
1578M29P001B	BRACKET - DR TUBE	CF6-80C2	NS	1
1578M30G08	LINK - SUPPORT	CF6-80C2	AR	1
1578M30G08	LINK - SUPPORT	CF6-80C2	OH	1
1578M30G08	LINK - SUPPORT	CF6-80C2	OH	1
1578M30G12	LINK - SUPPORT	CF6-80C2	SV	1
1578M30G12	LINK - SUPPORT	CF6-80C2	SV	1
1578M30G14	LINK - SUPPORT	CF6-80C2	AR	1
1578M30G18	LINK - SUPPORT	CF6-80C2	SV	1
1578M30G18	LINK - SUPPORT	CF6-80C2	SV	1
1578M30G18	LINK - SUPPORT	CF6-80C2	SV	1
1578M30G21	LINK - SUPPORT	CF6-80C2	OH	1
1578M30G22	LINK - SUPPORT	CF6-80C2	SV	1
1578M30G28	LINK - SUPPORT	CF6-80C2	AR	1
1578M30G49	LINK - SUPPORT	CF6-80C2	SV	1
1578M64P001A	BRACKET - FIRE DETECTOR	CF6-80C2	SV	1
1578M64P001B	BRACKET - FIRE DETECTOR	CF6-80C2	SV	1
1578M83G03	BRACKET - TUBE LPT CLG	CF6-80C2	SV	1
1578M85G01	BRACKET - MANIFOLD	CF6-80C2	NE	1
1578M87G01	BRACKET - TUBE AIR HPT	CF6-80C2	NE	1
1578M90G01	BRACKET	CF6-80C2	SV	1
1578M92G01	BRACKET	CF6-80C2	OH	1
1578M92G01	BRACKET	CF6-80C2	OH	1
1578M98G05	BRACKET - FIRE DETECTOR	CF6-80C2	AR	1
1578M98G05	BRACKET - FIRE DETECTOR	CF6-80C2	NE	1
1578M99P001D	BRACKET - FIRE PROTECTION	CF6-80C2	OH	1
1581M35G01	BRACKET - ECU	CF6-80C2	SV	1
1581M35G02	BRACKET - ECU	CF6-80C2	SV	1
158210-14	HEAT - EXCHANGER	CF6-50 (LMCO)	AR	1
158210-14	HEAT - EXCHANGER	CF6-50 (LMCO)	AR	1
158210-16	HEAT - EXCHANGER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
158210-16	HEAT - EXCHANGER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
158210-16	HEAT - EXCHANGER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
158210-16	HEAT - EXCHANGER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
158210-16	HEAT - EXCHANGER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
158210-16	HEAT - EXCHANGER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
158210-16	HEAT - EXCHANGER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
158210-16	HEAT - EXCHANGER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
158210-16	HEAT - EXCHANGER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
158210-8	HEAT - EXCHANGER	CF6-50	AR	1
1582M10G02	TUBE - B OIL SUMP SCAV	CF6-80C2	AR	1
1582M14G03	TUBE - C OIL SUMP SCAV	CF6-80C2	OH	1
1582M69G02	TUBE - MAST MANF TO MDL OIL	CF6-80C2	NE	1
1582M96P001B	BRACKET - CHANNEL R/S	CF6-80C2	NS	1
1583M21P01	RING - KEYED	CF6-80C2	AR	1
1583M21P01	RING - KEYED	CF6-80C2	AR	1
1583M21P01	RING - KEYED	CF6-80C2	AR	1
1583M74P03	PLATE - RETAINER	CF6-80C2	NS	2
1583M74P06	PLATE - RETAINER	CF6-80C2	NE	1
1583M74P06	PLATE - RETAINER	CF6-80C2	NE	1
1583M74P06	PLATE - RETAINER	CF6-80C2	NE	2
1583M74P06	PLATE - RETAINER	CF6-80C2	NE	2
1584M41P01	RING - RETAINING	CF6-80C2	NS	1
1584M42P01	RING - RETAINING	CF6-80C2	NE	8
1584M42P01	RING - RETAINING	CF6-80C2	NE	1
1584M48P01	SPACER - RESIL BOT	CF6-80C2	AR	4
1584M48P02	SPACER - RESIL BOT	CF6-80C2	NE	2
1584M48P02	SPACER - RESIL BOT	CF6-80C2	NE	1
1584M48P02	SPACER - RESIL BOT	CF6-80C2	NE	1
1584M48P02	SPACER - RESIL BOT	CF6-80C2	NE	2
159D6293P1	MOUNT - RESILIENT	CF6-80C2	AR	4
159D6293P1	MOUNT - RESILIENT	CF6-80C2	NS	1
1606M19G01	BRACKET - IDG AIR/OIL	CF6-80C2	NS	1
1606M32P01	BRACKET - LINK	CF6-80C2	SV	1
1606M32P02	BRACKET - LINK	CF6-80C2	NE	1
1606M32P02	BRACKET - LINK	CF6-80C2	NS	1
1606M32P02	BRACKET - LINK	CF6-80C2	NE	1
1606M32P02	BRACKET - LINK	CF6-80C2	SV	1
1606M39G02	TUBE - FUEL (MEC-PUMP)	CF6-80C2	SV	1
1606M59G01	TUBE - ACCY DRAIN FUEL	CF6-80C2	AR	1
1619M57G03	PLATE - BASE	CF6-80C2	OH	1
1619M57G03	PLATE - BASE	CF6-80C2	SV	4
1619M57G03	PLATE - BASE	CF6-80C2	OH	2
1619M57G04	PLATE - BASE	CF6-80C2	OH	7

Part Number	Part Description	Engine Type	Condition	Quantity
1619M57G04	PLATE - BASE	CF6-80C2	OH	1
1619M57G04	PLATE - BASE	CF6-80C2	OH	1
1622M23P01	SLEEVE - STG 5	CF6-80C2	NE	9
1622M23P01	SLEEVE - STG 5	CF6-80C2	NE	2
1622M24P01	PLUG - MACH THD	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
1622M24P01	PLUG - MACH THD	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1622M24P01	PLUG - MACH THD	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
1622M24P01	PLUG - MACH THD	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
1622M24P01	PLUG - MACH THD	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
1622M24P01	PLUG - MACH THD	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
1622M24P01	PLUG - MACH THD	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	7
1622M24P01	PLUG - MACH THD	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	7
1622M24P01	PLUG - MACH THD	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	7
1622M24P01	PLUG - MACH THD	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	12
1639M24P04	HPT NOZZLE STG 2 SHROUD	CF6-80C2	OH	1
1639M24P04	HPT NOZZLE STG 2 SHROUD	CF6-80C2	OH	1
1639M24P04	HPT NOZZLE STG 2 SHROUD	CF6-80C2	OH	1
1639M24P04	HPT NOZZLE STG 2 SHROUD	CF6-80C2	OH	1
1639M24P04	HPT NOZZLE STG 2 SHROUD	CF6-80C2	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
1639M24P04	HPT NOZZLE STG 2 SHROUD	CF6-80C2	OH	1
1639M24P04	HPT NOZZLE STG 2 SHROUD	CF6-80C2	OH	1
1639M24P04	HPT NOZZLE STG 2 SHROUD	CF6-80C2	OH	1
1639M24P04	HPT NOZZLE STG 2 SHROUD	CF6-80C2	OH	1
1639M24P04	HPT NOZZLE STG 2 SHROUD	CF6-80C2	OH	1
1639M24P04	HPT NOZZLE STG 2 SHROUD	CF6-80C2	OH	1
1639M24P04	HPT NOZZLE STG 2 SHROUD	CF6-80C2	OH	1
1639M24P06	HPT NOZZLE STG 2 SHROUD	CF6-80C2	OH	1
1639M24P06	HPT NOZZLE STG 2 SHROUD	CF6-80C2	OH	1
1639M24P06	HPT NOZZLE STG 2 SHROUD	CF6-80C2	OH	1
1639M24P06	HPT NOZZLE STG 2 SHROUD	CF6-80C2	OH	1
1639M24P06	HPT NOZZLE STG 2 SHROUD	CF6-80C2	OH	1
1639M24P06	HPT NOZZLE STG 2 SHROUD	CF6-80C2	OH	1
1639M24P06	HPT NOZZLE STG 2 SHROUD	CF6-80C2	OH	1
1639M24P06	HPT NOZZLE STG 2 SHROUD	CF6-80C2	OH	1
1639M24P06	HPT NOZZLE STG 2 SHROUD	CF6-80C2	OH	1
1639M24P06	HPT NOZZLE STG 2 SHROUD	CF6-80C2	OH	1
1639M24P06	HPT NOZZLE STG 2 SHROUD	CF6-80C2	OH	1
1639M24P06	HPT NOZZLE STG 2 SHROUD	CF6-80C2	OH	1
1639M36G01	SEAL - STAT AIR LPT STG 2	CF6-80C2	OH	4
1639M36G02	SEAL - STAT AIR LPT STG 2	CF6-80C2	AR	8
1639M36G02	SEAL - STAT AIR LPT STG 2	CF6-80C2	OH	1
1639M37G01	SEAL - STAT AIR LPT STG 3	CF6-80C2	OH	1
1639M38G02	SEAL - STAT AIR LPT STG 4	CF6-80C2	OH	4
1639M38G02	SEAL - STAT AIR LPT STG 4	CF6-80C2	OH	1
1639M38G02	SEAL - STAT AIR LPT STG 4	CF6-80C2	OH	1
1639M39G01	SEAL - STAT AIR LPT STG 5	CF6-80C2	OH	1
1639M57G03	CASE ASSY - LPT STTR	CF6-80A	OH	1
1639M70P17	HPT ROTOR BLADE STG 1	CF6-80C2	OH	1
1642M13G05	BRACKET - ELECTRIC	CF6-80C2	SV	1
1642M15P001A	BRACKET - GEARBOX	CF6-80C2	NE	4
1642M22P07	ISOLATOR - VIBRATION	CF6-80C2	NE	2

Part Number	Part Description	Engine Type	Condition	Quantity
1642M22P07	ISOLATOR - VIBRATION	CF6-80C2	NE	3
1642M22P07	ISOLATOR - VIBRATION	CF6-80C2	NE	1
1642M22P07	ISOLATOR - VIBRATION	CF6-80C2	NS	2
1642M22P07	ISOLATOR - VIBRATION	CF6-80C2	NS	2
1642M22P07	ISOLATOR - VIBRATION	CF6-80C2	NE	1
1642M23P01	SPACER - TUBE VIBRATION	CF6-80C2	NS	4
1642M23P01	SPACER - TUBE VIBRATION	CF6-80C2	NS	1
1642M23P01	SPACER - TUBE VIBRATION	CF6-80C2	NS	1
1642M70G01	BRACKET - TUBE AIR	CF6-80C2	NE	1
1642M70G01	BRACKET - TUBE AIR	CF6-80C2	SV	1
1642M74G01	TUBE - OIL GEARBOX SUPPLY	CF6-80C2	NE	1
1642M76G01	VALVE - CHECK STG 11	CF6-80C2	AR	4
1642M76G01	VALVE - CHECK STG 11	CF6-80C2	OH	1
1642M76G01	VALVE - CHECK STG 11	CF6-80C2	AR	2
1642M76G01	VALVE - CHECK STG 11	CF6-80C2	AR	2
1642M78G01	VALVE - CHECK STG 11	CF6-80C2	AR	2
1642M78G01	VALVE - CHECK STG 11	CF6-80C2	OH	1
1642M98G01	VALVE - TEE CHECK STG 11	CF6-80C2	SV	1
1642M98G01	VALVE - TEE CHECK STG 11	CF6-80C2	AR	1
1642M98G01	VALVE - TEE CHECK STG 11	CF6-80C2	OH	1
1642M98G01	VALVE - TEE CHECK STG 11	CF6-80C2	OH	1
1643M27G01	MANIFOLD - CORE COWL CLG	CF6-80A	AR	1
1643M47G02	MANIFOLD - HPT COOLING AIR	CF6-80C2	AR	2
1643M47G02	MANIFOLD - HPT COOLING AIR	CF6-80C2	OH	1
1643M49G02	MANIFOLD - HPT COOLING AIR	CF6-80C2	AR	2
1643M52P001A	BRACKET - TUBE SUPPORT	CF6-80C2	OH	1
1643M66P001C	BRACKET - LP RECOUP	CF6-80C2	NS	1
1643M66P001C	BRACKET - LP RECOUP	CF6-80C2	SV	1
1643M66P001C	BRACKET - LP RECOUP	CF6-80C2	NS	1
1643M67P001C	BRACKET - LP RECOUP	CF6-80C2	AR	1
1643M70P01	SPACER - SHOULDER	CF6-80C2	NS	6
1643M76G01	BRACKET - CABLE ELEC	CF6-80C2	AR	1
1643M77G01	BRACKET - SPRT FIRE DET	CF6-80C2	NS	2
1643M77G01	BRACKET - SPRT FIRE DET	CF6-80C2	SV	1
1643M78G01	BRACKET - SPRT FIRE DET	CF6-80C2	AR	1
1643M78G01	BRACKET - SPRT FIRE DET	CF6-80C2	NS	1
1643M78G01	BRACKET - SPRT FIRE DET	CF6-80C2	NS	2
1643M81P001A	BRACKET - IGNITION CABLE	CF6-50 (LMCO)	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
1646M45P11	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1
1646M45P11	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1
1646M45P11	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1
1646M45P11	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1
1646M45P11	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1
1646M45P11	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1
1646M45P11	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1
1646M45P11	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1
1646M45P11	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1
1646M45P11	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1
1646M45P11	SHROUD - HPT STATOR STG 1	CF6-80A	OH	1
1646M97P02	SEAL - AIR HPT AFT	CF6-80C2	AR	1
1647M20P03	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1647M20P03	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1647M20P03	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1647M20P03	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1647M20P03	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1647M20P03	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1647M20P03	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1647M20P03	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1647M20P03	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1647M20P03	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1647M20P03	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1647M20P03	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1647M20P03	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1647M20P03	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
1647M20P03	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1647M20P03	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1647M20P03	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1647M20P03	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1647M20P03	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1647M20P03	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1647M20P03	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1647M20P03	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1647M20P03	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1647M20P03	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1647M34P01	SUPPORT	CF6-80C2	AR	2
1647M37P01	SLEEVE - THREADED	CF6-80C2	OH	1
1647M37P01	SLEEVE - THREADED	CF6-80C2	OH	1
1647M39G01	HANGER - SUPPORT HPT STTR	CF6-80C2	OH	1
1647M50G02	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
1647M63P08	SEAL - HPT NOZ	CF6-80C2	NE	4
1647M63P08	SEAL - HPT NOZ	CF6-80C2	NE	12
1647M63P08	SEAL - HPT NOZ	CF6-80C2	NE	1
1647M63P08	SEAL - HPT NOZ	CF6-80C2	NE	1
1647M63P08	SEAL - HPT NOZ	CF6-80C2	NE	100
1647M63P09	SEAL - NOZZLE OUTER	CF6-80C2	NE	12
1647M63P09	SEAL - NOZZLE OUTER	CF6-80C2	NE	7
1647M63P09	SEAL - NOZZLE OUTER	CF6-80C2	NE	3
1647M63P09	SEAL - NOZZLE OUTER	CF6-80C2	NS	2
1647M63P09	SEAL - NOZZLE OUTER	CF6-80C2	NS	23
1647M63P09	SEAL - NOZZLE OUTER	CF6-80C2	NS	4
1647M63P09	SEAL - NOZZLE OUTER	CF6-80C2	NS	55
1647M63P09	SEAL - NOZZLE OUTER	CF6-80C2	NE	100
1647M63P10	SEAL - NOZZLE OUTER	CF6-80C2	NE	1
1647M63P10	SEAL - NOZZLE OUTER	CF6-80C2	NE	4
1647M63P10	SEAL - NOZZLE OUTER	CF6-80C2	NE	22
1647M63P10	SEAL - NOZZLE OUTER	CF6-80C2	NE	1
1647M63P10	SEAL - NOZZLE OUTER	CF6-80C2	NE	50
1647M63P10	SEAL - NOZZLE OUTER	CF6-80C2	NE	74
1647M63P11	SEAL - SPLINE	CF6-80C2, CF6-80A	NE	1
1647M63P11	SEAL - SPLINE	CF6-80C2, CF6-80A	NE	50

Part Number	Part Description	Engine Type	Condition	Quantity
1647M63P11	SEAL - SPLINE	CF6-80C2, CF6-80A	NE	100
1647M63P11	SEAL - SPLINE	CF6-80C2, CF6-80A	NE	50
1647M63P13	SEAL - HPT STATOR	CF6-80C2	NE	17
1647M63P16	SEAL - SPLINE	CF6-80C2	NS	8
1647M63P16	SEAL - SPLINE	CF6-80C2	NE	59
1647M63P16	SEAL - SPLINE	CF6-80C2	NE	50
1647M99P02	SEAL	CF6-80C2	AR	1
1647M99P02	SEAL	CF6-80C2	AR	1
1649M67P01	COVER PLATE	CF6-80C2	NE	1
1663M50P01	LINK - MOUNT TOP	CF6-80C2	AR	1
1663M61P07	AGB CARBON FACE SEAL	CF6-80C2	OH	1
1663M61P07	AGB CARBON FACE SEAL	CF6-80C2	OH	1
1663M63G02	LINK - SIDE	CF6-80C2	OH	1
1663M63G02	LINK - SIDE	CF6-80C2	OH	1
1663M64P07	AGB CARBON FACE SEAL	CF6-80C2	AR	1
1663M64P07	AGB CARBON FACE SEAL	CF6-80C2	AR	1
1663M64P07	AGB CARBON FACE SEAL	CF6-80C2	AR	1
1663M64P07	AGB CARBON FACE SEAL	CF6-80C2	OH	1
1663M64P07	AGB CARBON FACE SEAL	CF6-80C2	OH	1
1663M68G01	NUT - OUTER BRG NO. 6R	CF6-80C2	OH	1
1663M72P03	SEAL - BRG 4R VENT AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M72P03	SEAL - BRG 4R VENT AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M72P03	SEAL - BRG 4R VENT AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M72P03	SEAL - BRG 4R VENT AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M72P03	SEAL - BRG 4R VENT AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M72P03	SEAL - BRG 4R VENT AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M72P03	SEAL - BRG 4R VENT AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M72P03	SEAL - BRG 4R VENT AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M72P03	SEAL - BRG 4R VENT AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M72P03	SEAL - BRG 4R VENT AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M72P03	SEAL - BRG 4R VENT AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M72P03	SEAL - BRG 4R VENT AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M72P03	SEAL - BRG 4R VENT AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
1663M72P03	SEAL - BRG 4R VENT AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M72P03	SEAL - BRG 4R VENT AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M72P03	SEAL - BRG 4R VENT AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M72P03	SEAL - BRG 4R VENT AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M72P03	SEAL - BRG 4R VENT AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M72P03	SEAL - BRG 4R VENT AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M72P03	SEAL - BRG 4R VENT AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M72P03	SEAL - BRG 4R VENT AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M72P03	SEAL - BRG 4R VENT AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M72P03	SEAL - BRG 4R VENT AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M73G01	NUT - OUTER BRG NO. 6R	CF6-80C2	AR	1
1663M73G01	NUT - OUTER BRG NO. 6R	CF6-80C2	OH	1
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1663M74P01	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1663M76P01	DAMPER RING	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
1663M76P01	DAMPER RING	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
1663M76P01	DAMPER RING	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
1663M99P01	CAP - PRESS	CF6-80C2	SV	1
1663M99P02	CAP - PRESS	CF6-80C2	SV	1
1664M18G01	AGB LINK ASSY [RH]	CF6-80C2	OH	1
1664M20P01	AGB LINK ASSY [LH]	CF6-80C2	OH	1
1664M77P01	HOUSING - SEAL BRG NO. 6	CF6-80C2	SV	1
1664M81P03	SHIELD - HEAT BRG NO. 6	CF6-80C2	AR	1
1664M81P03	SHIELD - HEAT BRG NO. 6	CF6-80C2	AR	1
1664M84G01	SHIELD - HEAT BRG NO. 6	CF6-80C2	AR	1
1664M86P01	SLINGER - OIL BRG NO. 6	CF6-80C2	AR	1
1664M93P01	SLEEVE - WEAR HORIZ DR SFT	CF6-80C2	NE	2

Part Number	Part Description	Engine Type	Condition	Quantity
1664M93P02	SLEEVE - WEAR HORIZ DR SFT	CF6-80C2	NE	1
1665M55P01	ARRESTOR - FLAME	CF6-80C2	AR	1
1665M59P01	#4 MAIN BALL BEARING	CF6-80C2, CF6-80A	AR	1
1665M59P01	#4 MAIN BALL BEARING	CF6-80C2, CF6-80A	AR	1
1665M59P01	#4 MAIN BALL BEARING	CF6-80C2, CF6-80A	AR	1
1665M59P01	#4 MAIN BALL BEARING	CF6-80C2, CF6-80A	AR	1
1665M59P01	#4 MAIN BALL BEARING	CF6-80C2, CF6-80A	AR	1
1665M59P01	#4 MAIN BALL BEARING	CF6-80C2, CF6-80A	AR	1
1665M59P01	#4 MAIN BALL BEARING	CF6-80C2, CF6-80A	AR	1
1665M59P01	#4 MAIN BALL BEARING	CF6-80C2, CF6-80A	AR	1
1665M59P01	#4 MAIN BALL BEARING	CF6-80C2, CF6-80A	AR	1
1665M59P01	#4 MAIN BALL BEARING	CF6-80C2, CF6-80A	AR	1
1665M59P01	#4 MAIN BALL BEARING	CF6-80C2, CF6-80A	OH	1
1665M59P01	#4 MAIN BALL BEARING	CF6-80C2, CF6-80A	AR	1
1665M90G01	HOUSING - HORIZONTAL	CF6-80C2	OH	1
1665M90G01	HOUSING - HORIZONTAL	CF6-80C2	OH	1
1666M78P01	CUP (SPD)	CF6-50	NE	5
1666M78P01	CUP (SPD)	CF6-50	NE	8
1669M96P03	SEAL - VENT BRG NO. 4	CF6-80C2	OH	1
1678M36G02	NOZZLE - AIR CURTAIN	CF6-80C2	OH	1
1678M44G01	BRACKET - ELEC INTFC N1	CF6-80C2	SV	1
1678M45G01	BRACKET - ELECTRICAL	CF6-80C2	AR	1
1678M50G01	TUBE - AIR HPT SUPPLY	CF6-80C2	AR	1
1678M50G01	TUBE - AIR HPT SUPPLY	CF6-80C2	AR	1
1678M54G02	TUBE - OIL	CF6-80C2	NE	1
1678M62G03	TUBE - AIR CURTAIN RIGHT	CF6-80C2	AR	1
1678M62G04	NOZZLE - AIR	CF6-80C2	OH	1
1678M67P001B	BRACKET	CF6-80C2	AR	1
1678M67P001B	BRACKET	CF6-80C2	AR	1
1678M73P001B	BRACKET - IGNITION LEAD	CF6-80C2	SV	1
1678M73P001B	BRACKET - IGNITION LEAD	CF6-80C2	SV	1
1678M75G03	TUBE - AIR HPT SUPPLY	CF6-80C2	AR	1
1678M82G01	TUBE - OIL N1 SCAV	CF6-80C2	AR	1
1679M17P02	SPACER	CF6-80C2	NS	1
1679M18G01	BRACKET - TUBE LP	CF6-80C2	OH	1
1679M18G01	BRACKET - TUBE LP	CF6-80C2	NE	1
1679M26P02	TUBE - FUEL HOSE	CF6-80C2	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
1679M39P001A	BRACKET - DBL ANGLE	CF6-80C2	AR	1
1679M42P001A	BRACKET	CF6-80C2	NS	1
1679M73P001A	BRACKET - AIR CURTAIN	CF6-80C2	NE	1
1679M73P001A	BRACKET - AIR CURTAIN	CF6-80C2	NE	3
1679M78G06	MANIFOLD - AIR LPT COOL L/S	CF6-80C2	AR	1
1679M79G03	MANIFOLD - AIR LPT COOL R/S	CF6-80C2	AR	1
1679M85P01	KIT - LPT INLET MANIF SEAL	CF6-80C2	SV	1
1679M85P01	KIT - LPT INLET MANIF SEAL	CF6-80C2	SV	1
1679M85P01	KIT - LPT INLET MANIF SEAL	CF6-80C2	OH	1
1679M87P001B	BRACKET - EBU	CF6-80C2	NE	3
1679M92G01	TUBE - OIL	CF6-80C2	AR	1
1679M92G01	TUBE - OIL	CF6-80C2	SV	1
1697M73P01	WIRE - RETAINING	CF6-80C2	NE	3
1697M73P04	WIRE - RETAINING	CF6-80C2	NS	1
1703M40G01	VANE ASSY - FAN STATOR OGV	CF6-80C2	OH	1
1703M40G01	VANE ASSY - FAN STATOR OGV	CF6-80C2	OH	1
1703M55P01	SEAL ASSY - BRG 4R AIR	CF6-50 (LMCO)	AR	1
1703M55P01	SEAL ASSY - BRG 4R AIR	CF6-50 (LMCO)	AR	1
1703M55P01	SEAL ASSY - BRG 4R AIR	CF6-50 (LMCO)	AR	1
1703M55P01	SEAL ASSY - BRG 4R AIR	CF6-50 (LMCO)	OH	1
1703M55P01	SEAL ASSY - BRG 4R AIR	CF6-50 (LMCO)	OH	1
1703M55P01	SEAL ASSY - BRG 4R AIR	CF6-50 (LMCO)	OH	1
1703M55P02	SEAL ASSY - BRG 4R AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1703M55P02	SEAL ASSY - BRG 4R AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1703M55P02	SEAL ASSY - BRG 4R AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1703M55P02	SEAL ASSY - BRG 4R AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1703M55P02	SEAL ASSY - BRG 4R AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1703M55P02	SEAL ASSY - BRG 4R AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1703M55P02	SEAL ASSY - BRG 4R AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1703M55P02	SEAL ASSY - BRG 4R AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1703M55P02	SEAL ASSY - BRG 4R AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1703M58G01	LINER ASSY - STG 13	CF6-80C2	OH	8
1703M58G01	LINER ASSY - STG 13	CF6-80C2	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
1703M58G01	LINER ASSY - STG 13	CF6-80C2	OH	3
1703M58G01	LINER ASSY - STG 13	CF6-80C2	OH	1
1703M58G01	LINER ASSY - STG 13	CF6-80C2	OH	7
1703M58G01	LINER ASSY - STG 13	CF6-80C2	OH	1
1703M58G01	LINER ASSY - STG 13	CF6-80C2	OH	9
1703M58G01	LINER ASSY - STG 13	CF6-80C2	OH	9
1703M58G03	LINER ASSY - STG 13	CF6-80C2	OH	1
1703M58G03	LINER ASSY - STG 13	CF6-80C2	AR	1
1703M58G03	LINER ASSY - STG 13	CF6-80C2	OH	1
1703M67P10	DISK - FAN STG 1	CF6-80A	OH	1
1703M74G03	HPC ROTOR SPOOL SHAFT STG 11-14	CF6-80C2	AR	1
1703M82G02	SEAL - STATIONARY STG 13	CF6-80C2	AR	1
1703M82G02	SEAL - STATIONARY STG 13	CF6-80C2	AR	1
1703M92G02	SEAL - STATIONARY STG 13	CF6-80C2	AR	2
1703M92G02	SEAL - STATIONARY STG 13	CF6-80C2	AR	2
1703M92G02	SEAL - STATIONARY STG 13	CF6-80C2	NE	1
1703M92G02	SEAL - STATIONARY STG 13	CF6-80C2	NS	2
1703M92G03	SEAL - STATIONARY STG 13	CF6-80C2	AR	2
1703M92G03	SEAL - STATIONARY STG 13	CF6-80C2	AR	2
1703M92G03	SEAL - STATIONARY STG 13	CF6-80C2	NE	1
1704M39P42	DISK - FAN STG 1	CF6-50 (LMCO)	AR	1
1704M40P42	DISK - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1704M40P42	DISK - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1704M40P42	DISK - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1704M42P08	DISK - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1706M23P001A	BRACKET - SPRAY	CF6-80C2	AR	1
1706M23P001A	BRACKET - SPRAY	CF6-80C2	NS	1
1706M31P001A	BRACKET - TUBE OIL CLG	CF6-80C2	OH	1
1706M41G02	LPT STATOR COOLING MANIFOLD BRACKET	CF6-80C2	OH	4
1706M55G01	BRACKET - SUPPORT	CF6-80C2	AR	1
1706M55G01	BRACKET - SUPPORT	CF6-80C2	SV	1
1706M55G01	BRACKET - SUPPORT	CF6-80C2	SV	1
1706M55G01	BRACKET - SUPPORT	CF6-80C2	SV	1
1706M68G01	BRACKET - SUPPORT	CF6-80C2	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
1706M68G01	BRACKET - SUPPORT	CF6-80C2	SV	1
1706M86G01	BRACKET - CABLE TRAY	CF6-80C2	AR	1
1706M99P001A	BRACKET	CF6-80C2	AR	1
1707M14P01	HOUSING - BEARING	CF6-80C2	NE	4
1707M14P01	HOUSING - BEARING	CF6-80C2	NE	1
1707M15G01	MANIFOLD - OIL LUBE SUPPLY	CF6-80C2	AR	1
1707M15G01	MANIFOLD - OIL LUBE SUPPLY	CF6-80C2	AR	1
1707M15G01	MANIFOLD - OIL LUBE SUPPLY	CF6-80C2	SV	1
1707M21G01	BRACKET - HP RECOUP	CF6-80C2	NE	1
1707M21G01	BRACKET - HP RECOUP	CF6-80C2	NE	1
1707M28P001A	BRACKET - ELECTRIC	CF6-80C2	SV	1
1707M32P001A	BRACKET - OIL SCAVENGE	CF6-80C2	NE	4
1707M32P001A	BRACKET - OIL SCAVENGE	CF6-80C2	AR	1
1707M32P001A	BRACKET - OIL SCAVENGE	CF6-80C2	AR	1
1707M36P001A	BRACKET - SUPPORT EGT	CF6-80C2	SV	1
1707M39P001A	BRACKET - SUPPORT	CF6-80C2	NE	2
1707M52P01	TUBE/HOSE - FUEL LPTCC SPLY	CF6-80C2	AR	1
1707M52P01	TUBE/HOSE - FUEL LPTCC SPLY	CF6-80C2	SV	1
1707M52P01	TUBE/HOSE - FUEL LPTCC SPLY	CF6-80C2	SV	1
1707M52P01	TUBE/HOSE - FUEL LPTCC SPLY	CF6-80C2	SV	1
1707M54P02	TUBE/HOSE - FUEL HPTCC SPLY	CF6-80C2	SV	1
1707M54P03	TUBE/HOSE - FUEL HPTCC SPLY	CF6-80C2	NS	1
1707M54P04	TUBE/HOSE - FUEL HPTCC SPLY	CF6-80C2	OH	1
1707M56G01	BRACKET	CF6-80C2	SV	1
1707M56G01	BRACKET	CF6-80C2	SV	1
1707M60P001A	BRACKET	CF6-80C2	NS	1
1707M60P001A	BRACKET	CF6-80C2	OH	1
1707M61P001A	BRACKET	CF6-80C2	NS	1
1707M62G02	TUBE - D MID SCAV	CF6-80C2	OH	1
1707M68G01	TUBE - OIL D-SUPPLY	CF6-80C2	SV	1
1707M68G01	TUBE - OIL D-SUPPLY	CF6-80C2	OH	1
1707M71P01	SHIELD - SPRAY	CF6-80C2	NE	1
1707M71P01	SHIELD - SPRAY	CF6-80C2	SV	1
1707M72P01	SHIELD - SPRAY	CF6-80C2	SV	1
1707M80G01	TUBE - MID D SCAVENGE	CF6-80C2	AR	1
1707M80G02	TUBE - MID D SCAVENGE	CF6-80C2	AR	1
1707M94P001A	BRACKET - ELECTRIC CABLE	CF6-80C2	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
1707M94P001A	BRACKET - ELECTRIC CABLE	CF6-80C2	NE	1
1707M98G01	BRACKET - ELEC LEAD SHLDRS	CF6-80C2	SV	1
1707M99P001A	BRACKET - HYD SUCTION	CF6-80C2	AR	1
1712M62G03	SEAL - HPT STAT SPRT STG 1	CF6-80A	OH	1
1712M62G03	SEAL - HPT STAT SPRT STG 1	CF6-80A	OH	1
1712M62G06	SEAL - HPT STAT SPRT STG 1	CF6-80A	OH	1
1713M16P02	LINER - INNER LPT	CF6-80A	OH	1
1754M14P005A	BRACKET - BOLT FRAME LINK	CF6-80C2	NS	1
1754M15P001A	BRACKET - NUT FRAME LINK	CF6-80C2	AR	1
1754M15P001A	BRACKET - NUT FRAME LINK	CF6-80C2	AR	1
1754M15P001A	BRACKET - NUT FRAME LINK	CF6-80C2	NS	1
1754M15P001A	BRACKET - NUT FRAME LINK	CF6-80C2	NS	1
1754M15P001A	BRACKET - NUT FRAME LINK	CF6-80C2	SV	1
1754M16P001A	BRACKET - SUPPORT	CF6-80C2	AR	1
1754M71G01	TUBE - SCAVENGE	CF6-80C2	AR	1
1754M73G01	TUBE - OIL SUPPLY	CF6-80C2	SV	1
1754M75G01	TUBE - SCAVENGE	CF6-80C2	SV	1
1755M42P02	SWIRLER - SECONDARY	CF6-80C2	NE	3
1755M42P02	SWIRLER - SECONDARY	CF6-80C2	NE	3
1755M42P02	SWIRLER - SECONDARY	CF6-80C2	NE	3
1755M42P02	SWIRLER - SECONDARY	CF6-80C2	NE	3
1755M42P02	SWIRLER - SECONDARY	CF6-80C2	NE	3
1755M42P02	SWIRLER - SECONDARY	CF6-80C2	NE	3
1755M42P02	SWIRLER - SECONDARY	CF6-80C2	NE	3
1755M42P02	SWIRLER - SECONDARY	CF6-80C2	NE	3
1755M42P02	SWIRLER - SECONDARY	CF6-80C2	NE	3
1755M42P02	SWIRLER - SECONDARY	CF6-80C2	NE	1
1755M76G05	COWL - COMB CHMBR	CF6-50	AR	1
1756M38G01	TUBE - OIL B SUMP FWD	CF6-50 (Boeing)	AR	1
1756M38G01	TUBE - OIL B SUMP FWD	CF6-50 (Boeing)	AR	1
1756M40G01	TUBE - OIL B SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1756M40G01	TUBE - OIL B SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1756M40G01	TUBE - OIL B SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1756M40G01	TUBE - OIL B SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
1756M42G01	TUBE - MID OIL D-SUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1756M42G01	TUBE - MID OIL D-SUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1756M42G01	TUBE - MID OIL D-SUMP	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
1756M44G01	TUBE - OIL PYLON-D SUMP	CF6-50 (Boeing)	AR	1
1756M44G01	TUBE - OIL PYLON-D SUMP	CF6-50 (Boeing)	AR	1
1756M44G01	TUBE - OIL PYLON-D SUMP	CF6-50 (Boeing)	AR	1
1756M48G01	TUBE - OIL MID C-SUMP SCAV	CF6-50 (LMCO)	AR	1
1756M66P001A	BRACKET	CF6-80A	AR	1
1756M66P001A	BRACKET	CF6-80A	AR	1
1756M67G01	BRACKET	CF6-50	SV	1
1756M83P02	SEAL - LH AFT BEAM	CF6-80A	NE	2
1756M84P02	SEAL - LH AFT BEAM	CF6-80A	NE	2
1756M85P02	SEAL - RH AFT BEAM	CF6-80A	NE	3
1756M94G01	MANIFOLD ASSY - STG 8 AIR	CF6-50	OH	1
1756M94G03	MANIFOLD ASSY - STG 8 AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1756M94G03	MANIFOLD ASSY - STG 8 AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1756M94G03	MANIFOLD ASSY - STG 8 AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1756M94G03	MANIFOLD ASSY - STG 8 AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1756M95G01	BRACKET - WYE STG 8	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1756M95G01	BRACKET - WYE STG 8	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1756M95G01	BRACKET - WYE STG 8	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1756M95G01	BRACKET - WYE STG 8	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
1773M72G03	BRACKET - TUBE D SUMP	CF6-80C2	NS	1
1774M10P001A	BRACKET - TUBE MID PYLON	CF6-80C2	NS	1
1774M10P001A	BRACKET - TUBE MID PYLON	CF6-80C2	SV	1
1774M14G01	TUBE - D OIL LUBE	CF6-80C2	AR	1
1774M14G01	TUBE - D OIL LUBE	CF6-80C2	AR	1
1774M14G01	TUBE - D OIL LUBE	CF6-80C2	AR	1
1774M52P02	REDUCER - FTG	CF6-80C2	NS	1
1774M58G01	BRACKET - ANGLE	CF6-80C2	AR	1
1774M59P01	SEAL - RING	CF6-80C2	NE	1
1774M59P01	SEAL - RING	CF6-80C2	NE	4
1774M59P01	SEAL - RING	CF6-80C2	NS	1
1774M59P01	SEAL - RING	CF6-80C2	NS	2

Part Number	Part Description	Engine Type	Condition	Quantity
1774M59P01	SEAL - RING	CF6-80C2	NE	20
1774M59P01	SEAL - RING	CF6-80C2	NE	10
1774M60G01	TUBE - D OIL SCAV AFT	CF6-80C2	OH	1
1774M60G01	TUBE - D OIL SCAV AFT	CF6-80C2	OH	1
1774M60G01	TUBE - D OIL SCAV AFT	CF6-80C2	NS	1
1774M60G02	TUBE - D OIL SCAV AFT	CF6-80C2	SV	1
1774M60G02	TUBE - D OIL SCAV AFT	CF6-80C2	AR	1
1774M79P01	LPT STATOR AFT BRACKET	CF6-80C2	AR	1
1774M79P01	LPT STATOR AFT BRACKET	CF6-80C2	OH	6
1774M79P01	LPT STATOR AFT BRACKET	CF6-80C2	AR	6
1774M79P01	LPT STATOR AFT BRACKET	CF6-80C2	NE	1
1774M91G02	TUBE - CORE COMPT CLG AIR	CF6-80C2	AR	1
1775M24P001A	BRACKET - SUPPORT	CF6-80C2	NS	1
1775M24P001A	BRACKET - SUPPORT	CF6-80C2	AR	1
1775M24P001A	BRACKET - SUPPORT	CF6-80C2	NS	1
1775M37G01	BRACKET - T5 CABLE	CF6-80C2	NE	1
1775M37G01	BRACKET - T5 CABLE	CF6-80C2	NE	1
1775M37G01	BRACKET - T5 CABLE	CF6-80C2	NE	1
1775M37G01	BRACKET - T5 CABLE	CF6-80C2	NE	1
1775M37G01	BRACKET - T5 CABLE	CF6-80C2	NE	1
1775M37G01	BRACKET - T5 CABLE	CF6-80C2	NE	1
1775M37G01	BRACKET - T5 CABLE	CF6-80C2	NE	1
1775M37G01	BRACKET - T5 CABLE	CF6-80C2	NE	4
1775M46P001A	BRACKET - PMUX	CF6-80C2	NE	1
1775M70G01	TUBE - IDG PRESS RLF DR	CF6-80C2	NS	1
1775M70G01	TUBE - IDG PRESS RLF DR	CF6-80C2	NE	1
1775M91G01	TUBE - AIR	CF6-80C2	OH	1
1777M12G01	TUBE - FUEL	CF6-80A	NE	1
1777M32G01	BRACKET - VIBRATION SPRT	CF6-50 (LMCO)	NE	1
1777M32G02	BRACKET - VIBRATION SPRT	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
1777M32G02	BRACKET - VIBRATION SPRT	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
1777M32G02	BRACKET - VIBRATION SPRT	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
1777M36G01	VALVE - CHECK 7TH STAGE	CF6-80A	OH	1
1778M32P03	SEAL - DIFFUSER AFT	CF6-80A	AR	1
1778M32P03	SEAL - DIFFUSER AFT	CF6-80A	AR	1
1778M49P01	SUPPORT - STTR SHRD STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	48
1778M49P01	SUPPORT - STTR SHRD STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	OH	29

Part Number	Part Description	Engine Type	Condition	Quantity
1778M49P01	SUPPORT - STTR SHRD STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	OH	33
1778M49P01	SUPPORT - STTR SHRD STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	OH	46
1778M59P03	SUPPORT - STTR SHRD STG 1	CF6-50	NS	14
1778M59P03	SUPPORT - STTR SHRD STG 1	CF6-50	OH	3
1778M59P04	SUPPORT - STTR SHRD STG 1	CF6-50	NS	14
1778M59P04	SUPPORT - STTR SHRD STG 1	CF6-50	OH	3
1778M93P01	RETAINER - NUT (SPD)	CF6-80C2	NE	4
1778M93P01	RETAINER - NUT (SPD)	CF6-80C2	NE	18
1781M20G01	PLATFORM - STG 1	CF6-50 (LMCO)	AR	9
1781M20G01	PLATFORM - STG 1	CF6-50 (LMCO)	AR	33
1781M20G01	PLATFORM - STG 1	CF6-50 (LMCO)	AR	3
1781M20G01	PLATFORM - STG 1	CF6-50 (LMCO)	AR	38
1781M20G02	PLATFORM - STG 1	CF6-50	AR	3
1781M20G02	PLATFORM - STG 1	CF6-50	AR	3
1781M20G02	PLATFORM - STG 1	CF6-50	AR	3
1781M20G02	PLATFORM - STG 1	CF6-50	AR	3
1781M20G02	PLATFORM - STG 1	CF6-50	AR	3
1781M20G02	PLATFORM - STG 1	CF6-50	AR	3
1781M20G02	PLATFORM - STG 1	CF6-50	AR	3
1781M20G02	PLATFORM - STG 1	CF6-50	AR	2
1781M20G02	PLATFORM - STG 1	CF6-50	AR	1
1781M20G03	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	OH	37
1781M20G03	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
1781M20G03	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
1781M20G03	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
1781M20G03	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	OH	22
1781M20G03	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
1781M20G03	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
1781M20G03	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1781M20G05	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	SV	31
1781M20G05	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
1781M20G05	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
1781M20G05	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
1781M20G05	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
1781M20G05	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
1781M20G05	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
1781M20G05	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	17
1781M20G05	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	OH	14
1781M20G05	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	OH	38
1781M20G05	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1781M20G05	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
1781M20G05	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	35
1781M20G05	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	OH	10
1781M20G05	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
1781M20G06	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1781M20G06	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1781M20G06	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	SV	6
1781M20G06	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	OH	35
1781M20G06	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
1781M20G06	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
1781M20G06	PLATFORM - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
1781M87P07	SPOOL - STG 11-13	CF6-50	AR	1
1781M90P01	SEAL	CF6-80C2	NE	1
1781M90P01	SEAL	CF6-80C2	NE	1
1781M90P01	SEAL	CF6-80C2	NS	10
1781M90P01	SEAL	CF6-80C2	NS	2
1782M21P01	#4 BEARING VENT SEAL	CF6-80C2	OH	1
1782M72P01	RETAINER - STG 1	CF6-80A	SV	19
1782M85G01	HPC ROTOR BLADE RETAINER STG 1	CF6-80C2	NE	27
1782M85G01	HPC ROTOR BLADE RETAINER STG 1	CF6-80C2	NE	6

Part Number	Part Description	Engine Type	Condition	Quantity
1782M85G01	HPC ROTOR BLADE RETAINER STG 1	CF6-80C2	NE	1
1782M85G01	HPC ROTOR BLADE RETAINER STG 1	CF6-80C2	NE	3
1797M15G02	ELBOW	CF6-80C2	AR	1
1800M12G01	MANIFOLD - OIL GB REF PRESS	CF6-80C2	AR	1
1800M16G01	TUBE - OIL LUBE PUMP DISH	CF6-80C2	OH	1
1800M18G01	MANIFOLD - OIL LUBE PUMP	CF6-80C2	AR	1
1800M76P03	TUBE	CF6-80C2	AR	1
1800M76P03	TUBE	CF6-80C2	AR	1
1800M76P03	TUBE	CF6-80C2	AR	1
1800M87G01	SHROUD - FUEL LINE	CF6-80C2	AR	1
1800M87G01	SHROUD - FUEL LINE	CF6-80C2	OH	1
1800M88G01	BRACKET	CF6-80C2	NS	1
1801M32G01	MANIFOLD - HPT COOLING AIR	CF6-80C2	AR	1
1801M32G01	MANIFOLD - HPT COOLING AIR	CF6-80C2	AR	1
1801M32G01	MANIFOLD - HPT COOLING AIR	CF6-80C2	AR	2
1801M33G01	BRACKET - DRAIN	CF6-80C2	AR	1
1801M50P001A	BRACKET - SUPPORT EGT	CF6-80C2	SV	1
1801M53G03	BRACKET - EGT SUPPORT	CF6-80C2	SV	1
1801M53G03	BRACKET - EGT SUPPORT	CF6-80C2	SV	1
1801M97P01	WEDGE - DRAIN PYLON	CF6-80C2	NS	1
1805M95G01	NOZZLE - HPT STG 1	CF6-80C2	OH	1
1805M95G01	NOZZLE - HPT STG 1	CF6-80C2	OH	1
1805M95G01	NOZZLE - HPT STG 1	CF6-80C2	OH	1
1805M95G01	NOZZLE - HPT STG 1	CF6-80C2	OH	1
1805M95G01	NOZZLE - HPT STG 1	CF6-80C2	OH	1
1805M95G01	NOZZLE - HPT STG 1	CF6-80C2	OH	1
1805M95G01	NOZZLE - HPT STG 1	CF6-80C2	OH	1
1805M95G01	NOZZLE - HPT STG 1	CF6-80C2	OH	1
1805M95G01	NOZZLE - HPT STG 1	CF6-80C2	OH	1
1806M79G01	YOKE - ENGINE MOUNT FWD	CF6-80C2	AR	1
1806M79G01	YOKE - ENGINE MOUNT FWD	CF6-80C2	AR	1
1806M79G01	YOKE - ENGINE MOUNT FWD	CF6-80C2	AR	1
1806M79G01	YOKE - ENGINE MOUNT FWD	CF6-80C2	AR	1
1806M80G01	PLATFORM - ENGINE MOUNT	CF6-80C2	AR	1
1809M11P02	TUBE ASSY - NOZ FDR	CF6-50	NS	1
1809M11P02	TUBE ASSY - NOZ FDR	CF6-50	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
1810M23P001A	BRACKET	CF6-80C2	NS	1
1810M41G01	TUBE - FUEL DRAIN COMB FWD	CF6-80C2	NE	1
1810M73G01	MANIFOLD - ACC AIR	CF6-80C2	SV	1
1810M75P001A	BRACKET - OIL PRESS SPRT	CF6-80C2	NE	1
1810M75P001A	BRACKET - OIL PRESS SPRT	CF6-80C2	NS	5
1810M75P001A	BRACKET - OIL PRESS SPRT	CF6-80C2	SV	1
1810M83P01	MANIFOLD - COOLING LPT	CF6-80C2	AR	1
1810M83P01	MANIFOLD - COOLING LPT	CF6-80C2	AR	1
1810M83P01	MANIFOLD - COOLING LPT	CF6-80C2	AR	1
1810M83P01	MANIFOLD - COOLING LPT	CF6-80C2	AR	1
1810M83P01	MANIFOLD - COOLING LPT	CF6-80C2	AR	1
1810M83P01	MANIFOLD - COOLING LPT	CF6-80C2	AR	1
1810M83P01	MANIFOLD - COOLING LPT	CF6-80C2	AR	1
1810M83P01	MANIFOLD - COOLING LPT	CF6-80C2	AR	1
1810M83P01	MANIFOLD - COOLING LPT	CF6-80C2	AR	1
1810M83P01	MANIFOLD - COOLING LPT	CF6-80C2	AR	1
1810M83P02	MANIFOLD - COOLING LPT	CF6-80C2	OH	1
1810M83P03	MANIFOLD - COOLING LPT	CF6-80C2	OH	1
1810M85P01	MANIFOLD - INLET	CF6-80C2	OH	1
1811M53G02	MANIFOLD - PRESS SENSING	CF6-80C2	AR	1
1811M82P02	MANIFOLD - DRAIN	CF6-80C2	SV	1
1814M10G01	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
1814M10G01	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
1814M10G01	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
1814M10G01	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
1814M10G01	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
1814M10G01	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
1814M10G01	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
1814M10G01	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
1814M10G01	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
1814M10G01	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
1814M10G01	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
1814M10G01	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
1814M10G01	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
1814M10G01	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
1814M10G01	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
1814M10G01	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
1814M10G01	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
1814M10G01	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
1814M10G01	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
1814M10G03	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
1814M55G01	ARRESTOR - FLAME	CF6-80C2	OH	1
1814M57P01	SEAL - BLADE DAMPER	CF6-50 (LMCO), CF6-50 (Boeing)	NE	5
1814M57P01	SEAL - BLADE DAMPER	CF6-50 (LMCO), CF6-50 (Boeing)	NE	6
1814M73P03	DISK - HPTR STG 2	CF6-50 (LMCO)	AR	1
1814M73P09	DISK - HPTR STG 2	CF6-50 (Boeing)	AR	1
1814M73P12	DISK - HPTR STG 2	CF6-50 (LMCO)	AR	1
1815M91G02	HPT NOZZLE STG 1 SHROUD SUPPORT	CF6-80C2	OH	1
1819M73G01	BRACKET	CF6-80A	AR	1
1819M73G01	BRACKET	CF6-80A	AR	1
18207	VANE - STG 11	CF6-50	OH	1
1821M62G01	CABLE - ELECTRICAL W7	CF6-80C2	AR	1
1821M63G02	CABLE - ELECTRICAL W8	CF6-80C2	AR	1
1822M33G01	MANIFOLD - OIL INNER	CF6-80C2	AR	1
1822M33G01	MANIFOLD - OIL INNER	CF6-80C2	AR	1
1822M33G01	MANIFOLD - OIL INNER	CF6-80C2	AR	1
1822M33G01	MANIFOLD - OIL INNER	CF6-80C2	SV	1
1822M33G01	MANIFOLD - OIL INNER	CF6-80C2	OH	1
1822M33G01	MANIFOLD - OIL INNER	CF6-80C2	AR	1
1822M33G01	MANIFOLD - OIL INNER	CF6-80C2	AR	1
1822M33G01	MANIFOLD - OIL INNER	CF6-80C2	OH	1
1822M35G01	SHROUD - LPT STATOR STG 1	CF6-50	AR	16
1822M35G01	SHROUD - LPT STATOR STG 1	CF6-50	AR	8
1822M35G01	SHROUD - LPT STATOR STG 1	CF6-50	AR	8
1822M35G01	SHROUD - LPT STATOR STG 1	CF6-50	AR	16
1822M35G01	SHROUD - LPT STATOR STG 1	CF6-50	AR	16
1822M35G01	SHROUD - LPT STATOR STG 1	CF6-50	AR	16

Part Number	Part Description	Engine Type	Condition	Quantity
1822M35G01	SHROUD - LPT STATOR STG 1	CF6-50	AR	16
1822M35G01	SHROUD - LPT STATOR STG 1	CF6-50	AR	16
1822M35G01	SHROUD - LPT STATOR STG 1	CF6-50	AR	16
1822M35G01	SHROUD - LPT STATOR STG 1	CF6-50	AR	16
1822M35G01	SHROUD - LPT STATOR STG 1	CF6-50	AR	1
1822M35G02	SHROUD - LPT STATOR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	13
1822M35G02	SHROUD - LPT STATOR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
1822M35G02	SHROUD - LPT STATOR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
1822M35G02	SHROUD - LPT STATOR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
1822M35G02	SHROUD - LPT STATOR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
1822M35G02	SHROUD - LPT STATOR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
1822M35G02	SHROUD - LPT STATOR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
1822M35G02	SHROUD - LPT STATOR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
1822M35G02	SHROUD - LPT STATOR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
1822M35G02	SHROUD - LPT STATOR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
1822M35G02	SHROUD - LPT STATOR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
1822M35G02	SHROUD - LPT STATOR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
1822M35G02	SHROUD - LPT STATOR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1822M36G01	SHROUD - LPT STATOR STG 2	CF6-50	OH	1
1822M36G01	SHROUD - LPT STATOR STG 2	CF6-50	OH	1
1822M36G01	SHROUD - LPT STATOR STG 2	CF6-50	OH	1
1822M36G01	SHROUD - LPT STATOR STG 2	CF6-50	OH	1
1822M36G01	SHROUD - LPT STATOR STG 2	CF6-50	OH	1
1822M36G01	SHROUD - LPT STATOR STG 2	CF6-50	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
1822M36G03	SHROUD - LPT STATOR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
1822M36G03	SHROUD - LPT STATOR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
1822M36G03	SHROUD - LPT STATOR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
1822M36G03	SHROUD - LPT STATOR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
1822M36G03	SHROUD - LPT STATOR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
1822M36G03	SHROUD - LPT STATOR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
1822M36G03	SHROUD - LPT STATOR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
1822M36G03	SHROUD - LPT STATOR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
1822M36G03	SHROUD - LPT STATOR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
1822M36G03	SHROUD - LPT STATOR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
1822M36G03	SHROUD - LPT STATOR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
1822M36G04	SHROUD - LPT STATOR STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
1822M36G04	SHROUD - LPT STATOR STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
1822M36G04	SHROUD - LPT STATOR STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
1822M36G04	SHROUD - LPT STATOR STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
1822M36G04	SHROUD - LPT STATOR STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	SV	15
1822M36G04	SHROUD - LPT STATOR STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
1822M36G04	SHROUD - LPT STATOR STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	12
1822M36G04	SHROUD - LPT STATOR STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1822M36G04	SHROUD - LPT STATOR STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
1822M36G04	SHROUD - LPT STATOR STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
1822M36G04	SHROUD - LPT STATOR STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
1822M36G04	SHROUD - LPT STATOR STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
1822M36G04	SHROUD - LPT STATOR STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
1822M36G04	SHROUD - LPT STATOR STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
1822M36G04	SHROUD - LPT STATOR STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20

Part Number	Part Description	Engine Type	Condition	Quantity
1822M37G01	SHROUD - LPT STATOR STG 4	CF6-50	AR	10
1822M37G01	SHROUD - LPT STATOR STG 4	CF6-50	AR	10
1822M37G01	SHROUD - LPT STATOR STG 4	CF6-50	AR	20
1822M37G01	SHROUD - LPT STATOR STG 4	CF6-50	AR	20
1822M37G01	SHROUD - LPT STATOR STG 4	CF6-50	NE	8
1822M37G01	SHROUD - LPT STATOR STG 4	CF6-50	AR	20
1822M37G02	SHROUD - LPT STATOR STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
1822M37G02	SHROUD - LPT STATOR STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
1822M37G02	SHROUD - LPT STATOR STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
1822M37G02	SHROUD - LPT STATOR STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
1822M37G02	SHROUD - LPT STATOR STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
1822M37G02	SHROUD - LPT STATOR STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
1822M37G02	SHROUD - LPT STATOR STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
1822M37G02	SHROUD - LPT STATOR STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
1822M37G02	SHROUD - LPT STATOR STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
1822M37G02	SHROUD - LPT STATOR STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
1822M37G02	SHROUD - LPT STATOR STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
1822M67P01	SEAL - FWD	CF6-80C2	NS	1
1822M67P01	SEAL - FWD	CF6-80C2	NE	1
1822M68P01	SEAL - FWD	CF6-80C2	NS	2
1822M69P01	SEAL - FWD	CF6-80C2	NE	1
1822M70P01	SEAL - FWD	CF6-80C2	NE	1
1822M71P01	SEAL - FWD	CF6-80C2	NE	2
1822M72P01	SEAL - AFT	CF6-80C2	NE	1
1822M73P01	SEAL - AFT	CF6-80C2	NE	2
1822M75P01	SEAL - AFT	CF6-80C2	NE	1
1822M77P01	LPT STATOR INTRSTG SEAL RETAINER STG 5	CF6-80C2	AR	1
1822M77P01	LPT STATOR INTRSTG SEAL RETAINER STG 5	CF6-80C2	AR	19
1822M77P01	LPT STATOR INTRSTG SEAL RETAINER STG 5	CF6-80C2	AR	15

Part Number	Part Description	Engine Type	Condition	Quantity
1822M77P01	LPT STATOR INTRSTG SEAL RETAINER STG 5	CF6-80C2	OH	1
1822M77P01	LPT STATOR INTRSTG SEAL RETAINER STG 5	CF6-80C2	OH	7
1822M77P01	LPT STATOR INTRSTG SEAL RETAINER STG 5	CF6-80C2	OH	9
1823M13G05	BRACKET - ELECTRIC	CF6-80C2	NE	1
1823M19G03	BRACKET - ELECTRIC	CF6-80C2	SV	1
1823M19G07	BRACKET - ELECTRIC	CF6-80C2	SV	1
1823M21G03	BRACKET - ELECTRIC	CF6-80C2	NS	1
1823M30G03	BRACKET - ELECTRIC	CF6-80C2	SV	1
1823M31G01	BRACKET - ELECTRIC	CF6-80C2	SV	1
1823M37G01	BRACKET - ELECTRIC	CF6-80C2	SV	1
1823M39G01	BRACKET - ELECTRIC	CF6-80C2	NE	1
1823M39G03	BRACKET - ELECTRIC	CF6-80C2	NE	1
1823M39G05	BRACKET - ELECTRIC	CF6-80C2	SV	1
1823M46G01	BRACKET - ELECTRIC	CF6-80C2	SV	1
1823M51G01	BRACKET - ELECTRIC	CF6-80C2	AR	1
1823M65G01	BRACKET - ELECTRIC	CF6-80C2	AR	1
1823M65G01	BRACKET - ELECTRIC	CF6-80C2	SV	1
1823M65G01	BRACKET - ELECTRIC	CF6-80C2	SV	1
1823M67G01	BRACKET - ELECTRIC	CF6-80C2	SV	1
1823M69G01	BRACKET - ELECTRIC	CF6-80C2	AR	1
1823M72G03	BRACKET - ELECTRIC	CF6-80C2	SV	1
1823M72G05	BRACKET - ELECTRIC	CF6-80C2	SV	1
1823M79G01	BRACKET - ELECTRIC	CF6-80C2	NE	1
1823M81G01	BRACKET - ELECTRIC	CF6-80C2	SV	2
1823M81G01	BRACKET - ELECTRIC	CF6-80C2	SV	1
1823M93G03	BRACKET - ELECTRIC	CF6-80C2	SV	1
1824M14G01	BRACKET - TRAY	CF6-80C2	SV	1
1824M16G05	BRACKET - ELECTRIC	CF6-80C2	NE	1
1824M16G05	BRACKET - ELECTRIC	CF6-80C2	NE	1
1824M17G03	BRACKET - CABLE TRAY	CF6-80C2	SV	1
1824M25G01	BRACKET - ELECTRIC	CF6-80C2	SV	1
1824M28G01	BRACKET - ELECTRIC	CF6-80C2	NE	4
1824M31G01	BRACKET - ELECTRIC	CF6-80C2	NS	1
1824M31G01	BRACKET - ELECTRIC	CF6-80C2	SV	1
1824M41G05	BRACKET - ELECTRIC	CF6-80C2	NE	1
1824M41G05	BRACKET - ELECTRIC	CF6-80C2	NE	1
1824M43G01	BRACKET - ELECTRIC	CF6-80C2	SV	1
1824M49G03	BRACKET - ELECTRIC	CF6-80C2	SV	1
1824M49G03	BRACKET - ELECTRIC	CF6-80C2	AR	1
1824M49G03	BRACKET - ELECTRIC	CF6-80C2	SV	1
1824M53G01	BRACKET - ELECTRIC	CF6-80C2	NE	1
1824M53G01	BRACKET - ELECTRIC	CF6-80C2	SV	1
1824M56G03	BRACKET - ELECTRIC	CF6-80C2	AR	1
1824M61G01	BRACKET - ELECTRIC	CF6-80C2	NS	1
1824M75G03	BRACKET - ELECTRIC	CF6-80C2	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
1824M76G01	BRACKET - ELECTRIC	CF6-80C2	SV	1
1824M80G01	BRACKET - ELECTRIC	CF6-80C2	NS	1
1824M82G03	BRACKET - ELECTRIC	CF6-80C2	SV	1
1824M88P001A	BRACKET	CF6-80C2	NE	4
1824M88P001A	BRACKET	CF6-80C2	SV	1
1824M96G01	BRACKET - ELECTRIC	CF6-80C2	NS	1
1824M99G01	BRACKET - ELECTRIC	CF6-80C2	SV	1
1825M12G01	BRACKET - ELECTRIC	CF6-80C2	NE	1
1825M12G03	BRACKET - ELECTRIC	CF6-80C2	AR	1
1825M12G05	BRACKET - ELECTRIC	CF6-80C2	SV	1
1825M12G06	BRACKET - ELECTRIC	CF6-80C2	SV	1
1825M14G01	BRACKET - ELECTRIC	CF6-80C2	NE	1
1825M14G03	BRACKET - ELECTRIC	CF6-80C2	NE	1
1825M14G05	BRACKET - ELECTRIC	CF6-80C2	SV	1
1825M23G01	BRACKET - ELECTRIC	CF6-80C2	SV	1
1825M25G01	BRACKET - ELECTRIC	CF6-80C2	SV	1
1825M32G03	BRACKET - ELECTRIC	CF6-80C2	OH	1
1825M34G01	BRACKET - ELECTRIC	CF6-80C2	SV	1
1825M36G01	BRACKET - ELECTRIC	CF6-80C2	SV	1
1825M63G01	TUBE - FUEL PUMP DRAIN	CF6-80C2	AR	1
1825M63G01	TUBE - FUEL PUMP DRAIN	CF6-80C2	AR	1
1825M65G01	MANIFOLD - MEC SPLINE	CF6-80C2	OH	1
1825M65G01	MANIFOLD - MEC SPLINE	CF6-80C2	OH	1
1825M65G01	MANIFOLD - MEC SPLINE	CF6-80C2	SV	1
1825M74G01	BRACKET - SHIELD	CF6-80C2	AR	1
1825M74G01	BRACKET - SHIELD	CF6-80C2	OH	1
1825M84G01	MANIFOLD - AIR TURBINE	CF6-80C2	OH	1
1825M98G01	TUBE - AIR LPT CLG SPLY LS	CF6-80C2	OH	1
1826M21G01	MANIFOLD - AIR LPT COOL L/S	CF6-80C2	NE	1
1826M22G01	MANIFOLD - AIR LPT COOL R/S	CF6-80C2	NE	1
1826M26G01	BRACKET - MANIFOLD AIR	CF6-80C2	NE	1
1826M42G01	BRACKET - THERMOCOUPLE	CF6-80C2	NS	1
1826M42G01	BRACKET - THERMOCOUPLE	CF6-80C2	NS	2
1826M46G01	TUBE - AIR HPT COOLING	CF6-80C2	OH	1
1826M62G01	BRACKET - TUBE OIL SUPPLY	CF6-80C2	NE	1
1826M65G01	BRACKET - T49 THERMOCOUPLE	CF6-80C2	OH	1
1826M85P01	BRACKET - HARNESS T49	CF6-80C2	NS	3
1826M87G01	BRACKET - T49 THERMOCOUPLE	CF6-80C2	NE	1
1832M21G01	BRACKET - TUBE D SUMP	CF6-80C2	NS	1
1832M21G01	BRACKET - TUBE D SUMP	CF6-80C2	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
1832M21G01	BRACKET - TUBE D SUMP	CF6-80C2	NS	2
1835M59G01	BRACKET - TUBE HOSE IDG	CF6-80C2	SV	1
1835M71G01	TUBE - FUEL LPT VALVE SPLY	CF6-80C2	OH	1
1835M71G02	TUBE - FUEL LPT VALVE SPLY	CF6-80C2	OH	1
1835M73G02	TUBE - FUEL LPT VALVE RTN	CF6-80C2	AR	1
1835M73G02	TUBE - FUEL LPT VALVE RTN	CF6-80C2	SV	1
1835M95G07	TUBE - AIR COOLING	CF6-80C2	NS	1
1835M96G01	TUBE - AIR HP RECOUP R/S	CF6-80C2	OH	1
1836M12G01	BRACKET - CLEVIS ACC	CF6-80C2	NS	1
1836M33G01	TUBE - FUEL FILTER	CF6-80C2	AR	1
1836M39G01	MANIFOLD	CF6-80C2	OH	1
1836M40G01	BRACKET - FUEL FLTR	CF6-80C2	NE	2
1836M64G02	DUCT - AIR	CF6-80C2	AR	1
1836M78P06	MANIFOLD - COOLING LPT	CF6-80C2	AR	1
1836M78P06	MANIFOLD - COOLING LPT	CF6-80C2	OH	1
1836M78P06	MANIFOLD - COOLING LPT	CF6-80C2	OH	1
1836M78P07	MANIFOLD - COOLING LPT	CF6-80C2	AR	1
1836M78P07	MANIFOLD - COOLING LPT	CF6-80C2	OH	1
1836M78P09	MANIFOLD - COOLING LPT	CF6-80C2	AR	1
1836M82G02	TUBE - FUEL MANF DRAIN	CF6-80C2	AR	1
1836M84G01	TUBE - FUEL MANF DRAIN	CF6-80C2	AR	1
1843M40P02	LINK - FRAME	CF6-80C2	AR	1
1846M23G01	LINK ASSY - LH MOUNT	CF6-80C2	SV	1
1846M24G06	PLATFORM ASSY - ENGINE	CF6-80C2	OH	1
1846M24G06	PLATFORM ASSY - ENGINE	CF6-80C2	OH	1
1851M26G01	ADAPTER - GENERATOR	CF6-80C2	OH	1
1851M27P01	BEARING - ROLLER	CF6-80C2	AR	1
1851M30P01	AGB SPUR GEARSHAFT	CF6-80C2	OH	1
1851M30P01	AGB SPUR GEARSHAFT	CF6-80C2	AR	1
1851M31P01	SPACER - RTR CONT ALTNTR	CF6-80C2	AR	1
1851M31P02	SPACER - RTR CONT ALTNTR	CF6-80C2	AR	1
1851M37P01	BEARING - ANLR FLANGED BALL	CF6-80C2	AR	1
1851M56G33	ENGINE - IDENT PLUG	CF6-80C2	SV	1
1851M56G38	ENGINE - IDENT PLUG	CF6-80C2	SV	1
1853M64G01	CABLE - ELECTRICAL W13	CF6-80C2	SV	1
1853M68G01	ARRESTOR - FLAME	CF6-80A	AR	1
1853M96P01	BEARING - NO. 4R CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1854M36P01	SPACER - STG 1	CF6-80C2	OH	38

Part Number	Part Description	Engine Type	Condition	Quantity
1854M38P01	END - STOP	CF6-80C2	NE	3
1854M40P01	SEAL - LEAF STG 13	CF6-80C2	NE	5
1854M40P01	SEAL - LEAF STG 13	CF6-80C2	NE	50
1854M96G02	LINER ASSY - STG 13	CF6-80C2	OH	1
1854M97P01	LINER - COMP STATOR	CF6-80C2	AR	1
1854M97P02	LINER - COMP STATOR	CF6-80C2	NE	2
1854M97P02	LINER - COMP STATOR	CF6-80C2	OH	1
1854M97P02	LINER - COMP STATOR	CF6-80C2	NE	1
1856M15G02	HPC ROTOR SPOOL STG 3-9	CF6-80C2	OH	1
1856M16G01	SPOOL ASSY - STG 3 THRU 9	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M16G01	SPOOL ASSY - STG 3 THRU 9	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M16G01	SPOOL ASSY - STG 3 THRU 9	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M21P01	SEAL - DVTL SLT	CF6-80C2	NE	21
1856M21P01	SEAL - DVTL SLT	CF6-80C2	NE	7
1856M21P01	SEAL - DVTL SLT	CF6-80C2	NE	162
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G01	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1856M41G03	HPC STATOR ACT CONN LINK STG 5	CF6-80C2	OH	1
1856M41G03	HPC STATOR ACT CONN LINK STG 5	CF6-80C2	OH	1
1856M68P01	SEAL - IGV STG 1-2	CF6-80A	NE	29
1856M68P01	SEAL - IGV STG 1-2	CF6-80A	NE	15

Part Number	Part Description	Engine Type	Condition	Quantity
1856M68P01	SEAL - IGV STG 1-2	CF6-80A	NE	12
1856M68P01	SEAL - IGV STG 1-2	CF6-80A	NE	38
1856M72P01	SEAL - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50	NS	3
1856M72P01	SEAL - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50	NS	2
1856M72P01	SEAL - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50	NS	96
1856M72P01	SEAL - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50	NS	4
1856M75P01	SEAL - STG 5	CF6-80A	NE	6
1856M75P01	SEAL - STG 5	CF6-80A	NE	2
1856M75P01	SEAL - STG 5	CF6-80A	NS	86
1856M75P01	SEAL - STG 5	CF6-80A	NS	29
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1

[illegible]

Part Number	Part Description	Engine Type	Condition	Quantity
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	AR	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1862M24P02	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
1862M24P03	HPT NOZZLE STG 1 SHROUD	CF6-80C2	AR	1
1862M24P03	HPT NOZZLE STG 1 SHROUD	CF6-80C2	AR	1
1862M24P03	HPT NOZZLE STG 1 SHROUD	CF6-80C2	AR	1
1862M24P03	HPT NOZZLE STG 1 SHROUD	CF6-80C2	AR	1
1862M24P03	HPT NOZZLE STG 1 SHROUD	CF6-80C2	AR	1
1862M24P03	HPT NOZZLE STG 1 SHROUD	CF6-80C2	AR	1
1862M24P03	HPT NOZZLE STG 1 SHROUD	CF6-80C2	OH	1
1862M24P03	HPT NOZZLE STG 1 SHROUD	CF6-80C2	OH	1
1862M24P05	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1862M24P05	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1862M24P05	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1862M24P05	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1862M24P05	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1862M24P05	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1862M24P05	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1862M24P05	SHROUD - HPT STATOR STG 1	CF6-80C2	OH	1
1862M61G04	SHROUD - LPT STATOR STG 1	CF6-80C2	OH	3
1862M61G04	SHROUD - LPT STATOR STG 1	CF6-80C2	OH	1
1862M61G07	SHROUD - LPT STG 1	CF6-80C2	OH	1
1862M61G07	SHROUD - LPT STG 1	CF6-80C2	OH	1
1862M61G07	SHROUD - LPT STG 1	CF6-80C2	OH	1
1862M61G07	SHROUD - LPT STG 1	CF6-80C2	OH	3
1862M61G07	SHROUD - LPT STG 1	CF6-80C2	OH	1
1862M61G07	SHROUD - LPT STG 1	CF6-80C2	OH	1
1862M62G01	SHROUD - LPT STG 2	CF6-80C2	OH	16
1862M62G01	SHROUD - LPT STG 2	CF6-80C2	OH	5
1862M62G02	SHROUD - LPT STG 2	CF6-80C2	OH	5
1862M69P02	SHAFT - MID FAN	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1862M72G03	BAFFLE - SHROUD STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
1862M78G01	PLUG - BRG NO. 6	CF6-80A	AR	1
1862M78G01	PLUG - BRG NO. 6	CF6-80A	AR	1
1862M78G01	PLUG - BRG NO. 6	CF6-80A	AR	1
1862M79G01	TUBE - CTR VENT FLAME	CF6-80A	AR	1
1862M79G01	TUBE - CTR VENT FLAME	CF6-80A	AR	1
1862M79G01	TUBE - CTR VENT FLAME	CF6-80A	AR	1
1862M79G01	TUBE - CTR VENT FLAME	CF6-80A	AR	1
1862M81G02	SUPPORT - HPT STTR	CF6-80C2	OH	1
1863M36G06	HPT ROTOR DISK STG 1 [R88DT]	CF6-80C2	AR	1
1866M20P01	TUBE - SPHERICAL	CF6-80C2	SV	1
1866M33P01	KIT - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
1872M16G02	TUBE - FUEL MANF DRAIN	CF6-80C2	AR	1
1872M21G04	DUCT - AIR WYE	CF6-80C2	AR	1
1872M22G04	DUCT - AIR WYE	CF6-80C2	AR	1
1872M22G04	DUCT - AIR WYE	CF6-80C2	AR	1
1872M58G01	TUBE - FUEL MANF DR	CF6-80C2	NE	1
1872M79G01	BRACKET - SUPPORT	CF6-80C2	AR	1
1872M79G01	BRACKET - SUPPORT	CF6-80C2	AR	1
1872M79G01	BRACKET - SUPPORT	CF6-80C2	OH	1
1872M81G01	TUBE - FUEL (MEC-PUMP)	CF6-80C2	AR	1
1872M81G01	TUBE - FUEL (MEC-PUMP)	CF6-80C2	SV	1
1872M82G01	TUBE - FUEL PUMP (TO MEC)	CF6-80C2	AR	1
1872M82G01	TUBE - FUEL PUMP (TO MEC)	CF6-80C2	SV	1
1872M86P03	MANIFOLD - COOLING LPT	CF6-80C2	AR	1
1872M86P04	MANIFOLD - COOLING LPT	CF6-80C2	AR	1
1872M87G01	BRACKET - ELECTRIC	CF6-80C2	SV	1
1872M88G01	BRACKET - SUPPORT	CF6-80C2	OH	1
1872M94P01	HOSE ASSY	CF6-80C2	SV	1
1881M20G38	NOZZLE - HPT STG 1	CF6-80C2	OH	1
1881M20G39	NOZZLE - HPT STG 1	CF6-80C2	OH	1
1881M20G39	NOZZLE - HPT STG 1	CF6-80C2	OH	1
1881M20G39	NOZZLE - HPT STG 1	CF6-80C2	OH	1
1881M20G39	NOZZLE - HPT STG 1	CF6-80C2	OH	1
1881M20G39	NOZZLE - HPT STG 1	CF6-80C2	OH	1
1881M20G39	NOZZLE - HPT STG 1	CF6-80C2	OH	1
1881M20G39	NOZZLE - HPT STG 1	CF6-80C2	OH	1
1881M85P01	DAMPER - HPTR STG 2 BLADE	CF6-80C2	OH	56
1881M85P02	HPT ROTOR DAMPER SEAL STG 2	CF6-80C2	NE	27
1881M85P02	HPT ROTOR DAMPER SEAL STG 2	CF6-80C2	NE	4

Part Number	Part Description	Engine Type	Condition	Quantity
1881M85P02	HPT ROTOR DAMPER SEAL STG 2	CF6-80C2	NE	32
1881M85P02	HPT ROTOR DAMPER SEAL STG 2	CF6-80C2	NE	25
1881M85P02	HPT ROTOR DAMPER SEAL STG 2	CF6-80C2	NE	64
1883M25G03	TUBE - AIR CURT	CF6-80C2	AR	1
1883M41G01	MANIFOLD - COOLING LPT	CF6-80C2	OH	1
1883M60G01	SHIELD - SPRAY	CF6-80C2	AR	1
1883M60G01	SHIELD - SPRAY	CF6-80C2	AR	1
1883M61G01	BRACKET - SUPPORT	CF6-80C2	AR	1
1883M91P001A	BRACKET	CF6-80C2	SV	1
1883M97P001A	BRACKET - ELECTRICAL	CF6-80C2	NS	1
1883M97P001A	BRACKET - ELECTRICAL	CF6-80C2	NS	3
1883M97P001A	BRACKET - ELECTRICAL	CF6-80C2	SV	1
1883M99P001A	SHIELD - FIRE	CF6-80C2	NE	1
1884M93G01	TUBE - OIL RETU	CF6-80C2	NE	1
1885M12G01	BRACKET - ELECTRIC	CF6-80C2	SV	1
1885M17G01	BRACKET - SUPPORT	CF6-80C2	SV	1
1885M19G01	BRACKET - ELECTRIC	CF6-80C2	SV	1
1885M19G01	BRACKET - ELECTRIC	CF6-80C2	SV	1
1885M20G01	BRACKET - ELECTRIC	CF6-80C2	SV	1
1885M20G01	BRACKET - ELECTRIC	CF6-80C2	SV	1
1885M22G01	TUBE - AIR STG 11 LOWER R/S	CF6-80C2	OH	1
1885M23G01	TUBE - AIR STG 11 UPPER L/S	CF6-80C2	AR	1
1885M24G01	TUBE - AIR STG 11 LOWER L/S	CF6-80C2	OH	1
1885M24G01	TUBE - AIR STG 11 LOWER L/S	CF6-80C2	OH	1
1885M32G01	TUBE - D OIL SCAV FWD	CF6-80C2	NS	1
1885M32G02	TUBE - D OIL SCAV FWD	CF6-80C2	AR	1
1885M47G01	BRACKET - IDG BASE	CF6-80C2	AR	1
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	AR	24
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	AR	24
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	SV	1
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	SV	20
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	SV	2
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	AR	24
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	OH	10

Part Number	Part Description	Engine Type	Condition	Quantity
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	OH	1
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	OH	21
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	SV	19
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	OH	9
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	OH	15
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	OH	16
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	OH	2
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	OH	23
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	OH	1
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	OH	2
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	OH	1
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	NS	3
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	SV	20
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	OH	2
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	AR	21
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	OH	2
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	OH	1
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	SV	1
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	OH	1
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	OH	1
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	OH	1
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	SV	24
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	OH	3
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	AR	3
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	SV	10

Part Number	Part Description	Engine Type	Condition	Quantity
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	OH	1
1885M63G02	BRACKET - FRICTION DAMPER	CF6-80C2	NS	1
1885M68G01	BRACKET - SPRT STG 11	CF6-80C2	SV	1
1885M84G01	MANIFOLD - FUEL	CF6-80C2	NS	1
1885M86G01	TUBE - LWR H/X TO OIL TANK	CF6-80C2	OH	1
1885M87G01	TUBE - IDG OIL COOLER	CF6-80C2	NE	1
1885M93G01	BRACKET - SUPPORT	CF6-80C2	NS	1
1885M98G01	BRACKET - ELECTRIC	CF6-80C2	NE	1
1957M35P01	HPT ROTOR DAMPER SEAL BODY STG 2	CF6-80C2	OH	7
1957M35P01	HPT ROTOR DAMPER SEAL BODY STG 2	CF6-80C2	OH	1
1957M35P02	HPT ROTOR DAMPER SEAL BODY STG 2 [WEIGHTED]	CF6-80C2	OH	4
1957M35P02	HPT ROTOR DAMPER SEAL BODY STG 2 [WEIGHTED]	CF6-80C2	OH	1
1957M35P02	HPT ROTOR DAMPER SEAL BODY STG 2 [WEIGHTED]	CF6-80C2	OH	1
1957M35P03	HPT ROTOR DAMPER SEAL BODY STG 2	CF6-80C2	OH	4
1957M35P04	HPT ROTOR DAMPER SEAL BODY STG 2 [WEIGHTED]	CF6-80C2	OH	6
1957M35P04	HPT ROTOR DAMPER SEAL BODY STG 2 [WEIGHTED]	CF6-80C2	OH	4
1957M35P04	HPT ROTOR DAMPER SEAL BODY STG 2 [WEIGHTED]	CF6-80C2	OH	6
1957M35P04	HPT ROTOR DAMPER SEAL BODY STG 2 [WEIGHTED]	CF6-80C2	OH	54
1957M35P04	HPT ROTOR DAMPER SEAL BODY STG 2 [WEIGHTED]	CF6-80C2	OH	2
1957M35P04	HPT ROTOR DAMPER SEAL BODY STG 2 [WEIGHTED]	CF6-80C2	OH	1
1957M35P04	HPT ROTOR DAMPER SEAL BODY STG 2 [WEIGHTED]	CF6-80C2	OH	1
1957M35P05	HPT ROTOR DAMPER SEAL BODY STG 2	CF6-80C2	OH	69
1957M35P05	HPT ROTOR DAMPER SEAL BODY STG 2	CF6-80C2	NE	26
1957M35P05	HPT ROTOR DAMPER SEAL BODY STG 2	CF6-80C2	NE	48
1957M35P06	HPT ROTOR DAMPER SEAL BODY STG 2 [WEIGHTED]	CF6-80C2	OH	1
1957M35P06	HPT ROTOR DAMPER SEAL BODY STG 2 [WEIGHTED]	CF6-80C2	OH	1
1957M35P06	HPT ROTOR DAMPER SEAL BODY STG 2 [WEIGHTED]	CF6-80C2	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
1957M35P06	HPT ROTOR DAMPER SEAL BODY STG 2 [WEIGHTED]	CF6-80C2	OH	1
1957M35P06	HPT ROTOR DAMPER SEAL BODY STG 2 [WEIGHTED]	CF6-80C2	OH	6
1957M35P06	HPT ROTOR DAMPER SEAL BODY STG 2 [WEIGHTED]	CF6-80C2	OH	4
1957M35P06	HPT ROTOR DAMPER SEAL BODY STG 2 [WEIGHTED]	CF6-80C2	OH	2
1957M35P06	HPT ROTOR DAMPER SEAL BODY STG 2 [WEIGHTED]	CF6-80C2	OH	3
1960M29P01	HOUSING - CARBON SEAL	CF6-80A	AR	1
1962M44P01	BEARING - NO. 5 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1962M46P01	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1962M46P01	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1962M50P01	BEARING - DX THR BALL	CF6-50 (LMCO)	SV	1
1962M51P01	BEARING - CYL ROLLER	CF6-80A	AR	1
1962M51P01	BEARING - CYL ROLLER	CF6-80A	AR	1
1962M51P01	BEARING - CYL ROLLER	CF6-80A	SV	1
1962M51P01	BEARING - CYL ROLLER	CF6-80A	SV	1
1962M51P01	BEARING - CYL ROLLER	CF6-80A	AR	1
1962M52P01	BEARING - CYL ROLLER	CF6-50 (LMCO)	AR	1
1962M52P01	BEARING - CYL ROLLER	CF6-50 (LMCO)	AR	1
1962M52P01	BEARING - CYL ROLLER	CF6-50 (LMCO)	AR	1
1962M52P01	BEARING - CYL ROLLER	CF6-50 (LMCO)	AR	1
1962M58P01	BEARING - DX THR BALL	CF6-80A, CF6-50	AR	1
1962M58P01	BEARING - DX THR BALL	CF6-80A, CF6-50	AR	1
1962M58P01	BEARING - DX THR BALL	CF6-80A, CF6-50	AR	1
1967M29G01	LPT STATOR COOLING MANIFOLD BRACKET	CF6-80C2	OH	5
1967M29G01	LPT STATOR COOLING MANIFOLD BRACKET	CF6-80C2	SV	3
1967M32G01	BRACKET - B SUMP VENT	CF6-80C2	AR	1
1967M32G01	BRACKET - B SUMP VENT	CF6-80C2	NE	1
1967M32G01	BRACKET - B SUMP VENT	CF6-80C2	NE	1
1967M32G01	BRACKET - B SUMP VENT	CF6-80C2	SV	1
1967M33G01	DUCT - AIR LP RECOUP AFT	CF6-80C2	OH	1
1967M33G01	DUCT - AIR LP RECOUP AFT	CF6-80C2	OH	1
1967M33G01	DUCT - AIR LP RECOUP AFT	CF6-80C2	OH	1
1967M37G01	SHROUD - FUEL	CF6-80C2	OH	15
1967M37G01	SHROUD - FUEL	CF6-80C2	OH	15
1967M37G01	SHROUD - FUEL	CF6-80C2	OH	15
1967M74G01	PLATE - BASE	CF6-80C2	SV	2

Part Number	Part Description	Engine Type	Condition	Quantity
1968M49P13	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P13	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P13	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P13	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P13	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P13	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P13	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P13	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P13	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P13	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P13	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P13	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P13	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P13	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P13	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P13	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P13	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P13	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P13	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P13	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P13	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P13	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P13	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P14	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P14	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P14	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P14	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P14	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P14	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P14	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P14	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P14	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P14	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P15	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P16	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P16	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P16	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P16	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P16	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P16	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P16	NOZZLE - FUEL	CF6-80A	SV	1
1968M49P16	NOZZLE - FUEL	CF6-80A	SV	1
1968M71G12	DOME - COMB CHAMBER	CF6-80C2	AR	1
1968M97P01	RETAINER - SWIRLER	CF6-80A	NE	60
1968M98G18	DOME - COMB CHAMBER	CF6-80A	AR	1
1977M15G01	BACKET - CCC MANIFOLD	CF6-80C2	NS	1
1977M17P001A	BACKET - TUBE HOSE	CF6-80C2	SV	1
1977M20G01	SHIELD - SPRAY	CF6-80C2	NS	1
1977M27P001A	BACKET - SUPPORT	CF6-80C2	NE	8
1977M27P001A	BACKET - SUPPORT	CF6-80C2	NE	2
1977M27P001A	BACKET - SUPPORT	CF6-80C2	AR	1
1977M28G01	BACKET - LINK SUPPORT	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
1977M61P01	BRACKET - SUPPORT (SPD)	CF6-80C2	NE	1
1977M61P01	BRACKET - SUPPORT (SPD)	CF6-80C2	NE	1
1977M71G01	TUBE - LP RECOUP	CF6-80C2	OH	1
1977M79G01	BRACKET	CF6-80C2	NE	1
1977M79G01	BRACKET	CF6-80C2	SV	1
1977M90G01	BRACKET - SUPPORT	CF6-80C2	NE	1
1977M90G01	BRACKET - SUPPORT	CF6-80C2	SV	1
1977M90G01	BRACKET - SUPPORT	CF6-80C2	SV	1
1978M22G01	BRACKET - ELECTRIC	CF6-80C2	NE	1
1978M23G01	BRACKET - ELECTRIC	CF6-80C2	NE	1
1978M68G01	BRACKET - ANGLE	CF6-80C2	NE	1
1978M82G01	BRACKET - SUPPORT	CF6-80C2	SV	1
1978M84G01	BRACKET - SUPPORT	CF6-80C2	AR	1
1978M84G01	BRACKET - SUPPORT	CF6-80C2	SV	1
1978M84G01	BRACKET - SUPPORT	CF6-80C2	NE	1
1978M84G01	BRACKET - SUPPORT	CF6-80C2	NE	1
1978M85P01	ROD END	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
1978M85P01	ROD END	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
1978M85P01	ROD END	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
1978M91G01	BRACKET ASSY - VENT/DR PYLON	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1978M94G01	BRACKET	CF6-80C2	AR	1
1978M95P001A	BRACKET	CF6-80C2	NE	1
1978M95P001A	BRACKET	CF6-80C2	NE	14
1990M30G01	TUBE - OIL 4 + 5 BRG	CF6-80C2	AR	1
1990M36P02	TURNBUCKLE - 14TH STAGE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
1990M36P02	TURNBUCKLE - 14TH STAGE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1990M36P02	TURNBUCKLE - 14TH STAGE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
1990M37G01	BRACKET - SUPPORT FIRE	CF6-80C2	NE	1
1990M75G02	MANIFOLD ASSY - STG 14 RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1990M75G02	MANIFOLD ASSY - STG 14 RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1990M75G02	MANIFOLD ASSY - STG 14 RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1990M75G02	MANIFOLD ASSY - STG 14 RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1990M75G02	MANIFOLD ASSY - STG 14 RH	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1990M75G02	MANIFOLD ASSY - STG 14 RH	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1990M75G02	MANIFOLD ASSY - STG 14 RH	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
1990M75G02	MANIFOLD ASSY - STG 14 RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1990M75G02	MANIFOLD ASSY - STG 14 RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1990M75G02	MANIFOLD ASSY - STG 14 RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1990M75G02	MANIFOLD ASSY - STG 14 RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1990M75G02	MANIFOLD ASSY - STG 14 RH	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1990M75G02	MANIFOLD ASSY - STG 14 RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1990M75G02	MANIFOLD ASSY - STG 14 RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1990M75G02	MANIFOLD ASSY - STG 14 RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1990M84G01	LINK - TURNBUCKLE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1990M84G01	LINK - TURNBUCKLE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
1990M84G01	LINK - TURNBUCKLE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
1990M84G03	LINK - TURNBUCKLE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1990M84G03	LINK - TURNBUCKLE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1990M84G03	LINK - TURNBUCKLE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1990M84G03	LINK - TURNBUCKLE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
1990M84G05	LINK - TURNBUCKLE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1990M84G05	LINK - TURNBUCKLE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
1990M84G06	LINK - TURNBUCKLE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
1990M84G06	LINK - TURNBUCKLE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
1990M84G06	LINK - TURNBUCKLE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
1990M84G06	LINK - TURNBUCKLE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
1990M84G06	LINK - TURNBUCKLE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
1990M84G06	LINK - TURNBUCKLE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1990M84G07	LINK - TURNBUCKLE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
1990M84G07	LINK - TURNBUCKLE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
1990M84G07	LINK - TURNBUCKLE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
1990M84G07	LINK - TURNBUCKLE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
1990M84G07	LINK - TURNBUCKLE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
1990M84G07	LINK - TURNBUCKLE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1990M84G07	LINK - TURNBUCKLE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
1990M84G08	LINK - TURNBUCKLE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1990M84G08	LINK - TURNBUCKLE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1990M84G08	LINK - TURNBUCKLE	CF6-50 (LMCO), CF6-50 (Boeing)	NE	3
1990M88P01	BRACKET - TUBE CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1990M88P01	BRACKET - TUBE CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1990M89P01	BRACKET - TUBE CDP 16TH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1990M89P01	BRACKET - TUBE CDP 16TH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1990M93G01	TUBE - AIR PS3 CORE AFT	CF6-80C2	AR	1
1990M93G01	TUBE - AIR PS3 CORE AFT	CF6-80C2	AR	1
1990M93G01	TUBE - AIR PS3 CORE AFT	CF6-80C2	AR	1
1991M12P01	MANIFOLD - LPT COOLING	CF6-50 (LMCO)	AR	1
1991M12P01	MANIFOLD - LPT COOLING	CF6-50 (LMCO)	AR	1
1991M13P01	MANIFOLD ASSY - LP COOLING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1991M15P01	BRACKET - FLANGE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1991M16P01	BRACKET - FLANGE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1991M16P02	BRACKET - FLANGE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
1991M25G01	BRACKET - TUBE	CF6-50 (LMCO)	AR	1
1991M26G01	BRACKET	CF6-80C2	AR	1
1991M26G01	BRACKET	CF6-80C2	AR	1
1991M27P01	BRACKET	CF6-80C2	AR	1
1991M34G01	DUCT - AIR	CF6-80C2	AR	1
1991M37G01	BRACKET - ELEC SPRT	CF6-80C2	NS	1
1991M37G01	BRACKET - ELEC SPRT	CF6-80C2	SV	1
1991M52G01	BRACKET - TUBE	CF6-50 (LMCO)	AR	1
1996M14G01	TUBE - FUEL PUMP DRAIN	CF6-80C2	AR	1
1996M16G01	TUBE - OIL HYDR DRAIN UPR	CF6-80C2	OH	1
1996M17G01	TUBE - LWR SCUPPER DRN	CF6-80C2	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
1996M23G01	MANIFOLD - T2 DRAIN	CF6-80C2	NE	1
1996M24G01	TUBE - DR FUEL	CF6-80C2	AR	1
1996M37G01	TUBE - FUEL PUMP DRAIN	CF6-80C2	AR	1
1996M38G01	TUBE - OIL IDG	CF6-80C2	AR	1
1997M23G01	MANIFOLD - FUEL INNER	CF6-80C2	NS	1
1997M28P01	MANIFOLD - COOLING LPT	CF6-80A	OH	1
1997M29P01	MANIFOLD - COOLING LPT	CF6-80A	OH	1
1997M29P01	MANIFOLD - COOLING LPT	CF6-80A	AR	1
1997M29P01	MANIFOLD - COOLING LPT	CF6-80A	OH	1
1997M29P01	MANIFOLD - COOLING LPT	CF6-80A	OH	1
1997M29P01	MANIFOLD - COOLING LPT	CF6-80A	AR	1
1997M29P01	MANIFOLD - COOLING LPT	CF6-80A	OH	1
1997M29P01	MANIFOLD - COOLING LPT	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	AR	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	AR	2
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	AR	8
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	AR	9
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	AR	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	AR	10
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	AR	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	AR	8
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	AR	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M32G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
1998M69G01	BRACKET - ELECTRIC	CF6-80C2	NE	1
1998M69G01	BRACKET - ELECTRIC	CF6-80C2	SV	1
1998M73G01	TUBE - AIR LPT CLG LS	CF6-80C2	AR	1
1999M13P01	CLEVIS - ACTN COMPR STTR	CF6-80C2	AR	2
1999M13P01	CLEVIS - ACTN COMPR STTR	CF6-80C2	AR	1
1999M13P01	CLEVIS - ACTN COMPR STTR	CF6-80C2	AR	2
1999M13P01	CLEVIS - ACTN COMPR STTR	CF6-80C2	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
1999M21P02	RETAINER - RING	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
1999M21P02	RETAINER - RING	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
1999M21P02	RETAINER - RING	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
1999M21P02	RETAINER - RING	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
1999M21P02	RETAINER - RING	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
1999M21P02	RETAINER - RING	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
1999M22P01	SEAL - RING	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
1999M22P01	SEAL - RING	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
1999M24P01	SPOOL/SHAFT - STG 11-14	CF6-50 (LMCO)	AR	1
1999M24P02	SPOOL/SHAFT - STG 11-14	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
1999M25P07	SHAFT ASSY - REAR CPRSR	CF6-50	AR	1
1999M84P03	DISK - FAN STG 1	CF6-80C2	OH	1
1A1869	PLUG - MAG MACH THD	CF6-80C2	AR	1
2020M69G01	TUBE - PYLON DRAIN FUEL	CF6-80C2	NS	1
2020M72G01	BRACKET - TUBE SUPPORT	CF6-80C2	NE	1
2020M72G01	BRACKET - TUBE SUPPORT	CF6-80C2	NE	3
2021M20P001A	BRACKET - AIR CURTAIN	CF6-80C2	NE	1
2021M20P001A	BRACKET - AIR CURTAIN	CF6-80C2	NE	3
2021M40G01	BRACKET - EBU	CF6-80C2	NS	1
2021M83G01	BRACKET	CF6-80C2	AR	1
2023M27G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
2023M27G01	MANIFOLD - SHROUDED FUEL	CF6-80A	AR	1
2023M27G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
2023M27G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
2023M27G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
2023M27G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
2023M27G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
2023M27G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
2023M27G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
2023M27G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
2023M27G01	MANIFOLD - SHROUDED FUEL	CF6-80A	OH	1
2032M65P01	LUG - LKG STG 10	CF6-50 (LMCO)	AR	6
2032M65P01	LUG - LKG STG 10	CF6-50 (LMCO)	AR	10
2032M65P01	LUG - LKG STG 10	CF6-50 (LMCO)	OH	2
2032M66G01	HPC ROTOR LOCK LUG ASSY STG 10-14	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M66G01	HPC ROTOR LOCK LUG ASSY STG 10-14	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M66G01	HPC ROTOR LOCK LUG ASSY STG 10-14	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
2032M66G01	HPC ROTOR LOCK LUG ASSY STG 10-14	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M66G01	HPC ROTOR LOCK LUG ASSY STG 10-14	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
2032M66G01	HPC ROTOR LOCK LUG ASSY STG 10-14	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
2032M66G01	HPC ROTOR LOCK LUG ASSY STG 10-14	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	8
2032M66G01	HPC ROTOR LOCK LUG ASSY STG 10-14	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	NS	8
2032M66G01	HPC ROTOR LOCK LUG ASSY STG 10-14	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	NS	40
2032M90P02	LUG ASSY - STG 4 LKG	CF6-80C2, CF6-80A	OH	1
2032M90P02	LUG ASSY - STG 4 LKG	CF6-80C2, CF6-80A	OH	2
2032M90P02	LUG ASSY - STG 4 LKG	CF6-80C2, CF6-80A	OH	2
2032M90P03	LUG ASSY - STG 5 LKG	CF6-80C2	AR	2
2032M90P03	LUG ASSY - STG 5 LKG	CF6-80C2	OH	1
2032M90P03	LUG ASSY - STG 5 LKG	CF6-80C2	OH	2
2032M90P03	LUG ASSY - STG 5 LKG	CF6-80C2	OH	2
2032M90P08	LUG ASSY - STG 6 LKG	CF6-80C2	AR	3
2032M90P08	LUG ASSY - STG 6 LKG	CF6-80C2	OH	3
2032M90P09	LUG ASSY - STG 7 LKG	CF6-80C2	AR	3
2032M90P10	LUG ASSY - STG 8 LKG	CF6-80C2	AR	3
2032M90P10	LUG ASSY - STG 8 LKG	CF6-80C2	OH	3

Part Number	Part Description	Engine Type	Condition	Quantity
2032M90P11	LUG ASSY - STG 9 LKG	CF6-80C2	AR	3
2032M90P11	LUG ASSY - STG 9 LKG	CF6-80C2	OH	1
2032M95G01	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
2032M95G01	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
2032M95G01	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G01	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G01	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G01	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G01	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
2032M95G01	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G01	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G01	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
2032M95G01	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
2032M95G01	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
2032M95G01	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
2032M95G01	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G01	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
2032M95G02	LUG ASSY - BL LKG STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G02	LUG ASSY - BL LKG STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
2032M95G02	LUG ASSY - BL LKG STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G02	LUG ASSY - BL LKG STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G02	LUG ASSY - BL LKG STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
2032M95G02	LUG ASSY - BL LKG STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G02	LUG ASSY - BL LKG STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
2032M95G02	LUG ASSY - BL LKG STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
2032M95G02	LUG ASSY - BL LKG STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
2032M95G02	LUG ASSY - BL LKG STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
2032M95G02	LUG ASSY - BL LKG STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G02	LUG ASSY - BL LKG STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
2032M95G02	LUG ASSY - BL LKG STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
2032M95G02	LUG ASSY - BL LKG STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G02	LUG ASSY - BL LKG STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G02	LUG ASSY - BL LKG STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G02	LUG ASSY - BL LKG STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
2032M95G02	LUG ASSY - BL LKG STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2

Part Number	Part Description	Engine Type	Condition	Quantity
2032M95G02	LUG ASSY - BL LKG STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
2032M95G03	LUG ASSY - BL LKG STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
2032M95G03	LUG ASSY - BL LKG STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G03	LUG ASSY - BL LKG STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G03	LUG ASSY - BL LKG STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G03	LUG ASSY - BL LKG STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G03	LUG ASSY - BL LKG STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G03	LUG ASSY - BL LKG STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G03	LUG ASSY - BL LKG STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G03	LUG ASSY - BL LKG STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G03	LUG ASSY - BL LKG STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
2032M95G03	LUG ASSY - BL LKG STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
2032M95G03	LUG ASSY - BL LKG STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
2032M95G03	LUG ASSY - BL LKG STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G03	LUG ASSY - BL LKG STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
2032M95G04	LUG ASSY - BL LKG STG 6	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G04	LUG ASSY - BL LKG STG 6	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3

Part Number	Part Description	Engine Type	Condition	Quantity
2032M95G04	LUG ASSY - BL LKG STG 6	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G04	LUG ASSY - BL LKG STG 6	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
2032M95G04	LUG ASSY - BL LKG STG 6	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
2032M95G04	LUG ASSY - BL LKG STG 6	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
2032M95G04	LUG ASSY - BL LKG STG 6	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G04	LUG ASSY - BL LKG STG 6	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
2032M95G04	LUG ASSY - BL LKG STG 6	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
2032M95G04	LUG ASSY - BL LKG STG 6	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
2032M95G04	LUG ASSY - BL LKG STG 6	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G04	LUG ASSY - BL LKG STG 6	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G04	LUG ASSY - BL LKG STG 6	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G04	LUG ASSY - BL LKG STG 6	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
2032M95G04	LUG ASSY - BL LKG STG 6	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
2032M95G04	LUG ASSY - BL LKG STG 6	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
2032M95G04	LUG ASSY - BL LKG STG 6	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
2032M95G04	LUG ASSY - BL LKG STG 6	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3

Part Number	Part Description	Engine Type	Condition	Quantity
2032M95G04	LUG ASSY - BL LKG STG 6	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	4
2032M95G04	LUG ASSY - BL LKG STG 6	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	3
2032M95G05	LUG ASSY - BL LKG STG 7	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
2032M95G05	LUG ASSY - BL LKG STG 7	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
2032M95G05	LUG ASSY - BL LKG STG 7	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
2032M95G05	LUG ASSY - BL LKG STG 7	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
2032M95G05	LUG ASSY - BL LKG STG 7	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
2032M95G05	LUG ASSY - BL LKG STG 7	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
2032M95G05	LUG ASSY - BL LKG STG 7	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G05	LUG ASSY - BL LKG STG 7	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G05	LUG ASSY - BL LKG STG 7	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
2032M95G05	LUG ASSY - BL LKG STG 7	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
2032M95G05	LUG ASSY - BL LKG STG 7	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
2032M95G05	LUG ASSY - BL LKG STG 7	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
2032M95G05	LUG ASSY - BL LKG STG 7	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G05	LUG ASSY - BL LKG STG 7	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3

Part Number	Part Description	Engine Type	Condition	Quantity
2032M95G05	LUG ASSY - BL LKG STG 7	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
2032M95G05	LUG ASSY - BL LKG STG 7	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
2032M95G06	LUG ASSY - BL LKG STG 8	CF6-50 (LMCO)	OH	1
2032M95G06	LUG ASSY - BL LKG STG 8	CF6-50 (LMCO)	OH	3
2032M95G06	LUG ASSY - BL LKG STG 8	CF6-50 (LMCO)	OH	3
2032M95G06	LUG ASSY - BL LKG STG 8	CF6-50 (LMCO)	OH	3
2032M95G06	LUG ASSY - BL LKG STG 8	CF6-50 (LMCO)	OH	3
2032M95G06	LUG ASSY - BL LKG STG 8	CF6-50 (LMCO)	OH	3
2032M95G06	LUG ASSY - BL LKG STG 8	CF6-50 (LMCO)	OH	3
2032M95G06	LUG ASSY - BL LKG STG 8	CF6-50 (LMCO)	OH	3
2032M95G06	LUG ASSY - BL LKG STG 8	CF6-50 (LMCO)	OH	3
2032M95G06	LUG ASSY - BL LKG STG 8	CF6-50 (LMCO)	OH	1
2032M95G06	LUG ASSY - BL LKG STG 8	CF6-50 (LMCO)	OH	1
2032M95G06	LUG ASSY - BL LKG STG 8	CF6-50 (LMCO)	OH	1
2032M95G06	LUG ASSY - BL LKG STG 8	CF6-50 (LMCO)	OH	3
2032M95G06	LUG ASSY - BL LKG STG 8	CF6-50 (LMCO)	OH	3
2032M95G06	LUG ASSY - BL LKG STG 8	CF6-50 (LMCO)	OH	3
2032M95G06	LUG ASSY - BL LKG STG 8	CF6-50 (LMCO)	OH	2
2032M95G06	LUG ASSY - BL LKG STG 8	CF6-50 (LMCO)	OH	3
2032M95G07	LUG ASSY - BL LKG STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
2032M95G07	LUG ASSY - BL LKG STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G07	LUG ASSY - BL LKG STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
2032M95G07	LUG ASSY - BL LKG STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2032M95G07	LUG ASSY - BL LKG STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
2032M95G07	LUG ASSY - BL LKG STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
2032M95G08	HPC ROTOR LOCK LUG ASSY STG 6	CF6-80C2	OH	2
2032M95G08	HPC ROTOR LOCK LUG ASSY STG 6	CF6-80C2	OH	2
2032M95G08	HPC ROTOR LOCK LUG ASSY STG 6	CF6-80C2	OH	3
2032M95G08	HPC ROTOR LOCK LUG ASSY STG 6	CF6-80C2	OH	3

Part Number	Part Description	Engine Type	Condition	Quantity
2032M95G08	HPC ROTOR LOCK LUG ASSY STG 6	CF6-80C2	OH	2
2032M95G08	HPC ROTOR LOCK LUG ASSY STG 6	CF6-80C2	OH	3
2032M95G08	HPC ROTOR LOCK LUG ASSY STG 6	CF6-80C2	OH	3
2032M95G08	HPC ROTOR LOCK LUG ASSY STG 6	CF6-80C2	OH	3
2032M95G08	HPC ROTOR LOCK LUG ASSY STG 6	CF6-80C2	OH	3
2032M95G08	HPC ROTOR LOCK LUG ASSY STG 6	CF6-80C2	OH	3
2032M95G08	HPC ROTOR LOCK LUG ASSY STG 6	CF6-80C2	OH	2
2032M95G08	HPC ROTOR LOCK LUG ASSY STG 6	CF6-80C2	OH	3
2032M95G09	HPC ROTOR LOCK LUG ASSY STG 7	CF6-80C2	OH	1
2032M95G09	HPC ROTOR LOCK LUG ASSY STG 7	CF6-80C2	OH	3
2032M95G09	HPC ROTOR LOCK LUG ASSY STG 7	CF6-80C2	OH	3
2032M95G09	HPC ROTOR LOCK LUG ASSY STG 7	CF6-80C2	OH	3
2032M95G09	HPC ROTOR LOCK LUG ASSY STG 7	CF6-80C2	OH	3
2032M95G09	HPC ROTOR LOCK LUG ASSY STG 7	CF6-80C2	OH	2
2032M95G09	HPC ROTOR LOCK LUG ASSY STG 7	CF6-80C2	OH	1
2032M95G09	HPC ROTOR LOCK LUG ASSY STG 7	CF6-80C2	OH	3
2032M95G09	HPC ROTOR LOCK LUG ASSY STG 7	CF6-80C2	OH	3
2032M95G09	HPC ROTOR LOCK LUG ASSY STG 7	CF6-80C2	OH	3
2032M95G09	HPC ROTOR LOCK LUG ASSY STG 7	CF6-80C2	OH	2
2032M95G09	HPC ROTOR LOCK LUG ASSY STG 7	CF6-80C2	OH	3
2032M95G09	HPC ROTOR LOCK LUG ASSY STG 7	CF6-80C2	OH	3
2032M95G09	HPC ROTOR LOCK LUG ASSY STG 7	CF6-80C2	OH	3
2032M95G09	HPC ROTOR LOCK LUG ASSY STG 7	CF6-80C2	OH	1
2032M95G09	HPC ROTOR LOCK LUG ASSY STG 7	CF6-80C2	OH	3
2032M95G09	HPC ROTOR LOCK LUG ASSY STG 7	CF6-80C2	NS	2

Part Number	Part Description	Engine Type	Condition	Quantity
2032M95G09	HPC ROTOR LOCK LUG ASSY STG 7	CF6-80C2	NS	6
2032M95G10	HPC ROTOR LOCK LUG ASSY STG 8	CF6-80C2	OH	2
2032M95G10	HPC ROTOR LOCK LUG ASSY STG 8	CF6-80C2	OH	2
2032M95G10	HPC ROTOR LOCK LUG ASSY STG 8	CF6-80C2	OH	3
2032M95G10	HPC ROTOR LOCK LUG ASSY STG 8	CF6-80C2	OH	2
2032M95G10	HPC ROTOR LOCK LUG ASSY STG 8	CF6-80C2	OH	3
2032M95G10	HPC ROTOR LOCK LUG ASSY STG 8	CF6-80C2	OH	2
2032M95G10	HPC ROTOR LOCK LUG ASSY STG 8	CF6-80C2	NS	3
2032M95G10	HPC ROTOR LOCK LUG ASSY STG 8	CF6-80C2	NS	9
2032M95G10	HPC ROTOR LOCK LUG ASSY STG 8	CF6-80C2	OH	2
2032M95G10	HPC ROTOR LOCK LUG ASSY STG 8	CF6-80C2	OH	1
2032M95G10	HPC ROTOR LOCK LUG ASSY STG 8	CF6-80C2	OH	3
2032M95G10	HPC ROTOR LOCK LUG ASSY STG 8	CF6-80C2	OH	1
2032M95G10	HPC ROTOR LOCK LUG ASSY STG 8	CF6-80C2	OH	1
2032M95G10	HPC ROTOR LOCK LUG ASSY STG 8	CF6-80C2	OH	3
2032M95G10	HPC ROTOR LOCK LUG ASSY STG 8	CF6-80C2	OH	3
2032M95G10	HPC ROTOR LOCK LUG ASSY STG 8	CF6-80C2	OH	3
2032M95G10	HPC ROTOR LOCK LUG ASSY STG 8	CF6-80C2	OH	3
2032M95G10	HPC ROTOR LOCK LUG ASSY STG 8	CF6-80C2	OH	3
2032M95G10	HPC ROTOR LOCK LUG ASSY STG 8	CF6-80C2	OH	3
2032M95G10	HPC ROTOR LOCK LUG ASSY STG 8	CF6-80C2	OH	3
2032M95G10	HPC ROTOR LOCK LUG ASSY STG 8	CF6-80C2	OH	2
2032M95G10	HPC ROTOR LOCK LUG ASSY STG 8	CF6-80C2	OH	2
2032M95G11	HPC ROTOR LOCK LUG ASSY STG 9	CF6-80C2	OH	1
2032M95G11	HPC ROTOR LOCK LUG ASSY STG 9	CF6-80C2	OH	3
2032M95G11	HPC ROTOR LOCK LUG ASSY STG 9	CF6-80C2	OH	3

Part Number	Part Description	Engine Type	Condition	Quantity
2032M95G11	HPC ROTOR LOCK LUG ASSY STG 9	CF6-80C2	OH	3
2032M95G11	HPC ROTOR LOCK LUG ASSY STG 9	CF6-80C2	OH	2
2032M95G11	HPC ROTOR LOCK LUG ASSY STG 9	CF6-80C2	OH	1
2032M95G11	HPC ROTOR LOCK LUG ASSY STG 9	CF6-80C2	OH	1
2032M95G11	HPC ROTOR LOCK LUG ASSY STG 9	CF6-80C2	AR	2
2032M95G11	HPC ROTOR LOCK LUG ASSY STG 9	CF6-80C2	OH	3
2032M95G11	HPC ROTOR LOCK LUG ASSY STG 9	CF6-80C2	OH	3
2032M95G11	HPC ROTOR LOCK LUG ASSY STG 9	CF6-80C2	OH	3
2032M95G11	HPC ROTOR LOCK LUG ASSY STG 9	CF6-80C2	OH	3
2032M95G11	HPC ROTOR LOCK LUG ASSY STG 9	CF6-80C2	OH	2
2032M95G11	HPC ROTOR LOCK LUG ASSY STG 9	CF6-80C2	OH	3
2032M95G11	HPC ROTOR LOCK LUG ASSY STG 9	CF6-80C2	OH	3
2032M95G11	HPC ROTOR LOCK LUG ASSY STG 9	CF6-80C2	OH	3
2032M95G11	HPC ROTOR LOCK LUG ASSY STG 9	CF6-80C2	NS	3
2032M95G12	HPC ROTOR LOCK LUG ASSY STG 5	CF6-80C2	AR	2
2032M95G12	HPC ROTOR LOCK LUG ASSY STG 5	CF6-80C2	OH	1
2032M95G12	HPC ROTOR LOCK LUG ASSY STG 5	CF6-80C2	OH	1
2032M95G12	HPC ROTOR LOCK LUG ASSY STG 5	CF6-80C2	OH	2
2032M95G12	HPC ROTOR LOCK LUG ASSY STG 5	CF6-80C2	OH	2
2032M95G12	HPC ROTOR LOCK LUG ASSY STG 5	CF6-80C2	OH	2
2032M95G12	HPC ROTOR LOCK LUG ASSY STG 5	CF6-80C2	OH	1
2032M95G12	HPC ROTOR LOCK LUG ASSY STG 5	CF6-80C2	OH	2
2032M95G12	HPC ROTOR LOCK LUG ASSY STG 5	CF6-80C2	OH	2
2032M95G12	HPC ROTOR LOCK LUG ASSY STG 5	CF6-80C2	OH	2
2032M95G12	HPC ROTOR LOCK LUG ASSY STG 5	CF6-80C2	OH	2

Part Number	Part Description	Engine Type	Condition	Quantity
2032M95G12	HPC ROTOR LOCK LUG ASSY STG 5	CF6-80C2	OH	2
2032M95G12	HPC ROTOR LOCK LUG ASSY STG 5	CF6-80C2	OH	1
2032M95G12	HPC ROTOR LOCK LUG ASSY STG 5	CF6-80C2	OH	2
2032M95G12	HPC ROTOR LOCK LUG ASSY STG 5	CF6-80C2	OH	2
2032M95G12	HPC ROTOR LOCK LUG ASSY STG 5	CF6-80C2	OH	2
2032M95G12	HPC ROTOR LOCK LUG ASSY STG 5	CF6-80C2	OH	2
2032M95G12	HPC ROTOR LOCK LUG ASSY STG 5	CF6-80C2	OH	2
2032M95G12	HPC ROTOR LOCK LUG ASSY STG 5	CF6-80C2	OH	2
2032M95G12	HPC ROTOR LOCK LUG ASSY STG 5	CF6-80C2	OH	2
2032M95G12	HPC ROTOR LOCK LUG ASSY STG 5	CF6-80C2	NS	1
2032M95G12	HPC ROTOR LOCK LUG ASSY STG 5	CF6-80C2	NS	4
2032M95G13	HPC ROTOR LOCK LUG ASSY STG 4	CF6-80C2	OH	2
2032M95G13	HPC ROTOR LOCK LUG ASSY STG 4	CF6-80C2	OH	1
2032M95G13	HPC ROTOR LOCK LUG ASSY STG 4	CF6-80C2	OH	2
2032M95G13	HPC ROTOR LOCK LUG ASSY STG 4	CF6-80C2	OH	1
2032M95G13	HPC ROTOR LOCK LUG ASSY STG 4	CF6-80C2	OH	2
2032M95G13	HPC ROTOR LOCK LUG ASSY STG 4	CF6-80C2	OH	2
2032M95G13	HPC ROTOR LOCK LUG ASSY STG 4	CF6-80C2	OH	2
2032M95G13	HPC ROTOR LOCK LUG ASSY STG 4	CF6-80C2	OH	2
2032M95G13	HPC ROTOR LOCK LUG ASSY STG 4	CF6-80C2	OH	2
2032M95G13	HPC ROTOR LOCK LUG ASSY STG 4	CF6-80C2	OH	2
2032M95G13	HPC ROTOR LOCK LUG ASSY STG 4	CF6-80C2	OH	1
2032M95G13	HPC ROTOR LOCK LUG ASSY STG 4	CF6-80C2	NS	1
2032M95G13	HPC ROTOR LOCK LUG ASSY STG 4	CF6-80C2	NS	18

Part Number	Part Description	Engine Type	Condition	Quantity
2032M95G13	HPC ROTOR LOCK LUG ASSY STG 4	CF6-80C2	NS	2
2032M95G17	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80C2	OH	2
2032M95G17	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80C2	OH	2
2032M95G17	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80C2	OH	2
2032M95G17	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80C2	OH	1
2032M95G17	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80C2	OH	2
2032M95G17	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80C2	OH	1
2032M95G17	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80C2	OH	2
2032M95G17	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80C2	OH	2
2032M95G17	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80C2	OH	2
2032M95G17	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80C2	OH	2
2032M95G17	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80C2	OH	2
2032M95G17	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80C2	OH	1
2032M95G17	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80C2	OH	2
2032M95G17	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80C2	NS	2
2032M95G17	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80C2	NS	2
2032M95G18	HPC ROTOR LOCK LUG ASSY STG 6	CF6-80C2	OH	3
2032M95G18	HPC ROTOR LOCK LUG ASSY STG 6	CF6-80C2	OH	3
2032M95G18	HPC ROTOR LOCK LUG ASSY STG 6	CF6-80C2	OH	3
2032M95G18	HPC ROTOR LOCK LUG ASSY STG 6	CF6-80C2	OH	2
2032M95G18	HPC ROTOR LOCK LUG ASSY STG 6	CF6-80C2	OH	3
2032M95G18	HPC ROTOR LOCK LUG ASSY STG 6	CF6-80C2	OH	3
2032M95G18	HPC ROTOR LOCK LUG ASSY STG 6	CF6-80C2	OH	3
2032M95G18	HPC ROTOR LOCK LUG ASSY STG 6	CF6-80C2	OH	3
2032M95G18	HPC ROTOR LOCK LUG ASSY STG 6	CF6-80C2	OH	3

Part Number	Part Description	Engine Type	Condition	Quantity
2032M95G18	HPC ROTOR LOCK LUG ASSY STG 6	CF6-80C2	NE	4
2032M95G18	HPC ROTOR LOCK LUG ASSY STG 6	CF6-80C2	NE	3
2038M36G02	DUCT ASSY - HPC RTR AIR	CF6-50 (LMCO)	OH	1
2038M36G02	DUCT ASSY - HPC RTR AIR	CF6-50 (LMCO)	OH	1
2038M36G02	DUCT ASSY - HPC RTR AIR	CF6-50 (LMCO)	AR	1
2038M36G02	DUCT ASSY - HPC RTR AIR	CF6-50 (LMCO)	OH	1
2080M43P01	POWDER - PREFORMED (SPD)	CF6-80C2, CF6-80A	NE	193
2083M12G01	SHROUD - LPT STATOR STG 2	CF6-80C2	SV	13
2083M12G01	SHROUD - LPT STATOR STG 2	CF6-80C2	AR	16
2083M12G01	SHROUD - LPT STATOR STG 2	CF6-80C2	AR	16
2083M12G02	SHROUD - LPT STATOR STG 2	CF6-80C2	OH	16
2083M12G02	SHROUD - LPT STATOR STG 2	CF6-80C2	OH	4
2083M12G02	SHROUD - LPT STATOR STG 2	CF6-80C2	OH	16
2083M13G01	SHROUD - LPT STATOR STG 3	CF6-80C2	AR	20
2083M13G01	SHROUD - LPT STATOR STG 3	CF6-80C2	AR	20
2083M13G01	SHROUD - LPT STATOR STG 3	CF6-80C2	AR	20
2083M13G02	SHROUD - LPT STATOR STG 3	CF6-80C2	AR	11
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	20
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	AR	1
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	OH	10
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	OH	2
2083M14G01	SHROUD - LPT STATOR STG 4	CF6-80C2	OH	20
2083M27G09	CASE ASSY - LPT STTR	CF6-50	AR	1
2083M27G13	CASE ASSY - LPT STTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
2083M27G13	CASE ASSY - LPT STTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
2083M27G13	CASE ASSY - LPT STTR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2083M27G21	CASE ASSY - LPT STTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
2083M57G01	SHROUD - STG 1	CF6-80A	SV	2
2083M80G04	SUPPORT - HPT STATOR	CF6-80A	AR	1
2083M80G06	SUPPORT - HPT STATOR	CF6-80A	OH	1
2083M88P01	DEFLECTOR	CF6-80C2	AR	24
2083M92P01	PAD	CF6-80C2	NS	24
2083M94G07	CASE - LOW PRESSURE TURBINE	CF6-80C2	OH	1
2083M94G18	CASE - LOW PRESSURE TURBINE	CF6-80C2	OH	1
2083M94G23	CASE - LOW PRESSURE TURBINE	CF6-80C2	AR	1
2083M99P01	PLUG ASSY - BORESCOPE PORT	CF6-50 (Boeing)	AR	1
2084M34G03	NOZZLE - HPT STG 1	CF6-80A	AR	1
2084M46G01	NOZZLE - HPT STG 2	CF6-80A	OH	1
2084M46G01	NOZZLE - HPT STG 2	CF6-80A	OH	1
2084M46G01	NOZZLE - HPT STG 2	CF6-80A	OH	1
2084M46G01	NOZZLE - HPT STG 2	CF6-80A	OH	1
2084M46G01	NOZZLE - HPT STG 2	CF6-80A	OH	1
2084M46G01	NOZZLE - HPT STG 2	CF6-80A	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
2084M46G02	NOZZLE - HPT STG 2	CF6-80A	OH	1
2086M46G01	BLADE ASSY - HPTR STG 1	CF6-80A	OH	1
2086M46G01	BLADE ASSY - HPTR STG 1	CF6-80A	OH	1
2086M46G01	BLADE ASSY - HPTR STG 1	CF6-80A	OH	1
2086M46G01	BLADE ASSY - HPTR STG 1	CF6-80A	OH	1
2086M46G01	BLADE ASSY - HPTR STG 1	CF6-80A	OH	1
2086M46G01	BLADE ASSY - HPTR STG 1	CF6-80A	OH	1
2086M46G01	BLADE ASSY - HPTR STG 1	CF6-80A	OH	1
2086M46G01	BLADE ASSY - HPTR STG 1	CF6-80A	OH	1
2086M46G01	BLADE ASSY - HPTR STG 1	CF6-80A	OH	1
2086M46G01	BLADE ASSY - HPTR STG 1	CF6-80A	OH	1
2086M46G01	BLADE ASSY - HPTR STG 1	CF6-80A	OH	1
2086M46G01	BLADE ASSY - HPTR STG 1	CF6-80A	OH	1
2086M46G01	BLADE ASSY - HPTR STG 1	CF6-80A	OH	1
2086M46G01	BLADE ASSY - HPTR STG 1	CF6-80A	OH	1
2086M46G01	BLADE ASSY - HPTR STG 1	CF6-80A	OH	1
2086M46G01	BLADE ASSY - HPTR STG 1	CF6-80A	OH	1
2088M40G01	TUBE - D OIL SCAV FWD	CF6-80C2	NS	1
2088M90G01	BRACKET	CF6-80C2	NE	1
2088M90G01	BRACKET	CF6-80C2	AR	1
2092M11G01	SHROUD - LPT STG 2	CF6-80C2	OH	4
2092M11G01	SHROUD - LPT STG 2	CF6-80C2	OH	6
2092M13G01	SEAL ASSY - STG 2	CF6-50 (Boeing)	OH	6
2092M13G01	SEAL ASSY - STG 2	CF6-50 (Boeing)	OH	2
2092M13G01	SEAL ASSY - STG 2	CF6-50 (Boeing)	AR	6
2092M13G02	SEAL ASSY - STG 2	CF6-50 (Boeing)	OH	8
2092M13G02	SEAL ASSY - STG 2	CF6-50 (Boeing)	OH	6
2092M13G02	SEAL ASSY - STG 2	CF6-50 (Boeing)	OH	3
2092M13G02	SEAL ASSY - STG 2	CF6-50 (Boeing)	OH	1
2092M13G02	SEAL ASSY - STG 2	CF6-50 (Boeing)	AR	2
2092M13G02	SEAL ASSY - STG 2	CF6-50 (Boeing)	AR	1
2092M13G02	SEAL ASSY - STG 2	CF6-50 (Boeing)	AR	16
2092M13G02	SEAL ASSY - STG 2	CF6-50 (Boeing)	AR	4
2092M13G03	SEAL ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2092M13G03	SEAL ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2092M13G03	SEAL ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2092M13G03	SEAL ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	SV	16
2092M13G03	SEAL ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2092M13G03	SEAL ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2092M13G03	SEAL ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2092M13G03	SEAL ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
2092M13G03	SEAL ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
2092M13G03	SEAL ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
2092M13G03	SEAL ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
2092M13G03	SEAL ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
2092M13G03	SEAL ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	13
2092M13G03	SEAL ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
2092M13G03	SEAL ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
2092M14G01	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
2092M14G01	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	SV	10
2092M14G01	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	8
2092M14G01	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
2092M14G01	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
2092M14G01	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
2092M14G01	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
2092M14G01	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
2092M14G01	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
2092M14G01	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
2092M14G01	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	9
2092M14G01	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
2092M14G01	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
2092M14G01	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
2092M14G01	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
2092M14G01	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
2092M14G01	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
2092M14G01	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
2092M14G01	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
2092M14G01	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
2092M36G01	BRACKET - FWD INNER LINER	CF6-80C2	AR	3
2092M52G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	AR	2
2092M52G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	SV	1
2092M52G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	SV	2
2092M52G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	NE	1
2092M52G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	SV	2
2092M52G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	SV	1
2092M52G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	SV	1
2092M52G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	SV	1
2092M52G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	SV	1
2092M52G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	SV	2
2092M52G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	OH	1
2092M52G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	SV	2
2092M52G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	OH	1
2092M52G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	OH	2
2092M52G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	OH	1
2092M52G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	OH	1
2092M52G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	OH	1
2092M52G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	OH	1
2092M52G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	OH	1
2092M52G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	OH	1
2092M52G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	SV	1
2092M52G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
2092M53G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	SV	1
2092M53G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	SV	1
2092M53G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	SV	1
2092M53G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	SV	1
2092M53G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	SV	1
2092M53G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	OH	1
2092M53G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	SV	1
2092M53G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	AR	1
2092M53G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	SV	1
2092M53G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	SV	1
2092M53G01	CRF RECOUP AIR TUBE [2 & 7 O-CLOCK]	CF6-80C2	OH	1
2092M54G01	MANIFOLD - OIL IN CRF	CF6-80C2	OH	1
2092M54G01	MANIFOLD - OIL IN CRF	CF6-80C2	OH	1
2092M54G01	MANIFOLD - OIL IN CRF	CF6-80C2	OH	1
2092M54G01	MANIFOLD - OIL IN CRF	CF6-80C2	AR	1
2092M54G01	MANIFOLD - OIL IN CRF	CF6-80C2	OH	1
2093M33P01	LINK - YOKE	CF6-80C2	AR	1
2093M33P02	LINK - YOKE	CF6-80C2	OH	1
2093M52G01	RETAINER - BOLT YOKE LINK	CF6-80C2	AR	1
2093M52G01	RETAINER - BOLT YOKE LINK	CF6-80C2	OH	1
2093M96G01	TUBE ASSY - AIR HPR	CF6-80C2	SV	1
2093M96G01	TUBE ASSY - AIR HPR	CF6-80C2	SV	1
2093M96G01	TUBE ASSY - AIR HPR	CF6-80C2	SV	1
2093M96G01	TUBE ASSY - AIR HPR	CF6-80C2	SV	1
2093M96G01	TUBE ASSY - AIR HPR	CF6-80C2	SV	1
2093M96G01	TUBE ASSY - AIR HPR	CF6-80C2	SV	1
2093M96G01	TUBE ASSY - AIR HPR	CF6-80C2	OH	1
2093M96G01	TUBE ASSY - AIR HPR	CF6-80C2	OH	1
2093M96G01	TUBE ASSY - AIR HPR	CF6-80C2	OH	1
2093M96G01	TUBE ASSY - AIR HPR	CF6-80C2	OH	1
2093M96G01	TUBE ASSY - AIR HPR	CF6-80C2	OH	1
2096M44G01	MANIFOLD - COOLING LPT	CF6-80C2	OH	1
2096M76G01	TUBE - AIR	CF6-80A	AR	1
2096M76G01	TUBE - AIR	CF6-80A	AR	1
2096M85P06	JOINT - FLEXIBLE	CF6-80C2	NE	1
2096M86P06	COUPLING - RUBBER	CF6-80C2	NE	1

[illegible]

Part Number	Part Description	Engine Type	Condition	Quantity
212T3104-1	DUCT ASSY.	CF6-80A	SV	1
2155M10G01	MANIFOLD - OIL GB REF PRESS	CF6-80C2	AR	1
2155M10G01	MANIFOLD - OIL GB REF PRESS	CF6-80C2	AR	1
2155M10G01	MANIFOLD - OIL GB REF PRESS	CF6-80C2	AR	1
2155M14P02	SEAL	CF6-80C2	NS	2
2155M14P02	SEAL	CF6-80C2	NE	3
2155M26G01	TUBE - AIR STG 11 UPPER L/S	CF6-80C2	AR	1
2155M39G01	MANIFOLD ASSY - STG 14 LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
2155M39G01	MANIFOLD ASSY - STG 14 LH	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
2155M39G01	MANIFOLD ASSY - STG 14 LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
2155M39G01	MANIFOLD ASSY - STG 14 LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
2155M39G01	MANIFOLD ASSY - STG 14 LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
2155M39G01	MANIFOLD ASSY - STG 14 LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
2155M39G01	MANIFOLD ASSY - STG 14 LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
2155M39G01	MANIFOLD ASSY - STG 14 LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
2155M41G01	MANIFOLD ASSY - STG 14 LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
2155M41G01	MANIFOLD ASSY - STG 14 LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
2155M41G01	MANIFOLD ASSY - STG 14 LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
2155M41G01	MANIFOLD ASSY - STG 14 LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
2155M44G01	LINK - TURNBUCKLE	CF6-50	NS	2
2155M55G01	TUBE - AIR PS3 CORE MID	CF6-80C2	OH	1
2155M61G01	BRACKET - MANIFOLD	CF6-50	AR	1
2155M61G01	BRACKET - MANIFOLD	CF6-50	AR	1
2155M63G01	TUBE - OIL IDG SPLY	CF6-80C2	NE	1
2155M63G01	TUBE - OIL IDG SPLY	CF6-80C2	NE	1
2155M65G01	BRACKET - LINK	CF6-50 (LMCO), CF6-50 (Boeing)	NE	3
2155M84P01	BRACKET - SUPPORT	CF6-80C2	NE	1
2155M84P01	BRACKET - SUPPORT	CF6-80C2	NE	9
2155M91G01	BRACKET - TUBE OIL SUPPLY	CF6-80C2	NS	1
2156M27G01	TUBE - FUEL FILTR/SERV HTR	CF6-80C2	AR	1
2168M97P01	BRACKET - SUPPORT PS3 TUBE	CF6-80C2	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
2186M12P01	RING - SNAP	CF6-80C2	NS	2
2186M12P01	RING - SNAP	CF6-80C2	NE	4
2192M10P01	BRACKET - SUPPORT PS3 TUBE	CF6-80C2	NE	1
2192M10P01	BRACKET - SUPPORT PS3 TUBE	CF6-80C2	NE	1
2192M10P01	BRACKET - SUPPORT PS3 TUBE	CF6-80C2	AR	1
2192M35G01	BRACKET - TRANSMITTER	CF6-80C2	AR	1
2192M65G01	BRACKET - SUPPORT	CF6-80C2	NE	1
2192M65G01	BRACKET - SUPPORT	CF6-80C2	NS	1
2193M85G01	BRACKET - ELECTRIC	CF6-80C2	NE	1
21SN04-121	SWITCH - LOW OIL	CF6-50	AR	1
21SN04-121	SWITCH - LOW OIL	CF6-50	AR	1
21SN04-121	SWITCH - LOW OIL	CF6-50	AR	1
21SN04-121	SWITCH - LOW OIL	CF6-50	AR	1
21SN04-121	SWITCH - LOW OIL	CF6-50	AR	1
21SN04-121	SWITCH - LOW OIL	CF6-50	AR	1
21SN04-121	SWITCH - LOW OIL	CF6-50	AR	1
21SN04-183	SWITCH - OIL DIFF PRESS	CF6-80A	AR	1
21SN04-183	SWITCH - OIL DIFF PRESS	CF6-80A	AR	1
21SN04-225	SWITCH - OIL PRESSURE	CF6-80C2	AR	1
21SN04-268	SWITCH - OIL DIFF PRESS	CF6-80A	AR	1
21SN04-268	SWITCH - OIL DIFF PRESS	CF6-80A	AR	1
21SN04-268	SWITCH - OIL DIFF PRESS	CF6-80A	AR	1
21SN04-268	SWITCH - OIL DIFF PRESS	CF6-80A	OH	1
21SN04-269	SWITCH - FUEL DIFF PRESS	CF6-80A	SV	1
21SN04-269	SWITCH - FUEL DIFF PRESS	CF6-80A	SV	1
21SN04-269	SWITCH - FUEL DIFF PRESS	CF6-80A	OH	1
21SN04-269	SWITCH - FUEL DIFF PRESS	CF6-80A	OH	1
21SN04-333	SWITCH - FUEL PRESSURE	CF6-80C2	AR	1
21SN04-334	SWITCH - OIL DIFF PRESS	CF6-80C2	OH	1
21SN04-334	SWITCH - OIL DIFF PRESS	CF6-80C2	OH	1
21SN04-335	SWITCH - OIL PRESSURE	CF6-80C2	OH	1
21SN04-335	SWITCH - OIL PRESSURE	CF6-80C2	OH	1
21SN04-33A	SWITCH - LOW OIL PRESS	CF6-50 (LMCO)	AR	1
21SN04-33A	SWITCH - LOW OIL PRESS	CF6-50 (LMCO)	AR	1
21SN04-33A	SWITCH - LOW OIL PRESS	CF6-50 (LMCO)	AR	1
21SN04-33A	SWITCH - LOW OIL PRESS	CF6-50 (LMCO)	AR	1
21SN04-33A	SWITCH - LOW OIL PRESS	CF6-50 (LMCO)	AR	1
21SN04-33A	SWITCH - LOW OIL PRESS	CF6-50 (LMCO)	AR	1
21SN04-33A	SWITCH - LOW OIL PRESS	CF6-50 (LMCO)	AR	1
21SN04-33A	SWITCH - LOW OIL PRESS	CF6-50 (LMCO)	AR	1
21SN04-33A	SWITCH - LOW OIL PRESS	CF6-50 (LMCO)	AR	1
21SN04-34	SWITCH - DIFF PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
21SN04-34	SWITCH - DIFF PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
21SN04-34	SWITCH - DIFF PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
21SN04-34	SWITCH - DIFF PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
21SN04-34	SWITCH - DIFF PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
21SN04-34	SWITCH - DIFF PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
21SN04-34	SWITCH - DIFF PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
21SN04-34	SWITCH - DIFF PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
21SN04-34	SWITCH - DIFF PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
21SN04-34	SWITCH - DIFF PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
21SN04-34	SWITCH - DIFF PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
21SN04-34	SWITCH - DIFF PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
21SN04-34	SWITCH - DIFF PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
2204M37G02	CENTERBODY - AFT	CF6-50 (Boeing)	AR	1
221-4310-501	DUCT ASSY	CF6-80A	AR	1
221-5306-501	DUCT ASSY	CF6-80A	AR	1
224-0153-507	DETECTOR ASSY - FIRE	CF6-80C2	AR	1
224-1022-1	MOUNT ASSY	CF6-80A	AR	1
224-1022-7	MOUNT ASSY	CF6-80A	OH	1
224-2270-502	BRACKET - HOLD OPEN ROD	CF6-80C2	AR	1
224-2271-503	BRACKET - HOLD OPEN ROD	CF6-80C2	AR	1
224-2271-504	BRACKET - HOLD OPEN ROD	CF6-80C2	AR	1
224-2336-501	BRACKET ASSY - ENGINE HOLD	CF6-80C2	AR	1
224-2336-501	BRACKET ASSY - ENGINE HOLD	CF6-80C2	AR	1
224-2473-501	BRACKET	CF6-80C2	AR	1
224-2473-502	BRACKET	CF6-80C2	AR	1
224-4103-513	BRACKET - STARTER	CF6-80C2	AR	1
224-4103-513	BRACKET - STARTER	CF6-80C2	NS	1
224-4106-509	BRACKET - STARTER DUCT	CF6-80C2	AR	1
224-4202-505	DUCT ASSY - ANTI-ICING	CF6-80C2	AR	1
224-4208-503	BRACKET - ANTI-ICING	CF6-80C2	AR	1
224-4209-505	BRACKET - ANTI-ICING	CF6-80C2	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
224-4209-507	BRACKET - ANTI-ICING	CF6-80C2	AR	1
224-4214-507	ELBOW - ANTI-ICING ENGINE	CF6-80C2	AR	1
224-4216-501	BRACKET - FWD	CF6-80C2	AR	1
224-4302-517	MANIFOLD ASSY - 14TH STG	CF6-80C2	AR	1
224-4302-519	MANIFOLD ASSY - 14TH STG	CF6-80A	AR	1
224-4304-511	MANIFOLD ASSEMBLY	CF6-80C2	AR	1
224-4305-501	BRACKET	CF6-80C2	AR	1
224-4305-505	BRACKET - PNEUMATIC SYSTEM [UPR]	CF6-80C2	AR	1
224-4308-529	TUBE ASSY - UNION TO BHD FTG	CF6-80A	AR	1
224-4308-531	TUBE ASSY - REGULATOR	CF6-80C2	AR	1
224-4308-531	TUBE ASSY - REGULATOR	CF6-80C2	AR	1
224-4308-533	TUBE ASSY - FAN AIR VALVE	CF6-80A	AR	1
224-4308-535	TUBE ASSY - UNION TO 14TH	CF6-80A	AR	1
224-4308-537	TUBE ASSY - HIGH PRESS	CF6-80A	AR	1
224-4312-507	ADAPTER	CF6-80A	AR	1
224-4318-503	JOINT ASSY - INTERFACE	CF6-80C2	AR	1
224-4404-511	TUBE ASSY - LWR HYDR PUMP	CF6-80A	AR	1
224-4404-515	TUBE ASSY - HYDR FILTER	CF6-80C2	AR	1
224-4404-515	TUBE ASSY - HYDR FILTER	CF6-80C2	AR	1
224-4404-521	TUBE ASSY - BHD TEE TO	CF6-80C2	AR	1
224-4413-503	BRACKET - REMOTE FILTER	CF6-80C2	AR	1
224-4501-5	BRACKET - INSTALLATION	CF6-80C2	NE	1
224-4651-501	TUBE ASSY - PYLON TO	CF6-80A	AR	1
224-4652-501	TUBE ASSY - PYLON TO	CF6-80C2	AR	1
224-4653-501	TUBE ASSY - PYLON TO	CF6-80C2	AR	1
224-4750-527	BRACKET ASSY	CF6-80C2	AR	1
224-4750-537	BRACKET	CF6-80C2	AR	1
224-4750-609	BRACKET	CF6-80C2	AR	1
224-5012-501	TUBE ASSY - LWR BRKT TO	CF6-80A	AR	1
224-5012-501	TUBE ASSY - LWR BRKT TO	CF6-80A	AR	1
224-5012-502	TUBE ASSY - LWR BRKT TO	CF6-80A	AR	1
224-5012-502	TUBE ASSY - LWR BRKT TO	CF6-80A	AR	1
224-5012-503	TUBE ASSY - FWD LWR HOSE	CF6-80A	AR	1
224-5012-503	TUBE ASSY - FWD LWR HOSE	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
224-5012-504	TUBE ASSY - AFT LWR HOSE	CF6-80A	AR	1
224-5012-504	TUBE ASSY - AFT LWR HOSE	CF6-80A	AR	1
224-5012-507	TUBE ASSY - FWD TEE TO	CF6-80A	AR	1
224-5012-507	TUBE ASSY - FWD TEE TO	CF6-80A	AR	1
224-5012-508	TUBE ASSY - AFT TEE TO	CF6-80A	AR	1
224-5012-508	TUBE ASSY - AFT TEE TO	CF6-80A	AR	1
224-5020-501	TUBE ASSY - AFT FLTR TO	CF6-80A	AR	1
224-5020-501	TUBE ASSY - AFT FLTR TO	CF6-80A	AR	1
224-5021-501	TUBE ASSY - FWD FLTR TO	CF6-80A	AR	1
224-5022-501	TUBE ASSY - LWR PUMP TO	CF6-80A	AR	1
224-5022-501	TUBE ASSY - LWR PUMP TO	CF6-80A	AR	1
224-5023-501	TUBE ASSY - UPR PUMP TO	CF6-80A	AR	1
224-5023-501	TUBE ASSY - UPR PUMP TO	CF6-80A	AR	1
224-6003-503	SUPPORT - IDL CRANKS	CF6-80A	AR	1
224-6006-1	SUPPORT	CF6-80A	AR	1
224-6403-501	TUBE ASSY - ENG GEARBOX	CF6-80A	AR	1
224-6403-501	TUBE ASSY - ENG GEARBOX	CF6-80A	AR	1
224-6403-502	TUBE ASSY - UNION TO LP	CF6-80A	AR	1
224-6403-502	TUBE ASSY - UNION TO LP	CF6-80A	AR	1
224-6403-503	TUBE ASSY - PRESS TO	CF6-80A	AR	1
224-6403-503	TUBE ASSY - PRESS TO	CF6-80A	AR	1
224-6403-504	TUBE ASSY - LP SW PRESS	CF6-80A	AR	1
224-6403-504	TUBE ASSY - LP SW PRESS	CF6-80A	AR	1
224-6403-505	TUBE ASSY - LP SW VENT	CF6-80A	AR	1
224-6403-505	TUBE ASSY - LP SW VENT	CF6-80A	AR	1
224-7001-501	DUCT ASSY - TEE STG 8	CF6-80A	AR	1
224-7001-501	DUCT ASSY - TEE STG 8	CF6-80A	AR	1
224-7002-507	DUCT ASSY - TEE STG 14	CF6-80A	AR	1
224-7002-507	DUCT ASSY - TEE STG 14	CF6-80A	AR	1
224-7003-503	MANIFOLD - 14TH STAGE	CF6-80A	AR	1
224-7003-503	MANIFOLD - 14TH STAGE	CF6-80A	AR	1
224-7004-507	TUBE ASSY - RGLTR VALVE	CF6-80A	AR	1
224-7004-509	TUBE ASSY - HIGH PRESS	CF6-80A	AR	1
224-7005-505	DUCT ASSY - STG 8	CF6-80A	AR	1
224-7005-505	DUCT ASSY - STG 8	CF6-80A	AR	1
224-7204-501	DUCT ASSY - ENG AFT	CF6-80A	AR	1
224-7206-501	DUCT ASSY - TRIPOD SUPPORTED	CF6-80A	AR	1
224-7215-515	TUBE ASSY - SENSE LINE	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
224-7215-515	TUBE ASSY - SENSE LINE	CF6-80A	AR	1
224-7215-519	TUBE ASSY - SENSE LINE	CF6-80A	AR	1
224-7215-519	TUBE ASSY - SENSE LINE	CF6-80A	AR	1
224-7215-521	TUBE ASSY - SENSE LINE	CF6-80A	AR	1
224-7215-521	TUBE ASSY - SENSE LINE	CF6-80A	AR	1
224-7215-523	TUBE ASSY - SENSE LINE	CF6-80A	AR	1
224-7215-523	TUBE ASSY - SENSE LINE	CF6-80A	AR	1
224-8013-501	TUBE ASSY - XMTR TO PUMP	CF6-80A	AR	1
224-8013-501	TUBE ASSY - XMTR TO PUMP	CF6-80A	AR	1
224-8013-502	TUBE ASSY - INLET PORT TO SW	CF6-80A	AR	1
224-8013-502	TUBE ASSY - INLET PORT TO SW	CF6-80A	AR	1
224-8013-503	TUBE ASSY - OUTLET PORT	CF6-80A	AR	1
224-8013-503	TUBE ASSY - OUTLET PORT	CF6-80A	AR	1
224-8013-504	TUBE ASSY - HIGH PRESS	CF6-80A	AR	1
224-8013-505	TUBE ASSY - LOW PRESS	CF6-80A	AR	1
224-8013-505	TUBE ASSY - LOW PRESS	CF6-80A	AR	1
224-8501-502	TUBE ASSY - OIL TANK	CF6-80A	AR	1
224-8501-502	TUBE ASSY - OIL TANK	CF6-80A	AR	1
224-8501-505	TUBE ASSY - FUEL PUMP PAD	CF6-80A	AR	1
224-8501-505	TUBE ASSY - FUEL PUMP PAD	CF6-80A	AR	1
224-8501-506	TUBE ASSY - IDG PAD TO	CF6-80A	AR	1
224-8501-506	TUBE ASSY - IDG PAD TO	CF6-80A	AR	1
224-8501-507	TUBE ASSY - STARTER PAD	CF6-80A	AR	1
224-8501-507	TUBE ASSY - STARTER PAD	CF6-80A	AR	1
224-8501-508	TUBE ASSY - UPR HYD PUMP	CF6-80A	AR	1
224-8501-509	TUBE ASSY - LWR HYD PUMP	CF6-80A	AR	1
224-8501-509	TUBE ASSY - LWR HYD PUMP	CF6-80A	AR	1
224-8501-510	TUBE ASSY - LWR PYLON	CF6-80A	AR	1
224-8501-510	TUBE ASSY - LWR PYLON	CF6-80A	AR	1
224-8501-511	TUBE ASSY - LWR PYLON	CF6-80A	AR	1
224-8501-513	TUBE ASSY - FUEL CONT	CF6-80A	AR	1
224-8501-518	TUBE ASSY - PYLON DRAIN	CF6-80A	AR	1
224-8501-518	TUBE ASSY - PYLON DRAIN	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
224-8501-519	TUBE ASSY - TUBE TO TUBE	CF6-80A	AR	1
224-8501-519	TUBE ASSY - TUBE TO TUBE	CF6-80A	AR	1
224-8501-520	TUBE ASSY - TUBE TO TUBE	CF6-80A	AR	1
224-8501-520	TUBE ASSY - TUBE TO TUBE	CF6-80A	AR	1
224-8501-525	TUBE ASSY - TUBE TO DRAIN	CF6-80A	AR	1
224-8501-525	TUBE ASSY - TUBE TO DRAIN	CF6-80A	AR	1
224-8501-526	TUBE ASSY - DRAIN	CF6-80A	AR	1
224-8501-526	TUBE ASSY - DRAIN	CF6-80A	AR	1
224-8501-527	TUBE ASSY - VAR BYPASS	CF6-80A	AR	1
224-8501-527	TUBE ASSY - VAR BYPASS	CF6-80A	AR	1
224-8501-529	TUBE ASSY - OIL TANK	CF6-80A	AR	1
224-8501-529	TUBE ASSY - OIL TANK	CF6-80A	AR	1
224-8501-530	TUBE ASSY - COMBUSTOR	CF6-80A	AR	1
224-8501-530	TUBE ASSY - COMBUSTOR	CF6-80A	AR	1
224-8501-533	TUBE ASSY - TUBE TO LWR	CF6-80A	AR	1
224-8501-533	TUBE ASSY - TUBE TO LWR	CF6-80A	AR	1
224-8501-534	TUBE ASSY - FWD J-BOX HOSE	CF6-80A	AR	1
224-8501-534	TUBE ASSY - FWD J-BOX HOSE	CF6-80A	AR	1
224-8542-501	MANIFOLD ASSY - DRAIN TUBE	CF6-80A	AR	1
224-9091-501	TUBE ASSY - PYLON FUEL	CF6-80C2	AR	1
224-9101-503	BRACKET	CF6-80C2	SV	1
224-9252-505	DUCT ASSY - ANTI-ICING	CF6-80C2	AR	1
224-9270-501	DUCT ASSY - REGULATOR	CF6-80C2	AR	1
224-9271-501	DUCT ASSY - THRUST	CF6-80C2	AR	1
224-9304-501	BRACKET ASSY	CF6-80C2	NE	1
224-9311-503	MANIFOLD ASSEMBLY	CF6-80C2	OH	1
224-9311-503	MANIFOLD ASSEMBLY	CF6-80C2	OH	1
224-9314-501	MANIFOLD ASSEMBLY	CF6-80C2	OH	1
224-9404-503	BRACKET ASSY - SUPPORT	CF6-80C2	NE	1
224-9477-501	PLATE - MOUNTING	CF6-80C2	NS	1
224-9748-517	BRACKET	CF6-80C2	NS	1
224-9748-525	BRACKET	CF6-80C2	SV	1
224-9748-529	BRACKET	CF6-80C2	NE	1
224-9748-531	BRACKET	CF6-80C2	NS	1
224-9748-551	BRACKET	CF6-80C2	NE	1
224-9748-551	BRACKET	CF6-80C2	NE	1
224-9751-507	BRACKET	CF6-80C2	NE	1

Part Number	Part Description	Engine Type	Condition	Quantity
224-9751-507	BRACKET	CF6-80C2	NS	1
224-9751-523	BRACKET	CF6-80C2	NS	1
224-9751-523	BRACKET	CF6-80C2	NS	1
224-9751-589	BRACKET ASSY	CF6-80C2	AR	1
224-9762-517	BRACKET ASSY	CF6-80C2	NE	1
224-9787-503	BRACKET ASSY	CF6-80C2	SV	1
224-9793-501	BRACKET ASSY	CF6-80C2	NS	1
224-9817-501	BRACKET ASSY	CF6-80C2	AR	1
224-9817-501	BRACKET ASSY	CF6-80C2	NE	1
224-9817-501	BRACKET ASSY	CF6-80C2	SV	1
224-9830-501	BRACKET	CF6-80C2	SV	1
224D1028-525	DUCT ASSY - JOINT STG 14	CF6-80A	AR	1
224W4712-513	HARNESS ASSY - CORE RH	CF6-80C2	AR	1
224W4713-529	HARNESS ASSY - FIRESHIELD	CF6-80C2	AR	1
224W4714-511	HARNESS ASSY - FAN MISC WIRE	CF6-80C2	AR	1
224W8801-501	BUNDLE ASSY - GEN PWR WIRE	CF6-80A	AR	1
224W8801-501	BUNDLE ASSY - GEN PWR WIRE	CF6-80A	AR	1
224W8802-505	BUNDLE ASSY - FAN CASE WIRE	CF6-80A	AR	1
224W8802-525	BUNDLE ASSY - FAN CASE WIRE	CF6-80A	AR	1
224W8808-501	BUNDLE ASSY - THRUST WIRE	CF6-80A	AR	1
224W8808-501	BUNDLE ASSY - THRUST WIRE	CF6-80A	AR	1
224W9732-505	HARNESS ASSY - OIL WIRE	CF6-80C2	SV	1
224W9933-501	HARNESS ASSY - WIRE	CF6-80C2	AR	1
224W9933-501	HARNESS ASSY - WIRE	CF6-80C2	SV	1
224W9934-501	HARNESS ASSY - WIRE	CF6-80C2	NE	1
2254M26G01	LINER - COMB CHMBR INNER	CF6-80C2	AR	1
2285M80G01	TUBE - OIL SUPPLY	CF6-80C2	OH	1
2286M25G01	TUBE - OIL LUBE PUMP	CF6-80C2	AR	1
2286M25G01	TUBE - OIL LUBE PUMP	CF6-80C2	AR	1
22E57-1	COOLER - IDG AIR/OIL	CF6-80A	AR	1
22E57-1	COOLER - IDG AIR/OIL	CF6-80A	SV	1
22E57-1	COOLER - IDG AIR/OIL	CF6-80A	SV	1
22E57-1	COOLER - IDG AIR/OIL	CF6-80A	SV	1
22E57-1	COOLER - IDG AIR/OIL	CF6-80A	SV	1
22E57-1	COOLER - IDG AIR/OIL	CF6-80A	SV	1
22E57-2	COOLER - IDG AIR OIL	CF6-80A	AR	1
22E57-2	COOLER - IDG AIR OIL	CF6-80A	AR	1
22E57-2	COOLER - IDG AIR OIL	CF6-80A	SV	1
22E57-2	COOLER - IDG AIR OIL	CF6-80A	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
22E57-2	COOLER - IDG AIR OIL	CF6-80A	SV	1
2320-300	COUPLING	CF6-80A	AR	1
2320-300	COUPLING	CF6-80A	AR	1
2320-300	COUPLING	CF6-80A	SV	1
2320-550	COUPLING	CF6-80C2, CF6-80A	AR	1
2320-750	COUPLING	CF6-80C2	NE	2
23910-1A	MOUNT	CF6-80A	NS	4
23910-1A	MOUNT	CF6-80A	NS	4
23910-1A	MOUNT	CF6-80A	SV	4
23E50-3	COOLER ASSY - AIR/OIL	CF6-80A	AR	1
23E50-3	COOLER ASSY - AIR/OIL	CF6-80A	OH	1
2405-75-1220	COVER - GENERATOR	CF6-50 (LMCO)	AR	1
2412-550	COUPLING	CF6-80C2	SV	1
2412-550	COUPLING	CF6-80C2	SV	1
2420M28G01	TUBE - OIL LUBE PUMP	CF6-80C2	OH	1
2420M28G01	TUBE - OIL LUBE PUMP	CF6-80C2	OH	1
2420M30G01	BRACKET - OIL MONITORING	CF6-80C2	NE	1
2420M30G01	BRACKET - OIL MONITORING	CF6-80C2	SV	1
2420M70G01	MANIFOLD - FUEL LEFT SIDE	CF6-80C2	AR	1
2420M70G01	MANIFOLD - FUEL LEFT SIDE	CF6-80C2	OH	1
2420M71G01	MANIFOLD - FUEL RIGHT SIDE	CF6-80C2	AR	1
2436M61G01	MANIFOLD - FUEL LEFT SIDE	CF6-80C2	OH	1
2477M07G03	NOZZLE - LPT STG 5	CF6-80C2	AR	1
2605290-001	CABLE - VARIABLE STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
2605290-001	CABLE - VARIABLE STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
2605290-001	CABLE - VARIABLE STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
2605290-002	CABLE - VBV FDBK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
2605290-002	CABLE - VBV FDBK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
2605290-004	CABLE - VBV FEEDBACK	CF6-80C2	AR	1
2608M18P01	SHIELD - FIRE	CF6-80C2	NE	1
2608M18P01	SHIELD - FIRE	CF6-80C2	NE	1
2608M18P01	SHIELD - FIRE	CF6-80C2	NE	1
2608M19P01	SHIELD - FIRE	CF6-80C2	NE	1
2608M19P01	SHIELD - FIRE	CF6-80C2	NE	1
2608M19P01	SHIELD - FIRE	CF6-80C2	NE	1
2608M20P01	SHIELD - FIRE	CF6-80C2	NE	1
2608M20P01	SHIELD - FIRE	CF6-80C2	NE	1

Part Number	Part Description	Engine Type	Condition	Quantity
2608M20P01	SHIELD - FIRE	CF6-80C2	NE	1
2608M21P01	SHIELD - FIRE	CF6-80C2	NE	1
2608M21P01	SHIELD - FIRE	CF6-80C2	NE	1
2608M21P01	SHIELD - FIRE	CF6-80C2	NE	1
2608M22P01	SHIELD - FIRE	CF6-80C2	NE	1
2608M22P01	SHIELD - FIRE	CF6-80C2	NE	2
2608M22P01	SHIELD - FIRE	CF6-80C2	NE	1
2608M23P01	SHIELD - FIRE	CF6-80C2	NE	1
2608M23P01	SHIELD - FIRE	CF6-80C2	NE	1
2608M23P01	SHIELD - FIRE	CF6-80C2	NE	1
2608M23P01	SHIELD - FIRE	CF6-80C2	NE	1
2608M23P01	SHIELD - FIRE	CF6-80C2	NE	1
2608M24P01	SHIELD - FIRE	CF6-80C2	NE	1
2608M24P01	SHIELD - FIRE	CF6-80C2	NE	1
2608M24P01	SHIELD - FIRE	CF6-80C2	NE	2
2636M29P01	BRACKET - SUPPORT	CF6-80C2	NE	1
2636M30P01	BRACKET - SUPPORT	CF6-80C2	SV	1
2636M31P01	BRACKET - SUPPORT	CF6-80C2	SV	1
2636M31P01	BRACKET - SUPPORT	CF6-80C2	NE	1
2636M34G01	TUBE - OIL IN	CF6-80C2	AR	1
2636M34G01	TUBE - OIL IN	CF6-80C2	AR	1
2695M63G01	ELBOW - FITTING	CF6-80C2	NE	6
2695M63G01	ELBOW - FITTING	CF6-80C2	NE	1
2695M75G01	TUBE - OIL IN	CF6-80C2	NE	1
2695M75G01	TUBE - OIL IN	CF6-80C2	NE	1
2695M75G01	TUBE - OIL IN	CF6-80C2	NE	1
2695M75G01	TUBE - OIL IN	CF6-80C2	NE	1
2703-400	COUPLING - CLAMP	CF6-80C2, CF6-80A, PW2000	NE	1
2703-400	COUPLING - CLAMP	CF6-80C2, CF6-80A, PW2000	NE	1
2703-550	COUPLING - CLAMP	CF6-80A, PW2000	OH	1
2703-550	COUPLING - CLAMP	CF6-80A, PW2000	OH	1
2710963	VALVE	CF6-80A	SV	1
2710963	VALVE	CF6-80A	SV	1
2710963	VALVE	CF6-80A	SV	1
2710963	VALVE	CF6-80A	SV	1
2710963	VALVE	CF6-80A	SV	1
27574	TENSION BOLT	CF6-50 (LMCO)	NS	2
27574	TENSION BOLT	CF6-50 (LMCO)	NS	1
2757M04G01	SUPPORT - BRACKET	CF6-80C2	NE	1
277-1617-501	SUPPORT - BRACKET	CF6-80C2	NE	1
277-1617-501	SUPPORT - BRACKET	CF6-80C2	NE	1
28-1776-701	RING - MATING	CF6-80A	AR	3
28-2170-701	RING - MATING	CF6-80A	NE	15
2810181-101	VALVE - COOLING AIR	CF6-80A	AR	1
2810182-102	VALVE - COOLING AIR	CF6-80A	AR	1
2810182-102	VALVE - COOLING AIR	CF6-80A	SV	1
2810218-101	VALVE - COOLING AIR	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
2810218-101	VALVE - COOLING AIR	CF6-80A	AR	1
2810218-101	VALVE - COOLING AIR	CF6-80A	AR	1
2810218-101	VALVE - COOLING AIR	CF6-80A	AR	1
2810219-101	VALVE - COOLING AIR	CF6-80A	AR	1
2810219-101	VALVE - COOLING AIR	CF6-80A	AR	1
2810219-101	VALVE - COOLING AIR	CF6-80A	SV	1
2810219-101	VALVE - COOLING AIR	CF6-80A	AR	1
2810219-101	VALVE - COOLING AIR	CF6-80A	SV	1
2824M23G01	BRACKET ASSY-LEAF SEAL	CF6-80C2	NE	1
2824M23G01	BRACKET ASSY-LEAF SEAL	CF6-80C2	NE	20
2825M33G01	LUG - LKG STG 3	CF6-80C2	NE	2
2825M33G01	LUG - LKG STG 3	CF6-80C2	NE	2
286T0314-12	HARNESS - WIRE	CF6-80A	AR	1
286T0368	BUNDLE ASSY - WIRE (W368)	CF6-80A	AR	1
286T0368	BUNDLE ASSY - WIRE (W368)	CF6-80A	AR	1
286T0368	BUNDLE ASSY - WIRE (W368)	CF6-80A	AR	1
286T0368	BUNDLE ASSY - WIRE (W368)	CF6-80A	AR	1
286T0368	BUNDLE ASSY - WIRE (W368)	CF6-80A	AR	1
286T0368	BUNDLE ASSY - WIRE (W368)	CF6-80A	SV	1
286T5304-092	BUNDLE ASSY - WIRE	CF6-80C2	AR	1
286T5316	BUNDLE ASSY - WIRE (W5316)	CF6-80C2	AR	1
286T5318	BUNDLE ASSY - WIRE (W5318)	CF6-80C2	AR	1
286T5326	BUNDLE ASSY - WIRE (W5326)	CF6-80C2	AR	1
2873-300	SEAL	CF6-80A, PW2000	NE	10
2873-400	SEAL (1/25)	CF6-80C2, CF6-80A	NE	1
288269-13	STARTER MOTOR	CF6-50	AR	1
2C9924	VALVE CHECK	CF6-50 (Boeing)	NS	1
2CM16SAB3	STATOR - GEN AC	CF6-80C2, CF6-80A	SV	1
2CM16SAB3	STATOR - GEN AC	CF6-80C2, CF6-80A	SV	1
2CM18RAA1	ROTOR - GEN AC	CF6-80A	AR	1
2CM18SAA2	STATOR - GEN AC	CF6-80A	AR	1
2ISY3008B1	SENSOR - CORE SPEED	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
3003M70P01	TAPE - SILICONE	CF6-80A	NE	1
3017M97P06	TUBE - CONNECTOR	CF6-50	NE	11
30264-600	COUPLING	CF6-80C2	NE	1
30335-500	COUPLING	CF6-80C2	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
30335-600	COUPLING	CF6-80C2	AR	2
30377-600	COUPLING - CLAMP	CF6-80C2	NE	1
3041M48P01	RETAINER (SPD)	CF6-80A, CF6-50	NE	2
3041M98P03	SEAL - FWD FAN STTR CASE	CF6-50	NE	2
3041M98P03	SEAL - FWD FAN STTR CASE	CF6-50	NE	1
3042M21P01	SEGMENT - BACKSHEET (SPD)	CF6-50	NE	3
3042M56P01	COVER - FACE	CF6-50	NE	1
3042M63P01	SEGMENT - SEAL (SPD)	CF6-50	NS	4
3043M19P01	COVER - BRG AIR/OIL NO.1	CF6-50	AR	1
3043M46P01	SEAL - C	CF6-80C2	NS	1
3045M30P02	SLEEVE - WEAR (SPD)	CF6-50	NE	9
3045M54P01	RETAINER - LPT STATOR STG 1	CF6-50	NE	13
3045M54P01	RETAINER - LPT STATOR STG 1	CF6-50	NE	5
3046M71P01	RING - TABBED	CF6-50 (Boeing)	AR	1
3046M71P01	RING - TABBED	CF6-50 (Boeing)	NE	1
3046M71P01	RING - TABBED	CF6-50 (Boeing)	AR	1
3046M71P01	RING - TABBED	CF6-50 (Boeing)	AR	1
3049M84P240	FLANGE - TUBE	CF6-50	NS	2
3050M31P01	RING - HPTR PRESS TUBE	CF6-50	NE	1
3050M60P02	PLATE - TRUMPET (SPD)	CF6-80A, CF6-50	NE	3
3100013	PROBE - PLANE 5 TEMPERATURE	CF6-80C2	SV	1
310T1033-4	MOUNT - LPT ENGINE AFT	CF6-80A	AR	1
310U2033-13	MOUNT - REAR	CF6-80C2	OH	1
310U2033-18	MOUNT - AFT ENGINE	CF6-80C2	AR	1
312T2359-10	LINK ASSY	CF6-80C2	NE	1
312T2359-12	LINK ASSY	CF6-80C2	OH	1
312T2359-38	LINK ASSY	CF6-80C2	SV	1
312T2359-7	LINK ASSY	CF6-80C2	OH	1
314T1320-1	PLUG ASSY - EXH	CF6-80A	SV	1
314T1323-1	SEAL AS	CF6-80A	NE	2
314U2109-1	DUCT ASSY - TRANSITION	CF6-80C2	SV	1
314U2109-1	DUCT ASSY - TRANSITION	CF6-80C2	OH	1
315T1025-1	BRACKET	CF6-80A	NS	1
315T1032-1	PLATE - SHIM	CF6-80A	NS	1
315T1032-1	PLATE - SHIM	CF6-80A	NS	3
315T1040-19	CONTROL ASSY - FUEL	CF6-80C2, CF6-80A	OH	1
315T1045-4	COVER	CF6-80A	NS	1
315T2402-11	COVER	CF6-80A	NS	7
315T2402-4	FITTING ASSY	CF6-80A	NS	1
3199958	PROBE - TEMP	CF6-80A	AR	1
3202200-1	VALVE - PNEU CHECK	CF6-50 (LMCO)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
3202200-1	VALVE - PNEU CHECK	CF6-50 (LMCO)	OH	1
3202200-1	VALVE - PNEU CHECK	CF6-50 (LMCO)	AR	1
3202278-1	VALVE - FAN REV CHECK	CF6-80C2	OH	1
3202500-2	VALVE ASSY - HP	CF6-80C2	AR	1
320625-4	VALVE - PRESS RELIEF	CF6-50 (Boeing)	OH	1
320625-4	VALVE - PRESS RELIEF	CF6-50 (Boeing)	OH	1
320625-4	VALVE - PRESS RELIEF	CF6-50 (Boeing)	OH	1
320625-7	VALVE - PRESS RELIEF	CF6-50 (Boeing)	OH	1
3214330-6	VALVE - RGLTR CHECK	CF6-80C2	AR	1
3214330-6	VALVE - RGLTR CHECK	CF6-80C2	AR	1
3255-7302	TRANSDUCER - PRESS ABS	CF6-50	AR	1
3255-7302	TRANSDUCER - PRESS ABS	CF6-50	AR	1
3255-7302	TRANSDUCER - PRESS ABS	CF6-50	AR	1
3290280-3	VALVE ASSY	CF6-80C2	SV	1
3291172-3	VALVE - OUTLINE SHUTOFF	CF6-80C2	OH	1
332T1063-13	CHANNEL	CF6-80A	AR	1
332T1063-13	CHANNEL	CF6-80A	AR	1
332T1063-13	CHANNEL	CF6-80A	SV	1
332T1063-16	BRACE ASSY	CF6-80A	AR	1
332T1063-16	BRACE ASSY	CF6-80A	AR	1
332T1063-16	BRACE ASSY	CF6-80A	AR	1
332T1063-16	BRACE ASSY	CF6-80A	NS	1
332T1063-16	BRACE ASSY	CF6-80A	NS	1
332T1063-16	BRACE ASSY	CF6-80A	AR	1
332T1063-16	BRACE ASSY	CF6-80A	AR	1
332T1063-18	BRACE ASSY	CF6-80A	AR	1
332T1063-18	BRACE ASSY	CF6-80A	AR	1
332T1063-30	BRACKET ASSY	CF6-80A	OH	1
332T1063-30	BRACKET ASSY	CF6-80A	NE	1
332T1063-33	BRACKET	CF6-80A	NE	1
332T1063-36	BRACKET - SUPPORT	CF6-80A	AR	1
332T1063-36	BRACKET - SUPPORT	CF6-80A	AR	1
332T1063-39	BRACE ASSY	CF6-80A	AR	1
332T1064-6	SHIELD ASSY - DRIP	CF6-80A	NE	2
332T1065-2	RETAINER - BOOT SEAL	CF6-80A	NS	1
332T1065-2	RETAINER - BOOT SEAL	CF6-80A	NS	3
332T1070-10	TUBE ASSY - (LH MANIFOLD)	CF6-80A	AR	1
332T1070-12	TUBE ASSY - (VSV/VBV CIT SENS)	CF6-80A	SV	1
332T1070-12	TUBE ASSY - (VSV/VBV CIT SENS)	CF6-80A	AR	1
332T1070-16	TUBE ASSY	CF6-80A	OH	1
332T1070-16	TUBE ASSY	CF6-80A	SV	1
332T1070-18	TUBE ASSY - (CIT SENSOR)	CF6-80A	AR	1
332T1070-18	TUBE ASSY - (CIT SENSOR)	CF6-80A	AR	1
332T1070-18	TUBE ASSY - (CIT SENSOR)	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
332T1070-2	TUBE ASSY - (HYD PUMP PAD)	CF6-80A	AR	1
332T1070-2	TUBE ASSY - (HYD PUMP PAD)	CF6-80A	AR	1
332T1070-2	TUBE ASSY - (HYD PUMP PAD)	CF6-80A	AR	1
332T1070-20	TUBE ASSY	CF6-80A	AR	1
332T1070-20	TUBE ASSY	CF6-80A	AR	1
332T1070-20	TUBE ASSY	CF6-80A	AR	1
332T1070-20	TUBE ASSY	CF6-80A	AR	1
332T1070-20	TUBE ASSY	CF6-80A	AR	1
332T1070-20	TUBE ASSY	CF6-80A	AR	1
332T1070-21	TUBE ASSY - (STRUT)	CF6-80A	AR	1
332T1070-21	TUBE ASSY - (STRUT)	CF6-80A	AR	1
332T1070-21	TUBE ASSY - (STRUT)	CF6-80A	AR	1
332T1070-21	TUBE ASSY - (STRUT)	CF6-80A	OH	1
332T1070-21	TUBE ASSY - (STRUT)	CF6-80A	OH	1
332T1070-22	TUBE ASSY	CF6-80A	OH	1
332T1070-22	TUBE ASSY	CF6-80A	AR	1
332T1070-22	TUBE ASSY	CF6-80A	AR	1
332T1070-22	TUBE ASSY	CF6-80A	AR	1
332T1070-22	TUBE ASSY	CF6-80A	OH	1
332T1070-23	TUBE ASSY	CF6-80A	SV	1
332T1070-23	TUBE ASSY	CF6-80A	SV	1
332T1070-23	TUBE ASSY	CF6-80A	SV	1
332T1070-24	TUBE ASSY	CF6-80A	AR	1
332T1070-27	TUBE ASSY	CF6-80A	NE	2
332T1070-4	TUBE ASSY - (FUEL PUMP PAD)	CF6-80A	AR	1
332T1070-4	TUBE ASSY - (FUEL PUMP PAD)	CF6-80A	AR	1
332T1070-4	TUBE ASSY - (FUEL PUMP PAD)	CF6-80A	AR	1
332T1070-5	TUBE ASSY - (STARTER PAD)	CF6-80A	AR	1
332T1070-5	TUBE ASSY - (STARTER PAD)	CF6-80A	AR	1
332T1070-5	TUBE ASSY - (STARTER PAD)	CF6-80A	AR	1
332T1070-5	TUBE ASSY - (STARTER PAD)	CF6-80A	SV	1
332T1070-6	TUBE ASSY - (IDG PAD)	CF6-80A	AR	1
332T1070-6	TUBE ASSY - (IDG PAD)	CF6-80A	AR	1
332T1070-6	TUBE ASSY - (IDG PAD)	CF6-80A	SV	2
332T1070-8	TUBE ASSY - (STRUT DRAIN)	CF6-80A	AR	1
332T1070-9M	TUBE	CF6-80A	OH	1
332T1072-1	RETAINER	CF6-80A	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
332T1072-5	RETAINER	CF6-80A	NE	1
332T1072-5	RETAINER	CF6-80A	NS	1
332T1081-1	BOOT - SEALING	CF6-80A	NE	1
332T1082-14	FLANGE	CF6-80A	AR	1
332T1092-16	BRACKET	CF6-80A	AR	1
332T1092-3	BRACKET	CF6-80A	AR	1
332T1092-3	BRACKET	CF6-80A	AR	1
332T1092-3	BRACKET	CF6-80A	AR	1
332T1092-35	BRACKET	CF6-80A	AR	1
332T1092-37	BRACKET	CF6-80A	AR	1
332T1092-37	BRACKET	CF6-80A	AR	1
332T1095-19	BRACKET	CF6-80A	SV	1
332T1095-2	BRACKET	CF6-80A	SV	1
332T1095-20	BRACKET ASSY	CF6-80A, CF6-50 (LMCO)	AR	1
332T1095-22	BRACKET	CF6-80A	AR	1
332T1095-22	BRACKET	CF6-80A	AR	1
332T1095-25	BRACKET ASSY.	CF6-80A	NE	3
332T1095-51	BRACKET	CF6-80A	NS	1
332T1095-55	BRACKET - SB 767-26-43 CONFIG C	CF6-80A	NS	1
332T1111-103	BRACKET	CF6-80A	NE	1
332T1111-104	BRACKET	CF6-80A	AR	1
332T1111-104	BRACKET	CF6-80A	SV	1
332T1111-112	BRACKET ASSY	CF6-80A	AR	1
332T1111-114	BRACKET	CF6-80A	NS	1
332T1111-114	BRACKET	CF6-80A	AR	2
332T1111-114	BRACKET	CF6-80A	AR	1
332T1111-114	BRACKET	CF6-80A	AR	1
332T1111-115	BRACKET	CF6-80A	SV	1
332T1111-134	BRACKET	CF6-80A	OH	1
332T1111-134	BRACKET	CF6-80A	SV	1
332T1111-134	BRACKET	CF6-80A	SV	1
332T1111-135	BRACKET	CF6-80A	AR	1
332T1111-135	BRACKET	CF6-80A	NS	2
332T1111-135	BRACKET	CF6-80A	NS	2
332T1111-136	BRACKET - DRAIN	CF6-80A	NS	1
332T1111-136	BRACKET - DRAIN	CF6-80A	NS	1
332T1111-137	BRACKET	CF6-80A	NS	3
332T1111-137	BRACKET	CF6-80A	NS	1
332T1111-138	BRACKET	CF6-80A	AR	1
332T1111-141	BRACKET ASSY	CF6-80A	AR	1
332T1111-142	BRACKET	CF6-80A	NE	1
332T1111-142	BRACKET	CF6-80A	NS	1
332T1111-152	BRACKET	CF6-80A	NE	1
332T1111-167	BRACKET	CF6-80A	SV	1
332T1111-167	BRACKET	CF6-80A	NS	1
332T1111-167	BRACKET	CF6-80A	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
332T1111-167	BRACKET	CF6-80A	NS	2
332T1111-177	BRACKET	CF6-80A	NS	1
332T1111-178	BRACKET	CF6-80A	NS	1
332T1111-189	BRACKET	CF6-80A	NS	2
332T1111-19	BRACKET	CF6-80A	NS	1
332T1111-19	BRACKET	CF6-80A	AR	1
332T1111-191	SUPPORT ASSY	CF6-80A	NE	1
332T1111-195	BRACKET	CF6-80A	OH	1
332T1111-195	BRACKET	CF6-80A	SV	1
332T1111-204	BRACKET	CF6-80A	NS	1
332T1111-205	BRACKET	CF6-80A	NE	1
332T1111-34	BRACKET	CF6-80A	AR	1
332T1111-35	BRACKET	CF6-80A	NS	1
332T1111-35	BRACKET	CF6-80A	AR	1
332T1111-36	BRACKET	CF6-80A	AR	1
332T1111-49	BRACKET ASSY	CF6-80A	AR	1
332T1111-65	BRACKET	CF6-80A	NS	1
332T1111-67	BRACKET	CF6-80A	SV	1
332T1111-82	BRACKET	CF6-80A	AR	1
332T1111-85	BRACKET	CF6-80A	NE	7
332T1111-86	BRACKET	CF6-80A	NS	1
332T1111-86	BRACKET	CF6-80A	NS	1
332T1111-88	BRACKET	CF6-80A	NS	1
332T1111-88	BRACKET	CF6-80A	AR	1
332T1111-94	BRACKET	CF6-80A	NS	1
332T1112-1	BRACKET - FLANGE	CF6-80A	NS	1
332T1112-1	BRACKET - FLANGE	CF6-80A	NS	1
332T1112-1	BRACKET - FLANGE	CF6-80A	NS	1
332T1112-2	BRACKET - FLANGE	CF6-80A	NS	1
332T1204-10	TUBE ASSY	CF6-80A	AR	1
332T1204-2	TUBE ASSY	CF6-80A	AR	1
332T1204-2	TUBE ASSY	CF6-80A	AR	1
332T1204-2	TUBE ASSY	CF6-80A	AR	1
332T1204-2	TUBE ASSY	CF6-80A	AR	1
332T1204-3	TUBE ASSY	CF6-80A	AR	1
332T1204-3	TUBE ASSY	CF6-80A	AR	1
332T1204-3	TUBE ASSY	CF6-80A	AR	1
332T1204-3	TUBE ASSY	CF6-80A	AR	1
332T1204-7	BRACKET	CF6-80A	AR	1
332T1204-8	TUBE ASSY	CF6-80A	AR	1
332T1204-8	TUBE ASSY	CF6-80A	AR	1
332T1204-8	TUBE ASSY	CF6-80A	AR	1
332T1210-2	TUBE ASSY	CF6-80A	AR	1
332T1210-2	TUBE ASSY	CF6-80A	AR	1
332T1210-2	TUBE ASSY	CF6-80A	OH	1
332T1214-2	ROD ASSY	CF6-80A	SV	1
332T1216-3	TUBE ASSY	CF6-80A	AR	1
332T1216-3	TUBE ASSY	CF6-80A	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
332T1216-6	TUBE ASSY	CF6-80A	AR	1
332T1216-6	TUBE ASSY	CF6-80A	AR	1
332T1216-6	TUBE ASSY	CF6-80A	AR	1
332T1218-10	BRACKET	CF6-80A	AR	1
332T1218-10	BRACKET	CF6-80A	AR	1
332T1218-7	BRACKET	CF6-80A	AR	1
332T1221-1	BRACKET	CF6-80A	AR	1
332T1221-1	BRACKET	CF6-80A	AR	1
332T1221-1	BRACKET	CF6-80A	OH	1
332T1221-10	SPACER	CF6-80A	NS	1
332T1221-10	SPACER	CF6-80A	NE	4
332T1221-10	SPACER	CF6-80A	NE	6
332T1221-10	SPACER	CF6-80A	NE	16
332T1222-10	BRACKET	CF6-80A	AR	1
332T1222-10	BRACKET	CF6-80A	AR	1
332T1222-10	BRACKET	CF6-80A	AR	1
332T1222-11	BRACKET	CF6-80A	SV	2
332T1222-13	BRACKET	CF6-80A	SV	1
332T1222-13	BRACKET	CF6-80A	AR	1
332T1222-15	BRACKET	CF6-80A	AR	1
332T1222-15	BRACKET	CF6-80A	AR	1
332T1222-15	BRACKET	CF6-80A	OH	1
332T1222-15	BRACKET	CF6-80A	AR	1
332T1222-16	BRACKET	CF6-80A	OH	1
332T1222-17	BRACKET	CF6-80A	OH	1
332T1222-17	BRACKET	CF6-80A	AR	1
332T1222-22	BLOCK	CF6-80A	AR	1
332T1222-24	BLOCK	CF6-80A	OH	1
332T1222-25	BLOCK	CF6-80A	AR	1
332T1222-25	BLOCK	CF6-80A	AR	1
332T1222-25	BLOCK	CF6-80A	NE	2
332T1222-26	BLOCK	CF6-80A	AR	1
332T1222-30	BLOCK	CF6-80A	NS	1
332T1222-4	BLOCK	CF6-80A	AR	1
332T1223-12	TUBE ASSY	CF6-80A	AR	1
332T1223-12	TUBE ASSY	CF6-80A	AR	1
332T1223-12	TUBE ASSY	CF6-80A	OH	1
332T1225-9	DUCT ASSY	CF6-80A	AR	1
332T1225-9	DUCT ASSY	CF6-80A	OH	1
332T1225-9	DUCT ASSY	CF6-80A	SV	1
332T1225-9	DUCT ASSY	CF6-80A	OH	1
332T1226-6	DUCT ASSY	CF6-80A	AR	1
332T1228-1	DUCT ASSY	CF6-80A	AR	1
332T1228-1	DUCT ASSY	CF6-80A	AR	1
332T1228-1	DUCT ASSY	CF6-80A	AR	1
332T1228-1	DUCT ASSY	CF6-80A	SV	1
332T1228-1	DUCT ASSY	CF6-80A	SV	1
332T1228-1	DUCT ASSY	CF6-80A	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
332T1228-1	DUCT ASSY	CF6-80A	SV	1
332T1229-1	DUCT ASSY	CF6-80A	OH	1
332T1232-1	DUCT ASSY	CF6-80A	AR	1
332T1232-1	DUCT ASSY	CF6-80A	AR	1
332T1232-9	DUCT ASSY	CF6-80A	OH	1
332T1234-1	MANIFOLD ASSY	CF6-80A	OH	1
332T1234-1	MANIFOLD ASSY	CF6-80A	OH	1
332T1234-1	MANIFOLD ASSY	CF6-80A	OH	1
332T1234-1	MANIFOLD ASSY	CF6-80A	OH	1
332T1234-1	MANIFOLD ASSY	CF6-80A	OH	1
332T1234-7	MANIFOLD ASSY	CF6-80A	OH	1
332T1234-9	MANIFOLD ASSY	CF6-80A	OH	1
332T1235-16	DUCT ASSY	CF6-80A	AR	1
332T1235-16	DUCT ASSY	CF6-80A	OH	1
332T1235-16	DUCT ASSY	CF6-80A	OH	1
332T1235-9	DUCT ASSY	CF6-80A	AR	1
332T1235-9	DUCT ASSY	CF6-80A	AR	1
332T1236-1	DUCT ASSY	CF6-80A	AR	1
332T1236-1	DUCT ASSY	CF6-80A	AR	1
332T1236-1	DUCT ASSY	CF6-80A	SV	1
332T1236-1	DUCT ASSY	CF6-80A	AR	1
332T1238-10	BRACKET	CF6-80A	AR	1
332T1238-12	BRACKET ASSY	CF6-80A	SV	1
332T1239-3	LINK	CF6-80A	SV	1
332T1239-3	LINK	CF6-80A	OH	1
332T1239-3	LINK	CF6-80A	SV	1
332T1241-26	DUCT ASSY	CF6-80A	OH	1
332T1243-4	BRACKET ASSY - SUPPORT	CF6-80A	NE	1
332T1245-4	LINK ASSY	CF6-80A	NE	1
332T1250-23	BRACKET	CF6-80A	NE	1
332T1250-23	BRACKET	CF6-80A	NE	1
332T1250-23	BRACKET	CF6-80A	SV	1
332T1250-23	BRACKET	CF6-80A	SV	1
332T1700-10	LINK ASSY	CF6-80A	AR	1
332T1700-17	DUCT ASSY	CF6-80A	OH	1
332T1700-17	DUCT ASSY	CF6-80A	OH	1
332T1700-17	DUCT ASSY	CF6-80A	OH	1
332T1700JP-3	SLEEVE ASSY	CF6-80A	NE	1
332T216-6	TUBE	CF6-80A	AR	1
332U2110-12	TUBE ASSY	CF6-80C2	AR	1
332U2110-13	TUBE ASSY - (HYD CASE DR)	CF6-80C2	AR	1
332U2110-18	CASE - DRAIN	CF6-80C2	AR	1
332U2110-18	CASE - DRAIN	CF6-80C2	AR	1
332U2110-3	TUBE ASSY - (HYD SUPPLY)	CF6-80C2	AR	1
332U2110-4	TUBE ASSY - (HYD PRESS)	CF6-80C2	NS	1
332U2312-9	DUCT ASSY	CF6-80C2	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
332U2312-9	DUCT ASSY	CF6-80C2	AR	1
332U2321-1	MANIFOLD ASSY - STG 8 DUCT	CF6-80C2	AR	1
332U2321-1	MANIFOLD ASSY - STG 8 DUCT	CF6-80C2	SV	1
332U2321-11	DUCT - 8TH STG	CF6-80C2	AR	1
332U2322-26	MANIFOLD ASSY	CF6-80C2	AR	1
332U2322-26	MANIFOLD ASSY	CF6-80C2	AR	1
332U2322-35	MANIFOLD ASSY	CF6-80C2	AR	1
332U2322-45	MANIFOLD ASSY - 14TH STG	CF6-80C2	OH	1
332U2323-74	SUPPORT - LINK	CF6-80C2	OH	1
332U2323-74	SUPPORT - LINK	CF6-80C2	OH	1
332U2323-74	SUPPORT - LINK	CF6-80C2	SV	1
332U2324-10	DUCT ASSY	CF6-80C2	AR	1
332U2324-10	DUCT ASSY	CF6-80C2	AR	1
332U2324-7	MANIFOLD ASSY - STG 8 & 14 DUCT	CF6-80C2	AR	1
332U2327-8	CLEVIS ASSY	CF6-80C2	SV	1
332U2327-8	CLEVIS ASSY	CF6-80C2	NS	1
332U2330-82	CF6-80C2 LINK	CF6-80C2	OH	1
332U2330-82	CF6-80C2 LINK	CF6-80C2	SV	1
332U2330-92	LINK ASSY - SUPPORT	CF6-80C2	NE	1
332U2330-92	LINK ASSY - SUPPORT	CF6-80C2	AR	1
332U2330-92	LINK ASSY - SUPPORT	CF6-80C2	OH	1
332U2330-92	LINK ASSY - SUPPORT	CF6-80C2	SV	1
332U2340-11	TUBE - HP CONTROLLER	CF6-80C2	AR	1
332U2340-18	TUBE ASSY	CF6-80C2	AR	1
332U2340-18	TUBE ASSY	CF6-80C2	AR	1
332U2340-22	TUBE ASSY	CF6-80C2	AR	1
332U2340-24	TUBE ASSY	CF6-80C2	AR	1
332U2340-25	TUBE - HP CONTROLLER	CF6-80C2	AR	1
332U2340-3	TUBE ASSY	CF6-80C2	AR	1
332U2340-4	TUBE ASSY	CF6-80C2	AR	1
332U2340-4	TUBE ASSY	CF6-80C2	AR	1
332U2340-8	TUBE ASSY	CF6-80C2	AR	1
332U2340-8	TUBE ASSY	CF6-80C2	NE	1
332U2340-9	TUBE ASSY	CF6-80C2	NS	1
332U2520-13	TUBE	CF6-80C2	AR	1
332U2520-13	TUBE	CF6-80C2	AR	1
332U2520-9	TUBE	CF6-80C2	AR	1
332U2520-9	TUBE	CF6-80C2	AR	1
332U2716-25	TUBE	CF6-80C2	AR	1
332U2716-25	TUBE	CF6-80C2	AR	1
332U2801-1	DRIPSHIELD - FUEL	CF6-80C2	NE	2
332U2801-1	DRIPSHIELD - FUEL	CF6-80C2	NE	5
332U2911-133	BRACKET	CF6-80C2	NS	2
332U2911-134	BRACKET	CF6-80C2	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
332U2911-140	BRACKET	CF6-80C2	SV	1
332U2911-146	BRACKET	CF6-80C2	AR	1
332U2911-156	BRACKET	CF6-80C2	AR	1
332U2911-156	BRACKET	CF6-80C2	NS	1
332U2911-158	BRACKET	CF6-80C2	NS	1
332U2911-188	BRACKET	CF6-80C2	SV	1
332U2911-202	BRACKET	CF6-80C2	SV	1
332U2911-211	BRACKET	CF6-80C2	SV	1
332U2911-222	CHANNEL	CF6-80C2	NS	1
332U2911-226	BRACKET	CF6-80C2	NE	1
332U2911-248	BRACKET	CF6-80C2	SV	1
332U2911-253	BRACKET	CF6-80C2	NE	1
332U2911-283	BRACKET	CF6-80C2	SV	1
332U2911-35	BRACKET	CF6-80C2	NS	5
332U2911-37	BRACKET	CF6-80C2	NS	1
332U2911-37	BRACKET	CF6-80C2	NS	1
332U2911-38	BRACKET	CF6-80C2	SV	1
332U2911-38	BRACKET	CF6-80C2	SV	1
332U2911-423	BRACKET	CF6-80C2	SV	1
332U2911-429	BRACKET	CF6-80C2	NS	1
332U2911-437	BRACKET	CF6-80C2	OH	1
332U2911-444	BRACKET	CF6-80C2	SV	1
332U2911-446	BRACKET	CF6-80C2	NS	1
332U2911-447	BRACKET	CF6-80C2	NS	1
332U2911-471	BRACKET	CF6-80C2	NS	1
332U2911-471	BRACKET	CF6-80C2	NS	1
332U2911-488	BRACKET	CF6-80C2	NS	2
332U2911-489	BRACKET	CF6-80C2	NS	1
332U2911-492	BRACKET ASSY	CF6-80C2	SV	1
332U2911-493	BRACKET	CF6-80C2	SV	1
332U2911-494	BRACKET	CF6-80C2	NS	1
332U2911-499	BRACKET	CF6-80C2	NE	1
332U2911-506	BRACKET	CF6-80C2	NE	1
332U2911-506	BRACKET	CF6-80C2	AR	1
332U2911-512	BRACKET	CF6-80C2	SV	1
332U2911-636	BRACKET	CF6-80C2	SV	1
332U2911-640	BRACKET	CF6-80C2	SV	1
3-930035-1	HEATSHIELD	CF6-50	AR	1
3-930035-2	HEATSHIELD	CF6-50 (LMCO)	AR	1
3-930035-2	HEATSHIELD	CF6-50 (LMCO)	AR	1
3-930035-2	HEATSHIELD	CF6-50 (LMCO)	AR	1
332U2911-68	BRACKET	CF6-80C2	SV	1
332U2913-119	BRACKET	CF6-80C2	OH	1
332U2913-121	BRACKET	CF6-80C2	NS	1
332U2913-226	BRACKET	CF6-80C2	NS	1
332U2913-227	BRACKET	CF6-80C2	SV	1
332U2913-238	BRACKET	CF6-80C2	OH	1
332U2913-44	BRACKET	CF6-80C2	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
332U2913-46	BRACKET	CF6-80C2	NE	1
332U2913-51	BRACKET - FIRE DETECTOR	CF6-80C2	AR	1
332U2913-53	BRACKET	CF6-80C2	NS	1
332U2913-71	BRACKET	CF6-80C2	OH	1
332U2915-3	BRACKET	CF6-80C2	AR	1
34H40-200	COUPLING ASSEMBLY	CF6-50 (LMCO)	NE	1
34H40-600	COUPLING	CF6-50	AR	1
3505448-5-1	STARTER ASSY - PNEU	CF6-80C2, CF6-80A	AR	1
3505448-5-1	STARTER ASSY - PNEU	CF6-80C2, CF6-80A	OH	1
3505448-5-1	STARTER ASSY - PNEU	CF6-80C2, CF6-80A	OH	1
350880-6	PUMP ASSY - HYDRAULIC	CF6-80C2, CF6-80A, PW2000	AR	1
350880-6	PUMP ASSY - HYDRAULIC	CF6-80C2, CF6-80A, PW2000	SV	1
350880-6	PUMP ASSY - HYDRAULIC	CF6-80C2, CF6-80A, PW2000	AR	1
350880-6	PUMP ASSY - HYDRAULIC	CF6-80C2, CF6-80A, PW2000	SV	1
350880-6	PUMP ASSY - HYDRAULIC	CF6-80C2, CF6-80A, PW2000	SV	1
350880-6	PUMP ASSY - HYDRAULIC	CF6-80C2, CF6-80A, PW2000	SV	1
350880-6	PUMP ASSY - HYDRAULIC	CF6-80C2, CF6-80A, PW2000	SV	1
350880-7	PUMP ASSY - HYDRAULIC	CF6-80C2, CF6-80A, PW2000	AR	1
352A1548P1	MOUNT - RESILIENT	CF6-80A	SV	3
352A1548P1	MOUNT - RESILIENT	CF6-80A	SV	1
36B506885AAG1	ROTOR	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
36C717720G1	STATOR ASSY	CF6-50	OH	1
36C717720G1	STATOR ASSY	CF6-50	OH	1
36C717722P1	ROTOR	CF6-50 (LMCO)	SV	1
384022-5-1	STARTER ASSY - PNEU	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
384022-5-1	STARTER ASSY - PNEU	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
384022-5-1	STARTER ASSY - PNEU	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
397892-1	VALVE ASSY - PNEU STARTER	CF6-50 (Boeing)	SV	1
397892-1	VALVE ASSY - PNEU STARTER	CF6-50 (Boeing)	SV	1
417-1034	ADAPTER - OIL CAP	CF6-80C2	OH	1
417-1034	ADAPTER - OIL CAP	CF6-80C2	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
417-1034	ADAPTER - OIL CAP	CF6-80C2	SV	1
417-1034	ADAPTER - OIL CAP	CF6-80C2	SV	1
417-1034	ADAPTER - OIL CAP	CF6-80C2	SV	1
417-1034	ADAPTER - OIL CAP	CF6-80C2	SV	1
417-1034	ADAPTER - OIL CAP	CF6-80C2	SV	1
418-01104	XMTR - OIL PRESS	CF6-80A	AR	1
418-01104	XMTR - OIL PRESS	CF6-80A	SV	1
45731-1191	HEATER - SERVO FUEL	CF6-50 (Boeing)	AR	1
45731-1191	HEATER - SERVO FUEL	CF6-50 (Boeing)	AR	1
45731-1191	HEATER - SERVO FUEL	CF6-50 (Boeing)	AR	1
45731-1191	HEATER - SERVO FUEL	CF6-50 (Boeing)	AR	1
45731-1191	HEATER - SERVO FUEL	CF6-50 (Boeing)	AR	1
45731-1191	HEATER - SERVO FUEL	CF6-50 (Boeing)	AR	1
45731-1191	HEATER - SERVO FUEL	CF6-50 (Boeing)	AR	1
45731-1191	HEATER - SERVO FUEL	CF6-50 (Boeing)	AR	1
45731-1191	HEATER - SERVO FUEL	CF6-50 (Boeing)	AR	1
45731-1191	HEATER - SERVO FUEL	CF6-50 (Boeing)	SV	1
45731-1191	HEATER - SERVO FUEL	CF6-50 (Boeing)	OH	1
45731-1191	HEATER - SERVO FUEL	CF6-50 (Boeing)	OH	1
45731-1191	HEATER - SERVO FUEL	CF6-50 (Boeing)	OH	1
45D24	SWITCH - FUEL DIFF PRESS	CF6-50	AR	1
45D24	SWITCH - FUEL DIFF PRESS	CF6-50	AR	1
45D29	SWITCH - DIFF PRESS	CF6-80A	AR	1
45D29	SWITCH - DIFF PRESS	CF6-80A	AR	1
45D5-1	SWITCH - FUEL DIFF PRESS	CF6-50 (LMCO)	AR	1
45D5-1	SWITCH - FUEL DIFF PRESS	CF6-50 (LMCO)	AR	1
45D5-1	SWITCH - FUEL DIFF PRESS	CF6-50 (LMCO)	AR	1
45D5-1	SWITCH - FUEL DIFF PRESS	CF6-50 (LMCO)	AR	1
45D5-1	SWITCH - FUEL DIFF PRESS	CF6-50 (LMCO)	AR	1
45D5-1	SWITCH - FUEL DIFF PRESS	CF6-50 (LMCO)	AR	1
45D5-1	SWITCH - FUEL DIFF PRESS	CF6-50 (LMCO)	AR	1
45D5-1	SWITCH - FUEL DIFF PRESS	CF6-50 (LMCO)	AR	1
45D5-1	SWITCH - FUEL DIFF PRESS	CF6-50 (LMCO)	AR	1
45D5-1	SWITCH - FUEL DIFF PRESS	CF6-50 (LMCO)	SV	1
45D5-1	SWITCH - FUEL DIFF PRESS	CF6-50 (LMCO)	SV	1
45D5-1	SWITCH - FUEL DIFF PRESS	CF6-50 (LMCO)	AR	1
45D5-1	SWITCH - FUEL DIFF PRESS	CF6-50 (LMCO)	AR	1
472332	SENSOR - FAN N1 SPEED	CF6-50	AR	1
472332	SENSOR - FAN N1 SPEED	CF6-50	AR	1
472332	SENSOR - FAN N1 SPEED	CF6-50	AR	1
472332	SENSOR - FAN N1 SPEED	CF6-50	AR	1
472332	SENSOR - FAN N1 SPEED	CF6-50	AR	1
472332	SENSOR - FAN N1 SPEED	CF6-50	AR	1
472332	SENSOR - FAN N1 SPEED	CF6-50	AR	1
473271	SENSOR - FAN N1 SPEED	CF6-50 (LMCO)	AR	1
473271	SENSOR - FAN N1 SPEED	CF6-50 (LMCO)	AR	1
473271	SENSOR - FAN N1 SPEED	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
473271	SENSOR - FAN N1 SPEED	CF6-50 (LMCO)	AR	1
473271	SENSOR - FAN N1 SPEED	CF6-50 (LMCO)	AR	1
473271	SENSOR - FAN N1 SPEED	CF6-50 (LMCO)	AR	1
473271	SENSOR - FAN N1 SPEED	CF6-50 (LMCO)	AR	1
473271	SENSOR - FAN N1 SPEED	CF6-50 (LMCO)	AR	1
473271	SENSOR - FAN N1 SPEED	CF6-50 (LMCO)	AR	1
473271	SENSOR - FAN N1 SPEED	CF6-50 (LMCO)	AR	1
473271	SENSOR - FAN N1 SPEED	CF6-50 (LMCO)	AR	1
473271	SENSOR - FAN N1 SPEED	CF6-50 (LMCO)	SV	1
473271	SENSOR - FAN N1 SPEED	CF6-50 (LMCO)	AR	1
485000-14	DAMPER - PULSATION	CF6-80C2, CF6-50 (Boeing)	AR	1
491B0700079-624	NUT - NON LOCKING	CF6-80C2	NS	4
50-120-00	ADAPTER	CF6-50 (Boeing)	OH	1
50-120-00	ADAPTER	CF6-50 (Boeing)	AR	1
50-120-00	ADAPTER	CF6-50 (Boeing)	AR	1
5006834M	PUMP - FUEL	CF6-80C2	SV	1
5010365	STRAINER ASSEMBLY	CF6-80C2	NS	1
504000A01	TUBE	CF6-50 (LMCO)	NE	1
504000A01	TUBE	CF6-50 (LMCO)	NE	1
504006A01	TUBE	CF6-80C2, CF6-50 (LMCO)	NE	1
504009A01	TUBE	CF6-50 (LMCO)	OH	1
504010A01	BRACKET	CF6-50 (LMCO)	AR	1
504011A01	BRACKET	CF6-50 (LMCO)	NE	1
504013A01	BRACKET	CF6-50 (LMCO)	NS	1
504013A01	BRACKET	CF6-50 (LMCO)	NS	1
504015A01	BRACKET	CF6-50 (LMCO)	NE	1
504030A01	BRACKET	CF6-50 (LMCO)	SV	1
504031A01	BRACKET	CF6-50 (LMCO)	SV	1
504034A01	BRACKET	CF6-50 (LMCO)	SV	1
51291-009	DETECTOR - ENGINE LH (CF6-50)	CF6-50	AR	1
51291-009	DETECTOR - ENGINE LH (CF6-50)	CF6-50	AR	1
51291-009	DETECTOR - ENGINE LH (CF6-50)	CF6-50	SV	1
51291-009	DETECTOR - ENGINE LH (CF6-50)	CF6-50	AR	1
51291-010	DETECTOR - ENGINE RH (CF6-50)	CF6-50	SV	1
51291-010	DETECTOR - ENGINE RH (CF6-50)	CF6-50	AR	1
51291-010	DETECTOR - ENGINE RH (CF6-50)	CF6-50	OH	1
51291-010	DETECTOR - ENGINE RH (CF6-50)	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
51291-010	DETECTOR - ENGINE RH (CF6-50)	CF6-50	AR	1
51291-046	DETECTOR - ENGINE FAN LH (CF6-50)	CF6-50	AR	1
51291-046	DETECTOR - ENGINE FAN LH (CF6-50)	CF6-50	OH	1
51291-047	DETECTOR - ENGINE FAN LH	CF6-50	AR	1
51291-047	DETECTOR - ENGINE FAN LH	CF6-50	AR	1
51291-047	DETECTOR - ENGINE FAN LH	CF6-50	AR	1
51291-059	DETECTOR ASSY	CF6-80A	AR	1
51291-059	DETECTOR ASSY	CF6-80A	AR	1
51291-060	DETECTOR ASSY	CF6-80A	AR	1
51291-060	DETECTOR ASSY	CF6-80A	AR	1
5252-030	VALVE ASSY - PUMP/DISCHARGE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
5252-030	VALVE ASSY - PUMP/DISCHARGE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
5252-030	VALVE ASSY - PUMP/DISCHARGE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
537L685G03	KIT - CARBON (SPD)	CF6-80C2	NE	3
537L685G03	KIT - CARBON (SPD)	CF6-80C2	NE	1
540-0712-2	VALVE - AIR IDG SHUT OFF	CF6-80C2	SV	1
5570-01	DETECTOR - FIRE	CF6-80A	AR	1
5570-01	DETECTOR - FIRE	CF6-80A	AR	1
56B17	TRANSMITTER - OIL TEMP	CF6-50 (Boeing)	AR	1
56B17	TRANSMITTER - OIL TEMP	CF6-50 (Boeing)	AR	1
56B17	TRANSMITTER - OIL TEMP	CF6-50 (Boeing)	AR	1
56B17	TRANSMITTER - OIL TEMP	CF6-50 (Boeing)	AR	1
56B17	TRANSMITTER - OIL TEMP	CF6-50 (Boeing)	AR	1
580-258-002	CABLE - VBV FDBK	CF6-50	AR	1
580-258-002	CABLE - VBV FDBK	CF6-50	AR	1
580-258-003	CABLE - VBV FDBK	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
580-258-003	CABLE - VBV FDBK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
580-258-003	CABLE - VBV FDBK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
580-258-003	CABLE - VBV FDBK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
580-258-003	CABLE - VBV FDBK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
580-258-003	CABLE - VBV FDBK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
580-258-003	CABLE - VBV FDBK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
580-258-003	CABLE - VBV FDBK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
580-258-003	CABLE - VBV FDBK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
580-258-003	CABLE - VBV FDBK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
580-278-002	CABLE - VARIABLE STATOR	CF6-50	AR	1
580-278-005	CABLE - VARIABLE STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
580-278-005	CABLE - VARIABLE STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
580-278-005	CABLE - VARIABLE STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
580-278-005	CABLE - VARIABLE STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
580-278-005	CABLE - VARIABLE STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
580-278-005	CABLE - VARIABLE STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
580-278-005	CABLE - VARIABLE STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
580-278-005	CABLE - VARIABLE STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
580-289-008	CABLE - VARIABLE STATOR	CF6-80A	SV	1
580-289-054	CABLE - VSV FEEDBACK	CF6-80C2	AR	1
580-289-054	CABLE - VSV FEEDBACK	CF6-80C2	AR	1
580-290-002	CABLE - VARIABLE BYPASS	CF6-80A	OH	1
580-290-053	CABLE - VBV FEEDBACK	CF6-80C2	AR	1
580-299-102	CABLE ASSY - THROTTLE	CF6-80A	OH	1
580-299-102	CABLE ASSY - THROTTLE	CF6-80A	NE	1
580-299-102	CABLE ASSY - THROTTLE	CF6-80A	OH	1
5808	BRACKET	CF6-80A	SV	1
5808	BRACKET	CF6-80A	SV	1
5830213-102	VALVE - TURBINE CLEARANCE	CF6-80C2	AR	1
5830213-102	VALVE - TURBINE CLEARANCE	CF6-80C2	OH	1
5860040-106	VALVE - TURB CLEARANCE CTRL	CF6-80C2	OH	1
5860040-107	VALVE - TURB CLEARANCE CTRL	CF6-80C2	SV	1
5860040-107	VALVE - TURB CLEARANCE CTRL	CF6-80C2	SV	1
5860040-107	VALVE - TURB CLEARANCE CTRL	CF6-80C2	SV	1
5870141-105	VALVE - BORE CLG	CF6-80C2	AR	1
5870141-105	VALVE - BORE CLG	CF6-80C2	AR	1
5870141-105	VALVE - BORE CLG	CF6-80C2	AR	1
5870141-105	VALVE - BORE CLG	CF6-80C2	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
5880307-103	VALVE - BORE CLG	CF6-80C2	SV	1
5880307-103	VALVE - BORE CLG	CF6-80C2	OH	1
600725	HARNESS - WIRE	CF6-80A	AR	1
600725	HARNESS - WIRE	CF6-80A	AR	1
601323-09	CABLE - THERMOCOUPLE LWR	CF6-80A	SV	1
601323-09	CABLE - THERMOCOUPLE LWR	CF6-80A	SV	1
601323HAS	HARNESS - EGT LOWER	CF6-80A	SV	1
601324-00	JUNCTION BOX - THERMOCOUPLE	CF6-80A	AR	1
601324-00	JUNCTION BOX - THERMOCOUPLE	CF6-80A	SV	1
601324-00	JUNCTION BOX - THERMOCOUPLE	CF6-80A	AR	1
601392	KIT - CARBON SEAL	CF6-80A	NS	1
602533-01	CABLE - THERMOCOUPLE FWD	CF6-80A	SV	1
602533-01	CABLE - THERMOCOUPLE FWD	CF6-80A	AR	1
602533-01	CABLE - THERMOCOUPLE FWD	CF6-80A	AR	1
603A1118-019	TUBE - LOWER	CF6-80A	AR	1
603A3000-003	HARNESS - WIRE POSN 2	CF6-80A	AR	1
60659	SEAL ASSEMBLY	CF6-50 (LMCO)	OH	1
60659	SEAL ASSEMBLY	CF6-50 (LMCO)	OH	1
60659	SEAL ASSEMBLY	CF6-50 (LMCO)	OH	1
60659	SEAL ASSEMBLY	CF6-50 (LMCO)	NS	1
60659	SEAL ASSEMBLY	CF6-50 (LMCO)	NE	1
60659	SEAL ASSEMBLY	CF6-50 (LMCO)	NE	1
60660	SEAL ASSEMBLY	CF6-50 (LMCO)	OH	1
60660	SEAL ASSEMBLY	CF6-50 (LMCO)	OH	1
60660	SEAL ASSEMBLY	CF6-50 (LMCO)	NS	1
60661	SEAL ASSEMBLY	CF6-50 (LMCO)	NS	1
60661	SEAL ASSEMBLY	CF6-50 (LMCO)	OH	1
60661	SEAL ASSEMBLY	CF6-50 (LMCO)	NS	1
60662	SEAL ASSEMBLY	CF6-50 (LMCO)	OH	1
60662	SEAL ASSEMBLY	CF6-50 (LMCO)	OH	1
60675	SEAL - RING COMPOSITE	CF6-50	NS	1
60675	SEAL - RING COMPOSITE	CF6-50	NS	1
607999-00	BOX - THERMOCOUPLE JUNCTION	CF6-80C2	SV	1
609200DAI	EGT CABLE	CF6-80C2	SV	1
609200HAS	HARNESS - UPR THERMO	CF6-80C2	NE	1
609200HAS	HARNESS - UPR THERMO	CF6-80C2	SV	1
60B00254-26	HOSE	CF6-50 (Boeing)	AR	1
60B00254-26	HOSE	CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
60B90005-11	BUNDLE ASSY - WIRE (W3316/W3318)	CF6-50 (LMCO)	SV	1
60B90005-41	HARNESS - WIRE	CF6-50 (LMCO)	SV	1
60B90106-23	HOSE - FUEL SUPPLY	CF6-50 (LMCO)	AR	1
60B90106-23	HOSE - FUEL SUPPLY	CF6-50 (LMCO)	AR	1
60B90106-23	HOSE - FUEL SUPPLY	CF6-50 (LMCO)	AR	1
60B90117-3	HOSE ASSY - FLEXIBLE	CF6-50	AR	1
60B90117-3	HOSE ASSY - FLEXIBLE	CF6-50	AR	1
60B90117-3	HOSE ASSY - FLEXIBLE	CF6-50	AR	1
60B90117-3	HOSE ASSY - FLEXIBLE	CF6-50	AR	1
60B90117-3	HOSE ASSY - FLEXIBLE	CF6-50	AR	1
60B90117-3	HOSE ASSY - FLEXIBLE	CF6-50	AR	1
60B90117-3	HOSE ASSY - FLEXIBLE	CF6-50	AR	1
60B90117-3	HOSE ASSY - FLEXIBLE	CF6-50	AR	1
60B90117-4	HOSE ASSY - FLEXIBLE	CF6-50	AR	1
60B90117-4	HOSE ASSY - FLEXIBLE	CF6-50	AR	1
60B90117-4	HOSE ASSY - FLEXIBLE	CF6-50	AR	1
60B90117-4	HOSE ASSY - FLEXIBLE	CF6-50	AR	1
60B90117-4	HOSE ASSY - FLEXIBLE	CF6-50	AR	1
60B90117-4	HOSE ASSY - FLEXIBLE	CF6-50	AR	1
60B90117-4	HOSE ASSY - FLEXIBLE	CF6-50	AR	1
60B90117-4	HOSE ASSY - FLEXIBLE	CF6-50	AR	1
612A260P6	SPACER (.280) ID (.270) THK	CF6-80A	AR	58
612A260P6	SPACER (.280) ID (.270) THK	CF6-80A	NS	4
612A348P12	SPACER (.385) ID (.085) OD	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
612A348P12	SPACER (.385) ID (.085) OD	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	4
612A348P12	SPACER (.385) ID (.085) OD	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	50
619E223P1	FITTING - REDUCER	CF6-50 (Boeing)	NE	3
619E223P2	FITTING - REDUCER	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
619E223P2	FITTING - REDUCER	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
619E223P3	REDUCER	CF6-50 (Boeing)	NS	1
619E223P3	REDUCER	CF6-50 (Boeing)	NS	1
619E223P52	FITTING - REDUCER	CF6-80C2, CF6-50 (LMCO)	NS	1
619E223P53	FITTING - REDUCER	CF6-80C2	NE	1
619E223P59	FITTING - REDUCER	CF6-80C2	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
619E223P6	FITTING - REDUCER	CF6-80A	NS	2
61B43300	WIRE BUNDLE ASSY (W3300)	CF6-50	AR	1
61B43300-3	GEN. HARNESS	CF6-50 (LMCO)	AR	1
61B43300-3	GEN. HARNESS	CF6-50 (LMCO)	AR	1
61B43302	BUNDLE ASSY - WIRE	CF6-50 (Boeing)	AR	1
61B43302	BUNDLE ASSY - WIRE	CF6-50 (Boeing)	AR	1
61B43302	BUNDLE ASSY - WIRE	CF6-50 (Boeing)	AR	1
61B43302	BUNDLE ASSY - WIRE	CF6-50 (Boeing)	AR	1
61B43304	BUNDLE ASSY - WIRE	CF6-50 (Boeing)	AR	1
61B43304	BUNDLE ASSY - WIRE	CF6-50 (Boeing)	AR	1
61B43304	BUNDLE ASSY - WIRE	CF6-50 (Boeing)	AR	1
61B43306	BUNDLE ASSY - WIRE	CF6-50 (Boeing)	AR	1
61B43306	BUNDLE ASSY - WIRE	CF6-50 (Boeing)	AR	1
61B43306	BUNDLE ASSY - WIRE	CF6-50 (Boeing)	AR	1
61B43312-003	WIRE	CF6-50 (Boeing)	AR	1
61B43320-007	BUNDLE ASSY - WIRE	CF6-50	NE	1
61B43320-007	BUNDLE ASSY - WIRE	CF6-50	AR	1
61B43320-007	BUNDLE ASSY - WIRE	CF6-50	AR	1
61B43322	BUNDLE ASSY - WIRE	CF6-50	SV	1
61B45310	BUNDLE ASSY - WIRE (W5310)	CF6-80C2	SV	1
61B45320-092	BUNDLE ASSY - WIRE	CF6-80C2	AR	1
61B45324	BUNDLE ASSY - WIRE (W5324)	CF6-80C2	SV	1
6222M53	ACCELEROMETER - INTERNAL	CF6-80A	AR	1
63201	SEAL ASSY	CF6-80A	NS	1
63201	SEAL ASSY	CF6-80A	OH	1
63325	RETAINER	CF6-80C2, CF6-80A	NE	1
635E357G01	TURNBUCKLE ASSY - SPR	CF6-50 (LMCO)	AR	1
635E357G01	TURNBUCKLE ASSY - SPR	CF6-50 (LMCO)	AR	1
635E576G03	BRACKET - AFT MTG	CF6-50 (LMCO)	AR	1
635E576G03	BRACKET - AFT MTG	CF6-50 (LMCO)	AR	1
635E576G03	BRACKET - AFT MTG	CF6-50 (LMCO)	AR	1
635E576G03	BRACKET - AFT MTG	CF6-50 (LMCO)	AR	1
65066-06	PUMP ASSY - HYDRAULIC	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
65066-06	PUMP ASSY - HYDRAULIC	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
65066-06	PUMP ASSY - HYDRAULIC	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
65066-06	PUMP ASSY - HYDRAULIC	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
65B90166-17	COVER - AC GENERATOR	CF6-50	AR	1
65B94069-2	TUBE ASSY	CF6-50 (Boeing)	AR	1
65B94069-2	TUBE ASSY	CF6-50 (Boeing)	AR	1
65B94189-1	DUCT ASSY	CF6-50	AR	1
65B94189-1	DUCT ASSY	CF6-50	AR	1
65B94189-1	DUCT ASSY	CF6-50	AR	1
65B94189-1	DUCT ASSY	CF6-50	SV	1
65B94189-1	DUCT ASSY	CF6-50	AR	1
65B94189-1	DUCT ASSY	CF6-50	AR	1
65B94189-1	DUCT ASSY	CF6-50	AR	1
65B94340-1	INSTALLATION - ENGINE MOUNT	CF6-50 (Boeing)	AR	1
65B94340-2	RETAINER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	3
65B94340-2	RETAINER	CF6-50 (LMCO), CF6-50 (Boeing)	NE	6
65B94350-3	MOUNT ASSY - AFT ENGINE LWR	CF6-50 (LMCO)	AR	1
65B94350-8	MOUNT ASSY - AFT ENGINE LWR	CF6-50 (Boeing)	OH	1
65B94351-3	LINK ASSY - TANGENT	CF6-50 (Boeing)	OH	1
65B94351-4	LINK	CF6-50 (Boeing)	AR	1
65B94508-23	TUBE ASSY	CF6-50 (Boeing)	AR	1
65B94508-23	TUBE ASSY	CF6-50 (Boeing)	AR	1
65B94508-23	TUBE ASSY	CF6-50 (Boeing)	AR	1
65B94508-30	TUBE ASSY	CF6-50 (Boeing)	NE	1
65B94508-40	TUBE ASSY	CF6-50 (Boeing)	NS	1
65B94508-40	TUBE ASSY	CF6-50 (Boeing)	AR	1
65B94508-40	TUBE ASSY	CF6-50 (Boeing)	AR	1
65B94512-2	BUSHING-FLANGED	CF6-50 (Boeing)	NS	3
65B94525-2	BRACKET	CF6-50	NE	1
65B94525-2	BRACKET	CF6-50	AR	1
65B94541-1	DUCT ASSY - TRANSITION	CF6-50 (Boeing)	AR	1
65B94541-1	DUCT ASSY - TRANSITION	CF6-50 (Boeing)	AR	1
65B94544-14	DUCT ASSY - CROSSOVER	CF6-50 (Boeing)	SV	1
65B94558-3	VALVE - SENSE PORT FITTING	CF6-50 (Boeing)	NS	2
65B94558-3	VALVE - SENSE PORT FITTING	CF6-50 (Boeing)	NS	1
65B94565-1	BRACKET	CF6-50 (LMCO)	AR	1
65B94565-1	BRACKET	CF6-50 (LMCO)	AR	1
65B94565-10	BRACKET	CF6-50 (LMCO)	AR	1
65B94565-2	BRACKET - CONTROL	CF6-50 (Boeing)	AR	1
65B94565-6	BRACKET - CONTROL	CF6-50	AR	2
65B94565-6	BRACKET - CONTROL	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
65B94565-6	BRACKET - CONTROL	CF6-50	AR	4
65B94565-6	BRACKET - CONTROL	CF6-50	AR	1
65B94565-6	BRACKET - CONTROL	CF6-50	AR	1
65B94565-6	BRACKET - CONTROL	CF6-50	AR	1
65B94565-6	BRACKET - CONTROL	CF6-50	AR	1
65B94565-6	BRACKET - CONTROL	CF6-50	AR	3
65B94565-6	BRACKET - CONTROL	CF6-50	AR	1
65B94565-6	BRACKET - CONTROL	CF6-50	AR	1
65B94565-6	BRACKET - CONTROL	CF6-50	AR	1
65B94565-7	BRKT, CONTROL.	CF6-50	AR	1
65B94565-7	BRKT, CONTROL.	CF6-50	AR	1
65B94565-7	BRKT, CONTROL.	CF6-50	AR	1
65B94586-16	TUBE ASSY.	CF6-50 (LMCO)	SV	1
65B94586-16	TUBE ASSY.	CF6-50 (LMCO)	AR	1
65B94586-17	TUBE ASSY.	CF6-50	AR	1
65B94586-18	BRKT-FUEL PR	CF6-50 (LMCO)	AR	1
65B94586-18	BRKT-FUEL PR	CF6-50 (LMCO)	AR	1
65B94602-13	TUBE ASSY	CF6-50 (Boeing)	SV	1
65B94602-13	TUBE ASSY	CF6-50 (Boeing)	OH	1
65B94602-25	TUBE ASSY	CF6-50 (Boeing)	NS	2
65B94604-27	DUCT ASSY	CF6-50 (Boeing)	AR	1
65B94604-27	DUCT ASSY	CF6-50 (Boeing)	AR	1
65B94604-27	DUCT ASSY	CF6-50 (Boeing)	AR	1
65B94604-27	DUCT ASSY	CF6-50 (Boeing)	AR	1
65B94604-27	DUCT ASSY	CF6-50 (Boeing)	AR	1
65B94604-27	DUCT ASSY	CF6-50 (Boeing)	AR	1
65B94604-27	DUCT ASSY	CF6-50 (Boeing)	AR	1
65B94604-27	DUCT ASSY	CF6-50 (Boeing)	SV	1
65B94604-4	DUCT ASSY	CF6-50	AR	1
65B94604-4	DUCT ASSY	CF6-50	AR	1
65B94604-4	DUCT ASSY	CF6-50	AR	1
65B94604-4	DUCT ASSY	CF6-50	AR	1
65B94604-4	DUCT ASSY	CF6-50	AR	1
65B94613-10	TUBE	CF6-50 (Boeing)	AR	1
65B94613-11	TUBE ASSY	CF6-50 (Boeing)	AR	1
65B94613-16	TUBE ASSY	CF6-50 (Boeing)	AR	1
65B94613-21	TUBE ASSY	CF6-50 (Boeing)	AR	1
65B94613-21	TUBE ASSY	CF6-50 (Boeing)	AR	1
65B94613-21	TUBE ASSY	CF6-50 (Boeing)	AR	1
65B94613-21	TUBE ASSY	CF6-50 (Boeing)	AR	1
65B94618-1	DUCT ASSY - INLET	CF6-50	AR	1
65B94618-1	DUCT ASSY - INLET	CF6-50	AR	1
65B94618-1	DUCT ASSY - INLET	CF6-50	AR	1
65B94623-19	BRACKET - FUEL	CF6-50	AR	1
65B94623-19	BRACKET - FUEL	CF6-50	AR	1
65B94623-19	BRACKET - FUEL	CF6-50	AR	1
65B94623-2	BRACKET - FUEL	CF6-50 (Boeing)	NS	2
65B94624-100	BRACKET ASSY	CF6-50 (Boeing)	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
65B94624-100	BRACKET ASSY	CF6-50 (Boeing)	NS	3
65B94624-100	BRACKET ASSY	CF6-50 (Boeing)	NE	1
65B94624-100	BRACKET ASSY	CF6-50 (Boeing)	NS	1
65B94624-100	BRACKET ASSY	CF6-50 (Boeing)	SV	1
65B94624-100	BRACKET ASSY	CF6-50 (Boeing)	AR	1
65B94624-101	BRACKET	CF6-50	AR	1
65B94624-102	BRACKET	CF6-50	AR	1
65B94624-128	BRACKET	CF6-50 (Boeing)	AR	1
65B94624-128	BRACKET	CF6-50 (Boeing)	SV	1
65B94624-128	BRACKET	CF6-50 (Boeing)	SV	1
65B94624-128	BRACKET	CF6-50 (Boeing)	AR	1
65B94624-128	BRACKET	CF6-50 (Boeing)	AR	1
65B94624-128	BRACKET	CF6-50 (Boeing)	AR	1
65B94624-130	CHANNEL ASSY - SPT	CF6-50 (Boeing)	AR	1
65B94624-138	BRACKET ASSY	CF6-50	AR	1
65B94624-31	BRACKET - FIRE DETECTOR	CF6-50	SV	1
65B94624-31	BRACKET - FIRE DETECTOR	CF6-50	AR	1
65B94624-31	BRACKET - FIRE DETECTOR	CF6-50	AR	1
65B94624-33	BRACKET	CF6-50 (Boeing)	AR	1
65B94624-37	BRACKET - FIRE DET	CF6-50	SV	2
65B94624-43	BRKT, FIRE DET.	CF6-50	AR	1
65B94624-43	BRKT, FIRE DET.	CF6-50	AR	1
65B94624-47	BRACKET ASSY - SPT	CF6-50	AR	1
65B94624-47	BRACKET ASSY - SPT	CF6-50	SV	1
65B94624-47	BRACKET ASSY - SPT	CF6-50	AR	1
65B94624-71	BRACKET - FIRE DETECTOR	CF6-50 (Boeing)	AR	1
65B94624-71	BRACKET - FIRE DETECTOR	CF6-50 (Boeing)	AR	5
65B94624-80	BRACKET ASSY - SPT	CF6-50	AR	1
65B94624-80	BRACKET ASSY - SPT	CF6-50	SV	1
65B94624-80	BRACKET ASSY - SPT	CF6-50	AR	1
65B94624-82	BRACKET ASSY	CF6-50 (Boeing)	AR	1
65B94624-82	BRACKET ASSY	CF6-50 (Boeing)	SV	1
65B94624-82	BRACKET ASSY	CF6-50 (Boeing)	AR	1
65B94624-82	BRACKET ASSY	CF6-50 (Boeing)	SV	1
65B94624-84	BRACKET	CF6-50	AR	1
65B94624-84	BRACKET	CF6-50	SV	1
65B94624-85	BRACKET	CF6-50	AR	1
65B94624-96	CHANNEL ASSY	CF6-50 (Boeing)	SV	1
65B94624-96	CHANNEL ASSY	CF6-50 (Boeing)	AR	1
65B94624-97	CHANNEL ASSY	CF6-50	SV	1
65B94624-97	CHANNEL ASSY	CF6-50	OH	1
65B94624-98	BRACKET	CF6-50 (LMCO)	SV	1
65B94624-98	BRACKET	CF6-50 (LMCO)	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
65B94624-99	BRACKET	CF6-50	SV	1
65B94624-99	BRACKET	CF6-50	SV	1
65B94625-1	BRKT, DRAIN.	CF6-50	AR	1
65B94625-1	BRKT, DRAIN.	CF6-50	AR	1
65B94625-1	BRKT, DRAIN.	CF6-50	AR	1
65B94625-1	BRKT, DRAIN.	CF6-50	AR	1
65B94625-1	BRKT, DRAIN.	CF6-50	AR	1
65B94625-1	BRKT, DRAIN.	CF6-50	AR	1
65B94625-1	BRKT, DRAIN.	CF6-50	AR	1
65B94625-1	BRKT, DRAIN.	CF6-50	AR	1
65B94625-27	BRACKET	CF6-50 (Boeing)	NS	2
65B94625-3	BRKT-DRAIN	CF6-50	AR	1
65B94630-1	BRACKET ASSY - STARTER VALVE	CF6-50 (LMCO)	AR	1
65B94630-1	BRACKET ASSY - STARTER VALVE	CF6-50 (LMCO)	AR	1
65B94630-1	BRACKET ASSY - STARTER VALVE	CF6-50 (LMCO)	AR	1
65B94630-1	BRACKET ASSY - STARTER VALVE	CF6-50 (LMCO)	AR	1
65B94633-9	BRKT, INSTR.	CF6-50	AR	1
65B94633-9	BRKT, INSTR.	CF6-50	AR	1
65B94633-9	BRKT, INSTR.	CF6-50	AR	1
65B94634-1	BRKT, ELECT	CF6-50	AR	1
65B94634-1	BRKT, ELECT	CF6-50	AR	1
65B94634-1	BRKT, ELECT	CF6-50	SV	1
65B94634-1	BRKT, ELECT	CF6-50	SV	1
65B94634-103	BRACKET ELECT.	CF6-50 (LMCO)	AR	1
65B94634-103	BRACKET ELECT.	CF6-50 (LMCO)	AR	1
65B94634-105	BRACKET - ELECTRICAL	CF6-50 (LMCO)	NE	1
65B94634-105	BRACKET - ELECTRICAL	CF6-50 (LMCO)	NE	2
65B94634-105	BRACKET - ELECTRICAL	CF6-50 (LMCO)	AR	1
65B94634-121	BRACKET - ELECTRICAL	CF6-50 (Boeing)	AR	1
65B94634-121	BRACKET - ELECTRICAL	CF6-50 (Boeing)	AR	1
65B94634-121	BRACKET - ELECTRICAL	CF6-50 (Boeing)	AR	1
65B94634-121	BRACKET - ELECTRICAL	CF6-50 (Boeing)	AR	1
65B94634-121	BRACKET - ELECTRICAL	CF6-50 (Boeing)	AR	1
65B94634-121	BRACKET - ELECTRICAL	CF6-50 (Boeing)	AR	1
65B94634-121	BRACKET - ELECTRICAL	CF6-50 (Boeing)	AR	1
65B94634-121	BRACKET - ELECTRICAL	CF6-50 (Boeing)	AR	1
65B94634-121	BRACKET - ELECTRICAL	CF6-50 (Boeing)	AR	3
65B94634-121	BRACKET - ELECTRICAL	CF6-50 (Boeing)	OH	2
65B94634-121	BRACKET - ELECTRICAL	CF6-50 (Boeing)	AR	1
65B94634-121	BRACKET - ELECTRICAL	CF6-50 (Boeing)	AR	1
65B94634-121	BRACKET - ELECTRICAL	CF6-50 (Boeing)	AR	1
65B94634-121	BRACKET - ELECTRICAL	CF6-50 (Boeing)	AR	1
65B94634-121	BRACKET - ELECTRICAL	CF6-50 (Boeing)	AR	1
65B94634-121	BRACKET - ELECTRICAL	CF6-50 (Boeing)	SV	1
65B94634-121	BRACKET - ELECTRICAL	CF6-50 (Boeing)	SV	3
65B94634-121	BRACKET - ELECTRICAL	CF6-50 (Boeing)	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
65B94634-126	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-126	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-126	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-126	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-126	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-126	BRACKET - ELECTRICAL	CF6-50	SV	1
65B94634-149	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-149	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-149	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-149	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-151	BRKT, ELECT.	CF6-50	AR	1
65B94634-151	BRKT, ELECT.	CF6-50	AR	1
65B94634-155	BRACKET	CF6-50	AR	1
65B94634-155	BRACKET	CF6-50	AR	1
65B94634-155	BRACKET	CF6-50	AR	1
65B94634-155	BRACKET	CF6-50	AR	1
65B94634-155	BRACKET	CF6-50	AR	1
65B94634-155	BRACKET	CF6-50	AR	1
65B94634-155	BRACKET	CF6-50	AR	1
65B94634-21	BRACKET - ELECTRICAL	CF6-50	SV	1
65B94634-21	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-21	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-21	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-21	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-21	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-21	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-21	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-21	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-21	BRACKET - ELECTRICAL	CF6-50	AR	2
65B94634-21	BRACKET - ELECTRICAL	CF6-50	SV	1
65B94634-21	BRACKET - ELECTRICAL	CF6-50	SV	1
65B94634-21	BRACKET - ELECTRICAL	CF6-50	SV	1
65B94634-23	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-23	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-23	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-23	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-25	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-25	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-25	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-25	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-25	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-25	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-25	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-27	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-27	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-27	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-29	BRACKET- ELCT	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
65B94634-29	BRACKET- ELCT	CF6-50 (LMCO)	AR	1
65B94634-31	BRKT-ELECT.	CF6-50 (LMCO)	AR	1
65B94634-51	BRKT-ELECT.	CF6-50	AR	1
65B94634-51	BRKT-ELECT.	CF6-50	AR	1
65B94634-51	BRKT-ELECT.	CF6-50	AR	1
65B94634-62	BRAKET (2REQD)	CF6-50	AR	1
65B94634-62	BRAKET (2REQD)	CF6-50	AR	1
65B94634-62	BRAKET (2REQD)	CF6-50	AR	1
65B94634-62	BRAKET (2REQD)	CF6-50	AR	1
65B94634-62	BRAKET (2REQD)	CF6-50	AR	1
65B94634-62	BRAKET (2REQD)	CF6-50	AR	1
65B94634-62	BRAKET (2REQD)	CF6-50	SV	1
65B94634-71	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-85	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-85	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-85	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94634-85	BRACKET - ELECTRICAL	CF6-50	SV	1
65B94634-85	BRACKET - ELECTRICAL	CF6-50	SV	2
65B94634-86	BRKT-ELECT.	CF6-50 (LMCO)	AR	1
65B94634-86	BRKT-ELECT.	CF6-50 (LMCO)	AR	1
65B94636-23	BRACKET - HYDRAULIC	CF6-50	AR	1
65B94636-23	BRACKET - HYDRAULIC	CF6-50	AR	1
65B94636-23	BRACKET - HYDRAULIC	CF6-50	AR	1
65B94636-23	BRACKET - HYDRAULIC	CF6-50	AR	1
65B94636-27	BRKT-HYD.	CF6-50	AR	1
65B94636-37	BRACKET	CF6-50	AR	1
65B94636-37	BRACKET	CF6-50	AR	1
65B94636-37	BRACKET	CF6-50	AR	1
65B94636-37	BRACKET	CF6-50	AR	1
65B94636-46	BRACKET - HYDRAULIC	CF6-50	AR	1
65B94636-46	BRACKET - HYDRAULIC	CF6-50	AR	1
65B94636-46	BRACKET - HYDRAULIC	CF6-50	AR	1
65B94636-52	BRKT-HYD.	CF6-50	AR	1
65B94636-53	BRKT, HYD.	CF6-50 (LMCO)	AR	1
65B94636-53	BRKT, HYD.	CF6-50 (LMCO)	AR	1
65B94636-53	BRKT, HYD.	CF6-50 (LMCO)	AR	1
65B94636-59	BRACKET - HYDRAULIC	CF6-50	AR	1
65B94636-7	BRACKET - HYDRAULIC	CF6-50	AR	1
65B94636-7	BRACKET - HYDRAULIC	CF6-50	AR	1
65B94636-7	BRACKET - HYDRAULIC	CF6-50	AR	1
65B94639-16	TUBE ASSY	CF6-50 (Boeing)	NE	1
65B94639-17	TUBE ASSY	CF6-50 (Boeing)	NE	1
65B94639-17	TUBE ASSY	CF6-50 (Boeing)	OH	1
65B94639-17	TUBE ASSY	CF6-50 (Boeing)	AR	1
65B94639-28	LINE - OIL	CF6-50	AR	1
65B94639-28	LINE - OIL	CF6-50	AR	1
65B94639-28	LINE - OIL	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
65B94639-28	LINE - OIL	CF6-50	AR	1
65B94639-28	LINE - OIL	CF6-50	AR	1
65B94639-30	TUBE ASSY	CF6-50	AR	1
65B94639-30	TUBE ASSY	CF6-50	AR	1
65B94639-30	TUBE ASSY	CF6-50	AR	1
65B94639-30	TUBE ASSY	CF6-50	SV	1
65B94639-31	TUBE ASSY	CF6-50 (Boeing)	AR	1
65B94639-31	TUBE ASSY	CF6-50 (Boeing)	SV	1
65B94639-34	TUBE	CF6-50	AR	1
65B94639-34	TUBE	CF6-50	AR	1
65B94639-34	TUBE	CF6-50	AR	1
65B94639-34	TUBE	CF6-50	AR	1
65B94639-34	TUBE	CF6-50	AR	1
65B94639-34	TUBE	CF6-50	AR	1
65B94639-600	TUBE ASSY	CF6-80C2, CF6-50 (Boeing)	AR	1
65B94639-600	TUBE ASSY	CF6-80C2, CF6-50 (Boeing)	AR	1
65B94639-600	TUBE ASSY	CF6-80C2, CF6-50 (Boeing)	OH	1
65B94639-600	TUBE ASSY	CF6-80C2, CF6-50 (Boeing)	NS	1
65B94639-600	TUBE ASSY	CF6-80C2, CF6-50 (Boeing)	SV	1
65B94639-7	COLLECTOR - TANK	CF6-50 (Boeing)	AR	1
65B94639-7	COLLECTOR - TANK	CF6-50 (Boeing)	AR	1
65B94639-7	COLLECTOR - TANK	CF6-50 (Boeing)	AR	1
65B94639-7	COLLECTOR - TANK	CF6-50 (Boeing)	AR	1
65B94639-7	COLLECTOR - TANK	CF6-50 (Boeing)	AR	1
65B94661-2	TUBE ASSY	CF6-50 (Boeing)	AR	1
65B94661-2	TUBE ASSY	CF6-50 (Boeing)	AR	1
65B94663-4	FILLER	CF6-50 (Boeing)	NE	2
65B94681-3	BRKT-CONT.	CF6-50 (LMCO)	AR	1
65B94681-3	BRKT-CONT.	CF6-50 (LMCO)	AR	1
65B94683-1	HOUSING	CF6-50	AR	1
65B94683-4	PLATE	CF6-50 (LMCO)	AR	1
65B94683-4	PLATE	CF6-50 (LMCO)	AR	1
65B94690-9	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94690-9	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94690-9	BRACKET - ELECTRICAL	CF6-50	AR	1
65B94692-3	TUBE ASSY.	CF6-50	AR	1
65B94692-4	TUBE ASSY.	CF6-50 (LMCO)	AR	1
65B94692-4	TUBE ASSY.	CF6-50 (LMCO)	AR	1
65B94692-4	TUBE ASSY.	CF6-50 (LMCO)	AR	1
65B94692-4	TUBE ASSY.	CF6-50 (LMCO)	SV	1
65B94692-8	TUBE ASSY	CF6-50 (Boeing)	AR	1
65B94692-8	TUBE ASSY	CF6-50 (Boeing)	AR	1
65B94692-8	TUBE ASSY	CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
65B94692-8	TUBE ASSY	CF6-50 (Boeing)	AR	1
65B94692-9	TUBE ASSY - DRAIN 3/4 IN.	CF6-50 (Boeing)	AR	1
65B94692-9	TUBE ASSY - DRAIN 3/4 IN.	CF6-50 (Boeing)	AR	1
65B94813-2	DUCT - TEE	CF6-50 (Boeing)	OH	1
65B94814-3	DUCT ASSY (WELDED)	CF6-50 (Boeing)	AR	1
65B94814-3	DUCT ASSY (WELDED)	CF6-50 (Boeing)	AR	1
65B94814-3	DUCT ASSY (WELDED)	CF6-50 (Boeing)	AR	1
65B94814-3	DUCT ASSY (WELDED)	CF6-50 (Boeing)	AR	1
65B94814-3	DUCT ASSY (WELDED)	CF6-50 (Boeing)	AR	1
65B94814-3	DUCT ASSY (WELDED)	CF6-50 (Boeing)	AR	1
65B94814-3	DUCT ASSY (WELDED)	CF6-50 (Boeing)	AR	1
65B94814-3	DUCT ASSY (WELDED)	CF6-50 (Boeing)	AR	1
65B94819-2	DUCT - BLEED AIR STG 8TH	CF6-50	AR	1
65B94819-2	DUCT - BLEED AIR STG 8TH	CF6-50	AR	1
65B94819-2	DUCT - BLEED AIR STG 8TH	CF6-50	AR	1
65B94819-2	DUCT - BLEED AIR STG 8TH	CF6-50	AR	1
660-022M08N-130S	COVER	CF6-80C2	NE	1
6720085E23	NOZZLE - FUEL	CF6-50 (Boeing)	OH	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
6740281E33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

[illegible]

Part Number	Part Description	Engine Type	Condition	Quantity
6980200E8	NOZZLE - FUEL	CF6-80C2	OH	1
6980200E8	NOZZLE - FUEL	CF6-80C2	OH	1
6980200E8	NOZZLE - FUEL	CF6-80C2	OH	1
6980200E8	NOZZLE - FUEL	CF6-80C2	OH	1
6980200E8	NOZZLE - FUEL	CF6-80C2	OH	1
6980200E8	NOZZLE - FUEL	CF6-80C2	OH	1
6980200E8	NOZZLE - FUEL	CF6-80C2	OH	1
69B94002-15	BRACKET - FIRE DETECTOR	CF6-50	AR	2
69B94002-15	BRACKET - FIRE DETECTOR	CF6-50	AR	1
69B94002-15	BRACKET - FIRE DETECTOR	CF6-50	AR	1
69B94002-15	BRACKET - FIRE DETECTOR	CF6-50	AR	1
69B94002-15	BRACKET - FIRE DETECTOR	CF6-50	SV	3
69B94002-17	BRACKET - FIRE DETECTOR	CF6-50	AR	1
69B94002-17	BRACKET - FIRE DETECTOR	CF6-50	AR	1
69B94002-19	BRACKET - FIRE DETECTOR	CF6-50	NS	1
69B94002-19	BRACKET - FIRE DETECTOR	CF6-50	AR	1
69B94002-19	BRACKET - FIRE DETECTOR	CF6-50	SV	1
69B94002-27	BRKT, FIRE DET.	CF6-50	AR	1
69B94002-27	BRKT, FIRE DET.	CF6-50	AR	1
69B94002-27	BRKT, FIRE DET.	CF6-50	AR	1
69B94003-4	ROD - FTG COWL	CF6-50	AR	1
69B94003-5	ROD - FTG COWL	CF6-50 (Boeing)	AR	1
69B94005-1	BRACKET	CF6-50	AR	1
69B94005-1	BRACKET	CF6-50	AR	1
69B94005-2	ROD - FTG COWL	CF6-50 (Boeing)	AR	1
69B94005-3	SPACER	CF6-50 (Boeing)	AR	1
69B94005-3	SPACER	CF6-50 (Boeing)	AR	1
69B94005-3	SPACER	CF6-50 (Boeing)	NS	2
69B94005-5	FTG-COWL ROD	CF6-50 (LMCO)	AR	1
69B94005-5	FTG-COWL ROD	CF6-50 (LMCO)	AR	1
69B94005-6	BRACKET	CF6-50 (Boeing)	OH	1
69B94007-1	CLEVIS	CF6-50 (Boeing)	NS	1
69B94008-1	LINK	CF6-50 (Boeing)	AR	1
69B94008-1	LINK	CF6-50 (Boeing)	NE	5
69B94008-1	LINK	CF6-50 (Boeing)	AR	1
69B94013-1	SLEEVE	CF6-50 (Boeing)	AR	1
69B94013-1	SLEEVE	CF6-50 (Boeing)	AR	1
69B94015-5	FITTING - TRUST	CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
69B94017-1	SEAL	CF6-50 (Boeing)	NS	1
69B94019-1	BRACKET - AIR DUCT	CF6-50	SV	1
69B94019-1	BRACKET - AIR DUCT	CF6-50	AR	1
69B94019-2	BRACKET - AIR DUCT	CF6-50	AR	1
69B94019-2	BRACKET - AIR DUCT	CF6-50	AR	1
69B94019-2	BRACKET - AIR DUCT	CF6-50	SV	1
69B94019-3	BRACKET - AIR DUCT	CF6-50	AR	1
69B94019-3	BRACKET - AIR DUCT	CF6-50	AR	1
69B94019-3	BRACKET - AIR DUCT	CF6-50	AR	1
69B94019-4	BRACKET - AIR DUCT	CF6-50	AR	1
69B94019-4	BRACKET - AIR DUCT	CF6-50	AR	1
69B94020-3	BRACKET - AIR DUCT	CF6-50	AR	1
69B94020-4	BRACKET - AIR DUCT	CF6-50	AR	1
69B94020-4	BRACKET - AIR DUCT	CF6-50	AR	1
69B94020-5	BRACKET - AIR DUCT	CF6-50	AR	1
69B94020-5	BRACKET - AIR DUCT	CF6-50	AR	1
69B94020-5	BRACKET - AIR DUCT	CF6-50	AR	1
69B94020-5	BRACKET - AIR DUCT	CF6-50	AR	1
69B94020-5	BRACKET - AIR DUCT	CF6-50	SV	1
69B94021-1	CAP - CHANNEL	CF6-50 (LMCO)	NS	9
69B94021-1	CAP - CHANNEL	CF6-50 (LMCO)	AR	1
69B94021-3	BLOCK - CLAMP	CF6-50 (Boeing)	NS	2
69B94021-3	BLOCK - CLAMP	CF6-50 (Boeing)	AR	3
69B94021-4	CAP - CHANNEL	CF6-50	AR	1
69B94021-4	CAP - CHANNEL	CF6-50	AR	3
69B94142-2	RETAINER	CF6-50 (Boeing)	AR	1
69B94142-2	RETAINER	CF6-50 (Boeing)	NS	1
69B94151-1	PIN-INDEXING	CF6-50 (Boeing)	SV	2
69B94155-3	LINKAGE	CF6-50 (Boeing)	AR	2
69B94226-2	LINK - SPRING	CF6-50 (Boeing)	NS	1
69B94226-3	LINK - SPRING	CF6-50 (Boeing)	OH	1
69B94318-3	CAP - CHANNEL	CF6-50 (Boeing)	NE	1
69B94319-1	BRKT-ELECT.	CF6-50	AR	1
69B94319-1	BRKT-ELECT.	CF6-50	AR	1
69B94322-1	BRACKET - SPT	CF6-50 (Boeing)	NS	2
69B94325-2	LINK	CF6-50 (Boeing)	NE	6
69B94346-1	BRKT-INSTR	CF6-50	AR	1
69B94346-1	BRKT-INSTR	CF6-50	AR	1
69B94357-10	LINKAGE	CF6-50	AR	1
69B94357-10	LINKAGE	CF6-50	AR	1
69B94357-10	LINKAGE	CF6-50	AR	1
69B94357-10	LINKAGE	CF6-50	AR	1
69B94357-10	LINKAGE	CF6-50	AR	1
69B94357-10	LINKAGE	CF6-50	AR	1
69B94357-4	ROD - CONTROL	CF6-50 (LMCO)	AR	1
69B97200-3	PIN - SHEAR	CF6-80A, PW2000	NE	5
69B97200-3	PIN - SHEAR	CF6-80A, PW2000	NE	4
7005M95P01	TURNBUCKLE ASSY - SPR	CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
7005M95P01	TURNBUCKLE ASSY - SPR	CF6-50 (Boeing)	AR	1
7005M95P01	TURNBUCKLE ASSY - SPR	CF6-50 (Boeing)	AR	1
7005M95P01	TURNBUCKLE ASSY - SPR	CF6-50 (Boeing)	AR	1
7005M95P01	TURNBUCKLE ASSY - SPR	CF6-50 (Boeing)	AR	1
7005M95P01	TURNBUCKLE ASSY - SPR	CF6-50 (Boeing)	AR	1
7005M95P01	TURNBUCKLE ASSY - SPR	CF6-50 (Boeing)	AR	2
7008M51G01	BRACKET ASSY - FWD MTG	CF6-50	AR	1
7008M51G01	BRACKET ASSY - FWD MTG	CF6-50	AR	1
7008M51G01	BRACKET ASSY - FWD MTG	CF6-50	AR	1
7008M51P01	BRACKET - FWD MTG	CF6-50	AR	1
7008M54G01	BRACKET ASSY - FWD MTG	CF6-50	AR	1
7008M54G01	BRACKET ASSY - FWD MTG	CF6-50	AR	1
7008M54G01	BRACKET ASSY - FWD MTG	CF6-50	AR	1
7008M54P01	BRACKET - FWD MTG	CF6-50	AR	1
7008M55G03	BRACKET ASSY - AFT MTG	CF6-50	AR	1
7008M55G03	BRACKET ASSY - AFT MTG	CF6-50	AR	1
7017M89G01	RING - ISOLATION	CF6-50	AR	1
7017M89G02	RING - ISOLATION	CF6-50	AR	1
7017M89G02	RING - ISOLATION	CF6-50	AR	1
7017M89G02	RING - ISOLATION	CF6-50	AR	1
7017M89G02	RING - ISOLATION	CF6-50	AR	1
7017M89G03	RING - ISOLATION (AFT)	CF6-50	AR	1
7017M89G05	RING - ISOLATION	CF6-50	AR	1
7017M89G05	RING - ISOLATION	CF6-50	SV	1
7017M89G06	RING - ISOLATION	CF6-50	AR	1
7017M89G06	RING - ISOLATION	CF6-50	SV	1
7017M89G07	RING - ISOLATION (AFT)	CF6-50	AR	1
7017M89G08	RING - ISOLATION (AFT)	CF6-50	AR	1
7017M92G01	RING - ISOLATION MTG	CF6-50	AR	1
7017M92G01	RING - ISOLATION MTG	CF6-50	AR	1
7017M92G01	RING - ISOLATION MTG	CF6-50	AR	1
7017M92G01	RING - ISOLATION MTG	CF6-50	SV	2
7017M92G01	RING - ISOLATION MTG	CF6-50	AR	2
7017M92G01	RING - ISOLATION MTG	CF6-50	AR	2
7017M92G02	RING - ISOLATION MTG	CF6-50	AR	1
7017M92G02	RING - ISOLATION MTG	CF6-50	AR	2
7018M19G02	RING - INSOLATION	CF6-50	AR	1
7041M49P01	EYELET	CF6-50	NE	1
7041M56G01	RING - ISOLATION (AFT)	CF6-50	AR	1
7041M56G01	RING - ISOLATION (AFT)	CF6-50	SV	1
7041M56G01	RING - ISOLATION (AFT)	CF6-50	AR	1
7041M56G01	RING - ISOLATION (AFT)	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
7041M56G01	RING - ISOLATION (AFT)	CF6-50	AR	1
7041M56G01	RING - ISOLATION (AFT)	CF6-50	AR	1
7041M56G02	RING - ISOLATION (FWD)	CF6-50	AR	1
7041M56G02	RING - ISOLATION (FWD)	CF6-50	SV	1
7041M56G02	RING - ISOLATION (FWD)	CF6-50	AR	1
7041M56G02	RING - ISOLATION (FWD)	CF6-50	AR	1
7041M56G02	RING - ISOLATION (FWD)	CF6-50	AR	1
7041M56G03	RING - ISOLATION (AFT)	CF6-50	AR	1
7041M56G03	RING - ISOLATION (AFT)	CF6-50	AR	1
7041M56G03	RING - ISOLATION (AFT)	CF6-50	AR	1
7041M56G04	RING - ISOLATION (AFT)	CF6-50	AR	1
7041M56G04	RING - ISOLATION (AFT)	CF6-50	AR	1
7041M56G04	RING - ISOLATION (AFT)	CF6-50	AR	1
7041M56G04	RING - ISOLATION (AFT)	CF6-50	AR	1
7041M57G01	RING - ISOLATION MTG	CF6-50	AR	2
7041M57G01	RING - ISOLATION MTG	CF6-50	AR	1
7041M57G01	RING - ISOLATION MTG	CF6-50	AR	2
7041M57G01	RING - ISOLATION MTG	CF6-50	AR	2
7041M57G01	RING - ISOLATION MTG	CF6-50	AR	2
7041M57G01	RING - ISOLATION MTG	CF6-50	AR	1
7041M57G01	RING - ISOLATION MTG	CF6-50	AR	1
7041M57G01	RING - ISOLATION MTG	CF6-50	AR	2
7041M57G01	RING - ISOLATION MTG	CF6-50	AR	1
7041M57G01	RING - ISOLATION MTG	CF6-50	AR	1
7057M25P03	BRACKET - AFT UPPER OIL	CF6-80A	AR	1
7057M25P03	BRACKET - AFT UPPER OIL	CF6-80A	AR	1
7057M27P02	BRACKET - FWD UPPER	CF6-80A	AR	1
705B154P14	RING - RETAINING EXT	CF6-50 (LMCO), CF6-50 (Boeing)	NE	14
705B154P14	RING - RETAINING EXT	CF6-50 (LMCO), CF6-50 (Boeing)	NE	9
705B154P14	RING - RETAINING EXT	CF6-50 (LMCO), CF6-50 (Boeing)	NE	15
705B154P15	RING - RETAINING	CF6-80A	AR	2
705B154P15	RING - RETAINING	CF6-80A	NE	2
705B154P15	RING - RETAINING	CF6-80A	NE	3
705B155P66	RING - RETAINER	CF6-50 (LMCO)	NS	2
705B276P5	RING - RETAINING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
705B276P8	TGB RETAINING RING	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	NS	3
705B276P8	TGB RETAINING RING	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
705B276P9	RING - RETAINER	CF6-50 (LMCO)	NS	3
705B276P9	RING - RETAINER	CF6-50 (LMCO)	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
7068M11P04	MOUNT - ISOLATION	CF6-80C2, CF6-80A	SV	3
7068M11P05	MOUNT - ISOLATION	CF6-80C2, CF6-80A	NE	1
7068M11P05	MOUNT - ISOLATION	CF6-80C2, CF6-80A	NS	4
7068M11P05	MOUNT - ISOLATION	CF6-80C2, CF6-80A	NS	2
7068M11P05	MOUNT - ISOLATION	CF6-80C2, CF6-80A	NE	4
7068M11P05	MOUNT - ISOLATION	CF6-80C2, CF6-80A	NE	4
7068M11P05	MOUNT - ISOLATION	CF6-80C2, CF6-80A	NE	5
7068M11P05	MOUNT - ISOLATION	CF6-80C2, CF6-80A	NE	5
7068M11P05	MOUNT - ISOLATION	CF6-80C2, CF6-80A	NE	5
7068M11P05	MOUNT - ISOLATION	CF6-80C2, CF6-80A	NS	1
7069M94G06	SENSOR - ALTITUDE	CF6-80A	OH	1
707304E	CSD	CF6-50 (LMCO)	AR	1
707304E	CSD	CF6-50 (LMCO)	AR	1
707305	QUICK ATTACH-DETACH KIT	CF6-50 (LMCO)	AR	1
707305	QUICK ATTACH-DETACH KIT	CF6-50 (LMCO)	AR	1
7075M51G04	TANK ASSEMBLY - OIL	CF6-80A	AR	1
7075M51G04	TANK ASSEMBLY - OIL	CF6-80A	AR	1
7075M51G05	TANK ASSEMBLY - OIL	CF6-80A	AR	1
7075M51G05	TANK ASSEMBLY - OIL	CF6-80A	AR	1
7075M51G10	TANK ASSY - OIL	CF6-80C2	SV	1
7075M84G01	BRACKET - PMC	CF6-80A	AR	1
7075M84G01	BRACKET - PMC	CF6-80A	AR	1
707812	BRACKET	CF6-50 (LMCO)	AR	1
707812	BRACKET	CF6-50 (LMCO)	AR	1
707812	BRACKET	CF6-50 (LMCO)	AR	1
707812	BRACKET	CF6-50 (LMCO)	AR	1
707850	SHAFT	CF6-50 (LMCO)	AR	1
707850	SHAFT	CF6-50 (LMCO)	AR	1
707850	SHAFT	CF6-50 (LMCO)	AR	1
707850	SHAFT	CF6-50 (LMCO)	AR	1
707850	SHAFT	CF6-50 (LMCO)	AR	1
707850	SHAFT	CF6-50 (LMCO)	AR	1
7080M93P01	PLUG - SIGHT OIL LEVEL	CF6-80C2	AR	1
7082M59G01	CABLE - ELECTRICAL	CF6-80A	AR	1
7082M59G01	CABLE - ELECTRICAL	CF6-80A	AR	1
7082M59G01	CABLE - ELECTRICAL	CF6-80A	AR	1
7082M59G01	CABLE - ELECTRICAL	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
7082M59G02	CABLE - ELECTRICAL	CF6-80A	AR	1
7082M60G03	CABLE - ELECTRICAL	CF6-80A	AR	1
7082M60G03	CABLE - ELECTRICAL	CF6-80A	AR	1
7082M60G03	CABLE - ELECTRICAL	CF6-80A	SV	1
7082M60G04	CABLE - ELECTRICAL	CF6-80A	AR	1
7082M60G04	CABLE - ELECTRICAL	CF6-80A	AR	1
7082M60G04	CABLE - ELECTRICAL	CF6-80A	SV	1
7082M60G04	CABLE - ELECTRICAL	CF6-80A	AR	1
7082M60G04	CABLE - ELECTRICAL	CF6-80A	AR	1
7082M61G02	CABLE - ELECTRICAL	CF6-80A	AR	1
7082M61G02	CABLE - ELECTRICAL	CF6-80A	AR	1
7082M61G02	CABLE - ELECTRICAL	CF6-80A	AR	1
7082M61G03	CABLE - ELECTRICAL	CF6-80A	AR	1
7082M61G03	CABLE - ELECTRICAL	CF6-80A	AR	1
7082M68G02	CABLE - ELECTRICAL	CF6-80A	AR	1
7082M68G02	CABLE - ELECTRICAL	CF6-80A	AR	1
7082M69G02	CABLE - ELECTRICAL	CF6-80A	AR	1
7082M69G02	CABLE - ELECTRICAL	CF6-80A	AR	1
7082M70G02	CABLE - ELECTRICAL	CF6-80A	AR	1
7082M70G02	CABLE - ELECTRICAL	CF6-80A	AR	1
7082M71G01	CABLE - ELECTRICAL	CF6-80A	AR	1
7082M71G02	CABLE - ELECTRICAL	CF6-80A	AR	1
7083M92G01	BRACKET - PMC	CF6-80A	AR	1
7083M92G01	BRACKET - PMC	CF6-80A	AR	1
7083M92G01	BRACKET - PMC	CF6-80A	AR	1
7084-225	COUPLING	CF6-80C2, CF6-80A	AR	1
7084-225	COUPLING	CF6-80C2, CF6-80A	NS	1
7084-225	COUPLING	CF6-80C2, CF6-80A	NS	1
7084M54G01	BRACKET - PMC	CF6-80A	AR	1
7084M54G01	BRACKET - PMC	CF6-80A	AR	1
7084M54G01	BRACKET - PMC	CF6-80A	AR	1
7084M54G02	BRACKET - PMC	CF6-80A	AR	1
7084M54G02	BRACKET - PMC	CF6-80A	AR	1
7085M19P01	BRACKET - AFT UPPER OIL	CF6-80A	AR	1
7085M28P01	HINGE - UPPER AFT	CF6-80A	AR	1
7085M30P01	BRACKET - AFT UPPER OIL	CF6-80A	AR	1
7085M30P01	BRACKET - AFT UPPER OIL	CF6-80A	AR	1
7085M32P01	BRACKET - AFT UPPER OIL	CF6-80A	AR	1
7085M34P01	BRACKET - AFT LOWER OIL	CF6-80A	AR	1
7085M36P01	BRACKET - AFT LOWER OIL	CF6-80A	AR	1
7085M36P01	BRACKET - AFT LOWER OIL	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
7085M36P01	BRACKET - AFT LOWER OIL	CF6-80A	AR	1
7085M36P01	BRACKET - AFT LOWER OIL	CF6-80A	AR	1
7085M36P01	BRACKET - AFT LOWER OIL	CF6-80A	AR	1
7085M38P01	BRACKET - FWD LOWER	CF6-80A	AR	1
7085M38P01	BRACKET - FWD LOWER	CF6-80A	AR	1
7085M38P01	BRACKET - FWD LOWER	CF6-80A	AR	1
7085M40P01	ADAPTER - REAR MOUNT	CF6-80A	SV	1
7086M90P04	CABLE - GROUNDING	CF6-80A	NE	3
7087M94G03	VALVE - SIGNAL ACTIVE	CF6-80C2	AR	1
7087M94G03	VALVE - SIGNAL ACTIVE	CF6-80C2	AR	1
7097M48P01	SPACER - OIL TANK MOUNT	CF6-80C2	NS	1
71-0182-004	BRACKET	CF6-80A	SV	1
7100M37P01	SENSOR - STATIC	CF6-80A	AR	1
7107M48G03	SENSOR - ALTITUDE	CF6-80A	OH	1
7107M48G03	SENSOR - ALTITUDE	CF6-80A	SV	1
7108M42P01	PLATE - LOCK	CF6-80C2	NE	1
7108M99P01	SPACER - OIL TANK MOUNT	CF6-80C2	NS	2
7109M86P02	RETAINER - BUSHING	CF6-80C2	NS	2
7109M86P02	RETAINER - BUSHING	CF6-80C2	NS	1
7109M86P02	RETAINER - BUSHING	CF6-80C2	NS	1
7109M86P02	RETAINER - BUSHING	CF6-80C2	NS	1
7112M56P02	CAP AND ADAPTER - OIL	CF6-80C2, CF6-80A	SV	1
7112M56P02	CAP AND ADAPTER - OIL	CF6-80C2, CF6-80A	SV	1
7112M56P02	CAP AND ADAPTER - OIL	CF6-80C2, CF6-80A	SV	1
7114M42P04	ISOLATOR - VIBRATION	CF6-80C2	NE	2
7114M42P04	ISOLATOR - VIBRATION	CF6-80C2	NS	1
7114M42P04	ISOLATOR - VIBRATION	CF6-80C2	NE	7
7138M96G01	CABLE - ELECTRICAL W3	CF6-80C2	AR	1
7148M86P01	TUBING - SPIRAL	CF6-80C2	NE	1
7156M94G01	PLUG - ENGINE RTG	CF6-80C2	SV	1
7156M94G01	PLUG - ENGINE RTG	CF6-80C2	SV	1
7157M57G01	CABLE - W1 ELECTRICAL	CF6-80C2	AR	1
7157M57G01	CABLE - W1 ELECTRICAL	CF6-80C2	AR	1
7161M98G01	ENGINE - IDENT PLUG	CF6-80C2	NS	1
7161M98G06	ENGINE - IDENT PLUG	CF6-80C2	AR	1
7161M98G62	ENGINE - IDENT PLUG	CF6-80C2	AR	1
7161M98G64	ENGINE - IDENT PLUG	CF6-80C2	SV	1
718115-28	SEAL	CF6-80C2, CF6-80A	NE	9

Part Number	Part Description	Engine Type	Condition	Quantity
72-63-00-01-001	GEARBOX ASSEMBLY- TRANSFER	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
729490	DRIVE - CONSTANT SPEED	CF6-50	AR	1
729490	DRIVE - CONSTANT SPEED	CF6-50	AR	1
729825B	IDG ASSY	CF6-80A	AR	1
730462A	KIT - QUICK ADAPTER	CF6-80A	AR	1
730844B	KIT - QAD ADAPATER	CF6-80C2, CF6-80A, PW2000	AR	1
730844B	KIT - QAD ADAPATER	CF6-80C2, CF6-80A, PW2000	OH	1
732-13300-01	ACTUATOR - ECM	CF6-80A	SV	1
732-13380-03	ACTUATOR - FUEL SHUTOFF	CF6-80A	AR	1
732-13380-03	ACTUATOR - FUEL SHUTOFF	CF6-80A	AR	1
732-16836-11	NAMEPLATE	CF6-80A	NE	1
732-16860-03	ACTUATOR, FUEL SHUTOFF	CF6-50	AR	1
732-16860-04	ACTUATOR	CF6-50 (LMCO)	AR	1
7350	DETECTOR - FIRE	CF6-80A	SV	1
7351	DETECTOR - FIRE	CF6-80A	REP	1
7351	DETECTOR - FIRE	CF6-80A	REP	1
7351	DETECTOR - FIRE	CF6-80A	REP	1
7351	DETECTOR - FIRE	CF6-80A	REP	1
7351	DETECTOR - FIRE	CF6-80A	REP	1
7351	DETECTOR - FIRE	CF6-80A	REP	1
7351	DETECTOR - FIRE	CF6-80A	SV	1
7352	DETECTOR - FIRE	CF6-80A	OH	1
7352	DETECTOR - FIRE	CF6-80A	SV	1
7352	DETECTOR - FIRE	CF6-80A	SV	1
738SS21-8	SUPPORT - LINE	CF6-80C2	NE	1
744041	GENERATOR - INTEGRATED DRIVE	CF6-80A	AR	1
749859	ADAPTER - QAD KIT	CF6-80C2	AR	1
7578944	FILTER ASSY	CF6-80A	AR	1
7578944	FILTER ASSY	CF6-80A	SV	1
7578944	FILTER ASSY	CF6-80A	AR	1
7578944	FILTER ASSY	CF6-80A	AR	1
7578944	FILTER ASSY	CF6-80A	AR	1
7578944	FILTER ASSY	CF6-80A	AR	1
7578944	FILTER ASSY	CF6-80A	AR	1
7578944	FILTER ASSY	CF6-80A	AR	1
7578944	FILTER ASSY	CF6-80A	AR	1
7583141	FILTER	CF6-80A	NE	3
7583175	FILTER - ELEMENT	CF6-80A	NE	4
7583175	FILTER - ELEMENT	CF6-80A	NE	1

Part Number	Part Description	Engine Type	Condition	Quantity
7587866	FILTER ASSY - HYDR	CF6-80A	AR	1
7587866	FILTER ASSY - HYDR	CF6-80A	AR	1
766088B	IDG	CF6-80C2, CF6-80A	AR	1
7690W19P001	SLEEVE - VITON	CF6-80A	NE	1
76D94-1	EXCHANGER - HEAT	CF6-50	AR	1
773289-15	CONTROL - HP VALVE	CF6-80C2, CF6-80A	SV	1
773289-15	CONTROL - HP VALVE	CF6-80C2, CF6-80A	SV	1
773289-15	CONTROL - HP VALVE	CF6-80C2, CF6-80A	OH	1
773289-15	CONTROL - HP VALVE	CF6-80C2, CF6-80A	OH	1
773856-19	VALVE - CHECK IP	CF6-80C2, CF6-80A	SV	1
773857-21	VALVE - HIGH PRESS SHUTOFF	CF6-80A	SV	1
773857-21	VALVE - HIGH PRESS SHUTOFF	CF6-80A	OH	1
773857-21	VALVE - HIGH PRESS SHUTOFF	CF6-80A	SV	1
773857-4	VALVE - HP SHUTOFF	CF6-80A	AR	1
775538-6	CONTROL - VALVE STARTER	CF6-80A, PW2000	SV	1
775538-6	CONTROL - VALVE STARTER	CF6-80A, PW2000	SV	1
78151-119	SEAL - O-RING	CF6-50	NS	1
78228N1	RING - MATING	CF6-80C2, CF6-80A	NE	1
78229N2	SEAL ASSEMBLY	CF6-80C2	AR	1
7929536M6-0346	HOSE	CF6-50	AR	1
7929552-6-0167	HOSE - OIL TANK DRAIN	CF6-50 (LMCO)	NE	1
80-119-01	CABLE ASSY - ACCELEROMETER	CF6-50 (Boeing)	AR	1
80-120-01	BRACKET	CF6-50 (Boeing)	NS	1
80-120-01	BRACKET	CF6-50 (Boeing)	AR	1
80-200-00	BRACKET	CF6-50 (Boeing)	AR	1
80-200-00	BRACKET	CF6-50 (Boeing)	SV	1
80-200-00	BRACKET	CF6-50 (Boeing)	AR	1
80-200-00	BRACKET	CF6-50 (Boeing)	AR	1
80-200-00	BRACKET	CF6-50 (Boeing)	AR	1
801A50-0005A	C-RING	CF6-50 (Boeing)	NS	5
802170-11	VALVE - HIGH PRESS SHUTOFF	CF6-80C2	OH	1
8061-888	CONTROL - MAIN ENGINE	CF6-80A	AR	1
8061-889	CONTROL - MAIN ENGINE	CF6-80C2	AR	1
8062-819	CONTROL - MAIN ENG FUEL	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
8062-826	CONTROL - MAIN ENG FUEL	CF6-50	AR	1
8062-826	CONTROL - MAIN ENG FUEL	CF6-50	AR	1
8062-826	CONTROL - MAIN ENG FUEL	CF6-50	AR	1
8062-828	CONTROL - MAIN ENG FUEL	CF6-50	AR	1
8062-835	CONTROL - MAIN ENG FUEL	CF6-50 (Boeing)	SV	1
8062-835	CONTROL - MAIN ENG FUEL	CF6-50 (Boeing)	OH	1
8062-848	CONTROL - MAIN ENG FUEL	CF6-50 (LMCO)	AR	1
8062-899	CONTROL - MAIN ENG FUEL	CF6-50	AR	1
8062-899	CONTROL - MAIN ENG FUEL	CF6-50	AR	1
8062-899	CONTROL - MAIN ENG FUEL	CF6-50	AR	1
8062-899	CONTROL - MAIN ENG FUEL	CF6-50	AR	1
8062-899	CONTROL - MAIN ENG FUEL	CF6-50	AR	1
8063-503	CONTROL - MAIN ENGINE	CF6-80A	SV	1
8063-505	CONTROL - MAIN ENGINE	CF6-80A	SV	1
808492-1	FILTER - AIR	CF6-80A	AR	1
808492-1WE	FILTER - AIR	CF6-80A	NE	1
808556-1	VALVE	CF6-80C2, CF6-80A	SV	1
8140-0101	CONDITIONER ASSY - VBV	CF6-50	AR	1
8232MBS-0141	DECAL	CF6-80A	NE	3
8232MBS-0141	DECAL	CF6-80A	NE	1
85465-1	ROTOR - GEN AC	CF6-80C2	SV	1
85465-1	ROTOR - GEN AC	CF6-80C2	SV	1
85465-3	ROTOR - GEN AC	CF6-80C2	SV	1
8552C000	EXCHANGER - FUEL/OIL HEAT	CF6-80C2, CF6-80A	AR	1
8552C000	EXCHANGER - FUEL/OIL HEAT	CF6-80C2, CF6-80A	AR	1
85569-1	STATOR - GEN AC	CF6-80C2	AR	1
86-4101-2	COVER - DUST	CF6-80C2	NE	2
86-4102-2	COVER - DUST	CF6-80C2	NE	1
86-4253-1	ADAPTER	CF6-80C2	NE	1
87006-9	STATOR - GEN AC	CF6-80C2	OH	1
8757-200	SEAL	CF6-80C2	NE	1
8757-200	SEAL	CF6-80C2	NS	10
8757-200	SEAL	CF6-80C2	NS	1
8757-250	SEAL	CF6-80C2	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
8757-250	SEAL	CF6-80C2	NS	1
887111	PUMP - HYDRAULIC	CF6-80C2	OH	1
8896-250	COUPLING	CF6-80C2	SV	1
8901-185	SENSOR - CIT	CF6-80A	AR	1
8901-185	SENSOR - CIT	CF6-80A	AR	1
8901-218	SENSOR - CIT	CF6-50	AR	1
8901-224	SENSOR - CIT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8901-224	SENSOR - CIT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8901-224	SENSOR - CIT	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
8901-224	SENSOR - CIT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8901-224	SENSOR - CIT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8901-224	SENSOR - CIT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8901-224	SENSOR - CIT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8901-224	SENSOR - CIT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8901-224	SENSOR - CIT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8901-224	SENSOR - CIT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8901-224	SENSOR - CIT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8901-224	SENSOR - CIT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8901-224	SENSOR - CIT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8901-224	SENSOR - CIT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8901-224	SENSOR - CIT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8901-224	SENSOR - CIT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8901-224	SENSOR - CIT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8901-224	SENSOR - CIT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8901-224	SENSOR - CIT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8901-224	SENSOR - CIT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8901-254	SENSOR - FAN INLET	CF6-80A	AR	1
8901-254	SENSOR - FAN INLET	CF6-80A	AR	1
8901-254	SENSOR - FAN INLET	CF6-80A	SV	1
8901-254	SENSOR - FAN INLET	CF6-80A	AR	1
8901-254	SENSOR - FAN INLET	CF6-80A	AR	1
8901-328	SENSOR - INLET TEMPERATURE	CF6-80C2	AR	1
898626-3	VALVE ASSY - REGULATOR	CF6-50 (LMCO)	OH	1
898626-3	VALVE ASSY - REGULATOR	CF6-50 (LMCO)	AR	1
898626-4	VALVE ASSY PNEUM. PRESS- REGULATOR	CF6-50 (LMCO)	SV	1
898806-1	VALVE - PRESS REGULATOR	CF6-50 (Boeing)	SV	1
898806-1	VALVE - PRESS REGULATOR	CF6-50 (Boeing)	SV	1
898980-3	VALVE - PRES REG/SHUTOFF	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
898980-3	VALVE - PRES REG/SHUTOFF	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
898980-3	VALVE - PRES REG/SHUTOFF	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
898980-3	VALVE - PRES REG/SHUTOFF	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
898980-3	VALVE - PRES REG/SHUTOFF	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
898980-3	VALVE - PRES REG/SHUTOFF	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
898980-3	VALVE - PRES REG/SHUTOFF	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
898980-3	VALVE - PRES REG/SHUTOFF	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8TC34ABB1	SENSOR - TEMPERATURE	CF6-80A	AR	1
8TC34ABF1	PROBE - THERMOCOUPLE	CF6-80A	AR	1
8TC34ABF2	PROBE - THERMOCOUPLE	CF6-80A	SV	1
8TC34ABF2	PROBE - THERMOCOUPLE	CF6-80A	SV	1
8TC34ABF2	PROBE - THERMOCOUPLE	CF6-80A	SV	1
8TC34ABF2	PROBE - THERMOCOUPLE	CF6-80A	SV	1
8TC34ABF2	PROBE - THERMOCOUPLE	CF6-80A	NE	1
8TC34ABF2	PROBE - THERMOCOUPLE	CF6-80A	SV	1
8TC34ABF2	PROBE - THERMOCOUPLE	CF6-80A	SV	1
8TC34ABF2	PROBE - THERMOCOUPLE	CF6-80A	SV	1
8TC34ABF2	PROBE - THERMOCOUPLE	CF6-80A	SV	1
8TC34ABF2	PROBE - THERMOCOUPLE	CF6-80A	SV	1
8TC34ABF2	PROBE - THERMOCOUPLE	CF6-80A	OH	1
8TC34ABF2	PROBE - THERMOCOUPLE	CF6-80A	OH	1
8TC34ABF2	PROBE - THERMOCOUPLE	CF6-80A	OH	1
8TC34ABF2	PROBE - THERMOCOUPLE	CF6-80A	OH	1
8TC34ABF2	PROBE - THERMOCOUPLE	CF6-80A	OH	1
8TC34ABF2	PROBE - THERMOCOUPLE	CF6-80A	OH	1
8TC34ABF2	PROBE - THERMOCOUPLE	CF6-80A	OH	1
8TC34ABF2	PROBE - THERMOCOUPLE	CF6-80A	OH	1
8TC34ABF2	PROBE - THERMOCOUPLE	CF6-80A	SV	1
8TC34ABF2	PROBE - THERMOCOUPLE	CF6-80A	SV	1
8TC34ABF2	PROBE - THERMOCOUPLE	CF6-80A	SV	1
8TC34ABF2	PROBE - THERMOCOUPLE	CF6-80A	SV	1
8TC34ABF2	PROBE - THERMOCOUPLE	CF6-80A	SV	1
8TC34ABF2	PROBE - THERMOCOUPLE	CF6-80A	SV	1
8TC34ABF2	PROBE - THERMOCOUPLE	CF6-80A	SV	1
8TC34ABV1	TRANSMITTER - OIL TEMP	CF6-80C2	SV	1
8TC34ABW1	PROBE - THERMOCOUPLE	CF6-80C2	SV	1
8TC34ABW1	PROBE - THERMOCOUPLE	CF6-80C2	SV	1
8TC34ABW1	PROBE - THERMOCOUPLE	CF6-80C2	SV	1
8TC34ABW1	PROBE - THERMOCOUPLE	CF6-80C2	SV	1
8TC34ABW1	PROBE - THERMOCOUPLE	CF6-80C2	SV	1
8TC34ABW1	PROBE - THERMOCOUPLE	CF6-80C2	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
8TC34ABW1	PROBE - THERMOCOUPLE	CF6-80C2	SV	1
8TC34ABW1	PROBE - THERMOCOUPLE	CF6-80C2	SV	1
8TE34ACH1	HARNESS - BOT RH TC	CF6-50 (LMCO)	OH	1
8TE34ACH1	HARNESS - BOT RH TC	CF6-50 (LMCO)	AR	1
8TE34ACH1	HARNESS - BOT RH TC	CF6-50 (LMCO)	AR	1
8TE34ACH1	HARNESS - BOT RH TC	CF6-50 (LMCO)	AR	1
8TE34ACH1	HARNESS - BOT RH TC	CF6-50 (LMCO)	AR	1
8TE34ACJ1	HARNESS - BOT LH TC	CF6-50 (LMCO)	SV	1
8TE34ACJ1	HARNESS - BOT LH TC	CF6-50 (LMCO)	SV	1
8TE34ACJ1	HARNESS - BOT LH TC	CF6-50 (LMCO)	SV	1
8TE34ACJ2	HARNESS - BOT LH TC	CF6-50 (LMCO)	AR	1
8TE34ACJ3	HARNESS - BOT LH TC	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8TE34ACJ3	HARNESS - BOT LH TC	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8TE34ACJ3	HARNESS - BOT LH TC	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8TE34ACJ3	HARNESS - BOT LH TC	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8TE34ACJ3	HARNESS - BOT LH TC	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8TE34ACJ3	HARNESS - BOT LH TC	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8TE34ACJ3	HARNESS - BOT LH TC	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8TE34ACJ3	HARNESS - BOT LH TC	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8TE34ACJ3	HARNESS - BOT LH TC	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8TE34ACK1	HARNESS ASSY - TOP RH TC	CF6-50 (LMCO)	SV	1
8TE34ACK1	HARNESS ASSY - TOP RH TC	CF6-50 (LMCO)	SV	1
8TE34ACK2	HARNESS ASSY - TOP RH TC	CF6-50 (LMCO)	AR	1
8TE34ACK2	HARNESS ASSY - TOP RH TC	CF6-50 (LMCO)	AR	1
8TE34ACK2	HARNESS ASSY - TOP RH TC	CF6-50 (LMCO)	AR	1
8TE34ACK2	HARNESS ASSY - TOP RH TC	CF6-50 (LMCO)	AR	1
8TE34ACK2	HARNESS ASSY - TOP RH TC	CF6-50 (LMCO)	AR	1
8TE34ACK2	HARNESS ASSY - TOP RH TC	CF6-50 (LMCO)	AR	1
8TE34BCF3	HARNESS - TOP LH TC	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
8TE34BCF3	HARNESS - TOP LH TC	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
8TE34BCJ3	HARNESS - BOT L TC	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
8TE34BCK2	HARNESS ASSY - TOP RH TC	CF6-50 (LMCO)	NE	1
8TE34BCK2	HARNESS ASSY - TOP RH TC	CF6-50 (LMCO)	OH	1
8TJ124GGA1	XMTR - FUEL FLOW	CF6-80A	SV	1
8TJ124GGA1	XMTR - FUEL FLOW	CF6-80A	OH	1
8TJ124GGA1	XMTR - FUEL FLOW	CF6-80A	OH	1
8TJ124GGD1	XMTR - FUEL FLOW	CF6-80A	AR	1
8TJ124GGN3	FLOWMETER - TRANSMITTER	CF6-80A	OH	1
8TJ124GGT1	FLOWMETER - TRANSMITTER	CF6-80C2	OH	1
8TJ138AAA4	SENSOR - SHAFT SPEED FAN	CF6-80A	AR	1
8TJ138AAA4	SENSOR - SHAFT SPEED FAN	CF6-80A	AR	1
8TJ138AAA5	SENSOR - SHAFT SPEED FAN	CF6-80A	SV	1
8TJ146AAA1	TRANSMITTER - OIL LEVEL	CF6-80C2	AR	1
8TJ146AAA1	TRANSMITTER - OIL LEVEL	CF6-80C2	AR	1
8TJ146AAA1	TRANSMITTER - OIL LEVEL	CF6-80C2	OH	1
8TJ146AAA1	TRANSMITTER - OIL LEVEL	CF6-80C2	SV	1
8TJ146AAA1	TRANSMITTER - OIL LEVEL	CF6-80C2	SV	1
8TJ146AAA1	TRANSMITTER - OIL LEVEL	CF6-80C2	SV	1
8TJ162AAB1	SENSOR - N2 CORE SPEED	CF6-80C2	SV	1
8TJ163AAB1	SENSOR - N1	CF6-80C2	SV	1
8TJ99GAF	TRANSMITTER - OIL QTY	CF6-50 (LMCO)	AR	1
8TJ99GAF2	TRANSMITTER - OIL QTY	CF6-50 (LMCO)	OH	1
8TJ99GAF2	TRANSMITTER - OIL QTY	CF6-50 (LMCO)	AR	1
8TJ99GAF2	TRANSMITTER - OIL QTY	CF6-50 (LMCO)	SV	1
8TJ99GBM2	INDICATOR - OIL QUANTITY	CF6-50	AR	1
8TJ99GBM2	INDICATOR - OIL QUANTITY	CF6-50	AR	1
8TK34AAM1	LEAD - TC	CF6-50	AR	1
8TK34AAR	LEAD - TC FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8TK34AAR	LEAD - TC FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8TK34AAR	LEAD - TC FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8TK34AAR1	LEAD - TC AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8TK34AAR1	LEAD - TC AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8TK34AAR1	LEAD - TC AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8TK34AAR1	LEAD - TC AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
8TK34AAR1	LEAD - TC AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8TK34AAR1	LEAD - TC AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8TK34AAR1	LEAD - TC AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8TK34AAR1	LEAD - TC AFT	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
8TK34AAR1	LEAD - TC AFT	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
8TK34AAR1	LEAD - TC AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8TK34AAR1	LEAD - TC AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8TK34AAR1	LEAD - TC AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
8TK34AAR1	LEAD - TC AFT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
8TK34ABE1	LEAD - TC	CF6-50 (LMCO)	SV	1
8TK34ABE1	LEAD - TC	CF6-50 (LMCO)	AR	1
8TK34ABF1	LEAD - TC FWD	CF6-50 (LMCO)	AR	1
8TK34ACA2	LEAD - TC FWD	CF6-50	AR	1
8TK34ACA2	LEAD - TC FWD	CF6-50	AR	1
8TK34ACA2	LEAD - TC FWD	CF6-50	AR	1
8TK34ACA2	LEAD - TC FWD	CF6-50	NS	1
8TK34ACA2	LEAD - TC FWD	CF6-50	AR	1
8TK34ACB1	LEAD - TC	CF6-50	SV	1
8TK34ACB1	LEAD - TC	CF6-50	AR	1
8TK34ACB1	LEAD - TC	CF6-50	AR	1
8TK34ACB1	LEAD - TC	CF6-50	AR	1
8TK34ACB1	LEAD - TC	CF6-50	OH	1
8TK34ACB1	LEAD - TC	CF6-50	AR	1
8TU34AAE8	PROBE - EPR	CF6-80A	NE	1
8TU34AAE8	PROBE - EPR	CF6-80A	NE	1
8TU34AAE8	PROBE - EPR	CF6-80A	NE	1
8TU34PAB5	PROBE - PLUG	CF6-80A	AR	1
8TU34PAB6	PROBE - PLUG	CF6-80A	SV	1
8TU34PAB6	PROBE - PLUG	CF6-80A	SV	1
8TU34PAB6	PROBE - PLUG	CF6-80A	SV	1
8TU34PAB6	PROBE - PLUG	CF6-80A	SV	1
8TU34PAE1	PROBE - PLUG PRESSURE	CF6-80C2	SV	1
9005M56G01	TUBE - OIL GRBX SHAFT	CF6-50 (Boeing)	AR	1
9005M56G01	TUBE - OIL GRBX SHAFT	CF6-50 (Boeing)	AR	1
9005M56G01	TUBE - OIL GRBX SHAFT	CF6-50 (Boeing)	AR	1
9005M56G01	TUBE - OIL GRBX SHAFT	CF6-50 (Boeing)	AR	1
9005M56G01	TUBE - OIL GRBX SHAFT	CF6-50 (Boeing)	AR	1
9005M56G01	TUBE - OIL GRBX SHAFT	CF6-50 (Boeing)	AR	1
9005M56G01	TUBE - OIL GRBX SHAFT	CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9005M56G01	TUBE - OIL GRBX SHAFT	CF6-50 (Boeing)	AR	1
9005M56G01	TUBE - OIL GRBX SHAFT	CF6-50 (Boeing)	AR	1
9005M56G01	TUBE - OIL GRBX SHAFT	CF6-50 (Boeing)	AR	1
9005M56G01	TUBE - OIL GRBX SHAFT	CF6-50 (Boeing)	AR	1
9005M56G01	TUBE - OIL GRBX SHAFT	CF6-50 (Boeing)	AR	1
9005M56G01	TUBE - OIL GRBX SHAFT	CF6-50 (Boeing)	AR	1
9005M61P01	SLEEVE - TUBE CPLG FLEX	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9005M66G02	MANIFOLD ASSY - PYLON OIL	CF6-50 (Boeing)	AR	1
9005M66G02	MANIFOLD ASSY - PYLON OIL	CF6-50 (Boeing)	AR	1
9005M66G02	MANIFOLD ASSY - PYLON OIL	CF6-50 (Boeing)	AR	1
9005M66G02	MANIFOLD ASSY - PYLON OIL	CF6-50 (Boeing)	AR	1
9005M66G02	MANIFOLD ASSY - PYLON OIL	CF6-50 (Boeing)	AR	1
9005M66G02	MANIFOLD ASSY - PYLON OIL	CF6-50 (Boeing)	AR	1
9005M66G02	MANIFOLD ASSY - PYLON OIL	CF6-50 (Boeing)	AR	1
9005M66G02	MANIFOLD ASSY - PYLON OIL	CF6-50 (Boeing)	AR	1
9005M66G02	MANIFOLD ASSY - PYLON OIL	CF6-50 (Boeing)	AR	1
9005M66G02	MANIFOLD ASSY - PYLON OIL	CF6-50 (Boeing)	AR	1
9005M66G02	MANIFOLD ASSY - PYLON OIL	CF6-50 (Boeing)	AR	1
9005M66G02	MANIFOLD ASSY - PYLON OIL	CF6-50 (Boeing)	AR	1
9005M66G02	MANIFOLD ASSY - PYLON OIL	CF6-50 (Boeing)	AR	1
9005M89G01	TUBE - OIL BRG NO.1	CF6-50 (Boeing)	AR	1
9005M89G01	TUBE - OIL BRG NO.1	CF6-50 (Boeing)	AR	1
9005M89G01	TUBE - OIL BRG NO.1	CF6-50 (Boeing)	OH	1
9005M89G01	TUBE - OIL BRG NO.1	CF6-50 (Boeing)	AR	1
9005M89G01	TUBE - OIL BRG NO.1	CF6-50 (Boeing)	AR	1
9005M89G01	TUBE - OIL BRG NO.1	CF6-50 (Boeing)	AR	1
9006M16G01	NUT ASSY - SLFLKG	CF6-80A, CF6-50	NE	1
9006M21G02	TUBE - SCAVENGE	CF6-80A, CF6-50	AR	1
9006M21G02	TUBE - SCAVENGE	CF6-80A, CF6-50	AR	1
9006M21G02	TUBE - SCAVENGE	CF6-80A, CF6-50	AR	1
9006M21G02	TUBE - SCAVENGE	CF6-80A, CF6-50	AR	1
9006M21G02	TUBE - SCAVENGE	CF6-80A, CF6-50	SV	1
9006M21G02	TUBE - SCAVENGE	CF6-80A, CF6-50	AR	1
9006M21G02	TUBE - SCAVENGE	CF6-80A, CF6-50	AR	1
9006M21G02	TUBE - SCAVENGE	CF6-80A, CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9006M21G02	TUBE - SCAVENGE	CF6-80A, CF6-50	AR	1
9006M21G02	TUBE - SCAVENGE	CF6-80A, CF6-50	AR	1
9006M21G02	TUBE - SCAVENGE	CF6-80A, CF6-50	AR	1
9006M24G02	TUBE ASSY - OIL SUPPLY	CF6-50 (LMCO)	AR	1
9006M24G02	TUBE ASSY - OIL SUPPLY	CF6-50 (LMCO)	OH	1
9006M31G02	TUBE - SCAVENGE	CF6-80A	AR	1
9006M31G02	TUBE - SCAVENGE	CF6-80A	AR	1
9006M31G02	TUBE - SCAVENGE	CF6-80A	AR	1
9006M31G02	TUBE - SCAVENGE	CF6-80A	AR	1
9006M31G02	TUBE - SCAVENGE	CF6-80A	AR	1
9006M31G02	TUBE - SCAVENGE	CF6-80A	SV	1
9006M31G02	TUBE - SCAVENGE	CF6-80A	AR	1
9006M31G02	TUBE - SCAVENGE	CF6-80A	AR	1
9006M31G02	TUBE - SCAVENGE	CF6-80A	AR	1
9006M31G02	TUBE - SCAVENGE	CF6-80A	AR	1
9006M31G02	TUBE - SCAVENGE	CF6-80A	AR	1
9006M31G02	TUBE - SCAVENGE	CF6-80A	AR	1
9006M79G02	MOUNT ASSY - GRBX THRUST	CF6-50	SV	1
9006M79G02	MOUNT ASSY - GRBX THRUST	CF6-50	AR	1
9006M79G02	MOUNT ASSY - GRBX THRUST	CF6-50	AR	1
9006M79G02	MOUNT ASSY - GRBX THRUST	CF6-50	AR	1
9006M79G02	MOUNT ASSY - GRBX THRUST	CF6-50	AR	1
9006M79G02	MOUNT ASSY - GRBX THRUST	CF6-50	AR	1
9006M86P01	LINK	CF6-50 (Boeing)	OH	1
9006M97P01	RETAINER - SEAL	CF6-80A, CF6-50	AR	1
9006M97P03	RETAINER - SEAL	CF6-80A, CF6-50	SV	1
9008M43G03	MANIFOLD ASSY - FUEL SHRD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9008M43G03	MANIFOLD ASSY - FUEL SHRD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9008M43G03	MANIFOLD ASSY - FUEL SHRD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9008M43G06	MANIFOLD ASSY - FUEL SHRD	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9008M43G06	MANIFOLD ASSY - FUEL SHRD	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9008M43G06	MANIFOLD ASSY - FUEL SHRD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9008M77G02	TUBE ASSY - XFR GRBX PMP	CF6-50	AR	1
9008M77G02	TUBE ASSY - XFR GRBX PMP	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9008M77G02	TUBE ASSY - XFR GRBX PMP	CF6-50	AR	1
9009M11P01	SPACER - WASHER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9009M11P01	SPACER - WASHER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9009M11P01	SPACER - WASHER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9009M11P02	SPACER - WASHER	CF6-80A	NS	2
9009M14P16	FLANGE - BUSHING	CF6-80C2	NE	2
9009M15G01	NOZZLE - ASSY	CF6-50 (LMCO)	OH	1
9009M15G01	NOZZLE - ASSY	CF6-50 (LMCO)	AR	1
9009M15G01	NOZZLE - ASSY	CF6-50 (LMCO)	AR	1
9009M15G01	NOZZLE - ASSY	CF6-50 (LMCO)	AR	1
9009M15G01	NOZZLE - ASSY	CF6-50 (LMCO)	AR	1
9009M15G01	NOZZLE - ASSY	CF6-50 (LMCO)	SV	1
9009M15G01	NOZZLE - ASSY	CF6-50 (LMCO)	AR	1
9009M15G01	NOZZLE - ASSY	CF6-50 (LMCO)	OH	1
9009M15G01	NOZZLE - ASSY	CF6-50 (LMCO)	AR	1
9009M15G01	NOZZLE - ASSY	CF6-50 (LMCO)	AR	1
9009M15G01	NOZZLE - ASSY	CF6-50 (LMCO)	AR	1
9009M15G01	NOZZLE - ASSY	CF6-50 (LMCO)	AR	1
9009M15G01	NOZZLE - ASSY	CF6-50 (LMCO)	AR	1
9009M15G01	NOZZLE - ASSY	CF6-50 (LMCO)	AR	1
9009M15G01	NOZZLE - ASSY	CF6-50 (LMCO)	OH	1
9009M15G01	NOZZLE - ASSY	CF6-50 (LMCO)	AR	1
9009M19P03	PLUG - METERING	CF6-50 (Boeing)	NE	1
9009M24P02	TURNBUCKLE	CF6-50 (Boeing)	AR	1
9009M24P02	TURNBUCKLE	CF6-50 (Boeing)	AR	1
9009M24P02	TURNBUCKLE	CF6-50 (Boeing)	AR	1
9009M24P02	TURNBUCKLE	CF6-50 (Boeing)	AR	1
9009M24P02	TURNBUCKLE	CF6-50 (Boeing)	AR	1
9009M24P02	TURNBUCKLE	CF6-50 (Boeing)	AR	1
9009M24P02	TURNBUCKLE	CF6-50 (Boeing)	AR	1
9009M24P02	TURNBUCKLE	CF6-50 (Boeing)	AR	1
9009M24P02	TURNBUCKLE	CF6-50 (Boeing)	AR	1
9009M24P02	TURNBUCKLE	CF6-50 (Boeing)	AR	1
9009M24P02	TURNBUCKLE	CF6-50 (Boeing)	AR	1
9009M24P02	TURNBUCKLE	CF6-50 (Boeing)	AR	1
9009M24P02	TURNBUCKLE	CF6-50 (Boeing)	AR	1
9009M24P02	TURNBUCKLE	CF6-50 (Boeing)	AR	1
9009M24P02	TURNBUCKLE	CF6-50 (Boeing)	OH	1
9009M24P02	TURNBUCKLE	CF6-50 (Boeing)	OH	1
9009M24P02	TURNBUCKLE	CF6-50 (Boeing)	AR	1
9009M24P02	TURNBUCKLE	CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9009M24P02	TURNBUCKLE	CF6-50 (Boeing)	AR	1
9009M29P01	BRACKET - BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M29P01	BRACKET - BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9009M29P01	BRACKET - BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9009M29P01	BRACKET - BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M29P01	BRACKET - BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M29P01	BRACKET - BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9009M29P01	BRACKET - BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M29P01	BRACKET - BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M29P01	BRACKET - BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M29P01	BRACKET - BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M29P01	BRACKET - BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M29P01	BRACKET - BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M29P01	BRACKET - BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M29P01	BRACKET - BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M29P01	BRACKET - BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9009M29P01	BRACKET - BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9009M29P01	BRACKET - BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9009M29P01	BRACKET - BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9009M29P01	BRACKET - BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M29P01	BRACKET - BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9009M29P01	BRACKET - BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M29P01	BRACKET - BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M33P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9009M36G01	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M36G01	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M36G01	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M36G01	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M36G01	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9009M36G01	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M36G01	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M36G01	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M36G01	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M36G01	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M36G01	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9009M36G01	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M36G01	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M36G01	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M36G01	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M36G01	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M36G01	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M38P01	SEAL - FLGD OIL CONST SP DR	CF6-50 (LMCO)	NS	1
9009M39P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M39P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M39P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M39P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M39P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M39P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M39P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M39P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M39P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M39P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M39P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M39P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M39P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M39P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M39P08	SEAL - CARB FLNG OIL AC GEN	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M39P08	SEAL - CARB FLNG OIL AC GEN	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M39P08	SEAL - CARB FLNG OIL AC GEN	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M39P08	SEAL - CARB FLNG OIL AC GEN	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M39P08	SEAL - CARB FLNG OIL AC GEN	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9009M39P08	SEAL - CARB FLNG OIL AC GEN	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M39P08	SEAL - CARB FLNG OIL AC GEN	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M39P08	SEAL - CARB FLNG OIL AC GEN	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M39P08	SEAL - CARB FLNG OIL AC GEN	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M39P08	SEAL - CARB FLNG OIL AC GEN	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M41G09	TRANSFER GRBX - MAIN HSG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M41G09	TRANSFER GRBX - MAIN HSG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M41G09	TRANSFER GRBX - MAIN HSG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M41G09	TRANSFER GRBX - MAIN HSG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M41G09	TRANSFER GRBX - MAIN HSG	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M41G09	TRANSFER GRBX - MAIN HSG	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M41G09	TRANSFER GRBX - MAIN HSG	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M41G09	TRANSFER GRBX - MAIN HSG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M41G09	TRANSFER GRBX - MAIN HSG	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M41G09	TRANSFER GRBX - MAIN HSG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M41G09	TRANSFER GRBX - MAIN HSG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M41G13	TRANSFER GRBX - MAIN HSG	CF6-50 (LMCO)	AR	1
9009M45P03	BEARING - DX THR BALL	CF6-50	AR	1
9009M45P04	BEARING - DX THR BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M45P04	BEARING - DX THR BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M45P04	BEARING - DX THR BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M45P04	BEARING - DX THR BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M45P04	BEARING - DX THR BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M45P04	BEARING - DX THR BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M45P04	BEARING - DX THR BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9009M45P04	BEARING - DX THR BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M45P04	BEARING - DX THR BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M45P04	BEARING - DX THR BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M45P04	BEARING - DX THR BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M47G02	ADAPTER ASSY - XFR GRBX AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M47G02	ADAPTER ASSY - XFR GRBX AFT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M47G02	ADAPTER ASSY - XFR GRBX AFT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M47G02	ADAPTER ASSY - XFR GRBX AFT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M47G02	ADAPTER ASSY - XFR GRBX AFT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M47G02	ADAPTER ASSY - XFR GRBX AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M47G02	ADAPTER ASSY - XFR GRBX AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M47G02	ADAPTER ASSY - XFR GRBX AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M47G02	ADAPTER ASSY - XFR GRBX AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M47G02	ADAPTER ASSY - XFR GRBX AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M47G02	ADAPTER ASSY - XFR GRBX AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M47P02	ADAPTER - XFR GRBX	CF6-50 (LMCO)	OH	1
9009M49P01	HOUSING - DUPLEX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M49P01	HOUSING - DUPLEX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M49P01	HOUSING - DUPLEX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M49P01	HOUSING - DUPLEX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M49P01	HOUSING - DUPLEX	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M49P01	HOUSING - DUPLEX	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M49P01	HOUSING - DUPLEX	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M49P01	HOUSING - DUPLEX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M49P01	HOUSING - DUPLEX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9009M49P01	HOUSING - DUPLEX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M49P01	HOUSING - DUPLEX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M49P01	HOUSING - DUPLEX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M49P01	HOUSING - DUPLEX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M49P01	HOUSING - DUPLEX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M50P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M50P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M50P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M50P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M50P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M50P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M50P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9009M50P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9009M50P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M50P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M50P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M50P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M51P02	NUT - GRSHFT RND SLFLKG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M51P02	NUT - GRSHFT RND SLFLKG	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9009M51P02	NUT - GRSHFT RND SLFLKG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M51P02	NUT - GRSHFT RND SLFLKG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M51P02	NUT - GRSHFT RND SLFLKG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M51P02	NUT - GRSHFT RND SLFLKG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M51P02	NUT - GRSHFT RND SLFLKG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M51P02	NUT - GRSHFT RND SLFLKG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9009M51P02	NUT - GRSHFT RND SLFLKG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M51P02	NUT - GRSHFT RND SLFLKG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M51P02	NUT - GRSHFT RND SLFLKG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M53P02	NUT - GRSHFT RND SLFLKG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M53P02	NUT - GRSHFT RND SLFLKG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M53P02	NUT - GRSHFT RND SLFLKG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M53P02	NUT - GRSHFT RND SLFLKG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M53P02	NUT - GRSHFT RND SLFLKG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M53P02	NUT - GRSHFT RND SLFLKG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M53P02	NUT - GRSHFT RND SLFLKG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M53P02	NUT - GRSHFT RND SLFLKG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M53P02	NUT - GRSHFT RND SLFLKG	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9009M53P02	NUT - GRSHFT RND SLFLKG	CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9009M53P02	NUT - GRSHFT RND SLFLKG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M53P02	NUT - GRSHFT RND SLFLKG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M53P02	NUT - GRSHFT RND SLFLKG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M54G02	BRACKET ASSY - ACCESS GRBX	CF6-50	AR	1
9009M59G02	TRANSFER GRBX - RADIAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M59G02	TRANSFER GRBX - RADIAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M59G02	TRANSFER GRBX - RADIAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M59G02	TRANSFER GRBX - RADIAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M59G02	TRANSFER GRBX - RADIAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M59G02	TRANSFER GRBX - RADIAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M59G02	TRANSFER GRBX - RADIAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M59G02	TRANSFER GRBX - RADIAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9009M59G02	TRANSFER GRBX - RADIAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M59G02	TRANSFER GRBX - RADIAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M59G02	TRANSFER GRBX - RADIAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M59G02	TRANSFER GRBX - RADIAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M59G02	TRANSFER GRBX - RADIAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M59G02	TRANSFER GRBX - RADIAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M60G03	HOUSING ASSY - RDL DR SHIFT	CF6-50	AR	1
9009M60G03	HOUSING ASSY - RDL DR SHIFT	CF6-50	AR	1
9009M60G03	HOUSING ASSY - RDL DR SHIFT	CF6-50	AR	1
9009M60G03	HOUSING ASSY - RDL DR SHIFT	CF6-50	AR	1
9009M60G03	HOUSING ASSY - RDL DR SHIFT	CF6-50	AR	1
9009M60G05	HOUSING ASSY - RDL DR SHFT	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9009M60G05	HOUSING ASSY - RDL DR SHFT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M60G05	HOUSING ASSY - RDL DR SHFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M60G05	HOUSING ASSY - RDL DR SHFT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M60G05	HOUSING ASSY - RDL DR SHFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M60G05	HOUSING ASSY - RDL DR SHFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M60G05	HOUSING ASSY - RDL DR SHFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M60G05	HOUSING ASSY - RDL DR SHFT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M60G05	HOUSING ASSY - RDL DR SHFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M60G05	HOUSING ASSY - RDL DR SHFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M60G05	HOUSING ASSY - RDL DR SHFT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M60G05	HOUSING ASSY - RDL DR SHFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M60G05	HOUSING ASSY - RDL DR SHFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M62P02	SHIELD - BRG	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M62P02	SHIELD - BRG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9009M62P02	SHIELD - BRG	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M62P02	SHIELD - BRG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M62P02	SHIELD - BRG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M62P02	SHIELD - BRG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M62P02	SHIELD - BRG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M62P02	SHIELD - BRG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M62P02	SHIELD - BRG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M62P02	SHIELD - BRG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M62P02	SHIELD - BRG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M62P02	SHIELD - BRG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M62P02	SHIELD - BRG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M62P02	SHIELD - BRG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M66G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M66G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M66G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M66G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M66G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M66G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M66G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M66G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M66G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M66G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M66G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M66G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M66G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M66G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M66G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9009M66G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M66G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M66G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M67P01	GEARSHAFT - 46 TOOTH SPUR	CF6-50	AR	1
9009M67P02	GEARSHAFT - 46 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9009M67P02	GEARSHAFT - 46 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9009M67P02	GEARSHAFT - 46 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9009M67P02	GEARSHAFT - 46 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9009M67P02	GEARSHAFT - 46 TOOTH SPUR	CF6-50 (LMCO)	OH	1
9009M67P02	GEARSHAFT - 46 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9009M67P02	GEARSHAFT - 46 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9009M67P02	GEARSHAFT - 46 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9009M67P02	GEARSHAFT - 46 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9009M67P02	GEARSHAFT - 46 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9009M67P02	GEARSHAFT - 46 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9009M67P02	GEARSHAFT - 46 TOOTH SPUR	CF6-50 (LMCO)	OH	1
9009M67P02	GEARSHAFT - 46 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9009M67P02	GEARSHAFT - 46 TOOTH SPUR	CF6-50 (LMCO)	OH	1
9009M67P02	GEARSHAFT - 46 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9009M67P04	AGB SPUR GEARSHAFT [46 TOOTH]	CF6-80C2	AR	1
9009M67P04	AGB SPUR GEARSHAFT [46 TOOTH]	CF6-80C2	SV	1
9009M71G18	GEARBOX ASSY - TRANSFER	CF6-50	AR	1
9009M71G23	GEARBOX ASSY - TRANSFER	CF6-50	AR	1
9009M71G23	GEARBOX ASSY - TRANSFER	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9009M71G25	GEARBOX ASSY - TRANSFER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M71G25	GEARBOX ASSY - TRANSFER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M71G25	GEARBOX ASSY - TRANSFER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M71G27	GEARBOX ASSY - TRANSFER	CF6-50 (LMCO)	AR	1
9009M73P02	HOUSING - GRBX OIL SEAL	CF6-50	OH	1
9009M73P02	HOUSING - GRBX OIL SEAL	CF6-50	OH	1
9009M73P03	HOUSING - GRBX OIL SEAL	CF6-50 (LMCO)	AR	1
9009M73P03	HOUSING - GRBX OIL SEAL	CF6-50 (LMCO)	AR	1
9009M73P03	HOUSING - GRBX OIL SEAL	CF6-50 (LMCO)	AR	1
9009M73P03	HOUSING - GRBX OIL SEAL	CF6-50 (LMCO)	AR	1
9009M73P03	HOUSING - GRBX OIL SEAL	CF6-50 (LMCO)	AR	1
9009M73P03	HOUSING - GRBX OIL SEAL	CF6-50 (LMCO)	AR	1
9009M73P03	HOUSING - GRBX OIL SEAL	CF6-50 (LMCO)	AR	1
9009M73P03	HOUSING - GRBX OIL SEAL	CF6-50 (LMCO)	AR	1
9009M73P03	HOUSING - GRBX OIL SEAL	CF6-50 (LMCO)	AR	1
9009M73P03	HOUSING - GRBX OIL SEAL	CF6-50 (LMCO)	OH	1
9009M73P03	HOUSING - GRBX OIL SEAL	CF6-50 (LMCO)	AR	1
9009M77G03	HOUSING ASSY - MAIN AGB	CF6-50	AR	1
9009M77G03	HOUSING ASSY - MAIN AGB	CF6-50	AR	1
9009M77G05	HOUSING ASSY - MAIN AGB	CF6-50	AR	1
9009M77G06	HOUSING ASSY - MAIN AGB	CF6-50 (LMCO)	AR	1
9009M77G06	HOUSING ASSY - MAIN AGB	CF6-50 (LMCO)	OH	1
9009M77G08	HOUSING ASSY - MAIN AGB	CF6-50 (LMCO)	AR	1
9009M77G08	HOUSING ASSY - MAIN AGB	CF6-50 (LMCO)	AR	1
9009M77G09	HOUSING ASSY - MAIN AGB	CF6-50	AR	1
9009M77G09	HOUSING ASSY - MAIN AGB	CF6-50	AR	1
9009M80G01	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	OH	1
9009M80G01	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	AR	1
9009M80G01	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	AR	1
9009M80G01	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	AR	1
9009M80G01	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	OH	1
9009M80G01	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	AR	1
9009M80G01	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	AR	1
9009M80G01	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	AR	1
9009M80G01	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	AR	1
9009M80G01	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9009M80G01	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	AR	1
9009M80G01	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	AR	1
9009M80G01	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	AR	1
9009M80G01	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	OH	1
9009M80G01	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	AR	1
9009M82G01	NOZZLE - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M82G01	NOZZLE - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M82G01	NOZZLE - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M82G01	NOZZLE - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9009M82G01	NOZZLE - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M82G01	NOZZLE - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M82G01	NOZZLE - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M82G01	NOZZLE - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M82G01	NOZZLE - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M82G01	NOZZLE - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M82G01	NOZZLE - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M82G01	NOZZLE - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M82G01	NOZZLE - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M82G01	NOZZLE - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M82G01	NOZZLE - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M82G01	NOZZLE - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M86G01	GEARSHAFT ASSY - ACCY GRBX	CF6-50	AR	1
9009M86G02	GEARSHAFT ASSY - ACCY GRBX	CF6-50	OH	1
9009M86G02	GEARSHAFT ASSY - ACCY GRBX	CF6-50	AR	1
9009M86G02	GEARSHAFT ASSY - ACCY GRBX	CF6-50	AR	1
9009M86G02	GEARSHAFT ASSY - ACCY GRBX	CF6-50	AR	1
9009M86G02	GEARSHAFT ASSY - ACCY GRBX	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9009M86G02	GEARSHAFT ASSY - ACCY GRBX	CF6-50	OH	1
9009M86G04	GEARSHAFT ASSY - ACCY GRBX	CF6-50 (LMCO)	AR	1
9009M86G04	GEARSHAFT ASSY - ACCY GRBX	CF6-50 (LMCO)	AR	1
9009M86G04	GEARSHAFT ASSY - ACCY GRBX	CF6-50 (LMCO)	AR	1
9009M86G04	GEARSHAFT ASSY - ACCY GRBX	CF6-50 (LMCO)	OH	1
9009M86G04	GEARSHAFT ASSY - ACCY GRBX	CF6-50 (LMCO)	OH	1
9009M86G04	GEARSHAFT ASSY - ACCY GRBX	CF6-50 (LMCO)	AR	1
9009M86G05	GEARSHAFT ASSY - ACCY GRBX	CF6-50 (Boeing)	OH	1
9009M87P01	SPACER - HORIZ DRIVE	CF6-50	AR	1
9009M87P02	SPACER - HORIZ DRIVE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M87P02	SPACER - HORIZ DRIVE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M87P02	SPACER - HORIZ DRIVE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M87P02	SPACER - HORIZ DRIVE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M87P02	SPACER - HORIZ DRIVE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M87P02	SPACER - HORIZ DRIVE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M87P02	SPACER - HORIZ DRIVE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M87P02	SPACER - HORIZ DRIVE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M87P02	SPACER - HORIZ DRIVE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M87P02	SPACER - HORIZ DRIVE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M87P02	SPACER - HORIZ DRIVE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M87P02	SPACER - HORIZ DRIVE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M87P02	SPACER - HORIZ DRIVE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M87P02	SPACER - HORIZ DRIVE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M87P02	SPACER - HORIZ DRIVE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M87P02	SPACER - HORIZ DRIVE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M87P02	SPACER - HORIZ DRIVE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M87P02	SPACER - HORIZ DRIVE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9009M87P02	SPACER - HORIZ DRIVE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M87P02	SPACER - HORIZ DRIVE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M87P02	SPACER - HORIZ DRIVE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M87P02	SPACER - HORIZ DRIVE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M87P03	SPACER - HORIZ DRIVE	CF6-80A	AR	1
9009M90P03	GEARSHAFT - 45 TOOTH BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M90P03	GEARSHAFT - 45 TOOTH BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M90P03	GEARSHAFT - 45 TOOTH BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M90P03	GEARSHAFT - 45 TOOTH BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M90P03	GEARSHAFT - 45 TOOTH BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M90P03	GEARSHAFT - 45 TOOTH BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M90P03	GEARSHAFT - 45 TOOTH BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M90P03	GEARSHAFT - 45 TOOTH BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9009M90P03	GEARSHAFT - 45 TOOTH BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M90P03	GEARSHAFT - 45 TOOTH BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9009M90P03	GEARSHAFT - 45 TOOTH BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9010M59P05	SEAL - CHEVRON	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9010M59P06	SEAL - CHEVRON	CF6-80A, CF6-50 (Boeing)	NS	2
9010M82P03	NUT - LPT SFT CPLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9010M82P03	NUT - LPT SFT CPLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9010M82P03	NUT - LPT SFT CPLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9010M82P03	NUT - LPT SFT CPLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9010M82P03	NUT - LPT SFT CPLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9010M82P03	NUT - LPT SFT CPLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9010M82P03	NUT - LPT SFT CPLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9010M82P03	NUT - LPT SFT CPLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9010M82P03	NUT - LPT SFT CPLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9010M82P03	NUT - LPT SFT CPLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9010M82P03	NUT - LPT SFT CPLG	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9010M96P01	BRACKET - HOIST	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
9010M96P01	BRACKET - HOIST	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9010M96P01	BRACKET - HOIST	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9010M96P01	BRACKET - HOIST	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9010M96P01	BRACKET - HOIST	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9010M97P01	COVER - PRESS XDCR PLUG	CF6-80C2, CF6-80A	AR	1
9011M18G02	TUBE ASSY - RETURN OIL	CF6-50	SV	1
9011M20G02	TUBE - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9011M20G02	TUBE - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9011M20G02	TUBE - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9011M20G02	TUBE - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9011M20G02	TUBE - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9011M20G02	TUBE - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9011M20G02	TUBE - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9011M20G02	TUBE - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9011M20G02	TUBE - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9011M20G02	TUBE - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9011M20G02	TUBE - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9011M20G02	TUBE - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9011M20G02	TUBE - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9011M20G02	TUBE - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9011M20G02	TUBE - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9011M20G02	TUBE - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9011M20G02	TUBE - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9011M20G02	TUBE - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9011M29G03	BRACKET ASSY - FIRE DET	CF6-50	OH	1
9011M42G01	BRACKET ASSY - ANGLE	CF6-50	SV	1
9011M42G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9011M56P02	BRACKET - FUEL FILTER	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9011M56P02	BRACKET - FUEL FILTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9011M62P01	BRACKET - TUBE	CF6-50 (LMCO)	AR	1
9011M64P01	BRACKET	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9011M64P01	BRACKET	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9012M35P03	SEAL - CHEVRON	CF6-50	NS	1
9012M35P03	SEAL - CHEVRON	CF6-50	NS	1
9012M35P07	SEAL - CHEVRON	CF6-50	NS	1
9012M35P07	SEAL - CHEVRON	CF6-50	NS	1
9012M35P07	SEAL - CHEVRON	CF6-50	NE	3
9012M35P08	SEAL - CHEVRON	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9012M35P08	SEAL - CHEVRON	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9012M35P10	SEAL - CHEVRON	CF6-80A	NS	1
9012M37P05	SEAL - CHEVRON	CF6-50	NS	1
9012M37P06	SEAL - CHEVRON	CF6-50	NS	1
9012M37P08	SEAL - CHEVRON	CF6-80A	NE	1
9012M37P08	SEAL - CHEVRON	CF6-80A	NE	4
9012M38P03	SEAL - CHEVRON	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9012M38P04	SEAL - CHEVRON	CF6-80A, CF6-50 (Boeing)	NS	2
9012M58G05	VALVE ASSY - BYPASS	CF6-50	SV	1
9012M58G07	VALVE ASSY - BYPASS	CF6-50 (Boeing)	SV	1

[illegible]

Part Number	Part Description	Engine Type	Condition	Quantity
9013M27P03	SEAL - MET	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9013M27P04	SEAL - MET	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9013M27P04	SEAL - MET	CF6-50 (LMCO), CF6-50 (Boeing)	NS	11
9013M27P04	SEAL - MET	CF6-50 (LMCO), CF6-50 (Boeing)	NE	19
9013M27P06	SEAL - MET	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9014M45P28	COUPLING - GROOVED CLAMP	CF6-50 (LMCO)	SV	1
9014M52G01	TUBE ASSY - RETURN OIL	CF6-50	AR	1
9014M52G01	TUBE ASSY - RETURN OIL	CF6-50	AR	1
9014M52G01	TUBE ASSY - RETURN OIL	CF6-50	AR	1
9014M52G01	TUBE ASSY - RETURN OIL	CF6-50	AR	1
9014M61G02	RETAINER - OUTER SEAL	CF6-50	NE	1
9014M61G02	RETAINER - OUTER SEAL	CF6-50	NE	1
9014M61G02	RETAINER - OUTER SEAL	CF6-50	NE	1
9014M61G02	RETAINER - OUTER SEAL	CF6-50	NE	1
9014M61G02	RETAINER - OUTER SEAL	CF6-50	NE	1
9014M79P240	COUPLING - GROOVED CLAMP	CF6-50	AR	1
9014M85P01	SHIELD - SPRAY	CF6-50 (LMCO), CF6-50 (Boeing)	NE	8
901561	DETECTOR - FIRE	CF6-80C2	SV	1
9015M12P01	SHIELD - SPRAY	CF6-50 (Boeing)	OH	1
9015M12P02	SHIELD - SPRAY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9015M12P02	SHIELD - SPRAY	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9015M12P02	SHIELD - SPRAY	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9015M51P02	SHIELD - SPRAY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9015M51P02	SHIELD - SPRAY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9015M51P02	SHIELD - SPRAY	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9015M51P02	SHIELD - SPRAY	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9015M51P02	SHIELD - SPRAY	CF6-50 (LMCO), CF6-50 (Boeing)	NE	4
9015M62G01	TUBE ASSY - B BRG OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9015M62G01	TUBE ASSY - B BRG OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9015M62G01	TUBE ASSY - B BRG OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9015M62G01	TUBE ASSY - B BRG OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9015M62G01	TUBE ASSY - B BRG OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9015M62G01	TUBE ASSY - B BRG OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9015M63P03	PUSH ROD - ACTUATION LEVER	CF6-80C2, CF6-80A, CF6-50	NS	1
9015M67G01	BRACKET ASSY - FWD VENT	CF6-50 (Boeing)	AR	1
9015M67G02	BRACKET ASSY - FWD VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9015M67G02	BRACKET ASSY - FWD VENT	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9015M67G02	BRACKET ASSY - FWD VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9015M67G02	BRACKET ASSY - FWD VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9015M68G03	BRACKET ASSY - VENT TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9015M69G02	BRACKET ASSY - AFT VENT	CF6-50	NS	1
9015M73G05	BRACKET - CLEVIS STG 1 - 2	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9015M73G05	BRACKET - CLEVIS STG 1 - 2	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9015M73G05	BRACKET - CLEVIS STG 1 - 2	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9015M73G05	BRACKET - CLEVIS STG 1 - 2	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9015M73G05	BRACKET - CLEVIS STG 1 - 2	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9015M73G05	BRACKET - CLEVIS STG 1 - 2	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9015M73G05	BRACKET - CLEVIS STG 1 - 2	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9015M73G05	BRACKET - CLEVIS STG 1 - 2	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9015M78P02	SENSOR - SPEED CORE	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9015M78P02	SENSOR - SPEED CORE	CF6-50 (LMCO)	SV	1
9015M78P02	SENSOR - SPEED CORE	CF6-50 (LMCO)	OH	1
9016M13P03	BRACKET - SHOCK MTD	CF6-50 (LMCO)	AR	1
9016M13P03	BRACKET - SHOCK MTD	CF6-50 (LMCO)	OH	1
9016M13P03	BRACKET - SHOCK MTD	CF6-50 (LMCO)	AR	1
9016M13P03	BRACKET - SHOCK MTD	CF6-50 (LMCO)	OH	1
9016M13P03	BRACKET - SHOCK MTD	CF6-50 (LMCO)	OH	1
9016M13P03	BRACKET - SHOCK MTD	CF6-50 (LMCO)	AR	1
9016M13P03	BRACKET - SHOCK MTD	CF6-50 (LMCO)	AR	1
9016M13P03	BRACKET - SHOCK MTD	CF6-50 (LMCO)	AR	1
9016M13P03	BRACKET - SHOCK MTD	CF6-50 (LMCO)	AR	1
9016M13P03	BRACKET - SHOCK MTD	CF6-50 (LMCO)	AR	1
9016M13P03	BRACKET - SHOCK MTD	CF6-50 (LMCO)	OH	1
9016M13P03	BRACKET - SHOCK MTD	CF6-50 (LMCO)	SV	1
9016M13P04	BRACKET - SHOCK MTD	CF6-80C2	AR	1
9016M13P04	BRACKET - SHOCK MTD	CF6-80C2	AR	1
9016M13P04	BRACKET - SHOCK MTD	CF6-80C2	AR	1
9016M13P04	BRACKET - SHOCK MTD	CF6-80C2	AR	1
9016M13P04	BRACKET - SHOCK MTD	CF6-80C2	AR	1
9016M13P04	BRACKET - SHOCK MTD	CF6-80C2	AR	1
9016M13P04	BRACKET - SHOCK MTD	CF6-80C2	AR	1
9016M13P04	BRACKET - SHOCK MTD	CF6-80C2	AR	1
9016M13P04	BRACKET - SHOCK MTD	CF6-80C2	AR	1
9016M13P04	BRACKET - SHOCK MTD	CF6-80C2	AR	1
9016M13P04	BRACKET - SHOCK MTD	CF6-80C2	SV	1
9016M23G12	DOME ASSY - COMB CHMBR	CF6-50	AR	1
9016M23G14	DOME ASSY - COMB CHMBR	CF6-50	AR	1
9016M23G14	DOME ASSY - COMB CHMBR	CF6-50	AR	1
9016M23G14	DOME ASSY - COMB CHMBR	CF6-50	AR	1
9016M26G48	LINER ASSY - COMBUSTION	CF6-50 (LMCO)	AR	1
9016M26G48	LINER ASSY - COMBUSTION	CF6-50 (LMCO)	AR	1
9016M26G48	LINER ASSY - COMBUSTION	CF6-50 (LMCO)	AR	1
9016M26G52	LINER ASSY - COMBUSTION	CF6-50 (LMCO)	AR	1
9016M30P01	RING - METAL SEAL	CF6-50 (LMCO)	SV	30
9016M30P02	SEAL ASSY - RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
9016M71P11	SWIRLER	CF6-50	AR	28

Part Number	Part Description	Engine Type	Condition	Quantity
9016M71P12	SWIRLER	CF6-50	AR	2
9016M86P03	ADAPTER ASSY	CF6-50 (LMCO)	SV	2
9016M86P03	ADAPTER ASSY	CF6-50 (LMCO)	OH	2
9016M86P03	ADAPTER ASSY	CF6-50 (LMCO)	OH	2
9016M86P03	ADAPTER ASSY	CF6-50 (LMCO)	SV	2
9020M79G01	BRACKET ASSY - AFT LINER	CF6-80A, CF6-50 (Boeing)	AR	10
9020M79G01	BRACKET ASSY - AFT LINER	CF6-80A, CF6-50 (Boeing)	AR	11
9020M79G01	BRACKET ASSY - AFT LINER	CF6-80A, CF6-50 (Boeing)	AR	1
9020M79G01	BRACKET ASSY - AFT LINER	CF6-80A, CF6-50 (Boeing)	AR	11
9020M79G01	BRACKET ASSY - AFT LINER	CF6-80A, CF6-50 (Boeing)	SV	1
9020M79G01	BRACKET ASSY - AFT LINER	CF6-80A, CF6-50 (Boeing)	OH	10
9020M80G01	BRACKET - LINER	CF6-50 (LMCO)	AR	2
9020M80G01	BRACKET - LINER	CF6-50 (LMCO)	AR	1
9020M80G01	BRACKET - LINER	CF6-50 (LMCO)	AR	2
9020M81G01	BRACKET - LINER	CF6-50	AR	1
9020M81G01	BRACKET - LINER	CF6-50	AR	8
9020M81G01	BRACKET - LINER	CF6-50	AR	1
9020M81G01	BRACKET - LINER	CF6-50	AR	10
9021M12P03	SUPPORT - CONNECTING	CF6-80A	AR	1
9021M12P03	SUPPORT - CONNECTING	CF6-80A	AR	1
9021M12P04	SUPPORT - CONNECTING	CF6-80A, CF6-50	AR	1
9021M12P04	SUPPORT - CONNECTING	CF6-80A, CF6-50	AR	1
9021M12P04	SUPPORT - CONNECTING	CF6-80A, CF6-50	AR	1
9021M12P04	SUPPORT - CONNECTING	CF6-80A, CF6-50	AR	1
9021M13P03	RETAINER - SUPPORT SEAL	CF6-50 (Boeing)	AR	1
9021M13P03	RETAINER - SUPPORT SEAL	CF6-50 (Boeing)	NS	1
9021M13P04	RETAINER - SUPPORT SEAL	CF6-50	SV	1
9021M14P03	PAD - CONNECTOR	CF6-80A, CF6-50 (Boeing)	AR	1
9021M14P03	PAD - CONNECTOR	CF6-80A, CF6-50 (Boeing)	AR	1
9021M14P03	PAD - CONNECTOR	CF6-80A, CF6-50 (Boeing)	AR	1
9021M14P03	PAD - CONNECTOR	CF6-80A, CF6-50 (Boeing)	AR	1
9021M14P03	PAD - CONNECTOR	CF6-80A, CF6-50 (Boeing)	SV	1
9021M16G09	MOUNT ASSY - FWD ENGINE	CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9021M40G02	NUT ASSY - GANG CHANNEL	CF6-80A	SV	2
9021M42G03	NUT ASSY - GANG CHANNEL	CF6-80A	AR	2
9021M42G03	NUT ASSY - GANG CHANNEL	CF6-80A	NE	1
9021M57P01	BRACE - OIL TANK BRKT	CF6-50	AR	1
9021M57P01	BRACE - OIL TANK BRKT	CF6-50	AR	1
9021M57P01	BRACE - OIL TANK BRKT	CF6-50	AR	1
9021M81P01	RETAINER - ENG MT BOLT	CF6-50 (Boeing)	AR	1
9021M81P02	RETAINER - ENG MT BOLT	CF6-50 (Boeing)	NE	4
9021M81P02	RETAINER - ENG MT BOLT	CF6-50 (Boeing)	NE	1
9021M81P02	RETAINER - ENG MT BOLT	CF6-50 (Boeing)	NE	2
9022M58P02	CAP - BOROSCOPE PLUG	CF6-80A	AR	1
9022M58P03	CAP - BOROSCOPE PLUG	CF6-80C2	NS	1
9022M60P02	RETAINER - SEAL	CF6-50 (LMCO)	AR	1
9022M60P04	RETAINER - SEAL	CF6-80A	NS	1
9022M60P04	RETAINER - SEAL	CF6-80A	NS	1
9022M63G13	PLUG ASSY - BORESCOPE PORT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9022M63G13	PLUG ASSY - BORESCOPE PORT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9022M63G13	PLUG ASSY - BORESCOPE PORT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9022M63G13	PLUG ASSY - BORESCOPE PORT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9022M63G13	PLUG ASSY - BORESCOPE PORT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9022M63G13	PLUG ASSY - BORESCOPE PORT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9022M63G13	PLUG ASSY - BORESCOPE PORT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9022M63G13	PLUG ASSY - BORESCOPE PORT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9022M63G13	PLUG ASSY - BORESCOPE PORT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9022M63G15	PLUG ASSY - BORESCOPE	CF6-80A	AR	1
9022M63G15	PLUG ASSY - BORESCOPE	CF6-80A	AR	2
9022M63G15	PLUG ASSY - BORESCOPE	CF6-80A	OH	1
9022M63G15	PLUG ASSY - BORESCOPE	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9022M63G15	PLUG ASSY - BORESCOPE	CF6-80A	SV	1
9022M63G16	PLUG ASSY - BORESCOPE	CF6-80A	OH	2
9022M63G16	PLUG ASSY - BORESCOPE	CF6-80A	AR	3
9022M63G16	PLUG ASSY - BORESCOPE	CF6-80A	AR	1
9022M63G16	PLUG ASSY - BORESCOPE	CF6-80A	NS	1
9022M63G16	PLUG ASSY - BORESCOPE	CF6-80A	NE	1
9022M63G16	PLUG ASSY - BORESCOPE	CF6-80A	AR	2
9022M63G16	PLUG ASSY - BORESCOPE	CF6-80A	SV	1
9022M63G16	PLUG ASSY - BORESCOPE	CF6-80A	SV	1
9022M96G01	RETAINER - SEAL	CF6-80A, CF6-50	NE	1
9022M96G01	RETAINER - SEAL	CF6-80A, CF6-50	NE	1
9022M96G02	RETAINER - SEAL	CF6-80A, CF6-50	NE	1
9022M97P04	BRACE - REVERSER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9022M97P04	BRACE - REVERSER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9022M97P04	BRACE - REVERSER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9022M97P04	BRACE - REVERSER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	4
9025M12G02	NUT ASSY - SLFLKG	CF6-50	AR	1
9025M13G01	NUT - GANG CHAN SLFLKG	CF6-50	NE	1
9025M13G01	NUT - GANG CHAN SLFLKG	CF6-50	NE	1
9025M31G06	NUT ASSY - GANG CHAN SLFLKG	CF6-50 (LMCO)	NE	1
9025M31G06	NUT ASSY - GANG CHAN SLFLKG	CF6-50 (LMCO)	NE	4
9025M31G06	NUT ASSY - GANG CHAN SLFLKG	CF6-50 (LMCO)	OH	4
9025M89P01	PLATE - COVER	CF6-80A	NS	1
9025M89P03	COVER	CF6-50 (LMCO)	AR	1
9025M94G01	NUT ASSY - GANG CHANNEL	CF6-50 (Boeing)	NS	8
9025M94G01	NUT ASSY - GANG CHANNEL	CF6-50 (Boeing)	NS	20
9031M11P03	PLUG - BOROSCOPE PORT	CF6-80A	NE	3
9031M11P04	PLUG - BS PORT	CF6-80C2	NE	1
9031M41P05	COVER - INSTR AFT FAN CASE	CF6-50	NS	6
9031M61P21	MOUNT - GND HDLG	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9031M61P21	MOUNT - GND HDLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9031M61P21	MOUNT - GND HDLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9031M61P21	MOUNT - GND HDLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9031M61P21	MOUNT - GND HDLG	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9031M61P22	MOUNT - GND HDLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9031M61P22	MOUNT - GND HDLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9031M87G26	PANEL - PYLON	CF6-80A	AR	1
9031M87G26	PANEL - PYLON	CF6-80A	AR	1
9031M87G26	PANEL - PYLON	CF6-80A	AR	1
9031M87G27	PANEL - PYLON	CF6-80A	AR	1
9031M88P02	PANEL - ACCESS	CF6-50 (LMCO)	AR	1
9031M99G40	CASE ASSY - AFT FAN	CF6-50	AR	1
9031M99G40	CASE ASSY - AFT FAN	CF6-50	AR	1
9031M99G41	CASE ASSY - AFT FAN	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9031M99G44	CASE ASSY - AFT FAN	CF6-50 (LMCO)	AR	1
9031M99G44	CASE ASSY - AFT FAN	CF6-50 (LMCO)	AR	1
9031M99G44	CASE ASSY - AFT FAN	CF6-50 (LMCO)	AR	1
9032M21P18	SHAFT - MID FAN	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M21P25	SHAFT - MID FAN	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M26P01	RING - BRG 2 NUT KEYED RTNG	CF6-50	AR	1
9032M26P01	RING - BRG 2 NUT KEYED RTNG	CF6-50	AR	1
9032M26P01	RING - BRG 2 NUT KEYED RTNG	CF6-50	AR	1
9032M26P01	RING - BRG 2 NUT KEYED RTNG	CF6-50	AR	1
9032M26P01	RING - BRG 2 NUT KEYED RTNG	CF6-50	AR	1
9032M26P01	RING - BRG 2 NUT KEYED RTNG	CF6-50	AR	1
9032M26P02	RING - BRG 2 NUT KEYED RTNG	CF6-80A, CF6-50 (LMCO)	AR	1
9032M26P02	RING - BRG 2 NUT KEYED RTNG	CF6-80A, CF6-50 (LMCO)	OH	1
9032M26P02	RING - BRG 2 NUT KEYED RTNG	CF6-80A, CF6-50 (LMCO)	OH	1
9032M26P02	RING - BRG 2 NUT KEYED RTNG	CF6-80A, CF6-50 (LMCO)	AR	1
9032M26P02	RING - BRG 2 NUT KEYED RTNG	CF6-80A, CF6-50 (LMCO)	AR	1
9032M26P02	RING - BRG 2 NUT KEYED RTNG	CF6-80A, CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9032M26P02	RING - BRG 2 NUT KEYED RTNG	CF6-80A, CF6-50 (LMCO)	AR	1
9032M26P02	RING - BRG 2 NUT KEYED RTNG	CF6-80A, CF6-50 (LMCO)	NE	1
9032M49P03	DISK - HPC STG 10	CF6-50	OH	1
9032M49P03	DISK - HPC STG 10	CF6-50	AR	1
9032M49P03	DISK - HPC STG 10	CF6-50	AR	1
9032M49P03	DISK - HPC STG 10	CF6-50	AR	1
9032M49P03	DISK - HPC STG 10	CF6-50	AR	1
9032M49P03	DISK - HPC STG 10	CF6-50	OH	1
9032M49P07	DISK - HPC STG 10	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9032M49P07	DISK - HPC STG 10	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9032M49P12	DISK - HPC STG 10	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9032M49P12	DISK - HPC STG 10	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M49P12	DISK - HPC STG 10	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M49P12	DISK - HPC STG 10	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9032M49P12	DISK - HPC STG 10	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M62G02	HOUSING ASSY - MAIN	CF6-50	OH	1
9032M62G05	HOUSING ASSY - MAIN	CF6-80A, CF6-50	AR	1
9032M62G05	HOUSING ASSY - MAIN	CF6-80A, CF6-50	AR	1
9032M62G05	HOUSING ASSY - MAIN	CF6-80A, CF6-50	AR	1
9032M62G05	HOUSING ASSY - MAIN	CF6-80A, CF6-50	AR	1
9032M62G05	HOUSING ASSY - MAIN	CF6-80A, CF6-50	AR	1
9032M62G05	HOUSING ASSY - MAIN	CF6-80A, CF6-50	AR	1
9032M62G05	HOUSING ASSY - MAIN	CF6-80A, CF6-50	AR	1
9032M62G05	HOUSING ASSY - MAIN	CF6-80A, CF6-50	AR	1
9032M62G07	HOUSING ASSY - MAIN	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M62G07	HOUSING ASSY - MAIN	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M62G07	HOUSING ASSY - MAIN	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9032M62G07	HOUSING ASSY - MAIN	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9032M62G07	HOUSING ASSY - MAIN	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M62G07	HOUSING ASSY - MAIN	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9032M63G02	ADAPTER ASSY - BOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M63G02	ADAPTER ASSY - BOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M63G02	ADAPTER ASSY - BOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M63G02	ADAPTER ASSY - BOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M63G02	ADAPTER ASSY - BOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M63G02	ADAPTER ASSY - BOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M63G02	ADAPTER ASSY - BOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M63G02	ADAPTER ASSY - BOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M63G02	ADAPTER ASSY - BOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M63G02	ADAPTER ASSY - BOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M63G02	ADAPTER ASSY - BOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M63G02	ADAPTER ASSY - BOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M63G02	ADAPTER ASSY - BOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M63G02	ADAPTER ASSY - BOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9032M63G02	ADAPTER ASSY - BOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9032M63G02	ADAPTER ASSY - BOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9032M63G02	ADAPTER ASSY - BOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M63G02	ADAPTER ASSY - BOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M63G02	ADAPTER ASSY - BOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M63G02	ADAPTER ASSY - BOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M63G02	ADAPTER ASSY - BOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M63G02	ADAPTER ASSY - BOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M63G02	ADAPTER ASSY - BOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9032M63G02	ADAPTER ASSY - BOT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M63P02	HOUSING - ADPTR	CF6-50 (LMCO)	AR	1
9032M64P02	GEARSHAFT - INL GRBX BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9032M64P02	GEARSHAFT - INL GRBX BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9032M64P02	GEARSHAFT - INL GRBX BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M64P02	GEARSHAFT - INL GRBX BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M64P02	GEARSHAFT - INL GRBX BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M64P02	GEARSHAFT - INL GRBX BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M64P02	GEARSHAFT - INL GRBX BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M64P02	GEARSHAFT - INL GRBX BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M64P02	GEARSHAFT - INL GRBX BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M64P02	GEARSHAFT - INL GRBX BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M64P02	GEARSHAFT - INL GRBX BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9032M64P02	GEARSHAFT - INL GRBX BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M64P02	GEARSHAFT - INL GRBX BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M64P02	GEARSHAFT - INL GRBX BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M64P02	GEARSHAFT - INL GRBX BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9032M64P02	GEARSHAFT - INL GRBX BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M64P02	GEARSHAFT - INL GRBX BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M64P02	GEARSHAFT - INL GRBX BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M64P02	GEARSHAFT - INL GRBX BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M64P02	GEARSHAFT - INL GRBX BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M64P02	GEARSHAFT - INL GRBX BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M64P04	GEARSHAFT - INL GRBX BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M64P04	GEARSHAFT - INL GRBX BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M64P04	GEARSHAFT - INL GRBX BEVEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M64P05	GEARSHAFT - INL GRBX BEVEL	CF6-80A	AR	1
9032M64P08	GEARSHAFT - INL GRBX BEVEL	CF6-80A	SV	1
9032M64P08	GEARSHAFT - INL GRBX BEVEL	CF6-80A	SV	1
9032M64P08	GEARSHAFT - INL GRBX BEVEL	CF6-80A	SV	1
9032M64P08	GEARSHAFT - INL GRBX BEVEL	CF6-80A	OH	1
9032M64P09	GEARSHAFT - INL GRBX BEVEL	CF6-80A	AR	1
9032M68P04	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M68P04	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M68P04	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M68P04	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9032M68P04	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M68P04	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M68P04	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M68P04	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M68P04	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M68P04	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M68P04	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9032M68P04	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9032M68P04	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9032M68P04	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M68P04	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M68P04	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M68P04	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M68P04	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M71G02	NOZZLE - INLET GRBX OIL	CF6-50	AR	1
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9032M72P02	NUT - INLET GRBX SPANNER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9032M73G16	GEARBOX ASSY - INLET	CF6-50	AR	1
9032M78P04	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9032M88G03	SEAL ASSY - OUTER BRG 7	CF6-50	AR	1
9032M88G03	SEAL ASSY - OUTER BRG 7	CF6-50	AR	1
9032M88G03	SEAL ASSY - OUTER BRG 7	CF6-50	AR	1
9032M88G03	SEAL ASSY - OUTER BRG 7	CF6-50	AR	1
9032M88G03	SEAL ASSY - OUTER BRG 7	CF6-50	AR	1
9032M92P03	CHANNEL - SEAL	CF6-50 (LMCO)	AR	1
9033M43P04	FILTER - OIL SCAVENGE	CF6-50 (LMCO)	AR	1
9033M43P08	FILTER - OIL SCAVENGE	CF6-80C2, CF6-80A	AR	1
9033M43P08	FILTER - OIL SCAVENGE	CF6-80C2, CF6-80A	AR	1
9033M44P05	PUMP - LUBE & SCAVENGE	CF6-50	AR	1
9033M44P05	PUMP - LUBE & SCAVENGE	CF6-50	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
9033M44P05	PUMP - LUBE & SCAVENGE	CF6-50	AR	1
9033M49G02	BRACKET ASSY - IGN UNIT	CF6-50	SV	1
9033M49G02	BRACKET ASSY - IGN UNIT	CF6-50	AR	1
9033M49G02	BRACKET ASSY - IGN UNIT	CF6-50	AR	2
9033M49G02	BRACKET ASSY - IGN UNIT	CF6-50	AR	1
9033M49G02	BRACKET ASSY - IGN UNIT	CF6-50	AR	1
9033M49G02	BRACKET ASSY - IGN UNIT	CF6-50	SV	2
9033M51G02	BRACKET ASSY - IGN UNIT	CF6-50	SV	1
9033M51G02	BRACKET ASSY - IGN UNIT	CF6-50	AR	1
9033M51G02	BRACKET ASSY - IGN UNIT	CF6-50	AR	1
9033M52G03	BRACKET ASSY - IGN UNIT	CF6-50	SV	1
9033M52G03	BRACKET ASSY - IGN UNIT	CF6-50	AR	1
9033M52G03	BRACKET ASSY - IGN UNIT	CF6-50	AR	1
9033M65G02	TUBE ASSY - PMP TO FLTR	CF6-50	AR	1
9033M65G02	TUBE ASSY - PMP TO FLTR	CF6-50	AR	1
9033M65G02	TUBE ASSY - PMP TO FLTR	CF6-50	SV	1
9034M23P04	ARRESTOR - FLAME	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9034M23P04	ARRESTOR - FLAME	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9034M23P04	ARRESTOR - FLAME	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9034M23P04	ARRESTOR - FLAME	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9034M23P04	ARRESTOR - FLAME	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9034M23P04	ARRESTOR - FLAME	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9034M23P04	ARRESTOR - FLAME	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9034M23P04	ARRESTOR - FLAME	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9034M23P04	ARRESTOR - FLAME	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9035M55G03	BUMPER - DEFLECTION LIMITER	CF6-80C2	OH	1
9035M55G03	BUMPER - DEFLECTION LIMITER	CF6-80C2	OH	1
9035M55G03	BUMPER - DEFLECTION LIMITER	CF6-80C2	OH	1
9035M55G03	BUMPER - DEFLECTION LIMITER	CF6-80C2	OH	1
9035M55G03	BUMPER - DEFLECTION LIMITER	CF6-80C2	AR	1
9035M55G03	BUMPER - DEFLECTION LIMITER	CF6-80C2	OH	1
9035M55G03	BUMPER - DEFLECTION LIMITER	CF6-80C2	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9035M55G03	BUMPER - DEFLECTION LIMITER	CF6-80C2	AR	1
9035M58P01	MOUNT - FWD ENGINE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9035M58P01	MOUNT - FWD ENGINE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9035M58P01	MOUNT - FWD ENGINE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9035M58P02	BRACKET - DEF LIMITER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9035M58P02	BRACKET - DEF LIMITER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9035M58P02	BRACKET - DEF LIMITER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9035M58P02	BRACKET - DEF LIMITER	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9035M58P02	BRACKET - DEF LIMITER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9035M58P02	BRACKET - DEF LIMITER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9035M58P02	BRACKET - DEF LIMITER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9035M67G01	BUMPER ASSY - DEF LIMITER	CF6-50	AR	1
9035M67G02	BUMPER ASSY - DEF LIMITER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9037M15P01	BRACKET - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9037M17P07	LEAD - FWD TC	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9037M57G01	BRACKET ASSY - ANGLE	CF6-50 (LMCO)	SV	2
9037M85G01	TUBE ASSY - FWD B SUMP VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9037M85G01	TUBE ASSY - FWD B SUMP VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9037M85G01	TUBE ASSY - FWD B SUMP VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9037M85G01	TUBE ASSY - FWD B SUMP VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9039M34P02	BRACKET - IGN CABLE	CF6-50	AR	1
9039M34P02	BRACKET - IGN CABLE	CF6-50	AR	1
9039M34P02	BRACKET - IGN CABLE	CF6-50	AR	1
9039M34P04	BRACKET - IGN CABLE	CF6-50	NE	1
9039M34P04	BRACKET - IGN CABLE	CF6-50	NE	1
9039M34P04	BRACKET - IGN CABLE	CF6-50	AR	1
9039M34P04	BRACKET - IGN CABLE	CF6-50	AR	1
9039M34P04	BRACKET - IGN CABLE	CF6-50	AR	1
9039M50P01	BRACKET - CASE DR	CF6-50	AR	1
9039M50P01	BRACKET - CASE DR	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9039M51P01	BRACKET - V LINE	CF6-50	AR	1
9039M51P01	BRACKET - V LINE	CF6-50	AR	1
9039M51P01	BRACKET - V LINE	CF6-50	AR	1
9039M51P01	BRACKET - V LINE	CF6-50	SV	1
9039M52P01	BRACKET - IGN CABLE	CF6-50 (LMCO)	AR	1
9039M52P01	BRACKET - IGN CABLE	CF6-50 (LMCO)	OH	1
9039M52P01	BRACKET - IGN CABLE	CF6-50 (LMCO)	OH	1
9039M90P02	BRACKET - ELEC SYS ANGLE	CF6-50	AR	2
9039M90P02	BRACKET - ELEC SYS ANGLE	CF6-50	AR	1
9039M90P02	BRACKET - ELEC SYS ANGLE	CF6-50	AR	1
9039M90P02	BRACKET - ELEC SYS ANGLE	CF6-50	AR	1
9039M90P02	BRACKET - ELEC SYS ANGLE	CF6-50	AR	1
9039M90P02	BRACKET - ELEC SYS ANGLE	CF6-50	SV	2
9039M97P01	PLATE - HYD SYS	CF6-50 (LMCO)	AR	1
9039M97P01	PLATE - HYD SYS	CF6-50 (LMCO)	AR	1
9039M99P01	BRACKET - COWL HOLD OPEN	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9039M99P02	BRACKET - COWL HOLD OPEN	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9039M99P02	BRACKET - COWL HOLD OPEN	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9039M99P02	BRACKET - COWL HOLD OPEN	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9040875-1	EXCITER - IGNITION	CF6-80A, CF6-50 (LMCO)	AR	1
9040875-1	EXCITER - IGNITION	CF6-80A, CF6-50 (LMCO)	AR	1
9040875-1	EXCITER - IGNITION	CF6-80A, CF6-50 (LMCO)	AR	1
9040875-1	EXCITER - IGNITION	CF6-80A, CF6-50 (LMCO)	AR	1
9040875-1	EXCITER - IGNITION	CF6-80A, CF6-50 (LMCO)	AR	1
9040875-1	EXCITER - IGNITION	CF6-80A, CF6-50 (LMCO)	AR	1
9040875-1	EXCITER - IGNITION	CF6-80A, CF6-50 (LMCO)	AR	1
9040875-1	EXCITER - IGNITION	CF6-80A, CF6-50 (LMCO)	OH	1
9040875-1	EXCITER - IGNITION	CF6-80A, CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9040875-1	EXCITER - IGNITION	CF6-80A, CF6-50 (LMCO)	OH	1
9040875-1	EXCITER - IGNITION	CF6-80A, CF6-50 (LMCO)	AR	1
9040875-1	EXCITER - IGNITION	CF6-80A, CF6-50 (LMCO)	OH	1
9040875-1	EXCITER - IGNITION	CF6-80A, CF6-50 (LMCO)	AR	1
9040875-1	EXCITER - IGNITION	CF6-80A, CF6-50 (LMCO)	SV	1
9040875-1	EXCITER - IGNITION	CF6-80A, CF6-50 (LMCO)	AR	1
9040875-1	EXCITER - IGNITION	CF6-80A, CF6-50 (LMCO)	AR	1
9040875-1	EXCITER - IGNITION	CF6-80A, CF6-50 (LMCO)	AR	1
9040M12G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9040M12G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9040M12G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9040M12G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9040M12G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9040M13G01	BRACKET ASSY - HYD SYS	CF6-50	AR	1
9040M13G01	BRACKET ASSY - HYD SYS	CF6-50	AR	1
9040M13G01	BRACKET ASSY - HYD SYS	CF6-50	AR	2
9040M13G01	BRACKET ASSY - HYD SYS	CF6-50	AR	1
9040M13G01	BRACKET ASSY - HYD SYS	CF6-50	AR	1
9040M13G01	BRACKET ASSY - HYD SYS	CF6-50	AR	1
9040M13G01	BRACKET ASSY - HYD SYS	CF6-50	AR	1
9040M13G01	BRACKET ASSY - HYD SYS	CF6-50	AR	1
9040M13G01	BRACKET ASSY - HYD SYS	CF6-50	AR	1
9040M13G01	BRACKET ASSY - HYD SYS	CF6-50	AR	1
9040M13G01	BRACKET ASSY - HYD SYS	CF6-50	SV	1
9040M28G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9040M28G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9040M28G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9040M28G01	BRACKET ASSY - ANGLE	CF6-50	SV	1
9040M42G01	BRACKET ASSY - FUEL	CF6-50 (LMCO)	AR	1
9040M47G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9040M47G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9040M47G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9040M49G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9040M49G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9040M49G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9040M95G01	BRACKET ASSY - VSV CONDTN	CF6-80C2, CF6-50	AR	1
9040M95G01	BRACKET ASSY - VSV CONDTN	CF6-80C2, CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9040M95G01	BRACKET ASSY - VSV CONDTN	CF6-80C2, CF6-50	AR	1
9040M95G01	BRACKET ASSY - VSV CONDTN	CF6-80C2, CF6-50	AR	1
9041M95P02	BRACKET - ANGLE	CF6-50	AR	2
9042M12P04	ACTUATOR ASSY - VAR BYP	CF6-50	AR	1
9042M12P04	ACTUATOR ASSY - VAR BYP	CF6-50	AR	1
9042M12P04	ACTUATOR ASSY - VAR BYP	CF6-50	AR	1
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9042M45G02	ELBOW ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M46G01	ELBOW ASSY - HPT CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M46G01	ELBOW ASSY - HPT CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M46G01	ELBOW ASSY - HPT CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9042M46G01	ELBOW ASSY - HPT CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
9042M46G01	ELBOW ASSY - HPT CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
9042M46G01	ELBOW ASSY - HPT CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
9042M46G01	ELBOW ASSY - HPT CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M46G01	ELBOW ASSY - HPT CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4

Part Number	Part Description	Engine Type	Condition	Quantity
9042M46G01	ELBOW ASSY - HPT CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
9042M46G01	ELBOW ASSY - HPT CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M46G01	ELBOW ASSY - HPT CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9042M46G01	ELBOW ASSY - HPT CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M46G01	ELBOW ASSY - HPT CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
9042M46G01	ELBOW ASSY - HPT CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
9042M46G01	ELBOW ASSY - HPT CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
9042M46G01	ELBOW ASSY - HPT CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9042M46G01	ELBOW ASSY - HPT CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
9042M46G01	ELBOW ASSY - HPT CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9042M46G01	ELBOW ASSY - HPT CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9042M46G01	ELBOW ASSY - HPT CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9042M46G01	ELBOW ASSY - HPT CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	SV	2
9042M46G01	ELBOW ASSY - HPT CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M46G01	ELBOW ASSY - HPT CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9042M46G01	ELBOW ASSY - HPT CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M46G01	ELBOW ASSY - HPT CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
9042M46G01	ELBOW ASSY - HPT CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
9042M46G01	ELBOW ASSY - HPT CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
9042M57G01	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M57G01	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M57G01	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M57G01	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M57G01	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M57G01	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9042M57G01	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M57G01	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M57G01	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M57G01	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M57G01	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M57G02	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO)	AR	1
9042M59G02	TUBE ASSY - LEFT SIDE AIR	CF6-50 (Boeing)	AR	1
9042M59G02	TUBE ASSY - LEFT SIDE AIR	CF6-50 (Boeing)	AR	1
9042M59G02	TUBE ASSY - LEFT SIDE AIR	CF6-50 (Boeing)	AR	1
9042M59G02	TUBE ASSY - LEFT SIDE AIR	CF6-50 (Boeing)	AR	1
9042M59G02	TUBE ASSY - LEFT SIDE AIR	CF6-50 (Boeing)	OH	1
9042M59G02	TUBE ASSY - LEFT SIDE AIR	CF6-50 (Boeing)	AR	1
9042M59G02	TUBE ASSY - LEFT SIDE AIR	CF6-50 (Boeing)	AR	1
9042M59G02	TUBE ASSY - LEFT SIDE AIR	CF6-50 (Boeing)	OH	1
9042M59G02	TUBE ASSY - LEFT SIDE AIR	CF6-50 (Boeing)	AR	1
9042M59G02	TUBE ASSY - LEFT SIDE AIR	CF6-50 (Boeing)	AR	1
9042M59G02	TUBE ASSY - LEFT SIDE AIR	CF6-50 (Boeing)	AR	1
9042M59G02	TUBE ASSY - LEFT SIDE AIR	CF6-50 (Boeing)	OH	1
9042M59G02	TUBE ASSY - LEFT SIDE AIR	CF6-50 (Boeing)	OH	1
9042M59G02	TUBE ASSY - LEFT SIDE AIR	CF6-50 (Boeing)	OH	1
9042M59G02	TUBE ASSY - LEFT SIDE AIR	CF6-50 (Boeing)	OH	1
9042M59G02	TUBE ASSY - LEFT SIDE AIR	CF6-50 (Boeing)	OH	1
9042M59G02	TUBE ASSY - LEFT SIDE AIR	CF6-50 (Boeing)	OH	1
9042M59G02	TUBE ASSY - LEFT SIDE AIR	CF6-50 (Boeing)	AR	1
9042M59G02	TUBE ASSY - LEFT SIDE AIR	CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9042M59G02	TUBE ASSY - LEFT SIDE AIR	CF6-50 (Boeing)	AR	1
9042M59G02	TUBE ASSY - LEFT SIDE AIR	CF6-50 (Boeing)	AR	1
9042M60G01	TUBE ASSY - UPR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9042M60G01	TUBE ASSY - UPR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M60G01	TUBE ASSY - UPR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M60G01	TUBE ASSY - UPR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M60G01	TUBE ASSY - UPR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M60G01	TUBE ASSY - UPR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M60G01	TUBE ASSY - UPR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M60G01	TUBE ASSY - UPR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M60G01	TUBE ASSY - UPR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M60G01	TUBE ASSY - UPR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9042M60G02	TUBE ASSY - UPR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M60G02	TUBE ASSY - UPR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M63G01	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M63G01	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M63G01	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M63G01	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M63G01	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M63G01	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M63G01	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M63G01	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9042M63G01	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9042M63G01	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9042M63G01	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M63G01	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M63G01	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M63G02	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO)	OH	1
9042M63G02	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO)	AR	1
9042M63G02	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO)	AR	1
9042M63G02	TUBE ASSY - LWR AFT HPT AIR	CF6-50 (LMCO)	AR	1
9042M65G01	BRACKET ASSY - TUBE	CF6-50 (LMCO)	SV	1
9042M69G01	TUBE ASSY - FUEL DR	CF6-50	AR	1
9042M69G01	TUBE ASSY - FUEL DR	CF6-50	AR	1
9042M69G01	TUBE ASSY - FUEL DR	CF6-50	AR	1
9042M69G01	TUBE ASSY - FUEL DR	CF6-50	AR	1
9042M69G01	TUBE ASSY - FUEL DR	CF6-50	AR	1
9042M69G01	TUBE ASSY - FUEL DR	CF6-50	AR	1
9042M69G01	TUBE ASSY - FUEL DR	CF6-50	AR	1
9042M69G01	TUBE ASSY - FUEL DR	CF6-50	AR	1
9042M69G01	TUBE ASSY - FUEL DR	CF6-50	AR	1
9042M69G01	TUBE ASSY - FUEL DR	CF6-50	AR	1
9042M69G01	TUBE ASSY - FUEL DR	CF6-50	AR	1
9042M70G01	TUBE ASSY - PYLON GRBX OIL	CF6-50	AR	1
9042M70G01	TUBE ASSY - PYLON GRBX OIL	CF6-50	AR	1
9042M70G01	TUBE ASSY - PYLON GRBX OIL	CF6-50	AR	1
9042M70G01	TUBE ASSY - PYLON GRBX OIL	CF6-50	AR	1
9042M70G01	TUBE ASSY - PYLON GRBX OIL	CF6-50	AR	1
9042M70G01	TUBE ASSY - PYLON GRBX OIL	CF6-50	OH	1
9042M70G01	TUBE ASSY - PYLON GRBX OIL	CF6-50	OH	1
9042M70G01	TUBE ASSY - PYLON GRBX OIL	CF6-50	OH	1
9042M70G01	TUBE ASSY - PYLON GRBX OIL	CF6-50	AR	1
9042M70G01	TUBE ASSY - PYLON GRBX OIL	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9042M70G01	TUBE ASSY - PYLON GRBX OIL	CF6-50	AR	1
9042M70G01	TUBE ASSY - PYLON GRBX OIL	CF6-50	AR	1
9042M71G02	BRACKET ASSY - LWR RS TUBE	CF6-50 (Boeing)	AR	1
9042M71G02	BRACKET ASSY - LWR RS TUBE	CF6-50 (Boeing)	AR	1
9042M72G01	TUBE ASSY - FLTR TO CLG OIL	CF6-50 (LMCO)	AR	1
9042M72G01	TUBE ASSY - FLTR TO CLG OIL	CF6-50 (LMCO)	OH	1
9042M72G01	TUBE ASSY - FLTR TO CLG OIL	CF6-50 (LMCO)	OH	1
9042M72G01	TUBE ASSY - FLTR TO CLG OIL	CF6-50 (LMCO)	AR	1
9042M72G01	TUBE ASSY - FLTR TO CLG OIL	CF6-50 (LMCO)	AR	1
9042M72G01	TUBE ASSY - FLTR TO CLG OIL	CF6-50 (LMCO)	AR	1
9042M72G01	TUBE ASSY - FLTR TO CLG OIL	CF6-50 (LMCO)	AR	1
9042M72G01	TUBE ASSY - FLTR TO CLG OIL	CF6-50 (LMCO)	AR	1
9042M72G01	TUBE ASSY - FLTR TO CLG OIL	CF6-50 (LMCO)	AR	1
9042M72G01	TUBE ASSY - FLTR TO CLG OIL	CF6-50 (LMCO)	SV	1
9042M72G01	TUBE ASSY - FLTR TO CLG OIL	CF6-50 (LMCO)	AR	1
9042M73G02	BRACKET ASSY - DR CAN	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M84G02	BRACKET ASSY - UPR L AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M84G02	BRACKET ASSY - UPR L AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M84G02	BRACKET ASSY - UPR L AFT	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9042M91G02	BRACKET ASSY - TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M91G02	BRACKET ASSY - TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M91G02	BRACKET ASSY - TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	2
9042M91G02	BRACKET ASSY - TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9042M92G02	BRACKET ASSY - TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9042M92G02	BRACKET ASSY - TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9042M92G02	BRACKET ASSY - TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043105-4	LEAD ASSY - IGNITION	CF6-80C2, CF6-80A, CF6-50 (Boeing)	AR	1
9043105-4	LEAD ASSY - IGNITION	CF6-80C2, CF6-80A, CF6-50 (Boeing)	AR	1
9043105-4	LEAD ASSY - IGNITION	CF6-80C2, CF6-80A, CF6-50 (Boeing)	AR	1
9043105-4	LEAD ASSY - IGNITION	CF6-80C2, CF6-80A, CF6-50 (Boeing)	AR	1
9043105-4	LEAD ASSY - IGNITION	CF6-80C2, CF6-80A, CF6-50 (Boeing)	AR	1
9043105-4	LEAD ASSY - IGNITION	CF6-80C2, CF6-80A, CF6-50 (Boeing)	AR	1
9043105-4	LEAD ASSY - IGNITION	CF6-80C2, CF6-80A, CF6-50 (Boeing)	AR	1
9043105-4	LEAD ASSY - IGNITION	CF6-80C2, CF6-80A, CF6-50 (Boeing)	AR	1
9043105-4	LEAD ASSY - IGNITION	CF6-80C2, CF6-80A, CF6-50 (Boeing)	AR	1
9043105-4	LEAD ASSY - IGNITION	CF6-80C2, CF6-80A, CF6-50 (Boeing)	OH	1
9043105-4	LEAD ASSY - IGNITION	CF6-80C2, CF6-80A, CF6-50 (Boeing)	OH	1
9043105-4	LEAD ASSY - IGNITION	CF6-80C2, CF6-80A, CF6-50 (Boeing)	OH	1
9043105-4	LEAD ASSY - IGNITION	CF6-80C2, CF6-80A, CF6-50 (Boeing)	OH	1
9043105-4	LEAD ASSY - IGNITION	CF6-80C2, CF6-80A, CF6-50 (Boeing)	OH	1
9043205	BRACKET - SEAL FIRE	CF6-50 (Boeing)	NS	4
9043M21G01	TUBE ASSY - OIL TANK VENT	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9043M21G01	TUBE ASSY - OIL TANK VENT	CF6-50	AR	1
9043M21G01	TUBE ASSY - OIL TANK VENT	CF6-50	AR	1
9043M21G01	TUBE ASSY - OIL TANK VENT	CF6-50	AR	1
9043M21G01	TUBE ASSY - OIL TANK VENT	CF6-50	AR	1
9043M21G01	TUBE ASSY - OIL TANK VENT	CF6-50	AR	1
9043M21G01	TUBE ASSY - OIL TANK VENT	CF6-50	AR	1
9043M21G01	TUBE ASSY - OIL TANK VENT	CF6-50	AR	1
9043M21G01	TUBE ASSY - OIL TANK VENT	CF6-50	OH	1
9043M21G01	TUBE ASSY - OIL TANK VENT	CF6-50	AR	1
9043M21G01	TUBE ASSY - OIL TANK VENT	CF6-50	SV	1
9043M25G02	MANIFOLD ASSY - MID OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M25G02	MANIFOLD ASSY - MID OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M25G02	MANIFOLD ASSY - MID OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9043M25G02	MANIFOLD ASSY - MID OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M30G02	BRACKET - TUBE	CF6-50 (LMCO)	AR	1
9043M43G02	MANIFOLD ASSY - ACTR	CF6-50	AR	1
9043M43G02	MANIFOLD ASSY - ACTR	CF6-50	AR	1
9043M43G02	MANIFOLD ASSY - ACTR	CF6-50	OH	1
9043M43G03	MANIFOLD ASSY - ACTR HD END	CF6-50 (Boeing)	AR	1
9043M43G03	MANIFOLD ASSY - ACTR HD END	CF6-50 (Boeing)	OH	1
9043M43G03	MANIFOLD ASSY - ACTR HD END	CF6-50 (Boeing)	AR	1
9043M43G03	MANIFOLD ASSY - ACTR HD END	CF6-50 (Boeing)	AR	1
9043M43G03	MANIFOLD ASSY - ACTR HD END	CF6-50 (Boeing)	AR	1
9043M43G03	MANIFOLD ASSY - ACTR HD END	CF6-50 (Boeing)	AR	1
9043M44G02	MANIFOLD ASSY - ACTR ROD	CF6-50	AR	1
9043M44G02	MANIFOLD ASSY - ACTR ROD	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9043M44G03	MANIFOLD ASSY - ACTR ROD	CF6-50 (Boeing)	OH	1
9043M44G03	MANIFOLD ASSY - ACTR ROD	CF6-50 (Boeing)	AR	1
9043M44G03	MANIFOLD ASSY - ACTR ROD	CF6-50 (Boeing)	AR	1
9043M44G03	MANIFOLD ASSY - ACTR ROD	CF6-50 (Boeing)	OH	1
9043M44G03	MANIFOLD ASSY - ACTR ROD	CF6-50 (Boeing)	AR	1
9043M44G03	MANIFOLD ASSY - ACTR ROD	CF6-50 (Boeing)	OH	1
9043M44G03	MANIFOLD ASSY - ACTR ROD	CF6-50 (Boeing)	OH	1
9043M44G03	MANIFOLD ASSY - ACTR ROD	CF6-50 (Boeing)	AR	1
9043M44G03	MANIFOLD ASSY - ACTR ROD	CF6-50 (Boeing)	AR	1
9043M47G01	TUBE ASSY - OIL TANK VENT	CF6-50	SV	1
9043M47G01	TUBE ASSY - OIL TANK VENT	CF6-50	AR	1
9043M47G01	TUBE ASSY - OIL TANK VENT	CF6-50	AR	1
9043M55G01	TUBE ASSY - AFT B SUMP VENT	CF6-50 (LMCO)	AR	1
9043M55G01	TUBE ASSY - AFT B SUMP VENT	CF6-50 (LMCO)	SV	1
9043M55G01	TUBE ASSY - AFT B SUMP VENT	CF6-50 (LMCO)	AR	1
9043M55G03	TUBE ASSY - AFT B SUMP VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M55G03	TUBE ASSY - AFT B SUMP VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M55G03	TUBE ASSY - AFT B SUMP VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M55G03	TUBE ASSY - AFT B SUMP VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M55G03	TUBE ASSY - AFT B SUMP VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M55G03	TUBE ASSY - AFT B SUMP VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M55G03	TUBE ASSY - AFT B SUMP VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M55G03	TUBE ASSY - AFT B SUMP VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M55G03	TUBE ASSY - AFT B SUMP VENT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9043M55G03	TUBE ASSY - AFT B SUMP VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M55G03	TUBE ASSY - AFT B SUMP VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M55G03	TUBE ASSY - AFT B SUMP VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M64G01	BRACKET ASSY - ANGLE	CF6-50	AR	2
9043M64G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9043M64G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9043M64G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9043M64G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9043M64G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9043M70G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9043M70G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9043M70G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9043M71P01	BRACKET - LWR RS MANIFOLD	CF6-50 (Boeing)	AR	1
9043M71P01	BRACKET - LWR RS MANIFOLD	CF6-50 (Boeing)	AR	1
9043M73P01	BRACKET - UPR LS MANIFOLD	CF6-50 (LMCO)	AR	1
9043M74P01	BRACKET - LWR LS MANIFOLD	CF6-50 (LMCO)	SV	1
9043M74P01	BRACKET - LWR LS MANIFOLD	CF6-50 (LMCO)	SV	1
9043M74P01	BRACKET - LWR LS MANIFOLD	CF6-50 (LMCO)	AR	1
9043M79G02	TUBE ASSY - OIL TANK VENT	CF6-50	AR	1
9043M79G02	TUBE ASSY - OIL TANK VENT	CF6-50	AR	1
9043M79G02	TUBE ASSY - OIL TANK VENT	CF6-50	AR	1
9043M79G02	TUBE ASSY - OIL TANK VENT	CF6-50	AR	1
9043M79G02	TUBE ASSY - OIL TANK VENT	CF6-50	AR	1
9043M79G02	TUBE ASSY - OIL TANK VENT	CF6-50	AR	1
9043M79G02	TUBE ASSY - OIL TANK VENT	CF6-50	AR	1
9043M79G02	TUBE ASSY - OIL TANK VENT	CF6-50	AR	1
9043M80G02	TUBE ASSY - OIL TANK VENT	CF6-50	OH	1
9043M80G02	TUBE ASSY - OIL TANK VENT	CF6-50	AR	1
9043M80G02	TUBE ASSY - OIL TANK VENT	CF6-50	AR	1
9043M80G02	TUBE ASSY - OIL TANK VENT	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9043M80G02	TUBE ASSY - OIL TANK VENT	CF6-50	AR	1
9043M80G02	TUBE ASSY - OIL TANK VENT	CF6-50	AR	1
9043M80G02	TUBE ASSY - OIL TANK VENT	CF6-50	AR	1
9043M85G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M85G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M85G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M85G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M85G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M85G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M85G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9043M85G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M85G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M85G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M85G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M85G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M85G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M85G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M85G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M85G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M85G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M85G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9043M85G02	TUBE ASSY - AFT OIL	CF6-50 (LMCO)	AR	1
9043M85G02	TUBE ASSY - AFT OIL	CF6-50 (LMCO)	OH	1
9043M85G02	TUBE ASSY - AFT OIL	CF6-50 (LMCO)	AR	1
9043M95G01	TUBE ASSY - TANK VENT	CF6-50	AR	1
9043M98P01	TUBE/HOSE ASSY - OIL	CF6-50	AR	1
9043M98P01	TUBE/HOSE ASSY - OIL	CF6-50	AR	1
9044240-2	PLUG - MAIN IGNITER (TYPE IV)	CF6-80A, CF6-50 (Boeing)	AR	1
9044240-2	PLUG - MAIN IGNITER (TYPE IV)	CF6-80A, CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044240-2	PLUG - MAIN IGNITER (TYPE IV)	CF6-80A, CF6-50 (Boeing)	AR	1
9044240-2	PLUG - MAIN IGNITER (TYPE IV)	CF6-80A, CF6-50 (Boeing)	AR	1
9044240-2	PLUG - MAIN IGNITER (TYPE IV)	CF6-80A, CF6-50 (Boeing)	AR	1
9044240-2	PLUG - MAIN IGNITER (TYPE IV)	CF6-80A, CF6-50 (Boeing)	AR	1
9044240-2	PLUG - MAIN IGNITER (TYPE IV)	CF6-80A, CF6-50 (Boeing)	AR	1
9044240-2	PLUG - MAIN IGNITER (TYPE IV)	CF6-80A, CF6-50 (Boeing)	AR	1
9044240-2	PLUG - MAIN IGNITER (TYPE IV)	CF6-80A, CF6-50 (Boeing)	NE	1
9044240-2	PLUG - MAIN IGNITER (TYPE IV)	CF6-80A, CF6-50 (Boeing)	NE	1
9044M10G10	CASE ASSY - LPT STTR	CF6-50 (LMCO)	AR	1
9044M10G10	CASE ASSY - LPT STTR	CF6-50 (LMCO)	AR	1
9044M21P07	BLADE - LPT STG 1	CF6-50	AR	3
9044M21P09	BLADE - LPT STG 1	CF6-50 (LMCO)	AR	23
9044M21P09	BLADE - LPT STG 1	CF6-50 (LMCO)	AR	3
9044M21P09	BLADE - LPT STG 1	CF6-50 (LMCO)	AR	1
9044M21P09	BLADE - LPT STG 1	CF6-50 (LMCO)	AR	1
9044M21P09	BLADE - LPT STG 1	CF6-50 (LMCO)	OH	2
9044M21P09	BLADE - LPT STG 1	CF6-50 (LMCO)	AR	51
9044M21P09	BLADE - LPT STG 1	CF6-50 (LMCO)	AR	46
9044M21P09	BLADE - LPT STG 1	CF6-50 (LMCO)	AR	40
9044M21P09	BLADE - LPT STG 1	CF6-50 (LMCO)	OH	1
9044M21P09	BLADE - LPT STG 1	CF6-50 (LMCO)	AR	16
9044M21P09	BLADE - LPT STG 1	CF6-50 (LMCO)	AR	125
9044M21P09	BLADE - LPT STG 1	CF6-50 (LMCO)	AR	1
9044M21P09	BLADE - LPT STG 1	CF6-50 (LMCO)	AR	66
9044M21P09	BLADE - LPT STG 1	CF6-50 (LMCO)	AR	84
9044M21P09	BLADE - LPT STG 1	CF6-50 (LMCO)	AR	23
9044M21P09	BLADE - LPT STG 1	CF6-50 (LMCO)	AR	26
9044M21P09	BLADE - LPT STG 1	CF6-50 (LMCO)	AR	1
9044M21P09	BLADE - LPT STG 1	CF6-50 (LMCO)	AR	31
9044M22P04	BLADE - LPT STG 2	CF6-50	AR	8
9044M22P04	BLADE - LPT STG 2	CF6-50	AR	2
9044M22P04	BLADE - LPT STG 2	CF6-50	AR	11
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	126
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	3
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	1
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	1
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	126
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	3
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	4
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	123

Part Number	Part Description	Engine Type	Condition	Quantity
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	1
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	1
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	126
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	126
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	126
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	122
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	126
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	126
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	1
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	126
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	21
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	126
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	100
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	73
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	118
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	126
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	126
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	126
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	OH	34
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	126
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	124
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	126
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	115
9044M22P06	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	17
9044M22P10	BLADE - LPT STG 2	CF6-50 (LMCO)	OH	20
9044M22P11	BLADE - LPT STG 2	CF6-50 (LMCO)	SV	26
9044M22P11	BLADE - LPT STG 2	CF6-50 (LMCO)	OH	2
9044M22P11	BLADE - LPT STG 2	CF6-50 (LMCO)	OH	5
9044M22P11	BLADE - LPT STG 2	CF6-50 (LMCO)	OH	4
9044M22P11	BLADE - LPT STG 2	CF6-50 (LMCO)	OH	2
9044M22P11	BLADE - LPT STG 2	CF6-50 (LMCO)	OH	12
9044M22P11	BLADE - LPT STG 2	CF6-50 (LMCO)	OH	7
9044M22P11	BLADE - LPT STG 2	CF6-50 (LMCO)	OH	8
9044M22P11	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	46
9044M22P11	BLADE - LPT STG 2	CF6-50 (LMCO)	AR	79
9044M22P11	BLADE - LPT STG 2	CF6-50 (LMCO)	OH	30
9044M22P11	BLADE - LPT STG 2	CF6-50 (LMCO)	OH	57
9044M23P04	BLADE - LPT STG 3	CF6-50	AR	6
9044M23P04	BLADE - LPT STG 3	CF6-50	AR	33
9044M23P04	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P04	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P04	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P04	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	OH	1
9044M23P06	BLADE - LPT STG 3	CF6-50	OH	1
9044M23P06	BLADE - LPT STG 3	CF6-50	OH	1
9044M23P06	BLADE - LPT STG 3	CF6-50	OH	1
9044M23P06	BLADE - LPT STG 3	CF6-50	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	OH	39
9044M23P06	BLADE - LPT STG 3	CF6-50	OH	37
9044M23P06	BLADE - LPT STG 3	CF6-50	OH	11
9044M23P06	BLADE - LPT STG 3	CF6-50	OH	12
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	15
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	109

Part Number	Part Description	Engine Type	Condition	Quantity
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	107
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	112
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	112
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	112
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	112
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	112
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	80
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	112
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	79
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	87
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	1
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	112
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	112
9044M23P06	BLADE - LPT STG 3	CF6-50	AR	6
9044M23P13	BLADE - LPT STG 3	CF6-50 (LMCO)	AR	112
9044M23P13	BLADE - LPT STG 3	CF6-50 (LMCO)	AR	112
9044M23P13	BLADE - LPT STG 3	CF6-50 (LMCO)	AR	112
9044M23P15	BLADE - LPT STG 3	CF6-50	AR	106
9044M23P16	BLADE - LPT STG 3	CF6-50 (LMCO)	AR	3
9044M23P16	BLADE - LPT STG 3	CF6-50 (LMCO)	OH	1
9044M23P17	BLADE - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	17
9044M23P17	BLADE - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	49
9044M23P17	BLADE - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9044M23P17	BLADE - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
9044M26P03	SEAL - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M26P03	SEAL - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M26P03	SEAL - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M26P03	SEAL - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M26P03	SEAL - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M26P03	SEAL - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M26P03	SEAL - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M26P03	SEAL - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M26P03	SEAL - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M26P03	SEAL - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M26P03	SEAL - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M26P03	SEAL - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M26P03	SEAL - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M26P03	SEAL - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M26P03	SEAL - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M26P03	SEAL - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M26P03	SEAL - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M26P03	SEAL - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M26P03	SEAL - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M26P03	SEAL - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M26P03	SEAL - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M26P03	SEAL - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M26P03	SEAL - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G09	SEAL ASSY - STG 3	CF6-50	AR	1
9044M29G09	SEAL ASSY - STG 3	CF6-50	AR	1
9044M29G09	SEAL ASSY - STG 3	CF6-50	AR	1
9044M29G09	SEAL ASSY - STG 3	CF6-50	AR	1
9044M29G09	SEAL ASSY - STG 3	CF6-50	AR	1
9044M29G09	SEAL ASSY - STG 3	CF6-50	AR	1
9044M29G09	SEAL ASSY - STG 3	CF6-50	AR	1
9044M29G09	SEAL ASSY - STG 3	CF6-50	AR	1
9044M29G09	SEAL ASSY - STG 3	CF6-50	AR	1
9044M29G09	SEAL ASSY - STG 3	CF6-50	AR	1
9044M29G09	SEAL ASSY - STG 3	CF6-50	AR	1
9044M29G09	SEAL ASSY - STG 3	CF6-50	AR	1
9044M29G10	SEAL ASSY - STG 4	CF6-50	AR	1
9044M29G10	SEAL ASSY - STG 4	CF6-50	AR	1
9044M29G10	SEAL ASSY - STG 4	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10

Part Number	Part Description	Engine Type	Condition	Quantity
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G12	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G13	SEAL ASSY - STG 3	CF6-50	OH	6
9044M29G13	SEAL ASSY - STG 3	CF6-50	AR	1
9044M29G13	SEAL ASSY - STG 3	CF6-50	AR	1
9044M29G13	SEAL ASSY - STG 3	CF6-50	AR	1
9044M29G13	SEAL ASSY - STG 3	CF6-50	AR	1
9044M29G13	SEAL ASSY - STG 3	CF6-50	AR	1
9044M29G13	SEAL ASSY - STG 3	CF6-50	AR	1
9044M29G13	SEAL ASSY - STG 3	CF6-50	AR	1
9044M29G13	SEAL ASSY - STG 3	CF6-50	AR	1
9044M29G13	SEAL ASSY - STG 3	CF6-50	AR	1
9044M29G14	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9044M29G14	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G14	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G14	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9044M29G14	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
9044M29G14	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G14	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	SV	4
9044M29G14	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G14	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G14	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
9044M29G14	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
9044M29G14	SEAL ASSY - STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G17	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	14
9044M29G17	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M29G17	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9044M29G17	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M29G17	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M29G17	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M29G17	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M29G17	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M29G17	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
9044M29G17	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9044M29G17	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
9044M29G17	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G17	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G17	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G17	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G17	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G17	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M29G17	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G17	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G17	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M29G17	SEAL ASSY - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M31G14	NOZZLE ASSY - LPT STTR STG 1	CF6-50	AR	1
9044M31G14	NOZZLE ASSY - LPT STTR STG 1	CF6-50	AR	1
9044M31G18	NOZZLE ASSY - LPT STTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M31G18	NOZZLE ASSY - LPT STTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M31G18	NOZZLE ASSY - LPT STTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M31G18	NOZZLE ASSY - LPT STTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M31G18	NOZZLE ASSY - LPT STTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M31G18	NOZZLE ASSY - LPT STTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M31G18	NOZZLE ASSY - LPT STTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M31G18	NOZZLE ASSY - LPT STTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M31G18	NOZZLE ASSY - LPT STTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M31G18	NOZZLE ASSY - LPT STTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M31G18	NOZZLE ASSY - LPT STTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M31G18	NOZZLE ASSY - LPT STTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M31G18	NOZZLE ASSY - LPT STTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M31G18	NOZZLE ASSY - LPT STTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M31G18	NOZZLE ASSY - LPT STTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M31G18	NOZZLE ASSY - LPT STTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M31G18	NOZZLE ASSY - LPT STTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M31G19	NOZZLE ASSY - LPT STTR STG 1	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M31G22	NOZZLE ASSY - LPT STTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M31G22	NOZZLE ASSY - LPT STTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M31G22	NOZZLE ASSY - LPT STTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9044M31G22	NOZZLE ASSY - LPT STTR STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G13	NOZZLE ASSY - LPT STG 2	CF6-50	SV	1
9044M32G13	NOZZLE ASSY - LPT STG 2	CF6-50	AR	1
9044M32G13	NOZZLE ASSY - LPT STG 2	CF6-50	AR	2
9044M32G13	NOZZLE ASSY - LPT STG 2	CF6-50	AR	1
9044M32G13	NOZZLE ASSY - LPT STG 2	CF6-50	AR	1
9044M32G13	NOZZLE ASSY - LPT STG 2	CF6-50	AR	1
9044M32G13	NOZZLE ASSY - LPT STG 2	CF6-50	AR	1
9044M32G13	NOZZLE ASSY - LPT STG 2	CF6-50	AR	1
9044M32G13	NOZZLE ASSY - LPT STG 2	CF6-50	AR	1
9044M32G13	NOZZLE ASSY - LPT STG 2	CF6-50	AR	1
9044M32G13	NOZZLE ASSY - LPT STG 2	CF6-50	AR	1
9044M32G13	NOZZLE ASSY - LPT STG 2	CF6-50	AR	3
9044M32G14	NOZZLE ASSY - LPT STG 2	CF6-50	OH	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

[illegible]

Part Number	Part Description	Engine Type	Condition	Quantity
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G17	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G18	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G19	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M32G19	NOZZLE ASSY - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P03	NOZZLE ASSY - LPT STG 3	CF6-50	AR	1
9044M33P03	NOZZLE ASSY - LPT STG 3	CF6-50	AR	1
9044M33P03	NOZZLE ASSY - LPT STG 3	CF6-50	AR	1
9044M33P03	NOZZLE ASSY - LPT STG 3	CF6-50	AR	1
9044M33P03	NOZZLE ASSY - LPT STG 3	CF6-50	AR	1
9044M33P03	NOZZLE ASSY - LPT STG 3	CF6-50	AR	1
9044M33P03	NOZZLE ASSY - LPT STG 3	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

[illegible]

[illegible]

Part Number	Part Description	Engine Type	Condition	Quantity
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P06	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M33P07	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P07	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P07	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P07	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P07	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P07	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P07	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P07	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P07	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P07	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	17
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P08	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P09	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P09	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M33P09	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P09	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P09	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P09	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M33P09	NOZZLE ASSY - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

[illegible]

Part Number	Part Description	Engine Type	Condition	Quantity
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P06	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P07	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P07	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P07	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P07	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P07	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P07	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P07	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P07	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P07	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M34P08	NOZZLE ASSY - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M35G07	SHROUD ASSY - STG 2	CF6-50	AR	1
9044M35G07	SHROUD ASSY - STG 2	CF6-50	AR	1
9044M35G07	SHROUD ASSY - STG 2	CF6-50	AR	1
9044M35G07	SHROUD ASSY - STG 2	CF6-50	AR	1
9044M35G07	SHROUD ASSY - STG 2	CF6-50	AR	1
9044M35G07	SHROUD ASSY - STG 2	CF6-50	AR	1
9044M35G07	SHROUD ASSY - STG 2	CF6-50	AR	1
9044M35G07	SHROUD ASSY - STG 2	CF6-50	AR	1
9044M35G07	SHROUD ASSY - STG 2	CF6-50	AR	16
9044M35G07	SHROUD ASSY - STG 2	CF6-50	AR	16
9044M35G08	SHROUD ASSY - STG 3	CF6-50	OH	16
9044M35G08	SHROUD ASSY - STG 3	CF6-50	OH	12
9044M35G08	SHROUD ASSY - STG 3	CF6-50	OH	20
9044M35G08	SHROUD ASSY - STG 3	CF6-50	AR	20
9044M35G08	SHROUD ASSY - STG 3	CF6-50	AR	20
9044M35G08	SHROUD ASSY - STG 3	CF6-50	AR	20
9044M35G08	SHROUD ASSY - STG 3	CF6-50	AR	1
9044M35G08	SHROUD ASSY - STG 3	CF6-50	AR	1
9044M35G08	SHROUD ASSY - STG 3	CF6-50	AR	20
9044M35G10	SHROUD ASSY - STG 3	CF6-50	AR	5
9044M35G11	SHROUD ASSY - STG 2	CF6-50	AR	10
9044M35G12	SHROUD ASSY - STG 3	CF6-50	OH	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	OH	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	OH	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	OH	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	OH	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	OH	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	OH	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	OH	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	OH	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	OH	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	OH	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	OH	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	OH	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	AR	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	AR	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	AR	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	AR	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	AR	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	AR	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	AR	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	AR	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	AR	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	AR	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	AR	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	AR	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	AR	10
9044M35G12	SHROUD ASSY - STG 3	CF6-50	AR	20
9044M35G12	SHROUD ASSY - STG 3	CF6-50	OH	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	AR	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9044M35G12	SHROUD ASSY - STG 3	CF6-50	AR	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	AR	4
9044M35G12	SHROUD ASSY - STG 3	CF6-50	AR	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	AR	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	AR	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	AR	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	AR	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	AR	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	AR	1
9044M35G12	SHROUD ASSY - STG 3	CF6-50	AR	1
9044M36G04	SHROUD ASSY - STG 1	CF6-50	AR	8
9044M36G06	SHROUD ASSY - STG 1	CF6-50	OH	7
9044M36G06	SHROUD ASSY - STG 1	CF6-50	OH	6
9044M36G06	SHROUD ASSY - STG 1	CF6-50	OH	3
9044M36G06	SHROUD ASSY - STG 1	CF6-50	OH	5
9044M36G06	SHROUD ASSY - STG 1	CF6-50	AR	16
9044M36G06	SHROUD ASSY - STG 1	CF6-50	AR	10
9044M36G06	SHROUD ASSY - STG 1	CF6-50	AR	16
9044M36G06	SHROUD ASSY - STG 1	CF6-50	AR	15
9044M36G06	SHROUD ASSY - STG 1	CF6-50	AR	16
9044M36G08	SHROUD ASSY - STG 1	CF6-50	AR	7
9044M36G08	SHROUD ASSY - STG 1	CF6-50	AR	6
9044M46G02	SHROUD ASSY - STG 4	CF6-50	OH	15
9044M46G02	SHROUD ASSY - STG 4	CF6-50	AR	2
9044M46G02	SHROUD ASSY - STG 4	CF6-50	AR	11
9044M46G02	SHROUD ASSY - STG 4	CF6-50	AR	2
9044M46G02	SHROUD ASSY - STG 4	CF6-50	AR	7
9044M46G02	SHROUD ASSY - STG 4	CF6-50	AR	2
9044M46G04	SHROUD ASSY - STG 4	CF6-50	OH	20
9044M46G04	SHROUD ASSY - STG 4	CF6-50	AR	6
9044M46G04	SHROUD ASSY - STG 4	CF6-50	AR	4
9044M46G04	SHROUD ASSY - STG 4	CF6-50	AR	20
9044M46G04	SHROUD ASSY - STG 4	CF6-50	AR	20
9044M46G04	SHROUD ASSY - STG 4	CF6-50	AR	20
9044M46G04	SHROUD ASSY - STG 4	CF6-50	AR	15
9044M46G04	SHROUD ASSY - STG 4	CF6-50	AR	2
9044M46G04	SHROUD ASSY - STG 4	CF6-50	AR	20
9044M46G04	SHROUD ASSY - STG 4	CF6-50	OH	1
9044M46G04	SHROUD ASSY - STG 4	CF6-50	OH	1
9044M46G04	SHROUD ASSY - STG 4	CF6-50	OH	1
9044M46G04	SHROUD ASSY - STG 4	CF6-50	OH	1
9044M46G04	SHROUD ASSY - STG 4	CF6-50	OH	1
9044M46G04	SHROUD ASSY - STG 4	CF6-50	AR	13
9044M46G04	SHROUD ASSY - STG 4	CF6-50	AR	10
9044M46G04	SHROUD ASSY - STG 4	CF6-50	AR	10
9044M46G04	SHROUD ASSY - STG 4	CF6-50	AR	20
9044M46G04	SHROUD ASSY - STG 4	CF6-50	AR	5
9044M46G04	SHROUD ASSY - STG 4	CF6-50	AR	8

[illegible]

[illegible]

Part Number	Part Description	Engine Type	Condition	Quantity
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	1
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	42
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	66
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	24
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	4
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	10
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	1
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	82
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	70
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	51
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	63
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	64
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	23
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	22
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	54
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	1
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	1
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	1
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	1
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	1
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	1
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	3
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	23
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	1
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	25
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	56
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	24
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	63
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	20
9044M54P06	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	22
9044M54P09	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	3
9044M54P09	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	12
9044M54P09	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	2
9044M54P09	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	9
9044M54P09	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	61
9044M54P09	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	1
9044M54P09	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	1
9044M54P09	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	80
9044M54P09	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	1
9044M54P09	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	2
9044M54P09	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	14
9044M54P09	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	1
9044M54P09	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	1
9044M54P09	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	71
9044M54P09	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	13
9044M54P09	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	40
9044M54P09	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	22
9044M54P09	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	62

Part Number	Part Description	Engine Type	Condition	Quantity
9044M54P09	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	19
9044M54P09	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	17
9044M54P09	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	4
9044M54P09	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	61
9044M54P09	BLADE - LPT STG 4	CF6-50 (LMCO)	AR	30
9044M54P09	BLADE - LPT STG 4	CF6-50 (LMCO)	OH	15
9044M54P09	BLADE - LPT STG 4	CF6-50 (LMCO)	OH	24
9044M54P09	BLADE - LPT STG 4	CF6-50 (LMCO)	OH	8
9044M54P09	BLADE - LPT STG 4	CF6-50 (LMCO)	OH	35
9044M54P13	BLADE - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	12
9044M54P13	BLADE - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9044M54P14	BLADE - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	11
9044M54P14	BLADE - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	26
9044M54P14	BLADE - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	11
9044M60G05	BRACKET ASSY - LP TURB CLG	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9044M61G02	BRACKET ASSY - CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9044M61G02	BRACKET ASSY - CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9044M61G02	BRACKET ASSY - CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9044M61G02	BRACKET ASSY - CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9044M62G02	BRACKET ASSY - CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9044M62G02	BRACKET ASSY - CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9044M62G02	BRACKET ASSY - CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9044M62G02	BRACKET ASSY - CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9044M62G02	BRACKET ASSY - CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9044M62G02	BRACKET ASSY - CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9044M62G02	BRACKET ASSY - CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9044M62G02	BRACKET ASSY - CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1

[illegible]

[illegible]

Part Number	Part Description	Engine Type	Condition	Quantity
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	SV	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	SV	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	SV	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	OH	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	OH	1
9045M14G06	BLADE ASSY - HPTR STG 2	CF6-50	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9045M32P03	SUPPORT - FWD HPTS SHOUD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
9045M32P03	SUPPORT - FWD HPTS SHOUD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
9045M32P03	SUPPORT - FWD HPTS SHOUD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	21
9045M32P03	SUPPORT - FWD HPTS SHOUD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
9045M32P03	SUPPORT - FWD HPTS SHOUD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
9045M32P03	SUPPORT - FWD HPTS SHOUD	CF6-50 (LMCO), CF6-50 (Boeing)	REP	1
9045M32P03	SUPPORT - FWD HPTS SHOUD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
9045M32P03	SUPPORT - FWD HPTS SHOUD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
9045M32P03	SUPPORT - FWD HPTS SHOUD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	11
9045M32P03	SUPPORT - FWD HPTS SHOUD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
9045M32P03	SUPPORT - FWD HPTS SHOUD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
9045M32P03	SUPPORT - FWD HPTS SHOUD	CF6-50 (LMCO), CF6-50 (Boeing)	OH	10
9045M32P03	SUPPORT - FWD HPTS SHOUD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
9045M32P03	SUPPORT - FWD HPTS SHOUD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
9045M32P03	SUPPORT - FWD HPTS SHOUD	CF6-50 (LMCO), CF6-50 (Boeing)	NS	101
9045M32P03	SUPPORT - FWD HPTS SHOUD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
9045M32P03	SUPPORT - FWD HPTS SHOUD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
9045M49G06	SEAL ASSY - AFT AIR BOT	CF6-50 (Boeing)	AR	1
9045M49G06	SEAL ASSY - AFT AIR BOT	CF6-50 (Boeing)	AR	1
9045M49G06	SEAL ASSY - AFT AIR BOT	CF6-50 (Boeing)	AR	1
9045M49G06	SEAL ASSY - AFT AIR BOT	CF6-50 (Boeing)	AR	1
9045M49G06	SEAL ASSY - AFT AIR BOT	CF6-50 (Boeing)	AR	1
9045M49G06	SEAL ASSY - AFT AIR BOT	CF6-50 (Boeing)	AR	1
9045M49G06	SEAL ASSY - AFT AIR BOT	CF6-50 (Boeing)	AR	1
9045M49G06	SEAL ASSY - AFT AIR BOT	CF6-50 (Boeing)	AR	1
9045M49G06	SEAL ASSY - AFT AIR BOT	CF6-50 (Boeing)	AR	1
9045M49G06	SEAL ASSY - AFT AIR BOT	CF6-50 (Boeing)	AR	1
9045M49G06	SEAL ASSY - AFT AIR BOT	CF6-50 (Boeing)	OH	1
9045M49G06	SEAL ASSY - AFT AIR BOT	CF6-50 (Boeing)	AR	1
9045M49G06	SEAL ASSY - AFT AIR BOT	CF6-50 (Boeing)	AR	1
9045M49G06	SEAL ASSY - AFT AIR BOT	CF6-50 (Boeing)	AR	1
9045M49G06	SEAL ASSY - AFT AIR BOT	CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9045M87G04	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M87G04	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M87G04	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M87G04	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M87G04	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M87G04	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M87G04	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M87G04	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M87G04	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M87G04	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M87G04	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M87G04	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M87G04	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M87G04	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M87G04	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M87G04	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M87G04	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M87G04	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M87G04	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M87G04	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M87G04	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M87G04	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M87G05	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M87G05	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M87G05	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M87G05	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9045M87G05	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M87G05	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M87G05	TUBE ASSY - PRESS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9045M94G39	NOZZLE ASSY - HPT STG 1	CF6-50	OH	1
9045M94G39	NOZZLE ASSY - HPT STG 1	CF6-50	OH	1
9045M94G39	NOZZLE ASSY - HPT STG 1	CF6-50	OH	1
9045M94G39	NOZZLE ASSY - HPT STG 1	CF6-50	OH	1
9045M94G39	NOZZLE ASSY - HPT STG 1	CF6-50	OH	1
9046M14P01	NUT - PL RND BRG NO. 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M14P01	NUT - PL RND BRG NO. 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M14P01	NUT - PL RND BRG NO. 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M14P01	NUT - PL RND BRG NO. 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M14P01	NUT - PL RND BRG NO. 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M14P01	NUT - PL RND BRG NO. 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9046M14P01	NUT - PL RND BRG NO. 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M14P01	NUT - PL RND BRG NO. 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M14P01	NUT - PL RND BRG NO. 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9046M14P01	NUT - PL RND BRG NO. 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M14P01	NUT - PL RND BRG NO. 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M14P01	NUT - PL RND BRG NO. 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
9046M14P02	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M14P02	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M14P02	#3 BEARING INNR FACE PLAIN NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M16G01	SEAL ASSY - PRESS BAL ROT	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9046M16G01	SEAL ASSY - PRESS BAL ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M16G01	SEAL ASSY - PRESS BAL ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M16G01	SEAL ASSY - PRESS BAL ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M16G01	SEAL ASSY - PRESS BAL ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M16G01	SEAL ASSY - PRESS BAL ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M16G01	SEAL ASSY - PRESS BAL ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M16G01	SEAL ASSY - PRESS BAL ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M16G01	SEAL ASSY - PRESS BAL ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M16G01	SEAL ASSY - PRESS BAL ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M16G02	SEAL ASSY - PRESS BAL ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M16G02	SEAL ASSY - PRESS BAL ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M16P01	SEAL - PRESS BAL ROT	CF6-50 (LMCO)	AR	1
9046M16P01	SEAL - PRESS BAL ROT	CF6-50 (LMCO)	AR	1
9046M16P01	SEAL - PRESS BAL ROT	CF6-50 (LMCO)	AR	1
9046M16P01	SEAL - PRESS BAL ROT	CF6-50 (LMCO)	AR	1
9046M16P01	SEAL - PRESS BAL ROT	CF6-50 (LMCO)	OH	1
9046M16P01	SEAL - PRESS BAL ROT	CF6-50 (LMCO)	AR	1
9046M16P01	SEAL - PRESS BAL ROT	CF6-50 (LMCO)	AR	1
9046M16P01	SEAL - PRESS BAL ROT	CF6-50 (LMCO)	AR	1
9046M16P02	RING	CF6-50 (LMCO)	NS	1
9046M16P02	RING	CF6-50 (LMCO)	NS	1
9046M16P02	RING	CF6-50 (LMCO)	NS	1
9046M16P02	RING	CF6-50 (LMCO)	NS	1
9046M16P02	RING	CF6-50 (LMCO)	NS	1
9046M16P02	RING	CF6-50 (LMCO)	NS	1
9046M16P03	SEAL - PRESS BAL ROT	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9046M20P02	SEAL - BRG NO 7 AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M20P02	SEAL - BRG NO 7 AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M20P02	SEAL - BRG NO 7 AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M20P02	SEAL - BRG NO 7 AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M20P02	SEAL - BRG NO 7 AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M20P02	SEAL - BRG NO 7 AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M20P02	SEAL - BRG NO 7 AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M20P02	SEAL - BRG NO 7 AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M20P02	SEAL - BRG NO 7 AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M20P02	SEAL - BRG NO 7 AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M20P02	SEAL - BRG NO 7 AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M20P02	SEAL - BRG NO 7 AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M20P02	SEAL - BRG NO 7 AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M20P02	SEAL - BRG NO 7 AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M20P02	SEAL - BRG NO 7 AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M20P02	SEAL - BRG NO 7 AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9046M20P02	SEAL - BRG NO 7 AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M20P02	SEAL - BRG NO 7 AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M20P02	SEAL - BRG NO 7 AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M20P02	SEAL - BRG NO 7 AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M29P01	SHIELD - OIL BRG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M42P01	NOZZLE - OIL BRG NO. 7	CF6-50 (LMCO)	AR	1
9046M42P01	NOZZLE - OIL BRG NO. 7	CF6-50 (LMCO)	OH	1
9046M44G05	SEAL - STA OIL BRG NO. 3	CF6-50	AR	1
9046M44G05	SEAL - STA OIL BRG NO. 3	CF6-50	AR	1
9046M44G05	SEAL - STA OIL BRG NO. 3	CF6-50	AR	1
9046M44G05	SEAL - STA OIL BRG NO. 3	CF6-50	AR	1
9046M44G05	SEAL - STA OIL BRG NO. 3	CF6-50	OH	1
9046M44G05	SEAL - STA OIL BRG NO. 3	CF6-50	AR	1
9046M44G05	SEAL - STA OIL BRG NO. 3	CF6-50	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9046M44G05	SEAL - STA OIL BRG NO. 3	CF6-50	AR	1
9046M44G05	SEAL - STA OIL BRG NO. 3	CF6-50	AR	1
9046M44G05	SEAL - STA OIL BRG NO. 3	CF6-50	AR	1
9046M44G05	SEAL - STA OIL BRG NO. 3	CF6-50	AR	1
9046M44G05	SEAL - STA OIL BRG NO. 3	CF6-50	AR	1
9046M45P03	SEAL - OIL BRG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M45P03	SEAL - OIL BRG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M45P03	SEAL - OIL BRG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M45P03	SEAL - OIL BRG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M45P03	SEAL - OIL BRG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M45P03	SEAL - OIL BRG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M45P03	SEAL - OIL BRG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M45P03	SEAL - OIL BRG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M45P03	SEAL - OIL BRG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M45P03	SEAL - OIL BRG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M45P03	SEAL - OIL BRG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M45P03	SEAL - OIL BRG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M45P03	SEAL - OIL BRG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9046M62G01	AIR SEAL - 4R CDP STA AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M62G01	AIR SEAL - 4R CDP STA AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M62G01	AIR SEAL - 4R CDP STA AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9046M62G01	AIR SEAL - 4R CDP STA AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M62G01	AIR SEAL - 4R CDP STA AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M62G01	AIR SEAL - 4R CDP STA AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M62G02	AIR SEAL - 4R CDP STA AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M62G02	AIR SEAL - 4R CDP STA AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M62G02	AIR SEAL - 4R CDP STA AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P03	SEAL - STA 4R AIR/OIL	CF6-50 (Boeing)	AR	1
9046M67P03	SEAL - STA 4R AIR/OIL	CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M67P04	SEAL - STA 4R AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M69P05	SEAL - BRG NO 4R OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9046M73P01	SEAL - BRG 4B AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M73P01	SEAL - BRG 4B AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M73P01	SEAL - BRG 4B AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M73P01	SEAL - BRG 4B AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M73P01	SEAL - BRG 4B AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M73P01	SEAL - BRG 4B AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M73P01	SEAL - BRG 4B AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M73P01	SEAL - BRG 4B AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9046M74P02	SEAL - BRG 4B CUTER AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M74P02	SEAL - BRG 4B CUTER AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M74P02	SEAL - BRG 4B CUTER AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M74P02	SEAL - BRG 4B CUTER AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M74P02	SEAL - BRG 4B CUTER AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M74P02	SEAL - BRG 4B CUTER AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M74P02	SEAL - BRG 4B CUTER AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M74P02	SEAL - BRG 4B CUTER AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M74P02	SEAL - BRG 4B CUTER AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M74P02	SEAL - BRG 4B CUTER AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M74P02	SEAL - BRG 4B CUTER AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9046M74P02	SEAL - BRG 4B CUTER AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M74P02	SEAL - BRG 4B CUTER AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9046M74P02	SEAL - BRG 4B CUTER AIR ROT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M76P03	SEAL - BRG 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M76P03	SEAL - BRG 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M76P03	SEAL - BRG 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M76P03	SEAL - BRG 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M76P03	SEAL - BRG 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M76P03	SEAL - BRG 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M76P03	SEAL - BRG 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M76P03	SEAL - BRG 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M76P03	SEAL - BRG 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M76P03	SEAL - BRG 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M76P03	SEAL - BRG 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9046M76P03	SEAL - BRG 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M76P03	SEAL - BRG 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M76P03	SEAL - BRG 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M76P03	SEAL - BRG 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M76P03	SEAL - BRG 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M76P03	SEAL - BRG 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M76P03	SEAL - BRG 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M76P03	SEAL - BRG 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M76P03	SEAL - BRG 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M76P03	SEAL - BRG 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M76P03	SEAL - BRG 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M76P03	SEAL - BRG 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M77G05	SHIELD ASSY - BRG 5 HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M80P02	SHIELD - BRG NO. 5 OIL	CF6-50	AR	1
9046M82P02	SEAL - BRG 6 STA AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M82P02	SEAL - BRG 6 STA AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9046M82P02	SEAL - BRG 6 STA AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M82P02	SEAL - BRG 6 STA AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M82P02	SEAL - BRG 6 STA AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M82P02	SEAL - BRG 6 STA AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M82P02	SEAL - BRG 6 STA AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M82P02	SEAL - BRG 6 STA AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M82P02	SEAL - BRG 6 STA AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M82P02	SEAL - BRG 6 STA AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9046M82P02	SEAL - BRG 6 STA AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9046M82P02	SEAL - BRG 6 STA AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M82P02	SEAL - BRG 6 STA AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M82P02	SEAL - BRG 6 STA AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M82P02	SEAL - BRG 6 STA AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M82P02	SEAL - BRG 6 STA AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M82P02	SEAL - BRG 6 STA AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M89G05	SEAL ASSY - BRG STA VENT	CF6-50 (LMCO)	AR	1
9046M89G05	SEAL ASSY - BRG STA VENT	CF6-50 (LMCO)	AR	1
9046M89G05	SEAL ASSY - BRG STA VENT	CF6-50 (LMCO)	AR	1
9046M89G05	SEAL ASSY - BRG STA VENT	CF6-50 (LMCO)	AR	1
9046M89G05	SEAL ASSY - BRG STA VENT	CF6-50 (LMCO)	AR	1
9046M89G05	SEAL ASSY - BRG STA VENT	CF6-50 (LMCO)	AR	1
9046M89G05	SEAL ASSY - BRG STA VENT	CF6-50 (LMCO)	AR	1
9046M89G05	SEAL ASSY - BRG STA VENT	CF6-50 (LMCO)	AR	1
9046M89G05	SEAL ASSY - BRG STA VENT	CF6-50 (LMCO)	AR	1
9046M89G05	SEAL ASSY - BRG STA VENT	CF6-50 (LMCO)	AR	1
9046M89G08	SEAL ASSY - BRG STA VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9046M89G08	SEAL ASSY - BRG STA VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M89G08	SEAL ASSY - BRG STA VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M89G08	SEAL ASSY - BRG STA VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M89G08	SEAL ASSY - BRG STA VENT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9046M91P02	SHIELD - BRG 4R HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M91P02	SHIELD - BRG 4R HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M91P02	SHIELD - BRG 4R HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M91P02	SHIELD - BRG 4R HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M91P02	SHIELD - BRG 4R HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M91P02	SHIELD - BRG 4R HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M91P02	SHIELD - BRG 4R HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M94P03	SEAL - STA 4B AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M94P03	SEAL - STA 4B AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M94P03	SEAL - STA 4B AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M94P03	SEAL - STA 4B AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M94P03	SEAL - STA 4B AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M94P03	SEAL - STA 4B AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M94P03	SEAL - STA 4B AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M94P03	SEAL - STA 4B AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M94P03	SEAL - STA 4B AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M94P03	SEAL - STA 4B AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M94P03	SEAL - STA 4B AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M94P03	SEAL - STA 4B AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9046M94P03	SEAL - STA 4B AIR/OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9047M48P08	FAIRING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9047M48P08	FAIRING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9047M48P08	FAIRING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9047M48P08	FAIRING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9047M48P09	FAIRING	CF6-50 (LMCO)	OH	1
9047M48P10	FAIRING - FAN STATOR	CF6-80A	OH	1
9047M48P10	FAIRING - FAN STATOR	CF6-80A	OH	1
9047M48P10	FAIRING - FAN STATOR	CF6-80A	AR	1
9047M54G07	SUPPORT - STG 4 STATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9047M54G07	SUPPORT - STG 4 STATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9047M54G07	SUPPORT - STG 4 STATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9047M54G07	SUPPORT - STG 4 STATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9047M54G07	SUPPORT - STG 4 STATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9047M54G07	SUPPORT - STG 4 STATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9047M54G07	SUPPORT - STG 4 STATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9047M54G07	SUPPORT - STG 4 STATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9047M54G07	SUPPORT - STG 4 STATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9047M81P01	BRACKET - TUBE	CF6-50	NS	1
9047M93P02	BRACKET - LATCH	CF6-50	AR	1
9047M93P02	BRACKET - LATCH	CF6-50	AR	1
9048M33P06	BEARING - PLAIN ROD END	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9048M33P06	BEARING - PLAIN ROD END	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9048M33P06	BEARING - PLAIN ROD END	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	1
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	1
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	1
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	1
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	1
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	1
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	1
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	1
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	1
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	1
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	1
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	1
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	1
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	1
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	1
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	18
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	OH	3
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	35
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	23
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	33
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	39
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	1
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	24
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	28
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	44
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	1
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	6
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	17
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	32
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	40
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	3
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	35
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	20
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	OH	2
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	OH	2
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	OH	1
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	29
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	30
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	33
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	38
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	3
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	OH	5
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	31
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	21
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	OH	6
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	16
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	15
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	16
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	39
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	OH	4
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	OH	7
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	OH	2
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	OH	8
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	20
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	OH	2
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	25
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	32
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	OH	5
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	OH	12
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	AR	44
9048M61P25	BLADE - STG 2 (NARROW)	CF6-50 (LMCO)	OH	3
9048M61P26	BLADE - STG 2 (WIDE)	CF6-50 (LMCO)	AR	22
9048M61P26	BLADE - STG 2 (WIDE)	CF6-50 (LMCO)	AR	2
9048M61P26	BLADE - STG 2 (WIDE)	CF6-50 (LMCO)	AR	39
9048M61P26	BLADE - STG 2 (WIDE)	CF6-50 (LMCO)	AR	4
9048M61P26	BLADE - STG 2 (WIDE)	CF6-50 (LMCO)	AR	1
9048M61P26	BLADE - STG 2 (WIDE)	CF6-50 (LMCO)	AR	8
9048M61P26	BLADE - STG 2 (WIDE)	CF6-50 (LMCO)	AR	37
9048M61P26	BLADE - STG 2 (WIDE)	CF6-50 (LMCO)	AR	43
9048M61P26	BLADE - STG 2 (WIDE)	CF6-50 (LMCO)	AR	42
9048M61P26	BLADE - STG 2 (WIDE)	CF6-50 (LMCO)	AR	11
9048M61P26	BLADE - STG 2 (WIDE)	CF6-50 (LMCO)	AR	11
9048M61P26	BLADE - STG 2 (WIDE)	CF6-50 (LMCO)	AR	5
9048M61P26	BLADE - STG 2 (WIDE)	CF6-50 (LMCO)	AR	41
9048M61P26	BLADE - STG 2 (WIDE)	CF6-50 (LMCO)	AR	34
9048M61P26	BLADE - STG 2 (WIDE)	CF6-50 (LMCO)	AR	47
9048M61P26	BLADE - STG 2 (WIDE)	CF6-50 (LMCO)	AR	41
9048M61P26	BLADE - STG 2 (WIDE)	CF6-50 (LMCO)	AR	44
9048M61P26	BLADE - STG 2 (WIDE)	CF6-50 (LMCO)	AR	33
9048M61P26	BLADE - STG 2 (WIDE)	CF6-50 (LMCO)	OH	1
9048M61P26	BLADE - STG 2 (WIDE)	CF6-50 (LMCO)	AR	52
9048M61P26	BLADE - STG 2 (WIDE)	CF6-50 (LMCO)	AR	11
9048M61P26	BLADE - STG 2 (WIDE)	CF6-50 (LMCO)	AR	47
9048M61P26	BLADE - STG 2 (WIDE)	CF6-50 (LMCO)	OH	2
9048M61P26	BLADE - STG 2 (WIDE)	CF6-50 (LMCO)	AR	28
9048M61P26	BLADE - STG 2 (WIDE)	CF6-50 (LMCO)	OH	1
9048M61P26	BLADE - STG 2 (WIDE)	CF6-50 (LMCO)	OH	1
9048M61P26	BLADE - STG 2 (WIDE)	CF6-50 (LMCO)	AR	21
9048M61P27	BLADE - STG 2 (LOCKING)	CF6-50 (LMCO)	AR	1
9048M61P27	BLADE - STG 2 (LOCKING)	CF6-50 (LMCO)	AR	2
9048M61P27	BLADE - STG 2 (LOCKING)	CF6-50 (LMCO)	AR	2
9048M61P27	BLADE - STG 2 (LOCKING)	CF6-50 (LMCO)	AR	2
9048M61P27	BLADE - STG 2 (LOCKING)	CF6-50 (LMCO)	AR	2
9048M61P27	BLADE - STG 2 (LOCKING)	CF6-50 (LMCO)	AR	1
9048M61P27	BLADE - STG 2 (LOCKING)	CF6-50 (LMCO)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	AR	36
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	AR	38
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	AR	3
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	AR	44
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	AR	36
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	AR	38
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	AR	31
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	AR	40
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	AR	30
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	OH	6
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	OH	2
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	AR	30
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	AR	42
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	AR	15
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	AR	47
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	OH	5
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	AR	35
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	AR	1
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	OH	2
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	OH	1
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	AR	3
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	OH	3
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	OH	2
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	AR	36
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	AR	30
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	OH	5
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	OH	2
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	AR	38
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	AR	45
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	AR	55
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	OH	5
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	OH	6
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	OH	6
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	AR	33
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	AR	21
9048M63P29	BLADE - STG 4 (NARROW)	CF6-50 (LMCO)	AR	39
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	43
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	33
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	42
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	34

Part Number	Part Description	Engine Type	Condition	Quantity
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	25
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	27
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	19
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	32
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	19
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	42
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	29
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	25
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	32
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	27
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	45
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	17
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	39
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	51
9048M63P30	BLADE - STG 4 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	33
9048M63P31	BLADE - STG 4 (LOCKING)	CF6-50 (LMCO)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9048M63P32	BLADE - STG 4 (LOCKING)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9048M63P32	BLADE - STG 4 (LOCKING)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9048M63P32	BLADE - STG 4 (LOCKING)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9048M63P32	BLADE - STG 4 (LOCKING)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9048M63P32	BLADE - STG 4 (LOCKING)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9048M63P32	BLADE - STG 4 (LOCKING)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9048M63P32	BLADE - STG 4 (LOCKING)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9048M63P32	BLADE - STG 4 (LOCKING)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9048M63P32	BLADE - STG 4 (LOCKING)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9048M63P32	BLADE - STG 4 (LOCKING)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9048M63P32	BLADE - STG 4 (LOCKING)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9048M63P32	BLADE - STG 4 (LOCKING)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9048M63P32	BLADE - STG 4 (LOCKING)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9048M63P32	BLADE - STG 4 (LOCKING)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9048M63P32	BLADE - STG 4 (LOCKING)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9048M63P32	BLADE - STG 4 (LOCKING)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9048M63P32	BLADE - STG 4 (LOCKING)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9048M63P32	BLADE - STG 4 (LOCKING)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9048M63P32	BLADE - STG 4 (LOCKING)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9048M63P32	BLADE - STG 4 (LOCKING)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9048M63P32	BLADE - STG 4 (LOCKING)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M63P32	BLADE - STG 4 (LOCKING)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9048M63P32	BLADE - STG 4 (LOCKING)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9048M63P32	BLADE - STG 4 (LOCKING)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9048M63P32	BLADE - STG 4 (LOCKING)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9048M63P32	BLADE - STG 4 (LOCKING)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M71G02	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M72G01	LINER - SEGMENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M75G20	CASE ASSY - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9048M82G01	MOUNT ASSY - TAIL ENGINE	CF6-50	AR	1
9049M32P16	SPOOL - FAN RTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9049M32P16	SPOOL - FAN RTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M32P16	SPOOL - FAN RTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M61G07	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M61G07	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M61G07	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M61G07	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M61G07	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M61G07	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M61G07	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M61G07	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9049M61G08	SEGMENT ASSY - FAN CASE	CF6-50	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9049M63G13	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9049M63G14	SEGMENT ASSY - FAN CS LINER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G14	SEGMENT ASSY - FAN CS LINER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G14	SEGMENT ASSY - FAN CS LINER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G14	SEGMENT ASSY - FAN CS LINER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M63G14	SEGMENT ASSY - FAN CS LINER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9049M63G16	SEGMENT ASSY - FAN CASE	CF6-50 (LMCO)	AR	1
9049M64G07	LINER - AFT FAN CASE PYLON	CF6-50	AR	1
9049M64G19	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO)	AR	1
9049M64G19	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO)	AR	1
9049M64G19	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO)	AR	1
9049M64G19	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO)	AR	1
9049M64G19	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO)	AR	1
9049M64G20	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M64G20	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M64G20	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9049M64G20	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M64G20	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M64G20	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9049M64G20	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M64G21	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9049M64G21	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M64G21	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M64G21	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M64G21	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M64G21	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9049M64G22	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9049M64G22	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M64G23	PYLON LINER - AFT FAN CASE	CF6-50	AR	1
9049M64G23	PYLON LINER - AFT FAN CASE	CF6-50	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9049M64G24	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO)	OH	1
9049M64G24	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO)	OH	1
9049M64G24	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO)	OH	1
9049M64G29	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO)	AR	1
9049M64G29	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO)	AR	1
9049M64G29	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO)	AR	1
9049M64G29	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO)	AR	1
9049M64G29	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO)	AR	1
9049M64G29	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO)	AR	1
9049M64G29	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO)	AR	1
9049M64G29	PYLON LINER - AFT FAN CASE	CF6-50 (LMCO)	AR	1
9049M69P05	CHANNEL - THRUST REVERSER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9049M69P07	CHANNEL - THRUST REVERSER	CF6-50 (LMCO)	OH	1
9049M91P02	CLEVIS - ACTUATOR	CF6-50 (LMCO)	SV	1
9049M91P02	CLEVIS - ACTUATOR	CF6-50 (LMCO)	OH	1
9049M91P02	CLEVIS - ACTUATOR	CF6-50 (LMCO)	OH	1
9049M91P06	CLEVIS - ACTUATOR	CF6-80C2	AR	2
9049M91P06	CLEVIS - ACTUATOR	CF6-80C2	AR	1
9049M91P06	CLEVIS - ACTUATOR	CF6-80C2	AR	1
9049M92P01	CLEVIS - BYPASS	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	12
9049M92P01	CLEVIS - BYPASS	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	9
9049M92P01	CLEVIS - BYPASS	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M92P01	CLEVIS - BYPASS	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9049M92P01	CLEVIS - BYPASS	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	4

Part Number	Part Description	Engine Type	Condition	Quantity
9049M92P01	CLEVIS - BYPASS	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	4
9049M92P01	CLEVIS - BYPASS	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9049M92P03	CLEVIS - BYP	CF6-80C2	AR	10
9049M92P03	CLEVIS - BYP	CF6-80C2	SV	2
9049M92P03	CLEVIS - BYP	CF6-80C2	SV	11
9049M92P03	CLEVIS - BYP	CF6-80C2	SV	1
9049M92P03	CLEVIS - BYP	CF6-80C2	AR	12
9050M23P08	DISK - HPC STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M23P08	DISK - HPC STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M23P08	DISK - HPC STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M23P08	DISK - HPC STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M23P08	DISK - HPC STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M23P08	DISK - HPC STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M23P11	DISK - HPC STG 1	CF6-50	AR	1
9050M23P11	DISK - HPC STG 1	CF6-50	AR	1
9050M36G03	SUPPORT ASSY - STG 13-14	CF6-50	AR	1
9050M36G03	SUPPORT ASSY - STG 13-14	CF6-50	OH	1
9050M36G03	SUPPORT ASSY - STG 13-14	CF6-50	OH	1
9050M36G03	SUPPORT ASSY - STG 13-14	CF6-50	AR	1
9050M51G52	FRAME ASSY - TURB REAR	CF6-50 (Boeing)	AR	1
9050M51G59	FRAME ASSY - TURB REAR	CF6-50	AR	1
9050M51G63	FRAME ASSY - TURB REAR	CF6-50	AR	1
9050M51G64	FRAME ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M51G66	FRAME ASSY - TURB REAR	CF6-50	AR	1
9050M51G67	FRAME ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M51G69	FRAME ASSY - TURB REAR	CF6-50 (LMCO)	OH	1
9050M51G69	FRAME ASSY - TURB REAR	CF6-50 (LMCO)	AR	1
9050M51G69	FRAME ASSY - TURB REAR	CF6-50 (LMCO)	AR	1
9050M51G69	FRAME ASSY - TURB REAR	CF6-50 (LMCO)	AR	1
9050M51G69	FRAME ASSY - TURB REAR	CF6-50 (LMCO)	AR	1
9050M55G01	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M55G01	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M55G01	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9050M55G01	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M55G01	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M55G01	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M55G01	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M55G01	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M55G01	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M55G01	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M55G01	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M55G01	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M55G01	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M55G01	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M55G01	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M55G01	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M55G01	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M55G01	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9050M55G01	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9050M55G01	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M55G01	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M55G01	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M55G02	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M55G02	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M55G02	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M55G02	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9050M55G02	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9050M55G02	LINER ASSY - TURB REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9051M26G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M26G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M26G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M26G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M26G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M26G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M26G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M26G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M26G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M26G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9051M26G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M26G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M26G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M26G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G09	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G09	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G09	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G09	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G09	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G09	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G09	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G09	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G09	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G09	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G09	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9051M27G09	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G09	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G09	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G09	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G09	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G09	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G09	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G09	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G09	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G09	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G09	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G10	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G10	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G10	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G10	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G10	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G10	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G10	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G10	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9051M27G10	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G10	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G10	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G10	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G10	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9051M27G10	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G10	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9051M27G10	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9051M27G10	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G10	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G10	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G10	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G11	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G11	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G11	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G11	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G11	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G11	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G11	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G11	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G11	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G11	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G11	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G11	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G11	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G11	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G11	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G11	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G11	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G11	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G11	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9051M27G11	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9051M27G11	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G11	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G11	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G11	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G12	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G12	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G12	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G12	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G12	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G12	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G12	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G12	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G12	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G12	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G12	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G12	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G12	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G12	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9051M27G12	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G12	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M27G12	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M28G03	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9051M29G05	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G05	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G05	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G05	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G05	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G05	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G05	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G05	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G05	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G05	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M29G06	LINER ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9051M50G03	LINK - CONNECTING IGV	CF6-50 (LMCO)	AR	1
9051M50G03	LINK - CONNECTING IGV	CF6-50 (LMCO)	OH	1
9051M50G03	LINK - CONNECTING IGV	CF6-50 (LMCO)	AR	1
9051M50G03	LINK - CONNECTING IGV	CF6-50 (LMCO)	AR	1
9051M50G03	LINK - CONNECTING IGV	CF6-50 (LMCO)	AR	1
9051M50G03	LINK - CONNECTING IGV	CF6-50 (LMCO)	AR	1
9051M50G03	LINK - CONNECTING IGV	CF6-50 (LMCO)	AR	1
9051M50G03	LINK - CONNECTING IGV	CF6-50 (LMCO)	AR	1
9051M50G03	LINK - CONNECTING IGV	CF6-50 (LMCO)	AR	1
9051M50G03	LINK - CONNECTING IGV	CF6-50 (LMCO)	AR	1
9051M50G03	LINK - CONNECTING IGV	CF6-50 (LMCO)	AR	1
9051M50G03	LINK - CONNECTING IGV	CF6-50 (LMCO)	AR	1
9051M50G03	LINK - CONNECTING IGV	CF6-50 (LMCO)	AR	1
9051M50G03	LINK - CONNECTING IGV	CF6-50 (LMCO)	AR	1
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9051M50G04	HPC STATOR ACT CONN LINK STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9051M51G01	LINK ASSY - STG 1 CONN	CF6-50	AR	1
9051M51G01	LINK ASSY - STG 1 CONN	CF6-50	AR	2
9051M51G01	LINK ASSY - STG 1 CONN	CF6-50	AR	1
9051M51G02	LINK - CONNECTING	CF6-50	AR	1
9051M51G03	LINK - CONNECTING STG 1	CF6-80C2, CF6-80A, CF6-50	AR	2
9051M51G03	LINK - CONNECTING STG 1	CF6-80C2, CF6-80A, CF6-50	AR	2
9051M51G03	LINK - CONNECTING STG 1	CF6-80C2, CF6-80A, CF6-50	AR	2
9051M51G03	LINK - CONNECTING STG 1	CF6-80C2, CF6-80A, CF6-50	AR	2
9051M51G03	LINK - CONNECTING STG 1	CF6-80C2, CF6-80A, CF6-50	AR	2
9051M51G03	LINK - CONNECTING STG 1	CF6-80C2, CF6-80A, CF6-50	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M51G04	HPC STATOR ACT CONN LINK STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	2
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	1
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	1
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	1
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	2
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	1
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	1
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	2
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	1
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	2
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	1
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	2
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	2
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	1
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	1
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	1
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	1
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	1
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	2
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	1
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	1
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	2
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	1
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	2
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	2
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	1
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	2
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	2
9051M52G03	LINK - CONNECTING STG 2	CF6-80C2, CF6-80A, CF6-50	AR	2
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	2
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9051M52G04	HPC STATOR ACT CONN LINK STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9051M61P09	SUPPORT - LINER	CF6-50	AR	1
9051M61P09	SUPPORT - LINER	CF6-50	NE	1

Part Number	Part Description	Engine Type	Condition	Quantity
9051M71P17	DISK - FAN STG 1	CF6-50	AR	1
9051M95G02	BRACKET ASSY - LATCH	CF6-50	AR	1
9051M95G02	BRACKET ASSY - LATCH	CF6-50	AR	1
9051M96G02	SEAL ASSY - INNER LINER	CF6-50	AR	1
9051M96G02	SEAL ASSY - INNER LINER	CF6-50	AR	1
9051M96G02	SEAL ASSY - INNER LINER	CF6-50	AR	1
9053M14G02	MANIFOLD ASSY - GRBX	CF6-50	AR	1
9053M14G03	MANIFOLD ASSY - GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M14G03	MANIFOLD ASSY - GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M14G03	MANIFOLD ASSY - GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M14G03	MANIFOLD ASSY - GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M14G03	MANIFOLD ASSY - GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9053M14G03	MANIFOLD ASSY - GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M14G03	MANIFOLD ASSY - GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M14G03	MANIFOLD ASSY - GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M14G03	MANIFOLD ASSY - GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9053M14G03	MANIFOLD ASSY - GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M15G01	TUBE ASSY - OIL	CF6-50	AR	1
9053M15G01	TUBE ASSY - OIL	CF6-50	AR	1
9053M18G01	TUBE ASSY - OIL PUMP	CF6-50	AR	1
9053M19G03	TUBE ASSY - C AND D OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M19G03	TUBE ASSY - C AND D OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M19G03	TUBE ASSY - C AND D OIL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9053M19G03	TUBE ASSY - C AND D OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M19G03	TUBE ASSY - C AND D OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M19G03	TUBE ASSY - C AND D OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M19G03	TUBE ASSY - C AND D OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M19G03	TUBE ASSY - C AND D OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9053M19G03	TUBE ASSY - C AND D OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M19G03	TUBE ASSY - C AND D OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M19G03	TUBE ASSY - C AND D OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M19G03	TUBE ASSY - C AND D OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M19G03	TUBE ASSY - C AND D OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M27G01	MANIFOLD ASSY - AFT OIL	CF6-50	AR	1
9053M30G01	MANIFOLD ASSY - FUEL	CF6-50 (Boeing)	AR	1
9053M30G01	MANIFOLD ASSY - FUEL	CF6-50 (Boeing)	AR	1
9053M30G01	MANIFOLD ASSY - FUEL	CF6-50 (Boeing)	AR	1
9053M30G02	MANIFOLD - FUEL	CF6-50 (Boeing)	AR	1
9053M30G02	MANIFOLD - FUEL	CF6-50 (Boeing)	AR	1
9053M30G02	MANIFOLD - FUEL	CF6-50 (Boeing)	OH	1
9053M30G02	MANIFOLD - FUEL	CF6-50 (Boeing)	OH	1
9053M30G02	MANIFOLD - FUEL	CF6-50 (Boeing)	OH	1
9053M30G02	MANIFOLD - FUEL	CF6-50 (Boeing)	AR	1
9053M30G02	MANIFOLD - FUEL	CF6-50 (Boeing)	AR	1
9053M30G02	MANIFOLD - FUEL	CF6-50 (Boeing)	AR	1
9053M30G02	MANIFOLD - FUEL	CF6-50 (Boeing)	AR	1
9053M30G02	MANIFOLD - FUEL	CF6-50 (Boeing)	AR	1
9053M30G02	MANIFOLD - FUEL	CF6-50 (Boeing)	AR	1
9053M30G02	MANIFOLD - FUEL	CF6-50 (Boeing)	AR	1
9053M31G02	TUBE ASSY - FWD D SCAV OIL	CF6-50	AR	1
9053M31G02	TUBE ASSY - FWD D SCAV OIL	CF6-50	AR	1
9053M53G02	MANIFOLD ASSY - FUEL HD END	CF6-50	OH	1
9053M53G02	MANIFOLD ASSY - FUEL HD END	CF6-50	OH	1
9053M53G02	MANIFOLD ASSY - FUEL HD END	CF6-50	AR	1
9053M53G03	MANIFOLD ASSY - FUEL HD END	CF6-50 (Boeing)	AR	1
9053M53G03	MANIFOLD ASSY - FUEL HD END	CF6-50 (Boeing)	AR	1
9053M53G03	MANIFOLD ASSY - FUEL HD END	CF6-50 (Boeing)	AR	1
9053M53G03	MANIFOLD ASSY - FUEL HD END	CF6-50 (Boeing)	AR	1
9053M53G03	MANIFOLD ASSY - FUEL HD END	CF6-50 (Boeing)	AR	1
9053M53G03	MANIFOLD ASSY - FUEL HD END	CF6-50 (Boeing)	AR	1
9053M53G03	MANIFOLD ASSY - FUEL HD END	CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9053M78G01	TUBE - HIGH PRESS AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M78G01	TUBE - HIGH PRESS AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M78G01	TUBE - HIGH PRESS AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M78G01	TUBE - HIGH PRESS AIR	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9053M78G01	TUBE - HIGH PRESS AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M78G01	TUBE - HIGH PRESS AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M78G01	TUBE - HIGH PRESS AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M78G01	TUBE - HIGH PRESS AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M78G01	TUBE - HIGH PRESS AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M78G01	TUBE - HIGH PRESS AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M78G01	TUBE - HIGH PRESS AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9053M78G01	TUBE - HIGH PRESS AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9053M78G01	TUBE - HIGH PRESS AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9053M78G01	TUBE - HIGH PRESS AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M78G01	TUBE - HIGH PRESS AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M78G01	TUBE - HIGH PRESS AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M79G01	TUBE ASSY - UPR FWD HPT AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M79G01	TUBE ASSY - UPR FWD HPT AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M79G01	TUBE ASSY - UPR FWD HPT AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M79G01	TUBE ASSY - UPR FWD HPT AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M79G01	TUBE ASSY - UPR FWD HPT AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M79G01	TUBE ASSY - UPR FWD HPT AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9053M79G01	TUBE ASSY - UPR FWD HPT AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M79G01	TUBE ASSY - UPR FWD HPT AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M79G01	TUBE ASSY - UPR FWD HPT AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M79G01	TUBE ASSY - UPR FWD HPT AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M79G01	TUBE ASSY - UPR FWD HPT AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M79G01	TUBE ASSY - UPR FWD HPT AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M79G01	TUBE ASSY - UPR FWD HPT AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M79G01	TUBE ASSY - UPR FWD HPT AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M79G01	TUBE ASSY - UPR FWD HPT AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M79G01	TUBE ASSY - UPR FWD HPT AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M79G01	TUBE ASSY - UPR FWD HPT AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9053M79G01	TUBE ASSY - UPR FWD HPT AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M80G02	TUBE ASSY - LWR FWD AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M80G02	TUBE ASSY - LWR FWD AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M80G02	TUBE ASSY - LWR FWD AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M80G02	TUBE ASSY - LWR FWD AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M80G02	TUBE ASSY - LWR FWD AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M80G02	TUBE ASSY - LWR FWD AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M80G02	TUBE ASSY - LWR FWD AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9053M80G02	TUBE ASSY - LWR FWD AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9053M80G02	TUBE ASSY - LWR FWD AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M80G02	TUBE ASSY - LWR FWD AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M80G02	TUBE ASSY - LWR FWD AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M80G02	TUBE ASSY - LWR FWD AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9053M80G02	TUBE ASSY - LWR FWD AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9054M15P01	BRACKET - FLAT	CF6-50	OH	1
9054M42P02	BRACKET - HP RECOUP TUBE	CF6-50 (LMCO)	SV	1
9054M44G01	TUBE ASSY - MID OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9054M44G01	TUBE ASSY - MID OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9054M44G01	TUBE ASSY - MID OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9054M44G01	TUBE ASSY - MID OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9054M51G01	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9054M51G01	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9054M51G01	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9054M51G01	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9054M51G01	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9054M51G01	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9054M51G02	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9054M51G02	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9054M51G02	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9054M51G02	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9054M51G03	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9054M51G03	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9054M51G03	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9054M51G03	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1

Part Number	Part Description	Engine Type	Condition	Quantity
9054M51G03	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9054M52G01	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9054M52G02	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9054M52G02	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9054M52G02	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9054M52G02	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9054M52G02	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9054M52G02	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9054M52G02	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9054M52G02	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9054M52G02	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9054M52G02	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9054M52G02	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9054M52G02	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9054M52G02	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9054M80P02	CABLE - BLOWOUT PANEL	CF6-80A	NS	7
9054M80P02	CABLE - BLOWOUT PANEL	CF6-80A	NS	1
9054M80P02	CABLE - BLOWOUT PANEL	CF6-80A	NS	3
9054M82P02	ROD END	CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9055M19P05	RING	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9055M19P05	RING	CF6-50 (LMCO), CF6-50 (Boeing)	NE	4
9055M19P06	RING	CF6-50 (LMCO), CF6-50 (Boeing)	NE	3
9055M19P07	RING	CF6-80A	NS	1
9055M19P07	RING	CF6-80A	NS	1
9055M19P07	RING	CF6-80A	NS	5
9055M19P07	RING	CF6-80A	NS	2
9055M19P07	RING	CF6-80A	NS	2
9055M19P08	RING	CF6-80A	NS	1
9055M19P08	RING	CF6-80A	NS	1
9055M19P08	RING	CF6-80A	NS	2
9055M20P272	COUPLING	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
9055M41P01	BRACKET - CDP TUBE STG 14	CF6-50	AR	1
9055M70G02	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9055M70G02	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9055M70G02	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9055M77P01	BRACKET - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9055M77P01	BRACKET - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9055M77P01	BRACKET - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9055M78P01	BRACKET - TUBE STG 14	CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9055M87G01	TUBE ASSY - XFR GRBX OIL	CF6-50	AR	1
9055M90P04	HARNESS - BOTTOM R/H EGT	CF6-50 (LMCO)	AR	1
9055M90P07	HARNESS - EGT TOP LH	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9055M90P08	HARNESS - BOT R TC	CF6-50	SV	1
9055M91P02	THERMOCOUPLE - GAS TU	CF6-50 (LMCO)	AR	1
9055M91P02	THERMOCOUPLE - GAS TU	CF6-50 (LMCO)	AR	1
9055M91P04	HARNESS - BOT L TC	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9055M93G01	TUBE ASSY - MID OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9055M93G01	TUBE ASSY - MID OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9055M93G01	TUBE ASSY - MID OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9055M93G01	TUBE ASSY - MID OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9055M93G01	TUBE ASSY - MID OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9055M94G01	TUBE ASSY - AFT CDP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9055M94G01	TUBE ASSY - AFT CDP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9055M94G01	TUBE ASSY - AFT CDP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9055M94G01	TUBE ASSY - AFT CDP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9055M94G01	TUBE ASSY - AFT CDP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9055M94G01	TUBE ASSY - AFT CDP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9055M94G01	TUBE ASSY - AFT CDP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9055M94G01	TUBE ASSY - AFT CDP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9056M57P01	BRACKET - TUBE STG 14	CF6-50	AR	1
9056M57P01	BRACKET - TUBE STG 14	CF6-50	AR	1
9057M74G01	TUBE - AIR CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M74G01	TUBE - AIR CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M74G01	TUBE - AIR CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M74G01	TUBE - AIR CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M74G01	TUBE - AIR CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M74G01	TUBE - AIR CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M74G01	TUBE - AIR CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M74G01	TUBE - AIR CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M74G01	TUBE - AIR CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M74G01	TUBE - AIR CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M74G01	TUBE - AIR CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M74G01	TUBE - AIR CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M74G01	TUBE - AIR CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M74G01	TUBE - AIR CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M74G01	TUBE - AIR CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M74G01	TUBE - AIR CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M74G01	TUBE - AIR CDP	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9057M74G01	TUBE - AIR CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M74G01	TUBE - AIR CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M74G01	TUBE - AIR CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M76P01	TUBE/HOSE - FUEL RET	CF6-50 (Boeing)	AR	1
9057M82G04	BRACKET ASSY - TUBE STG 6	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M82G04	BRACKET ASSY - TUBE STG 6	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9057M82G04	BRACKET ASSY - TUBE STG 6	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M82G04	BRACKET ASSY - TUBE STG 6	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M82G04	BRACKET ASSY - TUBE STG 6	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9057M84G02	MANIFOLD ASSY - STG 14	CF6-50	AR	1
9057M84G02	MANIFOLD ASSY - STG 14	CF6-50	AR	1
9057M84G02	MANIFOLD ASSY - STG 14	CF6-50	AR	1
9057M84G03	MANIFOLD ASSY - STG 14	CF6-50	AR	1
9057M84G03	MANIFOLD ASSY - STG 14	CF6-50	AR	1
9057M84G03	MANIFOLD ASSY - STG 14	CF6-50	AR	1
9057M84G03	MANIFOLD ASSY - STG 14	CF6-50	AR	1
9057M84G03	MANIFOLD ASSY - STG 14	CF6-50	AR	1
9057M84G03	MANIFOLD ASSY - STG 14	CF6-50	AR	1
9057M84G03	MANIFOLD ASSY - STG 14	CF6-50	AR	1
9057M84G03	MANIFOLD ASSY - STG 14	CF6-50	AR	1
9057M84G03	MANIFOLD ASSY - STG 14	CF6-50	AR	1
9057M84G03	MANIFOLD ASSY - STG 14	CF6-50	AR	1
9057M84G03	MANIFOLD ASSY - STG 14	CF6-50	OH	1
9057M84G03	MANIFOLD ASSY - STG 14	CF6-50	AR	1
9057M84G03	MANIFOLD ASSY - STG 14	CF6-50	AR	1
9057M84G03	MANIFOLD ASSY - STG 14	CF6-50	AR	1
9057M84P03	TUBE	CF6-50	AR	1
9057M84P08	SLEEVE	CF6-50	NS	2
9057M84P08	SLEEVE	CF6-50	NS	2
9057M85G02	TUBE ASSY - AFT AIR SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M85G02	TUBE ASSY - AFT AIR SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M85G02	TUBE ASSY - AFT AIR SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M85G02	TUBE ASSY - AFT AIR SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M85G02	TUBE ASSY - AFT AIR SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9057M85G02	TUBE ASSY - AFT AIR SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M85G02	TUBE ASSY - AFT AIR SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M85G02	TUBE ASSY - AFT AIR SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M85G02	TUBE ASSY - AFT AIR SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M85G02	TUBE ASSY - AFT AIR SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M85G02	TUBE ASSY - AFT AIR SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9057M85G02	TUBE ASSY - AFT AIR SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M85G02	TUBE ASSY - AFT AIR SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M85G02	TUBE ASSY - AFT AIR SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M85G02	TUBE ASSY - AFT AIR SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M85G03	TUBE ASSY - AFT AIR SUPPLY	CF6-50 (LMCO)	SV	1
9057M98P01	BRACKET - MID TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9057M99G01	BRACKET ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M99G01	BRACKET ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M99G01	BRACKET ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9057M99G01	BRACKET ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9057M99G01	BRACKET ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9059M61P02	CLEVIS - TURNBUCKLE	CF6-80C2, CF6-50	AR	2
9059M61P02	CLEVIS - TURNBUCKLE	CF6-80C2, CF6-50	SV	1
9059M61P02	CLEVIS - TURNBUCKLE	CF6-80C2, CF6-50	AR	1
9059M61P02	CLEVIS - TURNBUCKLE	CF6-80C2, CF6-50	AR	1
9059M62P02	LINK - TURNBUCKLE	CF6-50	AR	1
9059M62P06	ADAPTER - LINK	CF6-80C2	NS	2
9059M62P06	ADAPTER - LINK	CF6-80C2	NS	1
9059M63G01	ADAPTER ASSY	CF6-50	AR	1
9059M63G06	ADAPTER ASSY	CF6-80C2	NE	2
9060M58G01	NUT ASSY - GANG CHANNEL	CF6-50	NS	4
9060M58G01	NUT ASSY - GANG CHANNEL	CF6-50	NS	1
9061M13G05	MANIFOLD ASSY - LP TURB CLG	CF6-50 (LMCO)	SV	1
9061M13G05	MANIFOLD ASSY - LP TURB CLG	CF6-50 (LMCO)	OH	1
9061M13G05	MANIFOLD ASSY - LP TURB CLG	CF6-50 (LMCO)	AR	1
9061M13G05	MANIFOLD ASSY - LP TURB CLG	CF6-50 (LMCO)	AR	1
9061M13G05	MANIFOLD ASSY - LP TURB CLG	CF6-50 (LMCO)	AR	1
9061M13G05	MANIFOLD ASSY - LP TURB CLG	CF6-50 (LMCO)	AR	1
9061M13G05	MANIFOLD ASSY - LP TURB CLG	CF6-50 (LMCO)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9061M13G05	MANIFOLD ASSY - LP TURB CLG	CF6-50 (LMCO)	OH	1
9061M13G05	MANIFOLD ASSY - LP TURB CLG	CF6-50 (LMCO)	OH	1
9061M13G05	MANIFOLD ASSY - LP TURB CLG	CF6-50 (LMCO)	AR	1
9061M13G05	MANIFOLD ASSY - LP TURB CLG	CF6-50 (LMCO)	AR	1
9061M13G05	MANIFOLD ASSY - LP TURB CLG	CF6-50 (LMCO)	AR	1
9061M14G05	MANIFOLD ASSY - LP TURB CLG	CF6-50	AR	1
9061M14G05	MANIFOLD ASSY - LP TURB CLG	CF6-50	OH	1
9061M14G07	MANIFOLD ASSY - LP TURB CLG	CF6-50 (LMCO)	AR	1
9061M14G07	MANIFOLD ASSY - LP TURB CLG	CF6-50 (LMCO)	AR	1
9061M14G07	MANIFOLD ASSY - LP TURB CLG	CF6-50 (LMCO)	AR	1
9061M14G07	MANIFOLD ASSY - LP TURB CLG	CF6-50 (LMCO)	OH	1
9061M14G07	MANIFOLD ASSY - LP TURB CLG	CF6-50 (LMCO)	OH	1
9061M14G07	MANIFOLD ASSY - LP TURB CLG	CF6-50 (LMCO)	OH	1
9061M14G07	MANIFOLD ASSY - LP TURB CLG	CF6-50 (LMCO)	OH	1
9061M14G07	MANIFOLD ASSY - LP TURB CLG	CF6-50 (LMCO)	OH	1
9061M14G07	MANIFOLD ASSY - LP TURB CLG	CF6-50 (LMCO)	OH	1
9061M21P03	DISK - LPT STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9061M21P03	DISK - LPT STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M21P03	DISK - LPT STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M21P03	DISK - LPT STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M21P03	DISK - LPT STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M21P03	DISK - LPT STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M21P03	DISK - LPT STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M21P08	DISK - LPT STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9061M21P09	DISK - LPT STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9061M21P09	DISK - LPT STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9061M22P11	DISK - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M22P11	DISK - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M22P11	DISK - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M22P11	DISK - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9061M22P11	DISK - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9061M22P11	DISK - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M22P11	DISK - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M22P11	DISK - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M22P11	DISK - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M22P11	DISK - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M22P11	DISK - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M22P11	DISK - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M22P13	DISK - LPT STG 2	CF6-50 (LMCO)	AR	1
9061M22P16	DISK - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M22P16	DISK - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M22P16	DISK - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9061M22P16	DISK - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M22P16	DISK - LPT STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M22P17	DISK - LPT STG 2	CF6-50 (LMCO)	AR	1
9061M23P10	DISK - LPT STG 3	CF6-50	AR	1
9061M23P10	DISK - LPT STG 3	CF6-50	AR	1
9061M24P05	DISK - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M24P05	DISK - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M24P07	DISK - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9061M24P07	DISK - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9061M24P07	DISK - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M24P07	DISK - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M24P07	DISK - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9061M24P07	DISK - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M24P07	DISK - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M24P07	DISK - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M24P07	DISK - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M24P07	DISK - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M26P20	SHAFT - LPT REAR	CF6-50 (Boeing)	AR	1
9061M26P22	SHAFT - LPT REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M26P22	SHAFT - LPT REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M26P22	SHAFT - LPT REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M26P22	SHAFT - LPT REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M26P22	SHAFT - LPT REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M26P22	SHAFT - LPT REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M26P22	SHAFT - LPT REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M26P22	SHAFT - LPT REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M26P22	SHAFT - LPT REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M26P22	SHAFT - LPT REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M26P22	SHAFT - LPT REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M26P22	SHAFT - LPT REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M26P22	SHAFT - LPT REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M26P22	SHAFT - LPT REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M28P10	SHAFT - LPT FRONT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M28P10	SHAFT - LPT FRONT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9061M28P10	SHAFT - LPT FRONT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M28P10	SHAFT - LPT FRONT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M28P10	SHAFT - LPT FRONT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M28P10	SHAFT - LPT FRONT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M28P10	SHAFT - LPT FRONT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M28P10	SHAFT - LPT FRONT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M28P10	SHAFT - LPT FRONT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M30G01	BRACKET ASSY - LP TURB CLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9061M30G01	BRACKET ASSY - LP TURB CLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9061M30G01	BRACKET ASSY - LP TURB CLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9061M30G01	BRACKET ASSY - LP TURB CLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9061M30G02	BRACKET ASSY - LP TURB CLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9061M30G02	BRACKET ASSY - LP TURB CLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9061M30G02	BRACKET ASSY - LP TURB CLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9061M41P01	SEAL - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M41P01	SEAL - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M41P01	SEAL - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M41P01	SEAL - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M41P01	SEAL - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M41P01	SEAL - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M41P01	SEAL - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M41P01	SEAL - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M41P01	SEAL - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M41P01	SEAL - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M41P01	SEAL - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M41P01	SEAL - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9061M41P01	SEAL - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M41P01	SEAL - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M41P01	SEAL - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M41P01	SEAL - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M41P01	SEAL - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M41P01	SEAL - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M41P01	SEAL - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M41P01	SEAL - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M41P01	SEAL - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M41P01	SEAL - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M41P01	SEAL - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M41P01	SEAL - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M41P01	SEAL - LPT STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M42P01	SEAL - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M42P01	SEAL - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M42P01	SEAL - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M42P01	SEAL - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M42P01	SEAL - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M42P01	SEAL - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M42P01	SEAL - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M42P01	SEAL - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M42P01	SEAL - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M42P01	SEAL - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M42P01	SEAL - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M42P01	SEAL - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M42P01	SEAL - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M42P01	SEAL - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9061M42P01	SEAL - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M42P01	SEAL - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M42P01	SEAL - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M42P01	SEAL - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M42P01	SEAL - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M42P01	SEAL - LPT STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M70G01	TUBE - LPTR AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M70G01	TUBE - LPTR AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M70G01	TUBE - LPTR AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M70G01	TUBE - LPTR AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M70G01	TUBE - LPTR AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M70G01	TUBE - LPTR AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M70G01	TUBE - LPTR AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M70G01	TUBE - LPTR AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M70G01	TUBE - LPTR AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M70G01	TUBE - LPTR AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M70G01	TUBE - LPTR AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M70G01	TUBE - LPTR AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M70G01	TUBE - LPTR AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9061M70G01	TUBE - LPTR AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M70G01	TUBE - LPTR AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9061M71P02	PLATE - IDENTIFICATION	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	15
9061M71P03	PLATE - INSTRUCTION	CF6-80C2	NS	19

Part Number	Part Description	Engine Type	Condition	Quantity
9061M71P04	PLATE - INSTRUCTION	CF6-80C2	NS	12
9061M71P06	PLATE - INSTRUCTION	CF6-80C2	NE	2
9061M71P07	PLATE - INSTRUCTION	CF6-80C2	NE	19
9061M71P07	PLATE - INSTRUCTION	CF6-80C2	NE	1
9061M71P11	PLATE - INSTRUCTION	CF6-80C2	NS	1
9061M71P11	PLATE - INSTRUCTION	CF6-80C2	NS	3
9061M71P11	PLATE - INSTRUCTION	CF6-80C2	NS	1
9062M27P01	DEFLECTOR - VANED	CF6-50	NE	3
9062M27P02	DEFLECTOR - VANED	CF6-50	NE	6
9062M51G08	HOUSING ASSY - SUMP	CF6-50	AR	1
9062M51G10	HOUSING ASSY - SUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9062M51G10	HOUSING ASSY - SUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9062M51G10	HOUSING ASSY - SUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9062M67G01	TUBE - OIL IMPINGEMENT (SPD)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9062M67G01	TUBE - OIL IMPINGEMENT (SPD)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9062M67G01	TUBE - OIL IMPINGEMENT (SPD)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9062M67G01	TUBE - OIL IMPINGEMENT (SPD)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9062M67G01	TUBE - OIL IMPINGEMENT (SPD)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9062M68G01	MANIFOLD ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9062M68G01	MANIFOLD ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9062M68G01	MANIFOLD ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9062M68G01	MANIFOLD ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9062M68G01	MANIFOLD ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9062M68G01	MANIFOLD ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9062M68G01	MANIFOLD ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9062M68G01	MANIFOLD ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9062M68G01	MANIFOLD ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9062M72G02	TUBE - SCAVENGE	CF6-50	OH	1
9062M73G05	TUBE ASSY - SUMP	CF6-50	AR	1
9064M10G01	MANIFOLD - LUBE	CF6-80A, CF6-50	AR	1
9064M10G01	MANIFOLD - LUBE	CF6-80A, CF6-50	AR	1
9064M10G01	MANIFOLD - LUBE	CF6-80A, CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9064M10G01	MANIFOLD - LUBE	CF6-80A, CF6-50	AR	1
9064M10G01	MANIFOLD - LUBE	CF6-80A, CF6-50	AR	1
9064M10G01	MANIFOLD - LUBE	CF6-80A, CF6-50	AR	1
9064M10G01	MANIFOLD - LUBE	CF6-80A, CF6-50	AR	1
9064M10G01	MANIFOLD - LUBE	CF6-80A, CF6-50	AR	1
9064M10G01	MANIFOLD - LUBE	CF6-80A, CF6-50	AR	1
9064M10G01	MANIFOLD - LUBE	CF6-80A, CF6-50	AR	1
9064M10G01	MANIFOLD - LUBE	CF6-80A, CF6-50	AR	1
9064M10G01	MANIFOLD - LUBE	CF6-80A, CF6-50	AR	1
9064M10G01	MANIFOLD - LUBE	CF6-80A, CF6-50	AR	1
9064M10G01	MANIFOLD - LUBE	CF6-80A, CF6-50	AR	1
9064M10G01	MANIFOLD - LUBE	CF6-80A, CF6-50	AR	1
9064M10G01	MANIFOLD - LUBE	CF6-80A, CF6-50	AR	1
9064M10G01	MANIFOLD - LUBE	CF6-80A, CF6-50	AR	1
9064M49G05	BELLCRANK - VALVE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9064M49G05	BELLCRANK - VALVE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M49G05	BELLCRANK - VALVE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	10
9064M49G05	BELLCRANK - VALVE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M49G05	BELLCRANK - VALVE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M49G05	BELLCRANK - VALVE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9064M49G05	BELLCRANK - VALVE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9064M49G05	BELLCRANK - VALVE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9064M49G05	BELLCRANK - VALVE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
9064M51G05	LUG - LKG STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	REP	1
9064M51G05	LUG - LKG STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M51G05	LUG - LKG STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9064M51G05	LUG - LKG STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	NE	6

Part Number	Part Description	Engine Type	Condition	Quantity
9064M52G03	LUG - LKG STG 3	CF6-50	NS	1
9064M52G05	LUG - LKG STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9064M52G05	LUG - LKG STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9064M52G06	LUG - LKG STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9064M52G06	LUG - LKG STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M52G06	LUG - LKG STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9064M52G06	LUG - LKG STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	NE	3
9064M53G08	CASE - FAN STTR FWD	CF6-50 (Boeing)	AR	1
9064M53G10	CASE - FAN STTR FWD	CF6-50	AR	1
9064M53G12	CASE - FAN STTR FWD	CF6-50 (LMCO)	OH	1
9064M53G12	CASE - FAN STTR FWD	CF6-50 (LMCO)	AR	1
9064M53G12	CASE - FAN STTR FWD	CF6-50 (LMCO)	AR	1
9064M53G14	CASE - FAN STTR FWD	CF6-50 (LMCO)	AR	1
9064M53G14	CASE - FAN STTR FWD	CF6-50 (LMCO)	AR	1
9064M55G08	SPINNER - FAN RTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M55G08	SPINNER - FAN RTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M55G08	SPINNER - FAN RTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M55G08	SPINNER - FAN RTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M55G08	SPINNER - FAN RTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M55G08	SPINNER - FAN RTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M55G08	SPINNER - FAN RTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M55G08	SPINNER - FAN RTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M55G08	SPINNER - FAN RTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M55G08	SPINNER - FAN RTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M55G08	SPINNER - FAN RTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M55G08	SPINNER - FAN RTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M55G08	SPINNER - FAN RTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M67P13	BLADE - STG 3 (NARROW)	CF6-50	AR	1
9064M67P13	BLADE - STG 3 (NARROW)	CF6-50	AR	3
9064M67P13	BLADE - STG 3 (NARROW)	CF6-50	AR	3

Part Number	Part Description	Engine Type	Condition	Quantity
9064M67P13	BLADE - STG 3 (NARROW)	CF6-50	AR	10
9064M67P14	BLADE - STG 3 (WIDE)	CF6-50	AR	1
9064M67P14	BLADE - STG 3 (WIDE)	CF6-50	AR	5
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	AR	47
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	AR	32
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	AR	29
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	OH	5
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	AR	27
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	AR	32
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	AR	33
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	AR	31
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	AR	17
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	AR	38
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	AR	29
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	AR	35
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	AR	35
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	AR	39
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	OH	3
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	AR	30
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	OH	6
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	AR	23
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	AR	38
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	OH	4
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	AR	38
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	OH	2
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	OH	3
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	OH	1
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	AR	31
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	OH	4
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	OH	4
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	AR	31
9064M67P17	BLADE - STG 3 (NARROW)	CF6-50 (LMCO)	AR	34
9064M67P18	BLADE - STG 3 (WIDE)	CF6-50 (LMCO)	AR	40
9064M67P18	BLADE - STG 3 (WIDE)	CF6-50 (LMCO)	AR	43
9064M67P18	BLADE - STG 3 (WIDE)	CF6-50 (LMCO)	AR	20
9064M67P18	BLADE - STG 3 (WIDE)	CF6-50 (LMCO)	AR	22
9064M67P18	BLADE - STG 3 (WIDE)	CF6-50 (LMCO)	AR	33
9064M67P18	BLADE - STG 3 (WIDE)	CF6-50 (LMCO)	AR	36
9064M67P18	BLADE - STG 3 (WIDE)	CF6-50 (LMCO)	AR	2
9064M67P18	BLADE - STG 3 (WIDE)	CF6-50 (LMCO)	AR	1
9064M67P18	BLADE - STG 3 (WIDE)	CF6-50 (LMCO)	AR	43
9064M67P18	BLADE - STG 3 (WIDE)	CF6-50 (LMCO)	AR	37
9064M67P18	BLADE - STG 3 (WIDE)	CF6-50 (LMCO)	AR	33
9064M67P18	BLADE - STG 3 (WIDE)	CF6-50 (LMCO)	AR	39
9064M67P18	BLADE - STG 3 (WIDE)	CF6-50 (LMCO)	AR	34
9064M67P18	BLADE - STG 3 (WIDE)	CF6-50 (LMCO)	AR	34
9064M67P18	BLADE - STG 3 (WIDE)	CF6-50 (LMCO)	AR	34
9064M67P18	BLADE - STG 3 (WIDE)	CF6-50 (LMCO)	AR	41

Part Number	Part Description	Engine Type	Condition	Quantity
9064M74G01	NUT ASSY - GANG CHAN SLFLKG	CF6-50 (LMCO)	AR	2
9064M74G01	NUT ASSY - GANG CHAN SLFLKG	CF6-50 (LMCO)	NS	1
9064M74G01	NUT ASSY - GANG CHAN SLFLKG	CF6-50 (LMCO)	NS	3
9064M74G01	NUT ASSY - GANG CHAN SLFLKG	CF6-50 (LMCO)	AR	2
9064M74G01	NUT ASSY - GANG CHAN SLFLKG	CF6-50 (LMCO)	AR	2
9064M74G01	NUT ASSY - GANG CHAN SLFLKG	CF6-50 (LMCO)	AR	2
9064M74G01	NUT ASSY - GANG CHAN SLFLKG	CF6-50 (LMCO)	AR	2
9064M74G01	NUT ASSY - GANG CHAN SLFLKG	CF6-50 (LMCO)	AR	2
9064M84P02	VANE - STG 4	CF6-50 (LMCO)	AR	112
9064M84P02	VANE - STG 4	CF6-50 (LMCO)	AR	111
9064M84P02	VANE - STG 4	CF6-50 (LMCO)	AR	111
9064M84P02	VANE - STG 4	CF6-50 (LMCO)	AR	112
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	111
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	112

Part Number	Part Description	Engine Type	Condition	Quantity
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	54
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	7
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	44
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	112

Part Number	Part Description	Engine Type	Condition	Quantity
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	70
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M84P04	VANE - FAN STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	42
9064M85G01	NUT ASSY - SLFLKG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9064M85G01	NUT ASSY - SLFLKG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	14
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M91P03	VANE - OGV OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	78
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	62
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	56
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	78
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	62
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	78
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	24
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	78
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	78
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	78
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	78
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	78
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	OH	15
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	78
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	OH	15
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	78
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	78

Part Number	Part Description	Engine Type	Condition	Quantity
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	22
9064M94P06	VANE - STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	78
9064M95P05	VANE - STG 2	CF6-50	AR	112
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	44
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	64
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	64
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	48
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	60
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	SV	56
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	112

Part Number	Part Description	Engine Type	Condition	Quantity
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	20
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	8
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	19
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	9
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	10
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	SV	56
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	52
9064M95P06	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	52
9064M96P08	VANE - STG 3	CF6-50	AR	103
9064M96P08	VANE - STG 3	CF6-50	AR	110
9064M96P09	VANE - STG 3 BORESCOPE	CF6-50	AR	1
9064M96P09	VANE - STG 3 BORESCOPE	CF6-50	AR	1
9064M96P10	VANE - STG 3 BORESCOPE	CF6-50	AR	1
9064M96P11	VANE - STG 3	CF6-50	AR	7
9064M96P12	VANE - STG 3 BORESCOPE	CF6-50	AR	1
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	66
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	44

Part Number	Part Description	Engine Type	Condition	Quantity
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	SV	40
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	110
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	58
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	110
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	110
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	23
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	27
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	78
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	109
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	110
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	64
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	46
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	55
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	84
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	2

Part Number	Part Description	Engine Type	Condition	Quantity
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	109
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	110
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	42
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	SV	25
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	SV	40
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	109
9064M96P14	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	24
9064M96P15	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P15	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9064M96P15	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P15	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P15	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P15	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P15	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P15	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P15	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P15	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P15	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P15	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P15	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P15	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P15	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P15	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P15	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	110
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	62
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	110
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	10
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	6
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	10
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	10
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	46
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	64
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	55
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	110
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	110
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	70
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	13
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	13
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	20
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	20
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	110
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	64
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P17	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	110
9064M96P18	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P18	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P18	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P18	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P18	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P18	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P18	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P18	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P18	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P18	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P18	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P18	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M96P19	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P19	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P19	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P19	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P19	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P19	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P19	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9064M96P19	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P19	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P19	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P19	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P19	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P19	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M96P19	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P19	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M96P19	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M97G09	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M97G09	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M97G09	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M97G09	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M97G09	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M97G09	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M97G09	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M97G09	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M97G10	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M97G10	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M97G10	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M98G05	INNER - FAN STATOR	CF6-50 (Boeing)	AR	1
9064M98G05	INNER - FAN STATOR	CF6-50 (Boeing)	OH	1
9064M98G05	INNER - FAN STATOR	CF6-50 (Boeing)	OH	1
9064M98G05	INNER - FAN STATOR	CF6-50 (Boeing)	OH	1
9064M98G05	INNER - FAN STATOR	CF6-50 (Boeing)	AR	1
9064M98G05	INNER - FAN STATOR	CF6-50 (Boeing)	AR	1
9064M98G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9064M98G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M98G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M98G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M98G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M98G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M98G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	REP	1
9064M98G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M98G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M98G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M98G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M98G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M98G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M98G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M98G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M98G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M98G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M98G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M98G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M98G08	INNER - FAN STATOR	CF6-50	AR	1
9064M99G05	INNER - FAN STATOR	CF6-50 (Boeing)	AR	1
9064M99G05	INNER - FAN STATOR	CF6-50 (Boeing)	AR	1
9064M99G05	INNER - FAN STATOR	CF6-50 (Boeing)	AR	1
9064M99G05	INNER - FAN STATOR	CF6-50 (Boeing)	OH	1
9064M99G05	INNER - FAN STATOR	CF6-50 (Boeing)	AR	1
9064M99G05	INNER - FAN STATOR	CF6-50 (Boeing)	AR	1
9064M99G05	INNER - FAN STATOR	CF6-50 (Boeing)	AR	1
9064M99G05	INNER - FAN STATOR	CF6-50 (Boeing)	AR	1
9064M99G05	INNER - FAN STATOR	CF6-50 (Boeing)	OH	1
9064M99G05	INNER - FAN STATOR	CF6-50 (Boeing)	OH	1
9064M99G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9064M99G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M99G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M99G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M99G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M99G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M99G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M99G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M99G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M99G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9064M99G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M99G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M99G07	INNER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9064M99G11	INNER - FAN STATOR	CF6-50 (Boeing)	AR	1
9064M99G11	INNER - FAN STATOR	CF6-50 (Boeing)	AR	1
9064M99G11	INNER - FAN STATOR	CF6-50 (Boeing)	AR	1
9064M99G11	INNER - FAN STATOR	CF6-50 (Boeing)	AR	1
9065M25P03	SEAL - ROT	CF6-50	AR	1
9065M25P05	SEAL - ROT	CF6-50	AR	1
9065M25P05	SEAL - ROT	CF6-50	AR	1
9065M25P05	SEAL - ROT	CF6-50	AR	1
9065M25P05	SEAL - ROT	CF6-50	AR	1
9065M25P05	SEAL - ROT	CF6-50	AR	1
9065M31P04	HOUSING - BRG AFT NO. 1	CF6-50	AR	1
9065M31P04	HOUSING - BRG AFT NO. 1	CF6-50	AR	1
9065M31P04	HOUSING - BRG AFT NO. 1	CF6-50	AR	1
9065M31P04	HOUSING - BRG AFT NO. 1	CF6-50	AR	1
9065M31P04	HOUSING - BRG AFT NO. 1	CF6-50	AR	1
9065M31P04	HOUSING - BRG AFT NO. 1	CF6-50	AR	1
9065M31P04	HOUSING - BRG AFT NO. 1	CF6-50	AR	1
9065M31P04	HOUSING - BRG AFT NO. 1	CF6-50	AR	1
9065M31P04	HOUSING - BRG AFT NO. 1	CF6-50	AR	1
9065M31P04	HOUSING - BRG AFT NO. 1	CF6-50	AR	1
9065M31P04	HOUSING - BRG AFT NO. 1	CF6-50	AR	1
9065M32P04	HOUSING - BRG FWD NO. 1	CF6-50	AR	1
9065M32P04	HOUSING - BRG FWD NO. 1	CF6-50	AR	1
9065M32P04	HOUSING - BRG FWD NO. 1	CF6-50	AR	1
9065M32P04	HOUSING - BRG FWD NO. 1	CF6-50	AR	1
9065M32P04	HOUSING - BRG FWD NO. 1	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9065M32P04	HOUSING - BRG FWD NO. 1	CF6-50	AR	1
9065M32P04	HOUSING - BRG FWD NO. 1	CF6-50	AR	1
9065M32P04	HOUSING - BRG FWD NO. 1	CF6-50	AR	1
9065M32P04	HOUSING - BRG FWD NO. 1	CF6-50	AR	1
9065M32P04	HOUSING - BRG FWD NO. 1	CF6-50	AR	1
9065M32P04	HOUSING - BRG FWD NO. 1	CF6-50	AR	1
9065M33P04	SEAL - FWD AIR ROT	CF6-50 (Boeing)	AR	1
9065M33P04	SEAL - FWD AIR ROT	CF6-50 (Boeing)	AR	1
9065M33P04	SEAL - FWD AIR ROT	CF6-50 (Boeing)	AR	1
9065M33P04	SEAL - FWD AIR ROT	CF6-50 (Boeing)	AR	1
9065M33P04	SEAL - FWD AIR ROT	CF6-50 (Boeing)	AR	1
9065M33P04	SEAL - FWD AIR ROT	CF6-50 (Boeing)	AR	1
9065M33P04	SEAL - FWD AIR ROT	CF6-50 (Boeing)	AR	1
9065M33P04	SEAL - FWD AIR ROT	CF6-50 (Boeing)	AR	1
9065M33P04	SEAL - FWD AIR ROT	CF6-50 (Boeing)	AR	1
9065M33P04	SEAL - FWD AIR ROT	CF6-50 (Boeing)	AR	1
9065M33P04	SEAL - FWD AIR ROT	CF6-50 (Boeing)	AR	1
9065M33P04	SEAL - FWD AIR ROT	CF6-50 (Boeing)	AR	1
9065M33P04	SEAL - FWD AIR ROT	CF6-50 (Boeing)	AR	1
9065M33P04	SEAL - FWD AIR ROT	CF6-50 (Boeing)	AR	1
9065M33P04	SEAL - FWD AIR ROT	CF6-50 (Boeing)	AR	1
9065M33P04	SEAL - FWD AIR ROT	CF6-50 (Boeing)	AR	1
9065M33P04	SEAL - FWD AIR ROT	CF6-50 (Boeing)	AR	1
9065M33P04	SEAL - FWD AIR ROT	CF6-50 (Boeing)	AR	1
9065M33P04	SEAL - FWD AIR ROT	CF6-50 (Boeing)	AR	1
9065M33P04	SEAL - FWD AIR ROT	CF6-50 (Boeing)	AR	1
9065M33P04	SEAL - FWD AIR ROT	CF6-50 (Boeing)	AR	1
9065M33P04	SEAL - FWD AIR ROT	CF6-50 (Boeing)	AR	1
9065M45G02	MANIFOLD - LUBE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M45G02	MANIFOLD - LUBE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M45G02	MANIFOLD - LUBE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M45G02	MANIFOLD - LUBE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M45G02	MANIFOLD - LUBE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M45G02	MANIFOLD - LUBE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M45G02	MANIFOLD - LUBE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9065M45G02	MANIFOLD - LUBE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M45G02	MANIFOLD - LUBE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M45G02	MANIFOLD - LUBE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M45G02	MANIFOLD - LUBE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M45G02	MANIFOLD - LUBE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M45G02	MANIFOLD - LUBE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M45G02	MANIFOLD - LUBE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M45G02	MANIFOLD - LUBE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M45G02	MANIFOLD - LUBE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M45G02	MANIFOLD - LUBE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M45G02	MANIFOLD - LUBE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M45G02	MANIFOLD - LUBE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M45G02	MANIFOLD - LUBE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M45G02	MANIFOLD - LUBE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9065M45G02	MANIFOLD - LUBE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M62G06	HOUSING ASSY - BRG NO. 1	CF6-50	AR	1
9065M62G08	HOUSING ASSY - BRG NO. 1	CF6-50	AR	1
9065M64P13	SHAFT - HPTR REAR	CF6-50	AR	1
9065M64P13	SHAFT - HPTR REAR	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9065M66G03	HOUSING ASSY - BRG NO. 2	CF6-50 (Boeing)	AR	1
9065M66G03	HOUSING ASSY - BRG NO. 2	CF6-50 (Boeing)	OH	1
9065M66G03	HOUSING ASSY - BRG NO. 2	CF6-50 (Boeing)	AR	1
9065M66G03	HOUSING ASSY - BRG NO. 2	CF6-50 (Boeing)	AR	1
9065M66G04	HOUSING ASSY - BRG NO. 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M66G04	HOUSING ASSY - BRG NO. 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M66G04	HOUSING ASSY - BRG NO. 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M66G04	HOUSING ASSY - BRG NO. 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M66G04	HOUSING ASSY - BRG NO. 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M66G04	HOUSING ASSY - BRG NO. 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M66G04	HOUSING ASSY - BRG NO. 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M66G04	HOUSING ASSY - BRG NO. 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9065M66G04	HOUSING ASSY - BRG NO. 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M66G04	HOUSING ASSY - BRG NO. 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M66G04	HOUSING ASSY - BRG NO. 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M66G04	HOUSING ASSY - BRG NO. 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M66G04	HOUSING ASSY - BRG NO. 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M66G05	HOUSING - BRG NO. 2	CF6-80A	AR	1
9065M66G05	HOUSING - BRG NO. 2	CF6-80A	AR	1
9065M66G05	HOUSING - BRG NO. 2	CF6-80A	AR	1
9065M66G05	HOUSING - BRG NO. 2	CF6-80A	AR	1
9065M66G05	HOUSING - BRG NO. 2	CF6-80A	AR	1
9065M66G05	HOUSING - BRG NO. 2	CF6-80A	SV	1
9065M66G05	HOUSING - BRG NO. 2	CF6-80A	AR	1
9065M66G05	HOUSING - BRG NO. 2	CF6-80A	OH	1
9065M67G07	SLEEVE ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M67G07	SLEEVE ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M67G07	SLEEVE ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M67G07	SLEEVE ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M67G07	SLEEVE ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9065M67G07	SLEEVE ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M67G07	SLEEVE ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M67G07	SLEEVE ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M67G07	SLEEVE ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M67G07	SLEEVE ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M67G07	SLEEVE ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M67G07	SLEEVE ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M67G07	SLEEVE ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9065M67G07	SLEEVE ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M67G07	SLEEVE ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M67G07	SLEEVE ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M67G07	SLEEVE ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M67G07	SLEEVE ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9065M67G07	SLEEVE ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M67G07	SLEEVE ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9065M67G07	SLEEVE ASSY - FAN FR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9066M34G01	BRACKET ASSY - TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9066M45G02	BRACKET - B SUMP TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9066M45G02	BRACKET - B SUMP TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9066M45G02	BRACKET - B SUMP TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9066M45G02	BRACKET - B SUMP TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9066M45G02	BRACKET - B SUMP TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9066M45G02	BRACKET - B SUMP TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9066M50P01	BRACKET - ANGLE	CF6-50 (LMCO)	AR	1
9066M50P01	BRACKET - ANGLE	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9066M54P01	PLUG - FAULT ISO MAG	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	5
9066M54P01	PLUG - FAULT ISO MAG	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9066M54P01	PLUG - FAULT ISO MAG	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9066M67G02	MANIFOLD ASSY - C AND D OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9066M67G02	MANIFOLD ASSY - C AND D OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9066M67G02	MANIFOLD ASSY - C AND D OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9066M67G02	MANIFOLD ASSY - C AND D OIL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9066M67G02	MANIFOLD ASSY - C AND D OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9066M67G02	MANIFOLD ASSY - C AND D OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9066M67G02	MANIFOLD ASSY - C AND D OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9066M67G02	MANIFOLD ASSY - C AND D OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9066M67G02	MANIFOLD ASSY - C AND D OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9066M67G02	MANIFOLD ASSY - C AND D OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9066M67G02	MANIFOLD ASSY - C AND D OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9066M67G02	MANIFOLD ASSY - C AND D OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9066M79G01	MANIFOLD - FUEL	CF6-50 (Boeing)	AR	1
9066M79G01	MANIFOLD - FUEL	CF6-50 (Boeing)	AR	1
9066M79G01	MANIFOLD - FUEL	CF6-50 (Boeing)	AR	1
9066M79G01	MANIFOLD - FUEL	CF6-50 (Boeing)	AR	1
9066M79G01	MANIFOLD - FUEL	CF6-50 (Boeing)	AR	1
9066M79G01	MANIFOLD - FUEL	CF6-50 (Boeing)	AR	1
9066M79G01	MANIFOLD - FUEL	CF6-50 (Boeing)	AR	1
9066M79G01	MANIFOLD - FUEL	CF6-50 (Boeing)	OH	1
9066M79G01	MANIFOLD - FUEL	CF6-50 (Boeing)	AR	1
9066M79G01	MANIFOLD - FUEL	CF6-50 (Boeing)	AR	1
9066M79G01	MANIFOLD - FUEL	CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9067M23P01	BRACKET - HP RECOUP TUBE	CF6-50 (LMCO)	SV	1
9067M23P01	BRACKET - HP RECOUP TUBE	CF6-50 (LMCO)	SV	1
9067M29G01	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9067M29G01	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9067M29G01	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9067M29G01	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9067M29G01	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9067M29G01	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9067M29G01	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9067M29G01	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9067M29G01	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9067M29G01	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9067M29G01	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9067M29G01	TUBE ASSY - HP RECOUP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9067M34G07	MANIFOLD ASSY - CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9067M34G07	MANIFOLD ASSY - CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9067M34G07	MANIFOLD ASSY - CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9067M34G07	MANIFOLD ASSY - CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9067M34G07	MANIFOLD ASSY - CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9067M34G07	MANIFOLD ASSY - CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9067M34G07	MANIFOLD ASSY - CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9067M34G07	MANIFOLD ASSY - CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9067M34G07	MANIFOLD ASSY - CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9067M34G07	MANIFOLD ASSY - CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9067M34G07	MANIFOLD ASSY - CDP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9067M34G08	MANIFOLD ASSY - CDP	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9067M76G01	MANIFOLD ASSY - LP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9067M76G01	MANIFOLD ASSY - LP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9067M76G01	MANIFOLD ASSY - LP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9067M76G01	MANIFOLD ASSY - LP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9067M76G01	MANIFOLD ASSY - LP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9067M77P03	CABLE - VARIABLE BYPASS	CF6-50 (LMCO)	AR	1
9067M88G02	BRACKET - TUBE	CF6-50	OH	1
9067M93G05	BRACKET - VIBRATION SPRT	CF6-50	SV	1
9067M93G06	BRACKET - ACTUATOR RESET	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9067M93G06	BRACKET - ACTUATOR RESET	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9067M93G06	BRACKET - ACTUATOR RESET	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9067M94G01	HOUSING ASSY - BELLCRANK	CF6-50	AR	1
9067M94G01	HOUSING ASSY - BELLCRANK	CF6-50	AR	1
9068M20G01	TUBE ASSY - TEMP RTN AFT	CF6-50 (Boeing)	AR	1
9068M20G01	TUBE ASSY - TEMP RTN AFT	CF6-50 (Boeing)	AR	1
9068M20G01	TUBE ASSY - TEMP RTN AFT	CF6-50 (Boeing)	AR	1
9068M20G01	TUBE ASSY - TEMP RTN AFT	CF6-50 (Boeing)	AR	1
9068M22P02	CLEVIS - CABLE	CF6-50 (LMCO)	NS	1
9068M22P04	CLEVIS - CABLE	CF6-50	SV	1
9068M24P01	LINK - CONNECTING	CF6-50	AR	1
9068M24P05	LINK - CONNECTING	CF6-80A	AR	1
9068M24P05	LINK - CONNECTING	CF6-80A	AR	1
9068M40G01	TUBE ASSY - STG 14 CDP AIR	CF6-50 (LMCO)	AR	1
9068M40G01	TUBE ASSY - STG 14 CDP AIR	CF6-50 (LMCO)	AR	1
9068M40G01	TUBE ASSY - STG 14 CDP AIR	CF6-50 (LMCO)	AR	1
9068M40G01	TUBE ASSY - STG 14 CDP AIR	CF6-50 (LMCO)	AR	1
9068M40G01	TUBE ASSY - STG 14 CDP AIR	CF6-50 (LMCO)	AR	1
9068M40G01	TUBE ASSY - STG 14 CDP AIR	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9068M40G01	TUBE ASSY - STG 14 CDP AIR	CF6-50 (LMCO)	AR	1
9068M40G01	TUBE ASSY - STG 14 CDP AIR	CF6-50 (LMCO)	AR	1
9068M40G01	TUBE ASSY - STG 14 CDP AIR	CF6-50 (LMCO)	AR	1
9068M40G01	TUBE ASSY - STG 14 CDP AIR	CF6-50 (LMCO)	AR	1
9068M40G01	TUBE ASSY - STG 14 CDP AIR	CF6-50 (LMCO)	AR	1
9068M40G01	TUBE ASSY - STG 14 CDP AIR	CF6-50 (LMCO)	AR	1
9068M40G01	TUBE ASSY - STG 14 CDP AIR	CF6-50 (LMCO)	AR	1
9068M40G01	TUBE ASSY - STG 14 CDP AIR	CF6-50 (LMCO)	AR	1
9068M40G01	TUBE ASSY - STG 14 CDP AIR	CF6-50 (LMCO)	AR	1
9068M41G01	MANIFOLD - FLOWMETER TO FWD	CF6-50 (Boeing)	AR	1
9068M41G02	MANIFOLD - FLOWMETER TO FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M41G02	MANIFOLD - FLOWMETER TO FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M41G02	MANIFOLD - FLOWMETER TO FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M41G02	MANIFOLD - FLOWMETER TO FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M41G02	MANIFOLD - FLOWMETER TO FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M41G02	MANIFOLD - FLOWMETER TO FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M41G02	MANIFOLD - FLOWMETER TO FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M41G02	MANIFOLD - FLOWMETER TO FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M41G02	MANIFOLD - FLOWMETER TO FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M41G02	MANIFOLD - FLOWMETER TO FWD	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9068M43G01	BRACKET ASSY - SHIELD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M43G01	BRACKET ASSY - SHIELD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M43G01	BRACKET ASSY - SHIELD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M44G01	MANIFOLD - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M50G01	BRACKET - FLOWMETER MTG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9068M54G01	TUBE ASSY - C SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M54G01	TUBE ASSY - C SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9068M54G01	TUBE ASSY - C SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M54G01	TUBE ASSY - C SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9068M54G01	TUBE ASSY - C SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M54G01	TUBE ASSY - C SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M54G01	TUBE ASSY - C SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M54G01	TUBE ASSY - C SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M54G01	TUBE ASSY - C SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M54G01	TUBE ASSY - C SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M54G01	TUBE ASSY - C SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M54G01	TUBE ASSY - C SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M54G01	TUBE ASSY - C SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M54G01	TUBE ASSY - C SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M54G03	TUBE ASSY - C SUMP AFT	CF6-50 (LMCO)	AR	1
9068M54G03	TUBE ASSY - C SUMP AFT	CF6-50 (LMCO)	AR	1
9068M54G03	TUBE ASSY - C SUMP AFT	CF6-50 (LMCO)	AR	1
9068M55G01	TUBE ASSY - C SUMP MID	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M55G01	TUBE ASSY - C SUMP MID	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M55G01	TUBE ASSY - C SUMP MID	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M55G01	TUBE ASSY - C SUMP MID	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M55G01	TUBE ASSY - C SUMP MID	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M55G01	TUBE ASSY - C SUMP MID	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M55G01	TUBE ASSY - C SUMP MID	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9068M55G01	TUBE ASSY - C SUMP MID	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9068M55G01	TUBE ASSY - C SUMP MID	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M55G01	TUBE ASSY - C SUMP MID	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9068M55G01	TUBE ASSY - C SUMP MID	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M55G01	TUBE ASSY - C SUMP MID	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M55G01	TUBE ASSY - C SUMP MID	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M55G01	TUBE ASSY - C SUMP MID	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M59G01	TUBE ASSY - C SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M59G01	TUBE ASSY - C SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M59G01	TUBE ASSY - C SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M59G01	TUBE ASSY - C SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M59G01	TUBE ASSY - C SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M59G01	TUBE ASSY - C SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M59G01	TUBE ASSY - C SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M59G01	TUBE ASSY - C SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M59G01	TUBE ASSY - C SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M59G01	TUBE ASSY - C SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M59G01	TUBE ASSY - C SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M59G01	TUBE ASSY - C SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M59G01	TUBE ASSY - C SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M59G01	TUBE ASSY - C SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M59G01	TUBE ASSY - C SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M59G01	TUBE ASSY - C SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M59G01	TUBE ASSY - C SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M59G01	TUBE ASSY - C SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M59G01	TUBE ASSY - C SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M59G01	TUBE ASSY - C SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M59G01	TUBE ASSY - C SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M59G01	TUBE ASSY - C SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M59G01	TUBE ASSY - C SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9068M59G01	TUBE ASSY - C SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M59G01	TUBE ASSY - C SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M59G01	TUBE ASSY - C SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M66P01	BRACKET - TUBE FLAT	CF6-50 (Boeing)	OH	1
9068M67G01	MANIFOLD ASSY - FUEL	CF6-50 (Boeing)	AR	1
9068M67G01	MANIFOLD ASSY - FUEL	CF6-50 (Boeing)	AR	1
9068M67G01	MANIFOLD ASSY - FUEL	CF6-50 (Boeing)	AR	1
9068M67G01	MANIFOLD ASSY - FUEL	CF6-50 (Boeing)	AR	1
9068M67G01	MANIFOLD ASSY - FUEL	CF6-50 (Boeing)	AR	1
9068M67G02	MANIFOLD - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M67G02	MANIFOLD - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M67G02	MANIFOLD - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M67G02	MANIFOLD - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M67G02	MANIFOLD - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9068M67G02	MANIFOLD - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9068M67G02	MANIFOLD - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9068M67G02	MANIFOLD - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9068M70G01	TUBE - FWD LUBE OIL INL	CF6-50	AR	1
9068M70G01	TUBE - FWD LUBE OIL INL	CF6-50	AR	1
9068M70G01	TUBE - FWD LUBE OIL INL	CF6-50	AR	1
9068M70G01	TUBE - FWD LUBE OIL INL	CF6-50	AR	1
9068M70G01	TUBE - FWD LUBE OIL INL	CF6-50	SV	1
9068M70G01	TUBE - FWD LUBE OIL INL	CF6-50	AR	1
9068M70G01	TUBE - FWD LUBE OIL INL	CF6-50	AR	1
9068M70G01	TUBE - FWD LUBE OIL INL	CF6-50	AR	1
9068M70G01	TUBE - FWD LUBE OIL INL	CF6-50	AR	1
9068M70G01	TUBE - FWD LUBE OIL INL	CF6-50	AR	1
9068M70G01	TUBE - FWD LUBE OIL INL	CF6-50	AR	1
9068M70G01	TUBE - FWD LUBE OIL INL	CF6-50	AR	1
9068M70G01	TUBE - FWD LUBE OIL INL	CF6-50	AR	1
9068M70G01	TUBE - FWD LUBE OIL INL	CF6-50	AR	1
9068M70G01	TUBE - FWD LUBE OIL INL	CF6-50	AR	1
9068M70G01	TUBE - FWD LUBE OIL INL	CF6-50	AR	1
9068M71G01	TUBE - AFT OIL	CF6-50 (Boeing)	AR	1
9068M71G01	TUBE - AFT OIL	CF6-50 (Boeing)	AR	1
9068M71G01	TUBE - AFT OIL	CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9068M87G02	MANIFOLD ASSY - STG 14 RH	CF6-50 (LMCO)	AR	1
9068M87G02	MANIFOLD ASSY - STG 14 RH	CF6-50 (LMCO)	AR	1
9068M91G02	BRACKET ASSY - ANGLE	CF6-50	AR	1
9068M91G02	BRACKET ASSY - ANGLE	CF6-50	AR	1
9068M95G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9068M95G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9068M95G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9068M99G01	BRACKET ASSY - DBL ANGLE	CF6-50 (LMCO)	SV	1
9068M99G01	BRACKET ASSY - DBL ANGLE	CF6-50 (LMCO)	SV	1
9069M18P001A	BRACKET - IGN CABLE	CF6-50	AR	1
9069M18P001A	BRACKET - IGN CABLE	CF6-50	AR	1
9069M18P001A	BRACKET - IGN CABLE	CF6-50	AR	1
9069M34G01	BRACKET ASSY - ANGLE	CF6-50 (Boeing)	SV	1
9069M35G01	BRACKET ASSY - ANGLE	CF6-50 (LMCO)	SV	1
9069M38G01	BRACKET ASSY - GEARBOX	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9069M55G02	BRACKET ASSY - R MID TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9069M55G02	BRACKET ASSY - R MID TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9069M55G02	BRACKET ASSY - R MID TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9069M55G02	BRACKET ASSY - R MID TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9069M55G02	BRACKET ASSY - R MID TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9069M56G01	BRACKET ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9069M56G01	BRACKET ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9069M56G01	BRACKET ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9069M56G01	BRACKET ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9069M56G01	BRACKET ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9069M57G02	BRACKET ASSY - LWR FWD	CF6-50 (LMCO)	OH	1
9069M57G03	BRACKET ASSY - LWR FWD	CF6-50	AR	1
9069M57G03	BRACKET ASSY - LWR FWD	CF6-50	AR	1
9069M69G01	COUPLING ASSY - LPT CLG	CF6-50	AR	1
9069M69G01	COUPLING ASSY - LPT CLG	CF6-50	OH	1
9069M70G01	TUBE ASSY - LPT MANF SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9069M70G01	TUBE ASSY - LPT MANF SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9069M70G01	TUBE ASSY - LPT MANF SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9069M70G01	TUBE ASSY - LPT MANF SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9069M70G01	TUBE ASSY - LPT MANF SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9069M70G01	TUBE ASSY - LPT MANF SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9069M70G01	TUBE ASSY - LPT MANF SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9069M70G01	TUBE ASSY - LPT MANF SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9069M70G01	TUBE ASSY - LPT MANF SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9069M70G01	TUBE ASSY - LPT MANF SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9069M70G01	TUBE ASSY - LPT MANF SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9069M70G01	TUBE ASSY - LPT MANF SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9069M70G01	TUBE ASSY - LPT MANF SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9069M70G01	TUBE ASSY - LPT MANF SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9069M70G01	TUBE ASSY - LPT MANF SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9069M70G01	TUBE ASSY - LPT MANF SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9069M70G01	TUBE ASSY - LPT MANF SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9069M70G01	TUBE ASSY - LPT MANF SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9069M70G01	TUBE ASSY - LPT MANF SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9069M71G02	BRACKET - B SUMP TUBE	CF6-50 (Boeing)	AR	1
9069M71G03	BRACKET - B SUMP TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9069M71G03	BRACKET - B SUMP TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9069M71G03	BRACKET - B SUMP TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9069M71G03	BRACKET - B SUMP TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9069M72G01	BRACKET ASSY - TUBE	CF6-50 (LMCO)	AR	1
9069M72G02	BRACKET ASSY - TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9069M72G02	BRACKET ASSY - TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9069M72G02	BRACKET ASSY - TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M20G01	BRACKET ASSY - GEARBOX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M22G01	TUBE ASSY - PS2C AIR	CF6-50	AR	1
9070M32G01	BRACKET - ANGLE	CF6-50 (LMCO)	SV	1
9070M34G01	TUBE ASSY - PYLON	CF6-50 (Boeing)	OH	1
9070M34G01	TUBE ASSY - PYLON	CF6-50 (Boeing)	AR	1
9070M34G01	TUBE ASSY - PYLON	CF6-50 (Boeing)	AR	1
9070M34G01	TUBE ASSY - PYLON	CF6-50 (Boeing)	AR	1
9070M34G01	TUBE ASSY - PYLON	CF6-50 (Boeing)	AR	1
9070M34G01	TUBE ASSY - PYLON	CF6-50 (Boeing)	AR	1
9070M34G01	TUBE ASSY - PYLON	CF6-50 (Boeing)	AR	1
9070M34G01	TUBE ASSY - PYLON	CF6-50 (Boeing)	AR	1
9070M34G01	TUBE ASSY - PYLON	CF6-50 (Boeing)	OH	1
9070M34G01	TUBE ASSY - PYLON	CF6-50 (Boeing)	AR	1
9070M34G01	TUBE ASSY - PYLON	CF6-50 (Boeing)	AR	1
9070M34G01	TUBE ASSY - PYLON	CF6-50 (Boeing)	AR	1
9070M34G01	TUBE ASSY - PYLON	CF6-50 (Boeing)	AR	1
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	14
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	29
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	51
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	19
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	11
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9070M35G03	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	30

Part Number	Part Description	Engine Type	Condition	Quantity
9070M35G05	TUBE ASSY - NOZ FDR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9070M49G01	TUBE ASSY - TEMP AFT AIR	CF6-50	AR	1
9070M51G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9070M51G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9070M51G01	BRACKET ASSY - ANGLE	CF6-50	AR	1
9070M51G01	BRACKET ASSY - ANGLE	CF6-50	SV	1
9070M54G01	MANIFOLD ASSY - UPR AFT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M54G01	MANIFOLD ASSY - UPR AFT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M54G01	MANIFOLD ASSY - UPR AFT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M54G01	MANIFOLD ASSY - UPR AFT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M57G01	MANIFOLD ASSY - SHROUDED	CF6-50	AR	1
9070M57G01	MANIFOLD ASSY - SHROUDED	CF6-50	OH	1
9070M57G04	MANIFOLD ASSY - SHROUDED	CF6-50	AR	1
9070M64G01	RING ASSY - OUTER	CF6-50 (LMCO)	AR	1
9070M64G01	RING ASSY - OUTER	CF6-50 (LMCO)	OH	1
9070M64G01	RING ASSY - OUTER	CF6-50 (LMCO)	AR	1
9070M64G01	RING ASSY - OUTER	CF6-50 (LMCO)	AR	1
9070M64G01	RING ASSY - OUTER	CF6-50 (LMCO)	AR	1
9070M64G01	RING ASSY - OUTER	CF6-50 (LMCO)	AR	1
9070M64G01	RING ASSY - OUTER	CF6-50 (LMCO)	AR	1
9070M64G01	RING ASSY - OUTER	CF6-50 (LMCO)	AR	2
9070M64G01	RING ASSY - OUTER	CF6-50 (LMCO)	AR	2
9070M64G01	RING ASSY - OUTER	CF6-50 (LMCO)	OH	1
9070M64G01	RING ASSY - OUTER	CF6-50 (LMCO)	AR	1
9070M64G03	RING ASSY - OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M64G03	RING ASSY - OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M64G03	RING ASSY - OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M64G03	RING ASSY - OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9070M64G03	RING ASSY - OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9070M64G03	RING ASSY - OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9070M64G03	RING ASSY - OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M64G03	RING ASSY - OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9070M64G03	RING ASSY - OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9070M64G03	RING ASSY - OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9070M64G03	RING ASSY - OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M64G03	RING ASSY - OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M65P02	ADAPTER - QIK ASSY AND DISC	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M65P02	ADAPTER - QIK ASSY AND DISC	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M65P02	ADAPTER - QIK ASSY AND DISC	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M65P02	ADAPTER - QIK ASSY AND DISC	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M65P02	ADAPTER - QIK ASSY AND DISC	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M65P02	ADAPTER - QIK ASSY AND DISC	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M65P02	ADAPTER - QIK ASSY AND DISC	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M65P02	ADAPTER - QIK ASSY AND DISC	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M65P02	ADAPTER - QIK ASSY AND DISC	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M65P02	ADAPTER - QIK ASSY AND DISC	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M65P02	ADAPTER - QIK ASSY AND DISC	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M65P02	ADAPTER - QIK ASSY AND DISC	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M65P02	ADAPTER - QIK ASSY AND DISC	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M65P02	ADAPTER - QIK ASSY AND DISC	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M65P02	ADAPTER - QIK ASSY AND DISC	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M65P02	ADAPTER - QIK ASSY AND DISC	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M65P02	ADAPTER - QIK ASSY AND DISC	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9070M65P02	ADAPTER - QIK ASSY AND DISC	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9070M67G03	BRACKET - FIRE	CF6-50 (LMCO)	SV	1
9070M81P01	TUBE/HOSE - FUEL ROD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9070M81P01	TUBE/HOSE - FUEL ROD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M81P01	TUBE/HOSE - FUEL ROD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9070M88G01	BRACE - DRAIN CAN PUMP	CF6-50 (LMCO)	AR	1
9070M88G01	BRACE - DRAIN CAN PUMP	CF6-50 (LMCO)	AR	1
9070M88G01	BRACE - DRAIN CAN PUMP	CF6-50 (LMCO)	AR	1
9070M88G01	BRACE - DRAIN CAN PUMP	CF6-50 (LMCO)	AR	1
9070M89P01	VALVE ASSY - EDUCATOR	CF6-50	AR	1
9070M89P04	VALVE ASSY - EDUCTOR	CF6-50 (LMCO)	AR	1
9070M89P04	VALVE ASSY - EDUCTOR	CF6-50 (LMCO)	AR	1
9070M89P04	VALVE ASSY - EDUCTOR	CF6-50 (LMCO)	AR	1
9070M89P04	VALVE ASSY - EDUCTOR	CF6-50 (LMCO)	AR	1
9070M89P04	VALVE ASSY - EDUCTOR	CF6-50 (LMCO)	AR	1
9070M89P04	VALVE ASSY - EDUCTOR	CF6-50 (LMCO)	AR	1
9070M94P03	BRACKET - COWL HOLD OPEN	CF6-50	AR	1
9070M94P04	BRACKET - COWL HOLD OPEN	CF6-50	AR	1
9070M94P04	BRACKET - COWL HOLD OPEN	CF6-50	OH	1
9070M98P002A	BRACKET	CF6-50 (Boeing)	NS	1
9072M47P01	SLEEVE - DEFL LMTR BUMPER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	5
9072M47P01	SLEEVE - DEFL LMTR BUMPER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9072M47P01	SLEEVE - DEFL LMTR BUMPER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9072M47P02	SLEEVE - DEFLECTION	CF6-80C2	AR	2
9072M56P02	RETAINER - LATCH BOTTOM	CF6-50	AR	1
9072M56P02	RETAINER - LATCH BOTTOM	CF6-50	AR	2
9072M56P02	RETAINER - LATCH BOTTOM	CF6-50	AR	1
9072M56P03	RETAINER - LATCH BOTTOM	CF6-80C2	AR	2
9072M58P01	RETAINER - SPRING	CF6-50	NE	2
9073M10P05	RING - SEAL	CF6-80A, CF6-50	AR	1
9073M10P05	RING - SEAL	CF6-80A, CF6-50	AR	1
9073M10P05	RING - SEAL	CF6-80A, CF6-50	AR	1
9073M10P05	RING - SEAL	CF6-80A, CF6-50	AR	1
9073M10P05	RING - SEAL	CF6-80A, CF6-50	AR	1
9073M10P05	RING - SEAL	CF6-80A, CF6-50	AR	1
9073M10P05	RING - SEAL	CF6-80A, CF6-50	SV	1
9073M10P05	RING - SEAL	CF6-80A, CF6-50	SV	1
9073M10P05	RING - SEAL	CF6-80A, CF6-50	SV	1
9073M10P05	RING - SEAL	CF6-80A, CF6-50	SV	1
9073M10P05	RING - SEAL	CF6-80A, CF6-50	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
9073M10P05	RING - SEAL	CF6-80A, CF6-50	SV	1
9073M10P05	RING - SEAL	CF6-80A, CF6-50	SV	1
9073M10P05	RING - SEAL	CF6-80A, CF6-50	SV	1
9073M10P05	RING - SEAL	CF6-80A, CF6-50	SV	1
9073M10P05	RING - SEAL	CF6-80A, CF6-50	SV	1
9073M10P05	RING - SEAL	CF6-80A, CF6-50	AR	1
9073M41P01	BUMPER	CF6-50 (Boeing)	NE	60
9073M41P01	BUMPER	CF6-50 (Boeing)	NE	2
9073M42G02	PLATFORM - STG 1	CF6-50	AR	38
9073M91P02	SEAL - AFT OUTER	CF6-50 (Boeing)	AR	1
9074M10G04	HOUSING - BRG NO. 3	CF6-50	OH	1
9074M10G04	HOUSING - BRG NO. 3	CF6-50	AR	1
9074M10G04	HOUSING - BRG NO. 3	CF6-50	AR	1
9074M10G05	HOUSING - BRG NO. 3	CF6-50	AR	1
9074M10G05	HOUSING - BRG NO. 3	CF6-50	AR	1
9074M10G06	HOUSING - BRG NO. 3	CF6-50	AR	1
9074M10G06	HOUSING - BRG NO. 3	CF6-50	AR	1
9074M10G06	HOUSING - BRG NO. 3	CF6-50	AR	1
9074M10G06	HOUSING - BRG NO. 3	CF6-50	AR	1
9074M10G06	HOUSING - BRG NO. 3	CF6-50	AR	1
9074M10G06	HOUSING - BRG NO. 3	CF6-50	AR	1
9074M10G06	HOUSING - BRG NO. 3	CF6-50	AR	1
9074M10G06	HOUSING - BRG NO. 3	CF6-50	AR	1
9074M10G06	HOUSING - BRG NO. 3	CF6-50	AR	1
9074M10G06	HOUSING - BRG NO. 3	CF6-50	AR	1
9074M10G06	HOUSING - BRG NO. 3	CF6-50	AR	1
9074M10G06	HOUSING - BRG NO. 3	CF6-50	OH	1
9074M10G06	HOUSING - BRG NO. 3	CF6-50	AR	1
9074M10G06	HOUSING - BRG NO. 3	CF6-50	AR	1
9074M10G07	HOUSING - BRG NO. 3	CF6-50	AR	1
9074M13G06	FAIRING - OUTER	CF6-50 (Boeing)	AR	25
9074M13G06	FAIRING - OUTER	CF6-50 (Boeing)	AR	5
9074M13G08	FAIRING - OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	NE	4
9074M13G08	FAIRING - OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	NE	32
9074M13G08	FAIRING - OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	NE	8
9074M13G08	FAIRING - OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	NE	10
9074M13G08	FAIRING - OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	NE	9
9074M13G08	FAIRING - OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	NE	13
9074M13G08	FAIRING - OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	NE	33

Part Number	Part Description	Engine Type	Condition	Quantity
9074M25G06	SEGMENT ASSY - FAN CS LINER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9074M25G06	SEGMENT ASSY - FAN CS LINER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9074M25G10	SEGMENT ASSY - FAN CS LINER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9074M25G10	SEGMENT ASSY - FAN CS LINER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9074M54P03	RETAINER - FIRE BARRIER INR	CF6-50 (Boeing)	NE	10
9074M54P03	RETAINER - FIRE BARRIER INR	CF6-50 (Boeing)	NE	2
9074M54P03	RETAINER - FIRE BARRIER INR	CF6-50 (Boeing)	NE	1
9074M68G03	PYLON - AFT FAN CASE FILLET	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9074M68G03	PYLON - AFT FAN CASE FILLET	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9074M68G04	PYLON - AFT FAN CASE FILLET	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9074M68G04	PYLON - AFT FAN CASE FILLET	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9074M68G04	PYLON - AFT FAN CASE FILLET	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9074M68G04	PYLON - AFT FAN CASE FILLET	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9074M68G04	PYLON - AFT FAN CASE FILLET	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9074M74G16	FRAME ASSY - FAN	CF6-50	AR	1
9074M74G17	FRAME ASSY - FAN	CF6-50	AR	1
9074M74G18	FRAME ASSY - FAN	CF6-50	AR	1
9074M74G25	FRAME ASSY - FAN	CF6-50 (LMCO)	AR	1
9074M74G25	FRAME ASSY - FAN	CF6-50 (LMCO)	AR	1
9074M74G25	FRAME ASSY - FAN	CF6-50 (LMCO)	AR	1
9074M74G39	FRAME ASSY - FAN	CF6-80A	AR	1
9076M49P02	BAFFLE	CF6-50 (LMCO)	AR	1
9076M49P02	BAFFLE	CF6-50 (LMCO)	AR	1
9076M49P02	BAFFLE	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9076M49P02	BAFFLE	CF6-50 (LMCO)	AR	1
9076M49P02	BAFFLE	CF6-50 (LMCO)	AR	1
9076M49P02	BAFFLE	CF6-50 (LMCO)	AR	1
9076M49P03	BAFFLE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9076M49P03	BAFFLE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9076M49P03	BAFFLE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9076M49P03	BAFFLE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9076M49P03	BAFFLE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9076M49P03	BAFFLE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9076M49P03	BAFFLE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9076M49P03	BAFFLE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9076M49P03	BAFFLE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9076M49P03	BAFFLE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9076M49P03	BAFFLE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9078M33G01	RETAINER ASSY - UPR ADPTR	CF6-50 (LMCO)	AR	1
9078M33G02	RETAINER ASSY - UPR ADPTR	CF6-50 (LMCO)	AR	1
9079M20G09	SEG ASSY - ACTN RING STG 5	CF6-80A, CF6-50 (LMCO)	OH	1
9079M20G09	SEG ASSY - ACTN RING STG 5	CF6-80A, CF6-50 (LMCO)	AR	1
9079M20G09	SEG ASSY - ACTN RING STG 5	CF6-80A, CF6-50 (LMCO)	AR	2
9079M20G09	SEG ASSY - ACTN RING STG 5	CF6-80A, CF6-50 (LMCO)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M20G13	HPC STATOR ACT RING SEGMT STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9079M34G02	LINK - STG 5 CONNECTING	CF6-50	AR	1
9079M58P01	SEAL - DVTL SLT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	32

Part Number	Part Description	Engine Type	Condition	Quantity
9079M58P01	SEAL - DVTL SLT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	27
9079M58P01	SEAL - DVTL SLT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	6
9079M58P01	SEAL - DVTL SLT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	3
9079M58P01	SEAL - DVTL SLT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9079M58P01	SEAL - DVTL SLT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	3
9079M58P01	SEAL - DVTL SLT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	3
9079M58P01	SEAL - DVTL SLT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9079M61G03	RING ASSY - FWD SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M61G03	RING ASSY - FWD SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M61G03	RING ASSY - FWD SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M61G03	RING ASSY - FWD SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M61G03	RING ASSY - FWD SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M61G03	RING ASSY - FWD SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M61G03	RING ASSY - FWD SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M63P20	SHAFT - REAR	CF6-50	AR	1
9079M70G05	OUTER - FAN STATOR	CF6-50 (Boeing)	AR	1
9079M70G06	OUTER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M70G06	OUTER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9079M70G06	OUTER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M70G06	OUTER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M70G07	OUTER - FAN STATOR	CF6-50 (Boeing)	AR	1
9079M70G10	OUTER - FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M70G12	OUTER - FAN STATOR	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9079M70P03	RING	CF6-50	AR	1
9079M71G06	CASE - FAN STATOR OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M71G06	CASE - FAN STATOR OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M71G06	CASE - FAN STATOR OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M71G06	CASE - FAN STATOR OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M71G06	CASE - FAN STATOR OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M71G06	CASE - FAN STATOR OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M71G07	CASE - FAN STATOR OUTER	CF6-50 (Boeing)	OH	1
9079M71G09	CASE - FAN STATOR OUTER	CF6-50	AR	1
9079M72G11	CASE - FAN STATOR OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M72G11	CASE - FAN STATOR OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M72G11	CASE - FAN STATOR OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M72G11	CASE - FAN STATOR OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M72G11	CASE - FAN STATOR OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M72G11	CASE - FAN STATOR OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M72G15	CASE - FAN STATOR OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M72G17	CASE - FAN STATOR OUTER	CF6-50 (LMCO)	AR	1
9079M73G01	BRACKET - ANGLE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	14
9079M73G01	BRACKET - ANGLE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
9079M73G01	BRACKET - ANGLE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	28
9079M73G01	BRACKET - ANGLE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9079M73G01	BRACKET - ANGLE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	3
9079M73G01	BRACKET - ANGLE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9079M73G01	BRACKET - ANGLE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	28

Part Number	Part Description	Engine Type	Condition	Quantity
9079M74G03	CASE - FAN STATOR STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M74G03	CASE - FAN STATOR STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M74G03	CASE - FAN STATOR STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M74G03	CASE - FAN STATOR STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9079M75G03	CASE ASSY - MID OUTER	CF6-50 (Boeing)	AR	1
9079M75G03	CASE ASSY - MID OUTER	CF6-50 (Boeing)	OH	1
9079M75G06	CASE ASSY - MID OUTER	CF6-50 (LMCO)	AR	1
9079M75G06	CASE ASSY - MID OUTER	CF6-50 (LMCO)	OH	1
9079M75G07	CASE ASSY - MID OUTER	CF6-50 (Boeing)	AR	1
9079M75G07	CASE ASSY - MID OUTER	CF6-50 (Boeing)	AR	1
9080M27P04	SHAFT - FAN FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M27P04	SHAFT - FAN FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M27P04	SHAFT - FAN FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M27P04	SHAFT - FAN FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M27P04	SHAFT - FAN FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M27P04	SHAFT - FAN FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M27P04	SHAFT - FAN FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M27P04	SHAFT - FAN FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M28G10	SHAFT ASSY - FAN FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M28G10	SHAFT ASSY - FAN FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M38G02	SUPPORT ASSY - LP TURB NOZ	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M38G02	SUPPORT ASSY - LP TURB NOZ	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M38G02	SUPPORT ASSY - LP TURB NOZ	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M38G02	SUPPORT ASSY - LP TURB NOZ	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M38G02	SUPPORT ASSY - LP TURB NOZ	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M67P01	SEAL - SEGMENTED FWD	CF6-50	NE	3
9080M67P01	SEAL - SEGMENTED FWD	CF6-50	SV	3
9080M67P01	SEAL - SEGMENTED FWD	CF6-50	AR	6
9080M67P01	SEAL - SEGMENTED FWD	CF6-50	AR	6

Part Number	Part Description	Engine Type	Condition	Quantity
9080M83G04	SEAL ASSY - AFT INNER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	12
9080M89G03	MANIFOLD ASSY - A SUMP VENT	CF6-50	AR	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9080M96G02	BRACKET ASSY - ACTUATOR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9081M10G08	DAMPER ASSY - HPTR STG 2	CF6-80A, CF6-50 (LMCO)	OH	1
9081M10G08	DAMPER ASSY - HPTR STG 2	CF6-80A, CF6-50 (LMCO)	OH	2
9081M10G08	DAMPER ASSY - HPTR STG 2	CF6-80A, CF6-50 (LMCO)	AR	7
9081M10G08	DAMPER ASSY - HPTR STG 2	CF6-80A, CF6-50 (LMCO)	OH	1
9081M10G08	DAMPER ASSY - HPTR STG 2	CF6-80A, CF6-50 (LMCO)	OH	1
9081M11P02	DAMPER - HPTR STG 2 (SPD)	CF6-80A, CF6-50	NE	3
9081M11P02	DAMPER - HPTR STG 2 (SPD)	CF6-80A, CF6-50	NE	1
9081M11P02	DAMPER - HPTR STG 2 (SPD)	CF6-80A, CF6-50	NE	1
9081M11P02	DAMPER - HPTR STG 2 (SPD)	CF6-80A, CF6-50	NE	1
9081M11P02	DAMPER - HPTR STG 2 (SPD)	CF6-80A, CF6-50	NE	9
9081M11P02	DAMPER - HPTR STG 2 (SPD)	CF6-80A, CF6-50	NS	1
9081M11P02	DAMPER - HPTR STG 2 (SPD)	CF6-80A, CF6-50	NS	49
9081M11P02	DAMPER - HPTR STG 2 (SPD)	CF6-80A, CF6-50	NS	10
9081M35P03	BUMPER - BRG 8	CF6-50	AR	1
9081M35P03	BUMPER - BRG 8	CF6-50	AR	1
9081M35P03	BUMPER - BRG 8	CF6-50	AR	1
9081M40G10	DUCT	CF6-50	AR	1
9081M40G11	DUCT	CF6-50	AR	1
9081M45P01	DISK - HPC STG 2	CF6-50	OH	1
9081M45P02	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9081M45P02	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9081M45P02	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M45P02	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M45P02	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M45P02	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M45P02	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M45P02	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M45P02	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M45P02	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M45P02	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M45P02	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M45P02	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M45P02	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M45P02	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M45P02	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M45P05	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M45P05	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M45P05	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M45P05	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M45P05	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M45P05	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M45P05	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9081M45P05	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9081M45P05	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M45P05	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M45P05	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M45P05	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M45P05	DISK - HPC STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M53P08	BLADE - FAN STG 1	CF6-50	AR	1
9081M63P02	CAP - STRUT NO. 3	CF6-50	AR	1
9081M64P04	CAP - STRUT NO. 1	CF6-50	OH	1
9081M64P04	CAP - STRUT NO. 1	CF6-50	AR	1
9081M64P04	CAP - STRUT NO. 1	CF6-50	AR	1
9081M64P04	CAP - STRUT NO. 1	CF6-50	AR	1
9081M69P01	BEARING - NO. 5 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M69P01	BEARING - NO. 5 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M69P01	BEARING - NO. 5 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M69P01	BEARING - NO. 5 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M69P01	BEARING - NO. 5 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M69P01	BEARING - NO. 5 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M69P01	BEARING - NO. 5 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M69P01	BEARING - NO. 5 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M69P01	BEARING - NO. 5 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M69P01	BEARING - NO. 5 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M69P01	BEARING - NO. 5 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M69P01	BEARING - NO. 5 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M69P01	BEARING - NO. 5 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M69P01	BEARING - NO. 5 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M69P01	BEARING - NO. 5 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M69P01	BEARING - NO. 5 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M69P01	BEARING - NO. 5 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9081M69P01	BEARING - NO. 5 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M69P01	BEARING - NO. 5 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M69P01	BEARING - NO. 5 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M69P01	BEARING - NO. 5 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M69P01	BEARING - NO. 5 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M69P01	BEARING - NO. 5 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M81P01	SLEEVE - THREADED	CF6-50 (LMCO)	OH	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P01	PLATE - BRG NO. 5 LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M82P03	PLATE - LOCK #5 BEARING	CF6-50	AR	1
9081M92G07	DUCT ASSY - MID FAN	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M92G07	DUCT ASSY - MID FAN	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M92G07	DUCT ASSY - MID FAN	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M92G07	DUCT ASSY - MID FAN	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M92G07	DUCT ASSY - MID FAN	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9081M92G07	DUCT ASSY - MID FAN	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9082M47P02	COVER - FAN SPEED SENSOR	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9082M49G03	BRACKET ASSY - HOLD OPEN	CF6-50	NE	1
9082M71P01	KEY - CPRSR STTR CASING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9082M71P01	KEY - CPRSR STTR CASING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9082M71P01	KEY - CPRSR STTR CASING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9-114-05	TRANSMITTER - FUEL FLOW	CF6-50 (Boeing)	AR	1
9-114-05	TRANSMITTER - FUEL FLOW	CF6-50 (Boeing)	AR	1
9-114-05	TRANSMITTER - FUEL FLOW	CF6-50 (Boeing)	AR	1
9-114-06	TRANSMITTER - FUEL FLOW	CF6-50 (LMCO)	AR	1
9-114-06	TRANSMITTER - FUEL FLOW	CF6-50 (LMCO)	AR	1
9-114-06	TRANSMITTER - FUEL FLOW	CF6-50 (LMCO)	AR	1
9-114-06	TRANSMITTER - FUEL FLOW	CF6-50 (LMCO)	SV	1
9082M71P02	KEY - CPRSR STTR CASING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9082M71P02	KEY - CPRSR STTR CASING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9082M71P02	KEY - CPRSR STTR CASING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9082M71P02	KEY - CPRSR STTR CASING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9082M71P02	KEY - CPRSR STTR CASING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9082M71P02	KEY - CPRSR STTR CASING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9082M71P02	KEY - CPRSR STTR CASING	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9082M86P01	SEAL - MID FRAME	CF6-50	OH	1
9082M94G02	SUPPORT ASSY - NOZZLE STG 1	CF6-50	AR	1
9082M94G09	SUPPORT ASSY - STG 1 NOZZLE	CF6-50	OH	1
9082M94G09	SUPPORT ASSY - STG 1 NOZZLE	CF6-50	OH	1
9082M94G10	SUPPORT ASSY - STG 1 NOZZLE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9082M99G04	SEAL ASSY - 4B BRG AFT AIR	CF6-50 (Boeing)	AR	1
9082M99G04	SEAL ASSY - 4B BRG AFT AIR	CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9082M99G04	SEAL ASSY - 4B BRG AFT AIR	CF6-50 (Boeing)	AR	1
9082M99G07	SEAL ASSY - 4B BRG AFT AIR	CF6-50	AR	1
9082M99G12	SEAL ASSY - 4B BRG AFT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9082M99G14	SEAL ASSY - 4B BRG AFT AIR	CF6-50 (Boeing)	AR	1
9083M15P02	SEAL - ROT AIR BRG NO. 4	CF6-50	AR	1
9083M15P02	SEAL - ROT AIR BRG NO. 4	CF6-50	AR	1
9083M15P02	SEAL - ROT AIR BRG NO. 4	CF6-50	AR	1
9083M15P02	SEAL - ROT AIR BRG NO. 4	CF6-50	AR	1
9083M15P02	SEAL - ROT AIR BRG NO. 4	CF6-50	AR	1
9083M15P02	SEAL - ROT AIR BRG NO. 4	CF6-50	AR	1
9083M16P01	SUPPORT - BRG 4R AIR SEAL	CF6-50	AR	1
9083M16P03	SUPPORT - BRG 4R AIR SEAL	CF6-50	AR	1
9083M16P03	SUPPORT - BRG 4R AIR SEAL	CF6-50	OH	1
9083M16P03	SUPPORT - BRG 4R AIR SEAL	CF6-50	AR	1
9083M16P03	SUPPORT - BRG 4R AIR SEAL	CF6-50	AR	1
9083M16P03	SUPPORT - BRG 4R AIR SEAL	CF6-50	AR	1
9083M19P06	RETAINER - STG 3 LP TURB	CF6-50 (LMCO), CF6-50 (Boeing)	NE	66
9083M19P08	RETAINER - STG 4 LP TURB	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9083M19P08	RETAINER - STG 4 LP TURB	CF6-50 (LMCO), CF6-50 (Boeing)	NS	3
9083M19P08	RETAINER - STG 4 LP TURB	CF6-50 (LMCO), CF6-50 (Boeing)	NE	15
9083M19P08	RETAINER - STG 4 LP TURB	CF6-50 (LMCO), CF6-50 (Boeing)	NS	4
9083M19P08	RETAINER - STG 4 LP TURB	CF6-50 (LMCO), CF6-50 (Boeing)	NS	4
9083M19P08	RETAINER - STG 4 LP TURB	CF6-50 (LMCO), CF6-50 (Boeing)	NS	3
9083M19P08	RETAINER - STG 4 LP TURB	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9083M19P08	RETAINER - STG 4 LP TURB	CF6-50 (LMCO), CF6-50 (Boeing)	NS	3
9083M19P08	RETAINER - STG 4 LP TURB	CF6-50 (LMCO), CF6-50 (Boeing)	NS	4
9083M19P08	RETAINER - STG 4 LP TURB	CF6-50 (LMCO), CF6-50 (Boeing)	NE	5

Part Number	Part Description	Engine Type	Condition	Quantity
9083M19P08	RETAINER - STG 4 LP TURB	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9083M19P08	RETAINER - STG 4 LP TURB	CF6-50 (LMCO), CF6-50 (Boeing)	NS	3
9083M19P08	RETAINER - STG 4 LP TURB	CF6-50 (LMCO), CF6-50 (Boeing)	NE	54
9083M19P08	RETAINER - STG 4 LP TURB	CF6-50 (LMCO), CF6-50 (Boeing)	NE	3
9083M19P08	RETAINER - STG 4 LP TURB	CF6-50 (LMCO), CF6-50 (Boeing)	NS	39
9083M19P08	RETAINER - STG 4 LP TURB	CF6-50 (LMCO), CF6-50 (Boeing)	NE	4
9083M19P08	RETAINER - STG 4 LP TURB	CF6-50 (LMCO), CF6-50 (Boeing)	NE	3
9083M19P08	RETAINER - STG 4 LP TURB	CF6-50 (LMCO), CF6-50 (Boeing)	NE	6
9083M19P08	RETAINER - STG 4 LP TURB	CF6-50 (LMCO), CF6-50 (Boeing)	NS	4
9083M19P08	RETAINER - STG 4 LP TURB	CF6-50 (LMCO), CF6-50 (Boeing)	NE	18
9083M19P08	RETAINER - STG 4 LP TURB	CF6-50 (LMCO), CF6-50 (Boeing)	NS	4
9083M19P08	RETAINER - STG 4 LP TURB	CF6-50 (LMCO), CF6-50 (Boeing)	NE	4
9083M19P09	RETAINER - STG 3 LP TURB	CF6-50	NE	38
9083M92G02	SHIELD ASSY - OIL SEAL HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9083M92G02	SHIELD ASSY - OIL SEAL HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9083M92G02	SHIELD ASSY - OIL SEAL HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9083M92G02	SHIELD ASSY - OIL SEAL HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9083M92G02	SHIELD ASSY - OIL SEAL HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9083M92G02	SHIELD ASSY - OIL SEAL HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9083M92G02	SHIELD ASSY - OIL SEAL HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9083M92G02	SHIELD ASSY - OIL SEAL HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9083M92G02	SHIELD ASSY - OIL SEAL HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9083M92G02	SHIELD ASSY - OIL SEAL HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9083M92G02	SHIELD ASSY - OIL SEAL HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9083M92G02	SHIELD ASSY - OIL SEAL HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9083M92G02	SHIELD ASSY - OIL SEAL HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9083M92G02	SHIELD ASSY - OIL SEAL HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9083M92G02	SHIELD ASSY - OIL SEAL HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9083M92G02	SHIELD ASSY - OIL SEAL HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9083M92G02	SHIELD ASSY - OIL SEAL HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9083M92G02	SHIELD ASSY - OIL SEAL HEAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9084M24P02	MOUNT - ACTN LEVER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9084M24P02	MOUNT - ACTN LEVER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9084M24P02	MOUNT - ACTN LEVER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9084M71P02	SEAL - AFT OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9084M71P02	SEAL - AFT OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9084M71P02	SEAL - AFT OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9084M71P02	SEAL - AFT OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9084M71P02	SEAL - AFT OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9084M71P02	SEAL - AFT OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9084M71P02	SEAL - AFT OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9084M71P02	SEAL - AFT OUTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9084M81P03	SUPPORT - STTR SHRD STG 1	CF6-50	AR	24
9084M81P03	SUPPORT - STTR SHRD STG 1	CF6-50	AR	24
9084M81P03	SUPPORT - STTR SHRD STG 1	CF6-50	AR	1
9084M81P03	SUPPORT - STTR SHRD STG 1	CF6-50	AR	15
9084M81P03	SUPPORT - STTR SHRD STG 1	CF6-50	AR	7
9085M84G02	NUT ASSY - GANG CHANNEL	CF6-50	NE	1

Part Number	Part Description	Engine Type	Condition	Quantity
90G222	SWITCH - PRESS	CF6-80A	AR	1
90G222	SWITCH - PRESS	CF6-80A	AR	1
9100M30G12	TANK ASSY - OIL	CF6-50 (Boeing)	AR	1
9100M30G12	TANK ASSY - OIL	CF6-50 (Boeing)	AR	1
9100M30G12	TANK ASSY - OIL	CF6-50 (Boeing)	AR	1
9100M30G12	TANK ASSY - OIL	CF6-50 (Boeing)	SV	1
9100M30G13	TANK ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9100M30G13	TANK ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9100M30G13	TANK ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9100M30G13	TANK ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9100M30G13	TANK ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9100M30G13	TANK ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9100M30G13	TANK ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9100M30G13	TANK ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9100M30G13	TANK ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9100M30G13	TANK ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9100M30G13	TANK ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9100M30G13	TANK ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9100M30G13	TANK ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9100M30G13	TANK ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9101M71P02	CAP - SLEEVE	CF6-50	NE	1
9101M71P02	CAP - SLEEVE	CF6-50	NS	1
9103M46P01	PLUG - INSTM TURB MID FR	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9103M46P01	PLUG - INSTM TURB MID FR	CF6-50 (LMCO), CF6-50 (Boeing)	SV	2
9103M46P01	PLUG - INSTM TURB MID FR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9103M46P01	PLUG - INSTM TURB MID FR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9103M46P01	PLUG - INSTM TURB MID FR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
9103M46P01	PLUG - INSTM TURB MID FR	CF6-50 (LMCO), CF6-50 (Boeing)	SV	4

Part Number	Part Description	Engine Type	Condition	Quantity
9103M46P01	PLUG - INSTM TURB MID FR	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9103M46P01	PLUG - INSTM TURB MID FR	CF6-50 (LMCO), CF6-50 (Boeing)	SV	4
9103M46P01	PLUG - INSTM TURB MID FR	CF6-50 (LMCO), CF6-50 (Boeing)	SV	4
9103M46P01	PLUG - INSTM TURB MID FR	CF6-50 (LMCO), CF6-50 (Boeing)	NS	8
9103M46P01	PLUG - INSTM TURB MID FR	CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9103M85G02	PLUG ASSY - BORESCOPE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9103M85G02	PLUG ASSY - BORESCOPE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9104M49P03	TUBE - HP TURB NOZ CLG AIR	CF6-50 (LMCO), CF6-50 (Boeing)	NE	3
9105M60G01	NOZZLE ASSY - EXHAUST	CF6-50 (LMCO)	OH	1
9105M60G01	NOZZLE ASSY - EXHAUST	CF6-50 (LMCO)	SV	1
9105M60G02	NOZZLE ASSY - EXHAUST	CF6-50 (LMCO)	SV	1
9105M64G01	CASE ASSY - FAN FRAME AND	CF6-50	AR	1
9105M90G08	NOZZLE ASSY - EXHAUST	CF6-50 (Boeing)	AR	1
9106M23P02	PLUG - MACH THD	CF6-50	NE	1
9106M37P03	SEAL - FWD	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	5
9106M38P02	RETAINER - SEAL	CF6-50 (LMCO)	NS	1
9106M40P02	SEAL - VALVE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	8
9106M53P01	REDUCER - TUBE	CF6-50 (LMCO)	NE	1
9106M53P01	REDUCER - TUBE	CF6-50 (LMCO)	SV	1
9106M66P03	LPT ROTOR RETAINING RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9106M66P03	LPT ROTOR RETAINING RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9106M66P03	LPT ROTOR RETAINING RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9106M66P03	LPT ROTOR RETAINING RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9106M66P04	LPT ROTOR RETAINING RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9106M66P04	LPT ROTOR RETAINING RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9106M66P04	LPT ROTOR RETAINING RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9106M66P04	LPT ROTOR RETAINING RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9107M15P01	REDUCER - TUBE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	3
9107M15P02	REDUCER - TUBE	CF6-80C2	NS	2
9107M15P02	REDUCER - TUBE	CF6-80C2	NE	2
9107M15P02	REDUCER - TUBE	CF6-80C2	NE	2
9107M53P01	PLUG - T3 SENSOR CRF	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9107M53P01	PLUG - T3 SENSOR CRF	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9107M82P01	SPACER	CF6-50	NS	1
9107M82P01	SPACER	CF6-50	NS	1
9107M92G01	NUT ASSY - SLFLKG	CF6-50 (Boeing)	NE	5
9109M42P01	COVER - BORESCOPE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9109M42P01	COVER - BORESCOPE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9109M86P01	PLUG - MACH THD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9109M86P01	PLUG - MACH THD	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9109M86P01	PLUG - MACH THD	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9109M86P01	PLUG - MACH THD	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9109M86P01	PLUG - MACH THD	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9109M86P01	PLUG - MACH THD	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9111M92G01	NUT ASSY - GANG CHANNEL	CF6-80A, CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9113M98G01	COVER ASSY - T2 SENSOR	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9113M98G01	COVER ASSY - T2 SENSOR	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9113M98G01	COVER ASSY - T2 SENSOR	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9114M13P01	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	SV	196
9114M13P01	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9114M13P01	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	150
9114M13P01	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	173
9114M13P01	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
9114M13P01	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	9
9114M13P01	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	33
9114M13P01	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	9
9114M13P01	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	22
9114M13P01	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	5
9114M13P01	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NE	22
9114M13P01	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	25
9114M13P01	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	30
9114M28P03	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	24
9114M28P03	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	14
9114M28P03	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	53
9114M28P03	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	77
9114M28P03	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	80
9114M28P03	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	25
9114M28P03	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9114M28P03	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	54
9114M28P03	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	80

Part Number	Part Description	Engine Type	Condition	Quantity
9114M28P03	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
9114M28P03	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	3
9114M28P03	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	25
9115M16P04	RETAINER - NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	24
9115M16P04	RETAINER - NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	38
9115M16P04	RETAINER - NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	23
9115M16P04	RETAINER - NUT	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	23
9115M18P132	FLANGE - TUBE	CF6-50	NS	1
9115M71P01	SLEEVE - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	40
9115M71P01	SLEEVE - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	46
9115M71P01	SLEEVE - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	8
9115M71P01	SLEEVE - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9115M71P01	SLEEVE - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	2
9115M71P01	SLEEVE - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9115M71P01	SLEEVE - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	3
9115M71P01	SLEEVE - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	46
9115M71P01	SLEEVE - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9115M71P01	SLEEVE - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	6
9115M71P01	SLEEVE - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	18
9115M71P01	SLEEVE - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9115M71P01	SLEEVE - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9115M71P01	SLEEVE - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	7
9115M71P01	SLEEVE - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	16
9115M71P01	SLEEVE - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	42
9115M71P01	SLEEVE - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	3
9116M14P01	SPACER	CF6-80A, CF6-50 (LMCO)	NS	1
9116M14P01	SPACER	CF6-80A, CF6-50 (LMCO)	NS	2
9118M10G01	TUBE - DR CAN PUMP/VALVE FUEL	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9118M43G01	MANIFOLD ASSY - AIR IGN CLG	CF6-50	AR	1
9118M43G01	MANIFOLD ASSY - AIR IGN CLG	CF6-50	AR	1
9118M43G01	MANIFOLD ASSY - AIR IGN CLG	CF6-50	AR	1
9118M43G01	MANIFOLD ASSY - AIR IGN CLG	CF6-50	AR	1
9118M43G01	MANIFOLD ASSY - AIR IGN CLG	CF6-50	AR	1
9118M43G01	MANIFOLD ASSY - AIR IGN CLG	CF6-50	AR	1
9118M43G01	MANIFOLD ASSY - AIR IGN CLG	CF6-50	AR	1
9118M43G01	MANIFOLD ASSY - AIR IGN CLG	CF6-50	AR	1
9118M43G01	MANIFOLD ASSY - AIR IGN CLG	CF6-50	AR	1
9118M43G01	MANIFOLD ASSY - AIR IGN CLG	CF6-50	AR	1
9118M43G01	MANIFOLD ASSY - AIR IGN CLG	CF6-50	AR	1
9118M43G01	MANIFOLD ASSY - AIR IGN CLG	CF6-50	AR	1
9118M57G01	BRACKET ASSY - SCUPPER	CF6-50	NS	1
9118M57G01	BRACKET ASSY - SCUPPER	CF6-50	AR	1
9118M73G01	MANIFOLD ASSY - LP RECOUP	CF6-50 (Boeing)	AR	1
9118M73G01	MANIFOLD ASSY - LP RECOUP	CF6-50 (Boeing)	AR	1
9118M73G01	MANIFOLD ASSY - LP RECOUP	CF6-50 (Boeing)	AR	1
9118M73G01	MANIFOLD ASSY - LP RECOUP	CF6-50 (Boeing)	AR	1
9118M74G01	TUBE ASSY - B SUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M74G01	TUBE ASSY - B SUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M74G01	TUBE ASSY - B SUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M74G01	TUBE ASSY - B SUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M74G01	TUBE ASSY - B SUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M74G01	TUBE ASSY - B SUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M74G01	TUBE ASSY - B SUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9118M74G01	TUBE ASSY - B SUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M74G01	TUBE ASSY - B SUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M74G01	TUBE ASSY - B SUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M74G01	TUBE ASSY - B SUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M74G01	TUBE ASSY - B SUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M74G01	TUBE ASSY - B SUMP	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9118M74G01	TUBE ASSY - B SUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M75G02	BELLCRANK ASSY - VAR BYP V	CF6-50	NS	1
9118M76G01	BELLCRANK ASSY - VAR BYP V	CF6-50	NE	1
9118M76G01	BELLCRANK ASSY - VAR BYP V	CF6-50	AR	1
9118M81G01	BRACKET ASSY - LP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M81G01	BRACKET ASSY - LP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M81G01	BRACKET ASSY - LP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9118M81G01	BRACKET ASSY - LP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9118M81G02	BRACKET ASSY - LP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9118M92G01	TUBE ASSY - PYLON CDP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M92G01	TUBE ASSY - PYLON CDP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M92G01	TUBE ASSY - PYLON CDP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M92G01	TUBE ASSY - PYLON CDP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M92G01	TUBE ASSY - PYLON CDP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M92G01	TUBE ASSY - PYLON CDP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M92G01	TUBE ASSY - PYLON CDP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M92G01	TUBE ASSY - PYLON CDP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M92G01	TUBE ASSY - PYLON CDP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M92G01	TUBE ASSY - PYLON CDP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9118M92G01	TUBE ASSY - PYLON CDP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M92G01	TUBE ASSY - PYLON CDP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M92G01	TUBE ASSY - PYLON CDP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M92G01	TUBE ASSY - PYLON CDP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M92G01	TUBE ASSY - PYLON CDP AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M95G01	BRACKET ASSY - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M95G01	BRACKET ASSY - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9118M95G01	BRACKET ASSY - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9118M99G03	BRACKET - TRANSDUCER	CF6-50	AR	1
9119M60P32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9119M60P32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9119M60P32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9119M60P32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9119M60P32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9119M60P32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9119M60P32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9119M60P32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9119M60P32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9119M60P32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9119M60P32	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9119M60P33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9119M60P33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9119M60P33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9119M60P33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9119M60P33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9119M60P33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9119M60P33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9119M60P33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9119M60P33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9119M60P33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9119M60P33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9119M60P33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9119M60P33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9119M60P33	NOZZLE - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9120M16P001A	BRACKET - TUBE	CF6-50 (LMCO)	AR	1
9120M16P001A	BRACKET - TUBE	CF6-50 (LMCO)	AR	1
9120M37G03	BRACKET ASSY - C SUMP	CF6-50 (Boeing)	AR	1
9120M37G03	BRACKET ASSY - C SUMP	CF6-50 (Boeing)	AR	1
9120M37G03	BRACKET ASSY - C SUMP	CF6-50 (Boeing)	OH	1
9120M43G02	MANIFOLD ASSY - FUEL ROD	CF6-50	AR	1
9120M43G02	MANIFOLD ASSY - FUEL ROD	CF6-50	AR	1
9120M43G03	MANIFOLD ASSY - FUEL ROD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9120M43G03	MANIFOLD ASSY - FUEL ROD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9120M43G03	MANIFOLD ASSY - FUEL ROD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9120M43G03	MANIFOLD ASSY - FUEL ROD	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9120M43G03	MANIFOLD ASSY - FUEL ROD	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9120M43G03	MANIFOLD ASSY - FUEL ROD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9120M43G03	MANIFOLD ASSY - FUEL ROD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9120M43G03	MANIFOLD ASSY - FUEL ROD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9120M48P01	BRACKET ASSY - IGN CA	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9120M48P01	BRACKET ASSY - IGN CA	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9120M48P01	BRACKET ASSY - IGN CA	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9120M48P01	BRACKET ASSY - IGN CA	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9120M48P01	BRACKET ASSY - IGN CA	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9120M89G01	BRACKET - IGN CABLE	CF6-50	AR	1
9120M89G01	BRACKET - IGN CABLE	CF6-50	SV	1
9120M89G01	BRACKET - IGN CABLE	CF6-50	AR	1
9121M13G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M13G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M13G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M13G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M13G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9121M13G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M13G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M13G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M13G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M13G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9121M13G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M13G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M13G01	TUBE ASSY - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M42G01	TUBE ASSY - UPR FWD HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M42G01	TUBE ASSY - UPR FWD HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M42G01	TUBE ASSY - UPR FWD HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M42G01	TUBE ASSY - UPR FWD HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M42G01	TUBE ASSY - UPR FWD HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9121M42G01	TUBE ASSY - UPR FWD HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9121M42G02	TUBE ASSY - UPR FWD HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M42G02	TUBE ASSY - UPR FWD HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M42G02	TUBE ASSY - UPR FWD HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M42G02	TUBE ASSY - UPR FWD HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M42G02	TUBE ASSY - UPR FWD HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M42G02	TUBE ASSY - UPR FWD HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M42G02	TUBE ASSY - UPR FWD HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9121M42G02	TUBE ASSY - UPR FWD HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9121M42G02	TUBE ASSY - UPR FWD HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M42G02	TUBE ASSY - UPR FWD HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M42G03	TUBE ASSY - UPR FWD HPT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M68G01	BRACKET ASSY - FWD TUBE BDL	CF6-50 (Boeing)	AR	1
9121M69G07	BRACKET ASSY - AFT TUBE BDL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M69G07	BRACKET ASSY - AFT TUBE BDL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M69G07	BRACKET ASSY - AFT TUBE BDL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M69G07	BRACKET ASSY - AFT TUBE BDL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9121M69G07	BRACKET ASSY - AFT TUBE BDL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9122M11G01	MANIFOLD - DRAIN CAN PUMP	CF6-50 (LMCO)	AR	1
9122M11G01	MANIFOLD - DRAIN CAN PUMP	CF6-50 (LMCO)	AR	1
9122M11G01	MANIFOLD - DRAIN CAN PUMP	CF6-50 (LMCO)	AR	1
9122M11G01	MANIFOLD - DRAIN CAN PUMP	CF6-50 (LMCO)	AR	1
9122M11G01	MANIFOLD - DRAIN CAN PUMP	CF6-50 (LMCO)	AR	1
9122M11G01	MANIFOLD - DRAIN CAN PUMP	CF6-50 (LMCO)	AR	1
9122M11G01	MANIFOLD - DRAIN CAN PUMP	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9122M11G01	MANIFOLD - DRAIN CAN PUMP	CF6-50 (LMCO)	AR	1
9122M12G01	TUBE - DR CAN PUMP/VALVE	CF6-50 (LMCO)	AR	1
9122M12G01	TUBE - DR CAN PUMP/VALVE	CF6-50 (LMCO)	OH	1
9122M12G01	TUBE - DR CAN PUMP/VALVE	CF6-50 (LMCO)	OH	1
9122M12G01	TUBE - DR CAN PUMP/VALVE	CF6-50 (LMCO)	AR	1
9122M12G01	TUBE - DR CAN PUMP/VALVE	CF6-50 (LMCO)	AR	1
9122M12G01	TUBE - DR CAN PUMP/VALVE	CF6-50 (LMCO)	AR	1
9122M12G01	TUBE - DR CAN PUMP/VALVE	CF6-50 (LMCO)	AR	1
9122M15G01	TUBE - AIR PS3	CF6-50	AR	1
9122M15G01	TUBE - AIR PS3	CF6-50	AR	1
9122M19G01	TUBE - AIR	CF6-50	AR	1
9122M19G01	TUBE - AIR	CF6-50	AR	1
9122M61P01	BRACKET - LS MID TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9122M61P01	BRACKET - LS MID TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9122M61P01	BRACKET - LS MID TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9122M61P01	BRACKET - LS MID TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9122M74G01	BRACKET ASSY	CF6-50	AR	1
9122M74G01	BRACKET ASSY	CF6-50	AR	1
9122M74G01	BRACKET ASSY	CF6-50	AR	1
9122M75G01	BRACKET ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9122M75G01	BRACKET ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9122M77G01	BRACKET ASSY	CF6-50 (Boeing)	AR	1
9122M77G01	BRACKET ASSY	CF6-50 (Boeing)	AR	1
9122M77G01	BRACKET ASSY	CF6-50 (Boeing)	NS	1
9122M77G01	BRACKET ASSY	CF6-50 (Boeing)	NS	1
9122M77G01	BRACKET ASSY	CF6-50 (Boeing)	OH	1
9122M90G01	TUBE ASSY - AIR	CF6-50	AR	1
9122M94G01	BRACKET ASSY	CF6-50 (LMCO)	AR	1
9122M94G01	BRACKET ASSY	CF6-50 (LMCO)	SV	1
9124M20G01	BRACKET ASSY	CF6-50	AR	1
9124M20G01	BRACKET ASSY	CF6-50	NS	1
9124M20G01	BRACKET ASSY	CF6-50	NS	2
9124M55G01	BRACKET ASSY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9125M65G05	ARM ASSY - VANE ACTN STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	46
9125M65G05	ARM ASSY - VANE ACTN STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	24
9125M65G05	ARM ASSY - VANE ACTN STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	9
9125M65G05	ARM ASSY - VANE ACTN STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9125M65G05	ARM ASSY - VANE ACTN STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	50
9125M65G05	ARM ASSY - VANE ACTN STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9125M65G05	ARM ASSY - VANE ACTN STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
9125M65G06	ARM ASSY - VANE ACTN STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
9125M65G06	ARM ASSY - VANE ACTN STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
9125M65G06	ARM ASSY - VANE ACTN STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
9125M65G06	ARM ASSY - VANE ACTN STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
9125M65G06	ARM ASSY - VANE ACTN STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	8

Part Number	Part Description	Engine Type	Condition	Quantity
9125M65G06	ARM ASSY - VANE ACTN STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
9125M65G06	ARM ASSY - VANE ACTN STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
9125M65G06	ARM ASSY - VANE ACTN STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	8
9125M65G06	ARM ASSY - VANE ACTN STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	28
9125M65G14	HPC STATOR ACT ARM STG 5 [SPLITLINE]	CF6-80C2	NE	4
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	SV	48
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	SV	50
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	OH	1
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	OH	1
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	OH	48
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	AR	50
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	AR	50
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	OH	50
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	OH	50
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	OH	49
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	AR	52
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	OH	50
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	OH	2
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	OH	50
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	OH	50
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	OH	46

Part Number	Part Description	Engine Type	Condition	Quantity
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	OH	50
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	OH	50
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	OH	36
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	OH	50
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	OH	49
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	OH	50
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	OH	2
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	OH	49
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	OH	50
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	NE	4
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	NE	45
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	NE	1
9125M65G17	HPC STATOR ACT ARM STG 5	CF6-80C2	NE	3
9125M65G18	HPC STATOR ACT ARM STG 5 [SPLITLINE]	CF6-80C2	AR	8
9125M65G18	HPC STATOR ACT ARM STG 5 [SPLITLINE]	CF6-80C2	AR	8
9125M65G18	HPC STATOR ACT ARM STG 5 [SPLITLINE]	CF6-80C2	AR	8
9125M65G18	HPC STATOR ACT ARM STG 5 [SPLITLINE]	CF6-80C2	OH	8
9125M65G18	HPC STATOR ACT ARM STG 5 [SPLITLINE]	CF6-80C2	OH	8
9125M65G18	HPC STATOR ACT ARM STG 5 [SPLITLINE]	CF6-80C2	OH	8
9125M65G18	HPC STATOR ACT ARM STG 5 [SPLITLINE]	CF6-80C2	OH	1
9125M65G18	HPC STATOR ACT ARM STG 5 [SPLITLINE]	CF6-80C2	OH	6
9125M65G18	HPC STATOR ACT ARM STG 5 [SPLITLINE]	CF6-80C2	OH	8
9125M65G18	HPC STATOR ACT ARM STG 5 [SPLITLINE]	CF6-80C2	OH	8
9125M65G18	HPC STATOR ACT ARM STG 5 [SPLITLINE]	CF6-80C2	OH	8
9125M65G18	HPC STATOR ACT ARM STG 5 [SPLITLINE]	CF6-80C2	OH	8

Part Number	Part Description	Engine Type	Condition	Quantity
9125M65G18	HPC STATOR ACT ARM STG 5 [SPLITLINE]	CF6-80C2	OH	2
9125M65G18	HPC STATOR ACT ARM STG 5 [SPLITLINE]	CF6-80C2	OH	8
9125M65G18	HPC STATOR ACT ARM STG 5 [SPLITLINE]	CF6-80C2	OH	8
9125M65G18	HPC STATOR ACT ARM STG 5 [SPLITLINE]	CF6-80C2	OH	8
9125M65G18	HPC STATOR ACT ARM STG 5 [SPLITLINE]	CF6-80C2	OH	8
9125M65G18	HPC STATOR ACT ARM STG 5 [SPLITLINE]	CF6-80C2	NE	16
9126M25G01	TUBE ASSY - VBV MID	CF6-50 (Boeing)	AR	1
9126M25G01	TUBE ASSY - VBV MID	CF6-50 (Boeing)	AR	1
9126M25G01	TUBE ASSY - VBV MID	CF6-50 (Boeing)	OH	1
9126M25G01	TUBE ASSY - VBV MID	CF6-50 (Boeing)	AR	1
9126M25G01	TUBE ASSY - VBV MID	CF6-50 (Boeing)	AR	1
9126M25G01	TUBE ASSY - VBV MID	CF6-50 (Boeing)	AR	1
9126M25G01	TUBE ASSY - VBV MID	CF6-50 (Boeing)	OH	1
9126M25G01	TUBE ASSY - VBV MID	CF6-50 (Boeing)	AR	1
9126M25G01	TUBE ASSY - VBV MID	CF6-50 (Boeing)	AR	1
9126M25G01	TUBE ASSY - VBV MID	CF6-50 (Boeing)	AR	1
9126M25G01	TUBE ASSY - VBV MID	CF6-50 (Boeing)	AR	1
9126M25G01	TUBE ASSY - VBV MID	CF6-50 (Boeing)	AR	1
9126M34G01	BRACKET ASSY	CF6-50	NE	1
9126M35G01	BRACKET ASSY - D SUMP	CF6-50 (LMCO)	AR	1
9126M35G01	BRACKET ASSY - D SUMP	CF6-50 (LMCO)	AR	1
9126M35G01	BRACKET ASSY - D SUMP	CF6-50 (LMCO)	AR	1
9126M36G01	BRACKET ASSY - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	5
9126M37G01	BRACKET ASSY - D LUBE SPLY	CF6-50 (Boeing)	AR	1
9126M37G01	BRACKET ASSY - D LUBE SPLY	CF6-50 (Boeing)	AR	1
9126M74G01	TUBE ASSY - FUEL FWD ROD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M74G01	TUBE ASSY - FUEL FWD ROD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M74G01	TUBE ASSY - FUEL FWD ROD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M74G01	TUBE ASSY - FUEL FWD ROD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M74G01	TUBE ASSY - FUEL FWD ROD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M74G01	TUBE ASSY - FUEL FWD ROD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M74G01	TUBE ASSY - FUEL FWD ROD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M74G01	TUBE ASSY - FUEL FWD ROD	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
9126M74G01	TUBE ASSY - FUEL FWD ROD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M74G01	TUBE ASSY - FUEL FWD ROD	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9126M74G01	TUBE ASSY - FUEL FWD ROD	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9126M76G01	TUBE ASSY - FUEL FWD HD END	CF6-50	AR	1
9126M76G01	TUBE ASSY - FUEL FWD HD END	CF6-50	AR	1
9126M78G01	MANIFOLD - AIR VBV SIGNAL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9126M78G01	MANIFOLD - AIR VBV SIGNAL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9126M78G01	MANIFOLD - AIR VBV SIGNAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M78G01	MANIFOLD - AIR VBV SIGNAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M78G01	MANIFOLD - AIR VBV SIGNAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M78G01	MANIFOLD - AIR VBV SIGNAL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9126M78G01	MANIFOLD - AIR VBV SIGNAL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9126M78G01	MANIFOLD - AIR VBV SIGNAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M78G01	MANIFOLD - AIR VBV SIGNAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M78G01	MANIFOLD - AIR VBV SIGNAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M89G01	TUBE ASSY - VBV UPPER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M89G01	TUBE ASSY - VBV UPPER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M89G01	TUBE ASSY - VBV UPPER	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9126M89G01	TUBE ASSY - VBV UPPER	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9126M89G01	TUBE ASSY - VBV UPPER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M89G01	TUBE ASSY - VBV UPPER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M89G01	TUBE ASSY - VBV UPPER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M89G01	TUBE ASSY - VBV UPPER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M89G01	TUBE ASSY - VBV UPPER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M89G01	TUBE ASSY - VBV UPPER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
9126M89G01	TUBE ASSY - VBV UPPER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M89G01	TUBE ASSY - VBV UPPER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M89G01	TUBE ASSY - VBV UPPER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M89G01	TUBE ASSY - VBV UPPER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M89G01	TUBE ASSY - VBV UPPER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M89G01	TUBE ASSY - VBV UPPER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M89G01	TUBE ASSY - VBV UPPER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M89G01	TUBE ASSY - VBV UPPER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9126M99P001A	BRACKET - LP TURB CLG MANF	CF6-50 (Boeing)	AR	1
9126M99P001A	BRACKET - LP TURB CLG MANF	CF6-50 (Boeing)	AR	1
9126M99P001A	BRACKET - LP TURB CLG MANF	CF6-50 (Boeing)	AR	1
9126M99P001A	BRACKET - LP TURB CLG MANF	CF6-50 (Boeing)	SV	1
9126M99P001A	BRACKET - LP TURB CLG MANF	CF6-50 (Boeing)	SV	1
9126M99P001A	BRACKET - LP TURB CLG MANF	CF6-50 (Boeing)	OH	1
9126M99P001A	BRACKET - LP TURB CLG MANF	CF6-50 (Boeing)	OH	1
9126M99P001A	BRACKET - LP TURB CLG MANF	CF6-50 (Boeing)	OH	1
9126M99P001A	BRACKET - LP TURB CLG MANF	CF6-50 (Boeing)	OH	1
9126M99P001A	BRACKET - LP TURB CLG MANF	CF6-50 (Boeing)	OH	1
9126M99P001A	BRACKET - LP TURB CLG MANF	CF6-50 (Boeing)	OH	1
9126M99P001A	BRACKET - LP TURB CLG MANF	CF6-50 (Boeing)	OH	1
9127M12G08	SUMP ASSY - TURB MID FR	CF6-50	AR	1
9127M12G08	SUMP ASSY - TURB MID FR	CF6-50	AR	1
9127M12G08	SUMP ASSY - TURB MID FR	CF6-50	AR	1
9127M12G08	SUMP ASSY - TURB MID FR	CF6-50	AR	1
9127M12G08	SUMP ASSY - TURB MID FR	CF6-50	AR	1
9127M12G09	SUMP ASSY - TURB MID FR	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9127M24P01	BAFFLE - AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9127M24P01	BAFFLE - AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9127M24P01	BAFFLE - AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9127M27P01	SEAL - BRG NO 6 AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M27P01	SEAL - BRG NO 6 AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M27P01	SEAL - BRG NO 6 AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M27P01	SEAL - BRG NO 6 AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M27P01	SEAL - BRG NO 6 AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M27P01	SEAL - BRG NO 6 AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M27P01	SEAL - BRG NO 6 AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M27P01	SEAL - BRG NO 6 AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M27P01	SEAL - BRG NO 6 AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M27P01	SEAL - BRG NO 6 AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M27P01	SEAL - BRG NO 6 AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M27P01	SEAL - BRG NO 6 AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M27P01	SEAL - BRG NO 6 AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M27P01	SEAL - BRG NO 6 AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M27P01	SEAL - BRG NO 6 AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M27P01	SEAL - BRG NO 6 AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M27P01	SEAL - BRG NO 6 AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M27P01	SEAL - BRG NO 6 AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9127M27P01	SEAL - BRG NO 6 AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M27P01	SEAL - BRG NO 6 AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M27P01	SEAL - BRG NO 6 AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9127M27P01	SEAL - BRG NO 6 AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9127M27P02	SEAL - BRG NO 6 AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M27P02	SEAL - BRG NO 6 AIR AND OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M28G02	SEAL - AFT VENT NO. 6	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M28G02	SEAL - AFT VENT NO. 6	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M28G02	SEAL - AFT VENT NO. 6	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M28G02	SEAL - AFT VENT NO. 6	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M28G02	SEAL - AFT VENT NO. 6	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M28G02	SEAL - AFT VENT NO. 6	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M28G02	SEAL - AFT VENT NO. 6	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M28G02	SEAL - AFT VENT NO. 6	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M28G02	SEAL - AFT VENT NO. 6	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M28G02	SEAL - AFT VENT NO. 6	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M28G02	SEAL - AFT VENT NO. 6	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M28G02	SEAL - AFT VENT NO. 6	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M28G02	SEAL - AFT VENT NO. 6	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M28G02	SEAL - AFT VENT NO. 6	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M36G05	NUT ASSY - GANG CHAN SLFLKG	CF6-50	NS	1
9127M36G05	NUT ASSY - GANG CHAN SLFLKG	CF6-50	NS	1
9127M36G05	NUT ASSY - GANG CHAN SLFLKG	CF6-50	NS	1
9127M37G02	NUT ASSY - GANG CHANNEL	CF6-50	NS	1
9127M37G02	NUT ASSY - GANG CHANNEL	CF6-50	NE	1
9127M78G02	SUPPORT - FAN REVERSER	CF6-50 (Boeing)	AR	1
9127M78G04	SUPPORT - FAN REVERSER	CF6-50 (Boeing)	AR	1
9127M78G06	SUPPORT - FAN REVERSER	CF6-50 (Boeing)	AR	1
9127M78G07	SUPPORT - FAN REVERSER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9127M79G03	CAP - STRUT NO. 4	CF6-50	OH	1
9127M79G03	CAP - STRUT NO. 4	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9127M89P01	DAMPER - HPTR STG 1 (SPD)	CF6-50 (LMCO)	OH	36
9127M90G01	DAMPER ASSY - HPTR STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	8
9127M90G01	DAMPER ASSY - HPTR STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	80
9127M90G01	DAMPER ASSY - HPTR STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	80
9127M90G01	DAMPER ASSY - HPTR STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	22
9127M90G01	DAMPER ASSY - HPTR STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
9127M90G01	DAMPER ASSY - HPTR STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9127M90G01	DAMPER ASSY - HPTR STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	68
9127M90G01	DAMPER ASSY - HPTR STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	10
9127M90G01	DAMPER ASSY - HPTR STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	80
9127M90G01	DAMPER ASSY - HPTR STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	69
9127M90G01	DAMPER ASSY - HPTR STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	11
9127M90G01	DAMPER ASSY - HPTR STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9127M90G01	DAMPER ASSY - HPTR STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	40
9127M90G01	DAMPER ASSY - HPTR STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	80
9127M90G01	DAMPER ASSY - HPTR STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	80
9127M90G01	DAMPER ASSY - HPTR STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	74

Part Number	Part Description	Engine Type	Condition	Quantity
9127M90G01	DAMPER ASSY - HPTR STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	80
9127M90G01	DAMPER ASSY - HPTR STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	80
9127M90G01	DAMPER ASSY - HPTR STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	79
9127M90G01	DAMPER ASSY - HPTR STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9127M90G01	DAMPER ASSY - HPTR STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9128M35P01	ADAPTER	CF6-50	AR	1
9128M35P01	ADAPTER	CF6-50	AR	1
9128M35P03	CLEVIS	CF6-50	AR	1
9128M47P01	BUMPER - CASE FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	112
9128M47P01	BUMPER - CASE FAN STATOR	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9128M47P02	BUMPER - CASE FAN STATOR	CF6-50 (LMCO)	AR	111
9128M47P02	BUMPER - CASE FAN STATOR	CF6-50 (LMCO)	AR	111
9128M47P02	BUMPER - CASE FAN STATOR	CF6-50 (LMCO)	NS	15
9128M47P02	BUMPER - CASE FAN STATOR	CF6-50 (LMCO)	NE	112
9128M47P02	BUMPER - CASE FAN STATOR	CF6-50 (LMCO)	NE	13
9128M49G01	CAP - STRUT NO. 2	CF6-50	AR	1
9128M52G20	FRAME ASSY - TURBINE MID	CF6-50	OH	1
9128M67G01	CAP - STRUT NO. 8	CF6-50	OH	1
9128M67G01	CAP - STRUT NO. 8	CF6-50	AR	1
9128M72P01	COVER - PAD	CF6-50	AR	1
9128M72P01	COVER - PAD	CF6-50	AR	1
9128M78G02	SEAL ASSY - PRESS BAL STA	CF6-50 (Boeing)	AR	1
9128M78G03	SEAL ASSY - PRESS BAL STA	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M78G03	SEAL ASSY - PRESS BAL STA	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M78G04	SEAL ASSY - PRESS BAL STA	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M78G04	SEAL ASSY - PRESS BAL STA	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9128M78G04	SEAL ASSY - PRESS BAL STA	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M78G04	SEAL ASSY - PRESS BAL STA	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M78G04	SEAL ASSY - PRESS BAL STA	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M78G04	SEAL ASSY - PRESS BAL STA	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M78G04	SEAL ASSY - PRESS BAL STA	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M78G04	SEAL ASSY - PRESS BAL STA	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M78G04	SEAL ASSY - PRESS BAL STA	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M78G04	SEAL ASSY - PRESS BAL STA	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9128M78G04	SEAL ASSY - PRESS BAL STA	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9128M78G04	SEAL ASSY - PRESS BAL STA	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M78G04	SEAL ASSY - PRESS BAL STA	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M79G01	SOCKET - TUBE	CF6-50	AR	1
9128M79G01	SOCKET - TUBE	CF6-50	AR	1
9128M79G01	SOCKET - TUBE	CF6-50	AR	1
9128M79G01	SOCKET - TUBE	CF6-50	AR	1
9128M79G01	SOCKET - TUBE	CF6-50	AR	1
9128M79G01	SOCKET - TUBE	CF6-50	AR	1
9128M79G01	SOCKET - TUBE	CF6-50	AR	1
9128M79G01	SOCKET - TUBE	CF6-50	AR	1
9128M79G01	SOCKET - TUBE	CF6-50	AR	8
9128M80P01	SOCKET - TUBE	CF6-50	OH	4
9128M80P01	SOCKET - TUBE	CF6-50	OH	4
9128M80P01	SOCKET - TUBE	CF6-50	AR	8
9128M81G03	SHAFT ASSY - HPTR REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M81G03	SHAFT ASSY - HPTR REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M81G03	SHAFT ASSY - HPTR REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M81G03	SHAFT ASSY - HPTR REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M81G03	SHAFT ASSY - HPTR REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M81G03	SHAFT ASSY - HPTR REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M81G03	SHAFT ASSY - HPTR REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9128M81G03	SHAFT ASSY - HPTR REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M81G10	SHAFT ASSY - HPTR REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M81G10	SHAFT ASSY - HPTR REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M81G10	SHAFT ASSY - HPTR REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M81G10	SHAFT ASSY - HPTR REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M81G10	SHAFT ASSY - HPTR REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M81G10	SHAFT ASSY - HPTR REAR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M82G01	NOZZLE ASSY - ACCESS GRBX	CF6-50 (Boeing)	OH	1
9128M82G01	NOZZLE ASSY - ACCESS GRBX	CF6-50 (Boeing)	OH	1
9128M93G17	SHAFT ASSY - HPTR REAR	CF6-50	AR	1
9128M94P01	SUPPORT - DUCT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9128M94P01	SUPPORT - DUCT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M94P01	SUPPORT - DUCT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M94P01	SUPPORT - DUCT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M94P01	SUPPORT - DUCT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9128M94P01	SUPPORT - DUCT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M94P01	SUPPORT - DUCT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M94P01	SUPPORT - DUCT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M94P01	SUPPORT - DUCT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9128M94P01	SUPPORT - DUCT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9128M94P01	SUPPORT - DUCT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M94P01	SUPPORT - DUCT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M94P02	SUPPORT - DUCT	CF6-80C2	SV	1
9128M94P02	SUPPORT - DUCT	CF6-80C2	OH	1
9128M95P01	SUPPORT - DUCT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M95P01	SUPPORT - DUCT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M95P01	SUPPORT - DUCT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M95P01	SUPPORT - DUCT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M95P01	SUPPORT - DUCT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9128M95P01	SUPPORT - DUCT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M95P01	SUPPORT - DUCT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M95P01	SUPPORT - DUCT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M95P01	SUPPORT - DUCT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M95P02	SUPPORT - DUCT	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9128M95P02	SUPPORT - DUCT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9128M95P02	SUPPORT - DUCT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M95P02	SUPPORT - DUCT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M95P02	SUPPORT - DUCT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M95P02	SUPPORT - DUCT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M95P02	SUPPORT - DUCT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M95P02	SUPPORT - DUCT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M95P02	SUPPORT - DUCT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9128M95P02	SUPPORT - DUCT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9128M95P02	SUPPORT - DUCT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M95P02	SUPPORT - DUCT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9128M95P03	SUPPORT - DUCT	CF6-80A	OH	1
9128M95P03	SUPPORT - DUCT	CF6-80A	SV	1
9128M95P03	SUPPORT - DUCT	CF6-80A	OH	1
9128M95P04	SUPPORT - DUCT	CF6-80C2	SV	1
9129M34P01	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	4
9129M34P01	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9129M34P01	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	SV	2
9129M34P01	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9129M35G01	BRACKET ASSY - FWD TUBE BDL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9129M35G01	BRACKET ASSY - FWD TUBE BDL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9129M35G01	BRACKET ASSY - FWD TUBE BDL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9129M35G01	BRACKET ASSY - FWD TUBE BDL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9129M35G01	BRACKET ASSY - FWD TUBE BDL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9129M35G01	BRACKET ASSY - FWD TUBE BDL	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9129M35G01	BRACKET ASSY - FWD TUBE BDL	CF6-50 (LMCO), CF6-50 (Boeing)	NE	18
9129M41P001B	PLATE COVER	CF6-50 (LMCO)	NS	1
9129M44G01	BRACKET ASSY	CF6-50 (Boeing)	AR	1
9129M48P001A	BRACKET - FLAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9129M48P001A	BRACKET - FLAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9129M48P005A	BRACKET - FLAT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9129M58G01	BRACKET ASSY - CLG SUPPLY	CF6-50 (LMCO)	SV	1
9129M58G01	BRACKET ASSY - CLG SUPPLY	CF6-50 (LMCO)	AR	1
9129M58G01	BRACKET ASSY - CLG SUPPLY	CF6-50 (LMCO)	AR	1
9129M58G02	BRACKET ASSY - CLG SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9129M58G02	BRACKET ASSY - CLG SUPPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9130M36P240	COUPLING - GROOVED CLAMP	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9130M36P240	COUPLING - GROOVED CLAMP	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9130M36P240	COUPLING - GROOVED CLAMP	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9130M36P40	COUPLING - GROOVED CLAMP	CF6-50 (LMCO)	SV	1
9132M20G01	NUT ASSY - GANG CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9133M21P03	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9133M21P03	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9133M21P03	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9133M21P03	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NE	18
9133M21P04	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9133M21P04	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	6
9133M21P04	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9133M21P04	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	5
9133M21P06	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9133M21P06	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9133M21P06	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9133M21P07	SPACER	CF6-50	NE	1
9133M21P07	SPACER	CF6-50	NE	3
9133M21P10	SPACER (.751-.760)	CF6-50	NS	2
9133M21P10	SPACER (.751-.760)	CF6-50	NS	1
9133M21P10	SPACER (.751-.760)	CF6-50	NS	2
9133M21P10	SPACER (.751-.760)	CF6-50	NS	2
9133M21P11	SPACER - SLEEVE	CF6-80C2, CF6-80A	NE	1
9133M21P11	SPACER - SLEEVE	CF6-80C2, CF6-80A	NE	9
9133M21P11	SPACER - SLEEVE	CF6-80C2, CF6-80A	NE	8
9133M21P11	SPACER - SLEEVE	CF6-80C2, CF6-80A	NE	32

Part Number	Part Description	Engine Type	Condition	Quantity
9133M21P12	SPACER - SLEEVE	CF6-80C2, CF6-80A	NE	2
9133M21P12	SPACER - SLEEVE	CF6-80C2, CF6-80A	NS	9
9133M21P12	SPACER - SLEEVE	CF6-80C2, CF6-80A	NS	2
9133M21P13	SPACER - SLEEVE	CF6-80A	NS	4
9133M21P13	SPACER - SLEEVE	CF6-80A	NS	1
9133M21P13	SPACER - SLEEVE	CF6-80A	NE	4
9133M21P13	SPACER - SLEEVE	CF6-80A	NE	6
9133M88P01	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9133M88P01	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	3
9134M80P01	COUPLING - TUBE FLANGED	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9134M80P01	COUPLING - TUBE FLANGED	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9135M62P01	CRF COMBUSTOR BOREScope PLUG	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9135M62P01	CRF COMBUSTOR BOREScope PLUG	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	5
9135M62P01	CRF COMBUSTOR BOREScope PLUG	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9135M62P01	CRF COMBUSTOR BOREScope PLUG	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9135M62P01	CRF COMBUSTOR BOREScope PLUG	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9135M62P01	CRF COMBUSTOR BOREScope PLUG	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9135M78P01	SPACER - SLEEVE	CF6-50 (LMCO), CF6-50 (Boeing)	NE	4
9135M78P01	SPACER - SLEEVE	CF6-50 (LMCO), CF6-50 (Boeing)	NE	17

Part Number	Part Description	Engine Type	Condition	Quantity
9135M78P01	SPACER - SLEEVE	CF6-50 (LMCO), CF6-50 (Boeing)	NE	4
9135M82P01	SPACER - SLEEVE	CF6-80C2, CF6-50	NS	1
9136M22P02	CHANNEL - SEAL	CF6-50 (LMCO)	AR	1
9136M22P02	CHANNEL - SEAL	CF6-50 (LMCO)	AR	1
9136M22P02	CHANNEL - SEAL	CF6-50 (LMCO)	AR	1
9136M42G01	TUBE ASSY - GEARBOX LUBE	CF6-50 (Boeing)	AR	1
9136M42G01	TUBE ASSY - GEARBOX LUBE	CF6-50 (Boeing)	AR	1
9136M42G01	TUBE ASSY - GEARBOX LUBE	CF6-50 (Boeing)	AR	1
9136M42G01	TUBE ASSY - GEARBOX LUBE	CF6-50 (Boeing)	AR	1
9136M42G01	TUBE ASSY - GEARBOX LUBE	CF6-50 (Boeing)	AR	1
9136M42G01	TUBE ASSY - GEARBOX LUBE	CF6-50 (Boeing)	AR	1
9136M42G01	TUBE ASSY - GEARBOX LUBE	CF6-50 (Boeing)	AR	1
9136M42G01	TUBE ASSY - GEARBOX LUBE	CF6-50 (Boeing)	AR	1
9136M42G01	TUBE ASSY - GEARBOX LUBE	CF6-50 (Boeing)	AR	1
9136M42G01	TUBE ASSY - GEARBOX LUBE	CF6-50 (Boeing)	AR	1
9136M42G01	TUBE ASSY - GEARBOX LUBE	CF6-50 (Boeing)	AR	1
9136M89G08	SPOOL ASSY - STG 3 THRU 9	CF6-50	AR	1
9136M89G19	SPOOL ASSY - STG 3 THRU 9	CF6-50	AR	1
9136M89G21	SPOOL ASSY - STG 3 THRU 9	CF6-80A	AR	1
9136M89G28	SPOOL - STG 3 THRU 9	CF6-80A	OH	1
9136M89G29	SPOOL ASSY - STG 3 THRU 9	CF6-50	OH	1
9137M21G03	SUPPORT ASSY - NOZZLE STG 2	CF6-50	AR	1
9137M28G01	SEAL ASSY - OUTER BRG 7	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9137M28G01	SEAL ASSY - OUTER BRG 7	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9137M28G01	SEAL ASSY - OUTER BRG 7	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9137M28G01	SEAL ASSY - OUTER BRG 7	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9137M28G01	SEAL ASSY - OUTER BRG 7	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9137M28G01	SEAL ASSY - OUTER BRG 7	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9137M28G01	SEAL ASSY - OUTER BRG 7	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9137M28G01	SEAL ASSY - OUTER BRG 7	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9137M28G01	SEAL ASSY - OUTER BRG 7	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9137M28G01	SEAL ASSY - OUTER BRG 7	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9137M28G01	SEAL ASSY - OUTER BRG 7	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9137M28G01	SEAL ASSY - OUTER BRG 7	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9137M29P03	CLEVIS - ACTUATION LEVER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9137M29P03	CLEVIS - ACTUATION LEVER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	13
9137M29P03	CLEVIS - ACTUATION LEVER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9137M29P03	CLEVIS - ACTUATION LEVER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	10
9137M29P03	CLEVIS - ACTUATION LEVER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9137M29P03	CLEVIS - ACTUATION LEVER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	6
9137M29P03	CLEVIS - ACTUATION LEVER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9137M29P03	CLEVIS - ACTUATION LEVER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9137M29P03	CLEVIS - ACTUATION LEVER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	6
9137M29P03	CLEVIS - ACTUATION LEVER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9137M29P03	CLEVIS - ACTUATION LEVER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9137M29P03	CLEVIS - ACTUATION LEVER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9137M29P03	CLEVIS - ACTUATION LEVER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	13
9137M29P03	CLEVIS - ACTUATION LEVER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
9137M30P01	ROD - PUSH ACTN LVR	CF6-80C2, CF6-80A, CF6-50 (LMCO)	AR	2
9137M30P01	ROD - PUSH ACTN LVR	CF6-80C2, CF6-80A, CF6-50 (LMCO)	OH	5
9137M30P01	ROD - PUSH ACTN LVR	CF6-80C2, CF6-80A, CF6-50 (LMCO)	OH	1
9137M30P01	ROD - PUSH ACTN LVR	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NE	1
9137M30P01	ROD - PUSH ACTN LVR	CF6-80C2, CF6-80A, CF6-50 (LMCO)	OH	1
9137M30P01	ROD - PUSH ACTN LVR	CF6-80C2, CF6-80A, CF6-50 (LMCO)	OH	6
9137M30P01	ROD - PUSH ACTN LVR	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NE	13
9137M92G36	FRAME ASSY - TURBINE MID	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9137M92G36	FRAME ASSY - TURBINE MID	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9137M92G41	FRAME ASSY - TURBINE MID	CF6-50	AR	1
9137M92G48	FRAME ASSY - TURBINE MID	CF6-50 (LMCO)	OH	1
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9137M95G02	HPC STATOR ACT CONN LINK STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9137M95G04	HPC STATOR ACT CONN LINK STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9137M95G05	HPC STATOR ACT CONN LINK STG 5	CF6-80C2	OH	1
9137M95G05	HPC STATOR ACT CONN LINK STG 5	CF6-80C2	OH	1
9138M80P04	PAD	CF6-50 (Boeing)	NE	1
9138M80P04	PAD	CF6-50 (Boeing)	SV	1
9139M12P01	FLANGE	CF6-50	NS	1
9139M12P01	FLANGE	CF6-50	NS	1
9140M13P003A	BRACKET - LP TURB CLG MANF	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9140M13P003A	BRACKET - LP TURB CLG MANF	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9140M13P003A	BRACKET - LP TURB CLG MANF	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9140M13P003A	BRACKET - LP TURB CLG MANF	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9140M13P003A	BRACKET - LP TURB CLG MANF	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9140M13P003A	BRACKET - LP TURB CLG MANF	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9140M14P001A	BRACKET - LP MANF DBL ANGLE	CF6-50 (LMCO)	OH	1
9140M15P001A	BRACKET - TUBE	CF6-50 (Boeing)	AR	1
9140M15P001A	BRACKET - TUBE	CF6-50 (Boeing)	OH	1
9140M15P001A	BRACKET - TUBE	CF6-50 (Boeing)	OH	1
9140M15P001A	BRACKET - TUBE	CF6-50 (Boeing)	OH	1
9140M15P001A	BRACKET - TUBE	CF6-50 (Boeing)	OH	1
9140M15P001A	BRACKET - TUBE	CF6-50 (Boeing)	OH	1
9140M15P001A	BRACKET - TUBE	CF6-50 (Boeing)	OH	1
9140M15P001A	BRACKET - TUBE	CF6-50 (Boeing)	OH	1
9140M15P001A	BRACKET - TUBE	CF6-50 (Boeing)	OH	1
9140M15P001A	BRACKET - TUBE	CF6-50 (Boeing)	OH	1
9140M17P001A	BRACKET - UPR RS MANIFOLD	CF6-50	AR	1
9140M18G02	BRACKET ASSY - LS LWR AFT	CF6-50 (LMCO)	AR	1
9140M18G02	BRACKET ASSY - LS LWR AFT	CF6-50 (LMCO)	AR	1
9140M18G02	BRACKET ASSY - LS LWR AFT	CF6-50 (LMCO)	AR	1
9140M46P001A	BRACKET	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9140M46P001A	BRACKET	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9140M48P001A	BRACKET	CF6-50 (LMCO)	NS	2
9140M48P001A	BRACKET	CF6-50 (LMCO)	NS	1
9140M48P001A	BRACKET	CF6-50 (LMCO)	NS	1
9140M54G01	TUBE ASSY - PS2C AIR	CF6-50	AR	1
9140M66P001A	BRACKET - ANGLE	CF6-50	NE	1
9140M66P001A	BRACKET - ANGLE	CF6-50	NE	1
9140M66P001A	BRACKET - ANGLE	CF6-50	NE	1
9140M87G01	BRACKET ASSY - TUBE	CF6-50 (LMCO)	AR	1
9141M45G01	TUBE - AIR TMF	CF6-50 (LMCO)	OH	1
9141M95G02	MANIFOLD - AIR TMF STRUT	CF6-50 (Boeing)	AR	1
9141M95G02	MANIFOLD - AIR TMF STRUT	CF6-50 (Boeing)	AR	1
9141M95G02	MANIFOLD - AIR TMF STRUT	CF6-50 (Boeing)	AR	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9141M95G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9141M97G02	TUBE - AIR TMF STRUT NO. 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M97G02	TUBE - AIR TMF STRUT NO. 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M97G02	TUBE - AIR TMF STRUT NO. 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M97G02	TUBE - AIR TMF STRUT NO. 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9141M97G02	TUBE - AIR TMF STRUT NO. 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M97G02	TUBE - AIR TMF STRUT NO. 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M97G02	TUBE - AIR TMF STRUT NO. 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M97G02	TUBE - AIR TMF STRUT NO. 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M97G02	TUBE - AIR TMF STRUT NO. 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M97G02	TUBE - AIR TMF STRUT NO. 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M97G02	TUBE - AIR TMF STRUT NO. 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M97G04	TUBE - AIR TMF STRUT NO. 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M97G04	TUBE - AIR TMF STRUT NO. 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M98P001A	BRACKET - TUBE TMF	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M98P001A	BRACKET - TUBE TMF	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9141M98P001A	BRACKET - TUBE TMF	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9141M99G02	BRACKET - TUBE TMF VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9142M97G01	SUPPORT ASSY - CORE COWL	CF6-50 (Boeing)	OH	1
9143M13G01	ADAPTER ASSY - IDLER/ALTNR	CF6-50 (Boeing)	OH	1
9143M37P03	HOUSING - BEARING	CF6-50 (Boeing)	NE	2
9143M37P04	HOUSING - BEARING	CF6-50 (Boeing)	NE	2
9143M46P02	COVER - IMPELLER	CF6-50	AR	1
9143M46P03	COVER - IMPELLER	CF6-50	OH	1
9143M46P04	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P04	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P04	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9143M46P04	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P04	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9143M46P04	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P04	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P04	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P04	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P04	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P04	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9143M46P04	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P04	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P06	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P06	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P06	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P06	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P06	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P06	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P06	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P06	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P06	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P06	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P06	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P06	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P06	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P06	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P06	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P06	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P06	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P06	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9143M46P06	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P06	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9143M46P06	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9143M46P06	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P06	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M46P06	COVER - IMPELLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9143M55G03	CAP - STRUT NO. 4	CF6-50	AR	1
9143M55G03	CAP - STRUT NO. 4	CF6-50	AR	1
9143M55G06	CAP - STRUT NO. 5	CF6-50 (LMCO)	OH	1
9143M55G06	CAP - STRUT NO. 5	CF6-50 (LMCO)	AR	1
9143M55G06	CAP - STRUT NO. 5	CF6-50 (LMCO)	AR	1
9143M57G01	CAP - STRUT NO. 2	CF6-50	OH	1
9143M57G01	CAP - STRUT NO. 2	CF6-50	AR	1
9143M57G01	CAP - STRUT NO. 2	CF6-50	AR	1
9143M57G01	CAP - STRUT NO. 2	CF6-50	AR	1
9143M58P02	CAP - STRUT NO. 8	CF6-50	AR	1
9143M58P02	CAP - STRUT NO. 8	CF6-50	AR	1
9143M58P02	CAP - STRUT NO. 8	CF6-50	AR	1
9143M59P02	CAP - STRUT NO. 6 - 7	CF6-50	AR	1
9143M59P02	CAP - STRUT NO. 6 - 7	CF6-50	AR	1
9143M74G02	NUT ASSY - GANG CHAN SLFLKG	CF6-50 (LMCO)	NE	2
9143M92P04	SEAL - CARBON FLANGED OIL	CF6-50 (LMCO)	AR	1
9143M92P04	SEAL - CARBON FLANGED OIL	CF6-50 (LMCO)	AR	1
9143M92P04	SEAL - CARBON FLANGED OIL	CF6-50 (LMCO)	AR	1
9143M92P04	SEAL - CARBON FLANGED OIL	CF6-50 (LMCO)	AR	1
9143M92P04	SEAL - CARBON FLANGED OIL	CF6-50 (LMCO)	AR	1
9143M92P04	SEAL - CARBON FLANGED OIL	CF6-50 (LMCO)	AR	1
9143M92P04	SEAL - CARBON FLANGED OIL	CF6-50 (LMCO)	AR	1
9143M92P04	SEAL - CARBON FLANGED OIL	CF6-50 (LMCO)	AR	1
9143M92P04	SEAL - CARBON FLANGED OIL	CF6-50 (LMCO)	AR	1
9143M92P04	SEAL - CARBON FLANGED OIL	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9143M92P04	SEAL - CARBON FLANGED OIL	CF6-50 (LMCO)	AR	1
9143M92P04	SEAL - CARBON FLANGED OIL	CF6-50 (LMCO)	AR	1
9144M11G02	BRACKET - TUBE TMF	CF6-50	OH	1
9144M38G01	MANIFOLD ASSY - AIR LH	CF6-50	AR	1
9144M38G01	MANIFOLD ASSY - AIR LH	CF6-50	AR	1
9146M53P23	DISK - FAN STG 1	CF6-50	AR	1
9146M53P24	DISK - FAN STG 1	CF6-50	AR	1
9146M53P24	DISK - FAN STG 1	CF6-50	AR	1
9146M66P01	RING - INTL KEYED RTNG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M66P01	RING - INTL KEYED RTNG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M66P01	RING - INTL KEYED RTNG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M66P01	RING - INTL KEYED RTNG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M66P01	RING - INTL KEYED RTNG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M66P01	RING - INTL KEYED RTNG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M66P01	RING - INTL KEYED RTNG	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9146M66P01	RING - INTL KEYED RTNG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P01	RING - BRG INNER	CF6-80A, CF6-50 (LMCO)	AR	1
9146M72P01	RING - BRG INNER	CF6-80A, CF6-50 (LMCO)	AR	1
9146M72P01	RING - BRG INNER	CF6-80A, CF6-50 (LMCO)	AR	1
9146M72P01	RING - BRG INNER	CF6-80A, CF6-50 (LMCO)	AR	1
9146M72P01	RING - BRG INNER	CF6-80A, CF6-50 (LMCO)	AR	1
9146M72P01	RING - BRG INNER	CF6-80A, CF6-50 (LMCO)	AR	1
9146M72P01	RING - BRG INNER	CF6-80A, CF6-50 (LMCO)	AR	1
9146M72P01	RING - BRG INNER	CF6-80A, CF6-50 (LMCO)	AR	1
9146M72P01	RING - BRG INNER	CF6-80A, CF6-50 (LMCO)	AR	1
9146M72P01	RING - BRG INNER	CF6-80A, CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9146M72P01	RING - BRG INNER	CF6-80A, CF6-50 (LMCO)	AR	1
9146M72P01	RING - BRG INNER	CF6-80A, CF6-50 (LMCO)	AR	1
9146M72P01	RING - BRG INNER	CF6-80A, CF6-50 (LMCO)	AR	1
9146M72P01	RING - BRG INNER	CF6-80A, CF6-50 (LMCO)	AR	1
9146M72P01	RING - BRG INNER	CF6-80A, CF6-50 (LMCO)	AR	1
9146M72P01	RING - BRG INNER	CF6-80A, CF6-50 (LMCO)	SV	1
9146M72P01	RING - BRG INNER	CF6-80A, CF6-50 (LMCO)	SV	1
9146M72P01	RING - BRG INNER	CF6-80A, CF6-50 (LMCO)	AR	1
9146M72P01	RING - BRG INNER	CF6-80A, CF6-50 (LMCO)	AR	1
9146M72P01	RING - BRG INNER	CF6-80A, CF6-50 (LMCO)	AR	1
9146M72P01	RING - BRG INNER	CF6-80A, CF6-50 (LMCO)	AR	1
9146M72P01	RING - BRG INNER	CF6-80A, CF6-50 (LMCO)	AR	1
9146M72P01	RING - BRG INNER	CF6-80A, CF6-50 (LMCO)	AR	1
9146M72P01	RING - BRG INNER	CF6-80A, CF6-50 (LMCO)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P03	RING - BRG NO. 6 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P04	RING - BRG NO. 6 INR	CF6-50 (LMCO)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P05	RING - BRG NO. 7 INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M72P14	RING - BRG INR NO. 2 6 7	CF6-80C2	OH	1
9146M72P14	RING - BRG INR NO. 2 6 7	CF6-80C2	AR	1
9146M72P14	RING - BRG INR NO. 2 6 7	CF6-80C2	AR	1
9146M72P14	RING - BRG INR NO. 2 6 7	CF6-80C2	AR	1
9146M83P01	KEY - CPRSR STTR CASING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M83P01	KEY - CPRSR STTR CASING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M83P01	KEY - CPRSR STTR CASING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M83P01	KEY - CPRSR STTR CASING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M83P01	KEY - CPRSR STTR CASING	CF6-50 (LMCO), CF6-50 (Boeing)	NE	4
9146M83P02	KEY - CPRSR STTR CASING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M83P02	KEY - CPRSR STTR CASING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9146M83P02	KEY - CPRSR STTR CASING	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9146M83P02	KEY - CPRSR STTR CASING	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9147M30P01	RING - AFT OUTER TMF LINER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9147M34G02	BAFFLE ASSY - AIR COVER STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
9147M34G04	BAFFLE ASSY - AIR COVER STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
9147M34G04	BAFFLE ASSY - AIR COVER STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
9147M34G04	BAFFLE ASSY - AIR COVER STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
9147M34G04	BAFFLE ASSY - AIR COVER STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
9147M34G04	BAFFLE ASSY - AIR COVER STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
9147M34G04	BAFFLE ASSY - AIR COVER STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9147M34G04	BAFFLE ASSY - AIR COVER STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
9147M34G04	BAFFLE ASSY - AIR COVER STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	18

Part Number	Part Description	Engine Type	Condition	Quantity
9147M34G04	BAFFLE ASSY - AIR COVER STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
9147M34G04	BAFFLE ASSY - AIR COVER STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
9147M34G04	BAFFLE ASSY - AIR COVER STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
9147M34G04	BAFFLE ASSY - AIR COVER STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
9147M34G04	BAFFLE ASSY - AIR COVER STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
9147M34G04	BAFFLE ASSY - AIR COVER STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
9147M34G04	BAFFLE ASSY - AIR COVER STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
9147M34G04	BAFFLE ASSY - AIR COVER STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
9147M34G04	BAFFLE ASSY - AIR COVER STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
9147M38G05	FRAME - COMPRESSOR REAR	CF6-50	AR	1
9147M38G08	FRAME - COMPRESSOR REAR	CF6-50 (LMCO)	AR	1
9147M92P01	ADAPTER	CF6-50 (LMCO)	AR	1
9147M92P01	ADAPTER	CF6-50 (LMCO)	AR	1
9147M92P01	ADAPTER	CF6-50 (LMCO)	AR	1
9147M92P01	ADAPTER	CF6-50 (LMCO)	AR	1
9147M92P01	ADAPTER	CF6-50 (LMCO)	AR	1
9147M92P01	ADAPTER	CF6-50 (LMCO)	AR	1
9147M92P01	ADAPTER	CF6-50 (LMCO)	AR	1
9147M92P01	ADAPTER	CF6-50 (LMCO)	AR	1
9147M92P01	ADAPTER	CF6-50 (LMCO)	AR	1
9147M92P01	ADAPTER	CF6-50 (LMCO)	AR	1
9147M92P01	ADAPTER	CF6-50 (LMCO)	OH	1
9147M92P01	ADAPTER	CF6-50 (LMCO)	OH	1
9147M92P01	ADAPTER	CF6-50 (LMCO)	OH	1
9147M92P03	ADAPTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9147M92P03	ADAPTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9147M92P03	ADAPTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9147M93P01	RETAINER - ADPTR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9148M12G01	TUBE ASSY - PS2C AIR	CF6-50	AR	1
9148M54P01	COVER - STG 10 PORT	CF6-50 (Boeing)	AR	1
9148M97G01	BRACKET ASSY	CF6-50	NS	1
9148M98G01	BRACKET ASSY - TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9148M98G01	BRACKET ASSY - TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9148M98G01	BRACKET ASSY - TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9148M98G01	BRACKET ASSY - TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9148M98G01	BRACKET ASSY - TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9148M98G01	BRACKET ASSY - TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9149M10G03	BRACKET ASSY - AFT TUBE CIT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9149M10G03	BRACKET ASSY - AFT TUBE CIT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9149M10G05	BRACKET ASSY - AFT TUBE CIT	CF6-50 (LMCO)	SV	1
9149M14G01	BRACKET - MAIN LUBE SPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9149M14G01	BRACKET - MAIN LUBE SPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9149M14G01	BRACKET - MAIN LUBE SPLY	CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9149M16P001A	BRACKET - UPPER B SUMP VENT	CF6-50 (LMCO)	SV	1
9149M17G01	BRACKET ASSY - AFT VENT	CF6-50 (Boeing)	SV	1
9149M17G01	BRACKET ASSY - AFT VENT	CF6-50 (Boeing)	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
9149M27G01	TUBE ASSY - FWD B SUMP VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9149M27G01	TUBE ASSY - FWD B SUMP VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9149M27G01	TUBE ASSY - FWD B SUMP VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9149M27G01	TUBE ASSY - FWD B SUMP VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9149M27G01	TUBE ASSY - FWD B SUMP VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9149M27G01	TUBE ASSY - FWD B SUMP VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9149M27G01	TUBE ASSY - FWD B SUMP VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9149M27G01	TUBE ASSY - FWD B SUMP VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9149M27G01	TUBE ASSY - FWD B SUMP VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9149M27G01	TUBE ASSY - FWD B SUMP VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9149M40G01	BRACKET ASSY	CF6-50 (Boeing)	AR	1
9149M70G05	BRACKET	CF6-50	AR	1
9149M84G01	HOUSING ASSY - COUPLING	CF6-50 (LMCO)	AR	1
9149M84G01	HOUSING ASSY - COUPLING	CF6-50 (LMCO)	AR	1
9149M84G01	HOUSING ASSY - COUPLING	CF6-50 (LMCO)	OH	1
9149M84G01	HOUSING ASSY - COUPLING	CF6-50 (LMCO)	OH	1
9149M84G01	HOUSING ASSY - COUPLING	CF6-50 (LMCO)	OH	1
9149M88G02	FLANGE ASSY - COUPLING	CF6-50 (LMCO), CF6-50 (Boeing)	NS	3
9149M88G02	FLANGE ASSY - COUPLING	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9150M15P01	RETAINER	CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9150M15P01	RETAINER	CF6-50 (LMCO), CF6-50 (Boeing)	NE	4
9150M15P01	RETAINER	CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9150M16P01	RETAINER	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9150M16P01	RETAINER	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9150M16P01	RETAINER	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1

Part Number	Part Description	Engine Type	Condition	Quantity
9150M16P01	RETAINER	CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9150M17G01	COUPLING ASSY - LPT CLG	CF6-50 (LMCO)	AR	1
9150M17G01	COUPLING ASSY - LPT CLG	CF6-50 (LMCO)	AR	1
9150M17G01	COUPLING ASSY - LPT CLG	CF6-50 (LMCO)	AR	1
9150M17G01	COUPLING ASSY - LPT CLG	CF6-50 (LMCO)	AR	1
9150M17G01	COUPLING ASSY - LPT CLG	CF6-50 (LMCO)	AR	1
9150M17G01	COUPLING ASSY - LPT CLG	CF6-50 (LMCO)	AR	1
9150M17G01	COUPLING ASSY - LPT CLG	CF6-50 (LMCO)	AR	1
9150M17G01	COUPLING ASSY - LPT CLG	CF6-50 (LMCO)	OH	1
9150M17G01	COUPLING ASSY - LPT CLG	CF6-50 (LMCO)	OH	1
9150M17G01	COUPLING ASSY - LPT CLG	CF6-50 (LMCO)	OH	1
9150M17G01	COUPLING ASSY - LPT CLG	CF6-50 (LMCO)	OH	1
9150M17G01	COUPLING ASSY - LPT CLG	CF6-50 (LMCO)	OH	1
9150M17G01	COUPLING ASSY - LPT CLG	CF6-50 (LMCO)	AR	1
9150M17G01	COUPLING ASSY - LPT CLG	CF6-50 (LMCO)	AR	1
9150M17G01	COUPLING ASSY - LPT CLG	CF6-50 (LMCO)	AR	1
9150M17G02	COUPLING ASSY - LPT CLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9150M17G02	COUPLING ASSY - LPT CLG	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9150M17G02	COUPLING ASSY - LPT CLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9150M17G02	COUPLING ASSY - LPT CLG	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9150M31G01	TUBE ASSY - FUEL FWD HD END	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9150M31G01	TUBE ASSY - FUEL FWD HD END	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9150M31G01	TUBE ASSY - FUEL FWD HD END	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9150M31G01	TUBE ASSY - FUEL FWD HD END	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9150M31G01	TUBE ASSY - FUEL FWD HD END	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9150M31G01	TUBE ASSY - FUEL FWD HD END	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9150M31G01	TUBE ASSY - FUEL FWD HD END	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9150M31G01	TUBE ASSY - FUEL FWD HD END	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9150M31G01	TUBE ASSY - FUEL FWD HD END	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9150M46G01	FLANGE - COUPLING (SPD)	CF6-50 (LMCO)	OH	1
9150M49G02	MANIFOLD - AIR TMF STRUT	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9150M49G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO)	OH	1
9150M49G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO)	OH	1
9150M49G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO)	OH	1
9150M49G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO)	OH	1
9150M49G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO)	AR	1
9150M49G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO)	OH	1
9150M49G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO)	OH	1
9150M49G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO)	AR	1
9150M49G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO)	AR	1
9150M49G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO)	OH	1
9150M49G03	MANIFOLD - AIR TMF STRUT	CF6-50 (LMCO)	OH	1
9150M59G01	BRACKET ASSY - CABLE	CF6-50 (LMCO)	OH	1
9150M66G03	TUBE ASSY - B SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9150M66G03	TUBE ASSY - B SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9150M66G03	TUBE ASSY - B SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9150M66G03	TUBE ASSY - B SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9150M66G03	TUBE ASSY - B SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9150M66G03	TUBE ASSY - B SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9150M66G03	TUBE ASSY - B SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9150M66G03	TUBE ASSY - B SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9150M66G03	TUBE ASSY - B SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9150M66G03	TUBE ASSY - B SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9150M66G03	TUBE ASSY - B SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9150M66G03	TUBE ASSY - B SUMP AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9150M73G01	BRACKET ASSY - TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9150M73G01	BRACKET ASSY - TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9150M74G01	BRACKET ASSY - TUBE	CF6-50 (LMCO)	AR	1
9150M74G01	BRACKET ASSY - TUBE	CF6-50 (LMCO)	SV	1
9150M74G01	BRACKET ASSY - TUBE	CF6-50 (LMCO)	AR	1
9150M74G01	BRACKET ASSY - TUBE	CF6-50 (LMCO)	OH	1
9150M96P001A	BRACKET - ANGLE	CF6-50 (LMCO)	AR	1
9150M96P001A	BRACKET - ANGLE	CF6-50 (LMCO)	AR	1
9153M16P001A	BRACKET - ELEC SYS ANGLE	CF6-50	AR	1
9153M16P001A	BRACKET - ELEC SYS ANGLE	CF6-50	AR	1
9153M16P001A	BRACKET - ELEC SYS ANGLE	CF6-50	AR	1
9153M16P001A	BRACKET - ELEC SYS ANGLE	CF6-50	NS	1
9153M16P001A	BRACKET - ELEC SYS ANGLE	CF6-50	NS	3
9153M90G03	BRACKET - OIL TUBE	CF6-50	SV	1
9153M99G03	BRACKET - OIL TUBE	CF6-50	SV	1
9154M97P01	SERVO - FUEL HEATER	CF6-50 (Boeing)	AR	1
9154M98P02	FILTER - FUEL	CF6-50 (Boeing)	AR	1
9154M98P03	FILTER - FUEL	CF6-50	AR	1
9154M98P15	FILTER - FUEL	CF6-80C2, CF6-80A, CF6-50 (Boeing)	AR	1
9155M15G02	SPINNER - FAN RTR	CF6-50	AR	1
9155M15G02	SPINNER - FAN RTR	CF6-50	AR	1
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	19
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	19
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38

Part Number	Part Description	Engine Type	Condition	Quantity
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P01	RETAINER - STG 1 BLADE RH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	25
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38

Part Number	Part Description	Engine Type	Condition	Quantity
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	19
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	SV	13
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	OH	6
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	35
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38

Part Number	Part Description	Engine Type	Condition	Quantity
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M41P02	RETAINER - STG 1 BLADE LH	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9155M42P05	SPACER - BLADE	CF6-50	AR	38
9155M51P01	RETAINER - SEAL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	6
9155M56G01	SHIELD - BRG NO. 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9155M56G01	SHIELD - BRG NO. 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9155M56G01	SHIELD - BRG NO. 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9155M56G01	SHIELD - BRG NO. 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9155M56G01	SHIELD - BRG NO. 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9155M56G01	SHIELD - BRG NO. 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9155M56G01	SHIELD - BRG NO. 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9155M56G01	SHIELD - BRG NO. 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9155M56G01	SHIELD - BRG NO. 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9155M56G01	SHIELD - BRG NO. 5 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9169M40P06	SEAL - O-RING	CF6-50	NS	18
9169M40P116	SEAL - O-RING	CF6-50 (Boeing)	NE	1
9169M43G01	BRACKET - LP MANF DBL ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9169M43G01	BRACKET - LP MANF DBL ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9169M43G01	BRACKET - LP MANF DBL ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9169M43G01	BRACKET - LP MANF DBL ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9169M43G01	BRACKET - LP MANF DBL ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9169M43G01	BRACKET - LP MANF DBL ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9169M43G01	BRACKET - LP MANF DBL ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9169M43G01	BRACKET - LP MANF DBL ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9169M43G01	BRACKET - LP MANF DBL ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9169M44G01	BRACKET - TUBE	CF6-50 (Boeing)	AR	1
9169M44G01	BRACKET - TUBE	CF6-50 (Boeing)	OH	1
9169M44G01	BRACKET - TUBE	CF6-50 (Boeing)	OH	1
9169M44G01	BRACKET - TUBE	CF6-50 (Boeing)	OH	1
9169M44G01	BRACKET - TUBE	CF6-50 (Boeing)	OH	1
9169M44G01	BRACKET - TUBE	CF6-50 (Boeing)	OH	1
9169M44G01	BRACKET - TUBE	CF6-50 (Boeing)	OH	1
9169M45G01	BRACKET - TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9169M45G01	BRACKET - TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9169M45G01	BRACKET - TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9169M45G01	BRACKET - TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	6
9169M45G01	BRACKET - TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9169M61P001A	BRACKET	CF6-50	AR	1
9169M61P001A	BRACKET	CF6-50	AR	1
9169M68G01	BRACKET - ELEC SYS	CF6-50 (LMCO)	AR	1
9169M84G01	BRACKET	CF6-50	NE	4
9169M85G03	BRACKET	CF6-50	AR	1
9169M85G03	BRACKET	CF6-50	AR	1
9169M85G03	BRACKET	CF6-50	AR	1
9169M85G03	BRACKET	CF6-50	AR	1
9170M31G01	MANIFOLD - AIR VBV SIGNAL	CF6-50	AR	1
9170M31G01	MANIFOLD - AIR VBV SIGNAL	CF6-50	SV	1
9170M34P001A	BRACKET - CDP ANGLE	CF6-50 (Boeing)	SV	1
9170M36P001A	BRACKET - CDP	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9170M36P001A	BRACKET - CDP	CF6-50	AR	1
9170M36P001A	BRACKET - CDP	CF6-50	AR	1
9170M55P03	TUBE/HOSE - FUEL SIG	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9170M55P03	TUBE/HOSE - FUEL SIG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9170M55P03	TUBE/HOSE - FUEL SIG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9170M55P03	TUBE/HOSE - FUEL SIG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9170M55P03	TUBE/HOSE - FUEL SIG	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9170M55P03	TUBE/HOSE - FUEL SIG	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9170M55P03	TUBE/HOSE - FUEL SIG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9170M56P03	TUBE/HOSE - FUEL ROD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9170M56P03	TUBE/HOSE - FUEL ROD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9170M56P03	TUBE/HOSE - FUEL ROD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9170M56P03	TUBE/HOSE - FUEL ROD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9170M56P03	TUBE/HOSE - FUEL ROD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9170M56P03	TUBE/HOSE - FUEL ROD	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9170M56P03	TUBE/HOSE - FUEL ROD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9170M56P03	TUBE/HOSE - FUEL ROD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9170M62P03	TUBE/HOSE - ACTR ROD	CF6-50 (Boeing)	AR	1
9170M63P03	TUBE/HOSE - FUEL HD END	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9170M63P03	TUBE/HOSE - FUEL HD END	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9170M63P03	TUBE/HOSE - FUEL HD END	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9170M63P03	TUBE/HOSE - FUEL HD END	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9170M63P03	TUBE/HOSE - FUEL HD END	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9170M63P03	TUBE/HOSE - FUEL HD END	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9170M63P04	TUBE/HOSE - FUEL HD END	CF6-50 (LMCO)	AR	1
9170M63P04	TUBE/HOSE - FUEL HD END	CF6-50 (LMCO)	AR	1
9170M63P04	TUBE/HOSE - FUEL HD END	CF6-50 (LMCO)	SV	1
9170M64P03	TUBE/HOSE - OIL	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9170M66P01	TUBE/HOSE - FUEL RET	CF6-50	OH	1
9170M66P03	TUBE/HOSE - FUEL RET	CF6-50 (LMCO)	AR	1
9170M66P03	TUBE/HOSE - FUEL RET	CF6-50 (LMCO)	OH	1
9170M66P03	TUBE/HOSE - FUEL RET	CF6-50 (LMCO)	AR	1
9170M66P03	TUBE/HOSE - FUEL RET	CF6-50 (LMCO)	OH	1
9170M66P04	TUBE/HOSE - FUEL RET	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9170M66P04	TUBE/HOSE - FUEL RET	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9170M66P04	TUBE/HOSE - FUEL RET	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9170M66P04	TUBE/HOSE - FUEL RET	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9170M66P04	TUBE/HOSE - FUEL RET	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9170M67P06	TUBE/HOSE ASSY - OIL	CF6-50	AR	1
9170M67P06	TUBE/HOSE ASSY - OIL	CF6-50	AR	1
9170M74G01	BRACKET ASSY - FIRE DET	CF6-50	AR	1
9170M74G01	BRACKET ASSY - FIRE DET	CF6-50	AR	1
9170M75G01	BRACKET ASSY - FIRE DET	CF6-50 (LMCO)	AR	1
9170M75G02	BRACKET ASSY - FIRE DET	CF6-50 (Boeing)	AR	1
9170M75G02	BRACKET ASSY - FIRE DET	CF6-50 (Boeing)	AR	1
9172M51P03	TUBE/HOSE - INL FWD OIL	CF6-50 (LMCO)	NS	1
9172M51P03	TUBE/HOSE - INL FWD OIL	CF6-50 (LMCO)	AR	1
9172M51P03	TUBE/HOSE - INL FWD OIL	CF6-50 (LMCO)	NS	2
9172M51P03	TUBE/HOSE - INL FWD OIL	CF6-50 (LMCO)	AR	1
9172M51P03	TUBE/HOSE - INL FWD OIL	CF6-50 (LMCO)	AR	1
9172M51P03	TUBE/HOSE - INL FWD OIL	CF6-50 (LMCO)	AR	1
9172M51P03	TUBE/HOSE - INL FWD OIL	CF6-50 (LMCO)	AR	1
9172M51P03	TUBE/HOSE - INL FWD OIL	CF6-50 (LMCO)	AR	1
9172M51P03	TUBE/HOSE - INL FWD OIL	CF6-50 (LMCO)	SV	1
9172M51P03	TUBE/HOSE - INL FWD OIL	CF6-50 (LMCO)	AR	1
9172M51P03	TUBE/HOSE - INL FWD OIL	CF6-50 (LMCO)	AR	1
9172M51P03	TUBE/HOSE - INL FWD OIL	CF6-50 (LMCO)	AR	1
9172M51P03	TUBE/HOSE - INL FWD OIL	CF6-50 (LMCO)	AR	1
9172M59G03	BRACKET	CF6-50	AR	1
9172M59G07	BRACKET	CF6-50 (LMCO)	AR	1
9172M59G07	BRACKET	CF6-50 (LMCO)	AR	1
9172M59G07	BRACKET	CF6-50 (LMCO)	SV	1
9172M67P01	PLATE - COVER	CF6-50	AR	1
9172M99G01	BRACKET ASSY - UPPER TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9172M99G01	BRACKET ASSY - UPPER TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9173M29P01	LINK - CONNECTING STG 3	CF6-50 (Boeing)	AR	1
9173M29P01	LINK - CONNECTING STG 3	CF6-50 (Boeing)	AR	1
9173M29P01	LINK - CONNECTING STG 3	CF6-50 (Boeing)	AR	1
9173M29P01	LINK - CONNECTING STG 3	CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9173M29P01	LINK - CONNECTING STG 3	CF6-50 (Boeing)	AR	1
9173M29P01	LINK - CONNECTING STG 3	CF6-50 (Boeing)	AR	1
9173M30P01	LINK - CONNECTING STG 4	CF6-50 (Boeing)	AR	1
9173M30P01	LINK - CONNECTING STG 4	CF6-50 (Boeing)	AR	1
9173M30P01	LINK - CONNECTING STG 4	CF6-50 (Boeing)	AR	2
9173M30P01	LINK - CONNECTING STG 4	CF6-50 (Boeing)	AR	1
9173M30P01	LINK - CONNECTING STG 4	CF6-50 (Boeing)	AR	2
9173M30P01	LINK - CONNECTING STG 4	CF6-50 (Boeing)	AR	2
9173M30P01	LINK - CONNECTING STG 4	CF6-50 (Boeing)	AR	1
9173M30P01	LINK - CONNECTING STG 4	CF6-50 (Boeing)	AR	2
9173M30P01	LINK - CONNECTING STG 4	CF6-50 (Boeing)	AR	2
9173M72G01	TUBE - SIMULATER	CF6-50	NE	1
9173M87P01	RETAINER - STG 2 BLD	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	21
9173M87P01	RETAINER - STG 2 BLD	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	26
9173M87P01	RETAINER - STG 2 BLD	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	26
9173M87P01	RETAINER - STG 2 BLD	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	26
9173M87P01	RETAINER - STG 2 BLD	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	26
9173M87P01	RETAINER - STG 2 BLD	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	26
9173M87P01	RETAINER - STG 2 BLD	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	21
9173M87P01	RETAINER - STG 2 BLD	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	19
9173M87P01	RETAINER - STG 2 BLD	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9173M87P01	RETAINER - STG 2 BLD	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
9173M87P01	RETAINER - STG 2 BLD	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	26
9173M87P01	RETAINER - STG 2 BLD	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	20

Part Number	Part Description	Engine Type	Condition	Quantity
9173M87P01	RETAINER - STG 2 BLD	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	26
9173M87P01	RETAINER - STG 2 BLD	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	26
9173M87P02	HPC ROTOR BLADE RETAINER STG 2	CF6-80C2	NE	16
9173M87P02	HPC ROTOR BLADE RETAINER STG 2	CF6-80C2	NE	7
9173M87P02	HPC ROTOR BLADE RETAINER STG 2	CF6-80C2	NE	22
9173M89G02	LUG - LKG STG 4	CF6-80C2, CF6-80A, CF6-50	OH	2
9173M90G01	HPC ROTOR LOCK LUG ASSY STG 3	CF6-80A	OH	2
9173M90G02	LUG ASSY - BL LKG STG 4	CF6-50 (LMCO)	OH	2
9173M90G02	LUG ASSY - BL LKG STG 4	CF6-50 (LMCO)	OH	1
9173M90G05	LUG ASSY - BL LKG STG 7	CF6-80A, CF6-50 (LMCO)	OH	1
9173M90G30	HPC ROTOR LOCK LUG ASSY STG 5	CF6-80C2	OH	2
9173M90G32	HPC ROTOR LOCK LUG ASSY STG 7	CF6-80C2	OH	3
9173M90G33	HPC ROTOR LOCK LUG ASSY STG 8	CF6-80C2	OH	3
9173M90G34	HPC ROTOR LOCK LUG ASSY STG 9	CF6-80C2	OH	3
9173M90G35	HPC ROTOR LOCK LUG ASSY STG 4	CF6-80C2	OH	2
9173M90G35	HPC ROTOR LOCK LUG ASSY STG 4	CF6-80C2	OH	2
9174M38P01	DOUBLER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9174M38P02	DOUBLER - CAST	CF6-50 (LMCO), CF6-50 (Boeing)	NS	8
9174M38P02	DOUBLER - CAST	CF6-50 (LMCO), CF6-50 (Boeing)	NS	11
9174M38P04	DOUBLER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9174M38P04	DOUBLER	CF6-50 (LMCO), CF6-50 (Boeing)	SV	2
9174M38P04	DOUBLER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	7
9174M38P04	DOUBLER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	7
9174M38P04	DOUBLER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9174M38P04	DOUBLER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	8
9174M38P04	DOUBLER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	8
9174M62P03	PLATE - DOUBLER	CF6-50	SV	1
9174M78P02	SLEEVE - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9174M78P02	SLEEVE - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	3
9174M78P02	SLEEVE - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	3
9174M78P02	SLEEVE - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	54
9174M78P02	SLEEVE - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9175M49G01	BRACKET ASSY - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9175M49G01	BRACKET ASSY - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9175M49G01	BRACKET ASSY - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9175M49G01	BRACKET ASSY - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9175M49G01	BRACKET ASSY - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9175M49G01	BRACKET ASSY - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9175M49G01	BRACKET ASSY - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9175M49G01	BRACKET ASSY - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9175M49G01	BRACKET ASSY - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9175M49G01	BRACKET ASSY - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9175M49G01	BRACKET ASSY - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9175M49G01	BRACKET ASSY - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9175M49G01	BRACKET ASSY - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
9175M49G01	BRACKET ASSY - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9175M49G01	BRACKET ASSY - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
9175M49G01	BRACKET ASSY - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9175M49G01	BRACKET ASSY - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9175M49G01	BRACKET ASSY - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9175M49G01	BRACKET ASSY - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	3
9175M55G01	BRACKET ASSY - VENT TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M55G01	BRACKET ASSY - VENT TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M55G01	BRACKET ASSY - VENT TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G11	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G11	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9175M93G11	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G11	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G11	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G11	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G11	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G11	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G11	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G11	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G11	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G11	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G11	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G11	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G11	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G11	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G11	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G11	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G11	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9175M93G11	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G11	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G11	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G12	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G12	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G12	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G12	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G12	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G12	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G12	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G12	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G12	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9175M93G12	RING ASSY - FIRESEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M10G01	TUBE ASSY - TANK VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M10G01	TUBE ASSY - TANK VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M10G01	TUBE ASSY - TANK VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M10G01	TUBE ASSY - TANK VENT	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9176M12G01	TUBE ASSY - SCAV RET	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M12G01	TUBE ASSY - SCAV RET	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M12G01	TUBE ASSY - SCAV RET	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M12G01	TUBE ASSY - SCAV RET	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M12G01	TUBE ASSY - SCAV RET	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9176M12G01	TUBE ASSY - SCAV RET	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M12G01	TUBE ASSY - SCAV RET	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M12G01	TUBE ASSY - SCAV RET	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M12G01	TUBE ASSY - SCAV RET	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9176M12G01	TUBE ASSY - SCAV RET	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M12G01	TUBE ASSY - SCAV RET	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M12G01	TUBE ASSY - SCAV RET	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M12G01	TUBE ASSY - SCAV RET	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M12G01	TUBE ASSY - SCAV RET	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M12G02	TUBE - OIL SCAVENGE	CF6-80A	AR	1
9176M12G02	TUBE - OIL SCAVENGE	CF6-80A	AR	1
9176M18G01	TUBE ASSY - D SCAV OIL	CF6-50 (LMCO)	AR	1
9176M18G01	TUBE ASSY - D SCAV OIL	CF6-50 (LMCO)	AR	1
9176M18G01	TUBE ASSY - D SCAV OIL	CF6-50 (LMCO)	AR	1
9176M18G01	TUBE ASSY - D SCAV OIL	CF6-50 (LMCO)	OH	1
9176M18G01	TUBE ASSY - D SCAV OIL	CF6-50 (LMCO)	AR	1
9176M18G01	TUBE ASSY - D SCAV OIL	CF6-50 (LMCO)	AR	1
9176M18G01	TUBE ASSY - D SCAV OIL	CF6-50 (LMCO)	AR	1
9176M18G01	TUBE ASSY - D SCAV OIL	CF6-50 (LMCO)	OH	1
9176M18G03	TUBE ASSY - D SCAV OIL	CF6-50 (Boeing)	AR	1
9176M20G01	TUBE ASSY - OIL SCAV TGB	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M20G01	TUBE ASSY - OIL SCAV TGB	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M20G01	TUBE ASSY - OIL SCAV TGB	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M20G01	TUBE ASSY - OIL SCAV TGB	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M20G01	TUBE ASSY - OIL SCAV TGB	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M20G01	TUBE ASSY - OIL SCAV TGB	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M20G01	TUBE ASSY - OIL SCAV TGB	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M20G01	TUBE ASSY - OIL SCAV TGB	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M20G01	TUBE ASSY - OIL SCAV TGB	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M20G01	TUBE ASSY - OIL SCAV TGB	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M20G01	TUBE ASSY - OIL SCAV TGB	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M20G01	TUBE ASSY - OIL SCAV TGB	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M20G01	TUBE ASSY - OIL SCAV TGB	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M20G01	TUBE ASSY - OIL SCAV TGB	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9176M20G01	TUBE ASSY - OIL SCAV TGB	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M20G01	TUBE ASSY - OIL SCAV TGB	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M20G01	TUBE ASSY - OIL SCAV TGB	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9176M20G03	TUBE ASSY - OIL SCAV TGB	CF6-50 (Boeing)	OH	1
9176M20G03	TUBE ASSY - OIL SCAV TGB	CF6-50 (Boeing)	AR	1
9176M22G01	TUBE - LUBE SUPPLY	CF6-50	AR	1
9176M25G01	MANIFOLD ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M25G01	MANIFOLD ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M25G01	MANIFOLD ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M25G01	MANIFOLD ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M25G01	MANIFOLD ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M25G01	MANIFOLD ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M25G01	MANIFOLD ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M25G02	MANIFOLD ASSY - AFT OIL	CF6-50 (Boeing)	AR	1
9176M25G02	MANIFOLD ASSY - AFT OIL	CF6-50 (Boeing)	AR	1
9176M25G02	MANIFOLD ASSY - AFT OIL	CF6-50 (Boeing)	SV	1
9176M25G02	MANIFOLD ASSY - AFT OIL	CF6-50 (Boeing)	AR	1
9176M25G02	MANIFOLD ASSY - AFT OIL	CF6-50 (Boeing)	SV	1
9176M25G02	MANIFOLD ASSY - AFT OIL	CF6-50 (Boeing)	AR	1
9176M52G04	RING ASSY - FIRESEAL INR	CF6-50 (LMCO)	AR	1
9176M52G07	RING ASSY - FIRESEAL INR	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9176M52G07	RING ASSY - FIRESEAL INR	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9176M52G07	RING ASSY - FIRESEAL INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M52G07	RING ASSY - FIRESEAL INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M52G07	RING ASSY - FIRESEAL INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M52G07	RING ASSY - FIRESEAL INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M52G07	RING ASSY - FIRESEAL INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M52G07	RING ASSY - FIRESEAL INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M52G07	RING ASSY - FIRESEAL INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9176M52G10	RING ASSY - FIRESEAL INR	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9176M52G10	RING ASSY - FIRESEAL INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M52G10	RING ASSY - FIRESEAL INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M52G10	RING ASSY - FIRESEAL INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M52G10	RING ASSY - FIRESEAL INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M52G10	RING ASSY - FIRESEAL INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M52G10	RING ASSY - FIRESEAL INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M52G10	RING ASSY - FIRESEAL INR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M53G01	BRACKET ASSY - ACTR RESET	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M53G01	BRACKET ASSY - ACTR RESET	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9176M84P007A	RING - FWD INR FIRESEAL	CF6-50 (Boeing)	AR	1
9176M84P007A	RING - FWD INR FIRESEAL	CF6-50 (Boeing)	OH	1
9176M84P007A	RING - FWD INR FIRESEAL	CF6-50 (Boeing)	AR	1
9176M84P007A	RING - FWD INR FIRESEAL	CF6-50 (Boeing)	AR	1
9176M84P007A	RING - FWD INR FIRESEAL	CF6-50 (Boeing)	AR	1
9176M84P007A	RING - FWD INR FIRESEAL	CF6-50 (Boeing)	AR	1
9176M84P007A	RING - FWD INR FIRESEAL	CF6-50 (Boeing)	AR	1
9176M84P007A	RING - FWD INR FIRESEAL	CF6-50 (Boeing)	AR	1
9176M84P007A	RING - FWD INR FIRESEAL	CF6-50 (Boeing)	AR	1
9176M85P005A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M85P005A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M85P005A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M85P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M85P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M85P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M85P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M85P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M85P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M85P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M85P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M85P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M85P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M86P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M86P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M86P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M86P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M86P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M86P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M86P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M86P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M86P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9176M86P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M87P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M87P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M87P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M87P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M87P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M87P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M87P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M87P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M87P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M87P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M88P007A	RING - FWD INR FIRESEAL	CF6-50 (LMCO)	AR	1
9176M88P007A	RING - FWD INR FIRESEAL	CF6-50 (LMCO)	AR	1
9176M88P007A	RING - FWD INR FIRESEAL	CF6-50 (LMCO)	AR	1
9176M88P007A	RING - FWD INR FIRESEAL	CF6-50 (LMCO)	AR	1
9176M88P007A	RING - FWD INR FIRESEAL	CF6-50 (LMCO)	AR	1
9176M88P007A	RING - FWD INR FIRESEAL	CF6-50 (LMCO)	AR	1
9176M88P007A	RING - FWD INR FIRESEAL	CF6-50 (LMCO)	AR	1
9176M88P007A	RING - FWD INR FIRESEAL	CF6-50 (LMCO)	AR	1
9176M88P007A	RING - FWD INR FIRESEAL	CF6-50 (LMCO)	AR	1
9176M89P005A	RING - FWD INR FIRESEAL	CF6-50 (LMCO)	AR	1
9176M89P005A	RING - FWD INR FIRESEAL	CF6-50 (LMCO)	AR	1
9176M89P005A	RING - FWD INR FIRESEAL	CF6-50 (LMCO)	AR	1
9176M89P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M89P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M89P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M89P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9176M89P007A	RING - FWD INR FIRESEAL	CF6-50	AR	1
9177M26P01	PLATE - LOCK	CF6-80A	NE	1
9177M26P01	PLATE - LOCK	CF6-80A	NE	1
9177M26P01	PLATE - LOCK	CF6-80A	NE	1
9177M55P02	BOOT	CF6-50	NS	2
9177M60P001A	BRACKET - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9177M60P001A	BRACKET - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9178M17G01	BRACKET ASSY - SPRAY SHIELD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M17G01	BRACKET ASSY - SPRAY SHIELD	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9178M18P001	BRACKET	CF6-50	AR	1
9178M18P001	BRACKET	CF6-50	SV	1
9178M18P001A	BRACKET	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M19P001A	BRACKET - ANGLE	CF6-50	AR	1
9178M19P001A	BRACKET - ANGLE	CF6-50	AR	1
9178M19P001A	BRACKET - ANGLE	CF6-50	AR	1
9178M19P001A	BRACKET - ANGLE	CF6-50	AR	1
9178M19P001A	BRACKET - ANGLE	CF6-50	SV	1
9178M19P001A	BRACKET - ANGLE	CF6-50	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
9178M20G01	BRACKET ASSY - AIR SPLY	CF6-50 (Boeing)	AR	1
9178M20G02	BRACKET ASSY - AIR SPLY	CF6-50 (Boeing)	.INSP	1
9178M20G03	BRACKET ASSY - AIR SPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M20G03	BRACKET ASSY - AIR SPLY	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9178M20G04	BRACKET ASSY - AIR SPLY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M40G01	SHIELD ASSY - SPRAY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M40G01	SHIELD ASSY - SPRAY	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M62G01	MANIFOLD ASSY - UPR AFT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9178M62G01	MANIFOLD ASSY - UPR AFT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M62G01	MANIFOLD ASSY - UPR AFT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M62G01	MANIFOLD ASSY - UPR AFT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9178M62G01	MANIFOLD ASSY - UPR AFT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M62G01	MANIFOLD ASSY - UPR AFT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M62G01	MANIFOLD ASSY - UPR AFT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9178M62G01	MANIFOLD ASSY - UPR AFT AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9178M62G02	MANIFOLD ASSY - UPR AFT AIR	CF6-50 (LMCO)	AR	1
9178M62G02	MANIFOLD ASSY - UPR AFT AIR	CF6-50 (LMCO)	AR	1
9178M62G02	MANIFOLD ASSY - UPR AFT AIR	CF6-50 (LMCO)	OH	1
9178M62G02	MANIFOLD ASSY - UPR AFT AIR	CF6-50 (LMCO)	AR	1
9178M63G01	MANIFOLD ASSY - AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M63G01	MANIFOLD ASSY - AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M63G01	MANIFOLD ASSY - AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9178M63G01	MANIFOLD ASSY - AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M63G01	MANIFOLD ASSY - AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M63G01	MANIFOLD ASSY - AIR	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
9178M63G01	MANIFOLD ASSY - AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9178M63G01	MANIFOLD ASSY - AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9178M63G01	MANIFOLD ASSY - AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9178M63G01	MANIFOLD ASSY - AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M63G01	MANIFOLD ASSY - AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9178M63G01	MANIFOLD ASSY - AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9178M63G01	MANIFOLD ASSY - AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9178M63G01	MANIFOLD ASSY - AIR	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9178M63G01	MANIFOLD ASSY - AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M63G01	MANIFOLD ASSY - AIR	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9178M63G01	MANIFOLD ASSY - AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M63G01	MANIFOLD ASSY - AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9178M63G01	MANIFOLD ASSY - AIR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9178M63G01	MANIFOLD ASSY - AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M64G01	MANIFOLD ASSY - LP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M64G01	MANIFOLD ASSY - LP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M64G01	MANIFOLD ASSY - LP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M64G01	MANIFOLD ASSY - LP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
9178M64G01	MANIFOLD ASSY - LP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M64G01	MANIFOLD ASSY - LP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M64G01	MANIFOLD ASSY - LP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M64G01	MANIFOLD ASSY - LP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M64G01	MANIFOLD ASSY - LP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M64G01	MANIFOLD ASSY - LP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M64G01	MANIFOLD ASSY - LP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9178M64G01	MANIFOLD ASSY - LP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9178M64G01	MANIFOLD ASSY - LP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9178M64G01	MANIFOLD ASSY - LP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9178M64G01	MANIFOLD ASSY - LP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9178M64G01	MANIFOLD ASSY - LP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M64G01	MANIFOLD ASSY - LP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M65G01	MANIFOLD ASSY - HP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M65G01	MANIFOLD ASSY - HP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M65G01	MANIFOLD ASSY - HP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9178M65G01	MANIFOLD ASSY - HP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M65G01	MANIFOLD ASSY - HP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9178M65G01	MANIFOLD ASSY - HP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M65G01	MANIFOLD ASSY - HP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M65G01	MANIFOLD ASSY - HP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9178M65G01	MANIFOLD ASSY - HP RECOUP	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9181M17G01	TUBE - CASE EXHAUST	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M17G01	TUBE - CASE EXHAUST	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M17G01	TUBE - CASE EXHAUST	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M17G01	TUBE - CASE EXHAUST	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M17G01	TUBE - CASE EXHAUST	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M17G01	TUBE - CASE EXHAUST	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9181M17G01	TUBE - CASE EXHAUST	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9181M17G01	TUBE - CASE EXHAUST	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M17G01	TUBE - CASE EXHAUST	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M17G01	TUBE - CASE EXHAUST	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9181M17G01	TUBE - CASE EXHAUST	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M17G01	TUBE - CASE EXHAUST	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M24P14	COVER - PLATE	CF6-50	NS	2
9181M24P14	COVER - PLATE	CF6-50	NS	3
9181M24P16	COVER - PLATE	CF6-50	SV	1
9181M24P16	COVER - PLATE	CF6-50	NS	1
9181M37G01	BRACKET ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M37G01	BRACKET ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M37G01	BRACKET ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M37G01	BRACKET ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M37G01	BRACKET ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M37G01	BRACKET ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M37G01	BRACKET ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M37G01	BRACKET ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9181M37G01	BRACKET ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M37G01	BRACKET ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9181M37G01	BRACKET ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M37G01	BRACKET ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M37G01	BRACKET ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M37G01	BRACKET ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M37G01	BRACKET ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M37G01	BRACKET ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M37G01	BRACKET ASSY - ACCESS GRBX	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M37G02	BRACKET ASSY - ACCESS GRBX	CF6-50 (Boeing)	OH	1
9181M38P01	LINK - MT	CF6-50	AR	1
9181M38P01	LINK - MT	CF6-50	AR	1
9181M38P01	LINK - MT	CF6-50	AR	1
9181M38P01	LINK - MT	CF6-50	AR	1
9181M38P01	LINK - MT	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9181M38P01	LINK - MT	CF6-50	AR	1
9181M38P01	LINK - MT	CF6-50	AR	1
9181M38P07	LINK - MT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9181M38P08	BEARING - SPHERICAL	CF6-50	NS	1
9181M38P08	BEARING - SPHERICAL	CF6-50	NS	2
9181M38P08	BEARING - SPHERICAL	CF6-50	NS	1
9181M38P09	LINK - MT	CF6-50 (Boeing)	AR	1
9181M38P09	LINK - MT	CF6-50 (Boeing)	AR	1
9181M38P09	LINK - MT	CF6-50 (Boeing)	NS	1
9181M38P09	LINK - MT	CF6-50 (Boeing)	NS	1
9181M40P01	BEARING - PLAIN SPHERICAL	CF6-50	NE	1
9181M40P01	BEARING - PLAIN SPHERICAL	CF6-50	NE	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9181M41P02	HPC STATOR ACT CONN LINK STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9181M42P02	HPC STATOR ACT CONN LINK STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9181M51P04	NUT ASSY - GANG CHANNEL	CF6-50 (Boeing)	NS	3

Part Number	Part Description	Engine Type	Condition	Quantity
9181M80P02	SEAL - HSG CARBON	CF6-50 (LMCO)	OH	1
9181M80P02	SEAL - HSG CARBON	CF6-50 (LMCO)	OH	1
9181M80P02	SEAL - HSG CARBON	CF6-50 (LMCO)	AR	1
9181M80P02	SEAL - HSG CARBON	CF6-50 (LMCO)	AR	1
9181M80P02	SEAL - HSG CARBON	CF6-50 (LMCO)	AR	1
9181M80P02	SEAL - HSG CARBON	CF6-50 (LMCO)	AR	1
9181M80P02	SEAL - HSG CARBON	CF6-50 (LMCO)	AR	1
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M80P08	SEAL - HSG CARBON	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M81G03	HEAT SHIELD - AFT	CF6-50	AR	1
9181M81G03	HEAT SHIELD - AFT	CF6-50	AR	1
9181M81G03	HEAT SHIELD - AFT	CF6-50	AR	1
9181M81G03	HEAT SHIELD - AFT	CF6-50	AR	1
9181M81G06	HEATSHIELD - AFT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9181M81G06	HEATSHIELD - AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M81G06	HEATSHIELD - AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M81G06	HEATSHIELD - AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M81G06	HEATSHIELD - AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M81G06	HEATSHIELD - AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M81G06	HEATSHIELD - AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M81G06	HEATSHIELD - AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M81G06	HEATSHIELD - AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M81G06	HEATSHIELD - AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M81G06	HEATSHIELD - AFT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9181M81G06	HEATSHIELD - AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M81G06	HEATSHIELD - AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M81G06	HEATSHIELD - AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M81G06	HEATSHIELD - AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9181M81G06	HEATSHIELD - AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M81G06	HEATSHIELD - AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M81G06	HEATSHIELD - AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M81G06	HEATSHIELD - AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M82G02	TUBE - CENTER VENT	CF6-50	AR	1
9181M82G02	TUBE - CENTER VENT	CF6-50	AR	1
9181M83P02	SLINGER ASSY - BRG 7 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M83P02	SLINGER ASSY - BRG 7 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M83P02	SLINGER ASSY - BRG 7 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M83P02	SLINGER ASSY - BRG 7 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M83P02	SLINGER ASSY - BRG 7 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M83P02	SLINGER ASSY - BRG 7 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M83P02	SLINGER ASSY - BRG 7 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M83P02	SLINGER ASSY - BRG 7 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M83P02	SLINGER ASSY - BRG 7 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M83P02	SLINGER ASSY - BRG 7 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M83P02	SLINGER ASSY - BRG 7 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M83P02	SLINGER ASSY - BRG 7 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M83P02	SLINGER ASSY - BRG 7 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M83P02	SLINGER ASSY - BRG 7 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M83P02	SLINGER ASSY - BRG 7 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9181M83P02	SLINGER ASSY - BRG 7 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M83P02	SLINGER ASSY - BRG 7 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9181M83P02	SLINGER ASSY - BRG 7 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M83P02	SLINGER ASSY - BRG 7 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M83P02	SLINGER ASSY - BRG 7 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M83P02	SLINGER ASSY - BRG 7 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M83P02	SLINGER ASSY - BRG 7 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M83P02	SLINGER ASSY - BRG 7 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M83P02	SLINGER ASSY - BRG 7 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M83P02	SLINGER ASSY - BRG 7 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M83P02	SLINGER ASSY - BRG 7 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M86P01	SHIELD - FWD HEAT	CF6-50	AR	1
9181M86P02	SHIELD - FWD HEAT	CF6-50 (LMCO)	OH	1
9181M86P02	SHIELD - FWD HEAT	CF6-50 (LMCO)	OH	1
9181M86P02	SHIELD - FWD HEAT	CF6-50 (LMCO)	AR	1
9181M86P02	SHIELD - FWD HEAT	CF6-50 (LMCO)	AR	1
9181M86P02	SHIELD - FWD HEAT	CF6-50 (LMCO)	AR	1
9181M86P02	SHIELD - FWD HEAT	CF6-50 (LMCO)	AR	1
9181M86P02	SHIELD - FWD HEAT	CF6-50 (LMCO)	NS	1
9181M86P02	SHIELD - FWD HEAT	CF6-50 (LMCO)	AR	1
9181M86P02	SHIELD - FWD HEAT	CF6-50 (LMCO)	AR	1
9181M86P02	SHIELD - FWD HEAT	CF6-50 (LMCO)	AR	1
9181M86P02	SHIELD - FWD HEAT	CF6-50 (LMCO)	AR	1
9181M86P02	SHIELD - FWD HEAT	CF6-50 (LMCO)	AR	1
9181M86P02	SHIELD - FWD HEAT	CF6-50 (LMCO)	AR	1
9181M86P02	SHIELD - FWD HEAT	CF6-50 (LMCO)	AR	1
9181M86P02	SHIELD - FWD HEAT	CF6-50 (LMCO)	AR	1
9181M86P02	SHIELD - FWD HEAT	CF6-50 (LMCO)	AR	1
9181M86P02	SHIELD - FWD HEAT	CF6-50 (LMCO)	AR	1
9181M93G01	NOZZLE - INLET GRBX OIL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M93G01	NOZZLE - INLET GRBX OIL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M93G01	NOZZLE - INLET GRBX OIL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M93G01	NOZZLE - INLET GRBX OIL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9181M93G01	NOZZLE - INLET GRBX OIL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M93G01	NOZZLE - INLET GRBX OIL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M93G01	NOZZLE - INLET GRBX OIL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M93G01	NOZZLE - INLET GRBX OIL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M93G01	NOZZLE - INLET GRBX OIL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M93G01	NOZZLE - INLET GRBX OIL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M93G01	NOZZLE - INLET GRBX OIL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M93G01	NOZZLE - INLET GRBX OIL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M93G01	NOZZLE - INLET GRBX OIL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M93G01	NOZZLE - INLET GRBX OIL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M93G01	NOZZLE - INLET GRBX OIL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M93G01	NOZZLE - INLET GRBX OIL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M93G01	NOZZLE - INLET GRBX OIL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9181M93G01	NOZZLE - INLET GRBX OIL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9181M93G01	NOZZLE - INLET GRBX OIL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9181M93G01	NOZZLE - INLET GRBX OIL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9182M18G03	SEGMENT ASSY - FAN CS LINER	CF6-50 (Boeing)	OH	1
9182M48G02	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	OH	1
9182M48G05	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1
9182M48G05	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1
9182M48G05	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1
9182M48G05	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1
9182M48G05	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1
9182M48G05	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1
9182M48G05	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1
9182M48G05	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1
9182M48G05	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1
9182M48G05	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1
9182M48G05	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1
9182M48G05	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1
9182M48G05	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1
9182M48G05	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	OH	1
9182M48G05	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1
9182M56G01	SEAL ASSY - 4B BRG AFT AIR	CF6-50	AR	1
9182M56G07	SEAL ASSY - 4B BRG AFT AIR	CF6-50	AR	1
9182M61G01	SEG ASSY - ACTN RING IGV	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G01	SEG ASSY - ACTN RING IGV	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G01	SEG ASSY - ACTN RING IGV	CF6-80A, CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9182M61G01	SEG ASSY - ACTN RING IGV	CF6-80A, CF6-50 (LMCO)	AR	1
9182M61G01	SEG ASSY - ACTN RING IGV	CF6-80A, CF6-50 (LMCO)	AR	1
9182M61G01	SEG ASSY - ACTN RING IGV	CF6-80A, CF6-50 (LMCO)	OH	1
9182M61G01	SEG ASSY - ACTN RING IGV	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G01	SEG ASSY - ACTN RING IGV	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G01	SEG ASSY - ACTN RING IGV	CF6-80A, CF6-50 (LMCO)	AR	1
9182M61G01	SEG ASSY - ACTN RING IGV	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G01	SEG ASSY - ACTN RING IGV	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G01	SEG ASSY - ACTN RING IGV	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G01	SEG ASSY - ACTN RING IGV	CF6-80A, CF6-50 (LMCO)	AR	1
9182M61G01	SEG ASSY - ACTN RING IGV	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G01	SEG ASSY - ACTN RING IGV	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G01	SEG ASSY - ACTN RING IGV	CF6-80A, CF6-50 (LMCO)	AR	1
9182M61G01	SEG ASSY - ACTN RING IGV	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G01	SEG ASSY - ACTN RING IGV	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G02	SEG ASSY - ACTN RING STG 1	CF6-80A, CF6-50 (LMCO)	AR	1
9182M61G02	SEG ASSY - ACTN RING STG 1	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G02	SEG ASSY - ACTN RING STG 1	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G02	SEG ASSY - ACTN RING STG 1	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G02	SEG ASSY - ACTN RING STG 1	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G02	SEG ASSY - ACTN RING STG 1	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G02	SEG ASSY - ACTN RING STG 1	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G02	SEG ASSY - ACTN RING STG 1	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G02	SEG ASSY - ACTN RING STG 1	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G02	SEG ASSY - ACTN RING STG 1	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G02	SEG ASSY - ACTN RING STG 1	CF6-80A, CF6-50 (LMCO)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9182M61G02	SEG ASSY - ACTN RING STG 1	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G02	SEG ASSY - ACTN RING STG 1	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G02	SEG ASSY - ACTN RING STG 1	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G02	SEG ASSY - ACTN RING STG 1	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G02	SEG ASSY - ACTN RING STG 1	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G02	SEG ASSY - ACTN RING STG 1	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G02	SEG ASSY - ACTN RING STG 1	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G02	SEG ASSY - ACTN RING STG 1	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G02	SEG ASSY - ACTN RING STG 1	CF6-80A, CF6-50 (LMCO)	AR	1
9182M61G02	SEG ASSY - ACTN RING STG 1	CF6-80A, CF6-50 (LMCO)	AR	1
9182M61G02	SEG ASSY - ACTN RING STG 1	CF6-80A, CF6-50 (LMCO)	AR	1
9182M61G02	SEG ASSY - ACTN RING STG 1	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G02	SEG ASSY - ACTN RING STG 1	CF6-80A, CF6-50 (LMCO)	OH	1
9182M61G03	SEG ASSY - ACTN RING STG 2	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G03	SEG ASSY - ACTN RING STG 2	CF6-80A, CF6-50 (LMCO)	AR	1
9182M61G03	SEG ASSY - ACTN RING STG 2	CF6-80A, CF6-50 (LMCO)	AR	1
9182M61G03	SEG ASSY - ACTN RING STG 2	CF6-80A, CF6-50 (LMCO)	OH	2
9182M61G03	SEG ASSY - ACTN RING STG 2	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G03	SEG ASSY - ACTN RING STG 2	CF6-80A, CF6-50 (LMCO)	AR	1
9182M61G03	SEG ASSY - ACTN RING STG 2	CF6-80A, CF6-50 (LMCO)	OH	1
9182M61G03	SEG ASSY - ACTN RING STG 2	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G03	SEG ASSY - ACTN RING STG 2	CF6-80A, CF6-50 (LMCO)	AR	1
9182M61G03	SEG ASSY - ACTN RING STG 2	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G03	SEG ASSY - ACTN RING STG 2	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G03	SEG ASSY - ACTN RING STG 2	CF6-80A, CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9182M61G03	SEG ASSY - ACTN RING STG 2	CF6-80A, CF6-50 (LMCO)	OH	1
9182M61G03	SEG ASSY - ACTN RING STG 2	CF6-80A, CF6-50 (LMCO)	AR	1
9182M61G03	SEG ASSY - ACTN RING STG 2	CF6-80A, CF6-50 (LMCO)	OH	1
9182M61G03	SEG ASSY - ACTN RING STG 2	CF6-80A, CF6-50 (LMCO)	AR	2
9182M61G04	SEG ASSY - ACTN RING STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9182M61G04	SEG ASSY - ACTN RING STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9182M61G04	SEG ASSY - ACTN RING STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9182M61G05	SEG ASSY - ACTN RING STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9182M61G05	SEG ASSY - ACTN RING STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9182M61G05	SEG ASSY - ACTN RING STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9182M61G05	SEG ASSY - ACTN RING STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9182M61G05	SEG ASSY - ACTN RING STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9182M61G05	SEG ASSY - ACTN RING STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9182M61G05	SEG ASSY - ACTN RING STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9182M61G05	SEG ASSY - ACTN RING STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9182M61G05	SEG ASSY - ACTN RING STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9182M61G05	SEG ASSY - ACTN RING STG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9182M90G01	SEAL ASSY - BRG 7 STA OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9182M90G01	SEAL ASSY - BRG 7 STA OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9182M90G01	SEAL ASSY - BRG 7 STA OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9182M90G01	SEAL ASSY - BRG 7 STA OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9182M90G01	SEAL ASSY - BRG 7 STA OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9182M90G01	SEAL ASSY - BRG 7 STA OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9182M90G01	SEAL ASSY - BRG 7 STA OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9182M90G01	SEAL ASSY - BRG 7 STA OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9182M90G01	SEAL ASSY - BRG 7 STA OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9182M90G01	SEAL ASSY - BRG 7 STA OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9182M90G01	SEAL ASSY - BRG 7 STA OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9182M90G01	SEAL ASSY - BRG 7 STA OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9182M90G01	SEAL ASSY - BRG 7 STA OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9183M43P01	PLATE - WEAR	CF6-50	NE	1
9183M43P01	PLATE - WEAR	CF6-50	NE	2
9185M14G01	GEARSHAFT ASSY - INLET GRBX	CF6-80A	SV	1
9185M14G01	GEARSHAFT ASSY - INLET GRBX	CF6-80A	AR	1
9185M71G01	GEARBOX ASSY - INLET	CF6-50	AR	1
9185M71G02	GEARBOX ASSY - INLET	CF6-50	AR	1
9185M71G03	GEARBOX ASSY - INLET	CF6-50	AR	1
9185M71G03	GEARBOX ASSY - INLET	CF6-50	AR	1
9185M71G07	GEARBOX ASSY - INLET	CF6-80A	AR	1
9185M71G14	GEARBOX ASSY - INLET	CF6-50	AR	1
9185M71G22	GEARBOX ASSY - INLET	CF6-80A	AR	1
9185M75G06	SPOOL ASSY - FAN RTR	CF6-50 (LMCO)	AR	1
9185M75G10	SPOOL ASSY - FAN RTR	CF6-50 (LMCO)	AR	1
9185M75G10	SPOOL ASSY - FAN RTR	CF6-50 (LMCO)	AR	1
9185M75G10	SPOOL ASSY - FAN RTR	CF6-50 (LMCO)	AR	1
9185M81P03	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9185M81P03	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	6
9185M81P03	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	SV	8
9185M81P03	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
9185M81P03	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9185M81P03	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	SV	8
9185M81P03	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NE	7
9185M81P03	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
9185M84P01	PLATE - XFR GRBX COVER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9185M84P01	PLATE - XFR GRBX COVER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9185M84P01	PLATE - XFR GRBX COVER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9185M84P01	PLATE - XFR GRBX COVER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9185M84P01	PLATE - XFR GRBX COVER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9185M84P01	PLATE - XFR GRBX COVER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9185M84P01	PLATE - XFR GRBX COVER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9185M84P01	PLATE - XFR GRBX COVER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9185M84P01	PLATE - XFR GRBX COVER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9185M84P01	PLATE - XFR GRBX COVER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9185M84P01	PLATE - XFR GRBX COVER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9186M31G01	SCREEN ASSY - HPTS NOZZLE	CF6-50	AR	1
9186M33G01	SUPPORT ASSY - NOZZLE STG 2	CF6-50	AR	1
9186M33G03	SUPPORT ASSY - NOZZLE STG 2	CF6-50	AR	1
9186M61P06	BLADE - LPT STG 1	CF6-50 (LMCO)	AR	105
9186M61P06	BLADE - LPT STG 1	CF6-50 (LMCO)	AR	3
9186M61P06	BLADE - LPT STG 1	CF6-50 (LMCO)	AR	88
9186M61P06	BLADE - LPT STG 1	CF6-50 (LMCO)	OH	32
9186M61P06	BLADE - LPT STG 1	CF6-50 (LMCO)	AR	3
9186M61P06	BLADE - LPT STG 1	CF6-50 (LMCO)	AR	1
9186M61P06	BLADE - LPT STG 1	CF6-50 (LMCO)	AR	105
9186M61P06	BLADE - LPT STG 1	CF6-50 (LMCO)	AR	102
9186M61P06	BLADE - LPT STG 1	CF6-50 (LMCO)	AR	127
9186M61P06	BLADE - LPT STG 1	CF6-50 (LMCO)	AR	9
9186M61P09	BLADE - LPT STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9186M76P02	RETAINER - STG 1 RTR BL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9186M76P03	RETAINER - STG 1 RTR BL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9186M76P04	RETAINER - STG 1 RTR BL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9186M76P04	RETAINER - STG 1 RTR BL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9186M76P04	RETAINER - STG 1 RTR BL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9186M76P04	RETAINER - STG 1 RTR BL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9186M76P04	RETAINER - STG 1 RTR BL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9186M76P04	RETAINER - STG 1 RTR BL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9186M96P04	SHIELD - RTR THRM	CF6-50	AR	1
9186M99P01	RETAINER - HPTR BLADE STG 2	CF6-80A, CF6-50 (LMCO)	OH	1
9186M99P01	RETAINER - HPTR BLADE STG 2	CF6-80A, CF6-50 (LMCO)	AR	1
9186M99P01	RETAINER - HPTR BLADE STG 2	CF6-80A, CF6-50 (LMCO)	AR	1
9186M99P01	RETAINER - HPTR BLADE STG 2	CF6-80A, CF6-50 (LMCO)	AR	1
9186M99P01	RETAINER - HPTR BLADE STG 2	CF6-80A, CF6-50 (LMCO)	AR	1
9186M99P01	RETAINER - HPTR BLADE STG 2	CF6-80A, CF6-50 (LMCO)	AR	1
9186M99P01	RETAINER - HPTR BLADE STG 2	CF6-80A, CF6-50 (LMCO)	AR	1
9186M99P01	RETAINER - HPTR BLADE STG 2	CF6-80A, CF6-50 (LMCO)	AR	1
9186M99P01	RETAINER - HPTR BLADE STG 2	CF6-80A, CF6-50 (LMCO)	AR	1
9186M99P01	RETAINER - HPTR BLADE STG 2	CF6-80A, CF6-50 (LMCO)	OH	1
9186M99P01	RETAINER - HPTR BLADE STG 2	CF6-80A, CF6-50 (LMCO)	AR	1
9186M99P01	RETAINER - HPTR BLADE STG 2	CF6-80A, CF6-50 (LMCO)	OH	1
9186M99P01	RETAINER - HPTR BLADE STG 2	CF6-80A, CF6-50 (LMCO)	AR	1
9186M99P01	RETAINER - HPTR BLADE STG 2	CF6-80A, CF6-50 (LMCO)	AR	1
9186M99P02	RETAINER - STG 2 RTR BL	CF6-50 (LMCO)	AR	1
9186M99P02	RETAINER - STG 2 RTR BL	CF6-50 (LMCO)	AR	1
9186M99P02	RETAINER - STG 2 RTR BL	CF6-50 (LMCO)	AR	1
9186M99P02	RETAINER - STG 2 RTR BL	CF6-50 (LMCO)	AR	1
9186M99P02	RETAINER - STG 2 RTR BL	CF6-50 (LMCO)	AR	1
9186M99P03	RETAINER - STG 2 RTR BL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9186M99P03	RETAINER - STG 2 RTR BL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9186M99P03	RETAINER - STG 2 RTR BL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9186M99P03	RETAINER - STG 2 RTR BL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9186M99P03	RETAINER - STG 2 RTR BL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9186M99P03	RETAINER - STG 2 RTR BL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9186M99P03	RETAINER - STG 2 RTR BL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9186M99P03	RETAINER - STG 2 RTR BL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9186M99P03	RETAINER - STG 2 RTR BL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9186M99P03	RETAINER - STG 2 RTR BL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9187M24G02	BRACKET - MTG	CF6-50	AR	1
9187M29P206	CONTROL - MAIN ENGINE	CF6-50 (Boeing)	AR	1
9187M29P206	CONTROL - MAIN ENGINE	CF6-50 (Boeing)	AR	1
9187M43P01	TUBE - AIR	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9187M47G01	TUBE - OIL	CF6-50 (Boeing)	AR	1
9187M47G01	TUBE - OIL	CF6-50 (Boeing)	AR	1
9187M47G01	TUBE - OIL	CF6-50 (Boeing)	AR	1
9187M47G01	TUBE - OIL	CF6-50 (Boeing)	AR	1
9187M47G01	TUBE - OIL	CF6-50 (Boeing)	AR	1
9187M47G01	TUBE - OIL	CF6-50 (Boeing)	AR	1
9187M47G01	TUBE - OIL	CF6-50 (Boeing)	OH	1
9187M47G01	TUBE - OIL	CF6-50 (Boeing)	AR	1
9187M73P124	COUPLING - GROOVED CLAMP	CF6-80C2	SV	1
9187M73P128	COUPLING - GROOVED CLAMP	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9187M73P128	COUPLING - GROOVED CLAMP	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9187M73P128	COUPLING - GROOVED CLAMP	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9187M73P128	COUPLING - GROOVED CLAMP	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9187M73P128	COUPLING - GROOVED CLAMP	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9187M73P128	COUPLING - GROOVED CLAMP	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	3
9187M73P136	COUPLING - GROOVED CLAMP	CF6-80C2, CF6-80A	AR	1
9187M73P136	COUPLING - GROOVED CLAMP	CF6-80C2, CF6-80A	AR	1
9187M73P156	COUPLING - GROOVED CLAMP	CF6-80C2, CF6-80A	AR	2
9187M73P156	COUPLING - GROOVED CLAMP	CF6-80C2, CF6-80A	NS	1
9187M73P156	COUPLING - GROOVED CLAMP	CF6-80C2, CF6-80A	SV	1
9187M73P164	COUPLING	CF6-80C2	NE	1
9187M73P180	COUPLING	CF6-80C2	SV	1
9187M73P180	COUPLING	CF6-80C2	NE	1
9187M73P24	COUPLING - GROOVED CLAMP	CF6-80C2	AR	1
9187M73P24	COUPLING - GROOVED CLAMP	CF6-80C2	AR	1
9187M73P24	COUPLING - GROOVED CLAMP	CF6-80C2	SV	1
9187M73P24	COUPLING - GROOVED CLAMP	CF6-80C2	AR	6
9187M73P28	COUPLING - GROOVED CLAMP	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9187M73P28	COUPLING - GROOVED CLAMP	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9187M73P40	COUPLING - GROOVED CLAMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9187M73P40	COUPLING - GROOVED CLAMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9187M73P48	COUPLING - GROOVED CLAMP	CF6-80C2	SV	1
9187M73P56	COUPLING - GROOVED CLAMP	CF6-80C2, CF6-80A	AR	1
9187M73P56	COUPLING - GROOVED CLAMP	CF6-80C2, CF6-80A	AR	1
9187M74G01	BRACKET ASSY - FIRE DET	CF6-50	AR	1
9187M74G01	BRACKET ASSY - FIRE DET	CF6-50	SV	1
9187M76G01	BRACKET ASSY - FIRE DET	CF6-50	AR	1
9187M76G01	BRACKET ASSY - FIRE DET	CF6-50	SV	1
9187M76G01	BRACKET ASSY - FIRE DET	CF6-50	SV	1
9191M36P01	CAP AND PLUG	CF6-80C2, CF6-50	SV	1
9191M36P02	CAP AND PLUG	CF6-80C2	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9191M36P02	CAP AND PLUG	CF6-80C2	AR	1
9191M36P02	CAP AND PLUG	CF6-80C2	NS	2
9191M36P02	CAP AND PLUG	CF6-80C2	NS	3
9191M43P01	HOSE ASSY - TEFLON	CF6-50	NE	1
9191M72G01	TUBE ASSY - PYLON OIL	CF6-50	AR	1
9191M72G01	TUBE ASSY - PYLON OIL	CF6-50	AR	1
9191M72G01	TUBE ASSY - PYLON OIL	CF6-50	AR	1
9191M72G01	TUBE ASSY - PYLON OIL	CF6-50	AR	1
9191M72G01	TUBE ASSY - PYLON OIL	CF6-50	AR	1
9191M72G01	TUBE ASSY - PYLON OIL	CF6-50	AR	1
9191M72G01	TUBE ASSY - PYLON OIL	CF6-50	AR	1
9191M89P001A	BRACKET - CABLE	CF6-50	SV	1
9191M89P001A	BRACKET - CABLE	CF6-50	SV	1
9191M99P02	BRACKET	CF6-50 (Boeing)	OH	1
9192M49G01	LINER ASSY - INR COMB CHMBR	CF6-50 (Boeing)	AR	1
9192M49G06	LINER ASSY - INR COMB CHMBR	CF6-50 (LMCO)	AR	1
9192M49G06	LINER ASSY - INR COMB CHMBR	CF6-50 (LMCO)	AR	1
9192M49G11	LINER ASSY - INR COMB CHMBR	CF6-50	AR	1
9192M69P04	ADAPTER - PLUG	CF6-80A	NS	2
9192M69P04	ADAPTER - PLUG	CF6-80A	SV	2
9192M69P08	ADAPTER - PLUG	CF6-80A	OH	1
9192M69P08	ADAPTER - PLUG	CF6-80A	NE	2
9192M88G23	NOZZLE ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M88G23	NOZZLE ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M88G23	NOZZLE ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M88G23	NOZZLE ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M88G23	NOZZLE ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M88G23	NOZZLE ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M88G23	NOZZLE ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M88G23	NOZZLE ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M88G23	NOZZLE ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M88G23	NOZZLE ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M88G23	NOZZLE ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M88G23	NOZZLE ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9192M95G05	SHROUD ASSY - STTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
91934U105	BEARING - BALL NO. 4B	CF6-80C2, CF6-80A	AR	1
91934U105	BEARING - BALL NO. 4B	CF6-80C2, CF6-80A	OH	1
9193M69P16	SPACER - SLEEVE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
9193M69P16	SPACER - SLEEVE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9193M69P16	SPACER - SLEEVE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	100
9193M69P18	SPACER - SLEEVE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	10
9193M69P18	SPACER - SLEEVE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9193M69P18	SPACER - SLEEVE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9193M69P19	SPACER - SLEEVE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	3
9193M69P19	SPACER - SLEEVE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	3
9193M69P19	SPACER - SLEEVE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9193M69P20	SPACER - SLEEVE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9193M69P20	SPACER - SLEEVE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	4
9193M69P21	SPACER - SLEEVE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9193M69P21	SPACER - SLEEVE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	62
9193M69P21	SPACER - SLEEVE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	2

Part Number	Part Description	Engine Type	Condition	Quantity
9193M69P21	SPACER - SLEEVE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9193M69P22	SPACER - SLEEVE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	39
9193M69P22	SPACER - SLEEVE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9193M69P22	SPACER - SLEEVE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9193M69P22	SPACER - SLEEVE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9193M69P23	SPACER - SLEEVE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	74
9193M69P23	SPACER - SLEEVE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	42
9193M69P23	SPACER - SLEEVE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9193M69P23	SPACER - SLEEVE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9193M69P23	SPACER - SLEEVE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9193M69P23	SPACER - SLEEVE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9193M69P24	SPACER - SLEEVE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	16
9193M69P24	SPACER - SLEEVE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	2

Part Number	Part Description	Engine Type	Condition	Quantity
9193M69P25	SPACER - SLEEVE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	3
9193M69P25	SPACER - SLEEVE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	3
9193M69P25	SPACER - SLEEVE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	6
9193M69P25	SPACER - SLEEVE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	6
9193M69P26	SPACER - SLEEVE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	6
9193M69P26	SPACER - SLEEVE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9193M69P26	SPACER - SLEEVE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	24
9193M69P26	SPACER - SLEEVE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9193M69P31	SPACER - SLEEVE	CF6-50 (LMCO)	NS	1
9193M69P31	SPACER - SLEEVE	CF6-50 (LMCO)	NS	2
9193M69P31	SPACER - SLEEVE	CF6-50 (LMCO)	NS	2
9193M69P31	SPACER - SLEEVE	CF6-50 (LMCO)	NS	8
9193M69P33	SPACER - SLEEVE	CF6-80C2	NS	34
9193M69P33	SPACER - SLEEVE	CF6-80C2	NE	1
9193M69P34	SPACER - SLEEVE	CF6-80C2	NE	19
9193M69P39	SPACER	CF6-80C2	NE	18
9193M69P39	SPACER	CF6-80C2	NE	2
9193M69P39	SPACER	CF6-80C2	NE	2
9193M78P10	SPACER - SLEEVE	CF6-80C2	NS	7
9193M78P10	SPACER - SLEEVE	CF6-80C2	SV	2
9193M78P10	SPACER - SLEEVE	CF6-80C2	NS	6
9193M78P10	SPACER - SLEEVE	CF6-80C2	NS	1
9193M78P13	SPACER	CF6-80C2	AR	84
9193M78P13	SPACER	CF6-80C2	NS	2
9193M78P13	SPACER	CF6-80C2	NS	2
9194M11P001A	BRACKET - LEAD	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9194M11P001A	BRACKET - LEAD	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
9194M14G02	MANIFOLD ASSY - STG 8 AIR	CF6-50	AR	1
9194M14G02	MANIFOLD ASSY - STG 8 AIR	CF6-50	AR	1
9194M14G02	MANIFOLD ASSY - STG 8 AIR	CF6-50	OH	1
9194M14G02	MANIFOLD ASSY - STG 8 AIR	CF6-50	OH	1
9194M14G02	MANIFOLD ASSY - STG 8 AIR	CF6-50	AR	1
9194M14G02	MANIFOLD ASSY - STG 8 AIR	CF6-50	AR	1
9194M14G02	MANIFOLD ASSY - STG 8 AIR	CF6-50	AR	1
9194M14G02	MANIFOLD ASSY - STG 8 AIR	CF6-50	AR	1
9194M14G02	MANIFOLD ASSY - STG 8 AIR	CF6-50	AR	1
9194M14G02	MANIFOLD ASSY - STG 8 AIR	CF6-50	AR	1
9194M14G02	MANIFOLD ASSY - STG 8 AIR	CF6-50	AR	1
9194M14G02	MANIFOLD ASSY - STG 8 AIR	CF6-50	AR	1
9194M14G02	MANIFOLD ASSY - STG 8 AIR	CF6-50	AR	1
9194M14G02	MANIFOLD ASSY - STG 8 AIR	CF6-50	AR	1
9194M14G02	MANIFOLD ASSY - STG 8 AIR	CF6-50	AR	1
9194M14G02	MANIFOLD ASSY - STG 8 AIR	CF6-50	AR	1
9194M14G02	MANIFOLD ASSY - STG 8 AIR	CF6-50	AR	1
9194M14G02	MANIFOLD ASSY - STG 8 AIR	CF6-50	AR	1
9194M18G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M18G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M18G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M18G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M18G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M18G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M18G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
9194M23G01	MANIFOLD - DRAIN CAN PUMP	CF6-50 (LMCO)	AR	1
9194M23G01	MANIFOLD - DRAIN CAN PUMP	CF6-50 (LMCO)	AR	1
9194M33P03	TUBE/HOSE ASSY - OIL	CF6-50	AR	1
9194M33P03	TUBE/HOSE ASSY - OIL	CF6-50	AR	1
9194M33P03	TUBE/HOSE ASSY - OIL	CF6-50	AR	1
9194M33P03	TUBE/HOSE ASSY - OIL	CF6-50	AR	1
9194M33P03	TUBE/HOSE ASSY - OIL	CF6-50	AR	1
9194M33P03	TUBE/HOSE ASSY - OIL	CF6-50	AR	1
9194M33P03	TUBE/HOSE ASSY - OIL	CF6-50	AR	1
9194M33P03	TUBE/HOSE ASSY - OIL	CF6-50	AR	1
9194M33P03	TUBE/HOSE ASSY - OIL	CF6-50	AR	1
9194M36P001A	BRACKET - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M59P001	BRACKET - ANGLE	CF6-50	AR	1
9194M59P001A	BRACKET - ANGLE	CF6-50 (Boeing)	NS	1
9194M59P001A	BRACKET - ANGLE	CF6-50 (Boeing)	SV	1
9194M60G01	BRACKET ASSY - ACCLRM	CF6-50 (LMCO)	SV	1
9194M61G01	TUBE ASSY - TEMP FWD AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M61G01	TUBE ASSY - TEMP FWD AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M61G01	TUBE ASSY - TEMP FWD AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M61G01	TUBE ASSY - TEMP FWD AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M61G01	TUBE ASSY - TEMP FWD AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M61G01	TUBE ASSY - TEMP FWD AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M61G01	TUBE ASSY - TEMP FWD AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M61G01	TUBE ASSY - TEMP FWD AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M61G01	TUBE ASSY - TEMP FWD AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M61G01	TUBE ASSY - TEMP FWD AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M61G01	TUBE ASSY - TEMP FWD AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M61G01	TUBE ASSY - TEMP FWD AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M61G01	TUBE ASSY - TEMP FWD AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M61G01	TUBE ASSY - TEMP FWD AIR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M63P001B	BRACKET - ANGLE	CF6-50 (Boeing)	NS	1
9194M64P01	COVER	CF6-50	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
9194M76P04	TUBE - ROD END FUEL HOSE	CF6-50 (LMCO)	AR	1
9194M76P05	TUBE - ROD END FUEL HOSE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M76P05	TUBE - ROD END FUEL HOSE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M76P05	TUBE - ROD END FUEL HOSE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M76P05	TUBE - ROD END FUEL HOSE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M76P05	TUBE - ROD END FUEL HOSE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M76P05	TUBE - ROD END FUEL HOSE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M76P05	TUBE - ROD END FUEL HOSE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M77P04	TUBE - HEAD END FUEL HOSE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M77P04	TUBE - HEAD END FUEL HOSE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M77P04	TUBE - HEAD END FUEL HOSE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M77P04	TUBE - HEAD END FUEL HOSE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M77P04	TUBE - HEAD END FUEL HOSE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9194M77P04	TUBE - HEAD END FUEL HOSE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9194M77P04	TUBE - HEAD END FUEL HOSE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9194M77P04	TUBE - HEAD END FUEL HOSE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M77P04	TUBE - HEAD END FUEL HOSE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M77P04	TUBE - HEAD END FUEL HOSE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M77P04	TUBE - HEAD END FUEL HOSE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9194M77P05	TUBE - HEAD END FUEL HOSE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M77P05	TUBE - HEAD END FUEL HOSE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M77P05	TUBE - HEAD END FUEL HOSE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M77P05	TUBE - HEAD END FUEL HOSE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M77P05	TUBE - HEAD END FUEL HOSE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9194M90P001A	BRACKET	CF6-50 (LMCO), CF6-50 (Boeing)	NS	3

Part Number	Part Description	Engine Type	Condition	Quantity
9195M10P01	BEARING - ROD END PLAIN	CF6-50 (Boeing)	OH	1
9195M10P02	BEARING - ROD END PLAIN	CF6-50 (Boeing)	OH	1
9195M10P06	BEARING - ROD END PLAIN	CF6-50 (Boeing)	NS	3
9195M59P01	SPACER - STG 2	CF6-50	NS	18
9195M59P01	SPACER - STG 2	CF6-50	NE	11
9195M59P01	SPACER - STG 2	CF6-50	NS	7
9195M59P02	SPACER - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
9195M71P02	BEARING - NO. 3 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9195M71P02	BEARING - NO. 3 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9195M71P02	BEARING - NO. 3 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9195M71P02	BEARING - NO. 3 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9195M71P02	BEARING - NO. 3 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9195M71P02	BEARING - NO. 3 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9195M71P02	BEARING - NO. 3 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9195M71P02	BEARING - NO. 3 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9195M71P02	BEARING - NO. 3 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9195M71P02	BEARING - NO. 3 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9195M71P02	BEARING - NO. 3 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9195M71P02	BEARING - NO. 3 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9195M71P02	BEARING - NO. 3 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9195M71P02	BEARING - NO. 3 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9195M71P02	BEARING - NO. 3 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9195M90G01	ADAPTER - LUBE PUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9195M90G01	ADAPTER - LUBE PUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9195M90G01	ADAPTER - LUBE PUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9195M90G01	ADAPTER - LUBE PUMP	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9195M90G01	ADAPTER - LUBE PUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9195M90G01	ADAPTER - LUBE PUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9195M90G01	ADAPTER - LUBE PUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9195M90G01	ADAPTER - LUBE PUMP	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9196M17P01	COVER	CF6-50	AR	1
9196M27G01	OUTER - FAN STATOR	CF6-50	OH	1
9196M27G02	OUTER - FAN STATOR	CF6-50	AR	1
9196M36P01	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9196M36P01	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9196M36P01	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9196M44G01	MANIFOLD ASSEMBLY	CF6-50 (LMCO)	OH	1
9196M44G01	MANIFOLD ASSEMBLY	CF6-50 (LMCO)	AR	1
9196M44G01	MANIFOLD ASSEMBLY	CF6-50 (LMCO)	AR	1
9196M44G01	MANIFOLD ASSEMBLY	CF6-50 (LMCO)	AR	1
9196M44G01	MANIFOLD ASSEMBLY	CF6-50 (LMCO)	AR	1
9196M44G01	MANIFOLD ASSEMBLY	CF6-50 (LMCO)	AR	1
9196M44G01	MANIFOLD ASSEMBLY	CF6-50 (LMCO)	AR	1
9196M44G01	MANIFOLD ASSEMBLY	CF6-50 (LMCO)	AR	1
9196M44G01	MANIFOLD ASSEMBLY	CF6-50 (LMCO)	OH	1
9196M44G01	MANIFOLD ASSEMBLY	CF6-50 (LMCO)	OH	1
9196M44G01	MANIFOLD ASSEMBLY	CF6-50 (LMCO)	OH	1
9196M44G01	MANIFOLD ASSEMBLY	CF6-50 (LMCO)	OH	1
9196M44G01	MANIFOLD ASSEMBLY	CF6-50 (LMCO)	OH	1
9196M44G01	MANIFOLD ASSEMBLY	CF6-50 (LMCO)	OH	1
9196M44G01	MANIFOLD ASSEMBLY	CF6-50 (LMCO)	OH	1
9196M44G01	MANIFOLD ASSEMBLY	CF6-50 (LMCO)	OH	1
9196M44G01	MANIFOLD ASSEMBLY	CF6-50 (LMCO)	OH	1
9196M44G01	MANIFOLD ASSEMBLY	CF6-50 (LMCO)	OH	1
9196M44G04	#1 BEARING MANIFOLD	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9196M44G04	#1 BEARING MANIFOLD	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9196M44G04	#1 BEARING MANIFOLD	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9197M11G01	BRACKET - ANGLE	CF6-50	AR	1
9197M11G01	BRACKET - ANGLE	CF6-50	AR	1
9197M12G01	BRACKET - ANGLE	CF6-50	AR	1
9197M12G01	BRACKET - ANGLE	CF6-50	AR	1

[illegible]

[illegible]

Part Number	Part Description	Engine Type	Condition	Quantity
9198M81G01	SEAL ASSY - STG 2	CF6-50	AR	1
9198M81G01	SEAL ASSY - STG 2	CF6-50	AR	1
9198M81G01	SEAL ASSY - STG 2	CF6-50	AR	1
9198M81G01	SEAL ASSY - STG 2	CF6-50	AR	1
9198M81G01	SEAL ASSY - STG 2	CF6-50	AR	1
9198M81G01	SEAL ASSY - STG 2	CF6-50	AR	1
9198M81G01	SEAL ASSY - STG 2	CF6-50	AR	1
9198M81G01	SEAL ASSY - STG 2	CF6-50	AR	1
9198M81G01	SEAL ASSY - STG 2	CF6-50	AR	1
9198M81G01	SEAL ASSY - STG 2	CF6-50	AR	1
9198M81G01	SEAL ASSY - STG 2	CF6-50	AR	1
9198M81G01	SEAL ASSY - STG 2	CF6-50	AR	1
9198M81G01	SEAL ASSY - STG 2	CF6-50	AR	1
9198M81G02	SEAL ASSY - STG 2	CF6-50	AR	16
9198M81G02	SEAL ASSY - STG 2	CF6-50	AR	16
9198M81G05	SEAL ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	15
9198M81G05	SEAL ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9198M81G05	SEAL ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	SV	16
9198M81G05	SEAL ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
9198M81G05	SEAL ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
9198M81G05	SEAL ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	15
9198M81G05	SEAL ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
9198M81G05	SEAL ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	11
9198M81G05	SEAL ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9198M81G05	SEAL ASSY - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9199M48G01	BRACKET - ANGLE	CF6-50 (LMCO)	SV	1
9199M59P001A	BRACKET	CF6-50	OH	1
9199M59P001A	BRACKET	CF6-50	NS	1
9199M59P001A	BRACKET	CF6-50	AR	1
9199M74G01	BRACKET ASSY - TUBE	CF6-50	AR	1
9200M10G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO)	AR	1
9200M10G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO)	AR	1
9200M10G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO)	AR	1
9200M10G01	TUBE ASSY - AFT OIL	CF6-50 (LMCO)	AR	1
9200M11G01	MANIFOLD ASSY - MID OIL	CF6-50	AR	1
9200M11G01	MANIFOLD ASSY - MID OIL	CF6-50	AR	1
9200M11G01	MANIFOLD ASSY - MID OIL	CF6-50	AR	1
9200M11G01	MANIFOLD ASSY - MID OIL	CF6-50	AR	1
9200M11G01	MANIFOLD ASSY - MID OIL	CF6-50	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9200M11G01	MANIFOLD ASSY - MID OIL	CF6-50	AR	1
9200M11G01	MANIFOLD ASSY - MID OIL	CF6-50	AR	1
9200M12G02	MANIFOLD ASSY	CF6-50	AR	1
9200M12G02	MANIFOLD ASSY	CF6-50	AR	1
9200M15G03	TUBE ASSY - MID OIL	CF6-50 (LMCO)	AR	1
9200M15G03	TUBE ASSY - MID OIL	CF6-50 (LMCO)	AR	1
9200M15G03	TUBE ASSY - MID OIL	CF6-50 (LMCO)	AR	1
9200M15G03	TUBE ASSY - MID OIL	CF6-50 (LMCO)	AR	1
9200M16G02	TUBE ASSY - MID OIL	CF6-50	AR	1
9200M16G02	TUBE ASSY - MID OIL	CF6-50	AR	1
9200M16G02	TUBE ASSY - MID OIL	CF6-50	AR	1
9200M16G02	TUBE ASSY - MID OIL	CF6-50	AR	1
9200M17G01	MANIFOLD ASSY - FUEL SHRD	CF6-50	AR	1
9200M17G01	MANIFOLD ASSY - FUEL SHRD	CF6-50	AR	1
9200M17G03	MANIFOLD ASSY - FUEL SHRD	CF6-50 (Boeing)	AR	1
9200M17G03	MANIFOLD ASSY - FUEL SHRD	CF6-50 (Boeing)	AR	1
9200M17G03	MANIFOLD ASSY - FUEL SHRD	CF6-50 (Boeing)	AR	1
9200M17G06	MANIFOLD ASSY - FUEL SHRD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M17G06	MANIFOLD ASSY - FUEL SHRD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M17G06	MANIFOLD ASSY - FUEL SHRD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M17G06	MANIFOLD ASSY - FUEL SHRD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M46P01	TUBE ASSY - XFR GRBX OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M46P01	TUBE ASSY - XFR GRBX OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M46P01	TUBE ASSY - XFR GRBX OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M46P01	TUBE ASSY - XFR GRBX OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M46P01	TUBE ASSY - XFR GRBX OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M46P01	TUBE ASSY - XFR GRBX OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M46P01	TUBE ASSY - XFR GRBX OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M46P01	TUBE ASSY - XFR GRBX OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M46P01	TUBE ASSY - XFR GRBX OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9200M46P01	TUBE ASSY - XFR GRBX OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M46P01	TUBE ASSY - XFR GRBX OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M46P01	TUBE ASSY - XFR GRBX OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M46P01	TUBE ASSY - XFR GRBX OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M82G01	TUBE ASSY - OIL C SCAV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M82G01	TUBE ASSY - OIL C SCAV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M82G01	TUBE ASSY - OIL C SCAV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M82G01	TUBE ASSY - OIL C SCAV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M82G01	TUBE ASSY - OIL C SCAV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M82G01	TUBE ASSY - OIL C SCAV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M82G01	TUBE ASSY - OIL C SCAV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M82G01	TUBE ASSY - OIL C SCAV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M82G01	TUBE ASSY - OIL C SCAV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M82G01	TUBE ASSY - OIL C SCAV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M82G03	TUBE ASSY - OIL C SCAV	CF6-50 (Boeing)	AR	1
9200M82G03	TUBE ASSY - OIL C SCAV	CF6-50 (Boeing)	OH	1
9200M82G03	TUBE ASSY - OIL C SCAV	CF6-50 (Boeing)	AR	1
9200M84G01	TUBE ASSY - B SUMP OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M84G01	TUBE ASSY - B SUMP OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M84G01	TUBE ASSY - B SUMP OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M84G01	TUBE ASSY - B SUMP OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M84G01	TUBE ASSY - B SUMP OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M84G01	TUBE ASSY - B SUMP OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9200M84G01	TUBE ASSY - B SUMP OIL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9200M84G01	TUBE ASSY - B SUMP OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9200M84G01	TUBE ASSY - B SUMP OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M84G01	TUBE ASSY - B SUMP OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M97G01	TUBE - OIL PUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M97G01	TUBE - OIL PUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M97G01	TUBE - OIL PUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M97G01	TUBE - OIL PUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M97G01	TUBE - OIL PUMP	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9200M97G01	TUBE - OIL PUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M97G01	TUBE - OIL PUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M97G01	TUBE - OIL PUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M97G01	TUBE - OIL PUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M97G01	TUBE - OIL PUMP	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9200M97G01	TUBE - OIL PUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M97G01	TUBE - OIL PUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9200M97G01	TUBE - OIL PUMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9202M44G07	GEARBOX ASSY - ACCESSORY	CF6-50 (LMCO)	AR	1
9202M44G07	GEARBOX ASSY - ACCESSORY	CF6-50 (LMCO)	AR	1
9202M44G08	GRBX ASSY - ACCESSORY EMU	CF6-80A	AR	1
9202M53G02	SEAL ASSY - BRG 7 STA OIL	CF6-50 (Boeing)	AR	1
9202M84G02	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1
9202M84G02	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1
9202M84G02	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1
9202M84G02	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1
9202M84G02	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9202M84G02	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1
9202M84G02	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1
9202M84G02	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1
9202M84G02	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1
9202M84G02	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1
9202M84G02	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1
9202M84G02	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1
9202M84G02	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1
9202M84G02	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	OH	1
9202M84G02	NOZZLE ASSY - ACCESS GRBX	CF6-50 (LMCO)	AR	1
9202M85P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9202M85P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9202M85P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9202M85P01	HOUSING - BEARING	CF6-50 (LMCO)	SV	1
9202M85P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9202M85P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9202M85P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9202M85P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9202M85P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9202M85P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9202M85P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9202M85P01	HOUSING - BEARING	CF6-50 (LMCO)	OH	1
9202M85P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9202M87P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9202M87P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9202M87P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9202M87P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9202M87P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9202M87P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9202M87P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9202M87P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9202M87P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9202M87P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9202M87P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9202M87P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9202M87P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9202M87P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9202M87P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9202M87P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9202M87P01	HOUSING - BEARING	CF6-50 (LMCO)	OH	1
9202M87P01	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9202M89P16	BEARING - SELF ALIGN PL	CF6-80C2, CF6-80A, CF6-50	NS	2
9202M91P06	BEARING - PLAIN SELF	CF6-50 (Boeing)	NS	1
9202M91P06	BEARING - PLAIN SELF	CF6-50 (Boeing)	NS	1
9202M92P01	BEARING - SPHER ROD END	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9204M13P02	BEARING - PLAIN SPHERICAL (SPD)	CF6-80A	NS	14
9204M13P02	BEARING - PLAIN SPHERICAL (SPD)	CF6-80A	NS	8
9204M13P17	BEARING - PLAIN SPHERICAL (SPD)	CF6-80A, CF6-50 (LMCO)	NS	4
9204M13P17	BEARING - PLAIN SPHERICAL (SPD)	CF6-80A, CF6-50 (LMCO)	NS	38
9204M13P17	BEARING - PLAIN SPHERICAL (SPD)	CF6-80A, CF6-50 (LMCO)	NS	1
9204M31P04	DISK - FAN STG 1	CF6-50	AR	1
9204M36P02	RING - TABBED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9204M36P02	RING - TABBED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9204M36P02	RING - TABBED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9204M36P02	RING - TABBED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9204M36P02	RING - TABBED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9204M36P02	RING - TABBED	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9204M36P02	RING - TABBED	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9204M36P02	RING - TABBED	CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9204M38G01	TUBE - CENTER VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9204M38G01	TUBE - CENTER VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9204M38G01	TUBE - CENTER VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9204M38G01	TUBE - CENTER VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9204M38G01	TUBE - CENTER VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9204M38G01	TUBE - CENTER VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9204M38G01	TUBE - CENTER VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9204M87P01	SPACER - RETAINER	CF6-50 (Boeing)	AR	21
9204M87P01	SPACER - RETAINER	CF6-50 (Boeing)	AR	38
9204M87P01	SPACER - RETAINER	CF6-50 (Boeing)	AR	38
9204M87P01	SPACER - RETAINER	CF6-50 (Boeing)	AR	38
9204M87P01	SPACER - RETAINER	CF6-50 (Boeing)	OH	9
9204M87P01	SPACER - RETAINER	CF6-50 (Boeing)	AR	27
9204M87P01	SPACER - RETAINER	CF6-50 (Boeing)	OH	4
9204M87P01	SPACER - RETAINER	CF6-50 (Boeing)	AR	37
9204M87P01	SPACER - RETAINER	CF6-50 (Boeing)	AR	38
9204M87P02	SPACER - RETAINER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	35
9204M87P02	SPACER - RETAINER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M87P02	SPACER - RETAINER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M87P02	SPACER - RETAINER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M87P02	SPACER - RETAINER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9204M87P02	SPACER - RETAINER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M87P02	SPACER - RETAINER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9204M87P02	SPACER - RETAINER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	11
9204M87P02	SPACER - RETAINER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M87P02	SPACER - RETAINER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M87P02	SPACER - RETAINER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M87P02	SPACER - RETAINER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M87P02	SPACER - RETAINER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M87P02	SPACER - RETAINER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38

Part Number	Part Description	Engine Type	Condition	Quantity
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	7
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	NS	10
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	25
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38

Part Number	Part Description	Engine Type	Condition	Quantity
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M88P02	SPACER - CHANNEL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	37
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	37
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	12
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	32
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M89P02	SPACER - BLADE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
9204M91G01	LINK ASSY - FAN FRAME	CF6-50 (LMCO)	OH	1
9204M91G01	LINK ASSY - FAN FRAME	CF6-50 (LMCO)	OH	1
9204M91G01	LINK ASSY - FAN FRAME	CF6-50 (LMCO)	AR	1
9204M91G01	LINK ASSY - FAN FRAME	CF6-50 (LMCO)	AR	1
9204M91G01	LINK ASSY - FAN FRAME	CF6-50 (LMCO)	AR	1
9204M91G01	LINK ASSY - FAN FRAME	CF6-50 (LMCO)	AR	1
9204M91G01	LINK ASSY - FAN FRAME	CF6-50 (LMCO)	OH	1
9204M91G01	LINK ASSY - FAN FRAME	CF6-50 (LMCO)	OH	1
9204M91G01	LINK ASSY - FAN FRAME	CF6-50 (LMCO)	AR	1
9204M92G03	MOUNT ASSY - FWD ENGINE	CF6-50 (LMCO)	AR	1
9204M92G03	MOUNT ASSY - FWD ENGINE	CF6-50 (LMCO)	AR	1
9204M92G11	MOUNT - ENGINE FWD	CF6-80A	SV	1
9204M92G11	MOUNT - ENGINE FWD	CF6-80A	AR	1
9204M92G13	MOUNT ASSY - FWD ENGINE	CF6-50 (LMCO)	OH	1
9204M92G13	MOUNT ASSY - FWD ENGINE	CF6-50 (LMCO)	OH	1
9204M92G14	MOUNT - ENGINE FWD	CF6-80A	AR	1
9204M93P01	LINK - SWAY	CF6-80A, CF6-50 (LMCO)	AR	1
9204M93P01	LINK - SWAY	CF6-80A, CF6-50 (LMCO)	SV	1
9204M93P01	LINK - SWAY	CF6-80A, CF6-50 (LMCO)	SV	1
9204M93P01	LINK - SWAY	CF6-80A, CF6-50 (LMCO)	SV	1
9204M93P01	LINK - SWAY	CF6-80A, CF6-50 (LMCO)	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
9204M93P01	LINK - SWAY	CF6-80A, CF6-50 (LMCO)	AR	1
9204M93P01	LINK - SWAY	CF6-80A, CF6-50 (LMCO)	OH	1
9204M93P01	LINK - SWAY	CF6-80A, CF6-50 (LMCO)	OH	1
9204M93P01	LINK - SWAY	CF6-80A, CF6-50 (LMCO)	OH	1
9204M93P01	LINK - SWAY	CF6-80A, CF6-50 (LMCO)	OH	1
9204M93P01	LINK - SWAY	CF6-80A, CF6-50 (LMCO)	AR	1
9204M93P01	LINK - SWAY	CF6-80A, CF6-50 (LMCO)	AR	1
9204M93P01	LINK - SWAY	CF6-80A, CF6-50 (LMCO)	OH	1
9204M93P01	LINK - SWAY	CF6-80A, CF6-50 (LMCO)	OH	1
9204M93P01	LINK - SWAY	CF6-80A, CF6-50 (LMCO)	AR	1
9204M93P01	LINK - SWAY	CF6-80A, CF6-50 (LMCO)	OH	1
9204M93P01	LINK - SWAY	CF6-80A, CF6-50 (LMCO)	OH	1
9204M93P01	LINK - SWAY	CF6-80A, CF6-50 (LMCO)	OH	1
9204M93P01	LINK - SWAY	CF6-80A, CF6-50 (LMCO)	OH	1
9204M93P01	LINK - SWAY	CF6-80A, CF6-50 (LMCO)	SV	1
9204M93P01	LINK - SWAY	CF6-80A, CF6-50 (LMCO)	OH	1
9204M93P01	LINK - SWAY	CF6-80A, CF6-50 (LMCO)	OH	1
9204M94P01	LINK - LH	CF6-50 (LMCO)	OH	1
9204M94P01	LINK - LH	CF6-50 (LMCO)	AR	1
9204M94P01	LINK - LH	CF6-50 (LMCO)	OH	1
9204M94P01	LINK - LH	CF6-50 (LMCO)	AR	1
9204M94P02	LINK - RH	CF6-50 (LMCO)	OH	1
9204M94P02	LINK - RH	CF6-50 (LMCO)	OH	1
9204M94P02	LINK - RH	CF6-50 (LMCO)	OH	1
9204M94P02	LINK - RH	CF6-50 (LMCO)	OH	1
9204M94P02	LINK - RH	CF6-50 (LMCO)	AR	1
9204M94P02	LINK - RH	CF6-50 (LMCO)	AR	1
9204M94P02	LINK - RH	CF6-50 (LMCO)	OH	1
9204M94P02	LINK - RH	CF6-50 (LMCO)	OH	1
9204M94P03	LINK - SIDE	CF6-80A	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9204M98P01	SPACER .387 IN	CF6-80A, CF6-50 (LMCO)	SV	3
9204M98P01	SPACER .387 IN	CF6-80A, CF6-50 (LMCO)	NS	1
9204M98P01	SPACER .387 IN	CF6-80A, CF6-50 (LMCO)	NS	7
9204M98P02	SPACER .387 IN	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	3
9204M98P03	SPACER .518 IN	CF6-80A, CF6-50 (LMCO)	NS	5
9204M98P05	SPACER (.513-.524)	CF6-50	NE	1
9204M98P05	SPACER (.513-.524)	CF6-50	NE	2
9204M98P05	SPACER (.513-.524)	CF6-50	NE	1
9204M99P02	BEARING - PLAIN	CF6-80C2, CF6-80A, CF6-50	NS	2
9204M99P02	BEARING - PLAIN	CF6-80C2, CF6-80A, CF6-50	NS	2
9205M51G01	LINK - CONNECTING IGV	CF6-50	AR	2
9205M51G02	LINK - CONNECTING STG 1	CF6-50 (LMCO)	AR	1
9205M51G02	LINK - CONNECTING STG 1	CF6-50 (LMCO)	AR	1
9205M51G03	LINK - CONNECTING STG 2	CF6-50	AR	1
9205M51G03	LINK - CONNECTING STG 2	CF6-50	AR	1
9205M52G04	CASE ASSY - TURB MID FRAME	CF6-50 (LMCO)	AR	1
9205M93P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9205M93P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9205M93P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9205M93P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9205M93P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9205M93P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9205M93P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9205M93P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9205M93P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9205M93P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9205M93P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9205M93P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9205M93P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9205M93P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9205M93P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9206M19P001A	BRACKET	CF6-80A, CF6-50 (LMCO)	NS	2
9206M19P001A	BRACKET	CF6-80A, CF6-50 (LMCO)	NS	1
9206M19P001A	BRACKET	CF6-80A, CF6-50 (LMCO)	OH	2
9206M19P001A	BRACKET	CF6-80A, CF6-50 (LMCO)	OH	1
9206M19P001A	BRACKET	CF6-80A, CF6-50 (LMCO)	NS	1
9206M21P001A	BRACKET	CF6-50 (LMCO)	AR	2
9206M21P001A	BRACKET	CF6-50 (LMCO)	SV	1
9206M21P001A	BRACKET	CF6-50 (LMCO)	NS	5
9206M21P001A	BRACKET	CF6-50 (LMCO)	SV	2
9206M21P001A	BRACKET	CF6-50 (LMCO)	OH	1
9206M21P001A	BRACKET	CF6-50 (LMCO)	OH	1
9206M21P001A	BRACKET	CF6-50 (LMCO)	NS	1
9206M22P001A	RETAINER	CF6-50 (LMCO)	SV	2
9206M22P001A	RETAINER	CF6-50 (LMCO)	OH	2
9206M22P001A	RETAINER	CF6-50 (LMCO)	OH	2
9206M59P03	SPACER - IGV STG 1 - 2	CF6-80C2	NE	50
9206M59P07	SPACER - IGV STG 1 - 2	CF6-80C2	NE	4
9206M59P07	SPACER - IGV STG 1 - 2	CF6-80C2	NE	6
9206M59P07	SPACER - IGV STG 1 - 2	CF6-80C2	NS	10
9206M59P07	SPACER - IGV STG 1 - 2	CF6-80C2	NS	5
9206M59P08	SPACER - IGV STG 1 - 2	CF6-80C2	NS	29
9206M59P09	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A	OH	4
9206M59P10	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO)	AR	100
9206M59P10	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO)	AR	23
9206M59P10	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO)	AR	39
9206M59P10	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO)	AR	29
9206M59P10	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO)	SV	6

Part Number	Part Description	Engine Type	Condition	Quantity
9206M59P11	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9206M59P11	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
9206M59P11	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	19
9206M59P11	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	2
9206M59P11	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	51
9206M59P11	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	50
9206M59P11	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	46
9206M59P11	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	10
9206M59P11	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9206M59P11	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	2
9206M59P11	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	73
9206M59P11	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	34

Part Number	Part Description	Engine Type	Condition	Quantity
9206M59P11	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	110
9206M59P12	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
9206M59P12	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9206M59P12	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
9206M59P12	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	14
9206M59P12	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	2
9206M59P12	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9206M59P12	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
9206M59P12	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	32
9206M59P12	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	50
9206M59P12	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	100
9206M59P12	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	57

Part Number	Part Description	Engine Type	Condition	Quantity
9206M59P13	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	11
9206M59P13	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	23
9206M59P13	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
9206M59P13	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	11
9206M59P13	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	23
9206M59P13	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9206M59P13	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	11
9206M59P13	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	6
9206M59P13	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
9206M59P14	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO)	AR	20
9206M59P14	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO)	AR	1
9206M59P14	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO)	AR	1
9206M59P14	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO)	AR	48

Part Number	Part Description	Engine Type	Condition	Quantity
9206M59P14	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NE	1
9206M59P14	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO)	SV	5
9206M59P14	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NE	85
9206M59P14	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NE	1
9206M59P14	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NE	16
9206M59P14	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NS	40
9206M59P14	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NS	110
9206M59P15	HPC STATOR VANE SPACER STG IGV-2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	21
9206M59P15	HPC STATOR VANE SPACER STG IGV-2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	61
9206M59P15	HPC STATOR VANE SPACER STG IGV-2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	13
9206M59P15	HPC STATOR VANE SPACER STG IGV-2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	53
9206M59P15	HPC STATOR VANE SPACER STG IGV-2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	6
9206M59P16	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	55
9206M59P16	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	20
9206M59P17	SPACER - IGV STG 1 - 2	CF6-80A	NE	23

Part Number	Part Description	Engine Type	Condition	Quantity
9206M59P17	SPACER - IGV STG 1 - 2	CF6-80A	AR	2
9206M59P17	SPACER - IGV STG 1 - 2	CF6-80A	AR	2
9206M59P17	SPACER - IGV STG 1 - 2	CF6-80A	AR	2
9206M59P17	SPACER - IGV STG 1 - 2	CF6-80A	AR	1
9206M59P17	SPACER - IGV STG 1 - 2	CF6-80A	AR	36
9206M59P21	SPACER - IGV STG 1 - 2	CF6-80C2, CF6-80A, CF6-50	NE	4
9206M61P02	SPACER - STG 3 - 4	CF6-80A	NE	10
9206M61P04	SPACER - STG 3 - 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	30
9206M61P04	SPACER - STG 3 - 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	49
9206M61P04	SPACER - STG 3 - 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	13
9206M61P04	SPACER - STG 3 - 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	15
9206M61P04	SPACER - STG 3 - 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	17
9206M61P07	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	24
9206M61P08	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9206M61P08	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9206M61P08	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9206M61P08	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	15
9206M61P09	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	46

Part Number	Part Description	Engine Type	Condition	Quantity
9206M61P09	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	7
9206M61P10	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	12
9206M61P10	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9206M61P10	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	9
9206M61P10	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
9206M61P10	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	30
9206M61P10	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	18
9206M61P11	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9206M61P11	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	2
9206M61P11	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9206M61P12	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
9206M61P12	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	5

Part Number	Part Description	Engine Type	Condition	Quantity
9206M61P12	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9206M61P12	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	15
9206M61P12	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	20
9206M61P12	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9206M61P13	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	45
9206M61P13	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
9206M61P13	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9206M61P13	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9206M61P13	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	12
9206M61P13	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	15
9206M61P14	SPACER - STG 3 - 4	CF6-80C2, CF6-80A	AR	12
9206M61P15	SPACER - STG 3 - 4	CF6-80C2, CF6-80A	AR	31
9206M61P15	SPACER - STG 3 - 4	CF6-80C2, CF6-80A	OH	3
9206M61P16	SPACER - STG 3 - 4	CF6-80C2	AR	22
9206M61P17	SPACER - STG 3 - 4	CF6-80C2	AR	5
9206M61P18	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50	NE	10

Part Number	Part Description	Engine Type	Condition	Quantity
9206M61P19	SPACER - STG 3 - 4	CF6-80C2, CF6-80A, CF6-50	NE	2
9206M61P20	SPACER - STG 3 - 4	CF6-80A	NE	2
9206M61P21	SPACER - STG 3 - 4	CF6-80A	NE	19
9206M61P21	SPACER - STG 3 - 4	CF6-80A	NS	5
9207M53P01	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50	NS	2
9207M53P06	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (Boeing)	NS	30
9207M53P06	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (Boeing)	NS	24
9207M53P06	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (Boeing)	NS	2
9207M53P06	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (Boeing)	OH	1
9207M53P07	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (Boeing)	AR	11
9207M53P07	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (Boeing)	NS	25
9207M53P07	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (Boeing)	OH	16
9207M53P07	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (Boeing)	OH	1
9207M53P07	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (Boeing)	NS	1
9207M53P08	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	5
9207M53P08	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	7
9207M53P08	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	21
9207M53P08	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
9207M53P08	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	58
9207M53P08	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9207M53P09	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9207M53P09	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9207M53P09	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	3
9207M53P09	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	112
9207M53P09	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	12
9207M53P09	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	6
9207M53P09	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9207M53P09	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	23
9207M53P09	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
9207M53P09	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9207M53P10	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
9207M53P10	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	45
9207M53P10	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	56
9207M53P10	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9207M53P10	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9207M53P10	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	15
9207M53P10	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9207M53P10	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	26
9207M53P10	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	6
9207M53P11	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	15
9207M53P12	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	22
9207M53P12	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9207M53P13	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO)	AR	12
9207M53P13	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO)	OH	7
9207M53P13	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NS	1
9207M53P13	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NS	1
9207M53P14	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO)	AR	25
9207M53P14	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NE	48
9207M53P15	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO)	AR	5
9207M53P15	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO)	AR	6
9207M53P15	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO)	OH	1
9207M53P15	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NS	4
9207M53P15	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NS	5
9207M53P16	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO)	AR	10
9207M53P16	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NS	5
9207M53P17	SPACER - STG 5	CF6-80C2, CF6-80A	NS	5
9207M53P18	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NE	2
9207M53P18	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NE	4
9207M53P19	SPACER - STG 5	CF6-80C2	NE	10
9207M53P19	SPACER - STG 5	CF6-80C2	NS	4

Part Number	Part Description	Engine Type	Condition	Quantity
9207M53P20	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50	NS	9
9207M53P21	SPACER - STG 5	CF6-80C2, CF6-80A, CF6-50	NS	22
9207M97G01	PLATE - LOCK THRUST LINK	CF6-50 (LMCO)	SV	1
9208M51P08	SEAL - NOZZLE OUTER	CF6-80A	NE	9
9208M52P04	SEAL - NOZZLE INNER	CF6-80A	NS	22
9208M52P04	SEAL - NOZZLE INNER	CF6-80A	NE	58
9208M53P03	SEAL - NOZ RDL	CF6-80C2, CF6-80A	NE	1
9208M76G07	SHIELD ASSY - THRM	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9208M76G07	SHIELD ASSY - THRM	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9210M10G01	BRACKET	CF6-50 (Boeing)	AR	1
9210M10G01	BRACKET	CF6-50 (Boeing)	OH	1
9210M10G01	BRACKET	CF6-50 (Boeing)	OH	1
9210M10G01	BRACKET	CF6-50 (Boeing)	OH	1
9210M11G01	TUBE - DRAIN B SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9210M11G01	TUBE - DRAIN B SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9210M11G01	TUBE - DRAIN B SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9210M11G01	TUBE - DRAIN B SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9210M11G01	TUBE - DRAIN B SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9210M11G01	TUBE - DRAIN B SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9210M11G01	TUBE - DRAIN B SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9210M11G01	TUBE - DRAIN B SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9210M11G01	TUBE - DRAIN B SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9210M11G01	TUBE - DRAIN B SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9210M11G01	TUBE - DRAIN B SUMP FWD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9210M13G01	TUBE - DRAIN AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9210M13G01	TUBE - DRAIN AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9210M13G01	TUBE - DRAIN AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9210M13G01	TUBE - DRAIN AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9210M13G01	TUBE - DRAIN AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9210M13G01	TUBE - DRAIN AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9210M13G01	TUBE - DRAIN AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9210M13G01	TUBE - DRAIN AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9210M13G01	TUBE - DRAIN AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9210M13G01	TUBE - DRAIN AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9210M13G01	TUBE - DRAIN AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9210M13G01	TUBE - DRAIN AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9210M13G01	TUBE - DRAIN AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9210M13G01	TUBE - DRAIN AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9210M13G01	TUBE - DRAIN AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9210M17G01	MANIFOLD ASSY - AIR LH	CF6-50 (Boeing)	AR	1
9210M17G01	MANIFOLD ASSY - AIR LH	CF6-50 (Boeing)	AR	1
9210M17G01	MANIFOLD ASSY - AIR LH	CF6-50 (Boeing)	SV	1
9210M17G01	MANIFOLD ASSY - AIR LH	CF6-50 (Boeing)	AR	1
9210M17G01	MANIFOLD ASSY - AIR LH	CF6-50 (Boeing)	OH	1
9210M17G01	MANIFOLD ASSY - AIR LH	CF6-50 (Boeing)	OH	1
9210M17G01	MANIFOLD ASSY - AIR LH	CF6-50 (Boeing)	OH	1
9210M17G01	MANIFOLD ASSY - AIR LH	CF6-50 (Boeing)	SV	1
9210M17G01	MANIFOLD ASSY - AIR LH	CF6-50 (Boeing)	AR	1
9210M17G01	MANIFOLD ASSY - AIR LH	CF6-50 (Boeing)	OH	1
9210M17G01	MANIFOLD ASSY - AIR LH	CF6-50 (Boeing)	AR	1
9210M17G01	MANIFOLD ASSY - AIR LH	CF6-50 (Boeing)	AR	1
9210M17G01	MANIFOLD ASSY - AIR LH	CF6-50 (Boeing)	OH	1
9210M17G01	MANIFOLD ASSY - AIR LH	CF6-50 (Boeing)	AR	1
9210M17G01	MANIFOLD ASSY - AIR LH	CF6-50 (Boeing)	OH	1
9210M17G02	MANIFOLD ASSY - AIR LH	CF6-50	AR	1
9210M17G02	MANIFOLD ASSY - AIR LH	CF6-50	AR	1
9210M17G02	MANIFOLD ASSY - AIR LH	CF6-50	AR	1
9210M17G02	MANIFOLD ASSY - AIR LH	CF6-50	AR	1
9210M17G02	MANIFOLD ASSY - AIR LH	CF6-50	AR	1
9210M17G02	MANIFOLD ASSY - AIR LH	CF6-50	AR	1
9210M17G02	MANIFOLD ASSY - AIR LH	CF6-50	AR	1
9210M41P01	ROTOR - GEN AC	CF6-80C2, CF6-80A	AR	1
9210M41P01	ROTOR - GEN AC	CF6-80C2, CF6-80A	AR	1
9210M41P01	ROTOR - GEN AC	CF6-80C2, CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9210M41P01	ROTOR - GEN AC	CF6-80C2, CF6-80A	SV	1
9210M41P01	ROTOR - GEN AC	CF6-80C2, CF6-80A	SV	1
9210M41P01	ROTOR - GEN AC	CF6-80C2, CF6-80A	SV	1
9210M88G01	TUBE - VSV HEAD END RIGHT	CF6-80A	AR	1
9210M88G01	TUBE - VSV HEAD END RIGHT	CF6-80A	AR	1
9210M88G01	TUBE - VSV HEAD END RIGHT	CF6-80A	OH	1
9210M88G01	TUBE - VSV HEAD END RIGHT	CF6-80A	OH	1
9211M10G01	SHROUD - IGV	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IGV	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IGV	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IGV	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IGV	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IGV	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IGV	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IGV	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IGV	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IGV	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IGV	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IGV	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IGV	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IGV	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	.INSP	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IG V	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9211M10G01	SHROUD - IGV	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IGV	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IGV	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M10G01	SHROUD - IGV	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G01	SHROUD ASSY - VANE STG 1	CF6-50	AR	1
9211M11G01	SHROUD ASSY - VANE STG 1	CF6-50	AR	1
9211M11G01	SHROUD ASSY - VANE STG 1	CF6-50	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G02	SHROUD ASSY - VANE STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G04	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G04	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G04	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G04	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9211M11G04	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G04	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G04	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G04	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G04	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G04	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G04	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G04	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G04	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G04	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G04	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G04	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G04	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9211M11G04	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G04	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G04	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G04	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G04	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G04	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G04	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G04	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M11G04	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9211M12G01	SHROUD ASSY - VANE STG 2	CF6-50	AR	1
9211M12G02	SHROUD ASSY - VANE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G02	SHROUD ASSY - VANE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G02	SHROUD ASSY - VANE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G02	SHROUD ASSY - VANE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G02	SHROUD ASSY - VANE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G02	SHROUD ASSY - VANE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9211M12G02	SHROUD ASSY - VANE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G02	SHROUD ASSY - VANE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G02	SHROUD ASSY - VANE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G02	SHROUD ASSY - VANE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G02	SHROUD ASSY - VANE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G02	SHROUD ASSY - VANE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G02	SHROUD ASSY - VANE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G02	SHROUD ASSY - VANE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G02	SHROUD ASSY - VANE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G02	SHROUD ASSY - VANE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G02	SHROUD ASSY - VANE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G02	SHROUD ASSY - VANE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G02	SHROUD ASSY - VANE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G02	SHROUD ASSY - VANE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G02	SHROUD ASSY - VANE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G02	SHROUD ASSY - VANE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G02	SHROUD ASSY - VANE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G02	SHROUD ASSY - VANE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M12G03	SHROUD ASSY - VANE STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M41P04	ADAPTER	CF6-50 (LMCO)	NS	2
9211M41P04	ADAPTER	CF6-50 (LMCO)	NS	1
9211M41P04	ADAPTER	CF6-50 (LMCO)	NS	4
9211M41P08	ADAPTER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	3
9211M41P08	ADAPTER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	4
9211M41P08	ADAPTER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	6
9211M51P001A	PLATE - LOCK THRUST LINK	CF6-50 (LMCO)	OH	2
9211M51P001A	PLATE - LOCK THRUST LINK	CF6-50 (LMCO)	OH	2
9211M51P001A	PLATE - LOCK THRUST LINK	CF6-50 (LMCO)	SV	2
9211M51P001A	PLATE - LOCK THRUST LINK	CF6-50 (LMCO)	SV	2
9211M59G02	TUBE ASSY - OIL INLET	CF6-50 (Boeing)	AR	1
9211M59G02	TUBE ASSY - OIL INLET	CF6-50 (Boeing)	AR	1
9211M59G02	TUBE ASSY - OIL INLET	CF6-50 (Boeing)	AR	1
9211M59G02	TUBE ASSY - OIL INLET	CF6-50 (Boeing)	AR	1
9211M59G02	TUBE ASSY - OIL INLET	CF6-50 (Boeing)	AR	1
9211M59G02	TUBE ASSY - OIL INLET	CF6-50 (Boeing)	AR	1
9211M73P02	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P02	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P02	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P02	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P02	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9211M73P02	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P02	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P02	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P02	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P02	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9211M73P02	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P02	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P02	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P02	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P02	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P02	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P02	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P02	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P02	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P02	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P02	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P02	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P02	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P04	BLADE - FAN STG 1	CF6-50 (LMCO)	AR	1
9211M73P04	BLADE - FAN STG 1	CF6-50 (LMCO)	AR	1
9211M73P04	BLADE - FAN STG 1	CF6-50 (LMCO)	AR	1
9211M73P06	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P06	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P06	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P06	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P06	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P07	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P07	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P07	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P07	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P07	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9211M73P07	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P07	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P07	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M73P07	BLADE - FAN STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9211M76G06	FAN UNISON RING	CF6-80C2	NE	1
9211M76G06	FAN UNISON RING	CF6-80C2	NE	1
9211M83G06	LUG ASSY - BL LKG STG 10	CF6-80A, CF6-50 (LMCO)	NS	3
9211M83G06	LUG ASSY - BL LKG STG 10	CF6-80A, CF6-50 (LMCO)	NS	1
9211M83G06	LUG ASSY - BL LKG STG 10	CF6-80A, CF6-50 (LMCO)	NE	3
9211M83G06	LUG ASSY - BL LKG STG 10	CF6-80A, CF6-50 (LMCO)	NS	1
9211M83G06	LUG ASSY - BL LKG STG 10	CF6-80A, CF6-50 (LMCO)	NS	1
9211M83G06	LUG ASSY - BL LKG STG 10	CF6-80A, CF6-50 (LMCO)	OH	2
9211M83G06	LUG ASSY - BL LKG STG 10	CF6-80A, CF6-50 (LMCO)	NE	1
9211M83G06	LUG ASSY - BL LKG STG 10	CF6-80A, CF6-50 (LMCO)	NS	1
9211M83G06	LUG ASSY - BL LKG STG 10	CF6-80A, CF6-50 (LMCO)	NS	1
9211M83G09	LUG ASSY - BL LKG STG 12	CF6-80A, CF6-50 (LMCO)	NE	2
9211M83G09	LUG ASSY - BL LKG STG 12	CF6-80A, CF6-50 (LMCO)	NE	1
9211M83G09	LUG ASSY - BL LKG STG 12	CF6-80A, CF6-50 (LMCO)	NE	3
9211M83G10	LUG ASSY - BL LKG STG 14	CF6-80A, CF6-50 (LMCO)	NE	1
9211M83G21	HPC ROTOR LOCK LUG ASSY STG 10-14	CF6-80C2	OH	2
9211M83G21	HPC ROTOR LOCK LUG ASSY STG 10-14	CF6-80C2	OH	6
9211M83G22	HPC ROTOR LOCK LUG ASSY STG 10-14	CF6-80C2, CF6-50	AR	8
9211M83G22	HPC ROTOR LOCK LUG ASSY STG 10-14	CF6-80C2, CF6-50	OH	2
9211M83G25	LUG ASSY - BLD LCKG STG 13	CF6-80A	NE	4
9212M71P01	SEAL - HP TURB STTR OUTER	CF6-50 (Boeing)	NE	5

Part Number	Part Description	Engine Type	Condition	Quantity
9212M71P01	SEAL - HP TURB STTR OUTER	CF6-50 (Boeing)	NE	7
9212M71P02	SEAL - HPT STATOR	CF6-80A	NE	3
9212M74G56	NOZZLE - HPT STG 1	CF6-80A	OH	1
9212M74G56	NOZZLE - HPT STG 1	CF6-80A	OH	1
9212M74G56	NOZZLE - HPT STG 1	CF6-80A	OH	1
9212M74G56	NOZZLE - HPT STG 1	CF6-80A	OH	1
9212M74G57	NOZZLE - HPT STG 1	CF6-80A	SV	1
9212M74G57	NOZZLE - HPT STG 1	CF6-80A	SV	1
9212M76P01	SEAL - HPT STTR INNER	CF6-50 (Boeing)	NE	23
9212M79P04	PLUG - MACH THD	CF6-80A	SV	1
9212M79P04	PLUG - MACH THD	CF6-80A	OH	1
9212M79P04	PLUG - MACH THD	CF6-80A	AR	1
9212M79P04	PLUG - MACH THD	CF6-80A	NS	1
9212M79P04	PLUG - MACH THD	CF6-80A	OH	1
9212M79P06	PLUG - MACH THD	CF6-80C2, CF6-80A	SV	1
9212M79P06	PLUG - MACH THD	CF6-80C2, CF6-80A	AR	1
9212M79P06	PLUG - MACH THD	CF6-80C2, CF6-80A	SV	1
9212M79P06	PLUG - MACH THD	CF6-80C2, CF6-80A	AR	1
9212M79P06	PLUG - MACH THD	CF6-80C2, CF6-80A	AR	1
9212M79P06	PLUG - MACH THD	CF6-80C2, CF6-80A	AR	1
9212M79P06	PLUG - MACH THD	CF6-80C2, CF6-80A	OH	1
9212M79P06	PLUG - MACH THD	CF6-80C2, CF6-80A	OH	1
9212M79P06	PLUG - MACH THD	CF6-80C2, CF6-80A	OH	1
9212M79P06	PLUG - MACH THD	CF6-80C2, CF6-80A	NE	1
9212M80G01	PLUNGER	CF6-80C2, CF6-80A	NE	2
9212M86G15	NOZZLE ASSY - HPT STG 1	CF6-50	OH	1
9212M86G36	NOZZLE ASSY - HPT STG 1	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9214M15G37	FRAME ASSY - TURB REAR	CF6-80A	AR	1
9214M45P001A	BRACKET	CF6-80A	NS	1
9214M46P001A	BRACKET	CF6-80A	NS	1
9214M47P001A	BRACKET	CF6-80A	NE	1
9214M48P02	COVER - PAD	CF6-80A	AR	1
9215M14P03	BEARING - PLAIN	CF6-80A	NE	2
9215M16P01	BEARING - PLAIN SPHERICAL	CF6-80A	NE	2
9215M23G01	NUT ASSY - SLFLKG	CF6-80A	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9215M23G01	NUT ASSY - SLFLKG	CF6-80A	NE	1
9215M33P01	HOUSING - BEARING	CF6-80A	OH	2
9215M33P01	HOUSING - BEARING	CF6-80A	AR	2
9215M33P01	HOUSING - BEARING	CF6-80A	AR	1
9215M33P01	HOUSING - BEARING	CF6-80A	AR	1
9215M33P01	HOUSING - BEARING	CF6-80A	AR	4
9215M33P01	HOUSING - BEARING	CF6-80A	AR	5
9215M33P01	HOUSING - BEARING	CF6-80A	AR	1
9215M33P01	HOUSING - BEARING	CF6-80A	AR	1
9215M33P02	HOUSING - BEARING	CF6-80A	AR	1
9215M33P02	HOUSING - BEARING	CF6-80A	AR	1
9215M33P02	HOUSING - BEARING	CF6-80A	AR	1
9215M33P03	HOUSING - BEARING	CF6-80A	AR	1
9215M33P03	HOUSING - BEARING	CF6-80A	AR	1
9215M33P03	HOUSING - BEARING	CF6-80A	AR	1
9215M33P03	HOUSING - BEARING	CF6-80A	NE	1
9215M33P04	HOUSING - BEARING	CF6-80A	AR	1
9215M33P04	HOUSING - BEARING	CF6-80A	AR	1
9215M33P04	HOUSING - BEARING	CF6-80A	AR	1
9215M33P04	HOUSING - BEARING	CF6-80A	NE	1
9215M33P05	HOUSING - BEARING	CF6-80A	AR	1
9215M33P05	HOUSING - BEARING	CF6-80A	AR	1
9215M33P05	HOUSING - BEARING	CF6-80A	AR	1
9215M33P05	HOUSING - BEARING	CF6-80A	AR	1
9215M33P06	HOUSING - BEARING	CF6-80A	AR	1
9215M33P06	HOUSING - BEARING	CF6-80A	AR	1
9215M33P06	HOUSING - BEARING	CF6-80A	AR	2
9215M33P06	HOUSING - BEARING	CF6-80A	AR	2
9215M33P07	HOUSING - BEARING	CF6-80A	AR	1
9215M33P07	HOUSING - BEARING	CF6-80A	AR	1
9215M33P07	HOUSING - BEARING	CF6-80A	AR	1
9215M44G01	LINK ASSY - AFT MOUNT	CF6-80A	NE	2
9215M44G01	LINK ASSY - AFT MOUNT	CF6-80A	NE	1
9215M44G01	LINK ASSY - AFT MOUNT	CF6-80A	NE	1
9215M47P01	SPACER - RING	CF6-80A	NE	1
9215M47P01	SPACER - RING	CF6-80A	AR	1
9215M47P01	SPACER - RING	CF6-80A	AR	1
9215M47P02	SPACER - RING	CF6-80A	NE	1
9215M47P02	SPACER - RING	CF6-80A	NE	1
9215M47P04	SPACER - RING	CF6-80C2, CF6-80A	NE	2
9215M47P05	SPACER - RING	CF6-80C2, CF6-80A	NE	1
9215M47P05	SPACER - RING	CF6-80C2, CF6-80A	SV	1
9215M47P05	SPACER - RING	CF6-80C2, CF6-80A	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
9215M47P05	SPACER - RING	CF6-80C2, CF6-80A	NE	1
9215M47P06	SPACER - RING	CF6-80C2, CF6-80A	AR	1
9215M47P06	SPACER - RING	CF6-80C2, CF6-80A	SV	1
9215M47P07	SPACER - RING	CF6-80C2, CF6-80A	NS	1
9215M47P07	SPACER - RING	CF6-80C2, CF6-80A	SV	1
9215M47P07	SPACER - RING	CF6-80C2, CF6-80A	OH	1
9215M47P07	SPACER - RING	CF6-80C2, CF6-80A	SV	1
9215M47P07	SPACER - RING	CF6-80C2, CF6-80A	SV	1
9215M47P07	SPACER - RING	CF6-80C2, CF6-80A	SV	1
9215M47P09	SPACER - RING	CF6-80C2, CF6-80A	SV	1
9215M47P15	SPACER - RING	CF6-80C2	NS	1
9215M47P16	SPACER - RING	CF6-80C2	SV	1
9215M47P16	SPACER - RING	CF6-80C2	OH	1
9215M47P17	SPACER - RING	CF6-80C2	SV	1
9215M47P18	SPACER - RING	CF6-80C2	NE	1
9215M47P19	SPACER - RING	CF6-80C2	NE	1
9215M50G05	HOUSING - BRG NO. 1	CF6-80A	AR	1
9215M51P03	HOUSING - AFT BRG NO. 1	CF6-80A	AR	1
9215M51P03	HOUSING - AFT BRG NO. 1	CF6-80A	AR	1
9215M51P03	HOUSING - AFT BRG NO. 1	CF6-80A	AR	1
9215M51P03	HOUSING - AFT BRG NO. 1	CF6-80A	AR	1
9215M51P03	HOUSING - AFT BRG NO. 1	CF6-80A	AR	1
9215M51P03	HOUSING - AFT BRG NO. 1	CF6-80A	AR	1
9215M54P02	SPACER - SHAFT	CF6-80A	AR	1
9215M54P02	SPACER - SHAFT	CF6-80A	AR	1
9215M54P02	SPACER - SHAFT	CF6-80A	AR	1
9215M54P02	SPACER - SHAFT	CF6-80A	AR	1
9215M54P02	SPACER - SHAFT	CF6-80A	AR	1
9215M54P02	SPACER - SHAFT	CF6-80A	AR	1
9215M54P02	SPACER - SHAFT	CF6-80A	SV	1
9215M54P02	SPACER - SHAFT	CF6-80A	SV	1
9215M54P02	SPACER - SHAFT	CF6-80A	OH	1
9215M61G01	NOZZLE - OIL	CF6-80A	AR	1
9215M68P01	HOUSING - BEARING	CF6-80A	OH	1
9215M68P01	HOUSING - BEARING	CF6-80A	OH	1
9215M68P01	HOUSING - BEARING	CF6-80A	OH	1
9215M69P01	HOUSING - BEARING	CF6-80A	AR	1
9215M69P01	HOUSING - BEARING	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9215M69P01	HOUSING - BEARING	CF6-80A	AR	1
9215M71P01	AGB MATING SEAL RING	CF6-80C2, CF6-80A	AR	3
9215M71P01	AGB MATING SEAL RING	CF6-80C2, CF6-80A	AR	2
9215M71P01	AGB MATING SEAL RING	CF6-80C2, CF6-80A	AR	1
9215M71P02	AGB MATING SEAL RING	CF6-80C2, CF6-80A	AR	2
9215M71P02	AGB MATING SEAL RING	CF6-80C2, CF6-80A	AR	1
9215M71P02	AGB MATING SEAL RING	CF6-80C2, CF6-80A	AR	1
9215M71P02	AGB MATING SEAL RING	CF6-80C2, CF6-80A	AR	1
9215M71P02	AGB MATING SEAL RING	CF6-80C2, CF6-80A	AR	1
9215M71P02	AGB MATING SEAL RING	CF6-80C2, CF6-80A	AR	2
9215M71P02	AGB MATING SEAL RING	CF6-80C2, CF6-80A	AR	2
9215M71P02	AGB MATING SEAL RING	CF6-80C2, CF6-80A	AR	2
9215M71P02	AGB MATING SEAL RING	CF6-80C2, CF6-80A	AR	2
9215M71P02	AGB MATING SEAL RING	CF6-80C2, CF6-80A	NE	2
9215M71P02	AGB MATING SEAL RING	CF6-80C2, CF6-80A	NE	1
9215M72G02	GEARSHAFT ASSY - ACCY GRBX	CF6-80A	OH	1
9215M72G02	GEARSHAFT ASSY - ACCY GRBX	CF6-80A	OH	1
9215M72G02	GEARSHAFT ASSY - ACCY GRBX	CF6-80A	AR	1
9215M75G05	CAGE - ROTATING FAN SPEED	CF6-80A	AR	1
9215M76P01	RETAINER - BRG	CF6-80A	AR	1
9215M76P01	RETAINER - BRG	CF6-80A	AR	1
9215M76P01	RETAINER - BRG	CF6-80A	AR	2
9215M76P01	RETAINER - BRG	CF6-80A	AR	2
9215M76P01	RETAINER - BRG	CF6-80A	AR	2
9215M76P01	RETAINER - BRG	CF6-80A	OH	1
9215M76P01	RETAINER - BRG	CF6-80A	OH	1
9215M76P02	RETAINER - BRG	CF6-80A	AR	1
9215M76P02	RETAINER - BRG	CF6-80A	OH	1
9215M76P02	RETAINER - BRG	CF6-80A	NE	1
9215M76P03	RETAINER - BRG	CF6-80A	AR	1
9215M76P03	RETAINER - BRG	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9215M76P03	RETAINER - BRG	CF6-80A	OH	1
9215M76P03	RETAINER - BRG	CF6-80A	NE	1
9215M76P04	RETAINER - BRG	CF6-80A	OH	1
9215M76P04	RETAINER - BRG	CF6-80A	NE	1
9215M76P05	RETAINER - BRG	CF6-80A	AR	1
9215M76P05	RETAINER - BRG	CF6-80A	AR	1
9215M76P06	RETAINER - BRG	CF6-80A	AR	1
9215M76P06	RETAINER - BRG	CF6-80A	AR	1
9215M76P06	RETAINER - BRG	CF6-80A	AR	1
9215M76P06	RETAINER - BRG	CF6-80A	AR	1
9215M78G22	GEARBOX ASSY - ACCESSORY	CF6-80A	AR	1
9215M84P02	TURNBUCKLE	CF6-80A	OH	1
9215M84P02	TURNBUCKLE	CF6-80A	AR	1
9215M98P06	RETAINER - SPRT SEAL R/S	CF6-80A	AR	1
9216M62G01	MANIFOLD - FUEL	CF6-80A	SV	1
9216M62G01	MANIFOLD - FUEL	CF6-80A	SV	1
9216M62G01	MANIFOLD - FUEL	CF6-80A	AR	1
9216M69G01	RETAINER - INNER	CF6-80A	AR	1
9216M70P01	RETAINER - OUTER	CF6-80A	AR	1
9216M70P01	RETAINER - OUTER	CF6-80A	AR	1
9216M74P01	RETAINER - HORIZ 1	CF6-80A	AR	1
9216M85G01	PANEL - BLOWOUT	CF6-80A	NE	1
9216M98P02	RAIL MOUNTING SPACERS	CF6-80C2, CF6-80A	OH	1
9216M98P02	RAIL MOUNTING SPACERS	CF6-80C2, CF6-80A	AR	6
9216M98P02	RAIL MOUNTING SPACERS	CF6-80C2, CF6-80A	AR	2
9216M98P02	RAIL MOUNTING SPACERS	CF6-80C2, CF6-80A	AR	5
9216M98P02	RAIL MOUNTING SPACERS	CF6-80C2, CF6-80A	SV	6
9216M98P02	RAIL MOUNTING SPACERS	CF6-80C2, CF6-80A	NE	1
9216M98P02	RAIL MOUNTING SPACERS	CF6-80C2, CF6-80A	NE	4
9216M98P02	RAIL MOUNTING SPACERS	CF6-80C2, CF6-80A	OH	2
9217M27P001B	BRACKET	CF6-80A	AR	1
9217M27P001C	BRACKET	CF6-80A	OH	1
9217M52G01	TUBE - PUMP MEC	CF6-80A	SV	1
9217M52G01	TUBE - PUMP MEC	CF6-80A	SV	1
9218M10G02	SUPPORT - HOUSING BRG NO. 4	CF6-80A	AR	1
9218M10G02	SUPPORT - HOUSING BRG NO. 4	CF6-80A	AR	1
9218M11P06	SHIELD - HEAT BEARING 4R	CF6-80A	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9218M11P06	SHIELD - HEAT BEARING 4R	CF6-80A	OH	1
9218M11P06	SHIELD - HEAT BEARING 4R	CF6-80A	OH	1
9218M19G01	TUBE - VENT CRF	CF6-80C2, CF6-80A	AR	1
9218M19G01	TUBE - VENT CRF	CF6-80C2, CF6-80A	SV	1
9218M19G01	TUBE - VENT CRF	CF6-80C2, CF6-80A	AR	1
9218M19G01	TUBE - VENT CRF	CF6-80C2, CF6-80A	OH	1
9218M19G01	TUBE - VENT CRF	CF6-80C2, CF6-80A	AR	1
9218M19G01	TUBE - VENT CRF	CF6-80C2, CF6-80A	AR	1
9218M20G01	TUBE - PRESSURIZATION	CF6-80C2, CF6-80A	OH	1
9218M20G01	TUBE - PRESSURIZATION	CF6-80C2, CF6-80A	AR	1
9218M20G01	TUBE - PRESSURIZATION	CF6-80C2, CF6-80A	NS	1
9218M20G01	TUBE - PRESSURIZATION	CF6-80C2, CF6-80A	AR	1
9218M20G01	TUBE - PRESSURIZATION	CF6-80C2, CF6-80A	AR	1
9218M20G01	TUBE - PRESSURIZATION	CF6-80C2, CF6-80A	NE	2
9218M23G01	NUT ASSY - SLFLKG	CF6-80A	NE	2
9218M24P11	SEAL - ROTATING CDP	CF6-80A	OH	1
9218M24P14	SEAL - ROTATING CDP	CF6-80A	NE	1
9218M24P14	SEAL - ROTATING CDP	CF6-80A	AR	1
9218M25G01	VENT - SEAL BRG 4	CF6-80A	SV	1
9218M25G04	VENT - SEAL BRG 4	CF6-80A	AR	1
9218M25G04	VENT - SEAL BRG 4	CF6-80A	AR	1
9218M25G06	VENT - SEAL BRG 4	CF6-80A	AR	1
9218M25G06	VENT - SEAL BRG 4	CF6-80A	OH	1
9218M25G06	VENT - SEAL BRG 4	CF6-80A	OH	1
9218M25G06	VENT - SEAL BRG 4	CF6-80A	OH	1
9218M27P02	RING - PISTON	CF6-80A	NE	1
9218M27P02	RING - PISTON	CF6-80A	NE	1
9218M29P02	NOZZLE - OIL BRG NO. 4B/4R	CF6-80A	AR	1
9218M29P02	NOZZLE - OIL BRG NO. 4B/4R	CF6-80A	AR	1
9218M29P02	NOZZLE - OIL BRG NO. 4B/4R	CF6-80A	AR	1
9218M29P02	NOZZLE - OIL BRG NO. 4B/4R	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9218M29P02	NOZZLE - OIL BRG NO. 4B/4R	CF6-80A	AR	1
9218M31P01	NOZZLE - OIL BRG NO. 4R AFT	CF6-80A	AR	1
9218M31P01	NOZZLE - OIL BRG NO. 4R AFT	CF6-80A	OH	1
9218M31P01	NOZZLE - OIL BRG NO. 4R AFT	CF6-80A	SV	1
9218M31P01	NOZZLE - OIL BRG NO. 4R AFT	CF6-80A	AR	1
9218M44P02	RING - RTNING INTER B- SUMP	CF6-80A	AR	1
9218M44P03	RING - RETAINING	CF6-80C2, CF6-80A	AR	1
9218M44P03	RING - RETAINING	CF6-80C2, CF6-80A	AR	1
9218M44P03	RING - RETAINING	CF6-80C2, CF6-80A	AR	1
9218M44P03	RING - RETAINING	CF6-80C2, CF6-80A	SV	1
9218M44P03	RING - RETAINING	CF6-80C2, CF6-80A	AR	1
9218M44P03	RING - RETAINING	CF6-80C2, CF6-80A	SV	1
9218M44P03	RING - RETAINING	CF6-80C2, CF6-80A	SV	1
9218M44P03	RING - RETAINING	CF6-80C2, CF6-80A	AR	1
9218M44P03	RING - RETAINING	CF6-80C2, CF6-80A	AR	1
9218M44P04	RING - RETAINING	CF6-80C2, CF6-80A	AR	1
9218M44P04	RING - RETAINING	CF6-80C2, CF6-80A	SV	1
9218M44P04	RING - RETAINING	CF6-80C2, CF6-80A	AR	1
9218M44P05	RING - RTNING INTER B- SUMP	CF6-80A	AR	1
9218M45G01	SEAL - STAT OIL BRG 4R/5R	CF6-80A	AR	1
9218M45G01	SEAL - STAT OIL BRG 4R/5R	CF6-80A	AR	1
9218M65P01	BEARING - BALL NO. 4B	CF6-80A	AR	1
9218M65P01	BEARING - BALL NO. 4B	CF6-80A	AR	1
9218M70P03	RETAINER - BLANKET INSUL	CF6-80A	AR	6
9218M90G03	NUT - SPANNER BRG NO. 4	CF6-80A	AR	1
9218M90G03	NUT - SPANNER BRG NO. 4	CF6-80A	AR	1
9218M90G03	NUT - SPANNER BRG NO. 4	CF6-80A	OH	1
9218M90G04	NUT - SPANNER BRG NO. 4	CF6-80A	AR	1
9218M90G04	NUT - SPANNER BRG NO. 4	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9218M90G04	NUT - SPANNER BRG NO. 4	CF6-80A	AR	1
9218M90G04	NUT - SPANNER BRG NO. 4	CF6-80A	AR	1
9218M90G04	NUT - SPANNER BRG NO. 4	CF6-80A	NE	1
9218M90G04	NUT - SPANNER BRG NO. 4	CF6-80A	NE	1
9218M90G04	NUT - SPANNER BRG NO. 4	CF6-80A	OH	1
9218M90G04	NUT - SPANNER BRG NO. 4	CF6-80A	OH	1
9218M91P02	PLATE - RETAINER BRG 4	CF6-80A	AR	1
9218M91P02	PLATE - RETAINER BRG 4	CF6-80A	AR	1
9218M91P02	PLATE - RETAINER BRG 4	CF6-80A	AR	1
9218M91P02	PLATE - RETAINER BRG 4	CF6-80A	AR	1
9218M91P02	PLATE - RETAINER BRG 4	CF6-80A	AR	1
9218M91P02	PLATE - RETAINER BRG 4	CF6-80A	AR	1
9218M91P02	PLATE - RETAINER BRG 4	CF6-80A	AR	1
9218M91P02	PLATE - RETAINER BRG 4	CF6-80A	AR	1
9218M91P02	PLATE - RETAINER BRG 4	CF6-80A	SV	1
9218M91P02	PLATE - RETAINER BRG 4	CF6-80A	AR	1
9218M91P02	PLATE - RETAINER BRG 4	CF6-80A	AR	1
9218M92G03	NUT - SPANNER AFT BRG NO. 4R	CF6-80A	AR	1
9218M92G03	NUT - SPANNER AFT BRG NO. 4R	CF6-80A	AR	1
9218M92G03	NUT - SPANNER AFT BRG NO. 4R	CF6-80A	AR	1
9218M92G03	NUT - SPANNER AFT BRG NO. 4R	CF6-80A	AR	1
9218M92G03	NUT - SPANNER AFT BRG NO. 4R	CF6-80A	SV	1
9218M92G03	NUT - SPANNER AFT BRG NO. 4R	CF6-80A	SV	1
9218M92G03	NUT - SPANNER AFT BRG NO. 4R	CF6-80A	SV	1
9218M92G03	NUT - SPANNER AFT BRG NO. 4R	CF6-80A	SV	1
9218M92G03	NUT - SPANNER AFT BRG NO. 4R	CF6-80A	SV	1
9218M92G03	NUT - SPANNER AFT BRG NO. 4R	CF6-80A	AR	1
9218M92G03	NUT - SPANNER AFT BRG NO. 4R	CF6-80A	AR	1
9218M92G03	NUT - SPANNER AFT BRG NO. 4R	CF6-80A	OH	1
9218M92G03	NUT - SPANNER AFT BRG NO. 4R	CF6-80A	OH	1
9218M93P01	NUT - SPANNER	CF6-80A	AR	1
9218M93P01	NUT - SPANNER	CF6-80A	AR	1
9218M93P01	NUT - SPANNER	CF6-80A	AR	1
9218M93P01	NUT - SPANNER	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9218M93P01	NUT - SPANNER	CF6-80A	AR	1
9218M93P01	NUT - SPANNER	CF6-80A	AR	1
9218M93P01	NUT - SPANNER	CF6-80A	AR	1
9218M93P01	NUT - SPANNER	CF6-80A	SV	1
9218M93P01	NUT - SPANNER	CF6-80A	SV	1
9218M93P01	NUT - SPANNER	CF6-80A	SV	1
9218M93P01	NUT - SPANNER	CF6-80A	SV	1
9218M93P01	NUT - SPANNER	CF6-80A	AR	1
9218M93P01	NUT - SPANNER	CF6-80A	AR	1
9218M94G03	NUT - SPANNER INNER BRG 5R	CF6-80A	AR	1
9218M94G04	#5R BEARING SPANNER NUT	CF6-80C2, CF6-80A	AR	1
9218M94G04	#5R BEARING SPANNER NUT	CF6-80C2, CF6-80A	AR	1
9218M94G04	#5R BEARING SPANNER NUT	CF6-80C2, CF6-80A	OH	1
9218M94G04	#5R BEARING SPANNER NUT	CF6-80C2, CF6-80A	OH	1
9218M94G04	#5R BEARING SPANNER NUT	CF6-80C2, CF6-80A	OH	1
9218M94G04	#5R BEARING SPANNER NUT	CF6-80C2, CF6-80A	AR	1
9218M94G04	#5R BEARING SPANNER NUT	CF6-80C2, CF6-80A	OH	1
9218M94G04	#5R BEARING SPANNER NUT	CF6-80C2, CF6-80A	AR	1
9218M94G04	#5R BEARING SPANNER NUT	CF6-80C2, CF6-80A	OH	1
9218M94G04	#5R BEARING SPANNER NUT	CF6-80C2, CF6-80A	OH	1
9218M94G04	#5R BEARING SPANNER NUT	CF6-80C2, CF6-80A	OH	1
9218M94G04	#5R BEARING SPANNER NUT	CF6-80C2, CF6-80A	OH	1
9218M94G04	#5R BEARING SPANNER NUT	CF6-80C2, CF6-80A	OH	1
9218M97G02	NUT - SPANNER DAMPER	CF6-80A	AR	1
9218M97G02	NUT - SPANNER DAMPER	CF6-80A	AR	1
9219M22P01	SHIELD - SPRAY	CF6-80C2, CF6-80A	NS	2
9219M23P01	PLUG - TIP	CF6-80C2, CF6-80A	NS	3
9219M26P01	SHAFT - PL	CF6-80C2, CF6-80A	NS	1
9219M29G02	PLUG ASSY - BORESCOPE	CF6-80A	SV	1
9219M29G02	PLUG ASSY - BORESCOPE	CF6-80A	NE	2
9219M81G01	BAFFLE ASSY - STG 1 HPT	CF6-80A	AR	1
9219M81G01	BAFFLE ASSY - STG 1 HPT	CF6-80A	NE	9
9220M25G04	GEARBOX - MOUNT LEFT	CF6-80A	OH	1
9220M25G04	GEARBOX - MOUNT LEFT	CF6-80A	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9220M25G04	GEARBOX - MOUNT LEFT	CF6-80A	OH	1
9220M25G04	GEARBOX - MOUNT LEFT	CF6-80A	OH	1
9220M26P02	MOUNT - FWD	CF6-80A	AR	1
9220M26P02	MOUNT - FWD	CF6-80A	AR	1
9220M26P02	MOUNT - FWD	CF6-80A	AR	1
9220M26P02	MOUNT - FWD	CF6-80A	AR	1
9220M26P02	MOUNT - FWD	CF6-80A	AR	1
9220M26P02	MOUNT - FWD	CF6-80A	AR	1
9220M26P02	MOUNT - FWD	CF6-80A	AR	1
9220M32G02	SHAFT ASSY - FWD FAN	CF6-80A	OH	1
9220M39G04	PAD - FAN FRAME ASSY RH	CF6-80A	NE	1
9220M70P02	ELBOW	CF6-80A	AR	1
9220M74P01	DUCT - VENT	CF6-80A	AR	1
9220M76G01	TUBE - OIL FWD STRUT 5	CF6-80A	AR	1
9220M86G01	DUCT - PRESSURIZATION	CF6-80A	OH	1
9220M86G01	DUCT - PRESSURIZATION	CF6-80A	OH	1
9220M86G01	DUCT - PRESSURIZATION	CF6-80A	OH	1
9220M87G03	ADAPTER - SCAV SUMP CPRSR	CF6-80C2, CF6-80A	OH	1
9220M87G03	ADAPTER - SCAV SUMP CPRSR	CF6-80C2, CF6-80A	OH	1
9220M89G07	TUBE - AIR HPR	CF6-80A	AR	1
9220M89G08	TUBE - AIR HPR	CF6-80A	AR	1
9220M89G09	TUBE - AIR HPR	CF6-80A	AR	1
9220M89G10	TUBE - AIR HPR	CF6-80A	AR	1
9220M89G11	TUBE - AIR HPR	CF6-80A	AR	1
9220M89G12	TUBE - AIR HPR	CF6-80A	AR	1
9221M25G01	TUBE - OIL SCAVENGE TGB	CF6-80A	AR	1
9221M25G01	TUBE - OIL SCAVENGE TGB	CF6-80A	AR	1
9221M25G01	TUBE - OIL SCAVENGE TGB	CF6-80A	AR	1
9221M25G01	TUBE - OIL SCAVENGE TGB	CF6-80A	AR	1
9221M51G01	BRACKET - INTERFACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9221M51G01	BRACKET - INTERFACE	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9221M60G01	TUBE - AIR B SUMP PRESS AFT	CF6-80A	AR	1
9221M60G01	TUBE - AIR B SUMP PRESS AFT	CF6-80A	OH	1
9221M60G01	TUBE - AIR B SUMP PRESS AFT	CF6-80A	AR	1
9221M60G01	TUBE - AIR B SUMP PRESS AFT	CF6-80A	AR	1
9221M60G01	TUBE - AIR B SUMP PRESS AFT	CF6-80A	AR	1
9222M13P01	ACCELEROMETER ASSY - NO. 1	CF6-50 (LMCO)	AR	1
9222M93G01	TUBE - AIR HPT COOLING	CF6-80A	AR	1
9223M19G03	LINK - THRUST	CF6-80A	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9223M19G04	LINK - THRUST	CF6-80A	AR	1
9223M19G04	LINK - THRUST	CF6-80A	AR	1
9223M19G04	LINK - THRUST	CF6-80A	OH	1
9223M20G01	LINK - AFT L/H	CF6-80A	AR	1
9223M20G01	LINK - AFT L/H	CF6-80A	OH	1
9223M20G01	LINK - AFT L/H	CF6-80A	OH	1
9223M21G01	LINK - AFT R/H	CF6-80A	OH	1
9223M21G01	LINK - AFT R/H	CF6-80A	OH	1
9223M22P01	ADAPTER - LOWER FAN FRAME	CF6-80A	NS	1
9223M22P01	ADAPTER - LOWER FAN FRAME	CF6-80A	NE	1
9223M22P01	ADAPTER - LOWER FAN FRAME	CF6-80A	NS	2
9223M22P01	ADAPTER - LOWER FAN FRAME	CF6-80A	OH	1
9224M14G02	BRACKET - LPT	CF6-80A	NS	2
9224M14G02	BRACKET - LPT	CF6-80A	NS	4
9224M14G02	BRACKET - LPT	CF6-80A	NS	4
9224M15G04	BRACKET - LPT	CF6-80A	NE	1
9224M45G04	LINER - INNER LPT STTR STG 1	CF6-80A	OH	1
9224M56P03	RETAINER - SLABBED HD BOLT	CF6-50 (LMCO), CF6-50 (Boeing)	NE	4
9224M56P03	RETAINER - SLABBED HD BOLT	CF6-50 (LMCO), CF6-50 (Boeing)	NS	8
9224M56P03	RETAINER - SLABBED HD BOLT	CF6-50 (LMCO), CF6-50 (Boeing)	NE	9
9224M56P03	RETAINER - SLABBED HD BOLT	CF6-50 (LMCO), CF6-50 (Boeing)	NE	9
9224M56P03	RETAINER - SLABBED HD BOLT	CF6-50 (LMCO), CF6-50 (Boeing)	NE	30
9224M56P04	RETAINER - SLABBED HD BOLT	CF6-50 (LMCO), CF6-50 (Boeing)	NE	102
9224M56P04	RETAINER - SLABBED HD BOLT	CF6-50 (LMCO), CF6-50 (Boeing)	NE	116
9224M67P02	DISK - LPT STG 4	CF6-80A	AR	1
9224M67P02	DISK - LPT STG 4	CF6-80A	OH	1
9224M67P02	DISK - LPT STG 4	CF6-80A	AR	1
9224M67P04	DISK - LPT STG 4	CF6-80A	AR	1
9225M60G04	SHROUD - PAD	CF6-80A	NE	1
9225M61G07	SHROUD - INNER STG 1	CF6-80A	OH	1
9225M61G07	SHROUD - INNER STG 1	CF6-80A	OH	1
9225M62G07	SHROUD - INNER STG 2	CF6-80A	SV	1
9225M62G07	SHROUD - INNER STG 2	CF6-80A	OH	1
9225M62G07	SHROUD - INNER STG 2	CF6-80A	AR	1
9225M62G07	SHROUD - INNER STG 2	CF6-80A	AR	1
9225M62G07	SHROUD - INNER STG 2	CF6-80A	AR	1
9225M62G07	SHROUD - INNER STG 2	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9225M62G07	SHROUD - INNER STG 2	CF6-80A	OH	1
9225M62G07	SHROUD - INNER STG 2	CF6-80A	OH	1
9225M63G07	SHROUD - INNER STG 3	CF6-80A	OH	1
9225M63G07	SHROUD - INNER STG 3	CF6-80A	SV	1
9225M63G07	SHROUD - INNER STG 3	CF6-80A	SV	1
9225M63G07	SHROUD - INNER STG 3	CF6-80A	SV	1
9225M63G07	SHROUD - INNER STG 3	CF6-80A	AR	1
9225M63G07	SHROUD - INNER STG 3	CF6-80A	AR	1
9225M70P04	SHROUD - LUG	CF6-80A	NE	1
9225M70P05	SHROUD - LUG	CF6-80A	NE	1
9225M90G06	BEAM - RIGHT	CF6-80A	AR	1
9225M91G04	BEAM - LEFT	CF6-80A	OH	1
9225M92P05	GUIDE - SECTOR	CF6-80A	NE	6
9225M92P05	GUIDE - SECTOR	CF6-80A	NE	3
9225M92P05	GUIDE - SECTOR	CF6-80A	NE	7
9225M92P12QQ	GUIDE	CF6-80A	NE	2
9225M92P12QQ	GUIDE	CF6-80A	NE	4
9225M92P12QQ	GUIDE	CF6-80A	NE	4
9226M26P01	SEAL - TUBE SCAVENGE	CF6-80A	NE	3
9226M55G01	TUBE - AIR HPT RECOUP	CF6-80A	SV	1
9226M67P01	CABLE - VARIABLE BYPASS	CF6-80A	AR	1
9226M83G01	BRACKET	CF6-80A	AR	1
9226M83G01	BRACKET	CF6-80A	AR	1
9226M84G01	RETAINER - VERT 1	CF6-80A	AR	1
9226M84G01	RETAINER - VERT 1	CF6-80A	OH	1
9226M85G01	RETAINER - VERT 2	CF6-80A	AR	1
9226M85G01	RETAINER - VERT 2	CF6-80A	AR	1
9226M85G01	RETAINER - VERT 2	CF6-80A	OH	1
9226M87G02	RETAINER - BOT 2	CF6-80A	AR	1
9226M87G03	RETAINER - BOT 2	CF6-80A	OH	1
9226M92G01	BELLCRANK	CF6-80A	NS	1
9227M33P001C	BRACKET	CF6-80A	SV	1
9227M33P001D	BRACKET	CF6-80A	NE	1
9227M34G01	BRACKET	CF6-80A	AR	1
9227M34G03	BRACKET	CF6-80A	AR	1
9227M34G03	BRACKET	CF6-80A	SV	1
9227M43P06	PROBE	CF6-80A	SV	1
9228M11G02	BRACKET - FWD	CF6-80A	AR	12
9228M11G02	BRACKET - FWD	CF6-80A	AR	6
9228M11G02	BRACKET - FWD	CF6-80A	OH	3
9228M11G02	BRACKET - FWD	CF6-80A	AR	12
9228M11G02	BRACKET - FWD	CF6-80A	AR	5
9228M11G02	BRACKET - FWD	CF6-80A	AR	12
9228M11G03	BRACKET - FWD	CF6-80A	AR	1
9228M11G03	BRACKET - FWD	CF6-80A	AR	1
9228M11G03	BRACKET - FWD	CF6-80A	AR	1
9228M11G03	BRACKET - FWD	CF6-80A	AR	1
9228M11G03	BRACKET - FWD	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9228M11G03	BRACKET - FWD	CF6-80A	AR	1
9228M11G03	BRACKET - FWD	CF6-80A	AR	1
9228M11G03	BRACKET - FWD	CF6-80A	AR	1
9228M11G03	BRACKET - FWD	CF6-80A	AR	1
9228M11G03	BRACKET - FWD	CF6-80A	AR	1
9228M11G03	BRACKET - FWD	CF6-80A	NE	1
9228M14P01	SLEEVE - CLEVIS	CF6-80A	NE	1
9228M14P02	SLEEVE - CLEVIS	CF6-80A	NE	4
9228M14P02	SLEEVE - CLEVIS	CF6-80A	NE	2
9228M14P03	SLEEVE - CLEVIS	CF6-80A	NE	1
9228M14P04	SLEEVE - CLEVIS	CF6-80A	NE	1
9228M14P05	SLEEVE - CLEVIS	CF6-80A	NS	4
9228M21P01	PLUG - FLANGED	CF6-80C2, CF6-80A	AR	1
9228M57G16	HOUSING ASSY - SUMP AFT	CF6-80A	AR	1
9228M64G18	FAIRING - OUTER	CF6-80A	AR	1
9228M64G18	FAIRING - OUTER	CF6-80A	AR	1
9228M64G18	FAIRING - OUTER	CF6-80A	SV	1
9228M64G19	FAIRING - OUTER	CF6-80A	AR	2
9228M64G19	FAIRING - OUTER	CF6-80A	AR	1
9228M64G19	FAIRING - OUTER	CF6-80A	AR	3
9228M64G19	FAIRING - OUTER	CF6-80A	AR	9
9228M64G19	FAIRING - OUTER	CF6-80A	OH	5
9228M64G19	FAIRING - OUTER	CF6-80A	AR	8
9228M64G19	FAIRING - OUTER	CF6-80A	NS	2
9228M64G19	FAIRING - OUTER	CF6-80A	NS	1
9228M64G20	FAIRING - OUTER	CF6-80A	AR	1
9228M64G20	FAIRING - OUTER	CF6-80A	AR	1
9228M64G21	FAIRING - OUTER	CF6-80A	AR	6
9228M64G21	FAIRING - OUTER	CF6-80A	AR	12
9228M64G21	FAIRING - OUTER	CF6-80A	OH	1
9228M64G21	FAIRING - OUTER	CF6-80A	OH	6
9228M64G21	FAIRING - OUTER	CF6-80A	NE	1
9228M64G21	FAIRING - OUTER	CF6-80A	NE	2
9228M64G21	FAIRING - OUTER	CF6-80A	NE	11
9228M64G21	FAIRING - OUTER	CF6-80A	AR	12
9228M64G22	FAIRING - OUTER	CF6-80A	AR	1
9228M64G22	FAIRING - OUTER	CF6-80A	AR	1
9228M64G22	FAIRING - OUTER	CF6-80A	OH	1
9228M64G22	FAIRING - OUTER	CF6-80A	AR	1
9228M64G23	FAIRING - OUTER	CF6-80A	AR	1
9228M64G23	FAIRING - OUTER	CF6-80A	AR	1
9228M64G24	FAIRING - OUTER	CF6-80A	AR	6
9228M64G24	FAIRING - OUTER	CF6-80A	AR	6
9228M64G24	FAIRING - OUTER	CF6-80A	AR	6
9228M64G24	FAIRING - OUTER	CF6-80A	NS	1
9228M64G25	FAIRING - OUTER	CF6-80A	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
9228M64G25	FAIRING - OUTER	CF6-80A	AR	2
9228M64G25	FAIRING - OUTER	CF6-80A	AR	2
9228M64G26	FAIRING - OUTER	CF6-80A	AR	7
9228M64G26	FAIRING - OUTER	CF6-80A	AR	16
9228M64G26	FAIRING - OUTER	CF6-80A	AR	16
9228M64G26	FAIRING - OUTER	CF6-80A	NE	1
9228M64G26	FAIRING - OUTER	CF6-80A	NE	1
9228M64G26	FAIRING - OUTER	CF6-80A	NE	1
9228M64G26	FAIRING - OUTER	CF6-80A	NE	6
9228M64G27	FAIRING - OUTER	CF6-80A	AR	2
9228M64G27	FAIRING - OUTER	CF6-80A	NS	1
9228M64G27	FAIRING - OUTER	CF6-80A	AR	2
9228M64G27	FAIRING - OUTER	CF6-80A	AR	2
9228M64G28	FAIRING - OUTER	CF6-80A	AR	2
9228M64G28	FAIRING - OUTER	CF6-80A	AR	18
9228M64G28	FAIRING - OUTER	CF6-80A	OH	3
9228M64G28	FAIRING - OUTER	CF6-80A	NE	1
9228M64G28	FAIRING - OUTER	CF6-80A	AR	17
9228M64G28	FAIRING - OUTER	CF6-80A	OH	2
9228M64G29	FAIRING - OUTER	CF6-80A	AR	1
9228M64G29	FAIRING - OUTER	CF6-80A	AR	1
9228M64G29	FAIRING - OUTER	CF6-80A	AR	1
9228M64G30	FAIRING - OUTER	CF6-80A	AR	7
9228M64G30	FAIRING - OUTER	CF6-80A	AR	6
9228M64G30	FAIRING - OUTER	CF6-80A	NE	1
9228M64G30	FAIRING - OUTER	CF6-80A	AR	8
9228M64G30	FAIRING - OUTER	CF6-80A	NS	3
9228M64G31	FAIRING - OUTER	CF6-80A	AR	1
9228M64G31	FAIRING - OUTER	CF6-80A	AR	1
9228M64G31	FAIRING - OUTER	CF6-80A	NS	1
9228M64G31	FAIRING - OUTER	CF6-80A	NS	1
9228M64G31	FAIRING - OUTER	CF6-80A	AR	1
9228M64G31	FAIRING - OUTER	CF6-80A	OH	1
9228M64G31	FAIRING - OUTER	CF6-80A	AR	1
9228M64G32	FAIRING - OUTER	CF6-80A	AR	1
9228M64G32	FAIRING - OUTER	CF6-80A	AR	1
9228M64G33	FAIRING - OUTER	CF6-80A	AR	1
9228M64G33	FAIRING - OUTER	CF6-80A	AR	1
9228M64G34	FAIRING - OUTER	CF6-80A	AR	1
9228M64G34	FAIRING - OUTER	CF6-80A	AR	1
9228M64G34	FAIRING - OUTER	CF6-80A	AR	1
9228M80G04	HOUSING ASSY - SUMP FWD	CF6-80A	AR	1
9228M83P05	HPC ROTOR SPLINED ADAPTER	CF6-80C2, CF6-80A	OH	1
9228M93P03	SHAFT - MID FAN	CF6-80A	NE	1
9229M20G01	TUBE ASSY - ANTI ICING AIR	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9229M20G01	TUBE ASSY - ANTI ICING AIR	CF6-50 (LMCO)	AR	1
9229M20G01	TUBE ASSY - ANTI ICING AIR	CF6-50 (LMCO)	AR	1
9229M20G01	TUBE ASSY - ANTI ICING AIR	CF6-50 (LMCO)	AR	1
9229M33P01	JOINT - FLEXIBLE	CF6-80C2, CF6-80A	NE	1
9229M33P01	JOINT - FLEXIBLE	CF6-80C2, CF6-80A	NE	1
9229M33P01	JOINT - FLEXIBLE	CF6-80C2, CF6-80A	NE	2
9229M33P01	JOINT - FLEXIBLE	CF6-80C2, CF6-80A	NE	1
9229M38G03	BRACKET	CF6-80A	AR	1
9229M38G03	BRACKET	CF6-80A	OH	1
9229M61G01	TUBE - ANTI-ICING	CF6-50	AR	1
9229M63G01	DUCT - ANTI ICING AIR	CF6-50 (LMCO)	OH	1
9229M63G01	DUCT - ANTI ICING AIR	CF6-50 (LMCO)	AR	1
9229M63G01	DUCT - ANTI ICING AIR	CF6-50 (LMCO)	AR	1
9229M76P01	PUMP - LUBE & SCAVENGER	CF6-80A, CF6-50 (LMCO)	AR	1
9229M76P01	PUMP - LUBE & SCAVENGER	CF6-80A, CF6-50 (LMCO)	OH	1
9229M76P01	PUMP - LUBE & SCAVENGER	CF6-80A, CF6-50 (LMCO)	OH	1
9229M87G03	BRACKET	CF6-80A	SV	1
9229M87G03	BRACKET	CF6-80A	SV	1
9229M87G03	BRACKET	CF6-80A	NE	1
9229M87G03	BRACKET	CF6-80A	NE	1
9232M12P05	LINER - VANE RETAINING STG 12/13	CF6-80A	AR	1
9232M12P05	LINER - VANE RETAINING STG 12/13	CF6-80A	NE	1
9232M12P05	LINER - VANE RETAINING STG 12/13	CF6-80A	AR	1
9232M12P05	LINER - VANE RETAINING STG 12/13	CF6-80A	AR	1
9232M12P06	LINER - VANE RETAINING STG 12/13	CF6-80A	AR	1
9232M12P06	LINER - VANE RETAINING STG 12/13	CF6-80A	AR	1
9232M12P07	LINER - VANE RETAINING STG 12/13	CF6-80A	AR	1
9232M12P07	LINER - VANE RETAINING STG 12/13	CF6-80A	OH	1
9232M12P07	LINER - VANE RETAINING STG 12/13	CF6-80A	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9232M12P07	LINER - VANE RETAINING STG 12/13	CF6-80A	OH	1
9232M12P07	LINER - VANE RETAINING STG 12/13	CF6-80A	AR	1
9232M12P07	LINER - VANE RETAINING STG 12/13	CF6-80A	AR	1
9232M12P07	LINER - VANE RETAINING STG 12/13	CF6-80A	AR	1
9232M12P08	LINER - VANE RETAINING STG 12/13	CF6-80A	OH	1
9232M12P08	LINER - VANE RETAINING STG 12/13	CF6-80A	OH	1
9232M12P08	LINER - VANE RETAINING STG 12/13	CF6-80A	AR	1
9232M12P08	LINER - VANE RETAINING STG 12/13	CF6-80A	AR	1
9232M12P09	LINER - VANE RETAINING STG 12/13	CF6-80A	AR	5
9232M12P09	LINER - VANE RETAINING STG 12/13	CF6-80A	AR	1
9232M12P09	LINER - VANE RETAINING STG 12/13	CF6-80A	AR	5
9232M12P09	LINER - VANE RETAINING STG 12/13	CF6-80A	AR	6
9232M12P09	LINER - VANE RETAINING STG 12/13	CF6-80A	AR	6
9232M12P09	LINER - VANE RETAINING STG 12/13	CF6-80A	AR	6
9232M12P09	LINER - VANE RETAINING STG 12/13	CF6-80A	AR	6
9232M12P10	LINER - VANE RETAINING STG 12/13	CF6-80A	OH	1
9232M12P10	LINER - VANE RETAINING STG 12/13	CF6-80A	OH	1
9232M12P10	LINER - VANE RETAINING STG 12/13	CF6-80A	OH	1
9232M12P11	LINER - VANE RETAINING STG 12/13	CF6-80A	AR	1
9232M12P11	LINER - VANE RETAINING STG 12/13	CF6-80A	NE	1
9232M12P11	LINER - VANE RETAINING STG 12/13	CF6-80A	SV	1
9232M12P11	LINER - VANE RETAINING STG 12/13	CF6-80A	OH	1
9232M12P11	LINER - VANE RETAINING STG 12/13	CF6-80A	OH	1
9232M12P12	LINER - VANE RETAINING STG 12/13	CF6-80A	OH	1
9232M12P12	LINER - VANE RETAINING STG 12/13	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9232M12P12	LINER - VANE RETAINING STG 12/13	CF6-80A	SV	1
9232M12P13	LINER - VANE RETAINING STG 12/13	CF6-80A	AR	1
9232M12P13	LINER - VANE RETAINING STG 12/13	CF6-80A	NE	1
9232M12P13	LINER - VANE RETAINING STG 12/13	CF6-80A	OH	1
9232M12P13	LINER - VANE RETAINING STG 12/13	CF6-80A	OH	1
9232M12P14	LINER - VANE RETAINING STG 12/13	CF6-80A	SV	1
9232M12P14	LINER - VANE RETAINING STG 12/13	CF6-80A	SV	1
9232M12P14	LINER - VANE RETAINING STG 12/13	CF6-80A	SV	3
9232M12P14	LINER - VANE RETAINING STG 12/13	CF6-80A	OH	1
9232M12P14	LINER - VANE RETAINING STG 12/13	CF6-80A	AR	6
9232M32P01	FLANGE - TUBE	CF6-80A	AR	1
9232M32P01	FLANGE - TUBE	CF6-80A	AR	1
9232M34G01	NOZZLE - OIL	CF6-80C2, CF6-80A	AR	1
9232M34G01	NOZZLE - OIL	CF6-80C2, CF6-80A	AR	1
9232M34G01	NOZZLE - OIL	CF6-80C2, CF6-80A	AR	1
9232M34G01	NOZZLE - OIL	CF6-80C2, CF6-80A	AR	1
9232M34G01	NOZZLE - OIL	CF6-80C2, CF6-80A	AR	1
9232M34G01	NOZZLE - OIL	CF6-80C2, CF6-80A	OH	1
9232M36G01	NOZZLE - OIL	CF6-80C2, CF6-80A	AR	1
9232M36G01	NOZZLE - OIL	CF6-80C2, CF6-80A	AR	1
9232M36G01	NOZZLE - OIL	CF6-80C2, CF6-80A	AR	1
9232M36G01	NOZZLE - OIL	CF6-80C2, CF6-80A	AR	1
9232M36G01	NOZZLE - OIL	CF6-80C2, CF6-80A	AR	1
9232M38G01	NOZZLE - OIL	CF6-80A	AR	1
9232M38G01	NOZZLE - OIL	CF6-80A	AR	1
9232M38G01	NOZZLE - OIL	CF6-80A	AR	1
9232M38G01	NOZZLE - OIL	CF6-80A	AR	1
9232M38G01	NOZZLE - OIL	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9232M38G01	NOZZLE - OIL	CF6-80A	OH	1
9232M40G01	NOZZLE - OIL	CF6-80C2, CF6-80A	OH	1
9232M40G01	NOZZLE - OIL	CF6-80C2, CF6-80A	OH	1
9232M40G01	NOZZLE - OIL	CF6-80C2, CF6-80A	AR	1
9232M40G01	NOZZLE - OIL	CF6-80C2, CF6-80A	AR	1
9232M40G01	NOZZLE - OIL	CF6-80C2, CF6-80A	OH	1
9232M42G01	NOZZLE - OIL	CF6-80A	AR	5
9232M42G01	NOZZLE - OIL	CF6-80A	AR	2
9232M42G01	NOZZLE - OIL	CF6-80A	AR	3
9232M42G01	NOZZLE - OIL	CF6-80A	AR	5
9232M42G01	NOZZLE - OIL	CF6-80A	AR	1
9232M42G01	NOZZLE - OIL	CF6-80A	AR	1
9232M42G01	NOZZLE - OIL	CF6-80A	AR	3
9232M42G01	NOZZLE - OIL	CF6-80A	AR	1
9232M44P01	NOZZLE - OIL	CF6-80A	AR	1
9232M44P01	NOZZLE - OIL	CF6-80A	AR	1
9232M46G06	HANGER - SUPPORT HPT STTR	CF6-80A	OH	1
9232M46G06	HANGER - SUPPORT HPT STTR	CF6-80A	OH	1
9232M46G06	HANGER - SUPPORT HPT STTR	CF6-80A	OH	1
9232M46G08	HANGER - SUPPORT HPT STTR	CF6-80A	OH	1
9232M46P01	HANGER	CF6-80A	AR	1
9232M72G01	ADAPTER - TRANSFER GRBX AFT	CF6-80A	AR	1
9232M74P02	COVER - WINDAGE	CF6-80A	NE	1
9232M74P02	COVER - WINDAGE	CF6-80A	NE	2
9232M74P02	COVER - WINDAGE	CF6-80A	NS	2
9232M74P02	COVER - WINDAGE	CF6-80A	OH	5
9232M74P02	COVER - WINDAGE	CF6-80A	OH	5
9232M74P02	COVER - WINDAGE	CF6-80A	OH	5
9232M74P02	COVER - WINDAGE	CF6-80A	OH	5
9232M74P02	COVER - WINDAGE	CF6-80A	OH	5
9232M77P01	COVER - WINDAGE	CF6-80A	OH	1
9232M77P01	COVER - WINDAGE	CF6-80A	OH	1
9232M77P02	COVER - WINDAGE	CF6-80A	AR	5
9232M77P02	COVER - WINDAGE	CF6-80A	SV	3
9232M77P02	COVER - WINDAGE	CF6-80A	AR	6
9232M77P02	COVER - WINDAGE	CF6-80A	AR	6
9232M77P02	COVER - WINDAGE	CF6-80A	AR	6
9232M77P02	COVER - WINDAGE	CF6-80A	AR	6

Part Number	Part Description	Engine Type	Condition	Quantity
9232M79G06	SEAL - NOZZLE AFT	CF6-80A	OH	1
9232M79G07	SEAL - NOZZLE AFT	CF6-80A	OH	1
9232M79G07	SEAL - NOZZLE AFT	CF6-80A	OH	1
9232M79G07	SEAL - NOZZLE AFT	CF6-80A	OH	1
9232M79G07	SEAL - NOZZLE AFT	CF6-80A	AR	1
9232M79G07	SEAL - NOZZLE AFT	CF6-80A	OH	1
9232M88G02	GEARBOX ASSY EMU - TRANSFER	CF6-80A	AR	1
9232M90P10	NUT ASSY - SLFLKG	CF6-80A	NS	1
9232M90P10	NUT ASSY - SLFLKG	CF6-80A	NS	1
9232M90P17	NUT ASSY - SLFLKG	CF6-80C2	NS	1
9232M90P17	NUT ASSY - SLFLKG	CF6-80C2	NS	1
9232M90P18	NUT ASSY - SLFLKG	CF6-80C2, CF6-80A	NE	4
9232M90P18	NUT ASSY - SLFLKG	CF6-80C2, CF6-80A	NE	3
9233M33P08	SEGMENT - FAIRING STG 3	CF6-80A	AR	18
9233M33P08	SEGMENT - FAIRING STG 3	CF6-80A	AR	18
9233M33P08	SEGMENT - FAIRING STG 3	CF6-80A	AR	18
9233M33P08	SEGMENT - FAIRING STG 3	CF6-80A	SV	17
9233M33P08	SEGMENT - FAIRING STG 3	CF6-80A	AR	18
9233M33P08	SEGMENT - FAIRING STG 3	CF6-80A	SV	18
9233M33P08	SEGMENT - FAIRING STG 3	CF6-80A	AR	17
9233M33P08	SEGMENT - FAIRING STG 3	CF6-80A	OH	18
9233M33P08	SEGMENT - FAIRING STG 3	CF6-80A	AR	18
9233M33P09	SEGMENT - FAIRING STG 3	CF6-80A	AR	4
9233M33P09	SEGMENT - FAIRING STG 3	CF6-80A	AR	4
9233M33P09	SEGMENT - FAIRING STG 3	CF6-80A	AR	4
9233M33P09	SEGMENT - FAIRING STG 3	CF6-80A	SV	4
9233M33P09	SEGMENT - FAIRING STG 3	CF6-80A	AR	4
9233M33P09	SEGMENT - FAIRING STG 3	CF6-80A	SV	4
9233M33P09	SEGMENT - FAIRING STG 3	CF6-80A	AR	4
9233M33P09	SEGMENT - FAIRING STG 3	CF6-80A	OH	4
9233M33P09	SEGMENT - FAIRING STG 3	CF6-80A	AR	4
9233M33P10	SEGMENT - FAIRING STG 3	CF6-80A	SV	2
9233M33P10	SEGMENT - FAIRING STG 3	CF6-80A	SV	2
9233M33P11	SEGMENT - FAIRING STG 3	CF6-80A	AR	2
9233M33P11	SEGMENT - FAIRING STG 3	CF6-80A	AR	2
9233M33P11	SEGMENT - FAIRING STG 3	CF6-80A	AR	2
9233M33P11	SEGMENT - FAIRING STG 3	CF6-80A	AR	2
9233M33P11	SEGMENT - FAIRING STG 3	CF6-80A	AR	2
9233M33P11	SEGMENT - FAIRING STG 3	CF6-80A	OH	2
9233M33P11	SEGMENT - FAIRING STG 3	CF6-80A	NS	1
9233M33P11	SEGMENT - FAIRING STG 3	CF6-80A	AR	2
9233M33P12	SEGMENT - FAIRING STG 3	CF6-80A	OH	16
9233M33P12	SEGMENT - FAIRING STG 3	CF6-80A	OH	1
9233M33P12	SEGMENT - FAIRING STG 3	CF6-80A	OH	1
9233M33P12	SEGMENT - FAIRING STG 3	CF6-80A	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9233M33P12	SEGMENT - FAIRING STG 3	CF6-80A	OH	1
9233M33P12	SEGMENT - FAIRING STG 3	CF6-80A	OH	4
9233M33P12	SEGMENT - FAIRING STG 3	CF6-80A	AR	4
9233M33P13	SEGMENT - FAIRING STG 3	CF6-80A	NE	3
9233M33P13	SEGMENT - FAIRING STG 3	CF6-80A	AR	4
9233M33P13	SEGMENT - FAIRING STG 3	CF6-80A	OH	4
9233M33P14	SEGMENT - FAIRING STG 3	CF6-80A	AR	2
9233M48G03	ELBOW - LPT DUCT	CF6-80A	AR	1
9233M48G03	ELBOW - LPT DUCT	CF6-80A	AR	1
9233M48G03	ELBOW - LPT DUCT	CF6-80A	AR	1
9233M48G03	ELBOW - LPT DUCT	CF6-80A	AR	1
9233M48G03	ELBOW - LPT DUCT	CF6-80A	AR	1
9234M14G06	SUPPORT - HPT STATOR	CF6-80A	OH	1
9234M18P01	SHIELD - HPT STATOR SUPPORT	CF6-80A	AR	1
9234M18P01	SHIELD - HPT STATOR SUPPORT	CF6-80A	AR	1
9234M18P01	SHIELD - HPT STATOR SUPPORT	CF6-80A	AR	1
9234M18P01	SHIELD - HPT STATOR SUPPORT	CF6-80A	AR	7
9234M18P01	SHIELD - HPT STATOR SUPPORT	CF6-80A	AR	2
9234M18P01	SHIELD - HPT STATOR SUPPORT	CF6-80A	AR	5
9234M18P01	SHIELD - HPT STATOR SUPPORT	CF6-80A	NE	9
9234M18P01	SHIELD - HPT STATOR SUPPORT	CF6-80A	NE	4
9234M18P02	SHIELD - HPT STATOR SUPPORT	CF6-80A	AR	1
9234M18P02	SHIELD - HPT STATOR SUPPORT	CF6-80A	AR	1
9234M18P02	SHIELD - HPT STATOR SUPPORT	CF6-80A	NS	4
9234M22G11	SUPPORT ASSY - STG 1 NOZZLE	CF6-80A	OH	1
9234M35P04	SHAFT - HPTR FWD	CF6-50	AR	1
9234M35P04	SHAFT - HPTR FWD	CF6-50	AR	1
9234M35P04	SHAFT - HPTR FWD	CF6-50	AR	1
9234M35P04	SHAFT - HPTR FWD	CF6-50	AR	1
9234M35P05	SHAFT - HPTR FWD	CF6-50 (Boeing)	AR	1
9234M36P01	RETAINER - SHIELD	CF6-80A	NE	3
9234M36P01	RETAINER - SHIELD	CF6-80A	OH	3
9234M36P01	RETAINER - SHIELD	CF6-80A	OH	5
9234M36P01	RETAINER - SHIELD	CF6-80A	OH	1
9234M36P01	RETAINER - SHIELD	CF6-80A	OH	4
9234M36P01	RETAINER - SHIELD	CF6-80A	NE	6
9234M37G02	BRACKET	CF6-80A	SV	5

Part Number	Part Description	Engine Type	Condition	Quantity
9234M37G03	BRACKET - RETAINER	CF6-80A	AR	6
9234M75P02	COVER - IMPELLER	CF6-80A	AR	1
9234M75P03	COVER - IMPELLER	CF6-80C2, CF6-80A	OH	1
9234M90G11	NOZZLE - HPT STG 2	CF6-80A	AR	1
9234M90G11	NOZZLE - HPT STG 2	CF6-80A	AR	1
9234M90G11	NOZZLE - HPT STG 2	CF6-80A	AR	1
9238M29P001A	RETAINER SEAL - THRUST LINK	CF6-80A	NS	1
9238M29P001A	RETAINER SEAL - THRUST LINK	CF6-80A	NS	3
9238M41G01	TUBE - VSV ROD END RIGHT	CF6-80A	OH	1
9238M41G01	TUBE - VSV ROD END RIGHT	CF6-80A	OH	1
9238M41G01	TUBE - VSV ROD END RIGHT	CF6-80A	OH	1
9238M45G01	TUBE - VBV HEAD RIGHT SIDE	CF6-80A	AR	1
9238M45G01	TUBE - VBV HEAD RIGHT SIDE	CF6-80A	AR	1
9238M52G01	MANIFOLD - AIR LPT	CF6-80A	AR	1
9238M54G01	MANIFOLD - AIR LPT	CF6-80A	AR	1
9238M66P07	EXCITER - IGNITION	CF6-80C2	AR	1
9238M66P07	EXCITER - IGNITION	CF6-80C2	AR	1
9238M66P07	EXCITER - IGNITION	CF6-80C2	SV	1
9238M66P08	EXCITER - IGNITION	CF6-80C2, CF6-80A	AR	1
9238M66P08	EXCITER - IGNITION	CF6-80C2, CF6-80A	AR	1
9238M66P08	EXCITER - IGNITION	CF6-80C2, CF6-80A	AR	1
9238M72G01	BRACKET	CF6-50	OH	1
9240M15G01	TUBE - OIL C SCAVENGE AFT	CF6-80A	AR	1
9240M15G01	TUBE - OIL C SCAVENGE AFT	CF6-80A	AR	1
9240M17G01	TUBE - OIL	CF6-80A	AR	1
9240M17G01	TUBE - OIL	CF6-80A	AR	1
9240M19G01	TUBE	CF6-80A	AR	1
9240M19G01	TUBE	CF6-80A	AR	1
9240M46G01	MANIFOLD	CF6-80A	AR	1
9240M46G01	MANIFOLD	CF6-80A	AR	1
9240M47G01	MANIFOLD - FUEL	CF6-80A	AR	1
9240M47G01	MANIFOLD - FUEL	CF6-80A	AR	1
9240M55G01	BRACKET ASSY - FIRE DET	CF6-50	NS	1
9240M55G01	BRACKET ASSY - FIRE DET	CF6-50	SV	1
9240M74G01	TUBE - OIL	CF6-80A	AR	1
9240M74G01	TUBE - OIL	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9241M29P02	ISOLATER - VIBRATION	CF6-50 (Boeing)	SV	1
9241M30G01	HOSE - CIT SIG	CF6-80A	AR	1
9241M30G01	HOSE - CIT SIG	CF6-80A	OH	1
9241M30G01	HOSE - CIT SIG	CF6-80A	OH	1
9241M31G01	HOSE - CIT RETURN	CF6-80A	OH	1
9241M31G01	HOSE - CIT RETURN	CF6-80A	AR	1
9241M31G01	HOSE - CIT RETURN	CF6-80A	AR	1
9241M32G02	HOSE - SIGNAL FUEL TUBE	CF6-80A	AR	1
9241M36G01	HOSE - OIL TRANSFER TUBE	CF6-80A	AR	1
9241M38G01	HOSE - HEAD END FUEL TUBE	CF6-80A	AR	1
9241M39G01	HOSE - ROD END FUEL TUBE	CF6-80A	AR	1
9241M48G02	TUBE - OIL TANK VENT	CF6-80A	AR	1
9243M30G51	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M30G51	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M30G51	LINER - SEGMENT AFT	CF6-80A	OH	1
9243M30G52	LINER - SEGMENT AFT	CF6-80A	SV	1
9243M30G53	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M30G53	LINER - SEGMENT AFT	CF6-80A	SV	1
9243M30G53	LINER - SEGMENT AFT	CF6-80A	OH	1
9243M30G54	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M30G54	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M30G56	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M30G56	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M30G56	LINER - SEGMENT AFT	CF6-80A	OH	1
9243M30G57	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M30G57	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M30G57	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M30G57	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M30G58	LINER - SEGMENT AFT	CF6-80A	OH	1
9243M30G58	LINER - SEGMENT AFT	CF6-80A	OH	1
9243M30G58	LINER - SEGMENT AFT	CF6-80A	OH	1
9243M30G58	LINER - SEGMENT AFT	CF6-80A	OH	1
9243M60G03	LINER - OUTER FWD SEG	CF6-80A	AR	1
9243M60G03	LINER - OUTER FWD SEG	CF6-80A	AR	1
9243M60G03	LINER - OUTER FWD SEG	CF6-80A	AR	1
9243M60G03	LINER - OUTER FWD SEG	CF6-80A	AR	1
9243M60G04	LINER - OUTER FWD SEG	CF6-80A	AR	1
9243M60G07	LINER - OUTER FWD SEG	CF6-80A	AR	1
9243M60G07	LINER - OUTER FWD SEG	CF6-80A	AR	1
9243M60G07	LINER - OUTER FWD SEG	CF6-80A	AR	1
9243M60G09	LINER - OUTER FWD SEG	CF6-80A	AR	1
9243M60G09	LINER - OUTER FWD SEG	CF6-80A	AR	1
9243M60G09	LINER - OUTER FWD SEG	CF6-80A	AR	1
9243M60G09	LINER - OUTER FWD SEG	CF6-80A	AR	1
9243M60G09	LINER - OUTER FWD SEG	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9243M60G09	LINER - OUTER FWD SEG	CF6-80A	AR	1
9243M60G09	LINER - OUTER FWD SEG	CF6-80A	AR	1
9243M60G09	LINER - OUTER FWD SEG	CF6-80A	AR	1
9243M60G09	LINER - OUTER FWD SEG	CF6-80A	AR	1
9243M60G09	LINER - OUTER FWD SEG	CF6-80A	OH	1
9243M60G10	LINER - OUTER FWD SEG	CF6-80A	AR	1
9243M60G10	LINER - OUTER FWD SEG	CF6-80A	AR	1
9243M64G05	LINER - OUTER AFT SEG	CF6-80A	AR	1
9243M64G05	LINER - OUTER AFT SEG	CF6-80A	AR	1
9243M68G26	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M68G26	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M68G28	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M68G28	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M68G28	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M68G28	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M68G28	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M68G28	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M68G28	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M68G28	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M68G28	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M68G28	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M68G28	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M68G28	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M68G28	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M68G28	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M68G28	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M68G30	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M68G32	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M68G33	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M68G35	LINER - SEGMENT AFT	CF6-80A	AR	1
9243M72G04	LINER - OUTER	CF6-80A	AR	1
9243M72G04	LINER - OUTER	CF6-80A	AR	1
9243M72G04	LINER - OUTER	CF6-80A	AR	1
9243M72G04	LINER - OUTER	CF6-80A	AR	1
9243M72G04	LINER - OUTER	CF6-80A	AR	1
9243M72G04	LINER - OUTER	CF6-80A	AR	1
9243M72G04	LINER - OUTER	CF6-80A	AR	1
9243M72G04	LINER - OUTER	CF6-80A	AR	1
9243M72G04	LINER - OUTER	CF6-80A	AR	1
9243M72G04	LINER - OUTER	CF6-80A	AR	1
9243M72G04	LINER - OUTER	CF6-80A	AR	1
9243M72G04	LINER - OUTER	CF6-80A	AR	1
9243M72G04	LINER - OUTER	CF6-80A	AR	1
9243M72G04	LINER - OUTER	CF6-80A	REP	1
9243M72G04	LINER - OUTER	CF6-80A	AR	1
9243M72G04	LINER - OUTER	CF6-80A	AR	1
9243M72G04	LINER - OUTER	CF6-80A	AR	1
9243M72G04	LINER - OUTER	CF6-80A	AR	1
9243M72G04	LINER - OUTER	CF6-80A	AR	1
9243M72G04	LINER - OUTER	CF6-80A	AR	1
9243M72G04	LINER - OUTER	CF6-80A	AR	1
9243M72G04	LINER - OUTER	CF6-80A	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
9243M75G57	LINER - SEG INNER AFT	CF6-80A	OH	1
9243M75G57	LINER - SEG INNER AFT	CF6-80A	OH	1
9243M79G40	LINER - SEGMENT FWD	CF6-80A	AR	1
9243M79G40	LINER - SEGMENT FWD	CF6-80A	AR	1
9243M79G41	LINER - SEGMENT FWD	CF6-80A	AR	1
9243M79G41	LINER - SEGMENT FWD	CF6-80A	AR	1
9243M79G41	LINER - SEGMENT FWD	CF6-80A	OH	1
9243M79G41	LINER - SEGMENT FWD	CF6-80A	OH	1
9243M79G42	LINER - SEGMENT FWD	CF6-80A	AR	1
9243M79G42	LINER - SEGMENT FWD	CF6-80A	AR	1
9243M79G42	LINER - SEGMENT FWD	CF6-80A	AR	1
9243M79G42	LINER - SEGMENT FWD	CF6-80A	AR	1
9243M79G43	LINER - SEGMENT FWD	CF6-80A	AR	1
9243M79G44	LINER - SEGMENT FWD	CF6-80A	AR	1
9243M79G44	LINER - SEGMENT FWD	CF6-80A	AR	1
9243M79G44	LINER - SEGMENT FWD	CF6-80A	AR	1
9243M79G44	LINER - SEGMENT FWD	CF6-80A	OH	1
9243M79G44	LINER - SEGMENT FWD	CF6-80A	AR	1
9243M79G45	LINER - SEGMENT FWD	CF6-80A	OH	1
9243M79G45	LINER - SEGMENT FWD	CF6-80A	REP	1
9243M79G46	LINER - SEGMENT FWD	CF6-80A	AR	1
9243M79G46	LINER - SEGMENT FWD	CF6-80A	AR	1
9243M79G46	LINER - SEGMENT FWD	CF6-80A	AR	1
9243M79G46	LINER - SEGMENT FWD	CF6-80A	OH	1
9243M79G46	LINER - SEGMENT FWD	CF6-80A	OH	1
9243M79G46	LINER - SEGMENT FWD	CF6-80A	OH	1
9243M79G46	LINER - SEGMENT FWD	CF6-80A	OH	1
9243M79G47	LINER - SEGMENT FWD	CF6-80A	AR	1
9243M79G47	LINER - SEGMENT FWD	CF6-80A	AR	1
9243M79G47	LINER - SEGMENT FWD	CF6-80A	AR	1
9243M79G48	LINER - SEGMENT FWD	CF6-80A	OH	1
9243M79G89	LINER - SEGMENT FWD	CF6-80A	AR	1
9243M83P03	SLEEVE - OGV	CF6-80A	NE	25
9243M83P03	SLEEVE - OGV	CF6-80A	NE	10
9244M15P03	BEARING - BALL NO. 1	CF6-80A	AR	1
9244M15P03	BEARING - BALL NO. 1	CF6-80A	AR	1
9244M15P04	BEARING - BALL NO. 1	CF6-80C2	AR	1
9244M20G02	SUPPORT - BALL BRG HOR AXIS	CF6-80A	AR	1
9244M20G02	SUPPORT - BALL BRG HOR AXIS	CF6-80A	AR	1
9244M20G03	SUPPORT - BALL BRG HOR AXIS	CF6-80A	AR	1
9244M24P002A	RETAINER - NUT	CF6-80A	AR	1
9244M24P002A	RETAINER - NUT	CF6-80A	AR	2
9244M70G06	TUBE - CENTER VENT	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9244M70G06	TUBE - CENTER VENT	CF6-80A	AR	1
9244M72P03	BEARING - NO. 6R	CF6-80A	OH	1
9244M74P01	SPACER - STG 1	CF6-80A	AR	38
9244M74P01	SPACER - STG 1	CF6-80A	AR	37
9244M74P01	SPACER - STG 1	CF6-80A	AR	38
9244M74P01	SPACER - STG 1	CF6-80A	AR	38
9244M74P01	SPACER - STG 1	CF6-80A	AR	38
9244M74P01	SPACER - STG 1	CF6-80A	AR	38
9244M74P01	SPACER - STG 1	CF6-80A	AR	38
9244M74P01	SPACER - STG 1	CF6-80A	OH	3
9244M74P01	SPACER - STG 1	CF6-80A	OH	2
9244M74P01	SPACER - STG 1	CF6-80A	AR	38
9244M74P01	SPACER - STG 1	CF6-80A	SV	37
9244M79P01	BRACKET - LATCH	CF6-80A	AR	1
9244M79P01	BRACKET - LATCH	CF6-80A	SV	1
9244M85G03	BRACKET - LATCH	CF6-80A	AR	1
9244M85G03	BRACKET - LATCH	CF6-80A	AR	1
9245M14G01	TUBE - AIR VENT	CF6-80A	AR	1
9245M14G01	TUBE - AIR VENT	CF6-80A	AR	1
9245M14G01	TUBE - AIR VENT	CF6-80A	AR	1
9245M14G01	TUBE - AIR VENT	CF6-80A	OH	1
9245M61P01	RETAINER	CF6-80A	AR	1
9245M71G01	TUBE - ABG SCAV	CF6-80A	OH	1
9245M71G01	TUBE - ABG SCAV	CF6-80A	SV	1
9245M71G03	TUBE - ABG SCAV	CF6-80A	AR	1
9245M71G03	TUBE - ABG SCAV	CF6-80A	AR	1
9245M71G03	TUBE - ABG SCAV	CF6-80A	AR	1
9245M94P001A	BRACKET	CF6-80A	SV	1
9245M94P001A	BRACKET	CF6-80A	AR	1
9245M96G02	TUBE - B SUMP PRESSURE	CF6-80A	AR	1
9245M96G02	TUBE - B SUMP PRESSURE	CF6-80A	AR	1
9246M50G01	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G01	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G01	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G01	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G01	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G01	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G01	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G01	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9246M50G01	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G01	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G01	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G01	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G01	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G01	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G01	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G01	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G01	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G01	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G01	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9246M50G01	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G01	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9246M50G02	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G02	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G02	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G02	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G02	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G02	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G02	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G02	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G02	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G02	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G02	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G02	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9246M50G02	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G02	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G02	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G02	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G02	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G02	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9246M50G02	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9246M50G02	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G02	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G02	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9246M50G02	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9246M50G02	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9246M50G02	MANIFOLD ASSY - SHROUDED	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9246M56G02	TUBE - AIR	CF6-80A	AR	1
9246M56G02	TUBE - AIR	CF6-80A	AR	1
9246M62G01	MANIFOLD - OIL MAIN SPLY AFT	CF6-80A	AR	1
9246M62G01	MANIFOLD - OIL MAIN SPLY AFT	CF6-80A	AR	1
9246M62G01	MANIFOLD - OIL MAIN SPLY AFT	CF6-80A	AR	1
9246M62G01	MANIFOLD - OIL MAIN SPLY AFT	CF6-80A	AR	1
9246M62G01	MANIFOLD - OIL MAIN SPLY AFT	CF6-80A	SV	1
9246M64G01	TUBE - SUPPLY	CF6-80A	AR	1
9246M84G01	TUBE - B SCAV	CF6-80A	AR	1
9246M84G01	TUBE - B SCAV	CF6-80A	AR	1
9246M84G01	TUBE - B SCAV	CF6-80A	AR	1
9246M84G01	TUBE - B SCAV	CF6-80A	AR	1
9246M84G01	TUBE - B SCAV	CF6-80A	AR	1
9246M84G01	TUBE - B SCAV	CF6-80A	AR	1
9246M84G01	TUBE - B SCAV	CF6-80A	AR	1
9246M92P01	SPLICE - BULB SEAL	CF6-80A	NS	1
9249M17G02	HOUSING ASSY - SUMP BRG	CF6-80A	AR	1
9249M17G03	SUMP - HSG BRG 6	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9249M17G04	SUMP - HSG BRG 6	CF6-80A	AR	1
9249M17G05	SUMP - HSG BRG 6	CF6-80A	AR	1
9249M18G03	SPANNER - NUT	CF6-80A	OH	1
9249M20P01	SEAL - ROTATING OIL	CF6-80A	AR	1
9249M20P03	SEAL - ROTATING OIL	CF6-80A	SV	1
9249M20P04	SEAL - ROTATING OIL	CF6-80A	SV	1
9249M20P04	SEAL - ROTATING OIL	CF6-80A	SV	1
9249M20P04	SEAL - ROTATING OIL	CF6-80A	OH	1
9249M21G02	SEAL - AIR VENT	CF6-80A	AR	1
9249M21G04	SEAL - AIR VENT	CF6-80A	AR	1
9249M21G04	SEAL - AIR VENT	CF6-80A	AR	1
9249M21G04	SEAL - AIR VENT	CF6-80A	OH	1
9249M21G04	SEAL - AIR VENT	CF6-80A	AR	1
9249M21G04	SEAL - AIR VENT	CF6-80A	AR	1
9249M24P01	BAFFLE - OIL BRG	CF6-80A	AR	1
9249M24P01	BAFFLE - OIL BRG	CF6-80A	AR	1
9249M25P001A	BRACKET - TUBE OIL IN C	CF6-80A	NS	2
9249M25P001A	BRACKET - TUBE OIL IN C	CF6-80A	SV	1
9249M26P02	HOUSING - CARBON SEAL	CF6-80A	AR	1
9249M27P01	SLINGER - OIL BRG NO. 6	CF6-80A	AR	1
9249M27P01	SLINGER - OIL BRG NO. 6	CF6-80A	AR	1
9249M95G06	SCOOP ASSY - LINER AND	CF6-80A	AR	1
9249M95G07	SCOOP ASSY - LINER AND	CF6-80A	AR	1
9249M95G07	SCOOP ASSY - LINER AND	CF6-80A	AR	1
9249M95G07	SCOOP ASSY - LINER AND	CF6-80A	AR	1
9249M95G07	SCOOP ASSY - LINER AND	CF6-80A	OH	1
9249M99G01	RETAINER - NUT	CF6-80A	AR	1
9249M99G01	RETAINER - NUT	CF6-80A	OH	1
9249M99G01	RETAINER - NUT	CF6-80A	NS	2
9249M99G01	RETAINER - NUT	CF6-80A	NE	3
9250M65G01	TUBE - AIR PS3 TO ALT	CF6-80A	AR	1
9250M71P001A	BRACKET - FLAT	CF6-80A	NE	2
9250M71P001A	BRACKET - FLAT	CF6-80A	SV	1
9250M71P001A	BRACKET - FLAT	CF6-80A	NE	1
9250M72P001A	BRACKET - FLAT	CF6-80A	AR	1
9250M72P001A	BRACKET - FLAT	CF6-80A	SV	1
9250M77G01	BRACKET	CF6-80A	AR	1
9250M77G01	BRACKET	CF6-80A	AR	1
9250M97P04	EXCHANGER - FUEL/OIL HEAT	CF6-80C2	SV	1
9250M99G01	BRACKET	CF6-80A	SV	1
9252M32G03	CASE - STG 2 FAN STATOR	CF6-80A	OH	1
9252M33G05	CASE - STG 3 FAN STATOR	CF6-80A	AR	1
9252M33G05	CASE - STG 3 FAN STATOR	CF6-80A	AR	1
9252M33G05	CASE - STG 3 FAN STATOR	CF6-80A	OH	1
9252M33G05	CASE - STG 3 FAN STATOR	CF6-80A	AR	1
9253M20P02	RING - DAMPENING	CF6-80C2, CF6-80A	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9253M20P02	RING - DAMPENING	CF6-80C2, CF6-80A	OH	1
9253M20P02	RING - DAMPENING	CF6-80C2, CF6-80A	OH	1
9253M20P02	RING - DAMPENING	CF6-80C2, CF6-80A	OH	1
9253M20P02	RING - DAMPENING	CF6-80C2, CF6-80A	AR	1
9253M20P02	RING - DAMPENING	CF6-80C2, CF6-80A	NE	1
9253M20P02	RING - DAMPENING	CF6-80C2, CF6-80A	OH	1
9253M30G09	LUG - LKG STG 2	CF6-80A	OH	1
9253M30G09	LUG - LKG STG 2	CF6-80A	OH	1
9253M31G17	LUG - LKG STG 3	CF6-80A	OH	1
9253M31G18	LUG - LKG STG 4	CF6-80A	OH	2
9253M46P01	BEARING - SPHERICAL	CF6-80A	NS	3
9253M90G02	SEAL - PRESS BAL	CF6-80A	SV	1
9253M91G02	SEAL - ROTATING	CF6-80A	SV	1
9254M14P001A	BRACKET - TUBE	CF6-80A	AR	1
9254M14P001A	BRACKET - TUBE	CF6-80A	AR	1
9254M34P01	JOINT - FLEXIBLE	CF6-80A	NE	2
9254M54G01	MANIFOLD - OIL	CF6-80A	AR	1
9254M54G01	MANIFOLD - OIL	CF6-80A	AR	1
9254M54G01	MANIFOLD - OIL	CF6-80A	AR	1
9254M54G01	MANIFOLD - OIL	CF6-80A	AR	1
9255M57G01	BRACKET	CF6-50	NE	1
9255M57G01	BRACKET	CF6-50	AR	1
9256M38G01	BRACKET	CF6-50 (LMCO)	OH	1
9256M38G01	BRACKET	CF6-50 (LMCO)	SV	1
9256M39P001A	BRACKET	CF6-50 (Boeing)	OH	1
9256M39P001A	BRACKET	CF6-50 (Boeing)	SV	1
9256M51P001A	BRACKET	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9256M51P001A	BRACKET	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9257-07	PUMP - FUEL	CF6-50	AR	1
9257-08	PUMP - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9257-08	PUMP - FUEL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9257M11P02	JOINT - FLEXIBLE	CF6-80A	NE	1
9257M32G05	TRANSITION - DUCT SUPPLY	CF6-80A	AR	1
9257M32G06	TRANSITION - DUCT SUPPLY	CF6-80A	AR	1
9257M32G06	TRANSITION - DUCT SUPPLY	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9257M32G06	TRANSITION - DUCT SUPPLY	CF6-80A	OH	1
9257M32G06	TRANSITION - DUCT SUPPLY	CF6-80A	OH	1
9257M32G06	TRANSITION - DUCT SUPPLY	CF6-80A	OH	1
9257M34P04	VIRBO-METER	CF6-80A	SV	1
9257M41G01	TUBE - EDUCTOR FWD	CF6-80A	SV	1
9257M41G01	TUBE - EDUCTOR FWD	CF6-80A	AR	1
9257M56G05	BRACKET - STG 3	CF6-80A	NS	1
9257M59G03	BRACKET - ANGLE	CF6-80A	NS	1
9257M62P01	HOSE	CF6-80A	NE	1
9257M62P01	HOSE	CF6-80A	NE	9
9257M62P02	HOSE	CF6-80A	NE	5
9257M63G02	BRACKET	CF6-80A	OH	1
9257M71G06	BRACKET	CF6-80A	SV	2
9257M71G06	BRACKET	CF6-80A	AR	3
9257M71G06	BRACKET	CF6-80A	SV	1
9257M81P001A	BRACKET	CF6-80A	AR	1
9257M90G03	BRACKET	CF6-80A	AR	1
9257M90G05	BRACKET	CF6-80A	AR	1
9257M91G05	BRACKET	CF6-80A	OH	1
9257M92G05	BRACKET	CF6-80A	AR	1
9258M14G03	BRACKET	CF6-80A	AR	1
9258M14G03	BRACKET	CF6-80A	OH	2
9258M14G03	BRACKET	CF6-80A	NS	1
9258M39G01	TUBE - FUEL	CF6-80A	AR	1
9258M39G01	TUBE - FUEL	CF6-80A	AR	1
9258M64G01	TUBE - AIR HPT COOLING	CF6-80A	AR	1
9258M64G01	TUBE - AIR HPT COOLING	CF6-80A	AR	1
9258M64G01	TUBE - AIR HPT COOLING	CF6-80A	AR	3
9258M64G01	TUBE - AIR HPT COOLING	CF6-80A	OH	1
9258M64G02	TUBE - AIR HPT COOLING	CF6-80C2, CF6-80A	AR	1
9258M64G02	TUBE - AIR HPT COOLING	CF6-80C2, CF6-80A	AR	1
9258M64G02	TUBE - AIR HPT COOLING	CF6-80C2, CF6-80A	OH	1
9258M64G02	TUBE - AIR HPT COOLING	CF6-80C2, CF6-80A	AR	1
9258M64G02	TUBE - AIR HPT COOLING	CF6-80C2, CF6-80A	AR	1
9258M64G02	TUBE - AIR HPT COOLING	CF6-80C2, CF6-80A	AR	2
9258M64G02	TUBE - AIR HPT COOLING	CF6-80C2, CF6-80A	AR	2
9258M64G02	TUBE - AIR HPT COOLING	CF6-80C2, CF6-80A	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
9258M64G02	TUBE - AIR HPT COOLING	CF6-80C2, CF6-80A	OH	2
9258M64G03	TUBE - AIR HPT COOLING	CF6-80C2, CF6-80A	AR	1
9258M64G03	TUBE - AIR HPT COOLING	CF6-80C2, CF6-80A	AR	1
9258M64G03	TUBE - AIR HPT COOLING	CF6-80C2, CF6-80A	AR	2
9258M64G03	TUBE - AIR HPT COOLING	CF6-80C2, CF6-80A	NE	1
9258M64G03	TUBE - AIR HPT COOLING	CF6-80C2, CF6-80A	SV	1
9258M67G01	ELBOW - AIR HPT COOLING	CF6-80C2, CF6-80A	AR	1
9258M67G01	ELBOW - AIR HPT COOLING	CF6-80C2, CF6-80A	AR	1
9258M67G01	ELBOW - AIR HPT COOLING	CF6-80C2, CF6-80A	AR	1
9258M67G01	ELBOW - AIR HPT COOLING	CF6-80C2, CF6-80A	AR	2
9258M67G01	ELBOW - AIR HPT COOLING	CF6-80C2, CF6-80A	AR	1
9258M67G01	ELBOW - AIR HPT COOLING	CF6-80C2, CF6-80A	AR	3
9258M67G01	ELBOW - AIR HPT COOLING	CF6-80C2, CF6-80A	AR	4
9258M67G01	ELBOW - AIR HPT COOLING	CF6-80C2, CF6-80A	OH	1
9258M67G01	ELBOW - AIR HPT COOLING	CF6-80C2, CF6-80A	OH	1
9258M67G01	ELBOW - AIR HPT COOLING	CF6-80C2, CF6-80A	SV	1
9258M67G01	ELBOW - AIR HPT COOLING	CF6-80C2, CF6-80A	AR	1
9258M67G01	ELBOW - AIR HPT COOLING	CF6-80C2, CF6-80A	AR	2
9258M67G01	ELBOW - AIR HPT COOLING	CF6-80C2, CF6-80A	AR	1
9258M67G01	ELBOW - AIR HPT COOLING	CF6-80C2, CF6-80A	AR	4
9258M80G01	BRACKET - BRACE	CF6-80A	OH	1
9258M80G01	BRACKET - BRACE	CF6-80A	NE	1
9258M91G01	BRACKET	CF6-80A	AR	1
9258M91G01	BRACKET	CF6-80A	AR	1
9258M91G02	BRACKET	CF6-80A	AR	1
9258M91G02	BRACKET	CF6-80A	AR	1
9259M42G01	TUBE - FUEL DRAIN	CF6-80A	AR	1
9259M42G01	TUBE - FUEL DRAIN	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9259M76P01	SEAL	CF6-80C2, CF6-80A	NE	1
9259M76P01	SEAL	CF6-80C2, CF6-80A	NE	3
9259M76P01	SEAL	CF6-80C2, CF6-80A	NE	1
9259M95G01	RETAINER - HALF SEAL	CF6-80A	AR	2
9259M95G01	RETAINER - HALF SEAL	CF6-80A	NS	2
9259M95G01	RETAINER - HALF SEAL	CF6-80A	SV	1
9260M12G03	BRACKET - SCAVENGE	CF6-80A	AR	1
9260M12G03	BRACKET - SCAVENGE	CF6-80A	AR	1
9261M25G01	MANIFOLD	CF6-80A	AR	1
9261M25G01	MANIFOLD	CF6-80A	AR	1
9261M25G01	MANIFOLD	CF6-80A	AR	1
9261M27G01	MANIFOLD	CF6-80A	AR	1
9261M27G01	MANIFOLD	CF6-80A	AR	1
9261M27G01	MANIFOLD	CF6-80A	AR	1
9261M27G01	MANIFOLD	CF6-80A	AR	1
9261M27G01	MANIFOLD	CF6-80A	AR	1
9261M27G01	MANIFOLD	CF6-80A	AR	1
9261M31G01	MANIFOLD	CF6-80A	SV	1
9261M31G01	MANIFOLD	CF6-80A	AR	1
9261M31G01	MANIFOLD	CF6-80A	SV	1
9261M31G01	MANIFOLD	CF6-80A	AR	1
9261M50G02	MANIFOLD - AIR LOW PRESS	CF6-80A	AR	1
9261M50G04	MANIFOLD - AIR LP RECOUP	CF6-80A	OH	1
9261M73P01	SENSOR - CIT	CF6-50	SV	1
9261M73P01	SENSOR - CIT	CF6-50	AR	1
9262M12G01	TUBE - FUEL COMBUSTOR DRAIN	CF6-80A	AR	1
9262M38G01	BRACKET - FUEL SHUT OFF	CF6-80A	NE	1
9262M38G01	BRACKET - FUEL SHUT OFF	CF6-80A	NS	1
9262M57G01	MANIFOLD - OIL MAIN SUPPLY	CF6-80A	OH	1
9262M60P001A	BRACKET	CF6-80A	AR	1
9262M61G01	RETAINER	CF6-80A	AR	1
9262M61G01	RETAINER	CF6-80A	AR	1
9262M61G01	RETAINER	CF6-80A	NS	1
9262M61G01	RETAINER	CF6-80A	NS	1
9262M84G01	TUBE - OIL B SCAV AFT	CF6-80A	AR	1
9262M84G01	TUBE - OIL B SCAV AFT	CF6-80A	AR	1
9262M84G01	TUBE - OIL B SCAV AFT	CF6-80A	AR	1
9262M84G01	TUBE - OIL B SCAV AFT	CF6-80A	OH	1
9262M84G01	TUBE - OIL B SCAV AFT	CF6-80A	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G06	BLADE ASSY - HPTR STG 2	CF6-80A	SV	1
9264M69G07	BLADE ASSY - HPTR STG 2	CF6-80A	OH	1
9264M69G07	BLADE ASSY - HPTR STG 2	CF6-80A	AR	1
9264M69G07	BLADE ASSY - HPTR STG 2	CF6-80A	OH	1
9264M69G07	BLADE ASSY - HPTR STG 2	CF6-80A	OH	1

[illegible]

[illegible]

Part Number	Part Description	Engine Type	Condition	Quantity
9267M28P07	BLADE - FAN STG 1	CF6-80A	AR	1
9267M28P07	BLADE - FAN STG 1	CF6-80A	OH	1
9267M28P07	BLADE - FAN STG 1	CF6-80A	OH	1
9267M28P07	BLADE - FAN STG 1	CF6-80A	OH	1
9267M28P07	BLADE - FAN STG 1	CF6-80A	OH	1
9267M28P07	BLADE - FAN STG 1	CF6-80A	OH	1
9267M28P07	BLADE - FAN STG 1	CF6-80A	OH	1
9267M28P07	BLADE - FAN STG 1	CF6-80A	OH	1
9267M28P07	BLADE - FAN STG 1	CF6-80A	OH	1
9267M28P07	BLADE - FAN STG 1	CF6-80A	OH	1
9267M28P07	BLADE - FAN STG 1	CF6-80A	OH	1
9267M28P09	BLADE - FAN STG 1	CF6-80A	AR	1
9267M28P09	BLADE - FAN STG 1	CF6-80A	AR	1
9267M28P09	BLADE - FAN STG 1	CF6-80A	AR	1
9267M28P09	BLADE - FAN STG 1	CF6-80A	OH	1
9267M30G12	LINER - COMB CHAMBER OUTER	CF6-80A	OH	1
9267M31G06	LINER - COMB CHAMBER INNER	CF6-80A	AR	1
9267M31G07	LINER - COMB CHAMBER INNER	CF6-80A	AR	1
9267M31G11	LINER - COMB CHAMBER INNER	CF6-80A	AR	1
9267M45P01	ADAPTER - GEARBOX	CF6-80A	AR	1
9267M46P01	ADAPTER - GEARBOX	CF6-80A	AR	1
9267M61P03	VANE - FAN STTR STG 1	CF6-80A	AR	78
9267M61P03	VANE - FAN STTR STG 1	CF6-80A	AR	78
9267M61P03	VANE - FAN STTR STG 1	CF6-80A	AR	78
9267M61P03	VANE - FAN STTR STG 1	CF6-80A	AR	78
9267M61P03	VANE - FAN STTR STG 1	CF6-80A	AR	78
9267M61P03	VANE - FAN STTR STG 1	CF6-80A	AR	78
9267M61P03	VANE - FAN STTR STG 1	CF6-80A	SV	42
9267M61P03	VANE - FAN STTR STG 1	CF6-80A	AR	78
9267M61P03	VANE - FAN STTR STG 1	CF6-80A	SV	36
9267M61P03	VANE - FAN STTR STG 1	CF6-80A	OH	25
9267M61P03	VANE - FAN STTR STG 1	CF6-80A	OH	25
9267M61P03	VANE - FAN STTR STG 1	CF6-80A	OH	24
9267M61P03	VANE - FAN STTR STG 1	CF6-80A	OH	3
9267M61P03	VANE - FAN STTR STG 1	CF6-80A	OH	1
9267M61P03	VANE - FAN STTR STG 1	CF6-80A	AR	78
9267M62P02	VANE - FAN STTR STG 2	CF6-80A	AR	112
9267M62P02	VANE - FAN STTR STG 2	CF6-80A	AR	112
9267M62P02	VANE - FAN STTR STG 2	CF6-80A	AR	112
9267M62P02	VANE - FAN STTR STG 2	CF6-80A	AR	113
9267M62P02	VANE - FAN STTR STG 2	CF6-80A	AR	11
9267M62P02	VANE - FAN STTR STG 2	CF6-80A	AR	112
9267M62P02	VANE - FAN STTR STG 2	CF6-80A	AR	112

Part Number	Part Description	Engine Type	Condition	Quantity
9267M62P02	VANE - FAN STTR STG 2	CF6-80A	SV	12
9267M62P02	VANE - FAN STTR STG 2	CF6-80A	SV	9
9267M62P02	VANE - FAN STTR STG 2	CF6-80A	AR	112
9267M62P02	VANE - FAN STTR STG 2	CF6-80A	AR	112
9267M62P02	VANE - FAN STTR STG 2	CF6-80A	SV	12
9267M62P02	VANE - FAN STTR STG 2	CF6-80A	SV	12
9267M62P02	VANE - FAN STTR STG 2	CF6-80A	SV	12
9267M62P02	VANE - FAN STTR STG 2	CF6-80A	AR	112
9267M62P02	VANE - FAN STTR STG 2	CF6-80A	AR	112
9267M75G04	TUBE - OIL IN STRUT 5	CF6-80A	OH	1
9267M75G04	TUBE - OIL IN STRUT 5	CF6-80A	OH	1
9267M90P01	ADAPTER - STARTER TO GRBX	CF6-50	AR	1
9268M26G01	MANIFOLD - OIL SCAVENGE	CF6-80A	AR	1
9268M26G05	MANIFOLD - OIL SCAVENGE	CF6-80A	AR	1
9268M26G05	MANIFOLD - OIL SCAVENGE	CF6-80A	AR	1
9268M26G05	MANIFOLD - OIL SCAVENGE	CF6-80A	AR	1
9268M26G05	MANIFOLD - OIL SCAVENGE	CF6-80A	AR	1
9268M30G01	BRACKET	CF6-80A	AR	1
9268M30G01	BRACKET	CF6-80A	AR	1
9268M32P02	SENSOR - TEMP	CF6-80A	AR	1
9268M40G01	TUBE - OIL SUPPLY MID	CF6-80A	AR	1
9268M44G01	TUBE - OIL C SCAVENGE	CF6-80A	AR	1
9268M44G01	TUBE - OIL C SCAVENGE	CF6-80A	AR	1
9268M44G01	TUBE - OIL C SCAVENGE	CF6-80A	AR	1
9268M44G01	TUBE - OIL C SCAVENGE	CF6-80A	AR	1
9268M44G01	TUBE - OIL C SCAVENGE	CF6-80A	AR	1
9268M46G01	TUBE - OIL C SCAV AFT	CF6-80A	AR	1
9268M46G01	TUBE - OIL C SCAV AFT	CF6-80A	AR	1
9268M46G01	TUBE - OIL C SCAV AFT	CF6-80A	AR	1
9268M66P001A	BRACKET	CF6-80A	AR	1
9268M67P001A	PLATE - COVER	CF6-80A	NS	1
9268M80P02	RETAINER - TOP 1	CF6-80A	OH	1
9268M80P05	RETAINER - TOP 1	CF6-80A	AR	1
9268M80P05	RETAINER - TOP 1	CF6-80A	OH	1
9268M80P07	RETAINER - TOP 1	CF6-80A	AR	1
9268M84P02	PLATE	CF6-80C2	NE	1
9269M24G01	TUBE	CF6-80A	AR	1
9269M24G01	TUBE	CF6-80A	OH	1
9269M24G01	TUBE	CF6-80A	AR	1
9269M24G01	TUBE	CF6-80A	AR	1
9269M42G03	FIREWALL - FRONT	CF6-80A	AR	1
9269M42G03	FIREWALL - FRONT	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9269M42G03	FIREWALL - FRONT	CF6-80A	AR	1
9269M42G03	FIREWALL - FRONT	CF6-80A	AR	1
9269M44P001A	RETAINER - SEAL	CF6-80A	SV	1
9269M44P001A	RETAINER - SEAL	CF6-80A	SV	1
9269M46P01	SEAL - CORNER	CF6-80A	NE	3
9269M53G03	TUBE	CF6-80A	AR	1
9269M53G03	TUBE	CF6-80A	AR	1
9269M53G03	TUBE	CF6-80A	AR	1
9269M53G03	TUBE	CF6-80A	AR	1
9269M57G01	BRACKET	CF6-80A	OH	1
9269M57G01	BRACKET	CF6-80A	OH	1
9269M57G01	BRACKET	CF6-80A	AR	1
9269M58G01	BRACKET	CF6-80A	AR	1
9269M94G03	TUBE - OIL	CF6-80A	SV	1
9269M94G03	TUBE - OIL	CF6-80A	OH	1
9269M94G03	TUBE - OIL	CF6-80A	OH	1
9269M98G01	TUBE - LOW PRESSURE RECOUP	CF6-80A	OH	1
9270M23P001A	BRACKET	CF6-80A	AR	1
9270M23P001A	BRACKET	CF6-80A	NS	4
9270M25G01	TUBE - C SCAVENGE	CF6-80A	AR	1
9270M25G01	TUBE - C SCAVENGE	CF6-80A	AR	1
9270M25G01	TUBE - C SCAVENGE	CF6-80A	AR	1
9270M25G01	TUBE - C SCAVENGE	CF6-80A	AR	1
9270M25G01	TUBE - C SCAVENGE	CF6-80A	AR	1
9270M27P01	COUPLING - L/P RECOUP BALL	CF6-80A	NE	1
9270M31P02	TUBE	CF6-80A	AR	1
9270M31P02	TUBE	CF6-80A	AR	1
9270M31P02	TUBE	CF6-80A	AR	1
9270M31P02	TUBE	CF6-80A	AR	1
9270M31P03	TUBE	CF6-80A	AR	1
9270M37P01	SECTION - TUBE	CF6-80A	NE	2
9270M37P02	HOSE - AIR	CF6-80A	NE	1
9270M38P001A	PLATE	CF6-80A	AR	1
9270M38P001B	PLATE	CF6-80A	AR	1
9270M38P005A	PLATE	CF6-80A	AR	1
9270M39P005A	PLATE	CF6-80A	AR	1
9271M92G01	TUBE - OIL B SCAVENGE FWD	CF6-80A	AR	1
9271M92G01	TUBE - OIL B SCAVENGE FWD	CF6-80A	AR	1
9271M92G01	TUBE - OIL B SCAVENGE FWD	CF6-80A	AR	1
9271M92G01	TUBE - OIL B SCAVENGE FWD	CF6-80A	AR	1
9271M92G01	TUBE - OIL B SCAVENGE FWD	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9271M94G01	TUBE - OIL B SCAVENGE	CF6-80A	OH	1
9271M94G01	TUBE - OIL B SCAVENGE	CF6-80A	AR	1
9271M94G01	TUBE - OIL B SCAVENGE	CF6-80A	AR	1
9271M94G01	TUBE - OIL B SCAVENGE	CF6-80A	AR	1
9271M94G01	TUBE - OIL B SCAVENGE	CF6-80A	OH	1
9272M11P05	SEGMENT - FAIRING STG 1	CF6-80A	OH	10
9272M11P05	SEGMENT - FAIRING STG 1	CF6-80A	AR	12
9272M11P05	SEGMENT - FAIRING STG 1	CF6-80A	AR	12
9272M11P05	SEGMENT - FAIRING STG 1	CF6-80A	AR	12
9272M11P05	SEGMENT - FAIRING STG 1	CF6-80A	AR	12
9272M11P05	SEGMENT - FAIRING STG 1	CF6-80A	OH	1
9272M11P05	SEGMENT - FAIRING STG 1	CF6-80A	AR	12
9272M11P05	SEGMENT - FAIRING STG 1	CF6-80A	OH	12
9272M11P06	SEGMENT - FAIRING STG 1	CF6-80A	OH	2
9272M11P06	SEGMENT - FAIRING STG 1	CF6-80A	OH	1
9272M11P06	SEGMENT - FAIRING STG 1	CF6-80A	AR	2
9272M11P06	SEGMENT - FAIRING STG 1	CF6-80A	AR	2
9272M11P06	SEGMENT - FAIRING STG 1	CF6-80A	AR	2
9272M11P06	SEGMENT - FAIRING STG 1	CF6-80A	AR	2
9272M11P06	SEGMENT - FAIRING STG 1	CF6-80A	OH	2
9272M11P08	SEGMENT - FAIRING STG 1	CF6-80A	OH	2
9272M11P10	SEGMENT - FAIRING STG 1	CF6-80A	AR	2
9272M11P10	SEGMENT - FAIRING STG 1	CF6-80A	AR	2
9272M11P10	SEGMENT - FAIRING STG 1	CF6-80A	AR	2
9272M11P10	SEGMENT - FAIRING STG 1	CF6-80A	OH	1
9272M11P10	SEGMENT - FAIRING STG 1	CF6-80A	NS	1
9272M11P10	SEGMENT - FAIRING STG 1	CF6-80A	AR	2
9272M11P10	SEGMENT - FAIRING STG 1	CF6-80A	AR	2
9272M11P12	SEGMENT - FAIRING STG 1	CF6-80A	OH	2
9272M11P12	SEGMENT - FAIRING STG 1	CF6-80A	OH	6
9272M11P13	SEGMENT - FAIRING STG 1	CF6-80A	NS	1
9272M20P07	SEAL - DIFFUSER AFT	CF6-80A	AR	1
9272M20P07	SEAL - DIFFUSER AFT	CF6-80A	AR	1
9272M20P07	SEAL - DIFFUSER AFT	CF6-80A	AR	1
9272M21P08	SEAL - DIFFUSER FWD	CF6-80A	AR	1
9272M21P08	SEAL - DIFFUSER FWD	CF6-80A	AR	1
9272M21P08	SEAL - DIFFUSER FWD	CF6-80A	AR	1
9272M21P10	SEAL - DIFFUSER FWD	CF6-80C2	AR	1
9272M21P10	SEAL - DIFFUSER FWD	CF6-80C2	AR	1
9272M21P10	SEAL - DIFFUSER FWD	CF6-80C2	AR	1
9272M21P10	SEAL - DIFFUSER FWD	CF6-80C2	AR	1
9272M21P10	SEAL - DIFFUSER FWD	CF6-80C2	AR	1
9272M21P10	SEAL - DIFFUSER FWD	CF6-80C2	OH	1
9272M21P10	SEAL - DIFFUSER FWD	CF6-80C2	AR	1
9272M22P05	SEGMENT - FAIRING STG 2	CF6-80A	AR	18
9272M22P05	SEGMENT - FAIRING STG 2	CF6-80A	OH	18
9272M22P05	SEGMENT - FAIRING STG 2	CF6-80A	AR	18
9272M22P05	SEGMENT - FAIRING STG 2	CF6-80A	AR	18

Part Number	Part Description	Engine Type	Condition	Quantity
9272M22P05	SEGMENT - FAIRING STG 2	CF6-80A	AR	17
9272M22P05	SEGMENT - FAIRING STG 2	CF6-80A	AR	18
9272M22P05	SEGMENT - FAIRING STG 2	CF6-80A	AR	18
9272M22P06	SEGMENT - FAIRING STG 2	CF6-80A	AR	4
9272M22P06	SEGMENT - FAIRING STG 2	CF6-80A	AR	4
9272M22P06	SEGMENT - FAIRING STG 2	CF6-80A	AR	4
9272M22P06	SEGMENT - FAIRING STG 2	CF6-80A	AR	4
9272M22P06	SEGMENT - FAIRING STG 2	CF6-80A	OH	4
9272M22P06	SEGMENT - FAIRING STG 2	CF6-80A	AR	4
9272M22P06	SEGMENT - FAIRING STG 2	CF6-80A	AR	4
9272M22P08	SEGMENT - FAIRING STG 2	CF6-80A	AR	2
9272M22P10	SEGMENT - FAIRING STG 2	CF6-80A	AR	2
9272M22P10	SEGMENT - FAIRING STG 2	CF6-80A	AR	2
9272M22P10	SEGMENT - FAIRING STG 2	CF6-80A	AR	2
9272M22P10	SEGMENT - FAIRING STG 2	CF6-80A	AR	2
9272M22P10	SEGMENT - FAIRING STG 2	CF6-80A	NS	1
9272M22P10	SEGMENT - FAIRING STG 2	CF6-80A	AR	2
9272M22P11	SEGMENT - FAIRING STG 2	CF6-80A	NE	5
9272M22P11	SEGMENT - FAIRING STG 2	CF6-80A	AR	18
9272M22P11	SEGMENT - FAIRING STG 2	CF6-80A	NE	2
9272M22P11	SEGMENT - FAIRING STG 2	CF6-80A	NE	6
9272M22P11	SEGMENT - FAIRING STG 2	CF6-80A	SV	18
9272M22P11	SEGMENT - FAIRING STG 2	CF6-80A	SV	18
9272M22P11	SEGMENT - FAIRING STG 2	CF6-80A	NE	4
9272M22P11	SEGMENT - FAIRING STG 2	CF6-80A	NE	1
9272M22P12	SEGMENT - FAIRING STG 2	CF6-80A	OH	2
9272M22P12	SEGMENT - FAIRING STG 2	CF6-80A	NS	2
9272M28P02	BUMPER - BEARING	CF6-80A	SV	1
9272M28P02	BUMPER - BEARING	CF6-80A	SV	1
9272M28P02	BUMPER - BEARING	CF6-80A	SV	1
9272M28P02	BUMPER - BEARING	CF6-80A	OH	1
9272M28P02	BUMPER - BEARING	CF6-80A	OH	1
9272M28P03	HPC ROTOR BUMBER BEARING	CF6-80C2	OH	1
9272M28P03	HPC ROTOR BUMBER BEARING	CF6-80C2	OH	1
9272M76G02	TUBE - COUPLING PRESSURE	CF6-80A	OH	1
9272M76G03A	TUBE - HPT PRESSURE	CF6-80A	REP	1
9272M76G07	HPT ROTOR PRESSURE TUBE CPLG NUT	CF6-80C2, CF6-80A	OH	1
9272M76G07	HPT ROTOR PRESSURE TUBE CPLG NUT	CF6-80C2, CF6-80A	OH	1
9272M83P01	RETAINER - SEAL	CF6-80A	NE	1
9272M83P01	RETAINER - SEAL	CF6-80A	NE	1
9272M83P02	RETAINER - SEAL	CF6-80A	NE	1
9272M84P02	RETAINER - SEAL	CF6-80A	NE	1

Part Number	Part Description	Engine Type	Condition	Quantity
9272M85P02	BRACKET - SEAL RETAINER	CF6-80A	NE	2
9273M60P02	CLOSURE	CF6-80A	AR	1
9273M61G02	#5R BEARING OUTER SPANNER NUT	CF6-80C2, CF6-80A	AR	1
9273M61G02	#5R BEARING OUTER SPANNER NUT	CF6-80C2, CF6-80A	AR	1
9273M61G02	#5R BEARING OUTER SPANNER NUT	CF6-80C2, CF6-80A	AR	1
9273M61G02	#5R BEARING OUTER SPANNER NUT	CF6-80C2, CF6-80A	OH	1
9273M61G02	#5R BEARING OUTER SPANNER NUT	CF6-80C2, CF6-80A	OH	1
9273M62P04	RING - PISTON BRG NO. 3	CF6-80C2, CF6-80A	NE	1
9273M62P04	RING - PISTON BRG NO. 3	CF6-80C2, CF6-80A	NE	1
9273M62P04	RING - PISTON BRG NO. 3	CF6-80C2, CF6-80A	NE	1
9273M62P04	RING - PISTON BRG NO. 3	CF6-80C2, CF6-80A	NE	1
9273M62P04	RING - PISTON BRG NO. 3	CF6-80C2, CF6-80A	NE	1
9273M62P04	RING - PISTON BRG NO. 3	CF6-80C2, CF6-80A	NE	1
9273M62P04	RING - PISTON BRG NO. 3	CF6-80C2, CF6-80A	NE	4
9273M66G01	MANIFOLD OIL - INLET BRG	CF6-80A	AR	1
9273M66G01	MANIFOLD OIL - INLET BRG	CF6-80A	AR	1
9273M66G01	MANIFOLD OIL - INLET BRG	CF6-80A	AR	1
9273M66G01	MANIFOLD OIL - INLET BRG	CF6-80A	AR	1
9273M66G01	MANIFOLD OIL - INLET BRG	CF6-80A	AR	1
9273M66G01	MANIFOLD OIL - INLET BRG	CF6-80A	AR	1
9273M69G01	MANIFOLD - OIL BRG 5	CF6-80A	OH	1
9273M73G05	COVER - WINDAGE FWD	CF6-80A	SV	1
9273M73G06	COVER - WINDAGE FWD	CF6-80A	AR	1
9273M73G06	COVER - WINDAGE FWD	CF6-80A	AR	1
9273M73G06	COVER - WINDAGE FWD	CF6-80A	OH	1
9273M73G06	COVER - WINDAGE FWD	CF6-80A	OH	1
9273M73G06	COVER - WINDAGE FWD	CF6-80A	AR	1
9273M73G07	COVER - WINDAGE FWD	CF6-80A	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9273M73G07	COVER - WINDAGE FWD	CF6-80A	OH	1
9273M73G07	COVER - WINDAGE FWD	CF6-80A	OH	1
9273M73G07	COVER - WINDAGE FWD	CF6-80A	OH	1
9273M73G07	COVER - WINDAGE FWD	CF6-80A	OH	1
9273M73G08	COVER - WINDAGE FWD	CF6-80A	AR	1
9273M73G08	COVER - WINDAGE FWD	CF6-80A	AR	1
9273M73G08	COVER - WINDAGE FWD	CF6-80A	AR	1
9273M73G08	COVER - WINDAGE FWD	CF6-80A	AR	1
9273M73G08	COVER - WINDAGE FWD	CF6-80A	AR	1
9273M73G10	COVER - WINDAGE FWD	CF6-80A	AR	1
9273M73G10	COVER - WINDAGE FWD	CF6-80A	OH	1
9273M73G10	COVER - WINDAGE FWD	CF6-80A	AR	1
9273M73G12	COVER - WINDAGE FWD	CF6-80A	AR	1
9273M73G13	COVER - WINDAGE FWD	CF6-80A	AR	1
9273M73G13	COVER - WINDAGE FWD	CF6-80A	AR	1
9273M73G13	COVER - WINDAGE FWD	CF6-80A	AR	1
9273M73G13	COVER - WINDAGE FWD	CF6-80A	AR	1
9273M73G13	COVER - WINDAGE FWD	CF6-80A	AR	1
9273M73G13	COVER - WINDAGE FWD	CF6-80A	AR	1
9273M73G15	COVER - WINDAGE FWD	CF6-80A	OH	1
9273M73G15	COVER - WINDAGE FWD	CF6-80A	AR	1
9273M73G16	COVER - WINDAGE FWD	CF6-80A	AR	1
9273M73G16	COVER - WINDAGE FWD	CF6-80A	AR	1
9273M75G01	BRACKET ASSY - AFT FAN	CF6-80A	AR	1
9273M75G01	BRACKET ASSY - AFT FAN	CF6-80A	AR	1
9273M80G01	BRACKET	CF6-80A	NS	1
9273M92P01	BLADE - FAN STG 2 (NARROW)	CF6-80A	AR	20
9273M92P01	BLADE - FAN STG 2 (NARROW)	CF6-80A	AR	1
9273M92P01	BLADE - FAN STG 2 (NARROW)	CF6-80A	AR	4
9273M92P01	BLADE - FAN STG 2 (NARROW)	CF6-80A	SV	7
9273M92P01	BLADE - FAN STG 2 (NARROW)	CF6-80A	AR	4
9273M92P01	BLADE - FAN STG 2 (NARROW)	CF6-80A	OH	2
9273M92P02	BLADE - FAN STG 2 (WIDE)	CF6-80A	OH	2
9273M92P02	BLADE - FAN STG 2 (WIDE)	CF6-80A	OH	1
9273M92P02	BLADE - FAN STG 2 (WIDE)	CF6-80A	OH	1
9273M92P02	BLADE - FAN STG 2 (WIDE)	CF6-80A	OH	2
9273M92P02	BLADE - FAN STG 2 (WIDE)	CF6-80A	OH	3
9273M92P03	BLADE - FAN STG 2 (LOCKING)	CF6-80A	AR	1
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	AR	24
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	AR	11

Part Number	Part Description	Engine Type	Condition	Quantity
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	SV	36
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	AR	28
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	AR	47
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	OH	2
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	AR	12
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	AR	7
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	AR	10
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	AR	24
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	AR	20
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	AR	23
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	OH	1
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	OH	4
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	NS	1
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	OH	1
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	OH	2
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	OH	2
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	OH	5
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	OH	3
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	OH	1
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	OH	20
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	SV	3
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	OH	2
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	OH	3
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	OH	21
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	OH	12
9273M92P05	BLADE - FAN STG 2 (NARROW)	CF6-80A	OH	15
9273M92P06	BLADE - FAN STG 2 (WIDE)	CF6-80A	OH	1
9273M92P06	BLADE - FAN STG 2 (WIDE)	CF6-80A	OH	1
9273M92P06	BLADE - FAN STG 2 (WIDE)	CF6-80A	OH	1
9273M92P06	BLADE - FAN STG 2 (WIDE)	CF6-80A	OH	2
9273M92P06	BLADE - FAN STG 2 (WIDE)	CF6-80A	OH	1
9273M92P06	BLADE - FAN STG 2 (WIDE)	CF6-80A	SV	24
9273M92P06	BLADE - FAN STG 2 (WIDE)	CF6-80A	OH	1
9273M92P06	BLADE - FAN STG 2 (WIDE)	CF6-80A	OH	2
9273M92P06	BLADE - FAN STG 2 (WIDE)	CF6-80A	OH	3
9273M92P06	BLADE - FAN STG 2 (WIDE)	CF6-80A	OH	1
9273M92P06	BLADE - FAN STG 2 (WIDE)	CF6-80A	OH	2
9273M92P06	BLADE - FAN STG 2 (WIDE)	CF6-80A	OH	4
9273M92P06	BLADE - FAN STG 2 (WIDE)	CF6-80A	OH	2
9273M92P06	BLADE - FAN STG 2 (WIDE)	CF6-80A	OH	1
9273M92P06	BLADE - FAN STG 2 (WIDE)	CF6-80A	OH	4
9273M92P06	BLADE - FAN STG 2 (WIDE)	CF6-80A	OH	3
9273M92P06	BLADE - FAN STG 2 (WIDE)	CF6-80A	OH	2
9273M92P06	BLADE - FAN STG 2 (WIDE)	CF6-80A	OH	8
9273M92P06	BLADE - FAN STG 2 (WIDE)	CF6-80A	OH	12
9273M92P06	BLADE - FAN STG 2 (WIDE)	CF6-80A	OH	4
9273M92P06	BLADE - FAN STG 2 (WIDE)	CF6-80A	OH	16
9273M92P06	BLADE - FAN STG 2 (WIDE)	CF6-80A	OH	4
9273M92P06	BLADE - FAN STG 2 (WIDE)	CF6-80A	NE	40
9273M92P06	BLADE - FAN STG 2 (WIDE)	CF6-80A	NE	3
9273M92P07	BLADE - FAN STG 2 (LOCKING)	CF6-80A	AR	1
9273M92P07	BLADE - FAN STG 2 (LOCKING)	CF6-80A	AR	2
9273M92P07	BLADE - FAN STG 2 (LOCKING)	CF6-80A	AR	2
9273M92P07	BLADE - FAN STG 2 (LOCKING)	CF6-80A	OH	2
9273M92P07	BLADE - FAN STG 2 (LOCKING)	CF6-80A	SV	2
9273M92P08	BLADE - FAN STG 2 (LOCKING)	CF6-80A	AR	2
9273M92P08	BLADE - FAN STG 2 (LOCKING)	CF6-80A	SV	2
9273M92P08	BLADE - FAN STG 2 (LOCKING)	CF6-80A	AR	2
9273M92P08	BLADE - FAN STG 2 (LOCKING)	CF6-80A	OH	1
9273M92P08	BLADE - FAN STG 2 (LOCKING)	CF6-80A	OH	2

Part Number	Part Description	Engine Type	Condition	Quantity
9273M92P08	BLADE - FAN STG 2 (LOCKING)	CF6-80A	OH	2
9273M92P08	BLADE - FAN STG 2 (LOCKING)	CF6-80A	OH	1
9273M92P08	BLADE - FAN STG 2 (LOCKING)	CF6-80A	SV	1
9273M92P08	BLADE - FAN STG 2 (LOCKING)	CF6-80A	OH	1
9273M93P05	BLADE - FAN STG 3 (NARROW)	CF6-80A	AR	5
9273M93P05	BLADE - FAN STG 3 (NARROW)	CF6-80A	AR	4
9273M93P05	BLADE - FAN STG 3 (NARROW)	CF6-80A	AR	24
9273M93P05	BLADE - FAN STG 3 (NARROW)	CF6-80A	AR	2
9273M93P05	BLADE - FAN STG 3 (NARROW)	CF6-80A	AR	3
9273M93P06	BLADE - FAN STG 3 (WIDE)	CF6-80A	AR	2
9273M93P06	BLADE - FAN STG 3 (WIDE)	CF6-80A	OH	5
9273M93P06	BLADE - FAN STG 3 (WIDE)	CF6-80A	AR	22
9273M93P06	BLADE - FAN STG 3 (WIDE)	CF6-80A	AR	11
9273M93P06	BLADE - FAN STG 3 (WIDE)	CF6-80A	AR	1
9273M93P07	BLADE - FAN STG 3 (LOCKING)	CF6-80A	AR	2
9273M93P07	BLADE - FAN STG 3 (LOCKING)	CF6-80A	AR	1
9273M93P07	BLADE - FAN STG 3 (LOCKING)	CF6-80A	AR	2
9273M93P08	BLADE - FAN STG 3 (LOCKING)	CF6-80A	AR	1
9273M93P08	BLADE - FAN STG 3 (LOCKING)	CF6-80A	AR	13
9273M93P08	BLADE - FAN STG 3 (LOCKING)	CF6-80A	AR	2
9273M93P09	BLADE - FAN STG 3 (NARROW)	CF6-80A	AR	12
9273M93P09	BLADE - FAN STG 3 (NARROW)	CF6-80A	AR	31
9273M93P09	BLADE - FAN STG 3 (NARROW)	CF6-80A	AR	11
9273M93P09	BLADE - FAN STG 3 (NARROW)	CF6-80A	AR	24
9273M93P09	BLADE - FAN STG 3 (NARROW)	CF6-80A	AR	36
9273M93P09	BLADE - FAN STG 3 (NARROW)	CF6-80A	OH	23
9273M93P09	BLADE - FAN STG 3 (NARROW)	CF6-80A	AR	6

Part Number	Part Description	Engine Type	Condition	Quantity
9273M93P09	BLADE - FAN STG 3 (NARROW)	CF6-80A	AR	31
9273M93P09	BLADE - FAN STG 3 (NARROW)	CF6-80A	AR	5
9273M93P09	BLADE - FAN STG 3 (NARROW)	CF6-80A	AR	4
9273M93P09	BLADE - FAN STG 3 (NARROW)	CF6-80A	OH	1
9273M93P09	BLADE - FAN STG 3 (NARROW)	CF6-80A	AR	4
9273M93P09	BLADE - FAN STG 3 (NARROW)	CF6-80A	AR	10
9273M93P09	BLADE - FAN STG 3 (NARROW)	CF6-80A	OH	20
9273M93P09	BLADE - FAN STG 3 (NARROW)	CF6-80A	AR	2
9273M93P09	BLADE - FAN STG 3 (NARROW)	CF6-80A	OH	1
9273M93P09	BLADE - FAN STG 3 (NARROW)	CF6-80A	OH	1
9273M93P09	BLADE - FAN STG 3 (NARROW)	CF6-80A	OH	20
9273M93P09	BLADE - FAN STG 3 (NARROW)	CF6-80A	OH	13
9273M93P09	BLADE - FAN STG 3 (NARROW)	CF6-80A	OH	2
9273M93P09	BLADE - FAN STG 3 (NARROW)	CF6-80A	OH	8
9273M93P10	BLADE - FAN STG 3 (WIDE)	CF6-80A	AR	31
9273M93P10	BLADE - FAN STG 3 (WIDE)	CF6-80A	SV	1
9273M93P10	BLADE - FAN STG 3 (WIDE)	CF6-80A	AR	24
9273M93P10	BLADE - FAN STG 3 (WIDE)	CF6-80A	AR	12
9273M93P10	BLADE - FAN STG 3 (WIDE)	CF6-80A	AR	10
9273M93P10	BLADE - FAN STG 3 (WIDE)	CF6-80A	AR	2
9273M93P10	BLADE - FAN STG 3 (WIDE)	CF6-80A	AR	7
9273M93P10	BLADE - FAN STG 3 (WIDE)	CF6-80A	SV	5
9273M93P10	BLADE - FAN STG 3 (WIDE)	CF6-80A	OH	4
9273M93P10	BLADE - FAN STG 3 (WIDE)	CF6-80A	OH	2
9273M93P10	BLADE - FAN STG 3 (WIDE)	CF6-80A	OH	1
9273M93P10	BLADE - FAN STG 3 (WIDE)	CF6-80A	OH	3
9273M93P10	BLADE - FAN STG 3 (WIDE)	CF6-80A	OH	2
9273M93P10	BLADE - FAN STG 3 (WIDE)	CF6-80A	OH	1
9273M93P11	BLADE - FAN STG 3 (LOCKING)	CF6-80A	AR	1
9273M93P11	BLADE - FAN STG 3 (LOCKING)	CF6-80A	AR	2
9273M93P11	BLADE - FAN STG 3 (LOCKING)	CF6-80A	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9273M93P11	BLADE - FAN STG 3 (LOCKING)	CF6-80A	OH	2
9273M93P11	BLADE - FAN STG 3 (LOCKING)	CF6-80A	AR	2
9273M93P12	BLADE - FAN STG 3 (LOCKING)	CF6-80A	AR	1
9273M93P12	BLADE - FAN STG 3 (LOCKING)	CF6-80A	AR	2
9273M93P12	BLADE - FAN STG 3 (LOCKING)	CF6-80A	AR	2
9273M93P12	BLADE - FAN STG 3 (LOCKING)	CF6-80A	SV	68
9273M93P12	BLADE - FAN STG 3 (LOCKING)	CF6-80A	AR	2
9273M93P12	BLADE - FAN STG 3 (LOCKING)	CF6-80A	AR	2
9273M94P05	BLADE - FAN STG 4 (NARROW)	CF6-80A	AR	6
9273M94P05	BLADE - FAN STG 4 (NARROW)	CF6-80A	AR	2
9273M94P05	BLADE - FAN STG 4 (NARROW)	CF6-80A	AR	3
9273M94P05	BLADE - FAN STG 4 (NARROW)	CF6-80A	AR	2
9273M94P06	BLADE - FAN STG 4 (WIDE)	CF6-80A	AR	1
9273M94P06	BLADE - FAN STG 4 (WIDE)	CF6-80A	AR	6
9273M94P06	BLADE - FAN STG 4 (WIDE)	CF6-80A	AR	2
9273M94P06	BLADE - FAN STG 4 (WIDE)	CF6-80A	AR	5
9273M94P06	BLADE - FAN STG 4 (WIDE)	CF6-80A	AR	1
9273M94P06	BLADE - FAN STG 4 (WIDE)	CF6-80A	AR	1
9273M94P06	BLADE - FAN STG 4 (WIDE)	CF6-80A	AR	1
9273M94P09	BLADE - FAN STG 4 (NARROW)	CF6-80A	AR	20
9273M94P09	BLADE - FAN STG 4 (NARROW)	CF6-80A	AR	30
9273M94P09	BLADE - FAN STG 4 (NARROW)	CF6-80A	AR	33
9273M94P09	BLADE - FAN STG 4 (NARROW)	CF6-80A	AR	36
9273M94P09	BLADE - FAN STG 4 (NARROW)	CF6-80A	AR	19
9273M94P09	BLADE - FAN STG 4 (NARROW)	CF6-80A	OH	22
9273M94P09	BLADE - FAN STG 4 (NARROW)	CF6-80A	AR	27
9273M94P09	BLADE - FAN STG 4 (NARROW)	CF6-80A	SV	30
9273M94P09	BLADE - FAN STG 4 (NARROW)	CF6-80A	AR	12

Part Number	Part Description	Engine Type	Condition	Quantity
9273M94P09	BLADE - FAN STG 4 (NARROW)	CF6-80A	AR	17
9273M94P09	BLADE - FAN STG 4 (NARROW)	CF6-80A	AR	5
9273M94P09	BLADE - FAN STG 4 (NARROW)	CF6-80A	AR	15
9273M94P09	BLADE - FAN STG 4 (NARROW)	CF6-80A	AR	7
9273M94P09	BLADE - FAN STG 4 (NARROW)	CF6-80A	SV	38
9273M94P09	BLADE - FAN STG 4 (NARROW)	CF6-80A	OH	5
9273M94P09	BLADE - FAN STG 4 (NARROW)	CF6-80A	AR	3
9273M94P09	BLADE - FAN STG 4 (NARROW)	CF6-80A	OH	6
9273M94P09	BLADE - FAN STG 4 (NARROW)	CF6-80A	OH	6
9273M94P09	BLADE - FAN STG 4 (NARROW)	CF6-80A	OH	5
9273M94P09	BLADE - FAN STG 4 (NARROW)	CF6-80A	OH	3
9273M94P09	BLADE - FAN STG 4 (NARROW)	CF6-80A	OH	4
9273M94P09	BLADE - FAN STG 4 (NARROW)	CF6-80A	OH	13
9273M94P10	BLADE - FAN STG 4 (WIDE)	CF6-80A	AR	43
9273M94P10	BLADE - FAN STG 4 (WIDE)	CF6-80A	AR	22
9273M94P11	BLADE - FAN STG 4 (LOCKING)	CF6-80A	AR	2
9273M94P11	BLADE - FAN STG 4 (LOCKING)	CF6-80A	AR	2
9273M94P11	BLADE - FAN STG 4 (LOCKING)	CF6-80A	AR	2
9273M94P11	BLADE - FAN STG 4 (LOCKING)	CF6-80A	AR	2
9273M94P11	BLADE - FAN STG 4 (LOCKING)	CF6-80A	OH	2
9273M94P11	BLADE - FAN STG 4 (LOCKING)	CF6-80A	AR	2
9273M94P11	BLADE - FAN STG 4 (LOCKING)	CF6-80A	AR	2
9273M94P11	BLADE - FAN STG 4 (LOCKING)	CF6-80A	OH	2
9273M94P12	BLADE - FAN STG 4 (LOCKING)	CF6-80A	AR	2
9273M94P12	BLADE - FAN STG 4 (LOCKING)	CF6-80A	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9273M94P12	BLADE - FAN STG 4 (LOCKING)	CF6-80A	AR	2
9273M94P12	BLADE - FAN STG 4 (LOCKING)	CF6-80A	AR	2
9273M94P12	BLADE - FAN STG 4 (LOCKING)	CF6-80A	AR	2
9273M94P12	BLADE - FAN STG 4 (LOCKING)	CF6-80A	AR	2
9273M94P12	BLADE - FAN STG 4 (LOCKING)	CF6-80A	OH	1
9273M94P12	BLADE - FAN STG 4 (LOCKING)	CF6-80A	OH	2
9274M62G04	RETAINER - SEAL	CF6-80A	SV	1
9280-18A6	PUMP - FUEL	CF6-80A	OH	1
9280M57P02	RETAINER	CF6-80A	NS	1
9280M71G01	TUBE - AIR COMPRESSOR	CF6-80A	AR	1
9280M71G01	TUBE - AIR COMPRESSOR	CF6-80A	AR	1
9281M10P04	ACCELEROMETER - EXTERNAL	CF6-80A	AR	1
9281M99G03	BRACKET	CF6-80A	AR	1
9281M99G03	BRACKET	CF6-80A	AR	1
9281M99G03	BRACKET	CF6-80A	NE	1
9281M99G03	BRACKET	CF6-80A	NE	1
9282M51G01	BRACKET	CF6-80A	NS	1
9282M99P02	FLANGE - TUBE	CF6-80C2	AR	1
9282M99P02	FLANGE - TUBE	CF6-80C2	SV	1
9282M99P02	FLANGE - TUBE	CF6-80C2	OH	1
9282M99P03	FLANGE - TUBE	CF6-80C2, CF6-80A	AR	1
9282M99P03	FLANGE - TUBE	CF6-80C2, CF6-80A	SV	1
9282M99P03	FLANGE - TUBE	CF6-80C2, CF6-80A	AR	1
9282M99P03	FLANGE - TUBE	CF6-80C2, CF6-80A	SV	1
9282M99P03	FLANGE - TUBE	CF6-80C2, CF6-80A	SV	1
9283M13P02	SEAL - STA AIR/OIL BRG NO. 5	CF6-80C2, CF6-80A	OH	1
9283M37G02	SEAL - STA AIR/OIL BRG NO. 5	CF6-80A	AR	1
9283M70G05	RETAINER - HPT STTR SHRD	CF6-80C2, CF6-80A	SV	4
9283M70G07	HPT NOZZLE STG 1 SHROUD RETAINER	CF6-80C2, CF6-80A	OH	7
9283M70G07	HPT NOZZLE STG 1 SHROUD RETAINER	CF6-80C2, CF6-80A	OH	7
9283M70G07	HPT NOZZLE STG 1 SHROUD RETAINER	CF6-80C2, CF6-80A	OH	10

Part Number	Part Description	Engine Type	Condition	Quantity
9283M70G07	HPT NOZZLE STG 1 SHROUD RETAINER	CF6-80C2, CF6-80A	OH	5
9283M70G07	HPT NOZZLE STG 1 SHROUD RETAINER	CF6-80C2, CF6-80A	OH	6
9283M70G07	HPT NOZZLE STG 1 SHROUD RETAINER	CF6-80C2, CF6-80A	OH	1
9283M70G07	HPT NOZZLE STG 1 SHROUD RETAINER	CF6-80C2, CF6-80A	OH	41
9283M92P01	PLUG - BUTTON	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NE	41
9283M92P01	PLUG - BUTTON	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NE	10
9283M92P01	PLUG - BUTTON	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NE	11
9283M92P01	PLUG - BUTTON	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NE	15
9283M92P01	PLUG - BUTTON	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NE	3
9283M92P01	PLUG - BUTTON	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NE	14
9283M92P01	PLUG - BUTTON	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NE	31
9283M92P01	PLUG - BUTTON	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NS	23
9283M92P01	PLUG - BUTTON	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NS	21
9283M92P01	PLUG - BUTTON	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NS	3
9284M16G02	MANIFOLD - AIR	CF6-80A	AR	1
9284M17P001A	SHIELD - SPRAY	CF6-80A	NS	1
9284M19G03	SHIELD - SPRAY	CF6-80A	NE	1
9284M20P001A	SHIELD	CF6-80A	NE	1
9284M22P03	SHIELD - SPRAY	CF6-80A	AR	2
9284M22P03	SHIELD - SPRAY	CF6-80A	NS	2
9285M33G01	MANIFOLD FUEL - HEAD END	CF6-80A	AR	1
9285M33G01	MANIFOLD FUEL - HEAD END	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9285M33G01	MANIFOLD FUEL - HEAD END	CF6-80A	AR	1
9285M33G01	MANIFOLD FUEL - HEAD END	CF6-80A	AR	1
9285M33G01	MANIFOLD FUEL - HEAD END	CF6-80A	AR	1
9285M33G01	MANIFOLD FUEL - HEAD END	CF6-80A	AR	1
9285M39P10	HOSE	CF6-80C2	AR	1
9285M39P10	HOSE	CF6-80C2	AR	1
9285M39P10	HOSE	CF6-80C2	AR	1
9285M39P11	HOSE - OIL	CF6-80C2, CF6-80A	OH	1
9285M39P11	HOSE - OIL	CF6-80C2, CF6-80A	AR	1
9285M39P11	HOSE - OIL	CF6-80C2, CF6-80A	AR	1
9285M39P11	HOSE - OIL	CF6-80C2, CF6-80A	AR	1
9285M39P11	HOSE - OIL	CF6-80C2, CF6-80A	AR	1
9285M40P01	HOSE - OIL TANK	CF6-80A	AR	1
9285M40P02	TUBE - HOSE SUPPLY	CF6-80A	AR	1
9285M40P02	TUBE - HOSE SUPPLY	CF6-80A	AR	1
9285M68G01	TUBE - AIR	CF6-80A	AR	1
9285M70G02	TUBE - AIR STG 10	CF6-80A	AR	1
9285M70G02	TUBE - AIR STG 10	CF6-80A	AR	1
9285M94G01	TUBE - AIR HPT COOLING	CF6-80A	AR	1
9285M94G01	TUBE - AIR HPT COOLING	CF6-80A	AR	1
9285M94G01	TUBE - AIR HPT COOLING	CF6-80A	AR	1
9285M94G01	TUBE - AIR HPT COOLING	CF6-80A	AR	1
9285M96G01	TUBE - AIR HPT COOLING	CF6-80A	AR	1
9285M96G01	TUBE - AIR HPT COOLING	CF6-80A	AR	1
9285M96G01	TUBE - AIR HPT COOLING	CF6-80A	AR	1
9285M96G01	TUBE - AIR HPT COOLING	CF6-80A	AR	1
9285M96G01	TUBE - AIR HPT COOLING	CF6-80A	OH	1
9285M98G01	TUBE - AIR HPT COOLING	CF6-80A	AR	1
9285M98G01	TUBE - AIR HPT COOLING	CF6-80A	AR	1
9285M98G01	TUBE - AIR HPT COOLING	CF6-80A	AR	1
9285M98G01	TUBE - AIR HPT COOLING	CF6-80A	AR	1
9285M98G01	TUBE - AIR HPT COOLING	CF6-80A	AR	1
9285M98G01	TUBE - AIR HPT COOLING	CF6-80A	OH	1
9285M98G01	TUBE - AIR HPT COOLING	CF6-80A	OH	1
9288M10G01	TUBE - AIR HPT SUPPLY	CF6-80A	AR	1
9288M10G01	TUBE - AIR HPT SUPPLY	CF6-80A	AR	1
9288M10G01	TUBE - AIR HPT SUPPLY	CF6-80A	OH	1
9288M10G01	TUBE - AIR HPT SUPPLY	CF6-80A	AR	1
9288M10G01	TUBE - AIR HPT SUPPLY	CF6-80A	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
9291M60P01	JOINT - FLEX	CF6-80A	NE	1
9291M72G02	TUBE - OIL	CF6-80A	AR	1
9291M72G02	TUBE - OIL	CF6-80A	AR	1
9291M72G02	TUBE - OIL	CF6-80A	AR	1
9291M72G02	TUBE - OIL	CF6-80A	SV	1
9291M87G01	BRACKET	CF6-80A	AR	1
9292M39G01	TUBE	CF6-80A	OH	1
9292M39G01	TUBE	CF6-80A	AR	1
9292M39G01	TUBE	CF6-80A	OH	1
9292M39G01	TUBE	CF6-80A	SV	1
9292M48G09	BRACKET	CF6-80A	AR	1
9292M48G09	BRACKET	CF6-80A	AR	1
9292M68G02	TUBE - AIR PS3 TO	CF6-80A	AR	1
9292M68G02	TUBE - AIR PS3 TO	CF6-80A	AR	1
9292M68G02	TUBE - AIR PS3 TO	CF6-80A	AR	1
9292M75G01	MANIFOLD - AIR	CF6-80A	SV	1
9292M75G01	MANIFOLD - AIR	CF6-80A	AR	1
9292M75G01	MANIFOLD - AIR	CF6-80A	AR	1
9292M94G01	TUBE - OIL B SUMP SUPPLY	CF6-80A	AR	1
9292M94G01	TUBE - OIL B SUMP SUPPLY	CF6-80A	AR	1
9292M94G01	TUBE - OIL B SUMP SUPPLY	CF6-80A	AR	1
9293M58G01	TUBE - COMBUSTOR FUEL	CF6-80A	AR	1
9293M58G01	TUBE - COMBUSTOR FUEL	CF6-80A	AR	1
9293M68P01	SEAL - RING	CF6-80A	NE	1
9293M71G01	BRACKET - STG 5 B SUMP VENT	CF6-80A	AR	1
9293M71G01	BRACKET - STG 5 B SUMP VENT	CF6-80A	SV	2
9293M71G01	BRACKET - STG 5 B SUMP VENT	CF6-80A	SV	1
9293M74G01	BRACKET - TRAY RS	CF6-50	SV	1
9293M82G04	TUBE - AIR HPT	CF6-80A	AR	1
9293M82G04	TUBE - AIR HPT	CF6-80A	AR	1
9293M87P01	SHIELD - SPRAY	CF6-80A	NS	1
9293M87P01	SHIELD - SPRAY	CF6-80A	NS	1
9293M88P01	SHIELD - SPRAY	CF6-80A	NE	1
9293M88P01	SHIELD - SPRAY	CF6-80A	NS	1
9293M88P01	SHIELD - SPRAY	CF6-80A	NS	2
9294M10P001A	BRACKET - F/D	CF6-50 (LMCO)	AR	1
9294M11G01	BRACKET - TRAY LS	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9294M22P01	BRACKET	CF6-80A	AR	7
9294M22P02	BRACKET - FLANGE	CF6-80A	AR	1
9294M23P01	BRACKET - FLANGE	CF6-80A	AR	4
9294M23P01	BRACKET - FLANGE	CF6-80A	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
9294M23P01	BRACKET - FLANGE	CF6-80A	OH	5
9294M48G02	TUBE - AIR HPT	CF6-80A	AR	1
9294M48G04	TUBE - AIR HPT	CF6-80A	AR	1
9294M85G01	MANIFOLD	CF6-80A	AR	1
9294M85G01	MANIFOLD	CF6-80A	AR	1
9294M86G01	MANIFOLD	CF6-80A	AR	1
9294M86G01	MANIFOLD	CF6-80A	AR	1
9294M97G03	BRACKET - CABLE	CF6-50 (LMCO)	AR	1
9294M97G03	BRACKET - CABLE	CF6-50 (LMCO)	SV	1
9294M97G03	BRACKET - CABLE	CF6-50 (LMCO)	NS	1
9294M97G03	BRACKET - CABLE	CF6-50 (LMCO)	AR	1
9294M97G03	BRACKET - CABLE	CF6-50 (LMCO)	AR	1
9294M97G03	BRACKET - CABLE	CF6-50 (LMCO)	SV	1
9294M97G05	BRACKET - CABLE	CF6-50 (LMCO)	SV	1
9295M10G02	TUBE - SCAV SUMP CRF	CF6-80C2, CF6-80A	AR	1
9295M10G02	TUBE - SCAV SUMP CRF	CF6-80C2, CF6-80A	AR	1
9295M10G02	TUBE - SCAV SUMP CRF	CF6-80C2, CF6-80A	AR	1
9295M10G02	TUBE - SCAV SUMP CRF	CF6-80C2, CF6-80A	AR	1
9295M10G02	TUBE - SCAV SUMP CRF	CF6-80C2, CF6-80A	AR	1
9295M10G02	TUBE - SCAV SUMP CRF	CF6-80C2, CF6-80A	SV	1
9295M10G02	TUBE - SCAV SUMP CRF	CF6-80C2, CF6-80A	SV	1
9295M20G02	ADAPTER - COMPR	CF6-80A	AR	1
9295M20G02	ADAPTER - COMPR	CF6-80A	AR	1
9295M22P01	SEAL - STG 3	CF6-80A	SV	1
9295M22P01	SEAL - STG 3	CF6-80A	SV	1
9295M22P01	SEAL - STG 3	CF6-80A	SV	1
9295M22P01	SEAL - STG 3	CF6-80A	AR	1
9295M22P01	SEAL - STG 3	CF6-80A	AR	1
9295M22P01	SEAL - STG 3	CF6-80A	OH	1
9295M23P01	SEAL - STG 4	CF6-80A	AR	1
9295M23P01	SEAL - STG 4	CF6-80A	AR	1
9295M23P01	SEAL - STG 4	CF6-80A	SV	1
9295M23P01	SEAL - STG 4	CF6-80A	SV	1
9295M23P01	SEAL - STG 4	CF6-80A	OH	1
9295M25G07	MANIFOLD - COOLING LPT	CF6-80A	OH	1
9295M25G07	MANIFOLD - COOLING LPT	CF6-80A	OH	1
9295M25G08	MANIFOLD - COOLING LPT	CF6-80A	OH	1
9295M29G01	SUPPORT - SHROUD HPT STATOR	CF6-80A	AR	2
9295M29G01	SUPPORT - SHROUD HPT STATOR	CF6-80A	AR	6

Part Number	Part Description	Engine Type	Condition	Quantity
9295M30G05	HPC STATOR ACT RING SEGMT STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9295M30G05	HPC STATOR ACT RING SEGMT STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9295M30G05	HPC STATOR ACT RING SEGMT STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9295M30G05	HPC STATOR ACT RING SEGMT STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9295M30G05	HPC STATOR ACT RING SEGMT STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9295M30G05	HPC STATOR ACT RING SEGMT STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9295M30G05	HPC STATOR ACT RING SEGMT STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9295M30G05	HPC STATOR ACT RING SEGMT STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9295M30G06	HPC STATOR ACT RING SEGMT STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9295M30G06	HPC STATOR ACT RING SEGMT STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9295M30G06	HPC STATOR ACT RING SEGMT STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9295M30G06	HPC STATOR ACT RING SEGMT STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9295M30G06	HPC STATOR ACT RING SEGMT STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9295M30G06	HPC STATOR ACT RING SEGMT STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9295M30G06	HPC STATOR ACT RING SEGMT STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9295M30G06	HPC STATOR ACT RING SEGMT STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9295M30G06	HPC STATOR ACT RING SEGMT STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9295M30G06	HPC STATOR ACT RING SEGMT STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9295M30G06	HPC STATOR ACT RING SEGMT STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9295M30G06	HPC STATOR ACT RING SEGMT STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9295M30G06	HPC STATOR ACT RING SEGMT STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9295M30G06	HPC STATOR ACT RING SEGMT STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9295M30G06	HPC STATOR ACT RING SEGMT STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9295M30G06	HPC STATOR ACT RING SEGMT STG 4	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

[illegible]

Part Number	Part Description	Engine Type	Condition	Quantity
9295M45G07	SEAL - STG 2	CF6-80A	OH	1
9295M46G05	SEAL - STG 3	CF6-80A	SV	2
9295M46G05	SEAL - STG 3	CF6-80A	SV	1
9295M46G05	SEAL - STG 3	CF6-80A	SV	2
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	OH	1
9295M46G07	SEAL - STG 3	CF6-80A	OH	1
9295M46G07	SEAL - STG 3	CF6-80A	OH	1
9295M46G07	SEAL - STG 3	CF6-80A	OH	1
9295M46G07	SEAL - STG 3	CF6-80A	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9295M46G07	SEAL - STG 3	CF6-80A	OH	1
9295M46G07	SEAL - STG 3	CF6-80A	OH	1
9295M46G07	SEAL - STG 3	CF6-80A	OH	1
9295M46G07	SEAL - STG 3	CF6-80A	OH	1
9295M46G07	SEAL - STG 3	CF6-80A	OH	1
9295M46G07	SEAL - STG 3	CF6-80A	OH	1
9295M46G07	SEAL - STG 3	CF6-80A	OH	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	OH	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M46G07	SEAL - STG 3	CF6-80A	AR	1
9295M47G05	SEAL - STG 4	CF6-80A	SV	6
9295M47G05	SEAL - STG 4	CF6-80A	SV	1
9295M47G09	SEAL - STG 4	CF6-80A	AR	1
9295M47G09	SEAL - STG 4	CF6-80A	AR	1
9295M47G09	SEAL - STG 4	CF6-80A	AR	1
9295M47G09	SEAL - STG 4	CF6-80A	AR	1
9295M47G09	SEAL - STG 4	CF6-80A	AR	1
9295M47G09	SEAL - STG 4	CF6-80A	AR	1
9295M47G09	SEAL - STG 4	CF6-80A	AR	1
9295M47G09	SEAL - STG 4	CF6-80A	AR	1
9295M47G09	SEAL - STG 4	CF6-80A	AR	1
9295M47G09	SEAL - STG 4	CF6-80A	OH	1
9295M47G09	SEAL - STG 4	CF6-80A	OH	1
9295M47G09	SEAL - STG 4	CF6-80A	OH	1
9295M47G09	SEAL - STG 4	CF6-80A	OH	1
9295M47G09	SEAL - STG 4	CF6-80A	OH	1
9295M47G09	SEAL - STG 4	CF6-80A	OH	1
9295M47G09	SEAL - STG 4	CF6-80A	OH	1
9295M47G09	SEAL - STG 4	CF6-80A	OH	1
9295M47G10	SEAL - STG 4	CF6-80A	AR	1
9295M47G10	SEAL - STG 4	CF6-80A	AR	1
9295M47G10	SEAL - STG 4	CF6-80A	AR	1
9295M47G10	SEAL - STG 4	CF6-80A	AR	1
9295M47G10	SEAL - STG 4	CF6-80A	AR	1
9295M47G10	SEAL - STG 4	CF6-80A	AR	1
9295M47G10	SEAL - STG 4	CF6-80A	AR	1
9295M47G10	SEAL - STG 4	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9295M47G10	SEAL - STG 4	CF6-80A	OH	1
9295M47G10	SEAL - STG 4	CF6-80A	OH	1
9295M47G10	SEAL - STG 4	CF6-80A	OH	1
9295M47G10	SEAL - STG 4	CF6-80A	OH	1
9295M47G10	SEAL - STG 4	CF6-80A	OH	1
9295M47G10	SEAL - STG 4	CF6-80A	OH	1
9295M47G10	SEAL - STG 4	CF6-80A	OH	1
9295M47G10	SEAL - STG 4	CF6-80A	OH	1
9295M47G10	SEAL - STG 4	CF6-80A	OH	1
9295M47G10	SEAL - STG 4	CF6-80A	OH	1
9295M47G10	SEAL - STG 4	CF6-80A	OH	1
9295M47G10	SEAL - STG 4	CF6-80A	OH	1
9295M47G10	SEAL - STG 4	CF6-80A	OH	1
9295M47G10	SEAL - STG 4	CF6-80A	OH	1
9295M47G10	SEAL - STG 4	CF6-80A	OH	1
9295M47G10	SEAL - STG 4	CF6-80A	OH	1
9295M47G10	SEAL - STG 4	CF6-80A	OH	1
9295M49P05	RETAINER	CF6-80A	SV	3
9295M49P05	RETAINER	CF6-80A	OH	1
9295M78G03	MOUNT ASSY - FWD ENGINE	CF6-50 (LMCO)	AR	1
9295M79G01	MOUNT - ENGINE FWD	CF6-80A	AR	1
9295M79G01	MOUNT - ENGINE FWD	CF6-80A	AR	1
9295M79G02	MOUNT - ENGINE FWD	CF6-80A	AR	1
9295M96G05	SHROUD - STG 1	CF6-80A	OH	1
9295M98G02	SHROUD - STG 3	CF6-80A	AR	24
9295M99G02	SHROUD - STG 4	CF6-80A	OH	2
9295M99G02	SHROUD - STG 4	CF6-80A	OH	9
9295M99G02	SHROUD - STG 4	CF6-80A	OH	8
9295M99G02	SHROUD - STG 4	CF6-80A	OH	21
9295M99G02	SHROUD - STG 4	CF6-80A	OH	1
9295M99G02	SHROUD - STG 4	CF6-80A	OH	6
9297M11P001A	BRACKET	CF6-50 (Boeing)	NS	1
9297M11P001A	BRACKET	CF6-50 (Boeing)	NS	1
9297M16G03	BRACKET - STG 6	CF6-80A	AR	1
9297M16G03	BRACKET - STG 6	CF6-80A	AR	1
9297M16G03	BRACKET - STG 6	CF6-80A	AR	1
9297M16G03	BRACKET - STG 6	CF6-80A	NS	1
9297M29G02	TUBE - FUEL VBV HEAD END	CF6-80A	OH	1
9297M29G02	TUBE - FUEL VBV HEAD END	CF6-80A	AR	1
9297M29G02	TUBE - FUEL VBV HEAD END	CF6-80A	OH	1
9297M31G02	TUBE - VSV ROD END	CF6-80A	AR	1
9297M31G02	TUBE - VSV ROD END	CF6-80A	OH	1
9297M31G02	TUBE - VSV ROD END	CF6-80A	SV	1
9297M31G02	TUBE - VSV ROD END	CF6-80A	SV	1
9297M44G01	MANIFOLD - CIT SENSOR	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9297M44G01	MANIFOLD - CIT SENSOR	CF6-80A	AR	1
9297M44G01	MANIFOLD - CIT SENSOR	CF6-80A	AR	1
9297M44G01	MANIFOLD - CIT SENSOR	CF6-80A	AR	1
9297M44G01	MANIFOLD - CIT SENSOR	CF6-80A	SV	1
9297M44G01	MANIFOLD - CIT SENSOR	CF6-80A	OH	1
9297M44G01	MANIFOLD - CIT SENSOR	CF6-80A	SV	1
9297M48G02	BRACKET	CF6-80A	AR	1
9297M63G01	TUBE - OIL VENT	CF6-80A	AR	1
9297M63G01	TUBE - OIL VENT	CF6-80A	AR	1
9297M70P001A	BRACKET	CF6-80A	OH	1
9297M70P001A	BRACKET	CF6-80A	AR	1
9297M85P001B	BRACKET	CF6-80A	NS	1
9297M86G01	MANIFOLD - SHROUDED FUEL L/S	CF6-80A	OH	1
9297M86G05	MANIFOLD - SHROUDED FUEL L/S	CF6-80A	AR	1
9297M86G05	MANIFOLD - SHROUDED FUEL L/S	CF6-80A	AR	1
9297M86G05	MANIFOLD - SHROUDED FUEL L/S	CF6-80A	AR	1
9297M86G05	MANIFOLD - SHROUDED FUEL L/S	CF6-80A	OH	1
9297M86G05	MANIFOLD - SHROUDED FUEL L/S	CF6-80A	OH	1
9297M86G05	MANIFOLD - SHROUDED FUEL L/S	CF6-80A	AR	1
9297M86G06	MANIFOLD - SHROUDED FUEL R/S	CF6-80A	AR	1
9297M86G06	MANIFOLD - SHROUDED FUEL R/S	CF6-80A	AR	1
9297M86G06	MANIFOLD - SHROUDED FUEL R/S	CF6-80A	SV	1
9297M86G06	MANIFOLD - SHROUDED FUEL R/S	CF6-80A	OH	1
9297M86G06	MANIFOLD - SHROUDED FUEL R/S	CF6-80A	OH	1
9297M86G06	MANIFOLD - SHROUDED FUEL R/S	CF6-80A	OH	1
9297M94G01	RETAINER - HALF	CF6-80A	AR	2
9298M12G05	ELBOW - SHROUDED	CF6-80A	AR	1
9298M12G05	ELBOW - SHROUDED	CF6-80A	AR	1
9298M12G05	ELBOW - SHROUDED	CF6-80A	AR	1
9298M12G05	ELBOW - SHROUDED	CF6-80A	AR	1
9298M12G05	ELBOW - SHROUDED	CF6-80A	AR	1
9298M12G05	ELBOW - SHROUDED	CF6-80A	AR	1
9298M12G05	ELBOW - SHROUDED	CF6-80A	AR	1
9298M12G06	ELBOW - SHROUDED	CF6-80A	AR	1
9298M12G06	ELBOW - SHROUDED	CF6-80A	AR	1
9298M12G06	ELBOW - SHROUDED	CF6-80A	AR	1
9298M12G06	ELBOW - SHROUDED	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9298M18G02	TUBE - OIL B SCAV AFT SEG	CF6-80A	OH	1
9298M18G02	TUBE - OIL B SCAV AFT SEG	CF6-80A	OH	1
9298M21G04	BIFURCATION - LOWER	CF6-80A	AR	1
9298M21G04	BIFURCATION - LOWER	CF6-80A	AR	1
9298M21G04	BIFURCATION - LOWER	CF6-80A	AR	1
9298M28G01	TUBE - OIL SUPPLY MID	CF6-80A	AR	1
9298M53G01	TUBE - FUEL PUMP OUTLET	CF6-80A	AR	1
9298M53G01	TUBE - FUEL PUMP OUTLET	CF6-80A	AR	1
9298M55G01	TUBE - HEAT FUEL	CF6-80A	AR	1
9298M55G01	TUBE - HEAT FUEL	CF6-80A	AR	1
9298M57G02	TUBE - INLET FLOWMETER	CF6-80A	AR	1
9298M57G02	TUBE - INLET FLOWMETER	CF6-80A	AR	1
9298M59G02	TUBE - FLOWMETER OUTLET	CF6-80A	AR	1
9298M59G02	TUBE - FLOWMETER OUTLET	CF6-80A	AR	1
9298M64G01	TUBE - OIL B SUMP SUPPLY	CF6-80A	AR	1
9298M64G01	TUBE - OIL B SUMP SUPPLY	CF6-80A	OH	1
9298M68G01	TUBE - OIL	CF6-80A	AR	1
9298M73P001B	BRACKET	CF6-80A	NS	1
9298M75G05	MANIFOLD - FUEL	CF6-80A	AR	1
9298M75G05	MANIFOLD - FUEL	CF6-80A	AR	1
9298M84P04	SHIELD - SPRAY	CF6-80A	NS	1
9298M84P04	SHIELD - SPRAY	CF6-80A	NS	1
9298M84P04	SHIELD - SPRAY	CF6-80A	NS	1
9298M85G01	TUBE - OIL B SUMP	CF6-80A	AR	1
9298M85G01	TUBE - OIL B SUMP	CF6-80A	AR	1
9298M97G01	RETAINER - HALF	CF6-80A	AR	1
9298M97G01	RETAINER - HALF	CF6-80A	NE	1
9299M23G01	TUBE - AIR HPR	CF6-80A	AR	2
9299M23G03	TUBE - AIR HPR	CF6-80A	AR	3
9299M23G04	TUBE - AIR HPR	CF6-80A	AR	3
9299M23G05	TUBE - AIR HPR	CF6-80A	SV	1
9299M23G05	TUBE - AIR HPR	CF6-80A	SV	1
9299M23G05	TUBE - AIR HPR	CF6-80A	OH	1
9299M23G05	TUBE - AIR HPR	CF6-80A	OH	1
9299M23G06	TUBE - AIR HPR	CF6-80A	SV	1
9299M23G08	TUBE - AIR HPR	CF6-80A	OH	2
9299M30G12	BLADE ASSY - HPTR STG 1	CF6-50 (LMCO)	AR	1
9299M30G12	BLADE ASSY - HPTR STG 1	CF6-50 (LMCO)	AR	1
9299M30G12	BLADE ASSY - HPTR STG 1	CF6-50 (LMCO)	AR	1
9299M30G12	BLADE ASSY - HPTR STG 1	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9299M30G12	BLADE ASSY - HPTR STG 1	CF6-50 (LMCO)	AR	1
9299M30G12	BLADE ASSY - HPTR STG 1	CF6-50 (LMCO)	AR	1
9299M45P02	DUCT - VENT	CF6-80A	OH	1
9299M45P02	DUCT - VENT	CF6-80A	OH	1
9299M45P04	DUCT - VENT	CF6-80A	AR	1
9299M45P04	DUCT - VENT	CF6-80A	OH	1
9299M49G02	TUBE - OIL IN SUMP	CF6-80A	OH	1
9299M55G03	LUG - LKG STG 3	CF6-80A	AR	2
9299M58P02	CLOSURE - SUMP BRG 5R	CF6-80C2, CF6-80A	AR	1
9299M58P02	CLOSURE - SUMP BRG 5R	CF6-80C2, CF6-80A	OH	1
9299M58P02	CLOSURE - SUMP BRG 5R	CF6-80C2, CF6-80A	OH	1
9299M59P01	SEAL - STAT OIL BRG 4R/5R	CF6-80A	SV	1
9299M59P01	SEAL - STAT OIL BRG 4R/5R	CF6-80A	SV	1
9299M59P01	SEAL - STAT OIL BRG 4R/5R	CF6-80A	OH	1
9299M59P01	SEAL - STAT OIL BRG 4R/5R	CF6-80A	OH	1
9299M60G05	LINER ASSY - OUTLET	CF6-80A	AR	4
9299M60G05	LINER ASSY - OUTLET	CF6-80A	AR	3
9299M60G05	LINER ASSY - OUTLET	CF6-80A	OH	4
9299M60G05	LINER ASSY - OUTLET	CF6-80A	AR	4
9299M60G06	LINER ASSY - OGV	CF6-80C2, CF6-80A	AR	4
9299M60G06	LINER ASSY - OGV	CF6-80C2, CF6-80A	NS	3
9299M60G07	LINER ASSY - OGV	CF6-80C2, CF6-80A	OH	4
9299M60G07	LINER ASSY - OGV	CF6-80C2, CF6-80A	OH	3
9299M60G07	LINER ASSY - OGV	CF6-80C2, CF6-80A	OH	1
9299M60G07	LINER ASSY - OGV	CF6-80C2, CF6-80A	OH	1
9299M60G07	LINER ASSY - OGV	CF6-80C2, CF6-80A	OH	3
9299M60G07	LINER ASSY - OGV	CF6-80C2, CF6-80A	OH	4
9299M60G07	LINER ASSY - OGV	CF6-80C2, CF6-80A	OH	4
9299M60G07	LINER ASSY - OGV	CF6-80C2, CF6-80A	OH	1
9299M60G07	LINER ASSY - OGV	CF6-80C2, CF6-80A	OH	1
9299M60G07	LINER ASSY - OGV	CF6-80C2, CF6-80A	OH	2
9299M66G01	GEARBOX - MOUNT RIGHT	CF6-80A	AR	1
9299M71G01	HOUSING - SUMP	CF6-80A	OH	1
9299M71G01	HOUSING - SUMP	CF6-80A	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9299M76P04	RING - DAMPENING	CF6-80A	OH	1
9299M88G01	TUBE - OIL IN COMP REAR FR	CF6-80A	NS	1
9299M88G01	TUBE - OIL IN COMP REAR FR	CF6-80A	NE	1
9299M88G01	TUBE - OIL IN COMP REAR FR	CF6-80A	NE	3
9299M90P01	WINDAGE - INNER COVER	CF6-80A	OH	11
9299M91P01	KEY - CPRSR STTR CASING	CF6-80A	AR	6
9299M96G07	PLUG ASSY - BORESCOPE STG 1	CF6-80C2	NS	3
9299M96G07	PLUG ASSY - BORESCOPE STG 1	CF6-80C2	NS	3
9299M96G07	PLUG ASSY - BORESCOPE STG 1	CF6-80C2	SV	1
9299M99P02	KEY - CASING (SPD)	CF6-80C2, CF6-80A	NE	3
9303M44G02	FUEL - HEAD END TUBE HOSE	CF6-80A	SV	1
9303M44G02	FUEL - HEAD END TUBE HOSE	CF6-80A	OH	1
9303M48G01	FUEL - HEAD END TUBE HOSE	CF6-80A	OH	1
9303M50G01	MANIFOLD FUEL - ROD END VBV	CF6-80A	OH	1
9303M56G01	BRACKET ASSY - MANF HNGD	CF6-50	NE	1
9303M56G01	BRACKET ASSY - MANF HNGD	CF6-50	AR	1
9303M56G01	BRACKET ASSY - MANF HNGD	CF6-50	OH	2
9303M56G01	BRACKET ASSY - MANF HNGD	CF6-50	NE	3
9303M56G01	BRACKET ASSY - MANF HNGD	CF6-50	NE	3
9303M57G01	BRACKET ASSY - MANF HNGD	CF6-50 (LMCO)	AR	4
9303M57G01	BRACKET ASSY - MANF HNGD	CF6-50 (LMCO)	AR	3
9303M57G01	BRACKET ASSY - MANF HNGD	CF6-50 (LMCO)	NE	2
9303M57G01	BRACKET ASSY - MANF HNGD	CF6-50 (LMCO)	NE	1
9303M65P01	SENSOR - FAN SPEED	CF6-50	AR	1
9303M65P01	SENSOR - FAN SPEED	CF6-50	AR	1
9303M85G01	BRACKET	CF6-50	NS	1
9303M85G02	BRACKET	CF6-50 (Boeing)	NS	1
9303M86G01	BRACKET	CF6-50	AR	1
9303M86G01	BRACKET	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9304M12P01	BRACKET - FLANGE	CF6-80A	AR	1
9304M12P01	BRACKET - FLANGE	CF6-80A	SV	12
9304M12P01	BRACKET - FLANGE	CF6-80A	OH	12
9304M12P01	BRACKET - FLANGE	CF6-80A	SV	1
9304M13P01	BRACKET - FLANGE	CF6-80A	AR	1
9304M13P02	BRACKET - FLANGE	CF6-80A	AR	1
9304M13P03	BRACKET - FLANGE	CF6-80A	AR	1
9304M13P03	BRACKET - FLANGE	CF6-80A	AR	15
9304M13P03	BRACKET - FLANGE	CF6-80A	OH	13
9304M13P03	BRACKET - FLANGE	CF6-80A	SV	6
9304M26P03	SEAL - CARBON	CF6-80A	AR	1
9304M26P04	SEAL	CF6-80A	NE	6
9304M62G02	BRACKET - CLEVIS STG 1	CF6-80A	SV	1
9304M93G01	ELBOW - AIR-HPT RECOUP	CF6-80A	AR	1
9304M93G01	ELBOW - AIR-HPT RECOUP	CF6-80A	AR	1
9304M93G02	ELBOW - AIR HPT RECOUP	CF6-80C2, CF6-80A	SV	1
9304M93G02	ELBOW - AIR HPT RECOUP	CF6-80C2, CF6-80A	AR	1
9304M93G02	ELBOW - AIR HPT RECOUP	CF6-80C2, CF6-80A	AR	1
9304M93G02	ELBOW - AIR HPT RECOUP	CF6-80C2, CF6-80A	AR	1
9304M93G02	ELBOW - AIR HPT RECOUP	CF6-80C2, CF6-80A	AR	1
9304M93G02	ELBOW - AIR HPT RECOUP	CF6-80C2, CF6-80A	AR	1
9304M93G02	ELBOW - AIR HPT RECOUP	CF6-80C2, CF6-80A	SV	1
9304M93G02	ELBOW - AIR HPT RECOUP	CF6-80C2, CF6-80A	SV	1
9304M93G02	ELBOW - AIR HPT RECOUP	CF6-80C2, CF6-80A	AR	1
9304M93G02	ELBOW - AIR HPT RECOUP	CF6-80C2, CF6-80A	AR	1
9304M93G02	ELBOW - AIR HPT RECOUP	CF6-80C2, CF6-80A	AR	1
9304M93G02	ELBOW - AIR HPT RECOUP	CF6-80C2, CF6-80A	SV	1
9304M93G04	ELBOW - AIR HPT RECOUP	CF6-80C2	AR	2
9304M93G04	ELBOW - AIR HPT RECOUP	CF6-80C2	AR	1
9304M93G04	ELBOW - AIR HPT RECOUP	CF6-80C2	SV	1
9312M23P01	SEAL - CARBON FACE	CF6-80A	AR	1
9312M23P01	SEAL - CARBON FACE	CF6-80A	AR	1
9312M23P01	SEAL - CARBON FACE	CF6-80A	AR	1
9312M23P01	SEAL - CARBON FACE	CF6-80A	AR	1
9312M23P01	SEAL - CARBON FACE	CF6-80A	AR	1
9312M23P01	SEAL - CARBON FACE	CF6-80A	AR	1
9312M23P01	SEAL - CARBON FACE	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9312M23P01	SEAL - CARBON FACE	CF6-80A	AR	1
9312M23P01	SEAL - CARBON FACE	CF6-80A	AR	1
9312M23P01	SEAL - CARBON FACE	CF6-80A	NE	1
9312M23P01	SEAL - CARBON FACE	CF6-80A	OH	1
9312M24P01	SEAL - CARBON FACE	CF6-80A	AR	1
9312M24P01	SEAL - CARBON FACE	CF6-80A	AR	1
9312M24P01	SEAL - CARBON FACE	CF6-80A	AR	1
9312M24P01	SEAL - CARBON FACE	CF6-80A	AR	1
9312M24P01	SEAL - CARBON FACE	CF6-80A	AR	1
9312M24P01	SEAL - CARBON FACE	CF6-80A	AR	1
9312M24P01	SEAL - CARBON FACE	CF6-80A	AR	1
9312M24P01	SEAL - CARBON FACE	CF6-80A	AR	1
9312M24P01	SEAL - CARBON FACE	CF6-80A	AR	1
9312M24P01	SEAL - CARBON FACE	CF6-80A	AR	1
9312M24P01	SEAL - CARBON FACE	CF6-80A	OH	1
9312M24P01	SEAL - CARBON FACE	CF6-80A	OH	1
9312M37P04	GEARSHAFT - 61 TOOTH SPUR	CF6-80A	AR	1
9312M37P04	GEARSHAFT - 61 TOOTH SPUR	CF6-80A	AR	1
9312M37P04	GEARSHAFT - 61 TOOTH SPUR	CF6-80A	AR	1
9312M37P04	GEARSHAFT - 61 TOOTH SPUR	CF6-80A	AR	1
9312M37P04	GEARSHAFT - 61 TOOTH SPUR	CF6-80A	SV	1
9312M38G04	GEARSHAFT - 77 TOOTH SPUR	CF6-80A	AR	1
9312M38G04	GEARSHAFT - 77 TOOTH SPUR	CF6-80A	AR	1
9312M38G04	GEARSHAFT - 77 TOOTH SPUR	CF6-80A	AR	1
9312M38G04	GEARSHAFT - 77 TOOTH SPUR	CF6-80A	AR	1
9312M39G04	AGB SPUR GEARSHAFT [47 TOOTH]	CF6-80C2, CF6-80A	OH	1
9312M40P04	GEARSHAFT - 77 TOOTH SPUR	CF6-80A	AR	1
9312M40P05	AGB SPUR GEARSHAFT [77 TOOTH]	CF6-80C2	AR	1
9312M41G04	CLUSTER - GEAR 54/31	CF6-80C2, CF6-80A	AR	1
9312M41G04	CLUSTER - GEAR 54/31	CF6-80C2, CF6-80A	AR	1
9312M41G04	CLUSTER - GEAR 54/31	CF6-80C2, CF6-80A	AR	1
9312M41G04	CLUSTER - GEAR 54/31	CF6-80C2, CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9312M41P04	BEARING - INTEGRATED DR GEN	CF6-80C2	AR	1
9312M42G03	GEARSHAFT - 75 TOOTH SPUR	CF6-80A	AR	1
9312M42G03	GEARSHAFT - 75 TOOTH SPUR	CF6-80A	AR	1
9312M42G03	GEARSHAFT - 75 TOOTH SPUR	CF6-80A	AR	1
9312M42G03	GEARSHAFT - 75 TOOTH SPUR	CF6-80A	AR	1
9312M42G03	GEARSHAFT - 75 TOOTH SPUR	CF6-80A	AR	1
9312M42G03	GEARSHAFT - 75 TOOTH SPUR	CF6-80A	SV	1
9312M42G03	GEARSHAFT - 75 TOOTH SPUR	CF6-80A	SV	1
9312M42P04	GEARSHAFT	CF6-80C2	AR	1
9312M42P04	GEARSHAFT	CF6-80C2	AR	1
9312M43P04	GEARSHAFT - 29 TOOTH SPUR	CF6-80A	AR	1
9312M43P04	GEARSHAFT - 29 TOOTH SPUR	CF6-80A	AR	1
9312M43P04	GEARSHAFT - 29 TOOTH SPUR	CF6-80A	AR	1
9312M43P04	GEARSHAFT - 29 TOOTH SPUR	CF6-80A	AR	1
9312M43P04	GEARSHAFT - 29 TOOTH SPUR	CF6-80A	AR	1
9312M43P04	GEARSHAFT - 29 TOOTH SPUR	CF6-80A	AR	1
9312M46P01	BEARING - BALL	CF6-80A	AR	1
9312M46P01	BEARING - BALL	CF6-80A	AR	1
9312M46P01	BEARING - BALL	CF6-80A	AR	1
9312M46P01	BEARING - BALL	CF6-80A	AR	1
9312M46P01	BEARING - BALL	CF6-80A	AR	1
9312M46P01	BEARING - BALL	CF6-80A	SV	1
9312M46P01	BEARING - BALL	CF6-80A	SV	1
9312M47P01	BEARING - BALL	CF6-80A	AR	1
9312M47P01	BEARING - BALL	CF6-80A	AR	1
9312M47P01	BEARING - BALL	CF6-80A	AR	1
9312M47P01	BEARING - BALL	CF6-80A	AR	1
9312M48P01	BEARING - BALL	CF6-80A	AR	1
9312M48P01	BEARING - BALL	CF6-80A	AR	1
9312M48P01	BEARING - BALL	CF6-80A	AR	1
9312M48P01	BEARING - BALL	CF6-80A	AR	1
9312M48P01	BEARING - BALL	CF6-80A	AR	1
9312M48P01	BEARING - BALL	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9312M48P01	BEARING - BALL	CF6-80A	AR	1
9312M48P01	BEARING - BALL	CF6-80A	AR	1
9312M48P01	BEARING - BALL	CF6-80A	SV	1
9312M48P01	BEARING - BALL	CF6-80A	SV	1
9312M49P01	BEARING - ANLR BALL	CF6-80A, CF6-50 (Boeing)	AR	1
9312M49P01	BEARING - ANLR BALL	CF6-80A, CF6-50 (Boeing)	AR	1
9312M49P01	BEARING - ANLR BALL	CF6-80A, CF6-50 (Boeing)	AR	1
9312M49P01	BEARING - ANLR BALL	CF6-80A, CF6-50 (Boeing)	AR	1
9312M49P01	BEARING - ANLR BALL	CF6-80A, CF6-50 (Boeing)	AR	1
9312M49P01	BEARING - ANLR BALL	CF6-80A, CF6-50 (Boeing)	SV	1
9312M49P01	BEARING - ANLR BALL	CF6-80A, CF6-50 (Boeing)	SV	1
9312M50P01	BEARING - BALL	CF6-80A	AR	1
9312M50P01	BEARING - BALL	CF6-80A	AR	1
9312M50P01	BEARING - BALL	CF6-80A	AR	1
9312M50P01	BEARING - BALL	CF6-80A	AR	1
9312M50P01	BEARING - BALL	CF6-80A	AR	1
9312M50P01	BEARING - BALL	CF6-80A	AR	1
9312M50P01	BEARING - BALL	CF6-80A	SV	1
9312M61P03	SHAFT - DRIVE RADIAL	CF6-80A	AR	1
9312M61P03	SHAFT - DRIVE RADIAL	CF6-80A	AR	1
9312M61P03	SHAFT - DRIVE RADIAL	CF6-80A	AR	1
9312M61P03	SHAFT - DRIVE RADIAL	CF6-80A	AR	1
9312M61P03	SHAFT - DRIVE RADIAL	CF6-80A	AR	1
9312M61P03	SHAFT - DRIVE RADIAL	CF6-80A	OH	1
9312M64G03	ADAPTER - HYDR PUMP	CF6-80A	AR	1
9312M64G03	ADAPTER - HYDR PUMP	CF6-80A	AR	1
9312M64G03	ADAPTER - HYDR PUMP	CF6-80A	AR	1
9312M64G06	ADAPTER - HYDR PUMP	CF6-80A	AR	1
9312M66G03	ADAPTER - IDG	CF6-80A	AR	1
9312M66G04	ADAPTER - IDG	CF6-80A	AR	1
9312M66G04	ADAPTER - IDG	CF6-80A	AR	1
9312M66G04	ADAPTER - IDG	CF6-80A	AR	1
9312M66G04	ADAPTER - IDG	CF6-80A	AR	1
9312M66G04	ADAPTER - IDG	CF6-80A	SV	1
9312M66G06	ADAPTER - IDG AGB	CF6-80C2	OH	1
9312M68G02	ADAPTER - LUBE PUMP	CF6-80A	AR	1
9312M68G03	ADAPTER - LUBE PUMP	CF6-80A	OH	1
9312M68G04	ADAPTER - LUBE PUMP	CF6-80C2	AR	1
9312M68G04	ADAPTER - LUBE PUMP	CF6-80C2	AR	1
9312M68G07	ADAPTER - LUBE PUMP	CF6-80C2	OH	1
9312M70G04	ADAPTER - STARTER	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9312M70G04	ADAPTER - STARTER	CF6-80A	AR	1
9312M70G04	ADAPTER - STARTER	CF6-80A	OH	1
9312M70G04	ADAPTER - STARTER	CF6-80A	OH	1
9312M70G05	ADAPTER - STARTER	CF6-80C2	AR	1
9312M72G06	ADAPTER - IDLER FUEL	CF6-80A	AR	1
9312M72G06	ADAPTER - IDLER FUEL	CF6-80A	AR	1
9312M72G06	ADAPTER - IDLER FUEL	CF6-80A	AR	1
9312M72G06	ADAPTER - IDLER FUEL	CF6-80A	AR	1
9312M74G03	ADAPTER - MAIN FUEL PUMP	CF6-80A	AR	1
9312M74G03	ADAPTER - MAIN FUEL PUMP	CF6-80A	AR	1
9312M74G03	ADAPTER - MAIN FUEL PUMP	CF6-80A	OH	1
9312M74G03	ADAPTER - MAIN FUEL PUMP	CF6-80A	OH	1
9312M74G03	ADAPTER - MAIN FUEL PUMP	CF6-80A	OH	1
9312M74G05	ADAPTER - MAIN FUEL PUMP	CF6-80C2	OH	1
9312M74G10	ADAPTER - MAIN FUEL PUMP	CF6-80C2	OH	1
9312M76G06	ADAPTER - GENERATOR	CF6-80A	AR	1
9312M76G07	ADAPTER - GENERATOR	CF6-80A	AR	1
9312M76G07	ADAPTER - GENERATOR	CF6-80A	AR	1
9312M76G07	ADAPTER - GENERATOR	CF6-80A	OH	1
9312M76G08	ADAPTER - GENERATOR	CF6-80C2	AR	1
9312M76G08	ADAPTER - GENERATOR	CF6-80C2	AR	1
9312M82P01	BEARING - BALL	CF6-80A	AR	1
9312M82P01	BEARING - BALL	CF6-80A	AR	1
9312M82P01	BEARING - BALL	CF6-80A	AR	1
9312M82P01	BEARING - BALL	CF6-80A	AR	1
9312M82P01	BEARING - BALL	CF6-80A	AR	1
9312M82P01	BEARING - BALL	CF6-80A	SV	1
9312M82P01	BEARING - BALL	CF6-80A	SV	1
9312M83P03	BEARING - BALL NO. 1	CF6-80A	AR	1
9312M96G10	HOUSING ASSY - ACCESSORY	CF6-80A	AR	1
9312M96G10	HOUSING ASSY - ACCESSORY	CF6-80A	AR	1
9312M99P02	SHAFT - HORIZONTAL DRIVE	CF6-80A	AR	1
9312M99P02	SHAFT - HORIZONTAL DRIVE	CF6-80A	AR	1
9312M99P02	SHAFT - HORIZONTAL DRIVE	CF6-80A	AR	1
9312M99P02	SHAFT - HORIZONTAL DRIVE	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9312M99P02	SHAFT - HORIZONTAL DRIVE	CF6-80A	AR	1
9312M99P02	SHAFT - HORIZONTAL DRIVE	CF6-80A	OH	1
9312M99P02	SHAFT - HORIZONTAL DRIVE	CF6-80A	OH	1
9312M99P03	HORIZONTAL DRIVE SHAFT	CF6-80C2	AR	1
9312M99P03	HORIZONTAL DRIVE SHAFT	CF6-80C2	SV	1
9313M10P01	SPACER	CF6-80A	AR	80
9313M10P01	SPACER	CF6-80A	NE	2
9313M10P01	SPACER	CF6-80A	SV	4
9313M10P01	SPACER	CF6-80A	OH	43
9313M10P01	SPACER	CF6-80A	NS	5
9313M10P01	SPACER	CF6-80A	NS	6
9313M10P01	SPACER	CF6-80A	AR	80
9313M10P01	SPACER	CF6-80A	NE	1
9313M27P03	VANE - FAN STTR STG 3	CF6-80A	AR	112
9313M27P03	VANE - FAN STTR STG 3	CF6-80A	AR	112
9313M27P03	VANE - FAN STTR STG 3	CF6-80A	AR	112
9313M27P03	VANE - FAN STTR STG 3	CF6-80A	AR	36
9313M27P03	VANE - FAN STTR STG 3	CF6-80A	AR	12
9313M27P03	VANE - FAN STTR STG 3	CF6-80A	AR	85
9313M27P03	VANE - FAN STTR STG 3	CF6-80A	AR	112
9313M27P03	VANE - FAN STTR STG 3	CF6-80A	AR	112
9313M27P03	VANE - FAN STTR STG 3	CF6-80A	AR	112
9313M27P03	VANE - FAN STTR STG 3	CF6-80A	AR	79
9313M27P03	VANE - FAN STTR STG 3	CF6-80A	SV	42
9313M27P03	VANE - FAN STTR STG 3	CF6-80A	AR	112
9313M27P03	VANE - FAN STTR STG 3	CF6-80A	SV	35
9313M27P03	VANE - FAN STTR STG 3	CF6-80A	SV	35
9313M27P03	VANE - FAN STTR STG 3	CF6-80A	AR	112
9313M34G01	HOUSING - SHAFT	CF6-80A	AR	1
9313M34G01	HOUSING - SHAFT	CF6-80A	NS	1
9313M52P01	BEARING - BALL INPUT SHAFT	CF6-80A	AR	1
9313M52P01	BEARING - BALL INPUT SHAFT	CF6-80A	AR	1
9313M52P01	BEARING - BALL INPUT SHAFT	CF6-80A	AR	1
9313M52P01	BEARING - BALL INPUT SHAFT	CF6-80A	AR	1
9313M52P01	BEARING - BALL INPUT SHAFT	CF6-80A	SV	1
9313M52P01	BEARING - BALL INPUT SHAFT	CF6-80A	SV	1
9313M52P01	BEARING - BALL INPUT SHAFT	CF6-80A	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
9313M52P01	BEARING - BALL INPUT SHAFT	CF6-80A	SV	1
9313M53P01	BEARING - BALL OUTPUT	CF6-80A	AR	1
9313M53P01	BEARING - BALL OUTPUT	CF6-80A	AR	1
9313M53P01	BEARING - BALL OUTPUT	CF6-80A	AR	1
9313M53P01	BEARING - BALL OUTPUT	CF6-80A	AR	1
9313M53P01	BEARING - BALL OUTPUT	CF6-80A	SV	1
9313M53P01	BEARING - BALL OUTPUT	CF6-80A	AR	1
9313M53P01	BEARING - BALL OUTPUT	CF6-80A	SV	1
9313M53P01	BEARING - BALL OUTPUT	CF6-80A	SV	1
9313M54P01	BEARING - ROLLER INPUT	CF6-80A	AR	1
9313M54P01	BEARING - ROLLER INPUT	CF6-80A	AR	1
9313M54P01	BEARING - ROLLER INPUT	CF6-80A	AR	1
9313M54P01	BEARING - ROLLER INPUT	CF6-80A	AR	1
9313M54P01	BEARING - ROLLER INPUT	CF6-80A	AR	1
9313M54P01	BEARING - ROLLER INPUT	CF6-80A	SV	1
9313M54P01	BEARING - ROLLER INPUT	CF6-80A	SV	1
9313M54P01	BEARING - ROLLER INPUT	CF6-80A	SV	1
9313M55P01	BEARING - RLR OUTPUT	CF6-80A	AR	1
9313M55P01	BEARING - RLR OUTPUT	CF6-80A	AR	1
9313M55P01	BEARING - RLR OUTPUT	CF6-80A	AR	1
9313M55P01	BEARING - RLR OUTPUT	CF6-80A	SV	1
9313M55P01	BEARING - RLR OUTPUT	CF6-80A	SV	1
9313M55P01	BEARING - RLR OUTPUT	CF6-80A	SV	1
9313M59P04	NUT - BRG RETAINER	CF6-80A	AR	1
9313M59P04	NUT - BRG RETAINER	CF6-80A	AR	1
9313M59P05	NUT - BRG RETAINER	CF6-80A	AR	1
9313M59P05	NUT - BRG RETAINER	CF6-80A	AR	1
9313M59P08	NUT - BRG RETAINER	CF6-80A	OH	1
9313M59P08	NUT - BRG RETAINER	CF6-80A	NE	2
9313M59P12	NUT - BRG RETAINER	CF6-80A	AR	1
9313M60P02	HOUSING - BALL BRG INPUT	CF6-80A	AR	1
9313M60P02	HOUSING - BALL BRG INPUT	CF6-80A	AR	1
9313M61P02	HOUSING - BALL BRG OUTPUT	CF6-80A	AR	1
9313M61P02	HOUSING - BALL BRG OUTPUT	CF6-80A	AR	1
9313M61P02	HOUSING - BALL BRG OUTPUT	CF6-80A	AR	1
9313M61P02	HOUSING - BALL BRG OUTPUT	CF6-80A	AR	1
9313M62P02	HOUSING - RLR BRG INPUT SHFT	CF6-80A	AR	1
9313M62P02	HOUSING - RLR BRG INPUT SHFT	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9313M62P02	HOUSING - RLR BRG INPUT SHFT	CF6-80A	AR	1
9313M63P02	HOUSING - RLR BRG OUTPT SHFT	CF6-80A	AR	1
9313M63P02	HOUSING - RLR BRG OUTPT SHFT	CF6-80A	AR	1
9313M63P02	HOUSING - RLR BRG OUTPT SHFT	CF6-80A	AR	1
9313M64P02	RETAINER - BALL BRG SHAFT	CF6-80A	AR	1
9313M64P02	RETAINER - BALL BRG SHAFT	CF6-80A	OH	1
9313M64P02	RETAINER - BALL BRG SHAFT	CF6-80A	AR	1
9313M65G05	RETAINER - BALL BRG OIL	CF6-80A	OH	1
9313M65G05	RETAINER - BALL BRG OIL	CF6-80A	OH	1
9313M65G06	RETAINER - BALL BRG OIL	CF6-80A	AR	1
9313M65G06	RETAINER - BALL BRG OIL	CF6-80A	AR	1
9313M65G06	RETAINER - BALL BRG OIL	CF6-80A	AR	1
9313M65G06	RETAINER - BALL BRG OIL	CF6-80A	AR	1
9313M66P02	RETAINER - RLR BRG SHAFT	CF6-80A	AR	1
9313M66P02	RETAINER - RLR BRG SHAFT	CF6-80A	AR	1
9313M67P02	RETAINER - RLR BRG SHAFT	CF6-80A	AR	1
9313M67P02	RETAINER - RLR BRG SHAFT	CF6-80A	AR	1
9313M67P02	RETAINER - RLR BRG SHAFT	CF6-80A	AR	1
9313M71G02	NOZZLE - OIL	CF6-80A	AR	1
9313M71G02	NOZZLE - OIL	CF6-80A	AR	1
9313M71G02	NOZZLE - OIL	CF6-80A	AR	1
9313M71G03	NOZZLE - OIL	CF6-80A	AR	1
9313M71G03	NOZZLE - OIL	CF6-80A	AR	1
9313M72P04	GEARSHAFT - BEVEL GEAR	CF6-80A	AR	1
9313M72P04	GEARSHAFT - BEVEL GEAR	CF6-80A	AR	1
9313M72P04	GEARSHAFT - BEVEL GEAR	CF6-80A	AR	1
9313M72P04	GEARSHAFT - BEVEL GEAR	CF6-80A	AR	1
9313M73P03	GEARSHAFT - PINION INPUT	CF6-80A	AR	1
9313M73P03	GEARSHAFT - PINION INPUT	CF6-80A	AR	1
9313M73P03	GEARSHAFT - PINION INPUT	CF6-80A	AR	1
9313M74G03	NOZZLE - OIL	CF6-80A	AR	1
9313M74G03	NOZZLE - OIL	CF6-80A	AR	1
9313M74G04	NOZZLE - OIL	CF6-80A	AR	1
9313M74G04	NOZZLE - OIL	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9313M74G04	NOZZLE - OIL	CF6-80A	AR	1
9313M75G03	NOZZLE - OIL	CF6-80A	AR	1
9313M75G04	NOZZLE - OIL	CF6-80A	AR	1
9313M75G04	NOZZLE - OIL	CF6-80A	AR	1
9313M75G04	NOZZLE - OIL	CF6-80A	AR	1
9313M75G04	NOZZLE - OIL	CF6-80A	AR	1
9313M76G04	NOZZLE - OIL	CF6-80A	AR	1
9313M76G04	NOZZLE - OIL	CF6-80A	AR	1
9313M76G05	NOZZLE - OIL	CF6-80A	AR	1
9313M76G05	NOZZLE - OIL	CF6-80A	AR	1
9313M77G04	NOZZLE - OIL	CF6-80A	AR	1
9313M77G04	NOZZLE - OIL	CF6-80A	AR	1
9313M77G05	NOZZLE - OIL	CF6-80A	AR	1
9313M77G05	NOZZLE - OIL	CF6-80A	AR	1
9313M81G02	SUPPORT - BALL BRG INPUT	CF6-80A	AR	1
9313M81G03	SUPPORT - BALL BRG INPUT	CF6-80A	AR	1
9313M81G03	SUPPORT - BALL BRG INPUT	CF6-80A	AR	1
9313M93G03	HOUSING - LOWER TRANSFER	CF6-80A	AR	1
9313M93G03	HOUSING - LOWER TRANSFER	CF6-80A	AR	1
9313M93G03	HOUSING - LOWER TRANSFER	CF6-80A	AR	1
9313M93G03	HOUSING - LOWER TRANSFER	CF6-80A	AR	1
9313M93G04	HOUSING - LOWER TRANSFER	CF6-80A	AR	1
9313M93G04	HOUSING - LOWER TRANSFER	CF6-80A	OH	1
9315M11G08	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9315M11G08	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9315M11G08	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9315M11G08	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9315M11G08	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9315M11G08	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9315M11G08	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9315M11G08	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9315M11G08	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9315M11G08	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9315M11G08	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9315M11G08	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9315M11G08	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9315M11G09	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9315M11G09	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9315M11G09	BLADE ASSY - HPTR STG 2	CF6-50	AR	1
9315M11G09	BLADE ASSY - HPTR STG 2	CF6-50	OH	1
9315M11G09	BLADE ASSY - HPTR STG 2	CF6-50	AR	1

[illegible]

[illegible]

Part Number	Part Description	Engine Type	Condition	Quantity
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M11G16	BLADE ASSY - HPTR STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M16G17	SEAL - HPTS INTERSTAGE AIR	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9315M70P14	SUPPORT - SHROUD HPT	CF6-80A	AR	1
9315M70P14	SUPPORT - SHROUD HPT	CF6-80A	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9315M70P15	SUPPORT - SHROUD HPT	CF6-80A	OH	1
9315M70P15	SUPPORT - SHROUD HPT	CF6-80A	OH	1
9315M70P15	SUPPORT - SHROUD HPT	CF6-80A	OH	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	OH	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	OH	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	OH	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	OH	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1

Part Number	Part Description	Engine Type	Condition	Quantity
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1
9315M75G08	SHROUD - HPT STATOR STG 2	CF6-80A	NE	1
9315M89P02	TUBE - COOLING AIR HPT	CF6-80A	NS	56
9315M89P02	TUBE - COOLING AIR HPT	CF6-80A	NS	53
9315M89P02	TUBE - COOLING AIR HPT	CF6-80A	NS	3
9317M80P02	RETAINING - RING	CF6-80A	AR	1
9317M80P02	RETAINING - RING	CF6-80A	AR	1
9317M80P02	RETAINING - RING	CF6-80A	SV	1
9317M80P02	RETAINING - RING	CF6-80A	SV	1
9317M80P02	RETAINING - RING	CF6-80A	AR	1
9317M90P01	BEARING - ROLLER	CF6-80A	AR	1
9317M90P01	BEARING - ROLLER	CF6-80A	AR	1
9317M90P01	BEARING - ROLLER	CF6-80A	AR	1
9317M90P01	BEARING - ROLLER	CF6-80A	AR	1
9317M90P01	BEARING - ROLLER	CF6-80A	AR	1
9317M90P01	BEARING - ROLLER	CF6-80A	AR	1
9317M90P01	BEARING - ROLLER	CF6-80A	AR	1
9317M90P01	BEARING - ROLLER	CF6-80A	AR	1
9317M90P01	BEARING - ROLLER	CF6-80A	AR	1
9317M90P01	BEARING - ROLLER	CF6-80A	AR	1
9317M90P01	BEARING - ROLLER	CF6-80A	AR	1
9317M90P01	BEARING - ROLLER	CF6-80A	AR	1
9317M90P01	BEARING - ROLLER	CF6-80A	AR	1
9317M90P01	BEARING - ROLLER	CF6-80A	AR	1
9317M90P01	BEARING - ROLLER	CF6-80A	SV	1
9317M90P01	BEARING - ROLLER	CF6-80A	SV	1
9317M90P01	BEARING - ROLLER	CF6-80A	SV	1
9317M90P01	BEARING - ROLLER	CF6-80A	SV	1
9317M90P01	BEARING - ROLLER	CF6-80A	SV	1
9317M90P01	BEARING - ROLLER	CF6-80A	SV	1
9317M90P01	BEARING - ROLLER	CF6-80A	SV	1
9317M90P01	BEARING - ROLLER	CF6-80A	AR	1
9317M91P01	BEARING - ROLLER	CF6-80A	AR	1
9317M91P01	BEARING - ROLLER	CF6-80A	AR	1
9317M91P01	BEARING - ROLLER	CF6-80A	AR	1
9317M91P01	BEARING - ROLLER	CF6-80A	AR	1
9317M91P01	BEARING - ROLLER	CF6-80A	AR	1
9317M91P01	BEARING - ROLLER	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9317M91P01	BEARING - ROLLER	CF6-80A	AR	1
9317M91P01	BEARING - ROLLER	CF6-80A	SV	1
9317M91P01	BEARING - ROLLER	CF6-80A	SV	1
9317M92P01	BEARING - ROLLER	CF6-80A	AR	1
9317M92P01	BEARING - ROLLER	CF6-80A	AR	1
9317M92P01	BEARING - ROLLER	CF6-80A	AR	1
9317M92P01	BEARING - ROLLER	CF6-80A	AR	1
9317M92P01	BEARING - ROLLER	CF6-80A	AR	1
9317M92P01	BEARING - ROLLER	CF6-80A	AR	1
9317M92P01	BEARING - ROLLER	CF6-80A	SV	1
9317M92P01	BEARING - ROLLER	CF6-80A	SV	1
9317M93P01	BEARING - ROLLER	CF6-80A	AR	1
9317M93P01	BEARING - ROLLER	CF6-80A	AR	1
9317M93P01	BEARING - ROLLER	CF6-80A	AR	1
9317M93P01	BEARING - ROLLER	CF6-80A	AR	1
9317M93P01	BEARING - ROLLER	CF6-80A	OH	1
9317M93P01	BEARING - ROLLER	CF6-80A	SV	1
9318M28P14	TUBE - STG 1 LPT STTR AIR	CF6-80C2, CF6-80A	NE	1
9318M28P14	TUBE - STG 1 LPT STTR AIR	CF6-80C2, CF6-80A	NE	2
9318M28P14	TUBE - STG 1 LPT STTR AIR	CF6-80C2, CF6-80A	NE	2
9318M28P14	TUBE - STG 1 LPT STTR AIR	CF6-80C2, CF6-80A	NE	2
9318M28P14	TUBE - STG 1 LPT STTR AIR	CF6-80C2, CF6-80A	NE	2
9318M28P14	TUBE - STG 1 LPT STTR AIR	CF6-80C2, CF6-80A	NE	12
9318M28P16	TUBE - STG 1 AIR NOZ	CF6-80C2	NE	1
9318M28P16	TUBE - STG 1 AIR NOZ	CF6-80C2	NE	1
9318M28P16ACS	TUBE - AIR	CF6-80C2	NS	1
9318M41G18	NOZZLE - LPT STATOR STG 1	CF6-80A	AR	1
9318M51P05	BLADE - LPTR STG 1	CF6-80A	OH	7
9318M51P06	BLADE - LPTR STG 1	CF6-80A	OH	1
9318M51P06	BLADE - LPTR STG 1	CF6-80A	OH	1
9318M51P06	BLADE - LPTR STG 1	CF6-80A	OH	5
9318M51P08	BLADE - LPTR STG 1	CF6-80A	OH	4
9318M51P11	BLADE - LPTR STG 1	CF6-80A	OH	17
9318M51P11	BLADE - LPTR STG 1	CF6-80A	OH	14
9318M51P11	BLADE - LPTR STG 1	CF6-80A	OH	4
9318M51P11	BLADE - LPTR STG 1	CF6-80A	OH	30
9318M51P11	BLADE - LPTR STG 1	CF6-80A	OH	15
9318M51P11	BLADE - LPTR STG 1	CF6-80A	OH	30
9318M51P12	BLADE - LPTR STG 1	CF6-80A	OH	1
9318M51P12	BLADE - LPTR STG 1	CF6-80A	OH	36

Part Number	Part Description	Engine Type	Condition	Quantity
9318M51P12	BLADE - LPTR STG 1	CF6-80A	OH	1
9318M51P12	BLADE - LPTR STG 1	CF6-80A	SV	5
9318M52P06	BLADE - LPTR STG 2	CF6-80A	OH	12
9318M52P06	BLADE - LPTR STG 2	CF6-80A	OH	3
9318M52P06	BLADE - LPTR STG 2	CF6-80A	OH	5
9318M52P06	BLADE - LPTR STG 2	CF6-80A	OH	16
9318M52P08	BLADE - LPTR STG 2	CF6-80A	AR	1
9318M52P10	BLADE - LPTR STG 2	CF6-80A	OH	8
9318M52P11	BLADE - LPTR STG 2	CF6-80A	OH	26
9318M52P11	BLADE - LPTR STG 2	CF6-80A	OH	30
9318M52P12	BLADE - LPTR STG 2	CF6-80A	SV	2
9318M52P12	BLADE - LPTR STG 2	CF6-80A	AR	2
9318M52P12	BLADE - LPTR STG 2	CF6-80A	OH	2
9318M53P14	BLADE - LPTR STG 3	CF6-80A	AR	1
9318M53P16	BLADE - LPTR STG 3	CF6-80A	OH	11
9318M53P16	BLADE - LPTR STG 3	CF6-80A	OH	4
9318M53P16	BLADE - LPTR STG 3	CF6-80A	OH	15
9318M53P16	BLADE - LPTR STG 3	CF6-80A	OH	3
9318M53P16	BLADE - LPTR STG 3	CF6-80A	OH	1
9318M53P16	BLADE - LPTR STG 3	CF6-80A	OH	2
9318M54P09	BLADE - LPTR STG 4	CF6-80A	OH	39
9318M54P09	BLADE - LPTR STG 4	CF6-80A	OH	18
9318M54P09	BLADE - LPTR STG 4	CF6-80A	OH	2
9318M54P09	BLADE - LPTR STG 4	CF6-80A	OH	23
9318M54P09	BLADE - LPTR STG 4	CF6-80A	OH	2
9318M59G04	SUPPORT - LINER OUTER	CF6-80A	AR	21
9318M59G04	SUPPORT - LINER OUTER	CF6-80A	AR	22
9318M59G04	SUPPORT - LINER OUTER	CF6-80A	SV	1
9318M87P03	RETAINER - BOLT	CF6-80C2, CF6-80A	NE	23
9318M93P06	RETAINER - BLD STG 3	CF6-80A	NE	9
9319M17G02	SEAL - STATIONARY CDP	CF6-80A	AR	1
9319M17G03	SEAL - STATIONARY CDP	CF6-80A	SV	1
9319M17G03	SEAL - STATIONARY CDP	CF6-80A	OH	1
9319M17G03	SEAL - STATIONARY CDP	CF6-80A	OH	1
9319M21P11	RING - DAMPENING	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9319M24G03	KEY - STG 1	CF6-80C2, CF6-80A	AR	28
9319M24G03	KEY - STG 1	CF6-80C2, CF6-80A	AR	1
9319M24G03	KEY - STG 1	CF6-80C2, CF6-80A	OH	1
9319M24G03	KEY - STG 1	CF6-80C2, CF6-80A	OH	1
9319M24G03	KEY - STG 1	CF6-80C2, CF6-80A	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9319M24G03	KEY - STG 1	CF6-80C2, CF6-80A	OH	2
9319M24G03	KEY - STG 1	CF6-80C2, CF6-80A	OH	1
9319M24G03	KEY - STG 1	CF6-80C2, CF6-80A	AR	38
9319M24G03	KEY - STG 1	CF6-80C2, CF6-80A	OH	8
9320M31P06	NUT ASSY - SLFLKG	CF6-80A	NE	1
9320M55G02	SLEEVE - FAN FRAME	CF6-80A	AR	1
9320M55G02	SLEEVE - FAN FRAME	CF6-80A	AR	1
9320M57G03	SLEEVE ASSY - FAN FRAME	CF6-80A	AR	1
9320M57G04	SLEEVE ASSY - FAN FRAME	CF6-80A	AR	1
9320M57G04	SLEEVE ASSY - FAN FRAME	CF6-80A	AR	1
9320M57G04	SLEEVE ASSY - FAN FRAME	CF6-80A	AR	1
9320M61P03	VANE - OUTER GUIDE	CF6-80A	AR	1
9320M61P03	VANE - OUTER GUIDE	CF6-80A	AR	1
9320M61P03	VANE - OUTER GUIDE	CF6-80A	AR	1
9320M61P03	VANE - OUTER GUIDE	CF6-80A	AR	1
9320M61P03	VANE - OUTER GUIDE	CF6-80A	AR	1
9320M61P03	VANE - OUTER GUIDE	CF6-80A	AR	1
9320M61P03	VANE - OUTER GUIDE	CF6-80A	AR	1
9320M61P03	VANE - OUTER GUIDE	CF6-80A	AR	1
9320M61P03	VANE - OUTER GUIDE	CF6-80A	AR	1
9320M61P03	VANE - OUTER GUIDE	CF6-80A	OH	1
9320M61P03	VANE - OUTER GUIDE	CF6-80A	AR	1
9320M61P03	VANE - OUTER GUIDE	CF6-80A	AR	1
9320M61P03	VANE - OUTER GUIDE	CF6-80A	AR	1
9320M61P03	VANE - OUTER GUIDE	CF6-80A	AR	1
9320M61P03	VANE - OUTER GUIDE	CF6-80A	AR	1
9320M61P03	VANE - OUTER GUIDE	CF6-80A	AR	1
9320M61P03	VANE - OUTER GUIDE	CF6-80A	AR	1
9320M61P03	VANE - OUTER GUIDE	CF6-80A	AR	1
9320M61P03	VANE - OUTER GUIDE	CF6-80A	AR	1
9320M61P03	VANE - OUTER GUIDE	CF6-80A	AR	1
9320M61P03	VANE - OUTER GUIDE	CF6-80A	AR	1
9320M61P03	VANE - OUTER GUIDE	CF6-80A	SV	1
9320M62P03	VANE - OUTLET GUIDE	CF6-80A	OH	1
9320M62P03	VANE - OUTLET GUIDE	CF6-80A	OH	1
9320M62P03	VANE - OUTLET GUIDE	CF6-80A	OH	1
9320M62P03	VANE - OUTLET GUIDE	CF6-80A	SV	1
9320M62P03	VANE - OUTLET GUIDE	CF6-80A	AR	1
9320M62P03	VANE - OUTLET GUIDE	CF6-80A	AR	1
9320M62P03	VANE - OUTLET GUIDE	CF6-80A	AR	1
9320M62P03	VANE - OUTLET GUIDE	CF6-80A	AR	1
9320M62P03	VANE - OUTLET GUIDE	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9320M67P03	VANE - OUTLET GUIDE	CF6-80A	AR	1
9320M67P03	VANE - OUTLET GUIDE	CF6-80A	AR	1
9320M67P03	VANE - OUTLET GUIDE	CF6-80A	AR	1
9320M67P03	VANE - OUTLET GUIDE	CF6-80A	AR	1
9320M67P03	VANE - OUTLET GUIDE	CF6-80A	AR	1
9320M67P03	VANE - OUTLET GUIDE	CF6-80A	AR	1
9320M67P03	VANE - OUTLET GUIDE	CF6-80A	AR	1
9320M67P03	VANE - OUTLET GUIDE	CF6-80A	AR	1
9320M67P03	VANE - OUTLET GUIDE	CF6-80A	AR	1
9320M67P03	VANE - OUTLET GUIDE	CF6-80A	AR	1
9320M67P03	VANE - OUTLET GUIDE	CF6-80A	AR	1
9320M67P03	VANE - OUTLET GUIDE	CF6-80A	AR	1
9320M67P03	VANE - OUTLET GUIDE	CF6-80A	AR	1
9320M67P03	VANE - OUTLET GUIDE	CF6-80A	AR	1
9320M67P03	VANE - OUTLET GUIDE	CF6-80A	AR	1
9320M67P03	VANE - OUTLET GUIDE	CF6-80A	AR	1
9320M67P03	VANE - OUTLET GUIDE	CF6-80A	AR	1
9320M67P03	VANE - OUTLET GUIDE	CF6-80A	AR	1
9320M67P03	VANE - OUTLET GUIDE	CF6-80A	AR	1
9320M67P03	VANE - OUTLET GUIDE	CF6-80A	AR	1
9320M70P03	HOUSING - FWD BRG NO. 1	CF6-80A	AR	1
9320M70P03	HOUSING - FWD BRG NO. 1	CF6-80A	AR	1
9320M70P03	HOUSING - FWD BRG NO. 1	CF6-80A	AR	1
9320M74P01	BAFFLE - OIL	CF6-80C2, CF6-80A	NS	3
9320M75P01	BAFFLE - IDG GRSHFT OIL	CF6-80C2, CF6-80A	AR	1
9320M76G02	GEARBOX - MOUNT RIGHT	CF6-80A	OH	1
9320M78P07	SEAL - OUTER INNER	CF6-80A	NE	6
9320M78P07	SEAL - OUTER INNER	CF6-80A	NE	25
9320M78P07	SEAL - OUTER INNER	CF6-80A	NE	25
9320M79P04	SEAL - INNER	CF6-80A	NE	35
9320M79P04	SEAL - INNER	CF6-80A	NE	7
9326M60P01	SPACER - STG 1	CF6-80C2	AR	26
9326M60P01	SPACER - STG 1	CF6-80C2	AR	38
9326M60P01	SPACER - STG 1	CF6-80C2	OH	24
9326M60P01	SPACER - STG 1	CF6-80C2	OH	1
9327M26P001A	BRACKET	CF6-80A	AR	1
9327M26P001A	BRACKET	CF6-80A	AR	1
9327M46G01	MANIFOLD - FUEL SUPPLY	CF6-80A	AR	1
9327M48P001A	BRACKET	CF6-80A	NE	1
9327M61G01	TUBE - AIR COOLING VALVE	CF6-80A	AR	1
9327M61G01	TUBE - AIR COOLING VALVE	CF6-80A	AR	1
9327M79G01	TUBE - OIL PUMP	CF6-80A	OH	1
9327M79G01	TUBE - OIL PUMP	CF6-80A	OH	1
9327M79G01	TUBE - OIL PUMP	CF6-80A	AR	1
9327M79G01	TUBE - OIL PUMP	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9327M79G01	TUBE - OIL PUMP	CF6-80A	AR	1
9327M81G02	TUBE - OIL	CF6-80A	AR	1
9327M81G02	TUBE - OIL	CF6-80A	OH	1
9327M81G02	TUBE - OIL	CF6-80A	AR	1
9327M81G02	TUBE - OIL	CF6-80A	AR	1
9327M81G02	TUBE - OIL	CF6-80A	AR	1
9327M98G01	BRACKET	CF6-80A	AR	1
9327M98G01	BRACKET	CF6-80A	NS	1
9327M99P001A	BRACKET	CF6-80A	AR	1
9328M11G03	BRACKET	CF6-80A	NE	1
9328M11G03	BRACKET	CF6-80A	SV	1
9328M12G01	BRACKET	CF6-80A	SV	1
9328M27G03	SHIELD - SPRAY	CF6-80A	OH	1
9329M25P01	BAFFLE - STTR STG 11-12	CF6-80A	OH	1
9329M25P01	BAFFLE - STTR STG 11-12	CF6-80A	OH	1
9329M25P01	BAFFLE - STTR STG 11-12	CF6-80A	OH	1
9329M25P01	BAFFLE - STTR STG 11-12	CF6-80A	AR	1
9329M25P01	BAFFLE - STTR STG 11-12	CF6-80A	AR	1
9329M25P01	BAFFLE - STTR STG 11-12	CF6-80A	AR	1
9329M25P01	BAFFLE - STTR STG 11-12	CF6-80A	AR	1
9329M25P01	BAFFLE - STTR STG 11-12	CF6-80A	AR	1
9329M25P01	BAFFLE - STTR STG 11-12	CF6-80A	AR	1
9329M25P01	BAFFLE - STTR STG 11-12	CF6-80A	AR	1
9329M25P01	BAFFLE - STTR STG 11-12	CF6-80A	AR	1
9329M25P01	BAFFLE - STTR STG 11-12	CF6-80A	AR	1
9329M25P01	BAFFLE - STTR STG 11-12	CF6-80A	AR	1
9329M25P01	BAFFLE - STTR STG 11-12	CF6-80A	AR	1
9329M25P01	BAFFLE - STTR STG 11-12	CF6-80A	AR	1
9329M25P01	BAFFLE - STTR STG 11-12	CF6-80A	OH	1
9329M25P01	BAFFLE - STTR STG 11-12	CF6-80A	AR	1
9329M25P01	BAFFLE - STTR STG 11-12	CF6-80A	SV	1
9329M25P02	BAFFLE - STTR STG 11-12	CF6-80A	AR	1
9329M25P02	BAFFLE - STTR STG 11-12	CF6-80A	AR	1
9329M25P02	BAFFLE - STTR STG 11-12	CF6-80A	OH	1
9329M25P02	BAFFLE - STTR STG 11-12	CF6-80A	OH	1
9329M25P02	BAFFLE - STTR STG 11-12	CF6-80A	OH	1
9329M25P02	BAFFLE - STTR STG 11-12	CF6-80A	OH	1
9329M25P02	BAFFLE - STTR STG 11-12	CF6-80A	OH	1
9329M25P02	BAFFLE - STTR STG 11-12	CF6-80A	AR	1
9329M25P02	BAFFLE - STTR STG 11-12	CF6-80A	OH	1
9329M32P02	ADAPTER - RTR PRESS TUBE	CF6-50 (Boeing)	AR	1
9329M32P03	ADAPTER - RTR PRESS TUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9329M34P01	FAIRING - STOP FAN STATOR	CF6-80A	NE	1
9329M34P01	FAIRING - STOP FAN STATOR	CF6-80A	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
9329M40P01	SEAL - RING	CF6-80A, CF6-50 (Boeing)	AR	1
9329M40P01	SEAL - RING	CF6-80A, CF6-50 (Boeing)	AR	1
9329M51G01	RING - IMPINGEMENT STG 1	CF6-80A	OH	1
9329M55P01	KEY - CPRSR STTR CASING	CF6-80A	AR	2
9329M55P01	KEY - CPRSR STTR CASING	CF6-80A	NS	1
9329M55P01	KEY - CPRSR STTR CASING	CF6-80A	NS	1
9329M61P02	RETAINER	CF6-80A	AR	10
9329M61P02	RETAINER	CF6-80A	AR	10
9329M61P02	RETAINER	CF6-80A	AR	10
9329M61P02	RETAINER	CF6-80A	AR	10
9329M61P02	RETAINER	CF6-80A	AR	10
9329M61P02	RETAINER	CF6-80A	OH	3
9329M61P02	RETAINER	CF6-80A	OH	10
9329M61P02	RETAINER	CF6-80A	OH	3
9329M61P02	RETAINER	CF6-80A	AR	10
9329M62P02	RETAINER	CF6-80A	SV	15
9329M62P02	RETAINER	CF6-80A	SV	18
9329M63P02	RETAINER	CF6-80A	SV	8
9329M63P02	RETAINER	CF6-80A	AR	18
9329M63P02	RETAINER	CF6-80A	AR	18
9329M63P02	RETAINER	CF6-80A	AR	18
9329M63P02	RETAINER	CF6-80A	SV	1
9329M63P02	RETAINER	CF6-80A	OH	12
9329M63P02	RETAINER	CF6-80A	AR	18
9329M63P02	RETAINER	CF6-80A	AR	18
9329M63P02	RETAINER	CF6-80A	OH	12
9329M63P02	RETAINER	CF6-80A	OH	18
9329M63P02	RETAINER	CF6-80A	AR	18
9329M63P02	RETAINER	CF6-80A	AR	18
9329M63P02	RETAINER	CF6-80A	OH	18
9329M63P02	RETAINER	CF6-80A	OH	10
9329M63P02	RETAINER	CF6-80A	OH	1
9329M63P02	RETAINER	CF6-80A	OH	3
9329M63P02	RETAINER	CF6-80A	OH	1
9329M63P02	RETAINER	CF6-80A	OH	2
9329M63P02	RETAINER	CF6-80A	OH	3
9329M84G02	HOUSING - DAMPER BRG NO. 3	CF6-80A	AR	1
9329M84G02	HOUSING - DAMPER BRG NO. 3	CF6-80A	OH	1
9329M84G04	HOUSING - DAMPER BRG NO. 3	CF6-80A	AR	1
9329M84G04	HOUSING - DAMPER BRG NO. 3	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9329M84G04	HOUSING - DAMPER BRG NO. 3	CF6-80A	AR	1
9329M84G04	HOUSING - DAMPER BRG NO. 3	CF6-80A	AR	1
9329M84G04	HOUSING - DAMPER BRG NO. 3	CF6-80A	SV	1
9329M84G04	HOUSING - DAMPER BRG NO. 3	CF6-80A	AR	1
9329M84G04	HOUSING - DAMPER BRG NO. 3	CF6-80A	AR	1
9329M84G04	HOUSING - DAMPER BRG NO. 3	CF6-80A	AR	1
9329M84G05	#3 BEARING HOUSING	CF6-80C2	AR	1
9329M84G05	#3 BEARING HOUSING	CF6-80C2	AR	1
9329M84G05	#3 BEARING HOUSING	CF6-80C2	SV	1
9329M84G07	#3 BEARING HOUSING	CF6-80C2	AR	1
9329M85P02	BEARING - RLR NO. 3	CF6-80C2, CF6-80A	AR	1
9329M85P02	BEARING - RLR NO. 3	CF6-80C2, CF6-80A	AR	1
9329M85P02	BEARING - RLR NO. 3	CF6-80C2, CF6-80A	AR	1
9329M85P02	BEARING - RLR NO. 3	CF6-80C2, CF6-80A	AR	1
9329M85P02	BEARING - RLR NO. 3	CF6-80C2, CF6-80A	AR	1
9329M85P02	BEARING - RLR NO. 3	CF6-80C2, CF6-80A	AR	1
9329M85P02	BEARING - RLR NO. 3	CF6-80C2, CF6-80A	AR	1
9329M87P03	RETAINER	CF6-80C2, CF6-80A	AR	1
9329M87P03	RETAINER	CF6-80C2, CF6-80A	AR	1
9329M87P03	RETAINER	CF6-80C2, CF6-80A	AR	1
9329M87P03	RETAINER	CF6-80C2, CF6-80A	AR	1
9329M87P03	RETAINER	CF6-80C2, CF6-80A	AR	1
9329M87P03	RETAINER	CF6-80C2, CF6-80A	AR	1
9329M87P03	RETAINER	CF6-80C2, CF6-80A	SV	1
9329M87P03	RETAINER	CF6-80C2, CF6-80A	AR	1
9329M87P03	RETAINER	CF6-80C2, CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9329M87P03	RETAINER	CF6-80C2, CF6-80A	AR	1
9329M87P03	RETAINER	CF6-80C2, CF6-80A	AR	1
9329M87P03	RETAINER	CF6-80C2, CF6-80A	AR	1
9329M93P01	KEY - CPRSR ANTIROTATION	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9329M93P01	KEY - CPRSR ANTIROTATION	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9329M93P01	KEY - CPRSR ANTIROTATION	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9329M93P01	KEY - CPRSR ANTIROTATION	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	4
9329M93P01	KEY - CPRSR ANTIROTATION	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9330M10G01	BRACKET - CLAMP	CF6-80A	NE	1
9330M13P001A	BRACKET	CF6-80A	NE	1
9330M13P001A	BRACKET	CF6-80A	SV	1
9330M13P001A	BRACKET	CF6-80A	NS	2
9330M13P001A	BRACKET	CF6-80A	NE	1
9330M32G01	COVER	CF6-80A	NE	1
9330M46P001A	BRACKET	CF6-80A	AR	1
9330M47P001A	BRACKET	CF6-80A	AR	4
9331M24G01	SEAL - PRESS BAL	CF6-80A	AR	1
9331M25G01	SEAL - ROTATING	CF6-80A	SV	1
9331M25G02	SEAL - ROTATING	CF6-80A	AR	1
9331M25G06	SEAL - ROTATING	CF6-80A	AR	1
9331M25G06	SEAL - ROTATING	CF6-80A	OH	1
9331M25G06	SEAL - ROTATING	CF6-80A	OH	1
9331M27P05	SHAFT - TORQUE CONE	CF6-80A	OH	1
9331M27P06	SHAFT - TORQUE CONE	CF6-80A	OH	1
9331M35P02	BRACKET - COVER	CF6-80A	AR	12
9331M35P02	BRACKET - COVER	CF6-80A	AR	6
9331M35P02	BRACKET - COVER	CF6-80A	OH	10
9331M35P02	BRACKET - COVER	CF6-80A	AR	8
9331M35P02	BRACKET - COVER	CF6-80A	AR	12
9331M36G02	BRACKET - FWD	CF6-80A	OH	1
9331M37P01	SEAL - FAN BLADE	CF6-80A	NE	1
9331M37P01	SEAL - FAN BLADE	CF6-80A	NE	1
9331M42P01	SPACER - SLEEVE	CF6-50	SV	1
9331M54G02	SHROUD - SUPPORT HPT	CF6-80A	SV	1
9331M54G02	SHROUD - SUPPORT HPT	CF6-80A	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
9331M54G02	SHROUD - SUPPORT HPT	CF6-80A	OH	1
9331M54G02	SHROUD - SUPPORT HPT	CF6-80A	OH	1
9331M54G02	SHROUD - SUPPORT HPT	CF6-80A	OH	1
9331M54G02	SHROUD - SUPPORT HPT	CF6-80A	OH	1
9331M54G02	SHROUD - SUPPORT HPT	CF6-80A	OH	1
9331M76G02	ADAPTER - IDLER AGB	CF6-80C2	AR	1
9331M76G02	ADAPTER - IDLER AGB	CF6-80C2	AR	1
9331M84G01	NOZZLE - OIL	CF6-80C2	AR	1
9331M84G01	NOZZLE - OIL	CF6-80C2	OH	1
9331M84G01	NOZZLE - OIL	CF6-80C2	OH	1
9331M84G01	NOZZLE - OIL	CF6-80C2	OH	1
9333M80P01	RETAINER	CF6-80C2	NE	2
9333M94P001B	COVER - HEAT SHIELD R/S	CF6-80C2	SV	1
9333M96G07	BRACKET	CF6-80C2	SV	1
9333M96G07	BRACKET	CF6-80C2	SV	1
9333M96G07	BRACKET	CF6-80C2	OH	1
9333M97P001A	COVER - HEAT SHIELD R/S	CF6-80C2	SV	1
9333M98G01	BRACKET	CF6-80C2	SV	1
9344M35P001A	BRACKET	CF6-80A	SV	2
9344M37G01	TUBE - AIR HPT	CF6-80A	AR	1
9344M37G01	TUBE - AIR HPT	CF6-80A	AR	1
9344M39G01	TUBE - AIR	CF6-80A	AR	1
9344M39G01	TUBE - AIR	CF6-80A	AR	1
9344M44G01	TUBE - AIR	CF6-80A	AR	1
9344M70P02	PUSH ROD - ACTUATION LEVER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9344M84G01	TUBE - OIL	CF6-80A	AR	1
9344M84G01	TUBE - OIL	CF6-80A	AR	1
9344M93G02	TUBE - FUEL F/M TO COOLER	CF6-80A	AR	1
9344M93G02	TUBE - FUEL F/M TO COOLER	CF6-80A	AR	1
9345M45G01	HOSE - RETURN FUEL TUBE	CF6-80A	AR	1
9345M45G01	HOSE - RETURN FUEL TUBE	CF6-80A	AR	1
9346M36G15	LINER - SEGMENT AFT	CF6-80A	AR	1
9346M36G17	LINER - SEGMENT AFT	CF6-80A	AR	1
9346M36G20	LINER - SEGMENT AFT	CF6-80A	AR	1
9346M36G22	LINER - SEGMENT AFT	CF6-80A	AR	1
9346M59P01	COVER	CF6-80C2, CF6-80A	NE	3
9346M80P02	COLLAR - SPLIT NUT BRG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9346M80P02	COLLAR - SPLIT NUT BRG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9346M80P02	COLLAR - SPLIT NUT BRG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9346M80P02	COLLAR - SPLIT NUT BRG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9346M80P02	COLLAR - SPLIT NUT BRG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9346M80P02	COLLAR - SPLIT NUT BRG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9346M80P02	COLLAR - SPLIT NUT BRG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9346M80P02	COLLAR - SPLIT NUT BRG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9346M80P02	COLLAR - SPLIT NUT BRG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9346M80P02	COLLAR - SPLIT NUT BRG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9346M99P01	LINK - SIDE	CF6-50 (LMCO)	AR	1
9346M99P01	LINK - SIDE	CF6-50 (LMCO)	OH	1
9346M99P01	LINK - SIDE	CF6-50 (LMCO)	OH	1
9346M99P01	LINK - SIDE	CF6-50 (LMCO)	AR	1
9346M99P01	LINK - SIDE	CF6-50 (LMCO)	AR	1
9346M99P01	LINK - SIDE	CF6-50 (LMCO)	OH	1
9346M99P01	LINK - SIDE	CF6-50 (LMCO)	OH	1
9346M99P02	LINK - SIDE	CF6-80A, CF6-50 (LMCO)	OH	1
9346M99P04	LINK - SIDE	CF6-50 (LMCO)	OH	1
9347M18P01	RETAINER - BLANKET INSUL	CF6-80A	AR	1
9347M18P01	RETAINER - BLANKET INSUL	CF6-80A	AR	1
9347M18P01	RETAINER - BLANKET INSUL	CF6-80A	AR	1
9347M18P01	RETAINER - BLANKET INSUL	CF6-80A	AR	1
9347M18P01	RETAINER - BLANKET INSUL	CF6-80A	OH	1
9348M21G01	SCOOP ASSY - LINER AND	CF6-80A	AR	1
9348M61P01	BEAM - LWR RR MOUNT	CF6-80C2	AR	1
9348M79G02	LINK ASSY - LH MOUNT	CF6-80C2	NE	1
9348M83G01	BRACKET - LPT RS	CF6-80A	SV	1
9348M83G02	BRACKET - LPT RS	CF6-80A	AR	1
9348M83G02	BRACKET - LPT RS	CF6-80A	NS	1
9348M84G02	LINK ASSY - RH MOUNT	CF6-80C2	NE	1
9348M84G03	LINK ASSY - RH MOUNT	CF6-80C2	SV	1
9348M85P02	SPACER - IMPELLER	CF6-50	AR	1
9349M26G01	CASE - LPTS FWD	CF6-80A	OH	1
9349M26G01	CASE - LPTS FWD	CF6-80A	AR	1
9349M26G01	CASE - LPTS FWD	CF6-80A	AR	1
9349M26G01	CASE - LPTS FWD	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9349M26G03	CASE - LPTS FWD	CF6-80A	AR	1
9349M26G03	CASE - LPTS FWD	CF6-80A	OH	1
9349M29P01	SPACER	CF6-80A	SV	8
9349M29P01	SPACER	CF6-80A	NS	5
9349M29P01	SPACER	CF6-80A	NS	1
9349M30P01	SPACER	CF6-80A	AR	1
9349M30P01	SPACER	CF6-80A	AR	1
9349M30P01	SPACER	CF6-80A	SV	3
9349M37P03	SEAL - CHEVRON	CF6-80A	NE	1
9349M37P03	SEAL - CHEVRON	CF6-80A	NE	1
9349M57G01	SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	NS	8
9349M57G02	SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9349M73P02	CLEVIS - ACTUATION LEVER	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	7
9349M73P02	CLEVIS - ACTUATION LEVER	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
9349M73P02	CLEVIS - ACTUATION LEVER	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9349M73P02	CLEVIS - ACTUATION LEVER	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9349M73P02	CLEVIS - ACTUATION LEVER	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9349M73P02	CLEVIS - ACTUATION LEVER	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	5
9349M73P02	CLEVIS - ACTUATION LEVER	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	10
9349M73P02	CLEVIS - ACTUATION LEVER	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	1

Part Number	Part Description	Engine Type	Condition	Quantity
9349M73P02	CLEVIS - ACTUATION LEVER	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9349M90G03	HOUSING ASSY - MAIN	CF6-80A	OH	1
9349M90G03	HOUSING ASSY - MAIN	CF6-80A	OH	1
9349M90G03	HOUSING ASSY - MAIN	CF6-80A	OH	1
9349M91P04	DISK - HPC STG 14	CF6-50	AR	1
9349M97P01	SEAL - CARBON	CF6-80A	NE	1
9350M10P003A	BRACKET	CF6-80A	NS	1
9350M10P003A	BRACKET	CF6-80A	NS	1
9350M11P001A	BRACKET	CF6-80A	AR	1
9350M11P005A	BRACKET	CF6-80A	NE	2
9350M11P005A	BRACKET	CF6-80A	SV	1
9350M12P001A	BRACKET	CF6-80A	NS	1
9350M12P001A	BRACKET	CF6-80A	NS	1
9350M13G01	BRACKET	CF6-80A	AR	1
9350M13G01	BRACKET	CF6-80A	NS	1
9350M13G01	BRACKET	CF6-80A	NS	1
9350M16P003A	BRACKET	CF6-80A	OH	1
9350M16P003A	BRACKET	CF6-80A	SV	1
9350M16P003A	BRACKET	CF6-80A	SV	1
9350M18P001A	BRACKET	CF6-80A	SV	1
9350M18P001A	BRACKET	CF6-80A	SV	4
9350M18P001A	BRACKET	CF6-80A	SV	1
9350M19P001A	BRACKET	CF6-80A	SV	1
9350M31P001A	BRACKET	CF6-80A	SV	1
9350M35G01	BRACKET	CF6-80A	AR	1
9350M35G01	BRACKET	CF6-80A	AR	1
9350M35G01	BRACKET	CF6-80A	SV	1
9350M37P001A	BRACKET	CF6-80A	SV	1
9350M39P001A	BRACKET	CF6-80A	AR	1
9350M40G01	BRACKET	CF6-80A	OH	1
9350M41G01	BRACKET	CF6-80A	OH	1
9350M41G01	BRACKET	CF6-80A	NS	1
9350M45P001A	BRACKET - LOWER	CF6-50 (LMCO)	NE	1
9350M48G01	TUBE - EDUCTOR AFT	CF6-80A	OH	1
9350M48G01	TUBE - EDUCTOR AFT	CF6-80A	OH	1
9350M68G01JSE	FLEX COUPLING	CF6-80A	NE	1
9350M71G01	TUBE - AIR	CF6-80A	AR	1
9350M73G02	MANIFOLD - AIR COOLING	CF6-80A	SV	1
9350M73G02	MANIFOLD - AIR COOLING	CF6-80A	AR	1
9351M50P03	SWITCH - POSITION	CF6-80A	AR	1
9351M50P03	SWITCH - POSITION	CF6-80A	AR	1
9351M66G01	TUBE - OIL PUMP	CF6-80A	AR	1
9351M66G01	TUBE - OIL PUMP	CF6-80A	AR	1
9351M86P001A	BRACKET - FLAT	CF6-80A	SV	1
9351M87G03	BRACKET - AIR B SUMP	CF6-80A	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
9352M23G01	BRACKET - TRAY RS	CF6-50 (LMCO)	AR	1
9352M23G01	BRACKET - TRAY RS	CF6-50 (LMCO)	AR	1
9352M25G01	BRACKET - VIBRATION	CF6-50	AR	1
9352M41P08	DOUBLER	CF6-50	NS	2
9352M41P08	DOUBLER	CF6-50	NS	15
9352M45G01	BRACKET	CF6-80A	NS	1
9352M47G01	SLEEVE	CF6-80A	NS	1
9352M47G01	SLEEVE	CF6-80A	NE	1
9352M52G01	TUBE - OIL SCAVENGE	CF6-80A	AR	1
9352M52G01	TUBE - OIL SCAVENGE	CF6-80A	AR	1
9352M54G01	TUBE - D SCAVENGE	CF6-80A	AR	1
9352M54G01	TUBE - D SCAVENGE	CF6-80A	AR	1
9352M56G01	TUBE - C SCAVENGE	CF6-80A	AR	1
9352M56G02	TUBE - C SCAVENGE	CF6-80A	AR	1
9353M44P001A	BRACKET	CF6-80A	SV	3
9353M66P01	PLATE - COVER	CF6-80A	NS	2
9353M66P01	PLATE - COVER	CF6-80A	NS	2
9354M30G01	TUBE - HPT AIR	CF6-80A	AR	1
9354M30G01	TUBE - HPT AIR	CF6-80A	SV	1
9354M30G01	TUBE - HPT AIR	CF6-80A	SV	1
9354M30G01	TUBE - HPT AIR	CF6-80A	SV	1
9354M32G01	TUBE - AIR HPT RECOUP	CF6-80A	AR	1
9354M32G01	TUBE - AIR HPT RECOUP	CF6-80A	AR	1
9354M32G01	TUBE - AIR HPT RECOUP	CF6-80A	AR	1
9354M32G01	TUBE - AIR HPT RECOUP	CF6-80A	AR	1
9354M32G01	TUBE - AIR HPT RECOUP	CF6-80A	AR	1
9354M35G01	TUBE - AIR HP RECOUP UPPER	CF6-80A	AR	1
9354M35G01	TUBE - AIR HP RECOUP UPPER	CF6-80A	AR	1
9354M35G01	TUBE - AIR HP RECOUP UPPER	CF6-80A	AR	1
9354M35G01	TUBE - AIR HP RECOUP UPPER	CF6-80A	AR	1
9354M35G01	TUBE - AIR HP RECOUP UPPER	CF6-80A	OH	1
9354M37G01	ELBOW - HP RECOUP	CF6-80A	AR	1
9354M37G01	ELBOW - HP RECOUP	CF6-80A	AR	1
9354M37G01	ELBOW - HP RECOUP	CF6-80A	AR	1
9354M37G01	ELBOW - HP RECOUP	CF6-80A	AR	1
9354M37G01	ELBOW - HP RECOUP	CF6-80A	AR	1
9354M37G01	ELBOW - HP RECOUP	CF6-80A	AR	2
9354M37G01	ELBOW - HP RECOUP	CF6-80A	SV	1
9354M37G01	ELBOW - HP RECOUP	CF6-80A	SV	1
9354M37G01	ELBOW - HP RECOUP	CF6-80A	SV	1
9354M37G01	ELBOW - HP RECOUP	CF6-80A	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
9354M37G01	ELBOW - HP RECOUP	CF6-80A	SV	2
9354M37G01	ELBOW - HP RECOUP	CF6-80A	SV	1
9354M37G01	ELBOW - HP RECOUP	CF6-80A	SV	1
9354M37G01	ELBOW - HP RECOUP	CF6-80A	SV	1
9354M37G01	ELBOW - HP RECOUP	CF6-80A	SV	1
9354M37G01	ELBOW - HP RECOUP	CF6-80A	SV	1
9354M37G01	ELBOW - HP RECOUP	CF6-80A	AR	1
9354M37G01	ELBOW - HP RECOUP	CF6-80A	AR	1
9354M37G01	ELBOW - HP RECOUP	CF6-80A	AR	2
9354M38G01	TUBE - AIR RECOUP LOWER	CF6-80A	OH	1
9354M38G01	TUBE - AIR RECOUP LOWER	CF6-80A	AR	1
9354M38G01	TUBE - AIR RECOUP LOWER	CF6-80A	AR	1
9354M38G01	TUBE - AIR RECOUP LOWER	CF6-80A	AR	1
9354M38G01	TUBE - AIR RECOUP LOWER	CF6-80A	AR	1
9354M43G01	MANIFOLD - AIR	CF6-80A	AR	1
9354M43G01	MANIFOLD - AIR	CF6-80A	AR	1
9354M43G01	MANIFOLD - AIR	CF6-80A	AR	1
9354M43G01	MANIFOLD - AIR	CF6-80A	AR	1
9354M43G02	MANIFOLD - AIR	CF6-80A	AR	1
9354M43G02	MANIFOLD - AIR	CF6-80A	AR	1
9354M43G02	MANIFOLD - AIR	CF6-80A	SV	1
9354M43G02	MANIFOLD - AIR	CF6-80A	SV	1
9354M43G02	MANIFOLD - AIR	CF6-80A	OH	1
9354M49P01	RETAINER	CF6-80A	AR	1
9354M49P01	RETAINER	CF6-80A	AR	1
9354M56P001A	BRACKET	CF6-80A	NS	1
9354M79G01	BRACKET - ANGLE	CF6-80A	AR	1
9354M81G01	BRACKET - RETAINER	CF6-80A	AR	1
9354M87G01	TUBE - AIR LPT COOL	CF6-80A	AR	1
9354M87G01	TUBE - AIR LPT COOL	CF6-80A	AR	1
9354M87G01	TUBE - AIR LPT COOL	CF6-80A	AR	1
9354M87G01	TUBE - AIR LPT COOL	CF6-80A	AR	1
9354M87G01	TUBE - AIR LPT COOL	CF6-80A	OH	1
9354M89G01	TUBE - AIR HP RECOUP UPPER	CF6-80A	AR	1
9354M89G01	TUBE - AIR HP RECOUP UPPER	CF6-80A	AR	1
9354M91G01	TUBE - AIR	CF6-80A	AR	1
9354M91G01	TUBE - AIR	CF6-80A	AR	1
9354M93G02	TUBE - AIR	CF6-80A	AR	1
9354M93G02	TUBE - AIR	CF6-80A	AR	1
9354M98P001A	BRACKET	CF6-80A	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
9355M20G02	TUBE - OIL TANK OUTLET FWD	CF6-80A	AR	1
9355M20G02	TUBE - OIL TANK OUTLET FWD	CF6-80A	AR	1
9355M20G02	TUBE - OIL TANK OUTLET FWD	CF6-80A	AR	1
9355M20G02	TUBE - OIL TANK OUTLET FWD	CF6-80A	AR	1
9355M35P001A	BRACKET - TUBE ANTI-ICE FWD	CF6-50 (LMCO)	NS	1
9355M36G03	BRACKET	CF6-80A	AR	1
9355M36G03	BRACKET	CF6-80A	AR	1
9355M36G03	BRACKET	CF6-80A	AR	1
9355M37P001A	BRACKET	CF6-80A	AR	1
9355M38P001A	BRACKET	CF6-80A	AR	1
9355M38P001A	BRACKET	CF6-80A	AR	1
9355M38P001A	BRACKET	CF6-80A	AR	1
9355M39P001A	BRACKET	CF6-80A	AR	3
9355M39P001A	BRACKET	CF6-80A	AR	2
9355M39P001A	BRACKET	CF6-80A	AR	1
9355M39P001A	BRACKET	CF6-80A	AR	1
9355M40G01	BRACKET	CF6-80A	AR	1
9355M40G01	BRACKET	CF6-80A	AR	1
9355M40G01	BRACKET	CF6-80A	AR	1
9355M41G01	TUBE - FUEL	CF6-80A	AR	1
9355M41G01	TUBE - FUEL	CF6-80A	AR	1
9355M41G01	TUBE - FUEL	CF6-80A	SV	1
9355M83G01	MANIFOLD - FUEL	CF6-80A	AR	1
9356M16P05	BEARING - RLR NO. 6R	CF6-80C2	AR	1
9356M16P05	BEARING - RLR NO. 6R	CF6-80C2	AR	1
9356M34G02	RING - IMPING STG 2 HPT NOZ	CF6-80A	AR	1
9356M34G02	RING - IMPING STG 2 HPT NOZ	CF6-80A	AR	1
9356M34G02	RING - IMPING STG 2 HPT NOZ	CF6-80A	AR	1
9356M34G02	RING - IMPING STG 2 HPT NOZ	CF6-80A	AR	1
9356M34G02	RING - IMPING STG 2 HPT NOZ	CF6-80A	AR	1
9356M34G02	RING - IMPING STG 2 HPT NOZ	CF6-80A	SV	1
9356M34G02	RING - IMPING STG 2 HPT NOZ	CF6-80A	SV	1
9356M34G02	RING - IMPING STG 2 HPT NOZ	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9356M34G02	RING - IMPING STG 2 HPT NOZ	CF6-80A	OH	1
9356M34G02	RING - IMPING STG 2 HPT NOZ	CF6-80A	OH	1
9356M46P03	SPACER - IMPELLER	CF6-80A	AR	1
9356M52G01	BRACKET - LPT COOLING	CF6-80A	NS	9
9356M52G01	BRACKET - LPT COOLING	CF6-80A	NS	1
9356M54G01	TUBE	CF6-80A	AR	1
9356M54G01	TUBE	CF6-80A	AR	1
9356M65P01	RETAINER - HPTR BLADE STG 2	CF6-80C2, CF6-80A	AR	1
9356M65P01	RETAINER - HPTR BLADE STG 2	CF6-80C2, CF6-80A	SV	1
9356M65P01	RETAINER - HPTR BLADE STG 2	CF6-80C2, CF6-80A	SV	1
9356M65P01	RETAINER - HPTR BLADE STG 2	CF6-80C2, CF6-80A	AR	1
9356M65P01	RETAINER - HPTR BLADE STG 2	CF6-80C2, CF6-80A	AR	1
9356M65P01	RETAINER - HPTR BLADE STG 2	CF6-80C2, CF6-80A	AR	1
9356M65P01	RETAINER - HPTR BLADE STG 2	CF6-80C2, CF6-80A	AR	1
9356M65P01	RETAINER - HPTR BLADE STG 2	CF6-80C2, CF6-80A	AR	1
9356M65P01	RETAINER - HPTR BLADE STG 2	CF6-80C2, CF6-80A	AR	1
9356M65P01	RETAINER - HPTR BLADE STG 2	CF6-80C2, CF6-80A	OH	1
9356M65P02	RETAINER - HPTR BLADE STG 2	CF6-80C2, CF6-80A	AR	1
9356M65P02	RETAINER - HPTR BLADE STG 2	CF6-80C2, CF6-80A	OH	1
9356M65P02	RETAINER - HPTR BLADE STG 2	CF6-80C2, CF6-80A	OH	1
9356M78P02	HPT NOZZLE STG 2 SEAL RING	CF6-80C2	AR	1
9356M78P02	HPT NOZZLE STG 2 SEAL RING	CF6-80C2	AR	1
9356M82G01	FRAME ASSY - TURB REAR	CF6-80A	AR	1
9356M82G01	FRAME ASSY - TURB REAR	CF6-80A	AR	1
9356M82G01	FRAME ASSY - TURB REAR	CF6-80A	AR	1
9356M82G01	FRAME ASSY - TURB REAR	CF6-80A	AR	1
9356M89G01	COVER - WINDAGE AFT	CF6-80A	AR	1
9356M89G02	COVER - WINDAGE AFT	CF6-80A	AR	1
9356M89G02	COVER - WINDAGE AFT	CF6-80A	AR	1
9356M89G03	COVER - WINDAGE AFT	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9356M89G05	COVER - WINDAGE AFT	CF6-80A	OH	1
9356M89G09	COVER - WINDAGE AFT	CF6-80A	AR	1
9356M89G09	COVER - WINDAGE AFT	CF6-80A	AR	1
9356M89G10	COVER - WINDAGE AFT	CF6-80A	AR	1
9356M89G10	COVER - WINDAGE AFT	CF6-80A	NE	2
9357M40G01	SEAL - PRESS BAL	CF6-80A	AR	1
9357M40G01	SEAL - PRESS BAL	CF6-80A	AR	1
9357M40G01	SEAL - PRESS BAL	CF6-80A	OH	1
9357M40G01	SEAL - PRESS BAL	CF6-80A	OH	1
9357M40G01	SEAL - PRESS BAL	CF6-80A	AR	1
9357M64G04	SEAL - STA P/B	CF6-80A	OH	1
9357M99G01	SPANNER - NUT	CF6-80A	AR	1
9357M99G01	SPANNER - NUT	CF6-80A	AR	1
9357M99G01	SPANNER - NUT	CF6-80A	AR	1
9357M99G01	SPANNER - NUT	CF6-80A	AR	1
9357M99G01	SPANNER - NUT	CF6-80A	AR	1
9357M99G01	SPANNER - NUT	CF6-80A	OH	1
9358M10G01	BRACKET	CF6-80A	AR	1
9358M10G01	BRACKET	CF6-80A	AR	1
9358M10G01	BRACKET	CF6-80A	SV	1
9358M10G01	BRACKET	CF6-80A	SV	1
9358M10G03	BRACKET	CF6-80A	AR	1
9358M10G03	BRACKET	CF6-80A	AR	1
9358M10G03	BRACKET	CF6-80A	SV	1
9358M16P001B	BRACKET	CF6-80A	AR	1
9358M16P001B	BRACKET	CF6-80A	NS	1
9358M27G01	BRACKET	CF6-50 (LMCO)	AR	1
9358M27G01	BRACKET	CF6-50 (LMCO)	AR	1
9358M27G01	BRACKET	CF6-50 (LMCO)	AR	1
9358M43G03	BRACKET	CF6-80A	AR	1
9358M43G03	BRACKET	CF6-80A	AR	1
9358M43G03	BRACKET	CF6-80A	OH	1
9358M48G01	TUBE	CF6-80A	AR	1
9358M48G01	TUBE	CF6-80A	AR	1
9358M56G01	MANIFOLD - OIL LUBE	CF6-80A	AR	1
9358M56G01	MANIFOLD - OIL LUBE	CF6-80A	AR	1
9358M60G01	BRACKET	CF6-80A	NE	1
9358M60G01	BRACKET	CF6-80A	SV	1
9358M60G01	BRACKET	CF6-80A	NE	4
9358M79G01	BRACKET	CF6-80A	AR	1
9358M79G01	BRACKET	CF6-80A	SV	1
9359M10P001A	BRACKET	CF6-80A	NS	1
9359M11P001A	BRACKET	CF6-80A	NE	1
9359M11P001A	BRACKET	CF6-80A	NS	6
9359M12P001A	BRACKET	CF6-80A	AR	1
9359M12P001A	BRACKET	CF6-80A	NE	1
9359M56P001A	BRACKET	CF6-80A	SV	1
9359M69G01	TUBE - OIL LUBE	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9359M69G01	TUBE - OIL LUBE	CF6-80A	AR	1
9359M91G01	TUBE - OIL	CF6-80A	AR	1
9360M14G01	TUBE - DRAIN	CF6-50 (LMCO)	OH	1
9360M14G01	TUBE - DRAIN	CF6-50 (LMCO)	OH	1
9360M14G01	TUBE - DRAIN	CF6-50 (LMCO)	AR	1
9360M14G01	TUBE - DRAIN	CF6-50 (LMCO)	AR	1
9360M14G01	TUBE - DRAIN	CF6-50 (LMCO)	AR	1
9360M14G01	TUBE - DRAIN	CF6-50 (LMCO)	AR	1
9360M61G01	BRACKET - ACCELEROMETER	CF6-80C2, CF6-80A	AR	1
9360M85G01	TUBE - VSV ROD END	CF6-80A	OH	1
9360M85G01	TUBE - VSV ROD END	CF6-80A	OH	1
9360M85G01	TUBE - VSV ROD END	CF6-80A	OH	1
9360M85G01	TUBE - VSV ROD END	CF6-80A	OH	1
9360M87G01	TUBE - VSV HEAD END	CF6-80A	AR	1
9360M87G01	TUBE - VSV HEAD END	CF6-80A	OH	1
9360M87G01	TUBE - VSV HEAD END	CF6-80A	OH	1
9360M91G01	BRACKET	CF6-80A	AR	1
9360M92G01	BRACKET - STG 1	CF6-80A	AR	1
9360M92G01	BRACKET - STG 1	CF6-80A	AR	1
9360M92G01	BRACKET - STG 1	CF6-80A	SV	1
9360M94G01	BRACKET	CF6-80A	OH	1
9360M94G01	BRACKET	CF6-80A	AR	1
9360M95G01	RETAINER	CF6-80A	AR	1
9360M95G02	RETAINER	CF6-80A	SV	1
9361M22G01	TUBE - AIR	CF6-80A	AR	1
9361M26G02	MANIFOLD - AIR	CF6-80A	AR	1
9361M26G02	MANIFOLD - AIR	CF6-80A	AR	1
9361M27G01	MANIFOLD - AIR	CF6-80A	AR	1
9361M27G01	MANIFOLD - AIR	CF6-80A	AR	1
9361M33G01	BRACKET	CF6-80A	AR	1
9361M34G01	TUBE - OIL TANK	CF6-80A	AR	1
9361M34G01	TUBE - OIL TANK	CF6-80A	AR	1
9361M34G01	TUBE - OIL TANK	CF6-80A	AR	1
9361M34G01	TUBE - OIL TANK	CF6-80A	AR	1
9361M34G01	TUBE - OIL TANK	CF6-80A	AR	1
9361M36G01	TUBE - OIL TANK	CF6-80A	AR	1
9361M36G01	TUBE - OIL TANK	CF6-80A	AR	1
9361M39G01	DUCT - COMP COOLING AFT	CF6-80A	SV	1
9361M42P001A	BRACKET	CF6-80A	AR	1
9361M42P001A	BRACKET	CF6-80A	AR	1
9361M62G01	TUBE - OIL VENT	CF6-80A	AR	1
9361M62G01	TUBE - OIL VENT	CF6-80A	AR	1
9361M62G01	TUBE - OIL VENT	CF6-80A	OH	1
9361M62G01	TUBE - OIL VENT	CF6-80A	OH	1
9361M72G01	MANIFOLD - AIR LPT	CF6-80A	SV	1
9361M72G01	MANIFOLD - AIR LPT	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9361M72G01	MANIFOLD - AIR LPT	CF6-80A	OH	1
9361M72G01	MANIFOLD - AIR LPT	CF6-80A	AR	1
9361M72G01	MANIFOLD - AIR LPT	CF6-80A	AR	1
9361M72G02	MANIFOLD - AIR LPT	CF6-80A	AR	1
9361M72G02	MANIFOLD - AIR LPT	CF6-80A	AR	1
9361M72G02	MANIFOLD - AIR LPT	CF6-80A	OH	1
9361M72G02	MANIFOLD - AIR LPT	CF6-80A	SV	1
9361M72G02	MANIFOLD - AIR LPT	CF6-80A	SV	1
9361M72G02	MANIFOLD - AIR LPT	CF6-80A	OH	1
9361M72G02	MANIFOLD - AIR LPT	CF6-80A	SV	1
9361M72G02	MANIFOLD - AIR LPT	CF6-80A	SV	1
9361M74G01	BRACKET	CF6-80A	AR	1
9361M75G01	MANIFOLD - AIR LPT	CF6-80A	AR	1
9361M75G01	MANIFOLD - AIR LPT	CF6-80A	AR	1
9361M75G01	MANIFOLD - AIR LPT	CF6-80A	AR	1
9361M75G01	MANIFOLD - AIR LPT	CF6-80A	AR	1
9361M98P01	VALVE - COOLING AIR	CF6-80A	AR	1
9361M98P01	VALVE - COOLING AIR	CF6-80A	AR	1
9361M98P01	VALVE - COOLING AIR	CF6-80A	AR	1
9361M98P01	VALVE - COOLING AIR	CF6-80A	OH	1
9362M12G01	HOUSING ASSY - SUMP AFT	CF6-80A	OH	1
9362M12G01	HOUSING ASSY - SUMP AFT	CF6-80A	OH	1
9362M12G01	HOUSING ASSY - SUMP AFT	CF6-80A	OH	1
9362M12G01	HOUSING ASSY - SUMP AFT	CF6-80A	OH	1
9362M12G01	HOUSING ASSY - SUMP AFT	CF6-80A	OH	1
9362M14P01	RING - RETAINING	CF6-80A	OH	1
9362M14P01	RING - RETAINING	CF6-80A	AR	1
9362M14P01	RING - RETAINING	CF6-80A	SV	1
9362M26P01	CAGE - ROTATING	CF6-80A	AR	1
9362M26P01	CAGE - ROTATING	CF6-80A	AR	1
9362M26P01	CAGE - ROTATING	CF6-80A	AR	1
9362M26P01	CAGE - ROTATING	CF6-80A	AR	1
9362M26P01	CAGE - ROTATING	CF6-80A	AR	1
9362M26P01	CAGE - ROTATING	CF6-80A	AR	1
9362M26P01	CAGE - ROTATING	CF6-80A	OH	1
9362M31G02	SLINGER - OIL BRG NO. 6	CF6-80A	NE	1
9362M31G02	SLINGER - OIL BRG NO. 6	CF6-80A	AR	1
9362M31G02	SLINGER - OIL BRG NO. 6	CF6-80A	SV	1
9362M31G02	SLINGER - OIL BRG NO. 6	CF6-80A	AR	1
9362M31G02	SLINGER - OIL BRG NO. 6	CF6-80A	AR	1
9362M31G02	SLINGER - OIL BRG NO. 6	CF6-80A	AR	1
9362M31G02	SLINGER - OIL BRG NO. 6	CF6-80A	AR	1
9362M32G01	COVER - AFT BRG NO. 6	CF6-80A	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9362M32G01	COVER - AFT BRG NO. 6	CF6-80A	AR	1
9362M32G01	COVER - AFT BRG NO. 6	CF6-80A	AR	1
9362M32G01	COVER - AFT BRG NO. 6	CF6-80A	AR	1
9362M35P01	SPACER	CF6-80A	NE	1
9362M35P01	SPACER	CF6-80A	OH	1
9362M36G01	PLUG - BRG NO. 6	CF6-80C2, CF6-80A	AR	1
9362M51G03	CASE - FAN FORWARD	CF6-80A	AR	1
9362M80P01	NOZZLE - OIL	CF6-80C2, CF6-80A	AR	1
9362M88G01	SHROUD - PAD	CF6-80A	NE	1
9362M90P01	SHROUD - LUG	CF6-80A	NE	1
9362M91G01	SHROUD - INNER STG 1	CF6-80A	SV	1
9362M91G01	SHROUD - INNER STG 1	CF6-80A	AR	1
9362M91G01	SHROUD - INNER STG 1	CF6-80A	AR	1
9362M91G01	SHROUD - INNER STG 1	CF6-80A	AR	1
9362M91G01	SHROUD - INNER STG 1	CF6-80A	AR	1
9362M91G01	SHROUD - INNER STG 1	CF6-80A	AR	1
9362M91G01	SHROUD - INNER STG 1	CF6-80A	AR	1
9362M91G01	SHROUD - INNER STG 1	CF6-80A	AR	1
9362M91G01	SHROUD - INNER STG 1	CF6-80A	OH	1
9362M92G01	SHROUD - INNER STG 2	CF6-80A	AR	1
9362M92G01	SHROUD - INNER STG 2	CF6-80A	AR	1
9362M92G01	SHROUD - INNER STG 2	CF6-80A	OH	1
9362M92G01	SHROUD - INNER STG 2	CF6-80A	OH	1
9362M92G01	SHROUD - INNER STG 2	CF6-80A	OH	1
9362M92G01	SHROUD - INNER STG 2	CF6-80A	OH	1
9362M92G01	SHROUD - INNER STG 2	CF6-80A	OH	1
9362M92G01	SHROUD - INNER STG 2	CF6-80A	OH	1
9362M93G01	SHROUD - INNER STG 3	CF6-80A	AR	1
9362M93G01	SHROUD - INNER STG 3	CF6-80A	AR	1
9362M93G01	SHROUD - INNER STG 3	CF6-80A	AR	1
9362M93G01	SHROUD - INNER STG 3	CF6-80A	AR	1
9362M93G01	SHROUD - INNER STG 3	CF6-80A	AR	1
9362M93G01	SHROUD - INNER STG 3	CF6-80A	OH	1
9362M93G01	SHROUD - INNER STG 3	CF6-80A	OH	1
9363M12G01	PLATE - FIREWALL UPPER	CF6-80A	AR	1
9363M17G02	TUBE - FUEL VARIABLE	CF6-80A	AR	1
9363M17G02	TUBE - FUEL VARIABLE	CF6-80A	AR	1
9363M19G01	TUBE ASSY - FUEL FWD HD END	CF6-80A	AR	1
9363M22P001A	BRACKET	CF6-80A	NE	1
9363M24G02	TUBE - OIL TRANSFER GEAR	CF6-80A	AR	1
9363M24G02	TUBE - OIL TRANSFER GEAR	CF6-80A	AR	1
9363M24G02	TUBE - OIL TRANSFER GEAR	CF6-80A	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9363M49G01	MANIFOLD - OIL	CF6-80A	AR	1
9363M49G01	MANIFOLD - OIL	CF6-80A	AR	1
9363M51P001A	BRACKET	CF6-80A	NS	1
9363M67G01	TUBE - OIL LUBE	CF6-80A	AR	1
9363M67G01	TUBE - OIL LUBE	CF6-80A	AR	1
9363M84G01	MANIFOLD - AIR CDP	CF6-80A	AR	1
9363M86G01	TUBE - FUEL SUPPLY	CF6-80A	AR	1
9363M86G01	TUBE - FUEL SUPPLY	CF6-80A	AR	1
9363M86G01	TUBE - FUEL SUPPLY	CF6-80A	AR	1
9363M86G01	TUBE - FUEL SUPPLY	CF6-80A	AR	1
9364M27G01	MANIFOLD - OIL	CF6-80A	AR	1
9364M27G01	MANIFOLD - OIL	CF6-80A	AR	1
9364M53G01	TUBE - FUEL (T2)	CF6-80A	AR	1
9364M53G01	TUBE - FUEL (T2)	CF6-80A	AR	1
9364M67G01	TUBE - AIR POC FWD	CF6-80A	AR	1
9364M67G01	TUBE - AIR POC FWD	CF6-80A	OH	1
9364M67G01	TUBE - AIR POC FWD	CF6-80A	OH	1
9364M69P03	TUBE - FUEL	CF6-80A	OH	1
9364M69P03	TUBE - FUEL	CF6-80A	OH	1
9364M69P03	TUBE - FUEL	CF6-80A	OH	1
9364M94G01	TUBE - OIL TANK VENT	CF6-80A	AR	1
9364M94G01	TUBE - OIL TANK VENT	CF6-80A	AR	1
9364M97P001A	BRACKET	CF6-80A	AR	1
9364M97P001A	BRACKET	CF6-80A	AR	1
9364M97P001A	BRACKET	CF6-80A	SV	1
9364M98P001A	BRACKET	CF6-80A	AR	1
9364M99P001A	BRACKET	CF6-80A	AR	1
9364M99P001A	BRACKET	CF6-80A	AR	1
9364M99P001A	BRACKET	CF6-80A	AR	2
9364M99P001A	BRACKET	CF6-80A	AR	1
9364M99P001A	BRACKET	CF6-80A	SV	1
9365M10P02	SUPPORT - BELLCRANK	CF6-80C2	AR	14
9365M22P01	COVER - PLATE AGB	CF6-80A	AR	1
9365M25P01	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	SV	3
9365M32P01	ADAPTER - GEARBOX	CF6-80A	OH	1
9365M32P01	ADAPTER - GEARBOX	CF6-80A	AR	1
9365M33P01	ADAPTER - GEARBOX	CF6-80A	AR	1
9365M33P01	ADAPTER - GEARBOX	CF6-80A	AR	1
9365M34P01	ADAPTER - GEARBOX	CF6-80A	AR	1
9365M35P01	ADAPTER - GEARBOX	CF6-80A	OH	1
9365M35P01	ADAPTER - GEARBOX	CF6-80A	OH	1
9365M40G01	SUPPORT - LINER OUTER	CF6-80A	AR	22
9365M40G01	SUPPORT - LINER OUTER	CF6-80A	AR	22
9365M40G01	SUPPORT - LINER OUTER	CF6-80A	SV	1
9365M40G01	SUPPORT - LINER OUTER	CF6-80A	SV	22
9365M40G01	SUPPORT - LINER OUTER	CF6-80A	AR	22
9365M40G01	SUPPORT - LINER OUTER	CF6-80A	NE	2

Part Number	Part Description	Engine Type	Condition	Quantity
9365M40G01	SUPPORT - LINER OUTER	CF6-80A	NE	2
9365M40G01	SUPPORT - LINER OUTER	CF6-80A	AR	22
9365M40G01	SUPPORT - LINER OUTER	CF6-80A	NE	10
9365M40G01	SUPPORT - LINER OUTER	CF6-80A	NE	13
9365M41P06	SEAL - O-RING	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9365M41P06	SEAL - O-RING	CF6-50 (LMCO), CF6-50 (Boeing)	NS	8
9365M41P15	SEAL - RING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	11
9365M41P15	SEAL - RING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9365M41P182	SEAL - O-RING	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9365M41P227	SEAL - RING	CF6-50 (LMCO), CF6-50 (Boeing)	NS	17
9365M41P229	SEAL - RING	CF6-50 (LMCO), CF6-50 (Boeing)	NS	16
9365M41P230	SEAL - RING	CF6-50 (LMCO)	NS	1
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	SV	44
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	1
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	AR	80
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	1
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	1
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	SV	3
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	SV	4
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	1
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	1
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	3
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	1
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	1
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	2
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	SV	3

Part Number	Part Description	Engine Type	Condition	Quantity
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	2
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	5
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	28
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	1
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	1
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	1
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	2
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	2
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	3
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	1
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	1
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	1
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	2
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	2
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	1
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	1
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	2
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	5
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	3
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	NS	1
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	SV	4
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	1
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	2
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	SV	2
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	3

Part Number	Part Description	Engine Type	Condition	Quantity
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	1
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	OH	3
9365M43P02	HPT ROTOR WINDAGE CUP STG 1	CF6-80C2, CF6-80A	SV	2
9365M47P01	SEAL - RING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9365M47P01	SEAL - RING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9365M47P01	SEAL - RING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9365M47P01	SEAL - RING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9365M55P01	SPACER - SPINNER	CF6-80A	NE	2
9365M55P01	SPACER - SPINNER	CF6-80A	NS	1
9365M65P01	SEAL - PYLON LOWER	CF6-80A	NE	2
9365M68G01	SEAL - AIR STA BRG NO. 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9365M68G01	SEAL - AIR STA BRG NO. 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9365M68G01	SEAL - AIR STA BRG NO. 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9365M68G01	SEAL - AIR STA BRG NO. 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9365M68G01	SEAL - AIR STA BRG NO. 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9365M68G01	SEAL - AIR STA BRG NO. 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9365M68G01	SEAL - AIR STA BRG NO. 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9365M68G01	SEAL - AIR STA BRG NO. 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9365M68G03	SEAL - AIR STA BRG NO. 3	CF6-50 (LMCO)	AR	1
9365M76G01	GEARSHAFT ASSY - INLET GRBX	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9365M76G01	GEARSHAFT ASSY - INLET GRBX	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9365M76G01	GEARSHAFT ASSY - INLET GRBX	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9365M76G01	GEARSHAFT ASSY - INLET GRBX	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9365M77P01	ADAPTER	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9366M17G01	TUBE - AIR PMC COOLING	CF6-80A	AR	1
9366M17G01	TUBE - AIR PMC COOLING	CF6-80A	AR	1
9366M17G01	TUBE - AIR PMC COOLING	CF6-80A	OH	1
9366M42G01	BRACKET	CF6-80A	AR	1
9366M42G01	BRACKET	CF6-80A	OH	1
9366M44G02	TUBE - EDUCTOR AFT	CF6-80A	AR	1
9366M44G02	TUBE - EDUCTOR AFT	CF6-80A	AR	1
9366M44G02	TUBE - EDUCTOR AFT	CF6-80A	AR	1
9366M44G02	TUBE - EDUCTOR AFT	CF6-80A	OH	1
9366M46G01	TUBE	CF6-80A	AR	1
9366M46G01	TUBE	CF6-80A	AR	1
9366M46G01	TUBE	CF6-80A	AR	1
9366M48G01	TUBE - AIR POC AFT	CF6-80A	AR	1
9366M48G01	TUBE - AIR POC AFT	CF6-80A	AR	1
9366M48G01	TUBE - AIR POC AFT	CF6-80A	AR	1
9366M48G01	TUBE - AIR POC AFT	CF6-80A	AR	1
9366M50G01	TUBE - AIR POC MID	CF6-80A	AR	1
9366M53G01	TUBE - FUEL	CF6-80A	SV	1
9366M55P001A	PLATE - COVER	CF6-80A	NS	1
9366M56G01	TUBE - AIR PMC	CF6-80A	AR	1
9366M60P01	TUBE - AIR	CF6-80A	AR	1
9366M64G01	TUBE - AIR	CF6-80A	AR	1
9366M64G01	TUBE - AIR	CF6-80A	AR	1
9366M72G01	TUBE	CF6-80A	AR	1
9366M74G01	TUBE	CF6-80A	AR	1
9366M76G01	TUBE ASSY - PMC	CF6-80A	AR	1
9366M76G01	TUBE ASSY - PMC	CF6-80A	AR	1
9366M77G01	TUBE - FUEL	CF6-80A	AR	1
9366M77G01	TUBE - FUEL	CF6-80A	AR	1
9366M77G01	TUBE - FUEL	CF6-80A	AR	1
9366M77G01	TUBE - FUEL	CF6-80A	AR	1
9366M77G01	TUBE - FUEL	CF6-80A	AR	1
9366M77G01	TUBE - FUEL	CF6-80A	AR	1
9366M79G01	TUBE - FUEL	CF6-80A	OH	1
9366M79G01	TUBE - FUEL	CF6-80A	OH	1
9366M79G01	TUBE - FUEL	CF6-80A	OH	1
9366M84P001A	BRACKET	CF6-80A	AR	1
9366M84P001A	BRACKET	CF6-80A	OH	1
9366M84P001A	BRACKET	CF6-80A	NE	1
9366M86G01	EDUCTOR - AIR PMC	CF6-80A	AR	1
9366M86G01	EDUCTOR - AIR PMC	CF6-80A	AR	1
9366M90P01	SEAL - SPLICE	CF6-80A	NS	1
9366M90P01	SEAL - SPLICE	CF6-80A	NS	1
9366M90P04	SEAL - SPLICE	CF6-80A	NS	1
9366M90P04	SEAL - SPLICE	CF6-80A	NS	1
9366M90P04	SEAL - SPLICE	CF6-80A	NS	1
9367M18P03	THERMOCOUPLE - EGT	CF6-80A	SV	1
9367M18P03	THERMOCOUPLE - EGT	CF6-80A	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
9367M20P01	SEAL - CARBON STG 7	CF6-80A	NS	10
9367M20P01	SEAL - CARBON STG 7	CF6-80A	NS	11
9367M20P01	SEAL - CARBON STG 7	CF6-80A	NS	11
9367M21G01	SHROUD - STG 1	CF6-80A	OH	3
9367M21G01	SHROUD - STG 1	CF6-80A	AR	10
9367M21G01	SHROUD - STG 1	CF6-80A	AR	10
9367M22G01	SHROUD - STG 2	CF6-80A	AR	13
9367M22G01	SHROUD - STG 2	CF6-80A	OH	1
9367M22G01	SHROUD - STG 2	CF6-80A	OH	3
9367M22G01	SHROUD - STG 2	CF6-80A	AR	7
9367M22G01	SHROUD - STG 2	CF6-80A	AR	20
9367M22G01	SHROUD - STG 2	CF6-80A	AR	4
9367M22G01	SHROUD - STG 2	CF6-80A	OH	4
9367M22G01	SHROUD - STG 2	CF6-80A	OH	1
9367M23G01	SHROUD - STG 3	CF6-80A	AR	1
9367M23G01	SHROUD - STG 3	CF6-80A	SV	17
9367M23G01	SHROUD - STG 3	CF6-80A	AR	24
9367M24G01	SHROUD - STG 4	CF6-80A	AR	15
9367M24G01	SHROUD - STG 4	CF6-80A	SV	7
9367M24G01	SHROUD - STG 4	CF6-80A	AR	16
9367M24G01	SHROUD - STG 4	CF6-80A	OH	1
9367M24G01	SHROUD - STG 4	CF6-80A	OH	1
9367M24G01	SHROUD - STG 4	CF6-80A	OH	1
9367M24G01	SHROUD - STG 4	CF6-80A	OH	1
9367M24G01	SHROUD - STG 4	CF6-80A	AR	24
9367M24G01	SHROUD - STG 4	CF6-80A	OH	12
9367M24G01	SHROUD - STG 4	CF6-80A	OH	4
9367M24G01	SHROUD - STG 4	CF6-80A	OH	4
9367M83P08	NOZZLE - LPT STG 3	CF6-80C2	SV	1
9367M83P08	NOZZLE - LPT STG 3	CF6-80C2	SV	1
9367M83P08	NOZZLE - LPT STG 3	CF6-80C2	SV	1
9367M83P08	NOZZLE - LPT STG 3	CF6-80C2	SV	1
9367M83P08	NOZZLE - LPT STG 3	CF6-80C2	AR	1
9367M83P08	NOZZLE - LPT STG 3	CF6-80C2	AR	1
9367M83P08	NOZZLE - LPT STG 3	CF6-80C2	AR	1
9367M83P08	NOZZLE - LPT STG 3	CF6-80C2	AR	1
9367M83P08	NOZZLE - LPT STG 3	CF6-80C2	AR	1
9367M83P08	NOZZLE - LPT STG 3	CF6-80C2	AR	1
9367M83P08	NOZZLE - LPT STG 3	CF6-80C2	AR	1
9367M83P08	NOZZLE - LPT STG 3	CF6-80C2	AR	1
9367M83P08	NOZZLE - LPT STG 3	CF6-80C2	AR	1
9367M83P08	NOZZLE - LPT STG 3	CF6-80C2	AR	1
9367M83P08	NOZZLE - LPT STG 3	CF6-80C2	AR	1
9367M83P08	NOZZLE - LPT STG 3	CF6-80C2	OH	1
9367M83P08	NOZZLE - LPT STG 3	CF6-80C2	OH	1
9367M83P08	NOZZLE - LPT STG 3	CF6-80C2	OH	1
9367M83P08	NOZZLE - LPT STG 3	CF6-80C2	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	SV	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	SV	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	SV	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	SV	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	SV	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	SV	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	AR	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	AR	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	AR	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	AR	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	AR	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	OH	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	OH	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	OH	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	OH	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	OH	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	OH	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	OH	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	AR	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	AR	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	AR	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	AR	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	AR	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	AR	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	AR	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	AR	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	AR	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	AR	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	AR	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	AR	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	AR	1
9367M84P37	NOZZLE - LPT STG 4	CF6-80C2	OH	1
9367M84P38	NOZZLE - LPT STG 4	CF6-80C2	SV	1
9367M84P38	NOZZLE - LPT STG 4	CF6-80C2	AR	1
9367M84P38	NOZZLE - LPT STG 4	CF6-80C2	AR	1
9367M84P38	NOZZLE - LPT STG 4	CF6-80C2	AR	1
9367M84P38	NOZZLE - LPT STG 4	CF6-80C2	OH	1
9367M84P38	NOZZLE - LPT STG 4	CF6-80C2	OH	1
9367M84P38	NOZZLE - LPT STG 4	CF6-80C2	OH	1
9367M85P08	NOZZLE - LPT STG 5	CF6-80C2	SV	1
9367M85P08	NOZZLE - LPT STG 5	CF6-80C2	AR	1
9367M85P10	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P10	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P10	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P10	NOZZLE - LPT STG 5	CF6-80C2	AR	1
9367M85P10	NOZZLE - LPT STG 5	CF6-80C2	AR	1
9367M85P10	NOZZLE - LPT STG 5	CF6-80C2	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9367M85P10	NOZZLE - LPT STG 5	CF6-80C2	AR	1
9367M85P10	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P13	NOZZLE - LPT STG 5	CF6-80C2	AR	1
9367M85P13	NOZZLE - LPT STG 5	CF6-80C2	AR	1
9367M85P13	NOZZLE - LPT STG 5	CF6-80C2	AR	1
9367M85P13	NOZZLE - LPT STG 5	CF6-80C2	AR	1
9367M85P13	NOZZLE - LPT STG 5	CF6-80C2	AR	1
9367M85P13	NOZZLE - LPT STG 5	CF6-80C2	AR	1
9367M85P13	NOZZLE - LPT STG 5	CF6-80C2	AR	1
9367M85P13	NOZZLE - LPT STG 5	CF6-80C2	AR	1
9367M85P13	NOZZLE - LPT STG 5	CF6-80C2	AR	1
9367M85P16	NOZZLE - LPT STG 5	CF6-80C2	OH	2
9367M85P16	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P16	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P16	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P16	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P24	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P24	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P24	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P24	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P24	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P24	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P24	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P24	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P24	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P24	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P24	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P24	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P24	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P24	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P24	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P24	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P24	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P24	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P24	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P24	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P24	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P24	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P26	NOZZLE - LPT STG 5	CF6-80C2	AR	1
9367M85P26	NOZZLE - LPT STG 5	CF6-80C2	AR	1
9367M85P26	NOZZLE - LPT STG 5	CF6-80C2	AR	1
9367M85P26	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P26	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P26	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P26	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P26	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M85P26	NOZZLE - LPT STG 5	CF6-80C2	OH	1
9367M90G16	CASE ASSEMBLY	CF6-80C2	OH	1
9368M15G01	BRACKET - CLEVIS STG 1	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9368M15G01	BRACKET - CLEVIS STG 1	CF6-80A	SV	1
9368M21G01	TUBE - AIR POC LOWER	CF6-80A	OH	1
9368M21G01	TUBE - AIR POC LOWER	CF6-80A	AR	1
9368M21G01	TUBE - AIR POC LOWER	CF6-80A	AR	1
9368M21G01	TUBE - AIR POC LOWER	CF6-80A	AR	1
9368M27G01	TUBE - T2 SENSOR FEEDBACK	CF6-80A	AR	1
9368M27G01	TUBE - T2 SENSOR FEEDBACK	CF6-80A	AR	1
9368M27G01	TUBE - T2 SENSOR FEEDBACK	CF6-80A	AR	1
9368M27G01	TUBE - T2 SENSOR FEEDBACK	CF6-80A	SV	1
9368M29G01	TUBE - FUEL	CF6-80A	OH	1
9368M29G01	TUBE - FUEL	CF6-80A	SV	1
9368M54P001A	BRACKET	CF6-80A	NS	1
9368M81P001A	BRACKET	CF6-80A	AR	1
9368M85G01	BRACKET	CF6-80A	AR	1
9368M86P001A	BRACKET	CF6-80A	OH	1
9368M86P001A	BRACKET	CF6-80A	AR	1
9368M87G01	BRACKET	CF6-80A	AR	1
9368M92G01	BRACKET	CF6-80A	AR	1
9368M96P01	JUNCTION BOX - THERMOCOUPLE	CF6-80A	SV	1
9368M96P01	JUNCTION BOX - THERMOCOUPLE	CF6-80A	SV	1
9369M22G01	TUBE - FUEL	CF6-80A	AR	1
9369M22G01	TUBE - FUEL	CF6-80A	AR	1
9369M22G01	TUBE - FUEL	CF6-80A	AR	1
9369M24G01	TUBE - FUEL	CF6-80A	AR	1
9369M24G01	TUBE - FUEL	CF6-80A	AR	1
9369M24G01	TUBE - FUEL	CF6-80A	AR	1
9369M24G01	TUBE - FUEL	CF6-80A	AR	1
9369M24G01	TUBE - FUEL	CF6-80A	AR	1
9369M24G01	TUBE - FUEL	CF6-80A	AR	1
9369M32P001A	BRACKET - THERMOCOUPLE	CF6-80A	NE	1
9369M32P001A	BRACKET - THERMOCOUPLE	CF6-80A	SV	1
9369M34G01	BRACKET - VIBRATION	CF6-50	NS	1
9369M34G01	BRACKET - VIBRATION	CF6-50	NS	2
9369M56G02	TUBE - LPT COOLING AFT AIR	CF6-80A	AR	1
9369M58G01	MANIFOLD - AIR	CF6-80A	AR	1
9369M60G01	TUBE - OIL B SCAVENGE AFT	CF6-80A	AR	1
9369M60G01	TUBE - OIL B SCAVENGE AFT	CF6-80A	AR	1
9369M60G01	TUBE - OIL B SCAVENGE AFT	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9369M60G01	TUBE - OIL B SCAVENGE AFT	CF6-80A	AR	1
9369M63G01	BRACKET	CF6-80A	OH	1
9369M71G01	TUBE - FUEL VBV RETURN	CF6-80A	AR	1
9369M71G01	TUBE - FUEL VBV RETURN	CF6-80A	OH	1
9369M77P001A	BRACKET	CF6-80A	SV	1
9369M77P001A	BRACKET	CF6-80A	SV	1
9369M78G01	BRACKET	CF6-80A	AR	1
9369M82P001A	BRACKET	CF6-80A	AR	1
9369M88G01	TUBE - AIR PMC	CF6-80A	AR	1
9370M30G02	TUBE - AIR TEMP	CF6-80A	AR	1
9370M30G02	TUBE - AIR TEMP	CF6-80A	AR	1
9370M36G01	BRACKET	CF6-50 (LMCO)	NS	1
9370M42P001A	BRACKET	CF6-80A	AR	1
9370M46P01	SHIELD - SPRAY	CF6-80C2	SV	1
9370M46P01	SHIELD - SPRAY	CF6-80C2	OH	2
9370M46P05	SHIELD - SPRAY	CF6-80C2	NE	1
9370M47P01	SHIELD - SPRAY	CF6-80C2	OH	1
9370M47P06	SHIELD - SPRAY	CF6-80C2	NS	1
9370M68G01	TUBE - FUEL (T2)	CF6-80A	AR	1
9370M68G01	TUBE - FUEL (T2)	CF6-80A	AR	1
9370M73G01	TUBE - AIR	CF6-80A	AR	1
9370M75G01	TUBE - AIR	CF6-80A	AR	1
9370M80P001A	BRACKET	CF6-80A	AR	1
9370M80P001A	BRACKET	CF6-80A	AR	1
9370M81G01	TUBE - FUEL COMB DRAIN	CF6-80A	AR	1
9370M86G01	BRACKET	CF6-80A	SV	1
9370M91P01	CUSHION	CF6-80C2	NE	1
9370M91P01	CUSHION	CF6-80C2	NE	1
9370M91P01	CUSHION	CF6-80C2	NS	1
9370M95G01	BRACKET	CF6-80A	AR	1
9370M95G01	BRACKET	CF6-80A	AR	1
9370M95G01	BRACKET	CF6-80A	AR	1
9370M98G01	TUBE - AIR	CF6-80A	AR	1
9370M98G01	TUBE - AIR	CF6-80A	AR	1
9371M19P05	SEAL	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9371M19P06	SEAL	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9371M19P06	SEAL	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9371M20G01	BRACKET	CF6-80A	AR	1
9371M38P001A	BRACKET	CF6-80A	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
9371M38P001A	BRACKET	CF6-80A	NE	1
9371M41G01	BRACKET	CF6-80A	NS	1
9371M48G01	BIFURCATION - LOWER	CF6-80A	AR	1
9371M48G01	BIFURCATION - LOWER	CF6-80A	AR	1
9371M50G01	TUBE - AIR MID SECT FWD	CF6-80A	AR	1
9371M50G01	TUBE - AIR MID SECT FWD	CF6-80A	AR	1
9371M52G01	TUBE - AIR MID SECT AFT	CF6-80A	AR	1
9371M52G01	TUBE - AIR MID SECT AFT	CF6-80A	AR	1
9371M65G02	TUBE - AIR LPT CASE	CF6-80A	AR	1
9371M65G02	TUBE - AIR LPT CASE	CF6-80A	AR	1
9371M65G02	TUBE - AIR LPT CASE	CF6-80A	AR	1
9371M65G02	TUBE - AIR LPT CASE	CF6-80A	AR	1
9371M65G02	TUBE - AIR LPT CASE	CF6-80A	OH	1
9371M65G02	TUBE - AIR LPT CASE	CF6-80A	OH	1
9371M69G01	MANIFOLD - AIR LP RECOUP	CF6-80A	AR	1
9371M69G01	MANIFOLD - AIR LP RECOUP	CF6-80A	AR	1
9371M70G01	MANIFOLD - AIR LP RECOUP	CF6-80A	AR	1
9371M72G01	MANFOLD - AIR LP RECOUP UPR	CF6-80A	AR	1
9371M72G01	MANFOLD - AIR LP RECOUP UPR	CF6-80A	OH	1
9371M73G01	MANFOLD - AIR LP RECOUP MID	CF6-80A	OH	1
9371M73G01	MANFOLD - AIR LP RECOUP MID	CF6-80A	OH	1
9371M73G01	MANFOLD - AIR LP RECOUP MID	CF6-80A	OH	1
9371M73G01	MANFOLD - AIR LP RECOUP MID	CF6-80A	OH	1
9371M73G01	MANFOLD - AIR LP RECOUP MID	CF6-80A	SV	1
9371M86G01	BRACKET	CF6-80A	AR	1
9371M92G01	TUBE - OIL SUPPLY AFT	CF6-80A	SV	1
9371M92G01	TUBE - OIL SUPPLY AFT	CF6-80A	AR	1
9371M92G01	TUBE - OIL SUPPLY AFT	CF6-80A	AR	1
9371M92G01	TUBE - OIL SUPPLY AFT	CF6-80A	AR	1
9372M12G14	HOUSING ASSY - MAIN AGB	CF6-80C2	AR	1
9372M12G17	HOUSING ASSY - MAIN AGB	CF6-80C2	AR	1
9372M15P01	BEARING - ROLLER	CF6-80C2	AR	1
9372M17P01	BEARING - ROLLER	CF6-80C2	AR	1
9372M19P01	BEARING - BALL	CF6-80C2	AR	1
9372M23P01	BEARING - BALL	CF6-80C2	AR	1
9372M24P01	BEARING - BALL	CF6-80C2	AR	1
9372M28G02	TGB HOUSING	CF6-80C2	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9372M28G02	TGB HOUSING	CF6-80C2	OH	1
9372M32G14	GEARBOX ASSY - TRANSFER	CF6-80C2	AR	1
9372M32G14	GEARBOX ASSY - TRANSFER	CF6-80C2	AR	1
9372M32G14	GEARBOX ASSY - TRANSFER	CF6-80C2	AR	1
9372M34G03	TGB RADIAL ADAPTER	CF6-80C2	AR	1
9372M34G03	TGB RADIAL ADAPTER	CF6-80C2	AR	1
9372M34G03	TGB RADIAL ADAPTER	CF6-80C2	AR	1
9372M34G03	TGB RADIAL ADAPTER	CF6-80C2	AR	1
9372M34G03	TGB RADIAL ADAPTER	CF6-80C2	OH	1
9372M36G02	TGB HORIZONTAL ADAPTER	CF6-80C2	AR	1
9372M36G04	TGB HORIZONTAL ADAPTER	CF6-80C2	AR	1
9372M60G02	GEARSHAFT - INLET GEARBOX	CF6-80C2	AR	1
9372M62P01	GEARSHAFT	CF6-80C2	AR	1
9372M62P01	GEARSHAFT	CF6-80C2	OH	1
9372M71P01	IGB HORZ GEARSHAFT BEARING	CF6-80C2	SV	1
9372M75P01	SPACER - BRG GRBX	CF6-80C2	AR	1
9372M75P01	SPACER - BRG GRBX	CF6-80C2	AR	1
9372M75P01	SPACER - BRG GRBX	CF6-80C2	NE	1
9372M75P02	SPACER - BRG GRBX	CF6-80C2	AR	1
9372M75P02	SPACER - BRG GRBX	CF6-80C2	AR	1
9372M75P02	SPACER - BRG GRBX	CF6-80C2	NE	1
9372M80G01	IGB OIL NOZZLE	CF6-80C2	AR	1
9372M80G01	IGB OIL NOZZLE	CF6-80C2	AR	1
9372M84P02	TGB RADIAL DRIVE SHAFT	CF6-80C2	AR	1
9372M84P02	TGB RADIAL DRIVE SHAFT	CF6-80C2	SV	1
9373M29G06	HOUSING ASSY - BRG NO. 2	CF6-80C2	AR	1
9373M32P05	BLADE - LPTR STG 2	CF6-80C2	OH	1
9373M33P06	LPT ROTOR BLADE STG 3	CF6-80C2	AR	56
9373M33P06	LPT ROTOR BLADE STG 3	CF6-80C2	AR	32
9373M33P06	LPT ROTOR BLADE STG 3	CF6-80C2	OH	9
9373M33P06	LPT ROTOR BLADE STG 3	CF6-80C2	OH	12
9373M33P06	LPT ROTOR BLADE STG 3	CF6-80C2	OH	25
9373M33P06	LPT ROTOR BLADE STG 3	CF6-80C2	OH	1
9373M33P06	LPT ROTOR BLADE STG 3	CF6-80C2	OH	2
9373M33P06	LPT ROTOR BLADE STG 3	CF6-80C2	OH	30
9373M33P06	LPT ROTOR BLADE STG 3	CF6-80C2	OH	5
9373M33P06	LPT ROTOR BLADE STG 3	CF6-80C2	OH	5
9373M33P07	BLADE - LPTR STG 3	CF6-80C2	AR	6
9373M33P08	LPT ROTOR BLADE STG 3	CF6-80C2	OH	1
9373M33P08	LPT ROTOR BLADE STG 3	CF6-80C2	OH	7
9373M33P08	LPT ROTOR BLADE STG 3	CF6-80C2	OH	25

Part Number	Part Description	Engine Type	Condition	Quantity
9373M33P08	LPT ROTOR BLADE STG 3	CF6-80C2	OH	15
9373M33P09	LPT ROTOR BLADE STG 3	CF6-80C2	AR	4
9373M33P09	LPT ROTOR BLADE STG 3	CF6-80C2	OH	2
9373M33P09	LPT ROTOR BLADE STG 3	CF6-80C2	OH	30
9373M34P03	BLADE - LPTR STG 4	CF6-80C2	AR	32
9373M34P04	BLADE - LPTR STG 4	CF6-80C2	OH	4
9373M34P04	BLADE - LPTR STG 4	CF6-80C2	OH	7
9373M34P04	BLADE - LPTR STG 4	CF6-80C2	OH	29
9373M34P05	BLADE - LPTR STG 4	CF6-80C2	OH	27
9373M34P05	BLADE - LPTR STG 4	CF6-80C2	OH	30
9373M34P05	BLADE - LPTR STG 4	CF6-80C2	OH	26
9373M34P05	BLADE - LPTR STG 4	CF6-80C2	OH	30
9373M34P05	BLADE - LPTR STG 4	CF6-80C2	OH	30
9373M34P05	BLADE - LPTR STG 4	CF6-80C2	OH	30
9373M34P05	BLADE - LPTR STG 4	CF6-80C2	OH	30
9373M34P05	BLADE - LPTR STG 4	CF6-80C2	OH	30
9373M34P05	BLADE - LPTR STG 4	CF6-80C2	OH	30
9373M35P03	BLADE - LPTR STG 5	CF6-80C2	AR	97
9373M35P03	BLADE - LPTR STG 5	CF6-80C2	OH	28
9373M35P04	BLADE - LPTR STG 5	CF6-80C2	AR	56
9373M35P04	BLADE - LPTR STG 5	CF6-80C2	OH	30
9373M35P04	BLADE - LPTR STG 5	CF6-80C2	OH	30
9373M35P04	BLADE - LPTR STG 5	CF6-80C2	OH	30
9373M35P04	BLADE - LPTR STG 5	CF6-80C2	OH	30
9373M35P04	BLADE - LPTR STG 5	CF6-80C2	OH	3
9373M35P04	BLADE - LPTR STG 5	CF6-80C2	OH	26
9373M35P04	BLADE - LPTR STG 5	CF6-80C2	OH	30
9373M35P04	BLADE - LPTR STG 5	CF6-80C2	OH	30
9373M35P04	BLADE - LPTR STG 5	CF6-80C2	OH	8
9373M35P04	BLADE - LPTR STG 5	CF6-80C2	OH	30
9373M35P04	BLADE - LPTR STG 5	CF6-80C2	OH	12
9373M35P04	BLADE - LPTR STG 5	CF6-80C2	OH	30
9373M35P04	BLADE - LPTR STG 5	CF6-80C2	OH	2
9373M48P01	LUBE NOZZLE COVER	CF6-80C2	SV	1
9373M56P01	WEDGE	CF6-80A	AR	2
9373M56P02	WEDGE - ISLN MT	CF6-80A	SV	1
9373M57P01	WEDGE	CF6-80A	AR	2
9373M57P01	WEDGE	CF6-80A	NS	1
9373M58P01	LINER - ISLN MT	CF6-80A	NE	1
9373M59P02	MOUNT - RESILIENT	CF6-80A	NE	12
9373M60P01	WEDGE	CF6-80A	NS	2
9373M62P03	SEAL - LPTR STG 2	CF6-80C2	AR	1
9373M62P03	SEAL - LPTR STG 2	CF6-80C2	AR	1
9373M62P03	SEAL - LPTR STG 2	CF6-80C2	AR	1
9373M63P03	SEAL - LPTR STG 3	CF6-80C2	AR	1
9373M63P03	SEAL - LPTR STG 3	CF6-80C2	AR	1
9373M63P03	SEAL - LPTR STG 3	CF6-80C2	AR	1
9373M63P03	SEAL - LPTR STG 3	CF6-80C2	AR	1
9373M63P03	SEAL - LPTR STG 3	CF6-80C2	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9373M64P03	SEAL - LPTR STG 4 & 5	CF6-80C2	AR	1
9373M64P03	SEAL - LPTR STG 4 & 5	CF6-80C2	AR	1
9373M64P03	SEAL - LPTR STG 4 & 5	CF6-80C2	AR	1
9373M64P03	SEAL - LPTR STG 4 & 5	CF6-80C2	AR	1
9373M64P03	SEAL - LPTR STG 4 & 5	CF6-80C2	AR	1
9373M64P03	SEAL - LPTR STG 4 & 5	CF6-80C2	SV	1
9373M64P03	SEAL - LPTR STG 4 & 5	CF6-80C2	AR	1
9373M64P03	SEAL - LPTR STG 4 & 5	CF6-80C2	AR	1
9373M64P03	SEAL - LPTR STG 4 & 5	CF6-80C2	OH	1
9373M66G01	SEAL - ROTATING	CF6-80A	AR	1
9373M77G01	HPT NOZZLE STG 2 RETAINER ASSY	CF6-80C2	OH	1
9373M77G01	HPT NOZZLE STG 2 RETAINER ASSY	CF6-80C2	OH	10
9373M77G01	HPT NOZZLE STG 2 RETAINER ASSY	CF6-80C2	OH	1
9373M77G01	HPT NOZZLE STG 2 RETAINER ASSY	CF6-80C2	OH	8
9373M82G06	SEAL - STA AIR STTR INTERSTG	CF6-80C2	OH	1
9373M82G06	SEAL - STA AIR STTR INTERSTG	CF6-80C2	OH	1
9373M88G09	LINER - COMB CHMBR INNER	CF6-80C2	AR	1
9374M15G07	SEAL - AIR/OIL STAT BRG NO. 1	CF6-80C2	OH	1
9374M15G08	SEAL - AIR/OIL STAT BRG NO. 1	CF6-80C2	AR	1
9374M15G08	SEAL - AIR/OIL STAT BRG NO. 1	CF6-80C2	AR	1
9374M15G08	SEAL - AIR/OIL STAT BRG NO. 1	CF6-80C2	OH	1
9374M17G01	NOZZLE - OIL BRG	CF6-80C2	AR	1
9374M17G01	NOZZLE - OIL BRG	CF6-80C2	AR	1
9374M17G01	NOZZLE - OIL BRG	CF6-80C2	AR	1
9374M17G01	NOZZLE - OIL BRG	CF6-80C2	AR	1
9374M17G01	NOZZLE - OIL BRG	CF6-80C2	AR	2
9374M17G01	NOZZLE - OIL BRG	CF6-80C2	AR	1
9374M17G01	NOZZLE - OIL BRG	CF6-80C2	AR	1
9374M17G01	NOZZLE - OIL BRG	CF6-80C2	AR	2
9374M29G02	#3 BEARING STATIONARY AIR SEAL	CF6-80C2, CF6-80A	AR	1
9374M29G02	#3 BEARING STATIONARY AIR SEAL	CF6-80C2, CF6-80A	OH	1
9374M29G02	#3 BEARING STATIONARY AIR SEAL	CF6-80C2, CF6-80A	OH	1
9374M29G02	#3 BEARING STATIONARY AIR SEAL	CF6-80C2, CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9374M29G02	#3 BEARING STATIONARY AIR SEAL	CF6-80C2, CF6-80A	OH	1
9374M29G02	#3 BEARING STATIONARY AIR SEAL	CF6-80C2, CF6-80A	OH	1
9374M29G02	#3 BEARING STATIONARY AIR SEAL	CF6-80C2, CF6-80A	OH	1
9374M29G02	#3 BEARING STATIONARY AIR SEAL	CF6-80C2, CF6-80A	OH	1
9374M29G02	#3 BEARING STATIONARY AIR SEAL	CF6-80C2, CF6-80A	OH	1
9374M37G05	#4R BEARING STATIONARY VENT SEAL	CF6-80C2	OH	1
9374M50G01	COVER - AFT BRG NO. 6	CF6-80C2	AR	1
9374M50G01	COVER - AFT BRG NO. 6	CF6-80C2	AR	1
9374M50G03	COVER - AFT BRG NO. 6	CF6-80C2	AR	1
9374M55G06	NUT - OUTER BRG NO. 6R	CF6-80C2	AR	1
9374M59P01	RING - RETAINING BRG NO. 6R	CF6-80C2	AR	1
9374M59P01	RING - RETAINING BRG NO. 6R	CF6-80C2	AR	1
9374M59P01	RING - RETAINING BRG NO. 6R	CF6-80C2	AR	1
9374M59P01	RING - RETAINING BRG NO. 6R	CF6-80C2	AR	1
9374M59P01	RING - RETAINING BRG NO. 6R	CF6-80C2	AR	1
9374M59P01	RING - RETAINING BRG NO. 6R	CF6-80C2	SV	1
9374M75G01	HPT NOZZLE STG 2 SHROUD RETAINER	CF6-80C2	OH	2
9374M75G01	HPT NOZZLE STG 2 SHROUD RETAINER	CF6-80C2	OH	9
9374M75G03	RETAINER - STG 2	CF6-80C2	OH	6
9374M75G03	RETAINER - STG 2	CF6-80C2	OH	7
9374M75G04	HPT NOZZLE STG 2 SHROUD RETAINER	CF6-80C2	NE	22
9374M75G04	HPT NOZZLE STG 2 SHROUD RETAINER	CF6-80C2	NE	42
9374M75G04	HPT NOZZLE STG 2 SHROUD RETAINER	CF6-80C2	OH	3
9374M76G17	DAMPER ASSY - HPTR STG 2	CF6-80C2	SV	1
9374M77P01	ROD END - L/H	CF6-80A	OH	1
9374M79P03	HPT ROTOR DAMPER SEAL STG 1	CF6-80C2	OH	14
9374M79P03	HPT ROTOR DAMPER SEAL STG 1	CF6-80C2	OH	2
9377M36G05	MANIFOLD - FUEL DRAIN R/S	CF6-80C2	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9377M36G06	MANIFOLD - FUEL DRAIN R/S	CF6-80C2	SV	1
9377M36G07	MANIFOLD - FUEL DRAIN R/S	CF6-80C2	AR	1
9377M45P03	TRANSMITTER - OIL LEVEL	CF6-80C2	NE	1
9377M61P02	FLOWMETER - TRANSMITTER	CF6-80C2	OH	1
9377M61P02	FLOWMETER - TRANSMITTER	CF6-80C2	OH	1
9377M62P01	SWITCH ASSY - FUEL	CF6-80C2	AR	1
9377M67P03	COUPLING - BHD	CF6-80C2	NS	1
9378M19G08	TUBE - FUEL PUMP (TO MEC)	CF6-80C2	AR	1
9378M31P01	FITTING - REDUCER	CF6-80C2, CF6-50 (LMCO)	AR	1
9378M31P01	FITTING - REDUCER	CF6-80C2, CF6-50 (LMCO)	SV	3
9378M31P01	FITTING - REDUCER	CF6-80C2, CF6-50 (LMCO)	SV	3
9378M31P01	FITTING - REDUCER	CF6-80C2, CF6-50 (LMCO)	NE	2
9378M67P03	TUBE/HOSE - VENT	CF6-80C2	AR	1
9378M73G01	TUBE - TRANSITION	CF6-80C2	AR	1
9378M73G01	TUBE - TRANSITION	CF6-80C2	AR	1
9378M73G03	TUBE - TRANSITION	CF6-80C2, CF6-80A, CF6-50 (Boeing)	AR	1
9378M77P01	TUBE - FERRULE	CF6-80C2	NE	2
9378M77P01	TUBE - FERRULE	CF6-80C2	NE	1
9378M83G03	TUBE - AIR HP RECOUP UPPER	CF6-80C2	AR	1
9378M83G04	TUBE - AIR HP RECOUP SUPPLY [UPR]	CF6-80C2	AR	1
9378M83G04	TUBE - AIR HP RECOUP SUPPLY [UPR]	CF6-80C2	OH	1
9378M83G04	TUBE - AIR HP RECOUP SUPPLY [UPR]	CF6-80C2	AR	1
9378M83G04	TUBE - AIR HP RECOUP SUPPLY [UPR]	CF6-80C2	OH	1
9378M85G02	TUBE - AIR HP RECOUP LOWER	CF6-80C2	AR	1
9378M85G03	TUBE - AIR HP RECOUP SUPPLY [LWR]	CF6-80C2	OH	1
9378M85G03	TUBE - AIR HP RECOUP SUPPLY [LWR]	CF6-80C2	AR	1
9378M85G03	TUBE - AIR HP RECOUP SUPPLY [LWR]	CF6-80C2	AR	1
9379M28P05	MOUNT - RESILIENT	CF6-80C2	NS	2
9379M28P05	MOUNT - RESILIENT	CF6-80C2	NE	10

Part Number	Part Description	Engine Type	Condition	Quantity
9379M29P02	SPACER - MOUNTING	CF6-80C2	NE	1
9379M29P02	SPACER - MOUNTING	CF6-80C2	NS	2
9379M40G02	HPC STATOR SHROUD STG IGV	CF6-80C2	SV	1
9379M40G02	HPC STATOR SHROUD STG IGV	CF6-80C2	SV	1
9379M40G02	HPC STATOR SHROUD STG IGV	CF6-80C2	SV	1
9379M40G02	HPC STATOR SHROUD STG IGV	CF6-80C2	AR	1
9379M40G02	HPC STATOR SHROUD STG IGV	CF6-80C2	AR	1
9379M40G02	HPC STATOR SHROUD STG IGV	CF6-80C2	SV	1
9379M40G02	HPC STATOR SHROUD STG IGV	CF6-80C2	AR	1
9379M40G02	HPC STATOR SHROUD STG IGV	CF6-80C2	AR	1
9379M41G05	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9379M41G05	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9379M41G05	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9379M41G05	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9379M41G05	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9379M41G05	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9379M41G05	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9379M41G05	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9379M41G05	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9379M41G05	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9379M41G05	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9379M41G05	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9379M41G05	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9379M41G05	SHROUD ASSY - VANE STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9379M42G04	SHROUD ASSY - VANE STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9379M42G04	SHROUD ASSY - VANE STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9379M42G04	SHROUD ASSY - VANE STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9379M42G04	SHROUD ASSY - VANE STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9379M42G04	SHROUD ASSY - VANE STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9379M42G04	SHROUD ASSY - VANE STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9379M42G04	SHROUD ASSY - VANE STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9379M42G04	SHROUD ASSY - VANE STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9379M42G04	SHROUD ASSY - VANE STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9379M42G04	SHROUD ASSY - VANE STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9379M42G04	SHROUD ASSY - VANE STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9379M42G04	SHROUD ASSY - VANE STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9379M42G04	SHROUD ASSY - VANE STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9379M42G04	SHROUD ASSY - VANE STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9379M42G04	SHROUD ASSY - VANE STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9379M44G08	RING - IMPINGMENT STG 2	CF6-80C2	OH	1
9379M59P05	HPT ROTOR AFT OUTER AIR SEAL	CF6-80C2	AR	1
9379M59P05	HPT ROTOR AFT OUTER AIR SEAL	CF6-80C2	AR	1
9379M63P01	DAMPER - RUBBER	CF6-80A, CF6-50 (LMCO)	NS	6
9379M63P02	DAMPER - RUBBER	CF6-80A, CF6-50 (LMCO)	NE	3
9379M98G11	SUPPORT - HPT STTR	CF6-80C2	AR	1
9379M98G12	SUPPORT - HPT STTR	CF6-80C2	OH	1
9379M98G12	SUPPORT - HPT STTR	CF6-80C2	OH	1
9380M25P02	HPC ROTOR MANIFOLD STG 10-14	CF6-80C2	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9380M27P03	HPC ROTOR DISK STG 2	CF6-80C2	OH	1
9380M27P07	HPC ROTOR DISK STG 2	CF6-80C2	OH	1
9380M27P08	HPC ROTOR DISK STG 2	CF6-80C2	AR	1
9380M29P04	DISK - HPC STG 10	CF6-80C2	OH	1
9380M47P01	RETAINER - BUMPER BRG	CF6-80C2	AR	1
9380M65P03	SEAL	CF6-80C2	NE	2
9380M67G01	RETAINER - NUT	CF6-80C2	SV	1
9380M67G01	RETAINER - NUT	CF6-80C2	AR	1
9380M67G01	RETAINER - NUT	CF6-80C2	OH	1
9380M67G02	RETAINER - NUT	CF6-80C2	SV	1
9380M67G02	RETAINER - NUT	CF6-80C2	AR	1
9380M67G02	RETAINER - NUT	CF6-80C2	OH	1
9380M68G01	RETAINER - BOLT	CF6-80C2	OH	1
9380M68G02	RETAINER - BOLT	CF6-80C2	AR	1
9380M68G02	RETAINER - BOLT	CF6-80C2	NS	1
9380M68G02	RETAINER - BOLT	CF6-80C2	OH	2
9380M68G02	RETAINER - BOLT	CF6-80C2	OH	1
9380M68G03	RETAINER - BOLT	CF6-80C2	AR	1
9380M78P01	RETAINER - NUT	CF6-80C2	NE	4
9380M86P02	HOUSING - BRG NO. 4B/4R	CF6-80A	AR	1
9380M86P02	HOUSING - BRG NO. 4B/4R	CF6-80A	OH	1
9381M17G61	LINER - SEG FAN INNER AFT	CF6-80C2	AR	1
9381M17G62	LINER - SEG FAN INNER AFT	CF6-80C2	AR	1
9381M17G63	LINER - SEG FAN INNER AFT	CF6-80C2	AR	1
9381M17G64	LINER - SEG FAN INNER AFT	CF6-80C2	AR	1
9381M17G65	LINER - SEG FAN INNER AFT	CF6-80C2	AR	1
9381M17G66	LINER - SEG FAN INNER AFT	CF6-80C2	AR	1
9381M17G66	LINER - SEG FAN INNER AFT	CF6-80C2	AR	1
9381M17G67	LINER - SEG FAN INNER AFT	CF6-80C2	AR	1
9381M17G68	LINER - SEG FAN INNER AFT	CF6-80C2	AR	1
9381M17G68	LINER - SEG FAN INNER AFT	CF6-80C2	AR	1
9381M17G69	LINER - SEG FAN INNER AFT	CF6-80C2	AR	1
9381M17G70	LINER - SEG FAN INNER AFT	CF6-80C2	AR	1
9381M17G71	LINER - SEG FAN INNER AFT	CF6-80C2	AR	1
9381M17G72	LINER - SEG FAN INNER AFT	CF6-80C2	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9381M17G73	LINER - SEG FAN INNER AFT	CF6-80C2	AR	1
9381M17G77	LINER - SEG FAN INNER AFT	CF6-80C2	AR	1
9381M17G78	LINER - SEG FAN INNER AFT	CF6-80C2	AR	1
9381M17G79	LINER - SEG FAN INNER AFT	CF6-80C2	AR	1
9381M17G81	LINER - SEG FAN INNER AFT	CF6-80C2	AR	1
9381M17G84	LINER - SEG FAN INNER AFT	CF6-80C2	AR	1
9381M17G95	LINER - SEG FAN INNER AFT	CF6-80C2	OH	1
9381M22P03	MOUNT - SWAY TRF	CF6-80C2	OH	1
9381M22P03	MOUNT - SWAY TRF	CF6-80C2	OH	1
9381M26P01	#6 BEARING AFT COVER	CF6-80C2	NS	3
9381M26P01	#6 BEARING AFT COVER	CF6-80C2	SV	1
9381M26P01	#6 BEARING AFT COVER	CF6-80C2	OH	1
9381M26P01	#6 BEARING AFT COVER	CF6-80C2	SV	1
9381M34P03	SLEEVE	CF6-80A	NE	6
9381M34P03	SLEEVE	CF6-80A	NE	6
9381M35G01	FAIRING - FLOWPATH	CF6-80C2	AR	1
9381M35G01	FAIRING - FLOWPATH	CF6-80C2	AR	2
9381M35G01	FAIRING - FLOWPATH	CF6-80C2	AR	1
9381M35G01	FAIRING - FLOWPATH	CF6-80C2	AR	1
9381M35G01	FAIRING - FLOWPATH	CF6-80C2	NE	4
9381M35G01	FAIRING - FLOWPATH	CF6-80C2	NE	4
9381M35G02	FAIRING - FLOWPATH	CF6-80C2	AR	1
9381M35G02	FAIRING - FLOWPATH	CF6-80C2	AR	1
9381M35G02	FAIRING - FLOWPATH	CF6-80C2	NE	1
9381M35G02	FAIRING - FLOWPATH	CF6-80C2	NE	1
9381M35G02	FAIRING - FLOWPATH	CF6-80C2	NS	1
9381M35G03	FAIRING - FLOWPATH	CF6-80C2	AR	1
9381M35G03	FAIRING - FLOWPATH	CF6-80C2	AR	1
9381M35G03	FAIRING - FLOWPATH	CF6-80C2	AR	1
9381M35G03	FAIRING - FLOWPATH	CF6-80C2	NE	1
9381M35G03	FAIRING - FLOWPATH	CF6-80C2	NE	2
9381M35G04	FAIRING - FLOWPATH	CF6-80C2	AR	1
9381M35G05	FAIRING - FLOWPATH	CF6-80C2	AR	1
9381M35G06	FAIRING - FLOWPATH	CF6-80C2	AR	1
9381M35G06	FAIRING - FLOWPATH	CF6-80C2	AR	1
9381M35G06	FAIRING - FLOWPATH	CF6-80C2	NE	2
9381M35G07	FAIRING - FLOWPATH	CF6-80C2	AR	1
9381M35G07	FAIRING - FLOWPATH	CF6-80C2	NE	4
9381M35G07	FAIRING - FLOWPATH	CF6-80C2	NE	3
9381M35G08	FAIRING - FLOWPATH	CF6-80C2	AR	1
9381M35G08	FAIRING - FLOWPATH	CF6-80C2	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9381M35G08	FAIRING - FLOWPATH	CF6-80C2	NE	1
9381M35G08	FAIRING - FLOWPATH	CF6-80C2	NE	2
9381M35G09	FAIRING - FLOWPATH	CF6-80C2	AR	1
9381M35G09	FAIRING - FLOWPATH	CF6-80C2	AR	1
9381M35G09	FAIRING - FLOWPATH	CF6-80C2	NE	1
9381M35G09	FAIRING - FLOWPATH	CF6-80C2	NE	2
9381M35G10	FAIRING - FLOWPATH	CF6-80C2	AR	1
9381M35G10	FAIRING - FLOWPATH	CF6-80C2	NE	1
9381M35G10	FAIRING - FLOWPATH	CF6-80C2	NE	3
9381M35G10	FAIRING - FLOWPATH	CF6-80C2	NE	3
9381M35G11	FAIRING - FLOWPATH	CF6-80C2	AR	1
9381M35G11	FAIRING - FLOWPATH	CF6-80C2	AR	1
9381M35G11	FAIRING - FLOWPATH	CF6-80C2	NE	2
9381M39P01	BRACKET - FWD MOUNT BEAM	CF6-80A	OH	1
9381M39P01	BRACKET - FWD MOUNT BEAM	CF6-80A	OH	1
9381M39P01	BRACKET - FWD MOUNT BEAM	CF6-80A	OH	1
9381M39P01	BRACKET - FWD MOUNT BEAM	CF6-80A	AR	2
9381M39P01	BRACKET - FWD MOUNT BEAM	CF6-80A	OH	1
9381M41G03	BRACKET ASSY - LCH THR RVSR	CF6-80C2	SV	1
9381M41G06	BRACKET ASSY - LCH THR RVSR	CF6-80C2	OH	1
9381M50G01	CASE - SUPPORT	CF6-80C2	SV	9
9381M50G01	CASE - SUPPORT	CF6-80C2	SV	8
9381M50G02	CASE - SUPPORT	CF6-80C2	SV	2
9381M50G03	CASE - SUPPORT	CF6-80C2	SV	2
9381M59P01	RETAINER	CF6-80C2	AR	18
9381M59P01	RETAINER	CF6-80C2	SV	17
9381M59P02	RETAINER	CF6-80C2	AR	18
9381M61G08	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
9381M61G08	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
9381M61G08	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
9381M61G08	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
9381M61G08	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
9381M61G08	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
9381M61G08	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9381M61G08	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
9381M61G08	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
9381M61G08	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
9381M61G08	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
9381M61G08	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
9381M61G08	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
9381M61G08	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
9381M61G08	SUPPORT - SHRD HPT STTR STG 1	CF6-80C2	OH	1
9381M62P04	SPACER - BUSHING	CF6-80C2	OH	1
9381M62P04	SPACER - BUSHING	CF6-80C2	NE	1
9381M62P04	SPACER - BUSHING	CF6-80C2	NE	1
9381M62P04	SPACER - BUSHING	CF6-80C2	NE	87
9381M62P06	SPACER - BUSHING	CF6-80C2	OH	4
9381M62P06	SPACER - BUSHING	CF6-80C2	NE	1
9381M62P06	SPACER - BUSHING	CF6-80C2	OH	4
9381M62P06	SPACER - BUSHING	CF6-80C2	NE	2
9381M62P06	SPACER - BUSHING	CF6-80C2	NE	2
9381M62P06	SPACER - BUSHING	CF6-80C2	NS	1
9381M62P06	SPACER - BUSHING	CF6-80C2	NE	10
9381M62P06	SPACER - BUSHING	CF6-80C2	NS	4
9381M68G01	FAN BY-PASS VALVE BELLCRANK	CF6-80C2	OH	1
9381M68G01	FAN BY-PASS VALVE BELLCRANK	CF6-80C2	OH	1
9381M68G01	FAN BY-PASS VALVE BELLCRANK	CF6-80C2	OH	1
9381M68G01	FAN BY-PASS VALVE BELLCRANK	CF6-80C2	OH	1
9381M69G26	FRAME ASSY - TURB REAR	CF6-80C2	SV	1
9381M69G34	FRAME ASSY - TURB REAR	CF6-80C2	OH	1
9381M69G34	FRAME ASSY - TURB REAR	CF6-80C2	AR	1
9381M70P01	SEGMENT - SUPPORT THRUST	CF6-80C2	AR	1
9381M70P02	SEGMENT - SUPPORT THRUST	CF6-80C2	AR	1
9381M70P02	SEGMENT - SUPPORT THRUST	CF6-80C2	AR	1
9381M75P01	SLEEVE - WEAR	CF6-80C2	NE	1
9381M83G01	NUT ASSY - SLFLKG GANG CHAN	CF6-80C2	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9381M83G01	NUT ASSY - SLFLKG GANG CHAN	CF6-80C2	AR	1
9381M83G01	NUT ASSY - SLFLKG GANG CHAN	CF6-80C2	NE	2
9381M83G01	NUT ASSY - SLFLKG GANG CHAN	CF6-80C2	AR	2
9382M10G04	MANIFOLD - OIL	CF6-80C2	OH	1
9382M12G01	MANIFOLD - LUBE	CF6-80C2	OH	1
9382M12G01	MANIFOLD - LUBE	CF6-80C2	OH	1
9382M14G01	MANIFOLD - LUBE FWD	CF6-80C2	AR	1
9382M14G01	MANIFOLD - LUBE FWD	CF6-80C2	SV	1
9382M16G01	BRACKET	CF6-80C2	NS	1
9382M21P01	DUCT - VENT INSULATED	CF6-80C2	AR	1
9382M21P01	DUCT - VENT INSULATED	CF6-80C2	AR	1
9382M21P01	DUCT - VENT INSULATED	CF6-80C2	AR	1
9382M21P01	DUCT - VENT INSULATED	CF6-80C2	AR	1
9382M21P05	DUCT - VENT INSULATED	CF6-80C2	OH	1
9382M21P05	DUCT - VENT INSULATED	CF6-80C2	OH	1
9382M21P05	DUCT - VENT INSULATED	CF6-80C2	AR	1
9382M21P05	DUCT - VENT INSULATED	CF6-80C2	OH	1
9382M21P06	DUCT - VENT INSULATED	CF6-80C2	OH	1
9382M22G01	DUCT - PRESS CRF	CF6-80C2	SV	1
9382M22G01	DUCT - PRESS CRF	CF6-80C2	AR	1
9382M22G01	DUCT - PRESS CRF	CF6-80C2	AR	1
9382M22G01	DUCT - PRESS CRF	CF6-80C2	AR	1
9382M22G01	DUCT - PRESS CRF	CF6-80C2	AR	1
9382M22G01	DUCT - PRESS CRF	CF6-80C2	AR	1
9382M22G01	DUCT - PRESS CRF	CF6-80C2	AR	1
9382M22G01	DUCT - PRESS CRF	CF6-80C2	AR	1
9382M22G01	DUCT - PRESS CRF	CF6-80C2	AR	1
9382M22G01	DUCT - PRESS CRF	CF6-80C2	AR	1
9382M22G02	DUCT - PRESS CRF	CF6-80C2	AR	1
9382M22G02	DUCT - PRESS CRF	CF6-80C2	OH	1
9382M36G01	TUBE - AIR	CF6-80C2	AR	4
9382M36G01	TUBE - AIR	CF6-80C2	OH	1
9382M36G01	TUBE - AIR	CF6-80C2	SV	1
9382M36G01	TUBE - AIR	CF6-80C2	AR	4
9382M36G01	TUBE - AIR	CF6-80C2	AR	4
9382M36G01	TUBE - AIR	CF6-80C2	OH	2
9382M36G02	TUBE - AIR	CF6-80C2	AR	2
9382M36G02	TUBE - AIR	CF6-80C2	AR	1
9382M36G02	TUBE - AIR	CF6-80C2	AR	2
9382M36G02	TUBE - AIR	CF6-80C2	AR	2
9382M36G03	TUBE - AIR	CF6-80C2	OH	1
9382M36G04	TUBE - AIR	CF6-80C2	SV	1
9382M36G04	TUBE - AIR	CF6-80C2	SV	2
9382M36G04	TUBE - AIR	CF6-80C2	SV	2
9382M36G04	TUBE - AIR	CF6-80C2	SV	1
9382M36G04	TUBE - AIR	CF6-80C2	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
9382M36G04	TUBE - AIR	CF6-80C2	SV	1
9382M36G04	TUBE - AIR	CF6-80C2	SV	1
9382M36G04	TUBE - AIR	CF6-80C2	SV	1
9382M36G04	TUBE - AIR	CF6-80C2	SV	1
9382M36G04	TUBE - AIR	CF6-80C2	SV	1
9382M36G04	TUBE - AIR	CF6-80C2	OH	1
9382M36G04	TUBE - AIR	CF6-80C2	SV	2
9382M36G04	TUBE - AIR	CF6-80C2	OH	1
9382M36G04	TUBE - AIR	CF6-80C2	OH	1
9382M36G04	TUBE - AIR	CF6-80C2	OH	1
9382M36G04	TUBE - AIR	CF6-80C2	OH	1
9382M36G04	TUBE - AIR	CF6-80C2	OH	1
9382M36G04	TUBE - AIR	CF6-80C2	OH	1
9382M36G04	TUBE - AIR	CF6-80C2	OH	1
9382M36G04	TUBE - AIR	CF6-80C2	OH	1
9382M36G04	TUBE - AIR	CF6-80C2	OH	1
9382M36G04	TUBE - AIR	CF6-80C2	OH	1
9382M36G04	TUBE - AIR	CF6-80C2	OH	1
9382M36G04	TUBE - AIR	CF6-80C2	OH	1
9382M36G04	TUBE - AIR	CF6-80C2	OH	1
9382M36G04	TUBE - AIR	CF6-80C2	OH	1
9382M36G04	TUBE - AIR	CF6-80C2	OH	1
9382M36G04	TUBE - AIR	CF6-80C2	OH	1
9382M36G04	TUBE - AIR	CF6-80C2	OH	1
9382M36G04	TUBE - AIR	CF6-80C2	OH	1
9382M36G04	TUBE - AIR	CF6-80C2	OH	1
9382M36G04	TUBE - AIR	CF6-80C2	OH	1
9382M36G04	TUBE - AIR	CF6-80C2	OH	1
9382M36G04	TUBE - AIR	CF6-80C2	OH	1
9382M36G04	TUBE - AIR	CF6-80C2	OH	1
9382M36G05	TUBE - AIR	CF6-80C2	OH	1
9382M36G05	TUBE - AIR	CF6-80C2	AR	1
9382M36G05	TUBE - AIR	CF6-80C2	OH	1
9382M36G05	TUBE - AIR	CF6-80C2	OH	1
9382M36G05	TUBE - AIR	CF6-80C2	OH	1
9382M36G06	TUBE - AIR	CF6-80C2	SV	1
9382M36G06	TUBE - AIR	CF6-80C2	OH	1
9382M36G06	TUBE - AIR	CF6-80C2	OH	1
9382M36G06	TUBE - AIR	CF6-80C2	OH	1
9382M36G06	TUBE - AIR	CF6-80C2	OH	1
9382M40G01	MANIFOLD - OIL SUPPLY	CF6-80C2	OH	1
9382M40G01	MANIFOLD - OIL SUPPLY	CF6-80C2	OH	1
9382M55G15	SHROUD - STG 5	CF6-80C2	AR	24
9382M58P03	BUMPER - SEGMENT	CF6-80C2	NE	6
9382M58P03	BUMPER - SEGMENT	CF6-80C2	NE	8
9382M58P03	BUMPER - SEGMENT	CF6-80C2	NE	1
9382M59P07	SHAFT - LPTR	CF6-80C2	OH	1
9382M62P01	RETAINER - LPT BLADE	CF6-80C2	NE	2
9382M62P01	RETAINER - LPT BLADE	CF6-80C2	NE	73
9382M62P01	RETAINER - LPT BLADE	CF6-80C2	NE	5
9382M62P01	RETAINER - LPT BLADE	CF6-80C2	NE	8

Part Number	Part Description	Engine Type	Condition	Quantity
9382M62P01	RETAINER - LPT BLADE	CF6-80C2	NE	3
9382M62P01	RETAINER - LPT BLADE	CF6-80C2	NE	7
9382M63P01	RETAINER - LPT BLADE	CF6-80C2	NS	2
9382M63P01	RETAINER - LPT BLADE	CF6-80C2	NE	3
9382M63P01	RETAINER - LPT BLADE	CF6-80C2	NS	45
9382M63P01	RETAINER - LPT BLADE	CF6-80C2	NS	7
9382M63P01	RETAINER - LPT BLADE	CF6-80C2	NS	45
9382M63P02	RETAINER - BLADE	CF6-80C2	NS	10
9382M63P02	RETAINER - BLADE	CF6-80C2	NS	40
9382M63P02	RETAINER - BLADE	CF6-80C2	NS	7
9382M63P02	RETAINER - BLADE	CF6-80C2	NS	11
9382M63P02	RETAINER - BLADE	CF6-80C2	NS	105
9382M63P02	RETAINER - BLADE	CF6-80C2	NE	50
9382M63P02	RETAINER - BLADE	CF6-80C2	NS	98
9382M63P02	RETAINER - BLADE	CF6-80C2	NS	7
9382M75P02	SEAL - RETAINER STG 5	CF6-80C2	OH	15
9382M75P02	SEAL - RETAINER STG 5	CF6-80C2	OH	3
9382M77P01	LUG - LIFTING TRF	CF6-80C2	AR	2
9382M79P07	SEAL - MAGNETIC	CF6-80C2	NS	2
9382M93P02	SEAL - BYPASS	CF6-80C2	NE	6
9382M94P02	HPC STATOR VANE RETAINER STG 8	CF6-80C2	NS	4
9382M94P02	HPC STATOR VANE RETAINER STG 8	CF6-80C2	NS	5
9382M95P05	HPC STATOR VANE RETAINER STG 9-13	CF6-80C2	NE	20
9382M95P05	HPC STATOR VANE RETAINER STG 9-13	CF6-80C2	NS	25
9382M95P05	HPC STATOR VANE RETAINER STG 9-13	CF6-80C2	NE	10
9383M22P01	SEAL - RETAINER STG 4	CF6-80C2	SV	14
9383M47P03	LINK - YOKE	CF6-80C2	SV	1
9383M47P03	LINK - YOKE	CF6-80C2	AR	1
9383M47P03	LINK - YOKE	CF6-80C2	NE	1
9383M47P03	LINK - YOKE	CF6-80C2	OH	1
9383M47P03	LINK - YOKE	CF6-80C2	OH	1
9383M47P05	LINK - YOKE	CF6-80C2	SV	1
9383M47P05	LINK - YOKE	CF6-80C2	AR	1
9383M47P05	LINK - YOKE	CF6-80C2	NE	1
9383M47P05	LINK - YOKE	CF6-80C2	SV	1
9383M47P05	LINK - YOKE	CF6-80C2	SV	1
9383M47P05	LINK - YOKE	CF6-80C2	OH	1
9383M47P09	LINK - YOKE	CF6-80C2	OH	1
9383M57P001A	RETAINER - BOLT	CF6-80C2	NE	1
9383M58P001A	PLATE - LOCK	CF6-80C2	NE	1
9383M60P001A	RETAINER - BOLT	CF6-80C2	AR	2
9383M60P001A	RETAINER - BOLT	CF6-80C2	AR	1
9383M60P001A	RETAINER - BOLT	CF6-80C2	OH	2

Part Number	Part Description	Engine Type	Condition	Quantity
9383M60P001A	RETAINER - BOLT	CF6-80C2	SV	2
9383M60P001A	RETAINER - BOLT	CF6-80C2	AR	2
9383M60P001A	RETAINER - BOLT	CF6-80C2	OH	1
9383M60P001A	RETAINER - BOLT	CF6-80C2	AR	1
9383M60P001A	RETAINER - BOLT	CF6-80C2	SV	1
9383M61P005A	PLATE - LOCK	CF6-80C2	OH	1
9383M61P005A	PLATE - LOCK	CF6-80C2	NS	2
9383M61P005A	PLATE - LOCK	CF6-80C2	SV	2
9383M61P005A	PLATE - LOCK	CF6-80C2	AR	2
9383M61P005A	PLATE - LOCK	CF6-80C2	SV	1
9383M61P005A	PLATE - LOCK	CF6-80C2	SV	1
9383M68G05	VALVE ASSY - BYP	CF6-80C2	SV	1
9383M68G05	VALVE ASSY - BYP	CF6-80C2	SV	1
9383M68G05	VALVE ASSY - BYP	CF6-80C2	OH	1
9383M68G05	VALVE ASSY - BYP	CF6-80C2	SV	1
9383M73G06	COWL - COMB CHAMBER INNER	CF6-80C2	AR	1
9383M78P01	SEAL - BULB	CF6-80C2	AR	1
9383M87G01	MANIFOLD - OIL BRG 5	CF6-80C2, CF6-80A	AR	1
9383M87G01	MANIFOLD - OIL BRG 5	CF6-80C2, CF6-80A	AR	1
9383M88P12	HPT ROTOR DAMPER SEAL BODY STG 1	CF6-80C2	OH	1
9383M88P12	HPT ROTOR DAMPER SEAL BODY STG 1	CF6-80C2	OH	11
9383M88P12	HPT ROTOR DAMPER SEAL BODY STG 1	CF6-80C2	OH	20
9383M88P12	HPT ROTOR DAMPER SEAL BODY STG 1	CF6-80C2	OH	11
9383M88P12	HPT ROTOR DAMPER SEAL BODY STG 1	CF6-80C2	OH	1
9383M88P12	HPT ROTOR DAMPER SEAL BODY STG 1	CF6-80C2	OH	3
9383M88P12	HPT ROTOR DAMPER SEAL BODY STG 1	CF6-80C2	OH	8
9383M88P12	HPT ROTOR DAMPER SEAL BODY STG 1	CF6-80C2	OH	49
9383M88P12	HPT ROTOR DAMPER SEAL BODY STG 1	CF6-80C2	OH	80
9383M88P12	HPT ROTOR DAMPER SEAL BODY STG 1	CF6-80C2	OH	7
9383M88P12	HPT ROTOR DAMPER SEAL BODY STG 1	CF6-80C2	OH	80
9383M88P12	HPT ROTOR DAMPER SEAL BODY STG 1	CF6-80C2	OH	78
9383M88P12	HPT ROTOR DAMPER SEAL BODY STG 1	CF6-80C2	OH	7

Part Number	Part Description	Engine Type	Condition	Quantity
9385M22G09	VANE SEC - FAN BSTR STG 2	CF6-80C2	OH	1
9385M22G09	VANE SEC - FAN BSTR STG 2	CF6-80C2	OH	1
9385M22G09	VANE SEC - FAN BSTR STG 2	CF6-80C2	OH	1
9385M23G05	VANE SEC - FAN BSTR STG 3	CF6-80C2	AR	1
9385M23G05	VANE SEC - FAN BSTR STG 3	CF6-80C2	AR	1
9385M23G05	VANE SEC - FAN BSTR STG 3	CF6-80C2	SV	4
9385M23G05	VANE SEC - FAN BSTR STG 3	CF6-80C2	AR	4
9385M23G05	VANE SEC - FAN BSTR STG 3	CF6-80C2	SV	4
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	AR	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	AR	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	AR	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	AR	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	AR	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M23G09	VANE SEC - FAN BSTR STG 3	CF6-80C2	OH	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	OH	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	OH	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	OH	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	OH	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	OH	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	OH	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	OH	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	OH	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	OH	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	OH	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	OH	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	OH	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	OH	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	OH	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	OH	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	OH	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	OH	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	OH	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	OH	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	OH	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	OH	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	OH	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	OH	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	OH	1
9385M24G05	VANE SEC - FAN BSTR STG 4	CF6-80C2	OH	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G08	VANE SEC - FAN BSTR STG 4	CF6-80C2	AR	1
9385M24G09	VANE SEC - FAN BSTR STG 4	CF6-80C2	SV	1
9385M24G09	VANE SEC - FAN BSTR STG 4	CF6-80C2	SV	1
9385M27P02	SEAL - PLATFORM	CF6-80C2	NS	20
9385M27P02	SEAL - PLATFORM	CF6-80C2	NS	2
9385M27P02	SEAL - PLATFORM	CF6-80C2	NE	1

Part Number	Part Description	Engine Type	Condition	Quantity
9385M27P02	SEAL - PLATFORM	CF6-80C2	NE	19
9385M35P002A	RETAINER - STG 5	CF6-80C2	AR	24
9385M35P002A	RETAINER - STG 5	CF6-80C2	AR	24
9385M35P002A	RETAINER - STG 5	CF6-80C2	AR	18
9385M35P002A	RETAINER - STG 5	CF6-80C2	NE	1
9385M35P002A	RETAINER - STG 5	CF6-80C2	NE	2
9385M35P002A	RETAINER - STG 5	CF6-80C2	SV	24
9386M36G04	TUBE - AIR HP RECOUP	CF6-80C2	SV	1
9386M52G02	TUBE ASSY	CF6-80A	AR	1
9387M23P01	PLUG - IGNITER (TYPE IV)	CF6-80C2	AR	1
9387M23P01	PLUG - IGNITER (TYPE IV)	CF6-80C2	AR	1
9391M73P06	RETAINER - BOLT	CF6-80C2	NE	4
9391M73P06	RETAINER - BOLT	CF6-80C2	NE	1
9391M73P06	RETAINER - BOLT	CF6-80C2	NE	2
9391M73P06	RETAINER - BOLT	CF6-80C2	NE	9
9391M73P06	RETAINER - BOLT	CF6-80C2	NE	7
9391M73P06	RETAINER - BOLT	CF6-80C2	NE	3
9391M73P06	RETAINER - BOLT	CF6-80C2	NE	1
9391M73P06	RETAINER - BOLT	CF6-80C2	NE	14
9391M73P06	RETAINER - BOLT	CF6-80C2	NE	14
9391M73P06	RETAINER - BOLT	CF6-80C2	NE	14
9392M10G01	BELLCRANK - ACTR	CF6-80C2	NS	1
9392M10G01	BELLCRANK - ACTR	CF6-80C2	NS	1
9392M10G01	BELLCRANK - ACTR	CF6-80C2	OH	1
9392M10G01	BELLCRANK - ACTR	CF6-80C2	OH	1
9392M10G01	BELLCRANK - ACTR	CF6-80C2	AR	1
9392M10G01	BELLCRANK - ACTR	CF6-80C2	AR	1
9392M10G01	BELLCRANK - ACTR	CF6-80C2	OH	1
9392M11G01	TUBE - OIL IN	CF6-80C2	AR	1
9392M11G01	TUBE - OIL IN	CF6-80C2	AR	1
9392M11G01	TUBE - OIL IN	CF6-80C2	AR	1
9392M11G01	TUBE - OIL IN	CF6-80C2	AR	1
9392M11G01	TUBE - OIL IN	CF6-80C2	AR	1
9392M11G01	TUBE - OIL IN	CF6-80C2	AR	1
9392M11G02	TUBE - OIL IN	CF6-80C2	AR	1
9392M11G02	TUBE - OIL IN	CF6-80C2	AR	1
9392M11G02	TUBE - OIL IN	CF6-80C2	AR	1
9392M11G02	TUBE - OIL IN	CF6-80C2	AR	1
9392M11G02	TUBE - OIL IN	CF6-80C2	NS	1
9392M11G02	TUBE - OIL IN	CF6-80C2	OH	1
9392M11G02	TUBE - OIL IN	CF6-80C2	OH	1
9392M16G01	TUBE - OIL SUPPLY	CF6-80C2	NE	1
9392M16G01	TUBE - OIL SUPPLY	CF6-80C2	NE	1
9392M22P04	SEAL - WIRE	CF6-80C2	NS	24
9392M22P05	SEAL - WIRE	CF6-80C2	NE	27
9392M22P06	SEAL - WIRE	CF6-80C2	NS	25
9392M22P06	SEAL - WIRE	CF6-80C2	NS	2
9392M22P07	SEAL - WIRE	CF6-80C2	NE	1

Part Number	Part Description	Engine Type	Condition	Quantity
9392M25P01	KEY - CPRSR STTR CASING	CF6-80C2	OH	2
9392M25P01	KEY - CPRSR STTR CASING	CF6-80C2	SV	1
9392M26G01	TUBE - EXPANDABLE SEAL AIR	CF6-80C2	NE	1
9392M31P01	BEARING - BALL	CF6-80C2	AR	1
9392M31P01	BEARING - BALL	CF6-80C2	AR	1
9392M31P01	BEARING - BALL	CF6-80C2	AR	1
9392M31P01	BEARING - BALL	CF6-80C2	AR	1
9392M38G01	TUBE - OIL SUPPLY	CF6-80C2	AR	1
9392M38G01	TUBE - OIL SUPPLY	CF6-80C2	AR	1
9392M38G01	TUBE - OIL SUPPLY	CF6-80C2	NS	1
9392M39P01	EXTENSION - FLOWPATH	CF6-80C2	SV	1
9392M39P01	EXTENSION - FLOWPATH	CF6-80C2	AR	1
9392M39P02	EXTENSION - FLOWPATH	CF6-80C2	SV	1
9392M39P02	EXTENSION - FLOWPATH	CF6-80C2	AR	1
9392M53G02	#4R BEARING INNR RACE SPANNER NUT	CF6-80C2	AR	1
9392M53G02	#4R BEARING INNR RACE SPANNER NUT	CF6-80C2	OH	1
9392M53G02	#4R BEARING INNR RACE SPANNER NUT	CF6-80C2	OH	1
9392M53G02	#4R BEARING INNR RACE SPANNER NUT	CF6-80C2	OH	1
9392M53G02	#4R BEARING INNR RACE SPANNER NUT	CF6-80C2	OH	1
9392M55P04	#4B BEARING HOUSING	CF6-80C2	OH	1
9392M57P02	NOZZLE - OIL BRG NO. 4B	CF6-80C2	AR	1
9392M57P02	NOZZLE - OIL BRG NO. 4B	CF6-80C2	AR	1
9392M57P02	NOZZLE - OIL BRG NO. 4B	CF6-80C2	AR	1
9392M57P02	NOZZLE - OIL BRG NO. 4B	CF6-80C2	AR	1
9392M57P02	NOZZLE - OIL BRG NO. 4B	CF6-80C2	NE	1
9392M61P02	#4B BEARING OUTER SPANNER NUT	CF6-80C2	AR	1
9392M61P02	#4B BEARING OUTER SPANNER NUT	CF6-80C2	AR	1
9392M61P02	#4B BEARING OUTER SPANNER NUT	CF6-80C2	AR	1
9392M61P02	#4B BEARING OUTER SPANNER NUT	CF6-80C2	AR	1
9392M61P02	#4B BEARING OUTER SPANNER NUT	CF6-80C2	AR	1
9392M61P02	#4B BEARING OUTER SPANNER NUT	CF6-80C2	OH	1
9392M61P02	#4B BEARING OUTER SPANNER NUT	CF6-80C2	OH	1
9392M64P03	NOZZLE - OIL BRG NO. 4B	CF6-80C2	AR	1
9392M64P03	NOZZLE - OIL BRG NO. 4B	CF6-80C2	AR	1
9392M64P03	NOZZLE - OIL BRG NO. 4B	CF6-80C2	OH	1
9392M64P03	NOZZLE - OIL BRG NO. 4B	CF6-80C2	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9392M66P01	#4R BEARING AFT SUMP CLOSURE	CF6-80C2	AR	1
9392M66P01	#4R BEARING AFT SUMP CLOSURE	CF6-80C2	AR	1
9392M66P01	#4R BEARING AFT SUMP CLOSURE	CF6-80C2	AR	1
9392M66P01	#4R BEARING AFT SUMP CLOSURE	CF6-80C2	OH	1
9392M66P01	#4R BEARING AFT SUMP CLOSURE	CF6-80C2	OH	1
9392M79P03	BAFFLE - AIR COVER HPT	CF6-80C2	AR	4
9392M79P03	BAFFLE - AIR COVER HPT	CF6-80C2	AR	24
9392M79P03	BAFFLE - AIR COVER HPT	CF6-80C2	AR	4
9392M79P03	BAFFLE - AIR COVER HPT	CF6-80C2	AR	24
9392M79P03	BAFFLE - AIR COVER HPT	CF6-80C2	OH	4
9392M79P03	BAFFLE - AIR COVER HPT	CF6-80C2	OH	4
9392M79P03	BAFFLE - AIR COVER HPT	CF6-80C2	OH	1
9392M79P03	BAFFLE - AIR COVER HPT	CF6-80C2	OH	3
9392M79P03	BAFFLE - AIR COVER HPT	CF6-80C2	NE	3
9392M81G05	VANE ASSY - FAN STG 1	CF6-80C2	AR	24
9392M86G07	SHROUD - HPT STATOR STG 2	CF6-80C2	AR	1
9392M86G07	SHROUD - HPT STATOR STG 2	CF6-80C2	AR	1
9392M86G07	SHROUD - HPT STATOR STG 2	CF6-80C2	AR	1
9392M86G07	SHROUD - HPT STATOR STG 2	CF6-80C2	AR	1
9392M86G07	SHROUD - HPT STATOR STG 2	CF6-80C2	AR	1
9392M86G07	SHROUD - HPT STATOR STG 2	CF6-80C2	AR	1
9392M86G07	SHROUD - HPT STATOR STG 2	CF6-80C2	AR	1
9392M86G07	SHROUD - HPT STATOR STG 2	CF6-80C2	AR	1
9392M86G07	SHROUD - HPT STATOR STG 2	CF6-80C2	AR	1
9392M86G07	SHROUD - HPT STATOR STG 2	CF6-80C2	AR	1
9392M86G07	SHROUD - HPT STATOR STG 2	CF6-80C2	AR	1
9392M86G07	SHROUD - HPT STATOR STG 2	CF6-80C2	AR	1
9392M86G07	SHROUD - HPT STATOR STG 2	CF6-80C2	AR	1
9392M86G07	SHROUD - HPT STATOR STG 2	CF6-80C2	AR	1
9392M86G07	SHROUD - HPT STATOR STG 2	CF6-80C2	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9392M86G07	SHROUD - HPT STATOR STG 2	CF6-80C2	AR	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M86G10	SHROUD - HPT STATOR STG 2	CF6-80C2	OH	1
9392M87G06	SUPPORT - SHROUD HPT STG 2	CF6-80C2	OH	1
9392M87G06	SUPPORT - SHROUD HPT STG 2	CF6-80C2	OH	1
9392M88P01	CHANNEL - NUT	CF6-80C2, CF6-80A	AR	1
9392M88P01	CHANNEL - NUT	CF6-80C2, CF6-80A	AR	4
9392M88P01	CHANNEL - NUT	CF6-80C2, CF6-80A	NE	3

Part Number	Part Description	Engine Type	Condition	Quantity
9392M89P02	HPC STATOR ACT LEVER MNT STG IGV-5	CF6-80C2	OH	1
9392M90G10	SUPPORT ASSY - NOZZLE STG 1	CF6-80C2	AR	1
9392M90G10	SUPPORT ASSY - NOZZLE STG 1	CF6-80C2	AR	1
9392M91G01	BRACKET	CF6-80A	NS	2
9392M91G01	BRACKET	CF6-80A	NS	6
9392M91G01	BRACKET	CF6-80A	NS	1
9392M92G07	CRF FORWARD SUMP ASSY	CF6-80C2	SV	1
9392M92G07	CRF FORWARD SUMP ASSY	CF6-80C2	OH	1
9392M92G07	CRF FORWARD SUMP ASSY	CF6-80C2	SV	1
9392M93G03	HPC REAR FRAME AFT SUMP HSG	CF6-80C2	OH	1
9392M93G03	HPC REAR FRAME AFT SUMP HSG	CF6-80C2	OH	1
9392M94P11	RING - THRUST REVERSER	CF6-80C2	AR	1
9392M94P12	RING - SUPPORT THRUST	CF6-80C2	AR	1
9392M94P13	RING - THRUST REVERSER	CF6-80C2	NE	1
9392M97P01	BRACKET - LEAF SEAL	CF6-80C2	NE	2
9392M97P01	BRACKET - LEAF SEAL	CF6-80C2	NS	2
9392M97P01	BRACKET - LEAF SEAL	CF6-80C2	NS	3
9392M97P01	BRACKET - LEAF SEAL	CF6-80C2	NE	12
9392M97P01	BRACKET - LEAF SEAL	CF6-80C2	NS	20
9392M97P01	BRACKET - LEAF SEAL	CF6-80C2	NS	5
9392M97P01	BRACKET - LEAF SEAL	CF6-80C2	NE	7
9392M97P01	BRACKET - LEAF SEAL	CF6-80C2	NS	4
9392M98G01	HPT LEAF SEAL PINS	CF6-80C2	OH	6
9392M98G02	HPT LEAF SEAL PINS	CF6-80C2	AR	28
9392M99P01	RING - SUPPORT	CF6-80C2	AR	1
9392M99P01	RING - SUPPORT	CF6-80C2	AR	1
9392M99P01	RING - SUPPORT	CF6-80C2	NS	1
9392M99P01	RING - SUPPORT	CF6-80C2	AR	1
9395M22P04	ADAPTER - N1 CONTROL HSG	CF6-80C2	AR	1
9395M23G10	ADAPTER ASSY - N1 CONTROL	CF6-80C2	AR	1
9395M28P001A	PLATE - LOCK	CF6-80C2	SV	1
9395M28P001A	PLATE - LOCK	CF6-80C2	AR	1
9395M28P001A	PLATE - LOCK	CF6-80C2	OH	1
9395M28P001A	PLATE - LOCK	CF6-80C2	OH	1
9395M28P001A	PLATE - LOCK	CF6-80C2	AR	1
9395M28P001A	PLATE - LOCK	CF6-80C2	OH	1
9395M28P001A	PLATE - LOCK	CF6-80C2	OH	1
9395M49P02	MOUNT - OIL TANK	CF6-80C2	AR	1
9395M49P02	MOUNT - OIL TANK	CF6-80C2	AR	1
9395M61G01	SHIELD ASSY - SUPPORT	CF6-80C2	SV	1
9395M61G01	SHIELD ASSY - SUPPORT	CF6-80C2	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
9395M82P05	SEAL - STG 2	CF6-80C2	NE	15
9395M82P05	SEAL - STG 2	CF6-80C2	NE	1
9395M82P05	SEAL - STG 2	CF6-80C2	NE	8
9395M82P05	SEAL - STG 2	CF6-80C2	NE	24
9395M84P04	SEAL - STG 4	CF6-80C2	NE	2
9395M84P04	SEAL - STG 4	CF6-80C2	NE	9
9395M84P04	SEAL - STG 4	CF6-80C2	NE	14
9395M84P04	SEAL - STG 4	CF6-80C2	NE	123
9397M18P01	ADAPTER - INL GRBX	CF6-80C2	AR	1
9397M18P01	ADAPTER - INL GRBX	CF6-80C2	AR	1
9397M25P01	BEARING - ROLLER	CF6-80C2	AR	1
9397M26P01	BEARING - ROLLER	CF6-80C2	AR	1
9397M26P01	BEARING - ROLLER	CF6-80C2	AR	1
9397M26P01	BEARING - ROLLER	CF6-80C2	AR	1
9397M26P01	BEARING - ROLLER	CF6-80C2	OH	1
9397M27P01	BEARING - ROLLER	CF6-80C2	AR	1
9397M27P01	BEARING - ROLLER	CF6-80C2	AR	1
9397M28P02	BEARING - ROLLER	CF6-80C2	AR	1
9397M29P01	BEARING - ROLLER	CF6-80C2	AR	1
9397M30P01	BEARING - BALL	CF6-80C2	AR	1
9397M32P01	BEARING - BALL	CF6-80C2	AR	1
9397M33P01	BEARING - BALL	CF6-80C2	AR	1
9397M33P01	BEARING - BALL	CF6-80C2	AR	1
9397M33P01	BEARING - BALL	CF6-80C2	AR	1
9397M33P01	BEARING - BALL	CF6-80C2	AR	1
9397M33P01	BEARING - BALL	CF6-80C2	AR	1
9397M34P01	BEARING - BALL	CF6-80C2	AR	1
9397M34P01	BEARING - BALL	CF6-80C2	AR	1
9397M35P01	BEARING - BALL	CF6-80C2	AR	1
9397M36P01	BEARING - BALL	CF6-80C2	AR	1
9397M48G02	IGB HOUSING	CF6-80C2	AR	1
9397M48G02	IGB HOUSING	CF6-80C2	AR	1
9397M53P01	FERRULE - IGNTR PL (SPD)	CF6-80C2	NE	10
9397M53P01	FERRULE - IGNTR PL (SPD)	CF6-80C2	NE	8
9397M63G13	MANIFOLD - COOLING LPT	CF6-80C2	AR	1
9397M63G13	MANIFOLD - COOLING LPT	CF6-80C2	AR	1
9397M63G15	MANIFOLD - COOLING LPT	CF6-80C2	AR	1
9397M63G16	MANIFOLD - COOLING LPT	CF6-80C2	AR	1
9397M73G06	HANGER - SUPPORT HPT STTR	CF6-80C2	OH	1
9397M75G01	TUBE - OIL	CF6-80C2	AR	1
9397M76G02	TUBE - OIL	CF6-80C2	AR	1
9397M81P02	SEAL - NOZZLE OUTER	CF6-80C2	NE	3
9397M81P02	SEAL - NOZZLE OUTER	CF6-80C2	NE	16
9397M86G01	BRACKET - FWD INNER LINER	CF6-80C2	AR	8
9397M86G01	BRACKET - FWD INNER LINER	CF6-80C2	AR	8

Part Number	Part Description	Engine Type	Condition	Quantity
9397M86G01	BRACKET - FWD INNER LINER	CF6-80C2	AR	8
9397M86G01	BRACKET - FWD INNER LINER	CF6-80C2	OH	1
9397M86G01	BRACKET - FWD INNER LINER	CF6-80C2	AR	8
9397M87G01	BRACKET - FWD INNER LINER	CF6-80C2	AR	7
9397M87G01	BRACKET - FWD INNER LINER	CF6-80C2	AR	8
9397M87G01	BRACKET - FWD INNER LINER	CF6-80C2	AR	8
9397M87G01	BRACKET - FWD INNER LINER	CF6-80C2	AR	8
9397M87G01	BRACKET - FWD INNER LINER	CF6-80C2	AR	4
9397M87G01	BRACKET - FWD INNER LINER	CF6-80C2	AR	7
9397M87G01	BRACKET - FWD INNER LINER	CF6-80C2	NE	2
9397M92G02	LUG - LKG STG 2	CF6-80C2	AR	2
9397M92G02	LUG - LKG STG 2	CF6-80C2	AR	1
9397M92G02	LUG - LKG STG 2	CF6-80C2	OH	1
9397M92G02	LUG - LKG STG 2	CF6-80C2	OH	1
9397M92G02	LUG - LKG STG 2	CF6-80C2	OH	1
9397M92G02	LUG - LKG STG 2	CF6-80C2	OH	1
9397M92G02	LUG - LKG STG 2	CF6-80C2	OH	1
9397M93G02	LUG - LKG STG 3	CF6-80C2	OH	1
9397M93G02	LUG - LKG STG 3	CF6-80C2	OH	1
9397M93G02	LUG - LKG STG 3	CF6-80C2	AR	1
9397M93G02	LUG - LKG STG 3	CF6-80C2	OH	1
9397M93G02	LUG - LKG STG 3	CF6-80C2	OH	2
9397M93G02	LUG - LKG STG 3	CF6-80C2	OH	1
9397M93G02	LUG - LKG STG 3	CF6-80C2	OH	1
9397M93G02	LUG - LKG STG 3	CF6-80C2	OH	2
9397M93G02	LUG - LKG STG 3	CF6-80C2	OH	1
9397M93G02	LUG - LKG STG 3	CF6-80C2	OH	1
9397M94G02	LUG - LKG STG 4	CF6-80C2	AR	2
9397M94G02	LUG - LKG STG 4	CF6-80C2	AR	2
9397M94G02	LUG - LKG STG 4	CF6-80C2	OH	1
9397M94G02	LUG - LKG STG 4	CF6-80C2	OH	2
9397M94G02	LUG - LKG STG 4	CF6-80C2	OH	1
9397M94G02	LUG - LKG STG 4	CF6-80C2	OH	2
9397M94G02	LUG - LKG STG 4	CF6-80C2	OH	2
9397M94G02	LUG - LKG STG 4	CF6-80C2	OH	1
9397M94G02	LUG - LKG STG 4	CF6-80C2	OH	2
9397M94G02	LUG - LKG STG 4	CF6-80C2	REP	1
9397M95G02	LUG - LKG STG 5	CF6-80C2	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9397M95G02	LUG - LKG STG 5	CF6-80C2	OH	1
9397M95G02	LUG - LKG STG 5	CF6-80C2	AR	2
9397M95G02	LUG - LKG STG 5	CF6-80C2	AR	1
9397M95G02	LUG - LKG STG 5	CF6-80C2	OH	2
9397M95G02	LUG - LKG STG 5	CF6-80C2	OH	1
9397M95G02	LUG - LKG STG 5	CF6-80C2	OH	1
94122	COVER	CF6-50 (LMCO)	NS	1
94122	COVER	CF6-50 (LMCO)	NS	2
943D604-1	COVER - GEN. LEAD	CF6-50 (LMCO)	NS	2
9559M12G04	LINER - COMB CHAMBER OUTER	CF6-80A	AR	1
9559M19P01	SEAL - C	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9559M19P01	SEAL - C	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	26
9559M19P01	SEAL - C	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	13
9559M19P01	SEAL - C	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9559M20G01	SEAL ASSY - RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9559M20G01	SEAL ASSY - RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	10
9559M20G01	SEAL ASSY - RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	60
9559M20G01	SEAL ASSY - RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	9
9559M20G02	SEAL ASSY - RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	5

Part Number	Part Description	Engine Type	Condition	Quantity
9559M20G02	SEAL ASSY - RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	23
9559M20G02	SEAL ASSY - RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9600M64P03	RING - BRG NO. 6 INR	CF6-50	AR	1
9600M64P03	RING - BRG NO. 6 INR	CF6-50	AR	1
9600M64P03	RING - BRG NO. 6 INR	CF6-50	AR	1
9600M64P03	RING - BRG NO. 6 INR	CF6-50	AR	1
9600M64P11	RING - BRG INNER	CF6-50	AR	1
9600M64P11	RING - BRG INNER	CF6-50	AR	1
9600M64P11	RING - BRG INNER	CF6-50	AR	1
9600M64P11	RING - BRG INNER	CF6-50	AR	1
9600M64P11	RING - BRG INNER	CF6-50	AR	1
9600M64P11	RING - BRG INNER	CF6-50	AR	1
9600M76P06	BEARING - DX THR BALL	CF6-50	AR	1
9600M76P06	BEARING - DX THR BALL	CF6-50	AR	1
9600M76P06	BEARING - DX THR BALL	CF6-50	AR	1
9600M76P06	BEARING - DX THR BALL	CF6-50	AR	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M76P07	BEARING - DX THR BALL	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M76P09	BEARING - DX THR BALL	CF6-80A, CF6-50 (Boeing)	AR	1
9600M76P09	BEARING - DX THR BALL	CF6-80A, CF6-50 (Boeing)	AR	1
9600M76P09	BEARING - DX THR BALL	CF6-80A, CF6-50 (Boeing)	AR	1
9600M76P09	BEARING - DX THR BALL	CF6-80A, CF6-50 (Boeing)	AR	1
9600M76P09	BEARING - DX THR BALL	CF6-80A, CF6-50 (Boeing)	AR	1
9600M78P01	BEARING - CYL ROLLER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M78P01	BEARING - CYL ROLLER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M78P01	BEARING - CYL ROLLER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M78P01	BEARING - CYL ROLLER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M78P01	BEARING - CYL ROLLER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9600M78P01	BEARING - CYL ROLLER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9600M78P01	BEARING - CYL ROLLER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M78P01	BEARING - CYL ROLLER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M78P01	BEARING - CYL ROLLER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M78P02	BEARING - CYL ROLLER	CF6-80A, CF6-50	SV	1
9600M78P03	BEARING - CYL ROLLER	CF6-80A, CF6-50	AR	1
9600M78P03	BEARING - CYL ROLLER	CF6-80A, CF6-50	AR	1
9600M91P04	BEARING - ROLLER	CF6-50 (Boeing)	AR	1
9600M91P04	BEARING - ROLLER	CF6-50 (Boeing)	AR	1
9600M91P04	BEARING - ROLLER	CF6-50 (Boeing)	AR	1
9600M91P05	BEARING - ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M91P05	BEARING - ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9600M91P05	BEARING - ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M91P05	BEARING - ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M91P05	BEARING - ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M91P05	BEARING - ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M91P05	BEARING - ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9600M91P06	BEARING - ROLLER	CF6-50	AR	1
9600M91P06	BEARING - ROLLER	CF6-50	AR	1
9600M91P06	BEARING - ROLLER	CF6-50	AR	1
9600M94P05	BEARING - CYL ROLLER	CF6-50	AR	1
9600M94P06	BEARING - CYL ROLLER	CF6-50	AR	1
9600M94P06	BEARING - CYL ROLLER	CF6-50	AR	1
9600M94P06	BEARING - CYL ROLLER	CF6-50	AR	1
9600M94P06	BEARING - CYL ROLLER	CF6-50	AR	1
9600M94P06	BEARING - CYL ROLLER	CF6-50	AR	1
9600M94P06	BEARING - CYL ROLLER	CF6-50	OH	1
9600M94P06	BEARING - CYL ROLLER	CF6-50	AR	1
9600M94P06	BEARING - CYL ROLLER	CF6-50	AR	1
9600M94P06	BEARING - CYL ROLLER	CF6-50	AR	1
9600M94P06	BEARING - CYL ROLLER	CF6-50	AR	1
9600M94P06	BEARING - CYL ROLLER	CF6-50	AR	1
9600M94P06	BEARING - CYL ROLLER	CF6-50	AR	1
9600M94P06	BEARING - CYL ROLLER	CF6-50	AR	1
9600M94P06	BEARING - CYL ROLLER	CF6-50	AR	1
9600M94P08	BEARING - CYL ROLLER	CF6-50 (LMCO)	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
9600M94P08	BEARING - CYL ROLLER	CF6-50 (LMCO)	AR	1
9601M03P03	BEARING - ANLR BALL	CF6-50	AR	1
9601M03P03	BEARING - ANLR BALL	CF6-50	AR	1
9601M03P03	BEARING - ANLR BALL	CF6-50	AR	1
9601M03P03	BEARING - ANLR BALL	CF6-50	AR	1
9601M03P03	BEARING - ANLR BALL	CF6-50	AR	1
9601M03P03	BEARING - ANLR BALL	CF6-50	AR	1
9601M03P03	BEARING - ANLR BALL	CF6-50	AR	1
9601M03P03	BEARING - ANLR BALL	CF6-50	AR	1
9601M03P03	BEARING - ANLR BALL	CF6-50	AR	1
9601M03P03	BEARING - ANLR BALL	CF6-50	AR	1
9601M03P03	BEARING - ANLR BALL	CF6-50	AR	1
9601M03P03	BEARING - ANLR BALL	CF6-50	AR	1
9601M03P03	BEARING - ANLR BALL	CF6-50	AR	1
9601M36P02	NUT - INLET GRBX GRSHFT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9601M36P04	NUT - INLET GRBX GRSHFT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9601M36P04	NUT - INLET GRBX GRSHFT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M36P04	NUT - INLET GRBX GRSHFT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M36P04	NUT - INLET GRBX GRSHFT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M36P04	NUT - INLET GRBX GRSHFT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9601M36P04	NUT - INLET GRBX GRSHFT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M36P04	NUT - INLET GRBX GRSHFT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M36P04	NUT - INLET GRBX GRSHFT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9601M36P04	NUT - INLET GRBX GRSHFT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M36P04	NUT - INLET GRBX GRSHFT	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M42P01	HOUSING - GRSHFT DX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M43P01	HOUSING - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9601M43P01	HOUSING - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M43P01	HOUSING - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M43P01	HOUSING - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M43P01	HOUSING - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M43P01	HOUSING - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M43P01	HOUSING - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M43P01	HOUSING - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9601M43P01	HOUSING - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M43P01	HOUSING - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M43P01	HOUSING - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M43P01	HOUSING - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M43P01	HOUSING - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M43P01	HOUSING - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M43P01	HOUSING - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M43P01	HOUSING - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9601M43P01	HOUSING - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M43P01	HOUSING - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	2

Part Number	Part Description	Engine Type	Condition	Quantity
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	2
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9601M52P02	RETAINER - INLET GRBX BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M72P08	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9601M73P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M73P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M73P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M73P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9601M73P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M73P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M73P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M73P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M73P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M73P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M73P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M73P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9601M73P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9601M73P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9601M73P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9601M73P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9601M73P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9601M73P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9601M73P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9601M73P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9601M73P07	SEAL - CARBON FACE	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9606M45P01	SLEEVE - ACTN ARM	CF6-50	NS	40
9607M01P04	#3 BEARING NUT KEY RETAIN RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M01P04	#3 BEARING NUT KEY RETAIN RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M01P04	#3 BEARING NUT KEY RETAIN RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9607M01P04	#3 BEARING NUT KEY RETAIN RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M01P04	#3 BEARING NUT KEY RETAIN RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M01P04	#3 BEARING NUT KEY RETAIN RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M01P04	#3 BEARING NUT KEY RETAIN RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M01P04	#3 BEARING NUT KEY RETAIN RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M01P04	#3 BEARING NUT KEY RETAIN RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M01P04	#3 BEARING NUT KEY RETAIN RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M01P04	#3 BEARING NUT KEY RETAIN RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M01P04	#3 BEARING NUT KEY RETAIN RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9607M01P04	#3 BEARING NUT KEY RETAIN RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M01P04	#3 BEARING NUT KEY RETAIN RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9607M31P02	IGB SPACER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9607M31P02	IGB SPACER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9607M31P02	IGB SPACER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M31P02	IGB SPACER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M31P02	IGB SPACER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M31P02	IGB SPACER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M31P02	IGB SPACER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M31P02	IGB SPACER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M31P04	IGB SPACER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9607M31P04	IGB SPACER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9607M35P02	NUT - BRG 6 RND PL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M35P02	NUT - BRG 6 RND PL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M35P02	NUT - BRG 6 RND PL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M35P02	NUT - BRG 6 RND PL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M35P02	NUT - BRG 6 RND PL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9607M35P02	NUT - BRG 6 RND PL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M35P02	NUT - BRG 6 RND PL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M35P02	NUT - BRG 6 RND PL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M35P02	NUT - BRG 6 RND PL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9607M35P02	NUT - BRG 6 RND PL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M35P02	NUT - BRG 6 RND PL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9607M35P02	NUT - BRG 6 RND PL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M35P02	NUT - BRG 6 RND PL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M35P02	NUT - BRG 6 RND PL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M35P02	NUT - BRG 6 RND PL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9607M35P02	NUT - BRG 6 RND PL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M35P02	NUT - BRG 6 RND PL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M35P02	NUT - BRG 6 RND PL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M35P02	NUT - BRG 6 RND PL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M35P02	NUT - BRG 6 RND PL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M35P02	NUT - BRG 6 RND PL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M35P02	NUT - BRG 6 RND PL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M35P02	NUT - BRG 6 RND PL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M35P02	NUT - BRG 6 RND PL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M35P02	NUT - BRG 6 RND PL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M35P02	NUT - BRG 6 RND PL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M36P02	RING - BRG 6 LKNT KEYED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M36P02	RING - BRG 6 LKNT KEYED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M36P02	RING - BRG 6 LKNT KEYED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M36P02	RING - BRG 6 LKNT KEYED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M36P03	RING - BRG 6 LKNT KEYED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M36P03	RING - BRG 6 LKNT KEYED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M36P03	RING - BRG 6 LKNT KEYED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M36P03	RING - BRG 6 LKNT KEYED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M36P03	RING - BRG 6 LKNT KEYED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9607M36P03	RING - BRG 6 LKNT KEYED	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9607M80P04	RING - KEYED RTNG	CF6-50	AR	1
9607M80P04	RING - KEYED RTNG	CF6-50	AR	1
9609M07P03	BEARING - SELF ALIGN PL	CF6-50	NS	7
9609M08P01	BEARING - SELF ALIGNMENT	CF6-80C2, CF6-80A, CF6-50	NS	1
9609M08P01	BEARING - SELF ALIGNMENT	CF6-80C2, CF6-80A, CF6-50	NS	1
9609M08P03	BEARING - SELF ALIGNMENT	CF6-80A	NE	1
9609M08P03	BEARING - SELF ALIGNMENT	CF6-80A	NE	1
9609M13P02	GUIDE - ACTN LEVER	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9628M93P02	NOZZLE - BRG 4R AND 4B OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9628M93P02	NOZZLE - BRG 4R AND 4B OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9628M93P02	NOZZLE - BRG 4R AND 4B OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9628M93P02	NOZZLE - BRG 4R AND 4B OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9628M93P02	NOZZLE - BRG 4R AND 4B OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9628M93P02	NOZZLE - BRG 4R AND 4B OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9628M93P02	NOZZLE - BRG 4R AND 4B OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9628M93P02	NOZZLE - BRG 4R AND 4B OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9628M93P02	NOZZLE - BRG 4R AND 4B OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9628M93P02	NOZZLE - BRG 4R AND 4B OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9628M93P02	NOZZLE - BRG 4R AND 4B OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9630M15P01	PLUG - MACH THD	CF6-50	AR	1
9630M15P02	PLUG - MACH THD	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9630M15P02	PLUG - MACH THD	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9630M22P01	PLUG	CF6-50	AR	1
9630M22P02	PLUG	CF6-50	NS	1
9630M22P02	PLUG	CF6-50	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
9630M22P02	PLUG	CF6-50	OH	1
9630M22P02	PLUG	CF6-50	OH	1
9631M84P02	RING - RETAINING INTERNAL	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9631M84P06	RING - RETAINING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	20
9631M84P06	RING - RETAINING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9631M84P06	RING - RETAINING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9631M84P06	RING - RETAINING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9631M84P06	RING - RETAINING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	3
9631M84P06	RING - RETAINING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9631M84P06	RING - RETAINING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9631M84P06	RING - RETAINING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9631M84P09	RING - RETAINING INTERNAL	CF6-80A	NS	56
9631M84P13	RING - INTL RTNG	CF6-80C2, CF6-80A	NE	9
9633M14G20	ARM ASSY - VANE ACTN IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
9633M14G20	ARM ASSY - VANE ACTN IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	24

Part Number	Part Description	Engine Type	Condition	Quantity
9633M14G20	ARM ASSY - VANE ACTN IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9633M14G20	ARM ASSY - VANE ACTN IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	6
9633M14G20	ARM ASSY - VANE ACTN IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	5
9633M14G20	ARM ASSY - VANE ACTN IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9633M14G20	ARM ASSY - VANE ACTN IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	8
9633M14G21	HPC STATOR ACT ARM STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9633M14G21	HPC STATOR ACT ARM STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	11
9633M14G21	HPC STATOR ACT ARM STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	3
9633M14G21	HPC STATOR ACT ARM STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	3
9633M14G22	HPC STATOR ACT ARM STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
9633M14G22	HPC STATOR ACT ARM STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	27
9633M14G22	HPC STATOR ACT ARM STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	6

Part Number	Part Description	Engine Type	Condition	Quantity
9633M14G22	HPC STATOR ACT ARM STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9633M14G22	HPC STATOR ACT ARM STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	72
9633M14G22	HPC STATOR ACT ARM STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9633M14G23	HPC STATOR ACT ARM STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	42
9633M14G23	HPC STATOR ACT ARM STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	37
9633M14G23	HPC STATOR ACT ARM STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9633M14G23	HPC STATOR ACT ARM STG 3	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9633M15G20	ARM ASSY - VANE ACTN IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9633M15G20	ARM ASSY - VANE ACTN IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9633M15G20	ARM ASSY - VANE ACTN IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
9633M15G20	ARM ASSY - VANE ACTN IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9633M15G20	ARM ASSY - VANE ACTN IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4

Part Number	Part Description	Engine Type	Condition	Quantity
9633M15G20	ARM ASSY - VANE ACTN IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
9633M15G20	ARM ASSY - VANE ACTN IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
9633M15G20	ARM ASSY - VANE ACTN IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9633M15G20	ARM ASSY - VANE ACTN IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9633M15G21	HPC STATOR ACT ARM STG 1 [SPLITLINE]	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
9633M15G21	HPC STATOR ACT ARM STG 1 [SPLITLINE]	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9633M15G22	HPC STATOR ACT ARM STG 2 [SPLITLINE]	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	24
9633M15G22	HPC STATOR ACT ARM STG 2 [SPLITLINE]	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
9633M15G22	HPC STATOR ACT ARM STG 2 [SPLITLINE]	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	3
9633M15G22	HPC STATOR ACT ARM STG 2 [SPLITLINE]	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9633M15G23	HPC STATOR ACT ARM STG 3 [SPLITLINE]	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9633M15G23	HPC STATOR ACT ARM STG 3 [SPLITLINE]	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2

Part Number	Part Description	Engine Type	Condition	Quantity
9633M20G03	HPC STATOR ACT ARM STG 4 [SPLITLINE]	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
9633M20G03	HPC STATOR ACT ARM STG 4 [SPLITLINE]	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9633M20G03	HPC STATOR ACT ARM STG 4 [SPLITLINE]	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9633M20G03	HPC STATOR ACT ARM STG 4 [SPLITLINE]	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9633M20G03	HPC STATOR ACT ARM STG 4 [SPLITLINE]	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	7
9633M62G20	SEAL ASSY - CLG AND VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9633M62G20	SEAL ASSY - CLG AND VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9633M62G20	SEAL ASSY - CLG AND VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9633M62G20	SEAL ASSY - CLG AND VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9633M62G20	SEAL ASSY - CLG AND VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9633M62G20	SEAL ASSY - CLG AND VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9633M62G20	SEAL ASSY - CLG AND VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9633M62G20	SEAL ASSY - CLG AND VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9633M62G20	SEAL ASSY - CLG AND VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9633M62G20	SEAL ASSY - CLG AND VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9633M62G20	SEAL ASSY - CLG AND VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9633M62G20	SEAL ASSY - CLG AND VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9633M62G20	SEAL ASSY - CLG AND VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9633M62G20	SEAL ASSY - CLG AND VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9633M62G20	SEAL ASSY - CLG AND VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9633M62G20	SEAL ASSY - CLG AND VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9633M62G23	SEAL ASSY - CLG AND VENT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9633M62G23	SEAL ASSY - CLG AND VENT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9633M62G29	SEAL ASSY - CLG AND VENT	CF6-50	AR	1
9633M69P07	KEY - CPRSR STTR CASING	CF6-50	NS	1
9634M08P01	RETAINER - BEARING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	3
9634M08P01	RETAINER - BEARING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M08P01	RETAINER - BEARING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M08P01	RETAINER - BEARING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M08P01	RETAINER - BEARING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M08P01	RETAINER - BEARING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M08P01	RETAINER - BEARING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M08P01	RETAINER - BEARING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M08P01	RETAINER - BEARING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M08P01	RETAINER - BEARING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M08P01	RETAINER - BEARING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M08P01	RETAINER - BEARING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M08P01	RETAINER - BEARING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M08P01	RETAINER - BEARING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M08P01	RETAINER - BEARING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M08P01	RETAINER - BEARING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9634M08P01	RETAINER - BEARING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M08P01	RETAINER - BEARING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9634M08P01	RETAINER - BEARING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M08P01	RETAINER - BEARING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M08P01	RETAINER - BEARING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M08P01	RETAINER - BEARING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M08P01	RETAINER - BEARING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9634M08P01	RETAINER - BEARING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M08P01	RETAINER - BEARING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M47P02	RETAINER - BALL BRG	CF6-50 (LMCO)	AR	1
9634M47P02	RETAINER - BALL BRG	CF6-50 (LMCO)	AR	1
9634M47P02	RETAINER - BALL BRG	CF6-50 (LMCO)	AR	1
9634M47P02	RETAINER - BALL BRG	CF6-50 (LMCO)	AR	1
9634M47P02	RETAINER - BALL BRG	CF6-50 (LMCO)	AR	1
9634M47P02	RETAINER - BALL BRG	CF6-50 (LMCO)	AR	1
9634M47P02	RETAINER - BALL BRG	CF6-50 (LMCO)	AR	1
9634M47P02	RETAINER - BALL BRG	CF6-50 (LMCO)	OH	1
9634M47P02	RETAINER - BALL BRG	CF6-50 (LMCO)	AR	1
9634M47P02	RETAINER - BALL BRG	CF6-50 (LMCO)	AR	1
9634M47P02	RETAINER - BALL BRG	CF6-50 (LMCO)	NE	1
9634M47P02	RETAINER - BALL BRG	CF6-50 (LMCO)	NE	1
9634M47P02	RETAINER - BALL BRG	CF6-50 (LMCO)	AR	1
9634M47P02	RETAINER - BALL BRG	CF6-50 (LMCO)	AR	1
9634M47P02	RETAINER - BALL BRG	CF6-50 (LMCO)	OH	1
9634M47P02	RETAINER - BALL BRG	CF6-50 (LMCO)	AR	1
9634M47P02	RETAINER - BALL BRG	CF6-50 (LMCO)	AR	1
9634M85P07	RING - SEAL MATING	CF6-50 (LMCO)	OH	1
9634M85P09	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M85P09	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9634M85P09	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M85P09	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M85P09	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M85P09	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M85P09	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9634M85P09	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M85P09	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M85P09	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M85P09	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M85P09	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M85P09	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M85P09	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M85P09	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M85P09	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9634M85P10	RING - MATING	CF6-50 (LMCO)	AR	1
9634M85P10	RING - MATING	CF6-50 (LMCO)	AR	1
9634M85P10	RING - MATING	CF6-50 (LMCO)	AR	1
9634M85P10	RING - MATING	CF6-50 (LMCO)	AR	1
9634M85P10	RING - MATING	CF6-50 (LMCO)	AR	1
9634M85P10	RING - MATING	CF6-50 (LMCO)	AR	1
9634M85P10	RING - MATING	CF6-50 (LMCO)	AR	1
9634M85P10	RING - MATING	CF6-50 (LMCO)	AR	1
9634M85P10	RING - MATING	CF6-50 (LMCO)	AR	1
9634M85P10	RING - MATING	CF6-50 (LMCO)	AR	1
9634M85P10	RING - MATING	CF6-50 (LMCO)	AR	1
9634M85P10	RING - MATING	CF6-50 (LMCO)	AR	1
9634M85P10	RING - MATING	CF6-50 (LMCO)	NS	4
9634M85P10	RING - MATING	CF6-50 (LMCO)	NS	1
9634M85P10	RING - MATING	CF6-50 (LMCO)	NS	3
9634M85P10	RING - MATING	CF6-50 (LMCO)	NS	3
9634M85P10	RING - MATING	CF6-50 (LMCO)	NS	5
9634M85P10	RING - MATING	CF6-50 (LMCO)	AR	1
9634M85P11	RING - SEAL MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9634M85P11	RING - SEAL MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M85P11	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M85P11	RING - SEAL MATING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9634M85P11	RING - SEAL MATING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9634M85P11	RING - SEAL MATING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9634M85P11	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M85P11	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M85P11	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M85P11	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9634M85P11	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9634M85P11	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9634M85P11	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9634M85P11	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9634M85P11	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9634M85P11	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9634M85P11	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9634M85P11	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9634M85P11	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
9634M85P11	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9634M85P11	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M85P11	RING - MATING	CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9634M85P12	RING - SEAL MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M85P12	RING - SEAL MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M85P12	RING - SEAL MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9634M85P12	RING - SEAL MATING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9645M84P02	RETAINER - BRG 4B	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9645M84P02	RETAINER - BRG 4B	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9645M84P02	RETAINER - BRG 4B	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9645M84P02	RETAINER - BRG 4B	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9645M84P02	RETAINER - BRG 4B	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9645M84P02	RETAINER - BRG 4B	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9645M84P02	RETAINER - BRG 4B	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9645M84P02	RETAINER - BRG 4B	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9645M84P02	RETAINER - BRG 4B	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9645M84P02	RETAINER - BRG 4B	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9645M84P02	RETAINER - BRG 4B	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9646M10P03	HOUSING	CF6-50	AR	1
9646M10P04	HOUSING - BRG 4B	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9646M51P05	HPC STATOR VANE SLEEVE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
9646M51P05	HPC STATOR VANE SLEEVE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
9646M51P05	HPC STATOR VANE SLEEVE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	10
9646M51P05	HPC STATOR VANE SLEEVE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	29
9646M51P05	HPC STATOR VANE SLEEVE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	6
9646M51P05	HPC STATOR VANE SLEEVE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	2

Part Number	Part Description	Engine Type	Condition	Quantity
9646M51P05	HPC STATOR VANE SLEEVE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	2
9646M51P05	HPC STATOR VANE SLEEVE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	23
9646M51P05	HPC STATOR VANE SLEEVE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	6
9646M51P05	HPC STATOR VANE SLEEVE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	6
9646M51P05	HPC STATOR VANE SLEEVE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	19
9646M51P05	HPC STATOR VANE SLEEVE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9646M53P01	SPACER - IGV STG 1 - 2	CF6-50	AR	34
9646M87P03	MOUNT ASSY - GND HDLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9646M87P03	MOUNT ASSY - GND HDLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9646M87P03	MOUNT ASSY - GND HDLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9646M87P03	MOUNT ASSY - GND HDLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9646M87P03	MOUNT ASSY - GND HDLG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9646M87P03	MOUNT ASSY - GND HDLG	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9646M87P04	MOUNT - GND HDLG REAR VERT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9646M87P04	MOUNT - GND HDLG REAR VERT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9646M87P04	MOUNT - GND HDLG REAR VERT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9646M87P04	MOUNT - GND HDLG REAR VERT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9646M87P04	MOUNT - GND HDLG REAR VERT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9648M01P08	BEARING - NO. 4B ANLR BALL	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9648M01P14	BEARING - NO. 4B ANLR BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M01P14	BEARING - NO. 4B ANLR BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M01P14	BEARING - NO. 4B ANLR BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M01P14	BEARING - NO. 4B ANLR BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P02	RING - INTL RTNG	CF6-80A, CF6-50 (LMCO)	SV	1
9648M79P02	RING - INTL RTNG	CF6-80A, CF6-50 (LMCO)	OH	1
9648M79P02	RING - INTL RTNG	CF6-80A, CF6-50 (LMCO)	OH	1
9648M79P02	RING - INTL RTNG	CF6-80A, CF6-50 (LMCO)	AR	1
9648M79P02	RING - INTL RTNG	CF6-80A, CF6-50 (LMCO)	OH	1
9648M79P02	RING - INTL RTNG	CF6-80A, CF6-50 (LMCO)	AR	1
9648M79P02	RING - INTL RTNG	CF6-80A, CF6-50 (LMCO)	AR	1
9648M79P02	RING - INTL RTNG	CF6-80A, CF6-50 (LMCO)	AR	1
9648M79P02	RING - INTL RTNG	CF6-80A, CF6-50 (LMCO)	AR	1
9648M79P02	RING - INTL RTNG	CF6-80A, CF6-50 (LMCO)	AR	1
9648M79P02	RING - INTL RTNG	CF6-80A, CF6-50 (LMCO)	OH	1
9648M79P02	RING - INTL RTNG	CF6-80A, CF6-50 (LMCO)	AR	1
9648M79P02	RING - INTL RTNG	CF6-80A, CF6-50 (LMCO)	AR	1
9648M79P02	RING - INTL RTNG	CF6-80A, CF6-50 (LMCO)	AR	1
9648M79P02	RING - INTL RTNG	CF6-80A, CF6-50 (LMCO)	OH	1
9648M79P02	RING - INTL RTNG	CF6-80A, CF6-50 (LMCO)	AR	1
9648M79P02	RING - INTL RTNG	CF6-80A, CF6-50 (LMCO)	AR	1
9648M79P02	RING - INTL RTNG	CF6-80A, CF6-50 (LMCO)	AR	1
9648M79P02	RING - INTL RTNG	CF6-80A, CF6-50 (LMCO)	OH	1
9648M79P02	RING - INTL RTNG	CF6-80A, CF6-50 (LMCO)	AR	1
9648M79P02	RING - INTL RTNG	CF6-80A, CF6-50 (LMCO)	AR	1
9648M79P03	RING - INTL RTNG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P04	RING - INTL RTNG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P04	RING - INTL RTNG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P04	RING - INTL RTNG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9648M79P04	RING - INTL RTNG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P04	RING - INTL RTNG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P04	RING - INTL RTNG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P04	RING - INTL RTNG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P04	RING - INTL RTNG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P04	RING - INTL RTNG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P04	RING - INTL RTNG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P04	RING - INTL RTNG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P04	RING - INTL RTNG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P04	RING - INTL RTNG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P04	RING - INTL RTNG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P04	RING - INTL RTNG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P10	IGB BALANCED INT DAMPER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P10	IGB BALANCED INT DAMPER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P10	IGB BALANCED INT DAMPER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P10	IGB BALANCED INT DAMPER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P10	IGB BALANCED INT DAMPER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P10	IGB BALANCED INT DAMPER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P10	IGB BALANCED INT DAMPER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9648M79P10	IGB BALANCED INT DAMPER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P10	IGB BALANCED INT DAMPER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P10	IGB BALANCED INT DAMPER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P10	IGB BALANCED INT DAMPER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P10	IGB BALANCED INT DAMPER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P10	IGB BALANCED INT DAMPER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P10	IGB BALANCED INT DAMPER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P10	IGB BALANCED INT DAMPER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P10	IGB BALANCED INT DAMPER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P10	IGB BALANCED INT DAMPER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P10	IGB BALANCED INT DAMPER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P10	IGB BALANCED INT DAMPER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P10	IGB BALANCED INT DAMPER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P10	IGB BALANCED INT DAMPER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	3
9648M79P11	RING - RETAINING	CF6-50	NE	1
9648M79P11	RING - RETAINING	CF6-50	AR	1
9648M79P11	RING - RETAINING	CF6-50	AR	1
9648M79P16	RING - RETAINING INTERNAL	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1

Part Number	Part Description	Engine Type	Condition	Quantity
9648M79P16	RING - RETAINING INTERNAL	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9648M79P32	RING - RETAINING	CF6-50	OH	1
9648M79P32	RING - RETAINING	CF6-50	AR	1
9648M79P34	RING - INTL RTNG	CF6-80A, CF6-50	AR	1
9648M79P35	RING - INTL RTNG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P35	RING - INTL RTNG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P35	RING - INTL RTNG	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9648M79P42	IGB BALANCED INT DAMPER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P42	IGB BALANCED INT DAMPER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9648M79P42	IGB BALANCED INT DAMPER RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9649M16P28	RING - EXT THREADED	CF6-50	NE	2
9649M39P04	COUPLING - CLAMP	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9649M39P04	COUPLING - CLAMP	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9649M39P04	COUPLING - CLAMP	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9649M39P06	COUPLING - CLAMP	CF6-80C2, CF6-80A, CF6-50 (Boeing)	AR	1
9649M41P03	BEARING - PLAIN ROD END	CF6-80C2, CF6-80A, CF6-50	NS	1
9649M90P20	FLANGE	CF6-80C2	AR	1
9649M90P25	FLANGE - SWIVEL	CF6-80A	SV	1
9658M51P03	BEARING - ROLLER	CF6-50 (LMCO)	AR	1
9658M51P03	BEARING - ROLLER	CF6-50 (LMCO)	AR	1
9658M51P03	BEARING - ROLLER	CF6-50 (LMCO)	AR	1
9658M51P03	BEARING - ROLLER	CF6-50 (LMCO)	AR	1
9658M51P03	BEARING - ROLLER	CF6-50 (LMCO)	AR	1
9658M51P03	BEARING - ROLLER	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9658M53P03	BEARING - NO. 6 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M53P03	BEARING - NO. 6 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M53P03	BEARING - NO. 6 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M53P03	BEARING - NO. 6 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9658M53P03	BEARING - NO. 6 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M53P03	BEARING - NO. 6 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M53P03	BEARING - NO. 6 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M53P03	BEARING - NO. 6 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M53P03	BEARING - NO. 6 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M53P03	BEARING - NO. 6 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M53P03	BEARING - NO. 6 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M53P03	BEARING - NO. 6 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M53P03	BEARING - NO. 6 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M53P03	BEARING - NO. 6 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M53P03	BEARING - NO. 6 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M53P03	BEARING - NO. 6 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M53P03	BEARING - NO. 6 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M53P03	BEARING - NO. 6 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M53P03	BEARING - NO. 6 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M53P03	BEARING - NO. 6 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M54P03	BEARING - NO. 7 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M54P03	BEARING - NO. 7 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M54P03	BEARING - NO. 7 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M54P03	BEARING - NO. 7 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M54P03	BEARING - NO. 7 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9658M54P04	BEARING - NO. 7 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9658M54P04	BEARING - NO. 7 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9658M54P04	BEARING - NO. 7 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M54P04	BEARING - NO. 7 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M54P04	BEARING - NO. 7 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M54P04	BEARING - NO. 7 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M54P04	BEARING - NO. 7 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M54P04	BEARING - NO. 7 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M54P04	BEARING - NO. 7 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M54P04	BEARING - NO. 7 CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9658M66G06	LUG - LKG	CF6-80A	NS	2
9658M66G06	LUG - LKG	CF6-80A	NS	2
9658M67G07	LUG - LKG	CF6-80A, CF6-50	NE	2
965C395-1	TERMINAL BOARD	CF6-50 (LMCO)	NE	1
9661M12P01	RING - DAMPENING	CF6-50 (LMCO)	NE	1
9661M12P01	RING - DAMPENING	CF6-50 (LMCO)	NE	1
9661M12P01	RING - DAMPENING	CF6-50 (LMCO)	NS	1
9661M12P21	RING - DAMPENING	CF6-50 (LMCO), CF6-50 (Boeing)	NE	3
9661M12P26	RING - DAMPENING	CF6-50	NE	1
9662M01G05	MOUNT ASSY - GND HDLG	CF6-50	AR	1
9662M01G05	MOUNT ASSY - GND HDLG	CF6-50	AR	1
9662M15P03	NOZZLE - BRG 5 AND 6 LUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9662M15P05	NOZZLE - BRG 5 AND 6 LUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9662M15P05	NOZZLE - BRG 5 AND 6 LUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9662M26P01	COLLAR - SPLIT NUT BRG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9662M26P01	COLLAR - SPLIT NUT BRG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9662M26P01	COLLAR - SPLIT NUT BRG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9662M26P01	COLLAR - SPLIT NUT BRG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9662M26P01	COLLAR - SPLIT NUT BRG 4	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9671M26P09	BEARING - NO. 4R CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9671M26P09	BEARING - NO. 4R CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9671M26P09	BEARING - NO. 4R CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9671M26P09	BEARING - NO. 4R CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9671M26P09	BEARING - NO. 4R CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9671M26P09	BEARING - NO. 4R CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9671M26P09	BEARING - NO. 4R CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9671M26P09	BEARING - NO. 4R CYL RLR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	SV	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	OH	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1
9671M28P01	NUT - BRG 5 INR RACE RND PL	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9673M66G07	LEVER ASSY - ACTUATION	CF6-50	AR	1
9673M66G07	LEVER ASSY - ACTUATION	CF6-50	AR	1
9673M66G09	LEVER ASSY - ACTUATION	CF6-50 (Boeing)	AR	1
9673M66G10	LEVER ASSY - ACTUATION	CF6-50 (LMCO)	AR	1
9673M66G10	LEVER ASSY - ACTUATION	CF6-50 (LMCO)	AR	1
9673M66G10	LEVER ASSY - ACTUATION	CF6-50 (LMCO)	AR	1
9673M66G10	LEVER ASSY - ACTUATION	CF6-50 (LMCO)	AR	1
9673M66G10	LEVER ASSY - ACTUATION	CF6-50 (LMCO)	AR	1
9673M66G10	LEVER ASSY - ACTUATION	CF6-50 (LMCO)	AR	1
9673M66G10	LEVER ASSY - ACTUATION	CF6-50 (LMCO)	AR	1
9673M66G10	LEVER ASSY - ACTUATION	CF6-50 (LMCO)	AR	1
9673M66G10	LEVER ASSY - ACTUATION	CF6-50 (LMCO)	AR	1
9673M66G10	LEVER ASSY - ACTUATION	CF6-50 (LMCO)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9673M66G13	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9673M66G23	HPC STATOR VANE ACT LEVER ARM ASSY	CF6-80C2	OH	1
96763-19	HOSE ASSY	CF6-80A	AR	1
96763-19	HOSE ASSY	CF6-80A	AR	1
96763-21	HOSE ASSY	CF6-80A	AR	1
96763-21	HOSE ASSY	CF6-80A	AR	1
9680M72P02	PLUG - BORESCOPE STG 2	CF6-50 (LMCO)	NS	1
9680M73G01	PLUG ASSY	CF6-50 (Boeing)	OH	1
9680M73G01	PLUG ASSY	CF6-50 (Boeing)	NS	2
9680M73G02	PLUG ASSY - BORESCOPE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9680M73G02	PLUG ASSY - BORESCOPE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9680M73G02	PLUG ASSY - BORESCOPE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9680M73G03	PLUG ASSY - BORESCOPE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9680M73G03	PLUG ASSY - BORESCOPE STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9680M93P03	HPC ROTOR SPLINED ADAPTER RETAINING RING	CF6-80C2, CF6-80A	AR	1
9680M93P03	HPC ROTOR SPLINED ADAPTER RETAINING RING	CF6-80C2, CF6-80A	AR	1
9680M93P04	HPC ROTOR SPLINED ADAPTER RETAINING RING	CF6-80C2, CF6-80A	AR	1
9680M93P04	HPC ROTOR SPLINED ADAPTER RETAINING RING	CF6-80C2, CF6-80A	AR	1
9680M93P04	HPC ROTOR SPLINED ADAPTER RETAINING RING	CF6-80C2, CF6-80A	AR	1
9680M93P04	HPC ROTOR SPLINED ADAPTER RETAINING RING	CF6-80C2, CF6-80A	NS	1
9681M32P01	PLATE - BRG NO. 5 LOCK	CF6-50	NS	1
9681M32P01	PLATE - BRG NO. 5 LOCK	CF6-50	AR	1
9682M74P01	REDUCER - TUBE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	11
9682M74P01	REDUCER - TUBE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	6

Part Number	Part Description	Engine Type	Condition	Quantity
9682M74P01	REDUCER - TUBE	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9683M98P01	SPACER - FLANGE	CF6-50 (Boeing)	NS	44
9683M98P01	SPACER - FLANGE	CF6-50 (Boeing)	NS	1
9683M98P01	SPACER - FLANGE	CF6-50 (Boeing)	NS	1
9683M98P04	SPACER - FLANGE	CF6-50	NS	1
9683M98P04	SPACER - FLANGE	CF6-50	NS	2
9683M98P05	SPACER - FLANGE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	3
9683M98P06	SPACER - FLANGE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9683M98P11	SPACER - FLANGE	CF6-80A	NE	2
9683M98P11	SPACER - FLANGE	CF6-80A	NE	1
9683M98P11	SPACER - FLANGE	CF6-80A	NE	1
9683M98P11	SPACER - FLANGE	CF6-80A	NE	1
9683M98P14	SPACER - FLANGE	CF6-80A	NE	1
9683M98P14	SPACER - FLANGE	CF6-80A	NE	2
9683M98P14	SPACER - FLANGE	CF6-80A	NE	3
9683M98P14	SPACER - FLANGE	CF6-80A	NE	2
96849-503	HOSE - PNEUMATIC	CF6-50 (LMCO)	AR	1
96849-505	HOSE ASSY - PIPE	CF6-50 (LMCO)	AR	1
96849-505	HOSE ASSY - PIPE	CF6-50 (LMCO)	AR	1
96849-505	HOSE ASSY - PIPE	CF6-50 (LMCO)	AR	1
9685M55P02	CAP - STRUT NO. 3	CF6-50	AR	1
9685M56P02	SLEEVE - OVAL	CF6-50	NE	1
9686M18P24	SEAL - HPT STTR	CF6-50 (LMCO), CF6-50 (Boeing)	NE	38
9686M18P24	SEAL - HPT STTR	CF6-50 (LMCO), CF6-50 (Boeing)	NE	3
9686M18P25	SEAL - HPT STTR	CF6-50	NS	8
9686M18P25	SEAL - HPT STTR	CF6-50	NS	4
9686M18P25	SEAL - HPT STTR	CF6-50	NS	2
9686M18P26	SEAL - HPT STTR	CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9686M18P26	SEAL - HPT STTR	CF6-50 (LMCO), CF6-50 (Boeing)	NE	74
9686M18P26	SEAL - HPT STTR	CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9686M18P37	SEAL - HP TURB STTR	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9686M18P37	SEAL - HP TURB STTR	CF6-50 (LMCO), CF6-50 (Boeing)	NE	4
9686M18P37	SEAL - HP TURB STTR	CF6-50 (LMCO), CF6-50 (Boeing)	NE	3
9686M18P37	SEAL - HP TURB STTR	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
9686M18P37	SEAL - HP TURB STTR	CF6-50 (LMCO), CF6-50 (Boeing)	NS	3
9686M18P37	SEAL - HP TURB STTR	CF6-50 (LMCO), CF6-50 (Boeing)	NS	48
9686M18P37	SEAL - HP TURB STTR	CF6-50 (LMCO), CF6-50 (Boeing)	NS	25
9686M18P37	SEAL - HP TURB STTR	CF6-50 (LMCO), CF6-50 (Boeing)	NS	25
9686M18P37	SEAL - HP TURB STTR	CF6-50 (LMCO), CF6-50 (Boeing)	NS	12
9686M18P37	SEAL - HP TURB STTR	CF6-50 (LMCO), CF6-50 (Boeing)	NS	4
9686M18P47	SEAL - HPT STATOR	CF6-80C2, CF6-80A	NE	13
9686M18P47	SEAL - HPT STATOR	CF6-80C2, CF6-80A	NE	2
9686M18P47	SEAL - HPT STATOR	CF6-80C2, CF6-80A	NE	3
9686M18P47	SEAL - HPT STATOR	CF6-80C2, CF6-80A	NE	25
9686M18P47	SEAL - HPT STATOR	CF6-80C2, CF6-80A	NE	16
9686M18P48	SEAL - HPT STATOR	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	30
9686M18P48	SEAL - HPT STATOR	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	51
9686M18P50	SEAL - HPT STATOR	CF6-80A	NS	7
9686M18P50	SEAL - HPT STATOR	CF6-80A	NS	42
9686M80P01	PLUG - MACH THD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9686M80P01	PLUG - MACH THD	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9686M80P01	PLUG - MACH THD	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9686M80P01	PLUG - MACH THD	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9686M80P01	PLUG - MACH THD	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9686M80P01	PLUG - MACH THD	CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9686M80P02	PLUG - MACH THD	CF6-80C2, CF6-80A	SV	1
9686M80P02	PLUG - MACH THD	CF6-80C2, CF6-80A	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
9686M80P02	PLUG - MACH THD	CF6-80C2, CF6-80A	SV	1
9686M80P02	PLUG - MACH THD	CF6-80C2, CF6-80A	SV	1
9686M80P02	PLUG - MACH THD	CF6-80C2, CF6-80A	SV	1
9686M80P02	PLUG - MACH THD	CF6-80C2, CF6-80A	SV	1
9686M80P02	PLUG - MACH THD	CF6-80C2, CF6-80A	NE	3
9686M86P01	PLUG - MACH THD	CF6-80C2, CF6-80A	AR	1
9686M86P01	PLUG - MACH THD	CF6-80C2, CF6-80A	NE	1
9686M86P01	PLUG - MACH THD	CF6-80C2, CF6-80A	NS	1
9686M86P01	PLUG - MACH THD	CF6-80C2, CF6-80A	NS	1
9686M86P01	PLUG - MACH THD	CF6-80C2, CF6-80A	NS	1
9686M86P01	PLUG - MACH THD	CF6-80C2, CF6-80A	NS	1
9686M86P01	PLUG - MACH THD	CF6-80C2, CF6-80A	SV	1
9686M86P01	PLUG - MACH THD	CF6-80C2, CF6-80A	SV	1
9690M72P04	BEARING - BALL NO. 1	CF6-50 (LMCO)	AR	1
9690M72P04	BEARING - BALL NO. 1	CF6-50 (LMCO)	AR	1
9690M72P04	BEARING - BALL NO. 1	CF6-50 (LMCO)	AR	1
9690M72P04	BEARING - BALL NO. 1	CF6-50 (LMCO)	AR	1
9690M72P04	BEARING - BALL NO. 1	CF6-50 (LMCO)	AR	1
9690M72P04	BEARING - BALL NO. 1	CF6-50 (LMCO)	AR	1
9690M72P04	BEARING - BALL NO. 1	CF6-50 (LMCO)	AR	1
9690M72P04	BEARING - BALL NO. 1	CF6-50 (LMCO)	AR	1
9690M72P04	BEARING - BALL NO. 1	CF6-50 (LMCO)	AR	1
9690M72P04	BEARING - BALL NO. 1	CF6-50 (LMCO)	AR	1
9690M72P04	BEARING - BALL NO. 1	CF6-50 (LMCO)	AR	1
9690M72P04	BEARING - BALL NO. 1	CF6-50 (LMCO)	AR	1
9690M72P04	BEARING - BALL NO. 1	CF6-50 (LMCO)	AR	1
9690M72P04	BEARING - BALL NO. 1	CF6-50 (LMCO)	AR	1
9690M72P04	BEARING - BALL NO. 1	CF6-50 (LMCO)	AR	1
9690M72P06	BEARING - BALL	CF6-50 (LMCO)	AR	1
9690M72P06	BEARING - BALL	CF6-50 (LMCO)	AR	1
9690M72P06	BEARING - BALL	CF6-50 (LMCO)	AR	1
9690M72P06	BEARING - BALL	CF6-50 (LMCO)	AR	1
9690M72P06	BEARING - BALL	CF6-50 (LMCO)	AR	1
9690M72P06	BEARING - BALL	CF6-50 (LMCO)	AR	1
9690M72P06	BEARING - BALL	CF6-50 (LMCO)	AR	1
9690M72P06	BEARING - BALL	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9690M72P06	BEARING - BALL	CF6-50 (LMCO)	AR	1
9690M72P06	BEARING - BALL	CF6-50 (LMCO)	AR	1
9690M72P06	BEARING - BALL	CF6-50 (LMCO)	AR	1
9690M72P06	BEARING - BALL	CF6-50 (LMCO)	AR	1
9691M29P11	ACTUATOR - VSV R/H	CF6-80A, CF6-50 (LMCO)	AR	1
9691M29P11	ACTUATOR - VSV R/H	CF6-80A, CF6-50 (LMCO)	AR	1
9691M29P16	ACTUATOR - VAR STTR	CF6-80C2	AR	1
9693M16P06	SPACER - CDP 4R AIR SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9693M16P06	SPACER - CDP 4R AIR SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9693M16P07	SPACER - CDP 4R AIR SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9693M16P07	SPACER - CDP 4R AIR SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9693M16P07	SPACER - CDP 4R AIR SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9693M16P07	SPACER - CDP 4R AIR SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9693M16P07	SPACER - CDP 4R AIR SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9693M16P07	SPACER - CDP 4R AIR SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9693M16P07	SPACER - CDP 4R AIR SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9693M16P07	SPACER - CDP 4R AIR SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9693M16P07	SPACER - CDP 4R AIR SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9693M18P04	RING - PISTON	CF6-50 (LMCO), CF6-50 (Boeing)	NE	12
9693M18P04	RING - PISTON	CF6-50 (LMCO), CF6-50 (Boeing)	NE	4
9693M33P01	RING - BRG 4 SPLINED LOCK	CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
9693M56P02	NUT ASSY - SLFLKG	CF6-50	AR	2
9693M59P02	SLEEVE - WELD	CF6-80A	NE	1
9693M68G04	SPACER ASSY - ACTN RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	61
9693M68G04	SPACER ASSY - ACTN RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	200
9693M86P03	SEAL - BRG 4R VENT AIR ROT	CF6-50	AR	1
9693M86P03	SEAL - BRG 4R VENT AIR ROT	CF6-50	AR	1
9693M86P03	SEAL - BRG 4R VENT AIR ROT	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9693M86P03	SEAL - BRG 4R VENT AIR ROT	CF6-50	AR	1
9693M86P03	SEAL - BRG 4R VENT AIR ROT	CF6-50	AR	1
9693M86P03	SEAL - BRG 4R VENT AIR ROT	CF6-50	AR	1
9693M86P03	SEAL - BRG 4R VENT AIR ROT	CF6-50	OH	1
9693M86P03	SEAL - BRG 4R VENT AIR ROT	CF6-50	AR	1
9693M86P03	SEAL - BRG 4R VENT AIR ROT	CF6-50	AR	1
9695M93G01	NUT ASSY - SLFLKG	CF6-80A, CF6-50	NE	1
9696M22P04	SHIELD - BRG NO. 6 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9696M22P04	SHIELD - BRG NO. 6 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9696M22P04	SHIELD - BRG NO. 6 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9696M22P04	SHIELD - BRG NO. 6 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9696M22P04	SHIELD - BRG NO. 6 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9696M22P04	SHIELD - BRG NO. 6 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9696M22P04	SHIELD - BRG NO. 6 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9696M22P04	SHIELD - BRG NO. 6 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9696M22P04	SHIELD - BRG NO. 6 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9696M22P04	SHIELD - BRG NO. 6 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9696M22P04	SHIELD - BRG NO. 6 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9696M22P04	SHIELD - BRG NO. 6 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9696M22P04	SHIELD - BRG NO. 6 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9696M22P04	SHIELD - BRG NO. 6 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9696M22P04	SHIELD - BRG NO. 6 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9696M22P04	SHIELD - BRG NO. 6 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9696M22P04	SHIELD - BRG NO. 6 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9696M22P04	SHIELD - BRG NO. 6 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9696M22P04	SHIELD - BRG NO. 6 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9696M22P04	SHIELD - BRG NO. 6 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9696M22P04	SHIELD - BRG NO. 6 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9696M22P04	SHIELD - BRG NO. 6 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9696M22P04	SHIELD - BRG NO. 6 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9696M22P04	SHIELD - BRG NO. 6 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9696M22P04	SHIELD - BRG NO. 6 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9696M22P04	SHIELD - BRG NO. 6 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9696M22P04	SHIELD - BRG NO. 6 OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9696M24P12	SPACER - RING (.040-.045)	CF6-50 (LMCO)	NS	1
9696M24P12	SPACER - RING (.040-.045)	CF6-50 (LMCO)	NS	1
9696M24P16	SPACER - RING (.120-.125)	CF6-50 (LMCO)	OH	1
9696M24P16	SPACER - RING (.120-.125)	CF6-50 (LMCO)	AR	1
9696M24P16	SPACER - RING (.120-.125)	CF6-50 (LMCO)	OH	1
9696M24P35	SPACER - RING (.060-.065)	CF6-50 (Boeing)	NS	1
9696M24P37	SPACER - RING (.100-.105)	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9696M24P37	SPACER - RING (.100-.105)	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9696M24P38	SPACER - RING (.120-.125)	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9696M24P38	SPACER - RING (.120-.125)	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9696M24P39	SPACER - RING (.140-.145)	CF6-50 (LMCO)	NE	144
9697M15P02	SLEEVE	CF6-50 (LMCO)	AR	8
9697M15P05	SLEEVE	CF6-50 (LMCO)	AR	5
9697M15P05	SLEEVE	CF6-50 (LMCO)	SV	8
9697M15P05	SLEEVE	CF6-50 (LMCO)	AR	7
9697M19P01	PLUG - MACH THD	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9697M19P01	PLUG - MACH THD	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9697M19P01	PLUG - MACH THD	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M61P01	NOZZLE - OIL BRG	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M64P01	RING - BRG NO. 7 INR	CF6-50	AR	1
9698M64P01	RING - BRG NO. 7 INR	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9698M65G01	SEAL - OIL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M01P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M01P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M01P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M01P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M01P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M01P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M01P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M01P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M01P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M01P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M01P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M01P03	BEARING	CF6-50 (LMCO)	AR	1
9699M01P03	BEARING	CF6-50 (LMCO)	AR	1
9699M01P03	BEARING	CF6-50 (LMCO)	AR	1
9699M01P03	BEARING	CF6-50 (LMCO)	AR	1
9699M02P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9699M02P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9699M02P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9699M02P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M02P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P02	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P03	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P03	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P03	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P03	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P03	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P03	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P03	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P03	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P03	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M02P03	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P03	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P03	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P03	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P03	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P03	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M02P03	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M03P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M03P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M03P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M03P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M03P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M03P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M03P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M03P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M03P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M03P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M03P02	BEARING	CF6-50	AR	1
9699M03P02	BEARING	CF6-50	AR	1
9699M04P01	BEARING - CYL ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M04P01	BEARING - CYL ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M04P01	BEARING - CYL ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M04P01	BEARING - CYL ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M04P01	BEARING - CYL ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M04P01	BEARING - CYL ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M04P01	BEARING - CYL ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M04P01	BEARING - CYL ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M04P01	BEARING - CYL ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M04P01	BEARING - CYL ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M04P01	BEARING - CYL ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M04P01	BEARING - CYL ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M04P01	BEARING - CYL ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M04P01	BEARING - CYL ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M04P01	BEARING - CYL ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M04P01	BEARING - CYL ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M04P01	BEARING - CYL ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M04P02	BEARING - CYL ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M04P02	BEARING - CYL ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M04P02	BEARING - CYL ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M04P02	BEARING - CYL ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M04P02	BEARING - CYL ROLLER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M06P01	BEARING	CF6-50 (LMCO)	AR	1
9699M06P01	BEARING	CF6-50 (LMCO)	AR	1
9699M06P01	BEARING	CF6-50 (LMCO)	AR	1
9699M06P01	BEARING	CF6-50 (LMCO)	AR	1
9699M06P01	BEARING	CF6-50 (LMCO)	AR	1
9699M06P01	BEARING	CF6-50 (LMCO)	AR	1
9699M06P01	BEARING	CF6-50 (LMCO)	AR	1
9699M06P01	BEARING	CF6-50 (LMCO)	AR	1
9699M06P01	BEARING	CF6-50 (LMCO)	AR	1
9699M06P01	BEARING	CF6-50 (LMCO)	OH	1
9699M06P01	BEARING	CF6-50 (LMCO)	AR	1
9699M06P01	BEARING	CF6-50 (LMCO)	AR	1
9699M06P01	BEARING	CF6-50 (LMCO)	AR	1
9699M06P01	BEARING	CF6-50 (LMCO)	AR	1
9699M06P01	BEARING	CF6-50 (LMCO)	AR	1
9699M06P01	BEARING	CF6-50 (LMCO)	AR	1
9699M06P01	BEARING	CF6-50 (LMCO)	AR	1
9699M06P01	BEARING	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M06P01	BEARING	CF6-50 (LMCO)	AR	1
9699M06P01	BEARING	CF6-50 (LMCO)	AR	1
9699M06P01	BEARING	CF6-50 (LMCO)	AR	1
9699M06P01	BEARING	CF6-50 (LMCO)	AR	1
9699M06P01	BEARING	CF6-50 (LMCO)	AR	1
9699M06P01	BEARING	CF6-50 (LMCO)	AR	1
9699M06P01	BEARING	CF6-50 (LMCO)	AR	1
9699M06P02	BEARING	CF6-50	AR	1
9699M06P02	BEARING	CF6-50	AR	1
9699M06P02	BEARING	CF6-50	AR	1
9699M06P02	BEARING	CF6-50	AR	1
9699M06P02	BEARING	CF6-50	AR	1
9699M07P02	BEARING - ANLR BALL	CF6-50	AR	1
9699M07P08	BEARING - ANLR BALL	CF6-50 (LMCO)	AR	1
9699M07P08	BEARING - ANLR BALL	CF6-50 (LMCO)	AR	1
9699M07P08	BEARING - ANLR BALL	CF6-50 (LMCO)	AR	1
9699M07P08	BEARING - ANLR BALL	CF6-50 (LMCO)	AR	1
9699M07P08	BEARING - ANLR BALL	CF6-50 (LMCO)	AR	1
9699M07P08	BEARING - ANLR BALL	CF6-50 (LMCO)	AR	1
9699M07P08	BEARING - ANLR BALL	CF6-50 (LMCO)	AR	1
9699M07P08	BEARING - ANLR BALL	CF6-50 (LMCO)	AR	1
9699M07P08	BEARING - ANLR BALL	CF6-50 (LMCO)	AR	1
9699M07P08	BEARING - ANLR BALL	CF6-50 (LMCO)	AR	1
9699M07P08	BEARING - ANLR BALL	CF6-50 (LMCO)	AR	1
9699M07P08	BEARING - ANLR BALL	CF6-50 (LMCO)	AR	1
9699M07P09	BEARING - ANLR BALL	CF6-50	AR	1
9699M07P09	BEARING - ANLR BALL	CF6-50	AR	1
9699M07P09	BEARING - ANLR BALL	CF6-50	AR	1
9699M07P09	BEARING - ANLR BALL	CF6-50	AR	1
9699M07P09	BEARING - ANLR BALL	CF6-50	AR	1
9699M07P09	BEARING - ANLR BALL	CF6-50	AR	1
9699M08P01	BEARING - ANLR BALL	CF6-50	AR	1
9699M08P02	BEARING - ANLR BALL	CF6-50 (LMCO)	AR	1
9699M08P02	BEARING - ANLR BALL	CF6-50 (LMCO)	AR	1
9699M08P02	BEARING - ANLR BALL	CF6-50 (LMCO)	AR	1
9699M08P02	BEARING - ANLR BALL	CF6-50 (LMCO)	AR	1
9699M08P02	BEARING - ANLR BALL	CF6-50 (LMCO)	AR	1
9699M08P02	BEARING - ANLR BALL	CF6-50 (LMCO)	AR	1
9699M08P02	BEARING - ANLR BALL	CF6-50 (LMCO)	OH	1
9699M08P02	BEARING - ANLR BALL	CF6-50 (LMCO)	AR	1
9699M08P02	BEARING - ANLR BALL	CF6-50 (LMCO)	AR	1
9699M08P02	BEARING - ANLR BALL	CF6-50 (LMCO)	AR	1
9699M08P02	BEARING - ANLR BALL	CF6-50 (LMCO)	AR	1
9699M08P03	BEARING - ANLR BALL	CF6-50	AR	1
9699M08P03	BEARING - ANLR BALL	CF6-50	AR	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M09P03	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P03	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P03	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P03	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M09P03	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M11P01	BEARING	CF6-50 (Boeing)	AR	1
9699M11P01	BEARING	CF6-50 (Boeing)	AR	1
9699M11P01	BEARING	CF6-50 (Boeing)	AR	1
9699M11P01	BEARING	CF6-50 (Boeing)	AR	1
9699M11P01	BEARING	CF6-50 (Boeing)	AR	1
9699M11P01	BEARING	CF6-50 (Boeing)	AR	1
9699M11P01	BEARING	CF6-50 (Boeing)	AR	1
9699M11P01	BEARING	CF6-50 (Boeing)	AR	1
9699M11P01	BEARING	CF6-50 (Boeing)	AR	1
9699M11P01	BEARING	CF6-50 (Boeing)	AR	1
9699M11P02	BEARING	CF6-50	AR	1
9699M11P02	BEARING	CF6-50	AR	1
9699M12P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M12P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M12P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M12P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M12P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M12P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M12P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M12P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M12P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M12P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M12P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M12P02	BEARING	CF6-50	AR	1
9699M12P02	BEARING	CF6-50	AR	1
9699M12P02	BEARING	CF6-50	AR	1
9699M14P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M14P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M14P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M14P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M14P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M14P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M14P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M14P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M14P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M14P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M14P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M15P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M15P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M15P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M15P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M15P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M15P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M15P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M15P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M15P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M15P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M15P01	BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M15P02	BEARING	CF6-50	AR	1
9699M15P02	BEARING	CF6-50	AR	1
9699M15P02	BEARING	CF6-50	AR	1
9699M16P03	BEARING - ANLR BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M16P03	BEARING - ANLR BALL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M16P03	BEARING - ANLR BALL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M17P04	GEARSHAFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M17P04	GEARSHAFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M17P04	GEARSHAFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M17P04	GEARSHAFT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M17P05	GEARSHAFT	CF6-50 (Boeing)	AR	1
9699M27P01	PLATE - XFR GRBX COVER	CF6-50	AR	1
9699M27P01	PLATE - XFR GRBX COVER	CF6-50	AR	1
9699M30P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M30P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9699M30P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9699M30P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M30P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9699M30P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9699M30P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M30P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M30P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9699M30P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M30P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M30P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M30P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9699M30P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M30P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M30P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9699M30P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9699M30P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9699M30P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
9699M30P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M30P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M34G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	AR	1
9699M34G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	AR	1
9699M34G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	AR	1
9699M34G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	AR	1
9699M34G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	AR	1
9699M34G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	AR	1
9699M34G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	AR	1
9699M34G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	AR	1
9699M34G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	NS	1
9699M34G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	AR	1
9699M34G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	AR	1
9699M34G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	AR	1
9699M34G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	AR	1
9699M34G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	OH	1
9699M34G02	ADAPTER ASSY - IDLER	CF6-50 (LMCO)	AR	1
9699M38G05	ADAPTER ASSY - IDL/FUEL PUMP	CF6-50	OH	1
9699M38G05	ADAPTER ASSY - IDL/FUEL PUMP	CF6-50	OH	1
9699M38G05	ADAPTER ASSY - IDL/FUEL PUMP	CF6-50	AR	1
9699M38G05	ADAPTER ASSY - IDL/FUEL PUMP	CF6-50	AR	1
9699M38G05	ADAPTER ASSY - IDL/FUEL PUMP	CF6-50	AR	1
9699M38G06	ADAPTER ASSY - IDL/FUEL PUMP	CF6-50	AR	1
9699M38G06	ADAPTER ASSY - IDL/FUEL PUMP	CF6-50	AR	1
9699M38G06	ADAPTER ASSY - IDL/FUEL PUMP	CF6-50	OH	1
9699M38G06	ADAPTER ASSY - IDL/FUEL PUMP	CF6-50	AR	1
9699M38G07	ADAPTER ASSY - AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M38G07	ADAPTER ASSY - AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M38G07	ADAPTER ASSY - AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M38G07	ADAPTER ASSY - AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M38G07	ADAPTER ASSY - AFT	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M38G07	ADAPTER ASSY - AFT	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M42G05	ADAPTER ASSY - STARTER	CF6-50	AR	1
9699M42G05	ADAPTER ASSY - STARTER	CF6-50	AR	1
9699M42G07	ADAPTER ASSY - STARTER	CF6-50 (LMCO)	OH	1
9699M42G07	ADAPTER ASSY - STARTER	CF6-50 (LMCO)	AR	1
9699M42G07	ADAPTER ASSY - STARTER	CF6-50 (LMCO)	AR	1
9699M42G07	ADAPTER ASSY - STARTER	CF6-50 (LMCO)	AR	1
9699M42G07	ADAPTER ASSY - STARTER	CF6-50 (LMCO)	OH	1
9699M42G07	ADAPTER ASSY - STARTER	CF6-50 (LMCO)	AR	1
9699M42G07	ADAPTER ASSY - STARTER	CF6-50 (LMCO)	AR	1
9699M42G07	ADAPTER ASSY - STARTER	CF6-50 (LMCO)	AR	1
9699M42G07	ADAPTER ASSY - STARTER	CF6-50 (LMCO)	AR	1
9699M42G07	ADAPTER ASSY - STARTER	CF6-50 (LMCO)	AR	1
9699M42G07	ADAPTER ASSY - STARTER	CF6-50 (LMCO)	AR	1
9699M42G07	ADAPTER ASSY - STARTER	CF6-50 (LMCO)	OH	1
9699M42G07	ADAPTER ASSY - STARTER	CF6-50 (LMCO)	AR	1
9699M44G02	ADAPTER ASSY - CONST SP DR	CF6-50	AR	1
9699M44G03	ADAPTER ASSY - CONST SP DR	CF6-50	AR	1
9699M44G05	ADAPTER ASSY - CONST SP DR	CF6-50 (LMCO)	OH	1
9699M44G05	ADAPTER ASSY - CONST SP DR	CF6-50 (LMCO)	AR	1
9699M44G05	ADAPTER ASSY - CONST SP DR	CF6-50 (LMCO)	AR	1
9699M44G05	ADAPTER ASSY - CONST SP DR	CF6-50 (LMCO)	AR	1
9699M44G05	ADAPTER ASSY - CONST SP DR	CF6-50 (LMCO)	AR	1
9699M44G05	ADAPTER ASSY - CONST SP DR	CF6-50 (LMCO)	AR	1
9699M44G05	ADAPTER ASSY - CONST SP DR	CF6-50 (LMCO)	AR	1
9699M44G05	ADAPTER ASSY - CONST SP DR	CF6-50 (LMCO)	AR	1
9699M44G05	ADAPTER ASSY - CONST SP DR	CF6-50 (LMCO)	AR	1
9699M44G05	ADAPTER ASSY - CONST SP DR	CF6-50 (LMCO)	AR	1
9699M44G05	ADAPTER ASSY - CONST SP DR	CF6-50 (LMCO)	AR	1
9699M44G05	ADAPTER ASSY - CONST SP DR	CF6-50 (LMCO)	AR	1
9699M44G05	ADAPTER ASSY - CONST SP DR	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M46G01	ADAPTER ASSY - HYDR PMP	CF6-50 (Boeing)	AR	1
9699M46G01	ADAPTER ASSY - HYDR PMP	CF6-50 (Boeing)	AR	1
9699M46G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M46G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M46G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M46G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M46G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M46G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M46G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M46G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M46G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M46G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M46G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M46G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M46G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M47G01	ADAPTER ASSY - HYDR PMP	CF6-50	OH	1
9699M47G01	ADAPTER ASSY - HYDR PMP	CF6-50	AR	1
9699M47G01	ADAPTER ASSY - HYDR PMP	CF6-50	AR	1
9699M47G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO)	OH	1
9699M47G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO)	AR	1
9699M47G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO)	AR	1
9699M47G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO)	AR	1
9699M47G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO)	OH	1
9699M47G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO)	AR	1
9699M47G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M47G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO)	AR	1
9699M47G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO)	AR	1
9699M47G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO)	OH	1
9699M47G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO)	AR	1
9699M47G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO)	AR	1
9699M47G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO)	AR	1
9699M47G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO)	OH	1
9699M47G03	ADAPTER ASSY - HYDR PMP	CF6-50 (LMCO)	AR	1
9699M49G01	ADAPTER ASSY - LUBE PUMP	CF6-50	AR	1
9699M49G01	ADAPTER ASSY - LUBE PUMP	CF6-50	AR	1
9699M49G01	ADAPTER ASSY - LUBE PUMP	CF6-50	AR	1
9699M49G01	ADAPTER ASSY - LUBE PUMP	CF6-50	OH	1
9699M49G01	ADAPTER ASSY - LUBE PUMP	CF6-50	AR	1
9699M49G01	ADAPTER ASSY - LUBE PUMP	CF6-50	AR	1
9699M49G01	ADAPTER ASSY - LUBE PUMP	CF6-50	AR	1
9699M49G01	ADAPTER ASSY - LUBE PUMP	CF6-50	AR	1
9699M50P03	GEARSHAFT - 54 TOOTH SPUR	CF6-50	AR	1
9699M50P03	GEARSHAFT - 54 TOOTH SPUR	CF6-50	OH	1
9699M50P03	GEARSHAFT - 54 TOOTH SPUR	CF6-50	AR	1
9699M50P04	GEARSHAFT - 54 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M50P04	GEARSHAFT - 54 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M50P04	GEARSHAFT - 54 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M50P04	GEARSHAFT - 54 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M50P04	GEARSHAFT - 54 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M50P04	GEARSHAFT - 54 TOOTH SPUR	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M50P04	GEARSHAFT - 54 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M50P04	GEARSHAFT - 54 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M50P04	GEARSHAFT - 54 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M50P04	GEARSHAFT - 54 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M50P04	GEARSHAFT - 54 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M50P04	GEARSHAFT - 54 TOOTH SPUR	CF6-50 (LMCO)	OH	1
9699M50P04	GEARSHAFT - 54 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M51P01	GEARSHAFT - 77 TOOTH SPUR	CF6-50	AR	1
9699M51P02	GEARSHAFT - 77 TOOTH SPUR	CF6-50 (LMCO)	OH	1
9699M51P02	GEARSHAFT - 77 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M51P02	GEARSHAFT - 77 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M51P02	GEARSHAFT - 77 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M51P02	GEARSHAFT - 77 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M51P02	GEARSHAFT - 77 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M51P02	GEARSHAFT - 77 TOOTH SPUR	CF6-50 (LMCO)	OH	1
9699M51P02	GEARSHAFT - 77 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M51P02	GEARSHAFT - 77 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M51P02	GEARSHAFT - 77 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M51P02	GEARSHAFT - 77 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M51P02	GEARSHAFT - 77 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M51P02	GEARSHAFT - 77 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M51P02	GEARSHAFT - 77 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M51P02	GEARSHAFT - 77 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M51P02	GEARSHAFT - 77 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M51P02	GEARSHAFT - 77 TOOTH SPUR	CF6-50 (LMCO)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M51P02	GEARSHAFT - 77 TOOTH SPUR	CF6-50 (LMCO)	OH	1
9699M51P02	GEARSHAFT - 77 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M53P02	GEARSHAFT - 52 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M53P02	GEARSHAFT - 52 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M53P02	GEARSHAFT - 52 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M53P02	GEARSHAFT - 52 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M53P02	GEARSHAFT - 52 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M53P02	GEARSHAFT - 52 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M53P02	GEARSHAFT - 52 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M53P02	GEARSHAFT - 52 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M53P02	GEARSHAFT - 52 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M53P02	GEARSHAFT - 52 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M53P02	GEARSHAFT - 52 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M53P02	GEARSHAFT - 52 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M53P02	GEARSHAFT - 52 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M54P02	GEARSHAFT - 67 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M54P02	GEARSHAFT - 67 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M54P02	GEARSHAFT - 67 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M54P02	GEARSHAFT - 67 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M54P02	GEARSHAFT - 67 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M54P02	GEARSHAFT - 67 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M54P02	GEARSHAFT - 67 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9699M54P02	GEARSHAFT - 67 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M54P02	GEARSHAFT - 67 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M54P02	GEARSHAFT - 67 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M54P02	GEARSHAFT - 67 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M54P02	GEARSHAFT - 67 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M54P02	GEARSHAFT - 67 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M54P02	GEARSHAFT - 67 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M54P02	GEARSHAFT - 67 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M55P02	GEARSHAFT - 75 TOOTH SPUR	CF6-50	AR	1
9699M55P02	GEARSHAFT - 75 TOOTH SPUR	CF6-50	OH	1
9699M55P02	GEARSHAFT - 75 TOOTH SPUR	CF6-50	AR	1
9699M55P02	GEARSHAFT - 75 TOOTH SPUR	CF6-50	AR	1
9699M55P03	GEARSHAFT - 75 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M55P03	GEARSHAFT - 75 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M55P03	GEARSHAFT - 75 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M55P03	GEARSHAFT - 75 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M55P03	GEARSHAFT - 75 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M55P03	GEARSHAFT - 75 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M55P03	GEARSHAFT - 75 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M55P03	GEARSHAFT - 75 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M55P03	GEARSHAFT - 75 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M55P03	GEARSHAFT - 75 TOOTH SPUR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M57P01	GEARSHAFT - 75 TOOTH SPUR	CF6-50	AR	1
9699M57P02	GEARSHAFT - 75 TOOTH SPUR	CF6-50	AR	1
9699M57P02	GEARSHAFT - 75 TOOTH SPUR	CF6-50	OH	1
9699M57P02	GEARSHAFT - 75 TOOTH SPUR	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M57P03	GEARSHAFT - 75 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M57P03	GEARSHAFT - 75 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M57P03	GEARSHAFT - 75 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M57P03	GEARSHAFT - 75 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M57P03	GEARSHAFT - 75 TOOTH SPUR	CF6-50 (LMCO)	OH	1
9699M57P03	GEARSHAFT - 75 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M57P03	GEARSHAFT - 75 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M57P03	GEARSHAFT - 75 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M57P03	GEARSHAFT - 75 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M57P03	GEARSHAFT - 75 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M57P03	GEARSHAFT - 75 TOOTH SPUR	CF6-50 (LMCO)	AR	1
9699M58G01	CLUSTER ASSY - SPUR GEAR	CF6-50	AR	1
9699M58G02	CLUSTER ASSY - SPUR GEAR	CF6-50	AR	1
9699M58G02	CLUSTER ASSY - SPUR GEAR	CF6-50	OH	1
9699M58G02	CLUSTER ASSY - SPUR GEAR	CF6-50	AR	1
9699M58G03	GEAR - CLUSTER	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M58G03	GEAR - CLUSTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M58G03	GEAR - CLUSTER	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M59P08	SHAFT - DRIVE RADIAL	CF6-50	AR	1
9699M59P09	SHAFT - DRIVE RADIAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M59P09	SHAFT - DRIVE RADIAL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M59P09	SHAFT - DRIVE RADIAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M59P09	SHAFT - DRIVE RADIAL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M59P09	SHAFT - DRIVE RADIAL	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M59P09	SHAFT - DRIVE RADIAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M59P09	SHAFT - DRIVE RADIAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M59P09	SHAFT - DRIVE RADIAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M59P09	SHAFT - DRIVE RADIAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M59P09	SHAFT - DRIVE RADIAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M59P09	SHAFT - DRIVE RADIAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M59P09	SHAFT - DRIVE RADIAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M59P09	SHAFT - DRIVE RADIAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M60P07	SHAFT - RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M60P07	SHAFT - RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M60P07	SHAFT - RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M60P07	SHAFT - RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M60P07	SHAFT - RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M60P07	SHAFT - RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M60P07	SHAFT - RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M60P07	SHAFT - RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M60P07	SHAFT - RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M60P07	SHAFT - RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M60P07	SHAFT - RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M61P03	SHAFT - RDL DR	CF6-50	AR	1
9699M61P04	SHAFT - RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M61P04	SHAFT - RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M61P04	SHAFT - RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M61P04	SHAFT - RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M61P04	SHAFT - RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M61P04	SHAFT - RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M61P04	SHAFT - RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M63P01	SHAFT - HORIZ DR	CF6-50	AR	1
9699M63P02	SHAFT - HORIZ DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M63P02	SHAFT - HORIZ DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M63P02	SHAFT - HORIZ DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M63P02	SHAFT - HORIZ DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M63P02	SHAFT - HORIZ DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M63P02	SHAFT - HORIZ DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M63P02	SHAFT - HORIZ DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M63P02	SHAFT - HORIZ DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M63P02	SHAFT - HORIZ DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M63P02	SHAFT - HORIZ DR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M63P02	SHAFT - HORIZ DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M63P02	SHAFT - HORIZ DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M63P02	SHAFT - HORIZ DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M63P02	SHAFT - HORIZ DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M63P02	SHAFT - HORIZ DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M63P02	SHAFT - HORIZ DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M63P02	SHAFT - HORIZ DR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M63P02	SHAFT - HORIZ DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M63P02	SHAFT - HORIZ DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M63P03	SHAFT - HORIZ DR	CF6-50	AR	1
9699M63P03	SHAFT - HORIZ DR	CF6-50	AR	1
9699M65P13	HOUSING - BEARING	CF6-50 (LMCO)	OH	1
9699M65P13	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P13	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P13	HOUSING - BEARING	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M65P13	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P13	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P13	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P13	HOUSING - BEARING	CF6-50 (LMCO)	OH	1
9699M65P13	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P13	HOUSING - BEARING	CF6-50 (LMCO)	OH	1
9699M65P13	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P13	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P13	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P13	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P13	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P13	HOUSING - BEARING	CF6-50 (LMCO)	OH	1
9699M65P13	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P15	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P15	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P15	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9699M65P15	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9699M65P15	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9699M65P15	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9699M65P15	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9699M65P15	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9699M65P15	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9699M65P15	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9699M65P15	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P15	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P15	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P15	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P15	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P15	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P15	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M65P15	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P15	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9699M65P15	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M65P15	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M65P15	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9699M65P16	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P16	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P16	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P16	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9699M65P16	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P16	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P16	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M65P16	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P16	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P16	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P16	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P16	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P16	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M65P16	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P17	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P18	HOUSING - BEARING	CF6-50 (LMCO)	OH	1
9699M65P19	HOUSING - BEARING	CF6-50 (LMCO)	OH	1
9699M65P20	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M65P20	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P20	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P20	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P20	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P20	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P20	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P20	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P20	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P20	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P20	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P20	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P20	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M65P20	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P21	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P21	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P21	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P21	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P21	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P21	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P21	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P21	HOUSING - BEARING	CF6-50 (LMCO)	OH	1
9699M65P21	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P21	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P21	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P21	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P21	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P21	HOUSING - BEARING	CF6-50 (LMCO)	OH	1
9699M65P21	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P22	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M65P22	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P22	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M65P22	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P22	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P22	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9699M65P22	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P22	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P22	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P22	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M65P22	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P22	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P22	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P22	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P22	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P22	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M65P22	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	OH	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	SV	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	OH	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	OH	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	OH	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	OH	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M65P23	HOUSING - BEARING	CF6-50 (LMCO)	AR	1
9699M67P01	RETAINER - RDL DR SFT HSG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M67P01	RETAINER - RDL DR SFT HSG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M67P01	RETAINER - RDL DR SFT HSG	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M67P01	RETAINER - RDL DR SFT HSG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M67P01	RETAINER - RDL DR SFT HSG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M67P01	RETAINER - RDL DR SFT HSG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M67P01	RETAINER - RDL DR SFT HSG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M67P01	RETAINER - RDL DR SFT HSG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M67P01	RETAINER - RDL DR SFT HSG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M67P01	RETAINER - RDL DR SFT HSG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M67P01	RETAINER - RDL DR SFT HSG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M67P01	RETAINER - RDL DR SFT HSG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M69G01	HOUSING ASSY - HORIZ	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M69G01	HOUSING ASSY - HORIZ	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M69G01	HOUSING ASSY - HORIZ	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M69G01	HOUSING ASSY - HORIZ	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M69G01	HOUSING ASSY - HORIZ	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M69G01	HOUSING ASSY - HORIZ	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M69G01	HOUSING ASSY - HORIZ	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M69G01	HOUSING ASSY - HORIZ	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M69G01	HOUSING ASSY - HORIZ	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M69G01	HOUSING ASSY - HORIZ	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M69G01	HOUSING ASSY - HORIZ	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M69G01	HOUSING ASSY - HORIZ	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M69G01	HOUSING ASSY - HORIZ	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M69G01	HOUSING ASSY - HORIZ	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M69G01	HOUSING ASSY - HORIZ	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M69G01	HOUSING ASSY - HORIZ	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M69G01	HOUSING ASSY - HORIZ	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M69G01	HOUSING ASSY - HORIZ	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M69G01	HOUSING ASSY - HORIZ	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M69G01	HOUSING ASSY - HORIZ	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M69G01	HOUSING ASSY - HORIZ	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M70P01	NOZZLE - RDL DR SFT OIL	CF6-50	NS	1
9699M75P01	NOZZLE - LUBE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M75P01	NOZZLE - LUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M75P01	NOZZLE - LUBE	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M75P01	NOZZLE - LUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M75P01	NOZZLE - LUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M75P01	NOZZLE - LUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M75P01	NOZZLE - LUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M75P01	NOZZLE - LUBE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M77P01	RING - RETAINING	CF6-50 (Boeing)	NS	1
9699M77P01	RING - RETAINING	CF6-50 (Boeing)	OH	1
9699M80P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M80P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M80P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M80P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M80P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M80P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M80P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M80P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M80P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M80P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M80P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M80P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M80P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M81P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M81P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M81P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M81P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M81P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M81P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M81P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M81P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M81P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M81P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M81P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M81P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M81P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M82P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M82P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M82P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M82P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M82P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M82P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M82P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M82P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M82P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M82P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M82P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M82P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M82P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M82P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M82P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M83P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M83P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M83P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M83P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M83P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M83P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M83P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M83P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M83P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M83P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M83P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M83P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M83P01	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M87P02	HOUSING - XFR GRBX DX BRG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M87P02	HOUSING - XFR GRBX DX BRG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M87P02	HOUSING - XFR GRBX DX BRG	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M87P02	HOUSING - XFR GRBX DX BRG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M87P02	HOUSING - XFR GRBX DX BRG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M87P02	HOUSING - XFR GRBX DX BRG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M87P02	HOUSING - XFR GRBX DX BRG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M87P02	HOUSING - XFR GRBX DX BRG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M87P02	HOUSING - XFR GRBX DX BRG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M87P02	HOUSING - XFR GRBX DX BRG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M87P02	HOUSING - XFR GRBX DX BRG	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M88P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M88P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M88P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M88P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M88P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M88P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M88P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M88P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M88P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M88P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M88P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M88P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M88P01	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M89G04	SHAFT ASSY - LWR RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M89G04	SHAFT ASSY - LWR RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M89G04	SHAFT ASSY - LWR RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M89G04	SHAFT ASSY - LWR RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M89G04	SHAFT ASSY - LWR RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M89G04	SHAFT ASSY - LWR RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M89G04	SHAFT ASSY - LWR RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M89G04	SHAFT ASSY - LWR RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M89G04	SHAFT ASSY - LWR RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M89G04	SHAFT ASSY - LWR RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M89G04	SHAFT ASSY - LWR RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M89G04	SHAFT ASSY - LWR RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M89G04	SHAFT ASSY - LWR RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M89G04	SHAFT ASSY - LWR RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M89G04	SHAFT ASSY - LWR RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M89G04	SHAFT ASSY - LWR RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M89G04	SHAFT ASSY - LWR RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M89G04	SHAFT ASSY - LWR RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M89G04	SHAFT ASSY - LWR RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M89G04	SHAFT ASSY - LWR RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M89G04	SHAFT ASSY - LWR RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M89G04	SHAFT ASSY - LWR RDL DR	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M92P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M92P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M92P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M92P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M92P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M92P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M92P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M92P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M92P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M92P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M92P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M92P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M92P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M92P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M92P02	HOUSING - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P01	RETAINER - BEARING	CF6-50 (LMCO)	OH	1
9699M95P01	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P01	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P01	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P01	RETAINER - BEARING	CF6-50 (LMCO)	SV	1
9699M95P01	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P01	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P01	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P01	RETAINER - BEARING	CF6-50 (LMCO)	OH	1
9699M95P01	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P01	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P01	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P01	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P01	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P01	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P01	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P01	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P01	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P03	RETAINER - BEARING	CF6-50 (Boeing)	AR	1
9699M95P03	RETAINER - BEARING	CF6-50 (Boeing)	AR	1
9699M95P03	RETAINER - BEARING	CF6-50 (Boeing)	AR	1
9699M95P03	RETAINER - BEARING	CF6-50 (Boeing)	SV	1
9699M95P03	RETAINER - BEARING	CF6-50 (Boeing)	AR	1
9699M95P03	RETAINER - BEARING	CF6-50 (Boeing)	AR	1
9699M95P03	RETAINER - BEARING	CF6-50 (Boeing)	AR	1
9699M95P03	RETAINER - BEARING	CF6-50 (Boeing)	OH	1
9699M95P03	RETAINER - BEARING	CF6-50 (Boeing)	AR	1
9699M95P03	RETAINER - BEARING	CF6-50 (Boeing)	AR	1
9699M95P03	RETAINER - BEARING	CF6-50 (Boeing)	AR	1
9699M95P03	RETAINER - BEARING	CF6-50 (Boeing)	AR	1
9699M95P03	RETAINER - BEARING	CF6-50 (Boeing)	AR	1
9699M95P03	RETAINER - BEARING	CF6-50 (Boeing)	AR	1
9699M95P03	RETAINER - BEARING	CF6-50 (Boeing)	AR	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9699M95P04	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
9699M95P06	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P06	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P06	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P06	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P06	RETAINER - BEARING	CF6-50 (LMCO)	SV	1
9699M95P06	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P06	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P06	RETAINER - BEARING	CF6-50 (LMCO)	OH	1
9699M95P06	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P06	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P06	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P06	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P06	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P06	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P06	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P06	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P07	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P07	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P07	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P07	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P07	RETAINER - BEARING	CF6-50 (LMCO)	SV	1
9699M95P07	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P07	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P07	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P07	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P07	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P07	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P07	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P07	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P07	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P07	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P07	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	OH	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	OH	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	SV	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	SV	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	OH	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	OH	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	AR	1
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	AR	2
9699M95P08	RETAINER - BEARING	CF6-50 (LMCO)	AR	2
9699M95P09	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P09	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P09	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P09	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
9699M95P09	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P09	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P09	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
9699M95P09	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P09	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P09	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P09	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
9699M95P09	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P09	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M95P09	RETAINER - BEARING	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M98P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M98P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M98P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M98P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M98P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M98P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M98P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M98P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M98P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M98P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M98P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M98P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
9699M98P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9699M98P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
9699M98P01	RETAINER - SEAL	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
97019-10-0394-067	HOSE - CSD	CF6-50	AR	1
97019-10-0394-067	HOSE - CSD	CF6-50	AR	1
97019-10-0394-067	HOSE - CSD	CF6-50	AR	1
9704M13P1	SPACER - ACTUATION LEVER	CF6-80C2, CF6-80A, CF6-50	NS	1
9704M13P1	SPACER - ACTUATION LEVER	CF6-80C2, CF6-80A, CF6-50	NS	1
9704M13P2	SPACER - ACTUATION LEVER	CF6-80C2, CF6-80A, CF6-50	NE	4
9704M13P2	SPACER - ACTUATION LEVER	CF6-80C2, CF6-80A, CF6-50	NE	2
97101-519	HOSE	CF6-50	AR	1
97101-519	HOSE	CF6-50	AR	1
974145-2	FILTER ASSY - FLUID PRESS	CF6-50 (Boeing)	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
975927-1	ELEMENT ASSY - FL PRESS	CF6-50	NS	1
97608	HOSE ASSY	CF6-50	AR	1
97608-5521	HOSE ASSY	CF6-50 (LMCO)	AR	1
97608-5521	HOSE ASSY	CF6-50 (LMCO)	OH	1
97608-5521	HOSE ASSY	CF6-50 (LMCO)	SV	1
977J150-4	GENERATOR	CF6-50 (LMCO)	AR	1
977J150-4	GENERATOR	CF6-50 (LMCO)	AR	1
977J150-4	GENERATOR	CF6-50 (LMCO)	AR	1
978690-11	VALVE ASSY - HIGH PRESS	CF6-50	AR	1
978690-4	VALVE ASSY - HIGH PRESS	CF6-50 (LMCO)	AR	1
978690-6	VALVE ASSY - HIGH PRESS	CF6-50	AR	1
978690-9	VALVE ASSY - HP CONTROL	CF6-50 (LMCO)	OH	1
978892-6	VALVE - HIGH PRESSURE	CF6-50 (Boeing)	AR	1
978892-6	VALVE - HIGH PRESSURE	CF6-50 (Boeing)	AR	1
978892-6	VALVE - HIGH PRESSURE	CF6-50 (Boeing)	AR	1
979826-7	VALVE - STARTER	CF6-80A	OH	1
979826-8	VALVE - START CONT	CF6-80C2	AR	1
979826-8	VALVE - START CONT	CF6-80C2	AR	1
979826-9	VALVE	CF6-80C2, CF6-80A, CF6-50 (LMCO)	OH	1
9811M69P10	SPACER (.196) ID (.625) LGTH	CF6-80C2, CF6-80A, CF6-50 (Boeing)	NE	9
9811M69P12	SPACER	CF6-80C2, CF6-80A, CF6-50 (Boeing)	NS	3
9811M69P12	SPACER	CF6-80C2, CF6-80A, CF6-50 (Boeing)	NS	6
9811M69P12	SPACER	CF6-80C2, CF6-80A, CF6-50 (Boeing)	NS	1
9811M69P14	SPACER	CF6-80A, CF6-50 (Boeing)	NS	1
9811M69P16	SPACER	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	NS	7
9811M69P19	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	3
9811M69P19	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	50
9811M69P2	SPACER (.196) ID (.125) THK	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	3

Part Number	Part Description	Engine Type	Condition	Quantity
9811M69P3	SPACER (.196) ID (.187) THK	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9811M69P3	SPACER (.196) ID (.187) THK	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9811M69P3	SPACER (.196) ID (.187) THK	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9811M69P4	SPACER (.196) ID (.250) THK	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
9811M69P5	SPACER (.196) ID (.312) THK	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	NS	3
9811M69P6	SPACER	CF6-80C2, CF6-80A	NS	1
9811M69P8	SPACER (.196) ID (.500) THK	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	6
9811M70P10	SPACER	CF6-80C2, CF6-80A, CF6-50	NS	1
9811M70P10	SPACER	CF6-80C2, CF6-80A, CF6-50	NS	16
9811M70P10	SPACER	CF6-80C2, CF6-80A, CF6-50	NS	1
9811M70P12	SPACER	CF6-50 (Boeing)	NS	6
9811M70P12	SPACER	CF6-50 (Boeing)	NS	1
9811M70P12	SPACER	CF6-50 (Boeing)	NS	1
9811M70P12	SPACER	CF6-50 (Boeing)	NS	1
9811M70P12	SPACER	CF6-50 (Boeing)	NS	3
9811M70P14	SPACER	CF6-50 (LMCO), CF6-50 (Boeing)	NS	4
9811M70P15	SPACER	CF6-50	NS	1
9811M70P15	SPACER	CF6-50	NS	2
9811M70P16	SPACER	CF6-80A	NS	8
9811M70P18	SPACER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	6
9811M70P18	SPACER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
9811M70P18	SPACER	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
9811M70P2	SPACER	CF6-80C2, CF6-80A	NS	3
9811M70P20	SPACER	CF6-80C2	NE	12
9811M70P20	SPACER	CF6-80C2	NE	1
9811M70P24	SPACER	CF6-80A	NE	2
9811M70P4	SPACER	CF6-80C2	NS	3
9811M70P40	SPACER	CF6-80A	NE	1
9811M70P40	SPACER	CF6-80A	NE	8
9811M70P5	SPACER	CF6-80C2, CF6-80A	NE	1
A039432	BALL -BEARING	CF6-80A	NS	2
A039432	BALL -BEARING	CF6-80A	NE	3
A039432	BALL -BEARING	CF6-80A	NE	1
A039432	BALL -BEARING	CF6-80A	NE	6
A0858	SEAL	CF6-80C2	NE	10
A1737-4	HOSE - OIL	CF6-80C2	OH	1
A2873-300	SEAL	CF6-80A	NS	2
A2873-750	SEAL	CF6-80C2, CF6-80A, PW2000	NS	3
A5599-1	HOSE - P3G	CF6-80C2	SV	1
A5599-2	HOSE - P3G	CF6-80C2	NE	2
A7387-550	SEAL	CF6-80C2	NS	1
A7387-600	SEAL	CF6-80C2	NE	1
A7387-600	SEAL	CF6-80C2	NS	1
A7387-600	SEAL	CF6-80C2	NS	1
AC9227F1640	ELEMENT - FILTER	CF6-50	AR	1
AC9380E2024M	ELEMENT ASSY - FILTER	CF6-50	AR	1
AC9380F4010	ELEMENT - FILTER	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
AD-9380-2024	FILTER - SCAVENGE	CF6-50 (Boeing)	AR	1
AD-9380-2024	FILTER - SCAVENGE	CF6-50 (Boeing)	AR	1
AD-9380-2024	FILTER - SCAVENGE	CF6-50 (Boeing)	AR	1
AD-9380-2024	FILTER - SCAVENGE	CF6-50 (Boeing)	AR	1
AD-9380-2024	FILTER - SCAVENGE	CF6-50 (Boeing)	AR	1
AD9227-1640	FILTER - FUEL	CF6-50	AR	1
AD9227-1640	FILTER - FUEL	CF6-50	AR	1
AD9227-1640	FILTER - FUEL	CF6-50	AR	1
AD9227-1640	FILTER - FUEL	CF6-50	AR	1
AD9227-1640	FILTER - FUEL	CF6-50	AR	1
AD9227-1640	FILTER - FUEL	CF6-50	AR	1
AD9227-1640	FILTER - FUEL	CF6-50	AR	1
AD9227-1650	FILTER - FUEL	CF6-50	AR	1
AD9227-1650	FILTER - FUEL	CF6-50	AR	1
AD9227-1650	FILTER - FUEL	CF6-50	AR	1
AD9227-1650	FILTER - FUEL	CF6-50	AR	1
AD9227-1650	FILTER - FUEL	CF6-50	AR	1
AD9227-1650	FILTER - FUEL	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
AD9227-1650	FILTER - FUEL	CF6-50	OH	1
AD9227-1750	FILTER - FUEL	CF6-50 (Boeing)	AR	1
AD9227-1780	FILTER - FUEL	CF6-50 (LMCO)	AR	1
AD9227-2450	FILTER - FUEL	CF6-80C2, CF6-80A, CF6-50 (Boeing)	AR	1
AD9227-2450	FILTER - FUEL	CF6-80C2, CF6-80A, CF6-50 (Boeing)	OH	1
AD9227-2480	FILTER - FUEL	CF6-80C2, CF6-50 (LMCO)	OH	1
AD9227-2480	FILTER - FUEL	CF6-80C2, CF6-50 (LMCO)	AR	1
AD9227-2750	FILTER - FUEL	CF6-50 (Boeing)	SV	1
AD9380-2024	FILTER - SCAVENGE OIL	CF6-50 (Boeing)	AR	1
AD9380-2024	FILTER - SCAVENGE OIL	CF6-50 (Boeing)	AR	1
AD9380-2024	FILTER - SCAVENGE OIL	CF6-50 (Boeing)	SV	1
AD9380-2024	FILTER - SCAVENGE OIL	CF6-50 (Boeing)	SV	1
AD9380-2024	FILTER - SCAVENGE OIL	CF6-50 (Boeing)	AR	1
AD9380-2024	FILTER - SCAVENGE OIL	CF6-50 (Boeing)	AR	1
AD9380-2024	FILTER - SCAVENGE OIL	CF6-50 (Boeing)	NS	1
AD9380-4010	FILTER - SCAVENGE OIL	CF6-50 (LMCO)	AR	1
AD9380-4010	FILTER - SCAVENGE OIL	CF6-50 (LMCO)	AR	1
AD9380-4010	FILTER - SCAVENGE OIL	CF6-50 (LMCO)	AR	1
AD9380-4010	FILTER - SCAVENGE OIL	CF6-50 (LMCO)	AR	1
AD9380-4010	FILTER - SCAVENGE OIL	CF6-50 (LMCO)	AR	1
AD9380-4010	FILTER - SCAVENGE OIL	CF6-50 (LMCO)	AR	1
AD9380-4010	FILTER - SCAVENGE OIL	CF6-50 (LMCO)	AR	1
AD9380-4010	FILTER - SCAVENGE OIL	CF6-50 (LMCO)	AR	1
AD9380-4010	FILTER - SCAVENGE OIL	CF6-50 (LMCO)	AR	1
AD9380-4010	FILTER - SCAVENGE OIL	CF6-50 (LMCO)	AR	1
AD9380-4010	FILTER - SCAVENGE OIL	CF6-50 (LMCO)	AR	1
AD9380-4010	FILTER - SCAVENGE OIL	CF6-50 (LMCO)	AR	1
AD9380-4010	FILTER - SCAVENGE OIL	CF6-50 (LMCO)	AR	1
AD9380-4010	FILTER - SCAVENGE OIL	CF6-50 (LMCO)	AR	1
AD9380-4011	FILTER - SCAVENGE OIL	CF6-50	AR	1
AD9380-4011	FILTER - SCAVENGE OIL	CF6-50	AR	1
AD9380-4011	FILTER - SCAVENGE OIL	CF6-50	AR	1
AD9380-4011	FILTER - SCAVENGE OIL	CF6-50	AR	1
AD9380-5011	FILTER - SCAVENGE OIL	CF6-80C2, CF6-80A	AR	1
AD9380-5011	FILTER - SCAVENGE OIL	CF6-80C2, CF6-80A	AR	1
AD9380-5011	FILTER - SCAVENGE OIL	CF6-80C2, CF6-80A	AR	1
AD9380-5011	FILTER - SCAVENGE OIL	CF6-80C2, CF6-80A	AR	1
AE1000100H0072	HOSE	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
AE1007609G0184	HOSE ASSY	CF6-50	AR	1
AE1007609G0184	HOSE ASSY	CF6-50	AR	1
AE1007609G0184	HOSE ASSY	CF6-50	AR	1
AE1010743M0187	HOSE ASSY	CF6-80C2	SV	1
AE1010744M0174	HOSE ASSY - (HYD PRESS)	CF6-80C2	AR	1
AE1010744M0174	HOSE ASSY - (HYD PRESS)	CF6-80C2	AR	1
AE1010744M0174	HOSE ASSY - (HYD PRESS)	CF6-80C2	NS	1
AE1010745M0222	HOSE ASSY - (HYD SUPPLY)	CF6-80C2	AR	1
AE272-13	SLEEVE	CF6-80A	NS	3
AE3104K0400-108	HOSE ASSY	CF6-50	AR	1
AE3104K0400-108	HOSE ASSY	CF6-50	AR	1
AE3104K0400-108	HOSE ASSY	CF6-50	AR	1
AE3663189K0155	HOSE ASSY	CF6-50 (LMCO)	AR	1
AE3663189K0155	HOSE ASSY	CF6-50 (LMCO)	AR	1
AE6665000K0114	HOSE - FLEX	CF6-80C2	AR	1
AE6665028H0130	HOSE ASSY	CF6-50 (LMCO)	NE	1
AE6665028H0183	HOSE ASSY	CF6-50 (LMCO)	NE	1
AE703402-2	LINE - MAIN FUEL	CF6-50 (LMCO)	AR	1
AE703402-2	LINE - MAIN FUEL	CF6-50 (LMCO)	AR	1
AE703402-2	LINE - MAIN FUEL	CF6-50 (LMCO)	AR	1
AE703402-2	LINE - MAIN FUEL	CF6-50 (LMCO)	OH	1
AE703402-2	LINE - MAIN FUEL	CF6-50 (LMCO)	OH	1
AE703402-2	LINE - MAIN FUEL	CF6-50 (LMCO)	SV	1
AE703402-2	LINE - MAIN FUEL	CF6-50 (LMCO)	SV	1
AE703402-2	LINE - MAIN FUEL	CF6-50 (LMCO)	OH	1
AE703402-2	LINE - MAIN FUEL	CF6-50 (LMCO)	OH	1
AE703402-2	LINE - MAIN FUEL	CF6-50 (LMCO)	AR	1
AE703402-2	LINE - MAIN FUEL	CF6-50 (LMCO)	AR	1
AE703402-2	LINE - MAIN FUEL	CF6-50 (LMCO)	AR	1
AE703402-2	LINE - MAIN FUEL	CF6-50 (LMCO)	AR	1
AE703514-1	TUBE/HOSE ASSY - OIL	CF6-80A	AR	1
AE704079-1	HOSE ASSY	CF6-50 (LMCO)	SV	1
AE704079-1	HOSE ASSY	CF6-50 (LMCO)	SV	1
AE704079-1	HOSE ASSY	CF6-50 (LMCO)	AR	1
AE704079-2	HOSE ASSY	CF6-50	SV	1
AE704079-2	HOSE ASSY	CF6-50	SV	1
AE704312-3	HOSE ASSY	CF6-80A	AR	1
AE704312-3	HOSE ASSY	CF6-80A	AR	1
AE705266-1	HOSE ASSY	CF6-50 (LMCO)	SV	1
AE705266-1	HOSE ASSY	CF6-50 (LMCO)	AR	1
AE705777-35	HOSE ASSY	CF6-80A	OH	1
AE705777-75	HOSE ASSY	CF6-80A	OH	1
AE705777-78	HOSE ASSY	CF6-80A	AR	1
AE705777-78	HOSE ASSY	CF6-80A	OH	1
AE705777-79	HOSE ASSY	CF6-80A	AR	1
AE705777-79	HOSE ASSY	CF6-80A	AR	1
AE705925-24	HOSE ASSY - LWR PUMP CASE	CF6-80A	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
AE705925-25	HOSE ASSY - UPR PUMP CASE	CF6-80A	AR	1
AE705925-3	HOSE ASSY - MEDIUM PRESS	CF6-80A	AR	1
AE705925-3	HOSE ASSY - MEDIUM PRESS	CF6-80A	AR	1
AE705925-4	HOSE ASSY - MEDIUM PRESS	CF6-80A	AR	1
AE705925-4	HOSE ASSY - MEDIUM PRESS	CF6-80A	AR	1
AE705925-5	HOSE ASSY	CF6-80A	AR	1
AE705925-5	HOSE ASSY	CF6-80A	AR	1
AE705925-5	HOSE ASSY	CF6-80A	AR	1
AE705925-5	HOSE ASSY	CF6-80A	AR	1
AE705925-6	HOSE ASSY - MEDIUM PRESS	CF6-80A	AR	1
AE705925-6	HOSE ASSY - MEDIUM PRESS	CF6-80A	AR	1
AE705926-1	HOSE ASSY - CRIMPED HIGH	CF6-80A	AR	1
AE706058-1	HOSE ASSY - MEDIUM	CF6-80A	AR	1
AE706058-1	HOSE ASSY - MEDIUM	CF6-80A	AR	1
AE706058-18	HOSE ASSY	CF6-80C2	NE	1
AE706058-2	HOSE ASSY - MEDIUM PRESS	CF6-80A	AR	1
AE706058-4	HOSE ASSY - MEDIUM	CF6-80A	AR	1
AE706058-4	HOSE ASSY - MEDIUM	CF6-80A	AR	1
AE706058-6	HOSE ASSY	CF6-80A	AR	1
AE706058-6	HOSE ASSY	CF6-80A	AR	1
AE706058-7	HOSE ASSY - MEDIUM	CF6-80A	AR	1
AE706059-1	HOSE ASSY	CF6-80A	AR	1
AE706059-1	HOSE ASSY	CF6-80A	AR	1
AE706060-1	HOSE ASSY - MEDIUM	CF6-80A	AR	1
AE706060-1	HOSE ASSY - MEDIUM	CF6-80A	AR	1
AE706823-2	HOSE ASSY - UPR PUMP SUCTION	CF6-80A	NE	1
AE706823-2	HOSE ASSY - UPR PUMP SUCTION	CF6-80A	NE	1
AE706823-2	HOSE ASSY - UPR PUMP SUCTION	CF6-80A	NE	1
AE706823-2	HOSE ASSY - UPR PUMP SUCTION	CF6-80A	NE	1
AE713811-1	HOSE ASSY - CASE DRAIN	CF6-80C2	SV	1
AE96787N	ADAPTER ASSY - UPR PUMP	CF6-80C2, CF6-50 (LMCO)	AR	1
AE96787N	ADAPTER ASSY - UPR PUMP	CF6-80C2, CF6-50 (LMCO)	AR	1
AE96787N	ADAPTER ASSY - UPR PUMP	CF6-80C2, CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
AEB794-171	FILTER ASSY - HYD SYSTEM	CF6-80C2	SV	1
AF56C-C3	VALVE - VAPOR VENT	CF6-50 (LMCO)	AR	1
AFP292J6-8A	REDUCER - EXPANDER UNION	CF6-80C2	NE	1
AFP292J6-8A	REDUCER - EXPANDER UNION	CF6-80C2	NE	5
AFP292J6-8A	REDUCER - EXPANDER UNION	CF6-80C2	NE	2
AH1257-03	VALVE ASSY - EDUCTOR	CF6-50 (LMCO)	OH	1
AH1257-04	VALVE ASSY - EDUCTOR	CF6-50	AR	1
AH1257-05	VALVE ASSY - EDUCTOR	CF6-50	AR	1
AH1257-06	VALVE ASSY - EDUCTOR	CF6-50 (LMCO)	AR	1
AIR22147	SLIDE - FLEX JOINT	CF6-80C2	OH	2
AMBK4-4014	LINK	CF6-80C2	SV	1
AMBK4-4014	LINK	CF6-80C2	NE	1
AMBK4-4014	LINK	CF6-80C2	SV	1
AMBK4-4017	LINK ASSEMBLY	CF6-80C2	OH	1
AMBK4-4059	LINK	CF6-80C2	NE	1
AMBK4-4063	LINK ASSEMBLY	CF6-80C2	NE	1
AN806-S6	PLUG - FLARED TUBE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	NS	8
AN806-S6	PLUG - FLARED TUBE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
AN806-S6	PLUG - FLARED TUBE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
AN814-4DL	PLUG AND BLEEDER - SCREW	CF6-80A, CF6-50 (LMCO)	NS	7
AN814-6DL	PLUG - MACH THD	CF6-80C2	NE	1
AN814-6DL	PLUG - MACH THD	CF6-80C2	NE	4
AN832-12J	ELBOW	CF6-50 (LMCO)	NS	21
AN833-6J	ELBOW	CF6-50 (LMCO)	NS	24
AN837-6J	ELBOW	CF6-50	NS	1
AN837-6J	ELBOW	CF6-50	NS	3
AN837-6J	ELBOW	CF6-50	NS	1
AN894K6-4	REDUCER	CF6-50	NS	1
AN919-6J	REDUCER	CF6-50 (LMCO)	NS	2
AN919-6J	REDUCER	CF6-50 (LMCO)	NS	1
AN919-6J	REDUCER	CF6-50 (LMCO)	NS	5
AN919-6J	REDUCER	CF6-50 (LMCO)	NS	4
AN929-6J	CAP ASSY	CF6-80A, CF6-50 (LMCO)	NS	21
AN929-8J	CAP ASSY	CF6-50 (LMCO)	NS	20
AR10103-015A1H	SEAL	CF6-80C2, CF6-80A, CF6-50	NE	2

Part Number	Part Description	Engine Type	Condition	Quantity
AS115-08H0115	HOSE ASSY - (HYD CASE DRAIN)	CF6-80C2	AR	1
AS115-08H0115	HOSE ASSY - (HYD CASE DRAIN)	CF6-80C2	AR	1
AS115-08H0115	HOSE ASSY - (HYD CASE DRAIN)	CF6-80C2	NS	1
AS116-08H0180	HOSE ASSY - (HYD CASE DRAIN)	CF6-80C2	OH	1
AS116-08H0180	HOSE ASSY - (HYD CASE DRAIN)	CF6-80C2	OH	1
AS120E130C315	HOSE - HIGH PRESS	CF6-80A	AR	1
AS120E130C315	HOSE - HIGH PRESS	CF6-80A	AR	1
AS120E130C315	HOSE - HIGH PRESS	CF6-80A	AR	1
AS120E130C315	HOSE - HIGH PRESS	CF6-80A	OH	1
AS137-06N2-0103L	HOSE	CF6-80C2	SV	1
AS137-08-0120	HOSE ASSY	CF6-80A	AR	1
AS137-08-0120	HOSE ASSY	CF6-80A	NS	2
AS137-08S0120	HOSE	CF6-80A	AR	1
AS138-08-0095	TUBE	CF6-80C2	.INSP	1
AS138-08N0095L	HOSE	CF6-80C2	AR	1
AS1503-03D0090	HOSE	CF6-80A	NE	1
AS1503-03D0090	HOSE	CF6-80A	NE	1
AS1503-03D0090	HOSE	CF6-80A	NS	2
AS1634A20H0144	HOSE ASSY - (HYD SUPPLY)	CF6-80C2	NS	1
AS1634A20H0144	HOSE ASSY - (HYD SUPPLY)	CF6-80C2	NE	1
AS1635A20H0214	HOSE ASSY - (HYD SUPPLY)	CF6-80C2	OH	1
AS1635B10H0120	HOSE - MED PRESS	CF6-80A	SV	1
AS1635B10H0120	HOSE - MED PRESS	CF6-80A	SV	1
AS1635B10H0120	HOSE - MED PRESS	CF6-80A	OH	1
AS1635B10H0134	HOSE - MED PRESS	CF6-80A	NS	1
AS1635B12H0364	HOSE - MED PRESS	CF6-80A	AR	1
AS1791-08	WIRE - SWIVEL	CF6-80C2	NE	1
AS1791-08	WIRE - SWIVEL	CF6-80C2	NE	3
AS1895-1-450	COUPLING	CF6-80C2, CF6-80A	AR	1
AS1895-4-150	COUPLING - CLAMP	CF6-80C2	NS	2
AS1895-4-150	COUPLING - CLAMP	CF6-80C2	NS	20
AS1895-4-150	COUPLING - CLAMP	CF6-80C2	SV	10
AS1895-4-150	COUPLING - CLAMP	CF6-80C2	NS	11
AS1895-4-150	COUPLING - CLAMP	CF6-80C2	OH	3
AS1895-7-300	SEAL	CF6-80A	NE	23
AS1895-7-400	SEAL	CF6-80C2, CF6-80A, PW2000	NS	1
AS1895-7-400	SEAL	CF6-80C2, CF6-80A, PW2000	NS	9

Part Number	Part Description	Engine Type	Condition	Quantity
AS1895-7-550	SEAL	CF6-80C2, CF6-80A, PW2000	NS	1
AS1895-7-550	SEAL	CF6-80C2, CF6-80A, PW2000	NS	1
AS1895-7-550	SEAL	CF6-80C2, CF6-80A, PW2000	NE	15
AS1895/4-150	COUPLING - CLAMP	CF6-80C2	NE	1
AS1895/7-550	SEAL	CF6-80C2	NE	1
AS1895/7-550	SEAL	CF6-80C2	NE	2
AS1895/7-550	SEAL	CF6-80C2	NS	1
AS1895/7-550	SEAL	CF6-80C2	NS	7
AS1895/7-550	SEAL	CF6-80C2	NS	1
AS1895/7-550	SEAL	CF6-80C2	NS	1
ASD3113H260	HOSE	CF6-80A	AR	1
ASG0005-1	TUBE ASSY	CF6-50	AR	1
ASG0005-531	TUBE ASSY	CF6-50	AR	1
ASG0005-553	TUBE ASSY	CF6-50	AR	1
ASG0005-556	TUBE ASSY	CF6-50	AR	1
ASG0005-557	TUBE ASSY	CF6-50	AR	1
ASG0005-557	TUBE ASSY	CF6-50	AR	1
ASG0014-5527	MODULE - FILTER HYD	CF6-50 (LMCO)	AR	1
ASG0014-5527	MODULE - FILTER HYD	CF6-50 (LMCO)	AR	1
ASG0014-5527	MODULE - FILTER HYD	CF6-50 (LMCO)	AR	1
ASG0052-1	BRACKET	CF6-50	SV	1
ASG0509-503	TUBE ASSY.	CF6-50	AR	1
ASG0517-1	BRACKET	CF6-50 (LMCO)	SV	1
ASG7010-1	DAMPER - HYD PUMP	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
ASH0000-501	ROD ASSY - FUEL SHUTOFF	CF6-50 (LMCO)	AR	1
ASH0011-503	LINK - THROTTLE	CF6-50 (LMCO)	OH	1
ASH0011-503	LINK - THROTTLE	CF6-50 (LMCO)	AR	1
ASH0018-1	SUPPORT ASSY	CF6-50 (LMCO)	AR	1
ASL0088-1	BRACKET	CF6-50 (LMCO)	AR	1
ASL0088-1	BRACKET	CF6-50 (LMCO)	SV	1
ASL0088-2	BRACKET	CF6-50 (LMCO)	SV	1
ASL0093-543	TUBE	CF6-50 (LMCO)	OH	1
ASL0093-543	TUBE	CF6-50 (LMCO)	AR	1
ASL0093-543	TUBE	CF6-50 (LMCO)	AR	1
ASL0093-551	TUBE ASSY	CF6-50 (LMCO)	AR	1
ASL0093-551	TUBE ASSY	CF6-50 (LMCO)	OH	1
ASL0093-551	TUBE ASSY	CF6-50 (LMCO)	AR	1
ASL0093-551	TUBE ASSY	CF6-50 (LMCO)	SV	1
ASL0093-563	TUBE ASSY	CF6-50 (LMCO)	AR	1
ASL0093-563	TUBE ASSY	CF6-50 (LMCO)	AR	1
ASL0093-563	TUBE ASSY	CF6-50 (LMCO)	AR	1
ASL0093-563	TUBE ASSY	CF6-50 (LMCO)	AR	1
ASL0093-563	TUBE ASSY	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
ASL0093-563	TUBE ASSY	CF6-50 (LMCO)	AR	1
ASL0093-563	TUBE ASSY	CF6-50 (LMCO)	AR	1
ASL0093-563	TUBE ASSY	CF6-50 (LMCO)	AR	1
ASL0093-573	TUBE ASSY - GENERATOR DRAIN	CF6-50 (LMCO)	NE	1
ASL0093-573	TUBE ASSY - GENERATOR DRAIN	CF6-50 (LMCO)	NE	1
ASL0093-574	TUBE ASSY	CF6-50 (LMCO)	AR	1
ASL0093-574	TUBE ASSY	CF6-50 (LMCO)	AR	1
ASL0093-574	TUBE ASSY	CF6-50 (LMCO)	SV	1
ASL0093-574	TUBE ASSY	CF6-50 (LMCO)	AR	1
ASL0093-574	TUBE ASSY	CF6-50 (LMCO)	AR	1
ASL0093-577	TUBE ASSY	CF6-50 (LMCO)	AR	1
ASL0093-577	TUBE ASSY	CF6-50 (LMCO)	AR	1
ASL0093-577	TUBE ASSY	CF6-50 (LMCO)	AR	1
ASL0093-577	TUBE ASSY	CF6-50 (LMCO)	AR	1
ASL0093-584	TUBE ASSY	CF6-50 (LMCO)	OH	1
ASL0093-584	TUBE ASSY	CF6-50 (LMCO)	AR	1
ASL0093-584	TUBE ASSY	CF6-50 (LMCO)	AR	1
ASL0093-588	TUBE ASSY	CF6-50 (LMCO)	NS	1
ASL0093-588	TUBE ASSY	CF6-50 (LMCO)	SV	1
ASL0093-590	TUBE ASSY	CF6-50 (LMCO)	NS	2
ASL0093-602	TUBE ASSY	CF6-50 (LMCO)	AR	1
ASL0093-602	TUBE ASSY	CF6-50 (LMCO)	AR	1
ASL0093-605	TUBE A	CF6-50	OH	1
ASL0093-605	TUBE A	CF6-50	AR	1
ASL0093-605	TUBE A	CF6-50	AR	1
ASL0093-605	TUBE A	CF6-50	AR	1
ASL0093-605	TUBE A	CF6-50	AR	1
ASL0093-605	TUBE A	CF6-50	AR	1
ASL0093-607	TUBE A	CF6-50	OH	1
ASL0093-607	TUBE A	CF6-50	AR	1
ASL0093-608	TUBE ASSY	CF6-50	AR	1
ASL0093-609	TUBE ASSY.	CF6-50	SV	1
ASL0093-614	TUBE A	CF6-50 (LMCO)	SV	1
ASL0093-614	TUBE A	CF6-50 (LMCO)	AR	1
ASL0093-614	TUBE A	CF6-50 (LMCO)	SV	1
ASL0093-616	TUBE ASSY	CF6-50 (LMCO)	NS	1
ASL0093-619	TUBE A	CF6-50	AR	1
ASL0093-622	TUBE ASSY	CF6-50 (LMCO)	SV	1
ASL0093-622	TUBE ASSY	CF6-50 (LMCO)	SV	1
ASL0093-627	TUBE A	CF6-50 (LMCO)	SV	1
ASL0093-627	TUBE A	CF6-50 (LMCO)	SV	1
ASL0093-627	TUBE A	CF6-50 (LMCO)	SV	1
ASL0093-627	TUBE A	CF6-50 (LMCO)	SV	1
ASL0093-627	TUBE A	CF6-50 (LMCO)	OH	1
ASL0093-628	TUBE A	CF6-50 (LMCO)	AR	1
ASL0093-633	TUBE ASSY	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
ASL0112-501	DRAIN ASSY - MANIFOLD	CF6-50 (LMCO)	AR	1
ASL0112-501	DRAIN ASSY - MANIFOLD	CF6-50 (LMCO)	AR	1
ASL0112-501	DRAIN ASSY - MANIFOLD	CF6-50 (LMCO)	AR	1
ASL0159-1	BRACKET ASSY.	CF6-50 (LMCO)	SV	1
ASL0159-1	BRACKET ASSY.	CF6-50 (LMCO)	AR	1
ASL0184-501	TUBE A	CF6-50 (LMCO)	SV	1
ASL0184-502	TUBE A	CF6-50 (LMCO)	SV	1
ASL0184-502	TUBE A	CF6-50 (LMCO)	AR	1
ASL0184-502	TUBE A	CF6-50 (LMCO)	AR	1
ASL0184-503	TUBE A	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
ASL0184-503	TUBE A	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
ASL0184-503	TUBE A	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
ASL0184-508	TUBING	CF6-50 (LMCO)	AR	1
ASL0184-508	TUBING	CF6-50 (LMCO)	SV	1
ASL0184-509	TUBE ASSY	CF6-50	AR	1
ASL0184-509	TUBE ASSY	CF6-50	AR	1
ASL0184-509	TUBE ASSY	CF6-50	SV	1
ASL0218-415	BRACKET	CF6-50 (LMCO)	SV	2
ASL0226-1	BRACKET-ASSY.	CF6-50	AR	1
ASL0226-1	BRACKET-ASSY.	CF6-50	AR	1
ASL0226-1	BRACKET-ASSY.	CF6-50	AR	1
ASL0260-503	TUBE A	CF6-50	AR	1
ASL0260-503	TUBE A	CF6-50	AR	1
ASL0276-501	BRACKET	CF6-50 (LMCO)	SV	1
ASL0291-1	BRACKET	CF6-50 (LMCO)	NS	3
ASL0319-1	TUBE ASSY - STARTER DRAIN	CF6-50 (LMCO)	OH	1
ASL0321-1	REDUCER	CF6-50 (LMCO)	NS	1
ASL0321-1	REDUCER	CF6-50 (LMCO)	NS	1
ASL0368-501	SPACER	CF6-50 (LMCO)	NE	1
ASL0368-501	SPACER	CF6-50 (LMCO)	NE	1
ASL0368-501	SPACER	CF6-50 (LMCO)	NS	1
ASL0368-501	SPACER	CF6-50 (LMCO)	NS	1
ASL0373-501	BRACKET	CF6-50 (LMCO)	AR	1
ASL0524-501	BRACKET ASSY	CF6-50 (LMCO)	NS	1
ASL0538-503	TUBE ASSY	CF6-50 (LMCO)	AR	1
ASL0538-503	TUBE ASSY	CF6-50 (LMCO)	AR	1
ASL0538-503	TUBE ASSY	CF6-50 (LMCO)	AR	1
ASL0564-1	RETAINER	CF6-50 (LMCO)	OH	1
ASL0564-1	RETAINER	CF6-50 (LMCO)	AR	2
ASL0564-1	RETAINER	CF6-50 (LMCO)	OH	2
ASL0564-1	RETAINER	CF6-50 (LMCO)	SV	2
ASL0580-501	BRACKET	CF6-50 (LMCO)	SV	1
ASM0010-1	DUCT ASSY	CF6-50 (LMCO)	AR	1
ASM0010-1	DUCT ASSY	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
ASM0010-1	DUCT ASSY	CF6-50 (LMCO)	OH	1
ASM0010-1	DUCT ASSY	CF6-50 (LMCO)	AR	1
ASM0010-1	DUCT ASSY	CF6-50 (LMCO)	AR	1
ASM0010-1	DUCT ASSY	CF6-50 (LMCO)	AR	1
ASM0010-1	DUCT ASSY	CF6-50 (LMCO)	AR	1
ASM0010-501	DUCT ASSY	CF6-50	SV	1
ASM0010-501	DUCT ASSY	CF6-50	AR	1
ASM0017-1	DUCT - INSTAL GEN COOLING	CF6-50 (LMCO)	NS	1
ASM0017-1	DUCT - INSTAL GEN COOLING	CF6-50 (LMCO)	AR	1
ASM0017-1	DUCT - INSTAL GEN COOLING	CF6-50 (LMCO)	AR	1
ASM0018-501	SHROUD	CF6-50 (LMCO)	OH	1
ASM0018-501	SHROUD	CF6-50 (LMCO)	SV	1
ASM0018-501	SHROUD	CF6-50 (LMCO)	AR	1
ASM0018-501	SHROUD	CF6-50 (LMCO)	AR	1
ASM0022-1	SHROUD A	CF6-50 (LMCO)	OH	1
ASM0023-501	CAP ASSY	CF6-50 (LMCO)	AR	1
ASM0023-501	CAP ASSY	CF6-50 (LMCO)	AR	1
ASM0023-501	CAP ASSY	CF6-50 (LMCO)	AR	1
ASM0024-1	DUCT	CF6-50 (LMCO)	AR	1
ASM0024-1	DUCT	CF6-50 (LMCO)	AR	1
ASM0024-7	DUCT - COOLING	CF6-50	AR	1
ASM0027-501	TUBE ASSY	CF6-50 (LMCO)	AR	1
ASM0027-501	TUBE ASSY	CF6-50 (LMCO)	OH	1
ASM0027-501	TUBE ASSY	CF6-50 (LMCO)	AR	1
ASM0027-505	TUBE	CF6-50 (LMCO)	NE	1
ASM0027-505	TUBE	CF6-50 (LMCO)	AR	1
ASM0027-505WE	TUBE	CF6-50 (LMCO)	NE	1
ASM0028-505	DUCT ASSY	CF6-50 (LMCO)	AR	1
ASM0028-505	DUCT ASSY	CF6-50 (LMCO)	AR	1
ASM0028-505	DUCT ASSY	CF6-50 (LMCO)	AR	1
ASM0500-501	DUCT ASSY - T	CF6-50	AR	1
ASM0500-501	DUCT ASSY - T	CF6-50	AR	1
ASM0500-501	DUCT ASSY - T	CF6-50	AR	1
ASM0500-503	DUCT ASSY	CF6-50 (LMCO)	AR	1
ASM0500-503	DUCT ASSY	CF6-50 (LMCO)	AR	1
ASM0500-503	DUCT ASSY	CF6-50 (LMCO)	AR	1
ASN0015-501	BRACKET ASSY.	CF6-50 (LMCO)	AR	1
ASN0015-501	BRACKET ASSY.	CF6-50 (LMCO)	AR	1
ASN0015-501	BRACKET ASSY.	CF6-50 (LMCO)	AR	1
ASN0015-501	BRACKET ASSY.	CF6-50 (LMCO)	AR	1
ASN0015-501	BRACKET ASSY.	CF6-50 (LMCO)	AR	1
ASN0015-503	BRACKET ASSY.	CF6-50	AR	1
ASN0015-503	BRACKET ASSY.	CF6-50	AR	1
ASN0015-503	BRACKET ASSY.	CF6-50	AR	1
ASN0016-505	SUPPORT	CF6-50	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
ASN0016-505	SUPPORT	CF6-50	SV	1
ASN0016-505	SUPPORT	CF6-50	AR	1
ASN0016-505	SUPPORT	CF6-50	AR	1
ASN0017-503	SUPPORT	CF6-50 (LMCO)	NS	1
ASN0017-503	SUPPORT	CF6-50 (LMCO)	NS	1
ASN0017-503	SUPPORT	CF6-50 (LMCO)	AR	1
ASN0017-503	SUPPORT	CF6-50 (LMCO)	AR	1
ASN0017-503	SUPPORT	CF6-50 (LMCO)	AR	1
ASN0054-1	BRACKET	CF6-50 (LMCO)	AR	1
ASN0065-1	BRACKET	CF6-50 (LMCO)	NS	1
ASN0066-1	BRACKET ASSY.	CF6-50 (LMCO)	AR	1
ASN0066-1	BRACKET ASSY.	CF6-50 (LMCO)	AR	1
ASN0066-1	BRACKET ASSY.	CF6-50 (LMCO)	AR	1
ASN0067-1	BRACKET ASSY.	CF6-50 (LMCO)	AR	1
ASN0067-1	BRACKET ASSY.	CF6-50 (LMCO)	AR	1
ASN0067-1	BRACKET ASSY.	CF6-50 (LMCO)	AR	1
ASN0515-1	BRACKET	CF6-50 (LMCO)	OH	1
ASN0521-501	COVER A	CF6-50 (LMCO)	SV	1
ASN0521-501	COVER A	CF6-50 (LMCO)	SV	2
ASN0521-501	COVER A	CF6-50 (LMCO)	AR	1
ASN0521-501	COVER A	CF6-50 (LMCO)	AR	1
ASN0521-501	COVER A	CF6-50 (LMCO)	AR	1
ASN0524-1	BRACKET	CF6-50 (LMCO)	AR	1
ASP0001-503	HARNESS - AC GEN	CF6-50 (LMCO)	SV	1
ASP0001-503	HARNESS - AC GEN	CF6-50 (LMCO)	SV	1
ASP0001-503	HARNESS - AC GEN	CF6-50 (LMCO)	AR	1
ASP0001-503	HARNESS - AC GEN	CF6-50 (LMCO)	AR	1
ASP0001-503	HARNESS - AC GEN	CF6-50 (LMCO)	AR	1
ASP0001-503	HARNESS - AC GEN	CF6-50 (LMCO)	AR	1
ASP0001-503	HARNESS - AC GEN	CF6-50 (LMCO)	AR	1
ASP0001-503	HARNESS - AC GEN	CF6-50 (LMCO)	AR	1
ASP0501-543	HARNESS ASSY	CF6-50	AR	1
ASP0501-543	HARNESS ASSY	CF6-50	AR	1
ASP0501-543	HARNESS ASSY	CF6-50	AR	1
ASP0501-543	HARNESS ASSY	CF6-50	AR	1
ASP0501-543	HARNESS ASSY	CF6-50	AR	1
ASP0501-569	WIRE ASSEMBLY	CF6-50	SV	1
B1548-05-12	VALVE - IDG CHECK	CF6-80C2	AR	1
B1548-05-12	VALVE - IDG CHECK	CF6-80C2	AR	1
B1548-05-12	VALVE - IDG CHECK	CF6-80C2	SV	1
B4354-1	PLUG - MAG MACH THD	CF6-80C2, CF6-80A	AR	1
B630-4	SHROUD ASSY	CF6-80A	OH	1
B63D89	COOLER - CSD OIL	CF6-50 (LMCO)	AR	1
B63D89	COOLER - CSD OIL	CF6-50 (LMCO)	AR	1
B63D89	COOLER - CSD OIL	CF6-50 (LMCO)	AR	1
B63D89	COOLER - CSD OIL	CF6-50 (LMCO)	AR	1
B63D89	COOLER - CSD OIL	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
B63D89	COOLER - CSD OIL	CF6-50 (LMCO)	AR	1
B63D89	COOLER - CSD OIL	CF6-50 (LMCO)	AR	1
B63D89	COOLER - CSD OIL	CF6-50 (LMCO)	AR	1
B63D89	COOLER - CSD OIL	CF6-50 (LMCO)	AR	1
B63D89	COOLER - CSD OIL	CF6-50 (LMCO)	AR	1
B63D89	COOLER - CSD OIL	CF6-50 (LMCO)	AR	1
BA5394	SEAL	CF6-50 (LMCO)	NE	1
BACA14AZ10A8T	ADAPTER	CF6-50 (Boeing)	NS	1
BACA14AZ10A8T	ADAPTER	CF6-50 (Boeing)	NE	4
BACA14AZ10A8T	ADAPTER	CF6-50 (Boeing)	NE	1
BACA14AZ12A16S	ADAPTER	CF6-80A	NS	1
BACA14BA8BJ	ELBOW	CF6-80A	NS	1
BACA14BA8BS	ELBOW	CF6-80A	AR	1
BACA14BA8BS	ELBOW	CF6-80A	AR	1
BACB30LM4HU11	BRACKET - BOLT-FIRE LOOP	CF6-50 (Boeing)	NS	16
BACB30LM4HU11	BRACKET - BOLT-FIRE LOOP	CF6-50 (Boeing)	NS	1
BACC10EY400A	COUPLING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
BACC10EY400B	COUPLING	CF6-80A	NS	1
BACC10EY600BE	COUPLING	CF6-50 (Boeing)	AR	1
BACE21AS0806	ELBOW	CF6-50 (Boeing)	NS	3
BACE21AS0806	ELBOW	CF6-50 (Boeing)	NS	1
BACE21AW0606M	ELBOW	CF6-80A	SV	1
BACE21BT0606JN	ELBOW	CF6-80C2, CF6-80A	NS	3
BACH5M0080AA-B	HOSE ASSY	CF6-80A	OH	1
BACH5M0080AAB	HOSE ASSY	CF6-80A	OH	1
BACH5M0080AAB	HOSE ASSY	CF6-80A	NS	2
BACH5M0104ARW	HOSE - LOW FLEX	CF6-80A	AR	1
BACH5M0140CRW	HOSE - HIGH FLEX	CF6-80A	OH	1
BACH5M0140CRW	HOSE - HIGH FLEX	CF6-80A	AR	1
BACH5M0140CRW	HOSE - HIGH FLEX	CF6-80A	AR	1
BACH5M0140CRW	HOSE - HIGH FLEX	CF6-80A	NS	1
BACH5P0060CKF	HOSE ASSY	CF6-80A	AR	1
BACH5P0060CKF	HOSE ASSY	CF6-80A	SV	1
BACH5P0107ZZ	HOSE ASSY	CF6-80A	AR	1
BACH5P0107ZZ	HOSE ASSY	CF6-80A	AR	1
BACH5P0130CKN	HOSE ASSY	CF6-80C2	NS	1
BACH5P02040K-F	HOSE ASSY	CF6-80A	AR	1
BACH5P0204CKF	HOSE ASSY	CF6-80A	OH	1
BACH5R0233DLF	HOSE ASSY	CF6-80A	NS	2
BACH5R0260DUF	HOSE ASSY	CF6-80A	OH	1
BACH5R0260DUF	HOSE ASSY	CF6-80A	NE	1
BACH5S0147EMF	HOSE	CF6-80C2	AR	1
BACH5S0164EMF	HOSE	CF6-80C2	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
BACH7F0243FF	HOSE ASSY	CF6-50 (Boeing)	AR	1
BACH7F0243FF	HOSE ASSY	CF6-50 (Boeing)	SV	1
BACH7F0243FF	HOSE ASSY	CF6-50 (Boeing)	OH	1
BACH7F0243FF	HOSE ASSY	CF6-50 (Boeing)	AR	1
BACJ40AC44-5	JUMPER - BONDING	CF6-50 (Boeing)	NS	1
BACJ40AC44-5	JUMPER - BONDING	CF6-50 (Boeing)	NS	23
BACJ40AC44-6	JUMPER - BONDING	CF6-80A	NS	28
BACJ40AD44-3	BONDING - JUMPER	CF6-80C2	NS	3
BACJ40AD44-5	JUMPER	CF6-50 (Boeing)	NE	89
BACJ40AD44-5	JUMPER	CF6-50 (Boeing)	NE	9
BACJ40AD44-6	JUMPER	CF6-50 (Boeing)	NE	19
BACJ40AD44-7	BONDING - JUMPER	CF6-50 (Boeing)	NE	4
BACJ40AD44-8	JUMPER	CF6-80A	NS	1
BACJ40AD44-8	JUMPER	CF6-80A	NS	1
BACJ40AD44-9	JUMPER - BONDING	CF6-80A	NS	1
BACJ40AD45-12	JUMPER - BONDING	CF6-80A	NS	2
BACJ40AD45-12	JUMPER - BONDING	CF6-80A	NS	1
BACJ40AD45-5	JUMPER ASSY	CF6-80A	NS	3
BACJ40AD45-5	JUMPER ASSY	CF6-80A	NS	1
BACJ40AD45-8	BONDING - JUMPER	CF6-80C2	NE	4
BACJ40AD45-9	BONDING - JUMPER	CF6-80C2	NE	9
BACN11Z14CK	NUT - FWD ENGINE MOUNT	CF6-80C2	NS	1
BACN11Z14CK	NUT - FWD ENGINE MOUNT	CF6-80C2	NE	1
BACP11PB4A	SEAL - O-RING	CF6-50 (Boeing)	NS	2
BACP11PB6A	SEAL - O-RING	CF6-50 (Boeing)	NE	23
BACP11PB6A	SEAL - O-RING	CF6-50 (Boeing)	NE	1
BACR12BM111	RING - BACK UP	CF6-80C2, CF6-80A, PW2000, CF6-50 (Boeing)	NS	7
BACR12BM212	RING - BACK UP	CF6-80C2, CF6-80A, PW2000, CF6-50 (Boeing)	NS	1
BACR12BM212	RING - BACK UP	CF6-80C2, CF6-80A, PW2000, CF6-50 (Boeing)	NS	1
BACR12BM212	RING - BACK UP	CF6-80C2, CF6-80A, PW2000, CF6-50 (Boeing)	NS	2
BACS18AF3	SPACER	CF6-80C2	NS	4
BLC1538M90P12-2	BLADE ASSY - HPTR STG 1	CF6-80C2	NE	1
BLC1538M90P12-2	BLADE ASSY - HPTR STG 1	CF6-80C2	NE	1
BLC1881M52G05-2	BLADE - HPTR STG 2	CF6-80C2	NE	1
BLC1881M52G05-2	BLADE - HPTR STG 2	CF6-80C2	NE	1
BLC1881M52G05-2	BLADE - HPTR STG 2	CF6-80C2	NE	1
BLC1881M52G05-2	BLADE - HPTR STG 2	CF6-80C2	NE	1
BLC1881M52G05-2	BLADE - HPTR STG 2	CF6-80C2	NE	1

Part Number	Part Description	Engine Type	Condition	Quantity
BLC1881M52G05-2	BLADE - HPTR STG 2	CF6-80C2	NE	1
BLC1881M52G05-2	BLADE - HPTR STG 2	CF6-80C2	NE	1
BLC1881M52G05-2	BLADE - HPTR STG 2	CF6-80C2	NE	1
BLC1881M52G05-2	BLADE - HPTR STG 2	CF6-80C2	NE	1
BLC1881M52G05-2	BLADE - HPTR STG 2	CF6-80C2	NE	1
BLC1881M52G05-2	BLADE - HPTR STG 2	CF6-80C2	OH	1
BLC1881M52G05-2	BLADE - HPTR STG 2	CF6-80C2	OH	1
BLC1881M52G05-2	BLADE - HPTR STG 2	CF6-80C2	OH	1
BLC1881M52G05-2	BLADE - HPTR STG 2	CF6-80C2	OH	1
BLC1881M52G05-2	BLADE - HPTR STG 2	CF6-80C2	OH	1
BLC9315M11G16	BLADE - HPTR STG 2	CF6-50 (LMCO)	OH	1
BLC9315M11G16	BLADE - HPTR STG 2	CF6-50 (LMCO)	OH	1
BLC9315M11G16	BLADE - HPTR STG 2	CF6-50 (LMCO)	OH	1
BLC9315M11G16	BLADE - HPTR STG 2	CF6-50 (LMCO)	OH	1
BLC9315M11G16	BLADE - HPTR STG 2	CF6-50 (LMCO)	OH	1
BLC9315M11G16	BLADE - HPTR STG 2	CF6-50 (LMCO)	OH	1
BLC9315M11G16	BLADE - HPTR STG 2	CF6-50 (LMCO)	OH	1
BLC9315M11G16	BLADE - HPTR STG 2	CF6-50 (LMCO)	OH	1
BLC9315M11G16	BLADE - HPTR STG 2	CF6-50 (LMCO)	OH	1
BLC9315M11G16	BLADE - HPTR STG 2	CF6-50 (LMCO)	OH	1
BLC9315M11G16	BLADE - HPTR STG 2	CF6-50 (LMCO)	OH	1
BLC9315M11G16	BLADE - HPTR STG 2	CF6-50 (LMCO)	OH	1
BLC9315M11G16	BLADE - HPTR STG 2	CF6-50 (LMCO)	OH	1
BLC9315M11G16	BLADE - HPTR STG 2	CF6-50 (LMCO)	OH	1
BLC9315M11G16	BLADE - HPTR STG 2	CF6-50 (LMCO)	OH	1
BRG-3	RACE - INNER NO. 3	CF6-50 (LMCO)	AR	1
BRG-4B	RACE - INNER NO. 4B	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
BRG-4B	RACE - INNER NO. 4B	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
BRG-4B	RACE - INNER NO. 4B	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
BRG-4B	RACE - INNER NO. 4B	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
BRG-4R	RACE - INNER NO. 4R	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
BSG0004-5511	HOSE ASSY	CF6-50	AR	1
BSG0004-5511	HOSE ASSY	CF6-50	AR	1
BSL0001-501	TRANSMITTER-FUEL PRESSURE	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
CH31843	PLUG - IGNITER (TYPE III)	CF6-80A, CF6-50 (LMCO)	AR	1
CH31843	PLUG - IGNITER (TYPE III)	CF6-80A, CF6-50 (LMCO)	AR	1
CH31843	PLUG - IGNITER (TYPE III)	CF6-80A, CF6-50 (LMCO)	AR	1
CH31843	PLUG - IGNITER (TYPE III)	CF6-80A, CF6-50 (LMCO)	AR	1
CH31843	PLUG - IGNITER (TYPE III)	CF6-80A, CF6-50 (LMCO)	AR	1
CH31843	PLUG - IGNITER (TYPE III)	CF6-80A, CF6-50 (LMCO)	AR	1
CH31843	PLUG - IGNITER (TYPE III)	CF6-80A, CF6-50 (LMCO)	AR	1
CH31843	PLUG - IGNITER (TYPE III)	CF6-80A, CF6-50 (LMCO)	AR	1
CH31843	PLUG - IGNITER (TYPE III)	CF6-80A, CF6-50 (LMCO)	AR	1
CH31843	PLUG - IGNITER (TYPE III)	CF6-80A, CF6-50 (LMCO)	AR	1
CH31843	PLUG - IGNITER (TYPE III)	CF6-80A, CF6-50 (LMCO)	AR	1
CH31843	PLUG - IGNITER (TYPE III)	CF6-80A, CF6-50 (LMCO)	AR	1
CH31843	PLUG - IGNITER (TYPE III)	CF6-80A, CF6-50 (LMCO)	AR	1
CH31843	PLUG - IGNITER (TYPE III)	CF6-80A, CF6-50 (LMCO)	AR	1
CH31904-2	PLUG - IGNITER (TYPE IV)	CF6-80C2	AR	1
CH31904-2	PLUG - IGNITER (TYPE IV)	CF6-80C2	AR	1
CH31904-2	PLUG - IGNITER (TYPE IV)	CF6-80C2	AR	1
CH31904-2	PLUG - IGNITER (TYPE IV)	CF6-80C2	AR	1
CH31905	PLUG - MAIN IGNITER (TYPE IV)	CF6-80A, CF6-50 (Boeing)	AR	1
CH31905	PLUG - MAIN IGNITER (TYPE IV)	CF6-80A, CF6-50 (Boeing)	AR	1
CH31905	PLUG - MAIN IGNITER (TYPE IV)	CF6-80A, CF6-50 (Boeing)	AR	1
CH31905	PLUG - MAIN IGNITER (TYPE IV)	CF6-80A, CF6-50 (Boeing)	AR	1
CH31905	PLUG - MAIN IGNITER (TYPE IV)	CF6-80A, CF6-50 (Boeing)	AR	1
CH31905	PLUG - MAIN IGNITER (TYPE IV)	CF6-80A, CF6-50 (Boeing)	AR	1
CH31905	PLUG - MAIN IGNITER (TYPE IV)	CF6-80A, CF6-50 (Boeing)	NE	1
CH53566-1	LEAD - IGNITION	CF6-80C2	NE	1
CH63038	SPACER - GASKET	CF6-50 (LMCO)	NE	2
CH63038	SPACER - GASKET	CF6-50 (LMCO)	NE	1

Part Number	Part Description	Engine Type	Condition	Quantity
CH63038	SPACER - GASKET	CF6-50 (LMCO)	NE	2
CH63038	SPACER - GASKET	CF6-50 (LMCO)	NE	2
CH63038	SPACER - GASKET	CF6-50 (LMCO)	NE	2
CH63038	SPACER - GASKET	CF6-50 (LMCO)	NE	3
CN1474M52G49-3A	VANE ASSY - HPT STG 1	CF6-80C2	NE	1
CN1474M52G49-3A	VANE ASSY - HPT STG 1	CF6-80C2	NE	1
CN1474M52G49-3A	VANE ASSY - HPT STG 1	CF6-80C2	NE	1
CN1474M52G49-3A	VANE ASSY - HPT STG 1	CF6-80C2	NE	1
CN1474M52G49-3A	VANE ASSY - HPT STG 1	CF6-80C2	NE	1
CN1474M52G49-3A	VANE ASSY - HPT STG 1	CF6-80C2	OH	1
CN1474M52G49-3A	VANE ASSY - HPT STG 1	CF6-80C2	OH	1
CN1474M52G49-3A	VANE ASSY - HPT STG 1	CF6-80C2	OH	1
CN1474M52G49-3A	VANE ASSY - HPT STG 1	CF6-80C2	OH	1
CN1474M52G49-3A	VANE ASSY - HPT STG 1	CF6-80C2	OH	1
CN9187M73P32	COUPLING - GROOVED CLAMP	CF6-50	AR	1
CN9212M74G56-2T	NOZZLE - HPT STG 1	CF6-80A	NE	1
CN9212M74G56-2T	NOZZLE - HPT STG 1	CF6-80A	NE	1
CN9212M74G56-2T	NOZZLE - HPT STG 1	CF6-80A	NE	1
CN9212M74G56-2T	NOZZLE - HPT STG 1	CF6-80A	NE	1
CN9212M74G56-2T	NOZZLE - HPT STG 1	CF6-80A	NE	1
CN9212M74G56-2T	NOZZLE - HPT STG 1	CF6-80A	NE	1
CN9212M74G56-2T	NOZZLE - HPT STG 1	CF6-80A	NE	1
CN9212M74G56-2T	NOZZLE - HPT STG 1	CF6-80A	NE	1
CN9212M74G56-2T	NOZZLE - HPT STG 1	CF6-80A	NE	1
CN9212M74G56-2T	NOZZLE - HPT STG 1	CF6-80A	NE	1
CN9212M74G56-2T	NOZZLE - HPT STG 1	CF6-80A	NE	1
CN9212M74G56-2T	NOZZLE - HPT STG 1	CF6-80A	NE	1
CN9212M74G56-2T	NOZZLE - HPT STG 1	CF6-80A	NE	1
CN9212M74G56-2T	NOZZLE - HPT STG 1	CF6-80A	NE	1
CN9212M74G56-2T	NOZZLE - HPT STG 1	CF6-80A	NE	1
CN9212M74G56-2T	NOZZLE - HPT STG 1	CF6-80A	OH	1
CN9212M74G57-2	NOZZLE - HPT STG 1	CF6-80A	NE	1
CN9234M90G19-5	SEGMENT ASSY - HPT STG 2 NGV	CF6-80A	NE	1
CN9234M90G19-5	SEGMENT ASSY - HPT STG 2 NGV	CF6-80A	NE	1
CN9234M90G19-5	SEGMENT ASSY - HPT STG 2 NGV	CF6-80A	NE	1
CN9234M90G19-5	SEGMENT ASSY - HPT STG 2 NGV	CF6-80A	NE	1
CN9234M90G19-5	SEGMENT ASSY - HPT STG 2 NGV	CF6-80A	NE	1
CN9234M90G19-5	SEGMENT ASSY - HPT STG 2 NGV	CF6-80A	NE	1

Part Number	Part Description	Engine Type	Condition	Quantity
CN9234M90G19-5	SEGMENT ASSY - HPT STG 2 NGV	CF6-80A	NE	1
DEC9299M96G07	PLUG ASSY - BORESCOPE HPT	CF6-80C2	NE	2
DN9187M73P56	COUPLING - GROOVED CLAMP	CF6-80A	NE	1
DN9187M73P56	COUPLING - GROOVED CLAMP	CF6-80A	NE	1
EL10593	V BAND CLAMP	CF6-80C2	INSP	7
EL10593	V BAND CLAMP	CF6-80C2	SV	1
EL10593	V BAND CLAMP	CF6-80C2	SV	2
F52481-4	RETAINER	CF6-80C2	NE	1
FWD MOUNT03	FWD MOUNT ASSY	CF6-80A	AR	1
J1018P04A	COUPLING - WELDING TUBE	CF6-80C2	NE	1
J1018P04A	COUPLING - WELDING TUBE	CF6-80C2	NE	1
J1018P08A	COUPLING - WELDING TUBE	CF6-80C2	NE	1
J1018P08A	COUPLING - WELDING TUBE	CF6-80C2	NE	4
J1018P08A	COUPLING - WELDING TUBE	CF6-80C2	NE	1
J1128P02	SEAL	CF6-80C2	NE	1
J1128P02	SEAL	CF6-80C2	NS	4
J1128P02	SEAL	CF6-80C2	NS	1
J1128P05	SEAL - RING	CF6-80C2, CF6-80A	NE	1
J1128P08	SEAL - RING	CF6-80C2	NE	1
J1128P10	SEAL - RING	CF6-80C2, CF6-80A	NS	1
J1128P10	SEAL - RING	CF6-80C2, CF6-80A	NS	85
J1128P11	SEAL - RING	CF6-80C2	NE	2
J1128P11	SEAL - RING	CF6-80C2	NE	1
J1128P12	SEAL - RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
J1128P12	SEAL - RING	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
J1168G01	BEARING ASSY - PL SELF	CF6-80C2	NS	3
J1168G01	BEARING ASSY - PL SELF	CF6-80C2	NE	3
J1168G01	BEARING ASSY - PL SELF	CF6-80C2	NE	2
J1168G01	BEARING ASSY - PL SELF	CF6-80C2	NE	10
J1168G01	BEARING ASSY - PL SELF	CF6-80C2	NE	1
J1168G01	BEARING ASSY - PL SELF	CF6-80C2	NE	1

Part Number	Part Description	Engine Type	Condition	Quantity
J1168G01	BEARING ASSY - PL SELF	CF6-80C2	NE	1
J1168G01	BEARING ASSY - PL SELF	CF6-80C2	NE	2
J1168G01	BEARING ASSY - PL SELF	CF6-80C2	NE	2
J1168G01	BEARING ASSY - PL SELF	CF6-80C2	NE	2
J1168G01	BEARING ASSY - PL SELF	CF6-80C2	NE	2
J1168G01	BEARING ASSY - PL SELF	CF6-80C2	NE	2
J1168G01	BEARING ASSY - PL SELF	CF6-80C2	NE	4
J1168G02	BEARING ASSY - PL SELF	CF6-80C2	NE	60
J1170P02	BEARING - BALL	CF6-80C2	NE	10
J1189G06	CAP - TUBE	CF6-80C2, CF6-80A	NE	1
J1236P16	ELBOW - WIRE SWIEVEL TUBE	CF6-80C2	NE	1
J1236P16	ELBOW - WIRE SWIEVEL TUBE	CF6-80C2	NE	1
J1311P03	SEAL - RING METAL-E	CF6-80C2	NE	5
J1311P03	SEAL - RING METAL-E	CF6-80C2	NE	11
J1311P03	SEAL - RING METAL-E	CF6-80C2	NE	4
J1311P05	SEAL - RING METAL-E	CF6-80C2	NS	2
J1311P05	SEAL - RING METAL-E	CF6-80C2	NS	18
J1314G105	CAP ASSY - TUBE	CF6-80C2	NS	4
J1315G106	CAP ASSY	CF6-80C2	NE	2
J1315G108	CAP ASSY	CF6-80C2	NS	1
J1328P10B	COUPLING - TUBE (SPD)	CF6-80C2	NE	1
J160P0051	TGB DRIVE SHAFT RETAINING RING	CF6-80C2	NS	7
J160P0051	TGB DRIVE SHAFT RETAINING RING	CF6-80C2	OH	1
J160P0051	TGB DRIVE SHAFT RETAINING RING	CF6-80C2	NS	1
J160P0109	TGB RETAINING RING	CF6-80C2	AR	1
J160P0121	HORIZONTAL DRIVE SHAFT RETAINING RING	CF6-80C2	NE	4
J178E0156A	HOSE - TEFLON	CF6-80C2	OH	1
J179H0100G	HOSE - TEFLON	CF6-80C2	AR	1
J179H0100J	HOSE - TEFLON	CF6-80C2	AR	1
J183L0164A	TUBE/HOSE - INL FWD OIL	CF6-50	AR	1
J1913-02	VALVE - COMBUSTOR DRAIN	CF6-80A	AR	1
J1913-02	VALVE - COMBUSTOR DRAIN	CF6-80A	OH	1
J191H0084G	HOSE - TEFLON	CF6-80C2	AR	1
J191H0084G	HOSE - TEFLON	CF6-80C2	AR	1
J204P0062	RING - RETAINING	CF6-80C2, CF6-80A	NS	6
J206P0087	RING - RETAINING	CF6-80C2	NS	1
J206P0087	RING - RETAINING	CF6-80C2	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
J221P043	SEAL - O-RING	CF6-80C2, CF6-80A	NS	1
J221P147	SEAL - O-RING	CF6-80A, CF6-50 (LMCO)	NS	1
J221P147	SEAL - O-RING	CF6-80A, CF6-50 (LMCO)	NS	2
J221P147	SEAL - O-RING	CF6-80A, CF6-50 (LMCO)	NS	8
J221P168	SEAL - O-RING	CF6-80A	NS	1
J264C0065AB	HOSE - P3G	CF6-80C2	AR	1
J2714-01	VALVE - COMBUSTOR DRAIN	CF6-80A	AR	1
J2714-01	VALVE - COMBUSTOR DRAIN	CF6-80A	AR	1
J382P08A	TUBE - COUPLING	CF6-80A, CF6-50 (LMCO)	AR	1
J382P16B	TUBE - COUPLING	CF6-80A	NE	1
J513P04	ELBOW	CF6-50 (LMCO)	NS	1
J513P04	ELBOW	CF6-50 (LMCO)	NS	4
J537G08	ELBOW - TUBE	CF6-80A	OH	1
JA1333M60P02	SPACER - ACTR	CF6-80A, CF6-50 (LMCO)	NE	10
JA1347M94P07	RING - INTEGRAL SEAL	CF6-80C2	NE	1
JA1375M50P18	SEAL	CF6-80C2	NE	2
JA1375M50P19	SEAL	CF6-80C2, CF6-80A	NE	6
JA1375M50P19	SEAL	CF6-80C2, CF6-80A	NE	3
JA1375M50P20	SEAL	CF6-80C2, CF6-80A	NE	1
JA1375M50P20	SEAL	CF6-80C2, CF6-80A	NE	1
JA1375M50P21	SEAL	CF6-80C2	NE	1
JA1774M59P01	SEAL - RING	CF6-80C2	NE	3
JA1774M59P01	SEAL - RING	CF6-80C2	NE	4
JA1774M59P01	SEAL - RING	CF6-80C2	NE	4
JA1774M59P01	SEAL - RING	CF6-80C2	NE	4
JA1774M59P01	SEAL - RING	CF6-80C2	NE	3
JA1822M77P01	SEAL - RETAINER	CF6-80C2	OH	3
JA1854M40P01	SEAL - LEAF STG 13	CF6-80C2	NE	1
JA1854M40P01	SEAL - LEAF STG 13	CF6-80C2	NE	1
JA1854M40P01	SEAL - LEAF STG 13	CF6-80C2	NE	46
JA1854M40P01	SEAL - LEAF STG 13	CF6-80C2	NE	3
JA1854M96G02	LINER ASSY - STG 13	CF6-80C2	AR	1
JA1862M74P01	SEAL - HPT STATOR OUTER	CF6-50 (LMCO)	AR	1
JA2032M66G01	LUG ASSY-LKG	CF6-80C2, CF6-50 (LMCO)	NE	4

Part Number	Part Description	Engine Type	Condition	Quantity
JA9010M13P22	SEAL	CF6-80C2, CF6-80A	NE	6
JA9146M80P03	SLEEVE - ACTN ARM	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NE	15
JA9146M80P05	SLEEVE - ACTN ARM	CF6-80C2	NE	21
JA9146M80P05	SLEEVE - ACTN ARM	CF6-80C2	NE	89
JA9295M30G06	RING ASSY - STG 4 SEG ACTN	CF6-80A	AR	1
JA9315M16G17	SEAL - STA HPT STTR INT STG	CF6-80A	OH	1
JA9315M16G17	SEAL - STA HPT STTR INT STG	CF6-80A	OH	1
JA9333M69P01	PAD WEAR	CF6-80C2	NE	5
JA9381M83G01	NUT ASSY - SLFLKG GANG CHANNEL	CF6-80C2	NE	2
JA9381M83G01	NUT ASSY - SLFLKG GANG CHANNEL	CF6-80C2	NE	1
JA9381M83G01	NUT ASSY - SLFLKG GANG CHANNEL	CF6-80C2	NE	2
JA9381M83G01	NUT ASSY - SLFLKG GANG CHANNEL	CF6-80C2	NE	2
JA9381M83G01	NUT ASSY - SLFLKG GANG CHANNEL	CF6-80C2	NE	1
JA9559M19P01	SEAL	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NE	60
JA9559M20G02	SEAL - RING	CF6-50 (LMCO)	NE	4
JA9559M20G02	SEAL - RING	CF6-50 (LMCO)	NE	7
JAK190P01	BLADE - STG 11 (NARROW)	CF6-80C2	OH	1
JAK388P18	BLADE - STG 13 (WIDE)	CF6-80C2	OH	2
JAK488P11	BLADE - STG 14 (NARROW)	CF6-80C2	OH	1
JAK615P01	BLADE - STG 6 (NARROW)	CF6-80C2	NE	1
JAK715P05	BLADE - STG 7 (NARROW)	CF6-80C2	OH	1
JAK715P08	BLADE - STG 7 (WIDE)	CF6-80C2	OH	1
JAK715P08	BLADE - STG 7 (WIDE)	CF6-80C2	OH	1
JAK818P08	BLADE - STG 8 (WIDE)	CF6-80C2	OH	5
JAK919P05	BLADE - STG 9 (NARROW)	CF6-80C2	OH	1
JE00023P03	SLEEVE - ACTUATION ARM	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	17
JE00023P03	SLEEVE - ACTUATION ARM	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	149
JK00112	SEAL - LEAF SHROUD STG 2	CF6-80C2	SV	24

Part Number	Part Description	Engine Type	Condition	Quantity
JK00112	SEAL - LEAF SHROUD STG 2	CF6-80C2	NE	2
JK00112	SEAL - LEAF SHROUD STG 2	CF6-80C2	NE	58
JK00112	SEAL - LEAF SHROUD STG 2	CF6-80C2	SV	2
JL00016-03	LINK ASSY - SUPPORT	CF6-80C2	NE	2
JL00016-03	LINK ASSY - SUPPORT	CF6-80C2	NE	2
JL00016-03	LINK ASSY - SUPPORT	CF6-80C2	NE	6
JL00016-03	LINK ASSY - SUPPORT	CF6-80C2	NE	6
K012P02	VANE - STG 10 (WIDE)	CF6-80C2	OH	1
K012P02	VANE - STG 10 (WIDE)	CF6-80C2	NE	1
K012P04	VANE - STG 10	CF6-80C2	OH	1
K012P05	VANE - STG 10	CF6-80C2	OH	1
K012P07	VANE - STG 10 (BOREScope)	CF6-80C2	OH	1
K012P09	VANE - STG 10 (BOREScope)	CF6-80C2	OH	1
K024G02	HPC ROTOR BLADE STG 1	CF6-80C2	OH	1
K024G02	HPC ROTOR BLADE STG 1	CF6-80C2	OH	1
K027P01	HPC STATOR VANE STG 13 [STD]	CF6-80C2	OH	2
K027P01	HPC STATOR VANE STG 13 [STD]	CF6-80C2	OH	16
K027P01	HPC STATOR VANE STG 13 [STD]	CF6-80C2	AR	62
K027P01	HPC STATOR VANE STG 13 [STD]	CF6-80C2	OH	9
K027P01	HPC STATOR VANE STG 13 [STD]	CF6-80C2	OH	3
K027P01	HPC STATOR VANE STG 13 [STD]	CF6-80C2	OH	1
K027P01	HPC STATOR VANE STG 13 [STD]	CF6-80C2	OH	3
K027P01	HPC STATOR VANE STG 13 [STD]	CF6-80C2	OH	2
K027P01	HPC STATOR VANE STG 13 [STD]	CF6-80C2	OH	2
K027P01	HPC STATOR VANE STG 13 [STD]	CF6-80C2	OH	1
K027P01	HPC STATOR VANE STG 13 [STD]	CF6-80C2	OH	2
K027P04	HPC STATOR VANE STG 13 [BOREScope]	CF6-80C2	AR	1
K027P04	HPC STATOR VANE STG 13 [BOREScope]	CF6-80C2	AR	1
K027P05	HPC STATOR VANE STG 13 [BOREScope]	CF6-80C2	AR	1
K040P06	BLADE - STG 10 (CONCAVE)	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K046P07	HPC STATOR OUTLET GUIDE VANE [NARROW]	CF6-80C2	OH	2
K046P07	HPC STATOR OUTLET GUIDE VANE [NARROW]	CF6-80C2	OH	1
K046P07	HPC STATOR OUTLET GUIDE VANE [NARROW]	CF6-80C2	AR	67
K046P07	HPC STATOR OUTLET GUIDE VANE [NARROW]	CF6-80C2	OH	1
K046P07	HPC STATOR OUTLET GUIDE VANE [NARROW]	CF6-80C2	OH	4
K046P07	HPC STATOR OUTLET GUIDE VANE [NARROW]	CF6-80C2	OH	3
K046P07	HPC STATOR OUTLET GUIDE VANE [NARROW]	CF6-80C2	OH	3
K046P07	HPC STATOR OUTLET GUIDE VANE [NARROW]	CF6-80C2	OH	64
K046P08	HPC STATOR OUTLET GUIDE VANE [WIDE]	CF6-80C2	AR	33
K047G02	HPC STATOR OUTLET GUIDE VANE	CF6-80C2	AR	3
K047G02	HPC STATOR OUTLET GUIDE VANE	CF6-80C2	AR	1
K050P01	BLADE - STG 10 (NARROW)	CF6-50 (LMCO)	AR	34
K050P01	BLADE - STG 10 (NARROW)	CF6-50 (LMCO)	AR	1
K050P01	BLADE - STG 10 (NARROW)	CF6-50 (LMCO)	AR	1
K050P01	BLADE - STG 10 (NARROW)	CF6-50 (LMCO)	AR	5
K050P01	BLADE - STG 10 (NARROW)	CF6-50 (LMCO)	AR	7
K050P01	BLADE - STG 10 (NARROW)	CF6-50 (LMCO)	AR	11
K050P01	BLADE - STG 10 (NARROW)	CF6-50 (LMCO)	AR	5
K050P01	BLADE - STG 10 (NARROW)	CF6-50 (LMCO)	AR	1
K050P01	BLADE - STG 10 (NARROW)	CF6-50 (LMCO)	AR	1
K050P01	BLADE - STG 10 (NARROW)	CF6-50 (LMCO)	AR	7
K050P01	BLADE - STG 10 (NARROW)	CF6-50 (LMCO)	AR	1
K050P01	BLADE - STG 10 (NARROW)	CF6-50 (LMCO)	AR	38
K050P01	BLADE - STG 10 (NARROW)	CF6-50 (LMCO)	AR	36
K050P01	BLADE - STG 10 (NARROW)	CF6-50 (LMCO)	OH	1
K050P01	BLADE - STG 10 (NARROW)	CF6-50 (LMCO)	AR	35
K050P01	BLADE - STG 10 (NARROW)	CF6-50 (LMCO)	AR	36
K050P01	BLADE - STG 10 (NARROW)	CF6-50 (LMCO)	AR	30
K050P01	BLADE - STG 10 (NARROW)	CF6-50 (LMCO)	AR	41
K050P01	BLADE - STG 10 (NARROW)	CF6-50 (LMCO)	AR	29
K050P01	BLADE - STG 10 (NARROW)	CF6-50 (LMCO)	AR	32
K050P01	BLADE - STG 10 (NARROW)	CF6-50 (LMCO)	AR	43
K050P01	BLADE - STG 10 (NARROW)	CF6-50 (LMCO)	AR	37
K050P01	BLADE - STG 10 (NARROW)	CF6-50 (LMCO)	OH	2
K050P01	BLADE - STG 10 (NARROW)	CF6-50 (LMCO)	AR	31
K050P01	BLADE - STG 10 (NARROW)	CF6-50 (LMCO)	OH	3
K050P02	BLADE - STG 10 (CONCAVE)	CF6-50 (LMCO)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
K050P03	BLADE - STG 10 (CONVEX)	CF6-50 (LMCO)	AR	2
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	28
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	18
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	9
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	2
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	7
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	1
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	1
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	11
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	3
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	1
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	1
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	1
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	7
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	32
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	1
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	4
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	4
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	9
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	1
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	2
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	1
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	1
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	28
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	1
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	7
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	1
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	1
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	27
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	24
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	32
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	21
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	32
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	30
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	19
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	25
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	24
K050P04	BLADE - STG 10 (WIDE)	CF6-50 (LMCO)	AR	30
K050P05	BLADE - STG 10 (EXTRA WIDE)	CF6-50 (LMCO)	AR	1
K050P05	BLADE - STG 10 (EXTRA WIDE)	CF6-50 (LMCO)	AR	6
K050P05	BLADE - STG 10 (EXTRA WIDE)	CF6-50 (LMCO)	AR	1
K050P05	BLADE - STG 10 (EXTRA WIDE)	CF6-50 (LMCO)	AR	8
K050P05	BLADE - STG 10 (EXTRA WIDE)	CF6-50 (LMCO)	OH	3

Part Number	Part Description	Engine Type	Condition	Quantity
K050P05	BLADE - STG 10 (EXTRA WIDE)	CF6-50 (LMCO)	OH	5
K050P07	BLADE - STG 10 (NARROW)	CF6-80A	AR	7
K050P07	BLADE - STG 10 (NARROW)	CF6-80A	AR	30
K050P07	BLADE - STG 10 (NARROW)	CF6-80A	AR	1
K050P07	BLADE - STG 10 (NARROW)	CF6-80A	OH	22
K050P07	BLADE - STG 10 (NARROW)	CF6-80A	OH	70
K050P07	BLADE - STG 10 (NARROW)	CF6-80A	OH	2
K050P07	BLADE - STG 10 (NARROW)	CF6-80A	OH	24
K050P07	BLADE - STG 10 (NARROW)	CF6-80A	AR	24
K050P07	BLADE - STG 10 (NARROW)	CF6-80A	AR	33
K050P07	BLADE - STG 10 (NARROW)	CF6-80A	AR	12
K050P07	BLADE - STG 10 (NARROW)	CF6-80A	AR	19
K050P07	BLADE - STG 10 (NARROW)	CF6-80A	AR	18
K050P07	BLADE - STG 10 (NARROW)	CF6-80A	OH	1
K050P07	BLADE - STG 10 (NARROW)	CF6-80A	OH	1
K050P08	BLADE - STG 10 (CONCAVE)	CF6-80A	AR	1
K050P08	BLADE - STG 10 (CONCAVE)	CF6-80A	AR	2
K050P08	BLADE - STG 10 (CONCAVE)	CF6-80A	AR	2
K050P08	BLADE - STG 10 (CONCAVE)	CF6-80A	AR	2
K050P08	BLADE - STG 10 (CONCAVE)	CF6-80A	OH	1
K050P09	BLADE - STG 10 (CONVEX)	CF6-80A	AR	1
K050P09	BLADE - STG 10 (CONVEX)	CF6-80A	OH	4
K050P09	BLADE - STG 10 (CONVEX)	CF6-80A	OH	6
K050P10	BLADE - STG 10 (WIDE)	CF6-80A	AR	14
K050P10	BLADE - STG 10 (WIDE)	CF6-80A	AR	13
K050P16	BLADE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K050P16	BLADE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
K050P16	BLADE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	8
K050P16	BLADE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K050P16	BLADE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	7
K050P16	BLADE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K050P17	BLADE - STG 10 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K050P17	BLADE - STG 10 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K050P19	BLADE - STG 10 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K050P21	BLADE - STG 10 (NARROW)	CF6-80A	AR	33
K050P21	BLADE - STG 10 (NARROW)	CF6-80A	AR	39
K050P21	BLADE - STG 10 (NARROW)	CF6-80A	AR	39
K050P21	BLADE - STG 10 (NARROW)	CF6-80A	AR	13

Part Number	Part Description	Engine Type	Condition	Quantity
K050P21	BLADE - STG 10 (NARROW)	CF6-80A	AR	40
K050P21	BLADE - STG 10 (NARROW)	CF6-80A	AR	37
K050P21	BLADE - STG 10 (NARROW)	CF6-80A	AR	24
K050P21	BLADE - STG 10 (NARROW)	CF6-80A	AR	40
K050P21	BLADE - STG 10 (NARROW)	CF6-80A	AR	19
K050P21	BLADE - STG 10 (NARROW)	CF6-80A	AR	20
K050P21	BLADE - STG 10 (NARROW)	CF6-80A	AR	17
K050P21	BLADE - STG 10 (NARROW)	CF6-80A	AR	37
K050P22	BLADE - STG 10 (CONCAVE)	CF6-80A	AR	1
K050P22	BLADE - STG 10 (CONCAVE)	CF6-80A	AR	2
K050P22	BLADE - STG 10 (CONCAVE)	CF6-80A	AR	2
K050P22	BLADE - STG 10 (CONCAVE)	CF6-80A	AR	2
K050P22	BLADE - STG 10 (CONCAVE)	CF6-80A	AR	2
K050P22	BLADE - STG 10 (CONCAVE)	CF6-80A	AR	2
K050P22	BLADE - STG 10 (CONCAVE)	CF6-80A	AR	2
K050P22	BLADE - STG 10 (CONCAVE)	CF6-80A	AR	2
K050P23	BLADE - STG 10 (CONVEX)	CF6-80A	AR	1
K050P23	BLADE - STG 10 (CONVEX)	CF6-80A	AR	2
K050P23	BLADE - STG 10 (CONVEX)	CF6-80A	AR	2
K050P23	BLADE - STG 10 (CONVEX)	CF6-80A	AR	2
K050P23	BLADE - STG 10 (CONVEX)	CF6-80A	AR	2
K050P23	BLADE - STG 10 (CONVEX)	CF6-80A	AR	2
K050P23	BLADE - STG 10 (CONVEX)	CF6-80A	AR	2
K050P24	BLADE - STG 10 (WIDE)	CF6-80A	AR	17
K050P24	BLADE - STG 10 (WIDE)	CF6-80A	AR	22
K050P24	BLADE - STG 10 (WIDE)	CF6-80A	AR	23
K050P24	BLADE - STG 10 (WIDE)	CF6-80A	AR	11
K050P24	BLADE - STG 10 (WIDE)	CF6-80A	AR	20
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	41
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	43
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	51
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	43

Part Number	Part Description	Engine Type	Condition	Quantity
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	41
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	14
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	15
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	8
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	50
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	43
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	45
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	49
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	73
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	78
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	41
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K081P27	VANE - STG 10 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
K081P28	VANE - STG 10 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	37
K081P28	VANE - STG 10 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	29
K081P28	VANE - STG 10 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	32
K081P28	VANE - STG 10 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P28	VANE - STG 10 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K081P28	VANE - STG 10 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P28	VANE - STG 10 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P28	VANE - STG 10 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
K081P28	VANE - STG 10 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	37
K081P28	VANE - STG 10 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P28	VANE - STG 10 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K081P28	VANE - STG 10 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P28	VANE - STG 10 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	17
K081P28	VANE - STG 10 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
K081P28	VANE - STG 10 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K081P28	VANE - STG 10 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	41
K081P28	VANE - STG 10 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	48
K081P28	VANE - STG 10 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	20
K081P28	VANE - STG 10 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	17
K081P28	VANE - STG 10 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	16
K081P28	VANE - STG 10 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	16
K081P28	VANE - STG 10 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
K081P28	VANE - STG 10 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	25
K081P28	VANE - STG 10 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	19
K081P28	VANE - STG 10 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	35
K081P28	VANE - STG 10 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	50
K081P29	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P29	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P29	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P29	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K081P29	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P29	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P29	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P29	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K081P29	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P29	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P29	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P29	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P29	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P29	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P29	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P29	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P29	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P29	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P30	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P30	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P30	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P30	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P30	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P30	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P30	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P30	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P30	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P30	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P30	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P30	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K081P30	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P30	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P30	VANE - STG 10	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K081P32	VANE - STG 10 (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K081P32	VANE - STG 10 (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K081P32	VANE - STG 10 (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K081P32	VANE - STG 10 (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K081P32	VANE - STG 10 (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
K081P32	VANE - STG 10 (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K081P32	VANE - STG 10 (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K081P32	VANE - STG 10 (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K081P32	VANE - STG 10 (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
K081P32	VANE - STG 10 (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
K081P32	VANE - STG 10 (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K081P32	VANE - STG 10 (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K081P37	VANE - STG 10 (WIDE+)	CF6-80A	AR	1
K081P38	VANE - STG 10 (NARROW)	CF6-80A	AR	57
K081P38	VANE - STG 10 (NARROW)	CF6-80A	OH	4
K081P38	VANE - STG 10 (NARROW)	CF6-80A	OH	3
K081P38	VANE - STG 10 (NARROW)	CF6-80A	OH	40
K081P38	VANE - STG 10 (NARROW)	CF6-80A	OH	49
K081P39	VANE - STG 10 (WIDE)	CF6-80A	OH	4
K081P39	VANE - STG 10 (WIDE)	CF6-80A	OH	3
K081P39	VANE - STG 10 (WIDE)	CF6-80A	OH	26
K081P39	VANE - STG 10 (WIDE)	CF6-80A	OH	10
K081P39	VANE - STG 10 (WIDE)	CF6-80A	OH	2
K081P39	VANE - STG 10 (WIDE)	CF6-80A	OH	1
K081P39	VANE - STG 10 (WIDE)	CF6-80A	OH	1
K081P40	VANE - STG 10	CF6-80A	AR	1
K081P40	VANE - STG 10	CF6-80A	AR	1
K081P40	VANE - STG 10	CF6-80A	AR	1
K081P40	VANE - STG 10	CF6-80A	AR	1
K081P40	VANE - STG 10	CF6-80A	AR	1
K081P40	VANE - STG 10	CF6-80A	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	33
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	17
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	32
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	22
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	33
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	25
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	27

Part Number	Part Description	Engine Type	Condition	Quantity
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	32
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	9
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	7
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	29
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	33
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	32
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	24
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	11
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	7
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	32
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	27
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	32
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K086P03	VANE - INLET GUIDE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3

Part Number	Part Description	Engine Type	Condition	Quantity
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	23
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	13
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	26

Part Number	Part Description	Engine Type	Condition	Quantity
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	26
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	22
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K086P04	HPC STATOR VANE STG IGV	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	34
K090P02	HPC ROTOR BLADE STG 10 [CONCAVE]	CF6-80C2	OH	2
K102G01	VANE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	8

Part Number	Part Description	Engine Type	Condition	Quantity
K102G01	VANE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K102G01	VANE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G01	VANE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K102G01	VANE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K102G01	VANE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K102G01	VANE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K102G01	VANE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	24
K102G02	VANE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K102G02	VANE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K102G02	VANE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G02	VANE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G02	VANE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K102G02	VANE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	6
K102G02	VANE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G02	VANE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G02	VANE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
K102G02	VANE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K102G02	VANE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K102G02	VANE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K102G02	VANE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K102G02	VANE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K102G02	VANE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K102G02	VANE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K102G02	VANE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	13
K102G02	VANE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K102G03	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K102G03	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K102G03	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G03	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G03	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G03	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G03	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G03	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G03	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G03	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G03	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K102G03	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G03	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G03	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G03	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G03	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G03	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G03	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G03	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G03	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G03	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G04	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G04	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G04	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G04	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G04	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G04	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G04	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G04	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G04	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G04	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G04	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G04	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G04	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K102G04	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G04	VANE - STG 8 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K102G06	VANE - STG 8 (SPLITLINE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G06	VANE - STG 8 (SPLITLINE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G06	VANE - STG 8 (SPLITLINE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G06	VANE - STG 8 (SPLITLINE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G06	VANE - STG 8 (SPLITLINE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G06	VANE - STG 8 (SPLITLINE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G06	VANE - STG 8 (SPLITLINE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G06	VANE - STG 8 (SPLITLINE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G06	VANE - STG 8 (SPLITLINE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K102G07	VANE - STG 8	CF6-50	OH	1
K102G08	VANE - STG 8 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K102G08	VANE - STG 8 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K102G16	VANE - STG 8 (NARROW)	CF6-80A	AR	1
K102G16	VANE - STG 8 (NARROW)	CF6-80A	OH	1
K102G16	VANE - STG 8 (NARROW)	CF6-80A	OH	3
K102G16	VANE - STG 8 (NARROW)	CF6-80A	OH	8
K102G16	VANE - STG 8 (NARROW)	CF6-80A	OH	7
K102G16	VANE - STG 8 (NARROW)	CF6-80A	OH	2
K102G16	VANE - STG 8 (NARROW)	CF6-80A	OH	11
K102G16	VANE - STG 8 (NARROW)	CF6-80A	OH	12
K102G16	VANE - STG 8 (NARROW)	CF6-80A	OH	2
K102G16	VANE - STG 8 (NARROW)	CF6-80A	OH	13
K102G16	VANE - STG 8 (NARROW)	CF6-80A	AR	14
K102G16	VANE - STG 8 (NARROW)	CF6-80A	AR	13
K102G16	VANE - STG 8 (NARROW)	CF6-80A	AR	10
K102G16	VANE - STG 8 (NARROW)	CF6-80A	AR	8
K102G16	VANE - STG 8 (NARROW)	CF6-80A	OH	4
K102G16	VANE - STG 8 (NARROW)	CF6-80A	OH	1
K102G16	VANE - STG 8 (NARROW)	CF6-80A	OH	1
K102G16	VANE - STG 8 (NARROW)	CF6-80A	OH	11

Part Number	Part Description	Engine Type	Condition	Quantity
K106G01	VANE - STG 8	CF6-50	AR	1
K106G01	VANE - STG 8	CF6-50	AR	1
K106G01	VANE - STG 8	CF6-50	AR	1
K118P06	BLADE - STG 12 (NARROW)	CF6-50 (LMCO)	AR	31
K118P06	BLADE - STG 12 (NARROW)	CF6-50 (LMCO)	AR	46
K118P06	BLADE - STG 12 (NARROW)	CF6-50 (LMCO)	AR	21
K118P06	BLADE - STG 12 (NARROW)	CF6-50 (LMCO)	AR	3
K118P06	BLADE - STG 12 (NARROW)	CF6-50 (LMCO)	AR	22
K118P06	BLADE - STG 12 (NARROW)	CF6-50 (LMCO)	AR	36
K118P06	BLADE - STG 12 (NARROW)	CF6-50 (LMCO)	OH	1
K118P06	BLADE - STG 12 (NARROW)	CF6-50 (LMCO)	OH	1
K118P06	BLADE - STG 12 (NARROW)	CF6-50 (LMCO)	OH	1
K118P06	BLADE - STG 12 (NARROW)	CF6-50 (LMCO)	AR	32
K118P06	BLADE - STG 12 (NARROW)	CF6-50 (LMCO)	OH	1
K118P06	BLADE - STG 12 (NARROW)	CF6-50 (LMCO)	OH	2
K118P06	BLADE - STG 12 (NARROW)	CF6-50 (LMCO)	OH	3
K118P06	BLADE - STG 12 (NARROW)	CF6-50 (LMCO)	OH	3
K118P06	BLADE - STG 12 (NARROW)	CF6-50 (LMCO)	AR	35
K118P06	BLADE - STG 12 (NARROW)	CF6-50 (LMCO)	OH	35
K118P07	BLADE - STG 12 (CONCAVE)	CF6-50 (LMCO)	AR	1
K118P07	BLADE - STG 12 (CONCAVE)	CF6-50 (LMCO)	AR	1
K118P07	BLADE - STG 12 (CONCAVE)	CF6-50 (LMCO)	AR	1
K118P07	BLADE - STG 12 (CONCAVE)	CF6-50 (LMCO)	AR	2
K118P07	BLADE - STG 12 (CONCAVE)	CF6-50 (LMCO)	AR	2
K118P08	BLADE - STG 12 (CONVEX)	CF6-50 (LMCO)	AR	2
K118P08	BLADE - STG 12 (CONVEX)	CF6-50 (LMCO)	AR	2
K118P08	BLADE - STG 12 (CONVEX)	CF6-50 (LMCO)	AR	2
K118P08	BLADE - STG 12 (CONVEX)	CF6-50 (LMCO)	OH	2
K118P09	BLADE - STG 12 (WIDE)	CF6-50 (LMCO)	AR	2
K118P09	BLADE - STG 12 (WIDE)	CF6-50 (LMCO)	AR	7
K118P09	BLADE - STG 12 (WIDE)	CF6-50 (LMCO)	AR	6
K118P09	BLADE - STG 12 (WIDE)	CF6-50 (LMCO)	AR	3
K118P09	BLADE - STG 12 (WIDE)	CF6-50 (LMCO)	AR	37
K118P09	BLADE - STG 12 (WIDE)	CF6-50 (LMCO)	AR	32
K118P09	BLADE - STG 12 (WIDE)	CF6-50 (LMCO)	AR	1
K118P09	BLADE - STG 12 (WIDE)	CF6-50 (LMCO)	OH	1
K118P09	BLADE - STG 12 (WIDE)	CF6-50 (LMCO)	OH	18
K118P10	BLADE - STG 12 (EXTRA WIDE)	CF6-50 (LMCO)	AR	1
K118P10	BLADE - STG 12 (EXTRA WIDE)	CF6-50 (LMCO)	AR	10
K118P10	BLADE - STG 12 (EXTRA WIDE)	CF6-50 (LMCO)	AR	2
K118P19	BLADE - STG 12 (NARROW)	CF6-80A	AR	36
K118P19	BLADE - STG 12 (NARROW)	CF6-80A	AR	38
K118P19	BLADE - STG 12 (NARROW)	CF6-80A	AR	35
K118P19	BLADE - STG 12 (NARROW)	CF6-80A	AR	29
K118P19	BLADE - STG 12 (NARROW)	CF6-80A	OH	7

Part Number	Part Description	Engine Type	Condition	Quantity
K118P19	BLADE - STG 12 (NARROW)	CF6-80A	AR	35
K118P19	BLADE - STG 12 (NARROW)	CF6-80A	OH	2
K118P19	BLADE - STG 12 (NARROW)	CF6-80A	OH	5
K118P19	BLADE - STG 12 (NARROW)	CF6-80A	OH	7
K118P20	BLADE - STG 12 (CONCAVE)	CF6-80A	AR	2
K118P20	BLADE - STG 12 (CONCAVE)	CF6-80A	AR	2
K118P20	BLADE - STG 12 (CONCAVE)	CF6-80A	AR	2
K118P21	BLADE - STG 12 (CONVEX)	CF6-80A	AR	2
K118P21	BLADE - STG 12 (CONVEX)	CF6-80A	AR	1
K118P22	BLADE - STG 12 (WIDE)	CF6-80A	OH	1
K118P33	BLADE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K118P33	BLADE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K118P33	BLADE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K118P33	BLADE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	8
K118P33	BLADE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K118P33	BLADE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	8
K118P33	BLADE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K118P34	BLADE - STG 12 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K118P34	BLADE - STG 12 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K118P36	BLADE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K118P36	BLADE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K118P38	BLADE - STG 12 (NARROW)	CF6-80A	AR	49
K118P38	BLADE - STG 12 (NARROW)	CF6-80A	OH	52
K118P38	BLADE - STG 12 (NARROW)	CF6-80A	OH	12
K118P38	BLADE - STG 12 (NARROW)	CF6-80A	AR	10
K118P38	BLADE - STG 12 (NARROW)	CF6-80A	AR	33
K118P38	BLADE - STG 12 (NARROW)	CF6-80A	AR	49
K118P38	BLADE - STG 12 (NARROW)	CF6-80A	AR	48
K118P38	BLADE - STG 12 (NARROW)	CF6-80A	AR	26
K118P38	BLADE - STG 12 (NARROW)	CF6-80A	AR	41
K118P38	BLADE - STG 12 (NARROW)	CF6-80A	OH	1
K118P39	BLADE - STG 12 (CONCAVE)	CF6-80A	AR	2
K118P39	BLADE - STG 12 (CONCAVE)	CF6-80A	AR	2
K118P39	BLADE - STG 12 (CONCAVE)	CF6-80A	AR	2
K118P39	BLADE - STG 12 (CONCAVE)	CF6-80A	AR	2
K118P39	BLADE - STG 12 (CONCAVE)	CF6-80A	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
K118P39	BLADE - STG 12 (CONCAVE)	CF6-80A	AR	1
K118P39	BLADE - STG 12 (CONCAVE)	CF6-80A	AR	2
K118P40	BLADE - STG 12 (CONVEX)	CF6-80A	AR	2
K118P40	BLADE - STG 12 (CONVEX)	CF6-80A	AR	2
K118P40	BLADE - STG 12 (CONVEX)	CF6-80A	AR	2
K118P40	BLADE - STG 12 (CONVEX)	CF6-80A	AR	2
K118P40	BLADE - STG 12 (CONVEX)	CF6-80A	AR	2
K118P40	BLADE - STG 12 (CONVEX)	CF6-80A	AR	2
K118P40	BLADE - STG 12 (CONVEX)	CF6-80A	AR	2
K118P40	BLADE - STG 12 (CONVEX)	CF6-80A	AR	2
K118P40	BLADE - STG 12 (CONVEX)	CF6-80A	OH	1
K118P41	BLADE - STG 12 (WIDE)	CF6-80A	OH	1
K118P41	BLADE - STG 12 (WIDE)	CF6-80A	OH	1
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	35
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	33
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	12
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	13
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	30

Part Number	Part Description	Engine Type	Condition	Quantity
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	13
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	8
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	20
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	37
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	15
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	13
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	13
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	9
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	8
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	8
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	8
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6

Part Number	Part Description	Engine Type	Condition	Quantity
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	32
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	42
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	22
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	35
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	32
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	31
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	32
K134P09	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	32
K134P10	BLADE - STG 6 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K134P10	BLADE - STG 6 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K134P10	BLADE - STG 6 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K134P10	BLADE - STG 6 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K134P10	BLADE - STG 6 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P10	BLADE - STG 6 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P10	BLADE - STG 6 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P10	BLADE - STG 6 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K134P10	BLADE - STG 6 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P10	BLADE - STG 6 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P10	BLADE - STG 6 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P10	BLADE - STG 6 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P10	BLADE - STG 6 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P10	BLADE - STG 6 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K134P10	BLADE - STG 6 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3

Part Number	Part Description	Engine Type	Condition	Quantity
K134P10	BLADE - STG 6 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P10	BLADE - STG 6 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K134P10	BLADE - STG 6 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P10	BLADE - STG 6 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P10	BLADE - STG 6 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P10	BLADE - STG 6 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P10	BLADE - STG 6 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P11	BLADE - STG 6 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K134P11	BLADE - STG 6 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K134P11	BLADE - STG 6 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K134P11	BLADE - STG 6 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K134P11	BLADE - STG 6 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K134P11	BLADE - STG 6 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K134P11	BLADE - STG 6 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P11	BLADE - STG 6 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K134P11	BLADE - STG 6 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P11	BLADE - STG 6 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P11	BLADE - STG 6 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P11	BLADE - STG 6 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P11	BLADE - STG 6 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K134P11	BLADE - STG 6 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K134P11	BLADE - STG 6 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K134P11	BLADE - STG 6 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P11	BLADE - STG 6 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3

Part Number	Part Description	Engine Type	Condition	Quantity
K134P11	BLADE - STG 6 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P11	BLADE - STG 6 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P11	BLADE - STG 6 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P11	BLADE - STG 6 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	14
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	13
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	11
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	29
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	12
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	26
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	17
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	14
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K134P12	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
K134P17	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	14
K134P17	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	12
K134P17	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	41
K134P17	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K134P17	BLADE - STG 6 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K134P18	BLADE - STG 6 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K134P20	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K134P20	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K134P20	BLADE - STG 6 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P09	BLADE - STG 7 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K140P09	BLADE - STG 7 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K140P09	BLADE - STG 7 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
K140P09	BLADE - STG 7 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P09	BLADE - STG 7 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P09	BLADE - STG 7 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K140P09	BLADE - STG 7 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	5

Part Number	Part Description	Engine Type	Condition	Quantity
K140P09	BLADE - STG 7 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P09	BLADE - STG 7 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K140P09	BLADE - STG 7 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P09	BLADE - STG 7 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K140P09	BLADE - STG 7 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P09	BLADE - STG 7 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P09	BLADE - STG 7 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K140P09	BLADE - STG 7 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P09	BLADE - STG 7 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P09	BLADE - STG 7 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K140P09	BLADE - STG 7 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P09	BLADE - STG 7 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
K140P09	BLADE - STG 7 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P09	BLADE - STG 7 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P09	BLADE - STG 7 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P10	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	OH	4
K140P10	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	1
K140P10	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	1
K140P10	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	1
K140P11	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P11	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P11	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P11	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3

Part Number	Part Description	Engine Type	Condition	Quantity
K140P11	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P11	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P12	BLADE - STG 7 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P12	BLADE - STG 7 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P12	BLADE - STG 7 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K140P12	BLADE - STG 7 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P12	BLADE - STG 7 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P12	BLADE - STG 7 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K140P12	BLADE - STG 7 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	19
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	30
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	13
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3

Part Number	Part Description	Engine Type	Condition	Quantity
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	9
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	16

Part Number	Part Description	Engine Type	Condition	Quantity
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	14
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	14
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	21
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	14
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	13
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	12
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	17
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K140P13	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3

Part Number	Part Description	Engine Type	Condition	Quantity
K140P14	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P14	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K140P14	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P14	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P14	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P14	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P14	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P14	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P14	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
K140P14	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K140P14	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P14	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P14	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P14	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P14	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P14	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3

Part Number	Part Description	Engine Type	Condition	Quantity
K140P14	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P14	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P14	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P14	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P14	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P14	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P14	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P14	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P14	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P15	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P15	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P15	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P15	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P15	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P15	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K140P15	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3

Part Number	Part Description	Engine Type	Condition	Quantity
K140P15	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P15	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P15	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P15	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P15	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P15	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K140P15	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P15	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P15	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P15	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P15	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P15	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P15	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P15	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P15	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P15	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3

Part Number	Part Description	Engine Type	Condition	Quantity
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	11
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	17
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	13
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	22
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	13
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	11
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	22
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	19
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	11
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	11
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	8

Part Number	Part Description	Engine Type	Condition	Quantity
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	33
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	11
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	19
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	17
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	12
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	12
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	31
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
K140P16	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K140P21	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	8
K140P21	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	21
K140P21	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	15
K140P21	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K140P21	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K140P21	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
K140P21	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	23
K140P21	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	17
K140P21	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K140P21	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
K140P21	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K140P21	BLADE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	23
K140P22	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P22	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P22	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3

Part Number	Part Description	Engine Type	Condition	Quantity
K140P22	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K140P22	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K140P22	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K140P22	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P22	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P22	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P22	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P22	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P22	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P22	BLADE - STG 7 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K140P23	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
K140P23	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K140P23	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P23	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P23	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P23	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K140P23	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K140P23	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K140P23	BLADE - STG 7 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P24	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
K140P24	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	29
K140P24	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
K140P24	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K140P24	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K140P24	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K140P24	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
K140P24	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K140P24	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K140P24	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K140P24	BLADE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	31
K141P01	BLADE - STG 11 (NARROW)	CF6-50	AR	1
K141P04	BLADE - STG 11 (WIDE)	CF6-50	OH	1
K142P13	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P13	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K142P13	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	2
K142P13	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P15	BLADE - STG 8 (CONVEX)	CF6-80A, CF6-50	AR	1
K142P16	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P16	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P16	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P16	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	2
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	2
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	3
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	2
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	4
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	2
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	2
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	8
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	18
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	16
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	25
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	OH	13
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	22
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	5
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	10
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	OH	16
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	OH	2
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	OH	4
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	19
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	5
K142P17	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO)	OH	3
K142P18	BLADE - STG 8 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P18	BLADE - STG 8 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	3
K142P18	BLADE - STG 8 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	2
K142P18	BLADE - STG 8 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	2
K142P18	BLADE - STG 8 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P18	BLADE - STG 8 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	2
K142P18	BLADE - STG 8 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	3
K142P18	BLADE - STG 8 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	2
K142P18	BLADE - STG 8 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	OH	2
K142P18	BLADE - STG 8 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	OH	2
K142P19	BLADE - STG 8 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	2
K142P19	BLADE - STG 8 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
K142P19	BLADE - STG 8 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	3
K142P19	BLADE - STG 8 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	3
K142P19	BLADE - STG 8 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	3
K142P19	BLADE - STG 8 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P19	BLADE - STG 8 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P19	BLADE - STG 8 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	3
K142P19	BLADE - STG 8 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P19	BLADE - STG 8 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	3
K142P19	BLADE - STG 8 (CONVEX)	CF6-80A, CF6-50 (LMCO)	OH	1
K142P19	BLADE - STG 8 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	3
K142P19	BLADE - STG 8 (CONVEX)	CF6-80A, CF6-50 (LMCO)	OH	2
K142P19	BLADE - STG 8 (CONVEX)	CF6-80A, CF6-50 (LMCO)	OH	2
K142P20	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	6
K142P20	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P20	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	6
K142P20	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P20	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	3
K142P20	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P20	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P20	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P20	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	3
K142P20	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	4
K142P20	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P20	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	6
K142P20	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K142P20	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P20	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K142P20	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO)	OH	3
K142P20	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO)	OH	10
K142P20	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO)	OH	1
K142P20	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO)	OH	4
K142P20	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO)	OH	3
K142P20	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO)	OH	2
K142P20	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO)	OH	2
K142P25	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	6
K142P25	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K142P25	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	10
K142P25	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K142P25	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	14
K142P25	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	15
K142P25	BLADE - STG 8 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	28
K142P26	BLADE - STG 8 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K142P26	BLADE - STG 8 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K142P26	BLADE - STG 8 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3

Part Number	Part Description	Engine Type	Condition	Quantity
K142P26	BLADE - STG 8 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K142P26	BLADE - STG 8 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K142P26	BLADE - STG 8 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K142P27	BLADE - STG 8 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K142P27	BLADE - STG 8 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K142P27	BLADE - STG 8 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K142P28	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
K142P28	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K142P28	BLADE - STG 8 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K143P09	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P09	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	2
K143P09	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	50
K143P09	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	3
K143P09	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	2
K143P09	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	5
K143P09	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	6
K143P09	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	8
K143P09	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	4
K143P09	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	3
K143P09	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K143P09	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	18
K143P09	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	4
K143P09	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	2
K143P09	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	3
K143P09	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P09	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	13
K143P09	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	4
K143P09	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P09	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	22
K143P09	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	8
K143P09	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	16
K143P09	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	6
K143P10	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50	AR	1
K143P10	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50	AR	3
K143P10	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50	AR	1
K143P10	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50	AR	1
K143P10	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50	AR	3
K143P10	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50	AR	3
K143P10	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50	AR	2
K143P10	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50	AR	1
K143P10	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50	AR	3
K143P11	BLADE - STG 9 (CONVEX)	CF6-50 (LMCO)	AR	1
K143P11	BLADE - STG 9 (CONVEX)	CF6-50 (LMCO)	AR	1
K143P11	BLADE - STG 9 (CONVEX)	CF6-50 (LMCO)	OH	1
K143P12	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P12	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P12	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	4
K143P12	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	5
K143P12	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P12	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
K143P12	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	13
K143P12	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	3
K143P12	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	12
K143P12	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	23
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	7
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	34
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	34
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	2
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	5
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	5
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	5
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	3
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	5
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	2
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	3
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	25
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	15
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	40
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	34
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	8
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	OH	5
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	OH	25
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	OH	25
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	OH	25
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	OH	41
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	OH	1
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	49
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	33
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	29
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	26
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	37
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	15
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	OH	19
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	OH	1
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	OH	1
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	OH	5
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	OH	4

Part Number	Part Description	Engine Type	Condition	Quantity
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	19
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	31
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	OH	4
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	OH	1
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	32
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	39
K143P13	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	33
K143P14	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	3
K143P14	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	3
K143P14	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	3
K143P14	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	3
K143P14	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	2
K143P14	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	2
K143P14	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	2
K143P14	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P14	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	3
K143P14	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	3
K143P14	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	3
K143P14	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	2
K143P14	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P14	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	2
K143P14	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	4
K143P14	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	3
K143P14	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	2
K143P14	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	3

Part Number	Part Description	Engine Type	Condition	Quantity
K143P14	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	3
K143P14	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P14	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO)	AR	3
K143P15	BLADE - STG 9 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	3
K143P15	BLADE - STG 9 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	3
K143P15	BLADE - STG 9 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	3
K143P15	BLADE - STG 9 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	3
K143P15	BLADE - STG 9 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	3
K143P15	BLADE - STG 9 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	3
K143P15	BLADE - STG 9 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	3
K143P15	BLADE - STG 9 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P15	BLADE - STG 9 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P15	BLADE - STG 9 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	2
K143P15	BLADE - STG 9 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	2
K143P15	BLADE - STG 9 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	2
K143P15	BLADE - STG 9 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P15	BLADE - STG 9 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	3
K143P15	BLADE - STG 9 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P15	BLADE - STG 9 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P15	BLADE - STG 9 (CONVEX)	CF6-80A, CF6-50 (LMCO)	OH	3
K143P15	BLADE - STG 9 (CONVEX)	CF6-80A, CF6-50 (LMCO)	OH	1
K143P16	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	18
K143P16	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P16	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P16	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	19

Part Number	Part Description	Engine Type	Condition	Quantity
K143P16	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	4
K143P16	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	6
K143P16	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	18
K143P16	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	5
K143P16	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P16	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P16	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P16	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K143P16	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	13
K143P16	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	OH	1
K143P16	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	OH	1
K143P16	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	OH	2
K143P16	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	OH	1
K143P16	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	OH	9
K143P16	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO)	OH	1
K143P21	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K143P21	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	37
K143P21	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K143P21	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K143P21	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	8
K143P21	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2

Part Number	Part Description	Engine Type	Condition	Quantity
K143P21	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K143P21	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
K143P21	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K143P21	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K143P21	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	6
K143P21	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K143P21	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K143P21	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	37
K143P21	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K143P21	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	41
K143P21	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	42
K143P21	BLADE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	41
K143P22	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K143P22	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K143P22	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K143P22	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3

Part Number	Part Description	Engine Type	Condition	Quantity
K143P22	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K143P22	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K143P22	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K143P22	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K143P22	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K143P22	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K143P22	BLADE - STG 9 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K143P23	BLADE - STG 9 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K143P23	BLADE - STG 9 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K143P23	BLADE - STG 9 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K143P23	BLADE - STG 9 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K143P23	BLADE - STG 9 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K143P23	BLADE - STG 9 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K143P23	BLADE - STG 9 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K143P23	BLADE - STG 9 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K143P23	BLADE - STG 9 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3

Part Number	Part Description	Engine Type	Condition	Quantity
K143P24	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K143P24	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K143P24	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K143P24	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K143P24	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
K143P24	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	19
K143P24	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
K143P24	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
K143P24	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
K143P24	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	21
K143P24	BLADE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K145G01	VANE - STG OGV	CF6-50 (LMCO)	AR	3
K145G01	VANE - STG OGV	CF6-50 (LMCO)	AR	1
K145G01	VANE - STG OGV	CF6-50 (LMCO)	AR	3
K145G01	VANE - STG OGV	CF6-50 (LMCO)	AR	1
K145G01	VANE - STG OGV	CF6-50 (LMCO)	AR	5
K145G01	VANE - STG OGV	CF6-50 (LMCO)	AR	3
K145G01	VANE - STG OGV	CF6-50 (LMCO)	AR	4
K145G01	VANE - STG OGV	CF6-50 (LMCO)	AR	1
K145G01	VANE - STG OGV	CF6-50 (LMCO)	AR	4
K145G01	VANE - STG OGV	CF6-50 (LMCO)	AR	1
K145G01	VANE - STG OGV	CF6-50 (LMCO)	AR	1
K145G01	VANE - STG OGV	CF6-50 (LMCO)	AR	1
K145G01	VANE - STG OGV	CF6-50 (LMCO)	AR	1
K145G01	VANE - STG OGV	CF6-50 (LMCO)	AR	2
K145G01	VANE - STG OGV	CF6-50 (LMCO)	AR	1
K145G01	VANE - STG OGV	CF6-50 (LMCO)	AR	2
K145G01	VANE - STG OGV	CF6-50 (LMCO)	AR	6

Part Number	Part Description	Engine Type	Condition	Quantity
K145G01	VANE - STG OGV	CF6-50 (LMCO)	AR	3
K145G01	VANE - STG OGV	CF6-50 (LMCO)	AR	5
K145G01	VANE - STG OGV	CF6-50 (LMCO)	OH	1
K145G01	VANE - STG OGV	CF6-50 (LMCO)	OH	5
K145G01	VANE - STG OGV	CF6-50 (LMCO)	OH	3
K145G01	VANE - STG OGV	CF6-50 (LMCO)	AR	1
K145G01	VANE - STG OGV	CF6-50 (LMCO)	AR	1
K145G01	VANE - STG OGV	CF6-50 (LMCO)	AR	2
K145G03	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K145G03	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K145G03	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K146P09	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	11
K146P09	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K146P09	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	2
K146P11	BLADE - STG 4 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	2
K146P12	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	15
K146P12	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K146P12	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K146P12	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K146P13	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	12
K146P13	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K146P13	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K146P13	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
K146P13	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	20
K146P13	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	15

Part Number	Part Description	Engine Type	Condition	Quantity
K146P13	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	17
K146P13	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K146P13	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	15
K146P13	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K146P13	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	14
K146P14	BLADE - STG 4 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K146P14	BLADE - STG 4 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K146P14	BLADE - STG 4 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K146P14	BLADE - STG 4 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K146P14	BLADE - STG 4 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K146P15	BLADE - STG 4 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K146P15	BLADE - STG 4 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K146P15	BLADE - STG 4 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K146P15	BLADE - STG 4 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K146P16	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K146P16	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5

Part Number	Part Description	Engine Type	Condition	Quantity
K146P16	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K146P16	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	21
K146P16	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K146P16	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K146P16	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
K146P16	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K146P16	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K146P16	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K146P16	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K146P16	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K146P21	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K146P21	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	13
K146P21	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K146P21	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K146P21	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K146P21	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	16

Part Number	Part Description	Engine Type	Condition	Quantity
K146P21	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	13
K146P21	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
K146P21	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K146P21	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K146P21	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	11
K146P21	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	13
K146P21	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	13
K146P21	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	15
K146P21	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
K146P21	BLADE - STG 4 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	14
K146P22	BLADE - STG 4 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K146P22	BLADE - STG 4 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K146P22	BLADE - STG 4 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K146P22	BLADE - STG 4 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K146P22	BLADE - STG 4 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K146P22	BLADE - STG 4 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
K146P22	BLADE - STG 4 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K146P22	BLADE - STG 4 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K146P23	BLADE - STG 4 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K146P23	BLADE - STG 4 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K146P24	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
K146P24	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
K146P24	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	17
K146P24	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
K146P24	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	11
K146P24	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K146P24	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	29
K146P24	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	24
K146P24	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
K146P24	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K146P24	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	25
K146P24	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	18

Part Number	Part Description	Engine Type	Condition	Quantity
K146P24	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	26
K146P24	BLADE - STG 4 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	25
K147P09	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO)	OH	12
K147P09	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO)	OH	1
K147P10	BLADE - STG 5 (CONCAVE)	CF6-80A	AR	2
K147P11	BLADE - STG 5 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	1
K147P11	BLADE - STG 5 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	2
K147P11	BLADE - STG 5 (CONVEX)	CF6-80A, CF6-50 (LMCO)	AR	1
K147P12	BLADE - STG 5 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K147P12	BLADE - STG 5 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
K147P13	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K147P13	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
K147P13	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	17
K147P13	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K147P13	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K147P13	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K147P13	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K147P13	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	18
K147P13	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	4

Part Number	Part Description	Engine Type	Condition	Quantity
K147P13	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K147P13	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K147P13	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	7
K147P14	BLADE - STG 5 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K147P14	BLADE - STG 5 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K147P14	BLADE - STG 5 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K147P14	BLADE - STG 5 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K147P14	BLADE - STG 5 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K147P14	BLADE - STG 5 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K147P14	BLADE - STG 5 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K147P14	BLADE - STG 5 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K147P15	BLADE - STG 5 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K147P15	BLADE - STG 5 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K147P15	BLADE - STG 5 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K147P15	BLADE - STG 5 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K147P15	BLADE - STG 5 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K147P15	BLADE - STG 5 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K147P15	BLADE - STG 5 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K147P16	BLADE - STG 5 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
K147P16	BLADE - STG 5 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
K147P16	BLADE - STG 5 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K147P16	BLADE - STG 5 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	14
K147P16	BLADE - STG 5 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K147P16	BLADE - STG 5 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K147P16	BLADE - STG 5 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
K147P16	BLADE - STG 5 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
K147P16	BLADE - STG 5 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K147P16	BLADE - STG 5 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	13
K147P21	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K147P21	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	13
K147P21	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K147P21	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K147P21	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	9

Part Number	Part Description	Engine Type	Condition	Quantity
K147P21	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
K147P21	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
K147P21	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	13
K147P21	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	15
K147P21	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
K147P21	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K147P21	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K147P21	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
K147P21	BLADE - STG 5 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K147P22	BLADE - STG 5 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K147P22	BLADE - STG 5 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K147P22	BLADE - STG 5 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K147P22	BLADE - STG 5 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K147P22	BLADE - STG 5 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K147P22	BLADE - STG 5 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K147P22	BLADE - STG 5 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
K147P22	BLADE - STG 5 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K147P22	BLADE - STG 5 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K147P22	BLADE - STG 5 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K147P22	BLADE - STG 5 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K147P23	BLADE - STG 5 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K147P23	BLADE - STG 5 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K147P23	BLADE - STG 5 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K147P23	BLADE - STG 5 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K147P23	BLADE - STG 5 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K147P23	BLADE - STG 5 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K147P23	BLADE - STG 5 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K147P23	BLADE - STG 5 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K147P23	BLADE - STG 5 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K147P24	BLADE - STG 5 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	24
K147P24	BLADE - STG 5 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K147P24	BLADE - STG 5 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	11

Part Number	Part Description	Engine Type	Condition	Quantity
K147P24	BLADE - STG 5 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K147P24	BLADE - STG 5 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	11
K147P24	BLADE - STG 5 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	15
K147P24	BLADE - STG 5 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
K147P24	BLADE - STG 5 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	29
K147P24	BLADE - STG 5 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K147P24	BLADE - STG 5 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K147P24	BLADE - STG 5 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	14
K156P01	BLADE - STG 11 (NARROW)	CF6-50 (LMCO)	AR	24
K156P01	BLADE - STG 11 (NARROW)	CF6-50 (LMCO)	AR	13
K156P01	BLADE - STG 11 (NARROW)	CF6-50 (LMCO)	AR	1
K156P01	BLADE - STG 11 (NARROW)	CF6-50 (LMCO)	AR	1
K156P01	BLADE - STG 11 (NARROW)	CF6-50 (LMCO)	AR	1
K156P01	BLADE - STG 11 (NARROW)	CF6-50 (LMCO)	AR	2
K156P01	BLADE - STG 11 (NARROW)	CF6-50 (LMCO)	AR	1
K156P01	BLADE - STG 11 (NARROW)	CF6-50 (LMCO)	AR	35
K156P01	BLADE - STG 11 (NARROW)	CF6-50 (LMCO)	AR	40
K156P01	BLADE - STG 11 (NARROW)	CF6-50 (LMCO)	AR	43
K156P01	BLADE - STG 11 (NARROW)	CF6-50 (LMCO)	AR	19
K156P01	BLADE - STG 11 (NARROW)	CF6-50 (LMCO)	AR	20
K156P01	BLADE - STG 11 (NARROW)	CF6-50 (LMCO)	AR	42
K156P01	BLADE - STG 11 (NARROW)	CF6-50 (LMCO)	AR	36
K156P01	BLADE - STG 11 (NARROW)	CF6-50 (LMCO)	OH	2
K156P02	BLADE - STG 11 (CONCAVE)	CF6-50 (LMCO)	AR	2
K156P02	BLADE - STG 11 (CONCAVE)	CF6-50 (LMCO)	AR	2
K156P02	BLADE - STG 11 (CONCAVE)	CF6-50 (LMCO)	AR	2
K156P02	BLADE - STG 11 (CONCAVE)	CF6-50 (LMCO)	OH	2
K156P02	BLADE - STG 11 (CONCAVE)	CF6-50 (LMCO)	OH	1
K156P03	BLADE - STG 11 (CONVEX)	CF6-50 (LMCO)	AR	2
K156P03	BLADE - STG 11 (CONVEX)	CF6-50 (LMCO)	AR	2
K156P03	BLADE - STG 11 (CONVEX)	CF6-50 (LMCO)	AR	2
K156P03	BLADE - STG 11 (CONVEX)	CF6-50 (LMCO)	AR	1
K156P03	BLADE - STG 11 (CONVEX)	CF6-50 (LMCO)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
K156P03	BLADE - STG 11 (CONVEX)	CF6-50 (LMCO)	AR	2
K156P04	BLADE - STG 11 (WIDE)	CF6-50 (LMCO)	AR	26
K156P04	BLADE - STG 11 (WIDE)	CF6-50 (LMCO)	AR	37
K156P04	BLADE - STG 11 (WIDE)	CF6-50 (LMCO)	AR	28
K156P04	BLADE - STG 11 (WIDE)	CF6-50 (LMCO)	AR	29
K156P05	BLADE - STG 11 (EXTRA WIDE)	CF6-50 (LMCO)	AR	6
K156P05	BLADE - STG 11 (EXTRA WIDE)	CF6-50 (LMCO)	AR	1
K156P07	BLADE - STG 11 (NARROW)	CF6-80A	OH	2
K156P07	BLADE - STG 11 (NARROW)	CF6-80A	AR	38
K156P07	BLADE - STG 11 (NARROW)	CF6-80A	AR	1
K156P07	BLADE - STG 11 (NARROW)	CF6-80A	AR	1
K156P07	BLADE - STG 11 (NARROW)	CF6-80A	AR	7
K156P07	BLADE - STG 11 (NARROW)	CF6-80A	OH	2
K156P07	BLADE - STG 11 (NARROW)	CF6-80A	OH	4
K156P09	BLADE - STG 11 (CONVEX)	CF6-80A	AR	1
K156P10	BLADE - STG 11 (WIDE)	CF6-80A	AR	4
K156P10	BLADE - STG 11 (WIDE)	CF6-80A	AR	30
K156P10	BLADE - STG 11 (WIDE)	CF6-80A	AR	1
K156P10	BLADE - STG 11 (WIDE)	CF6-80A	AR	31
K156P10	BLADE - STG 11 (WIDE)	CF6-80A	AR	2
K156P10	BLADE - STG 11 (WIDE)	CF6-80A	AR	2
K156P10	BLADE - STG 11 (WIDE)	CF6-80A	AR	19
K156P10	BLADE - STG 11 (WIDE)	CF6-80A	AR	27
K156P10	BLADE - STG 11 (WIDE)	CF6-80A	AR	5
K156P16	BLADE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K156P19	BLADE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K156P19	BLADE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K156P21	BLADE - STG 11 (NARROW)	CF6-80A, CF6-50 (LMCO)	OH	35
K156P21	BLADE - STG 11 (NARROW)	CF6-80A, CF6-50 (LMCO)	OH	45
K156P21	BLADE - STG 11 (NARROW)	CF6-80A, CF6-50 (LMCO)	OH	1
K156P22	BLADE - STG 11 (CONCAVE)	CF6-80A	AR	2
K156P22	BLADE - STG 11 (CONCAVE)	CF6-80A	AR	1
K156P22	BLADE - STG 11 (CONCAVE)	CF6-80A	AR	2
K156P22	BLADE - STG 11 (CONCAVE)	CF6-80A	OH	1
K156P23	BLADE - STG 11 (CONVEX)	CF6-80A	AR	1
K156P23	BLADE - STG 11 (CONVEX)	CF6-80A	AR	2
K156P23	BLADE - STG 11 (CONVEX)	CF6-80A	AR	2
K156P23	BLADE - STG 11 (CONVEX)	CF6-80A	AR	2
K156P23	BLADE - STG 11 (CONVEX)	CF6-80A	AR	2
K156P23	BLADE - STG 11 (CONVEX)	CF6-80A	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
K156P24	BLADE - STG 11 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	25
K156P24	BLADE - STG 11 (WIDE)	CF6-80A, CF6-50 (LMCO)	NE	40
K156P24	BLADE - STG 11 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	6
K156P24	BLADE - STG 11 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	27
K156P24	BLADE - STG 11 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	31
K156P24	BLADE - STG 11 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	33
K156P24	BLADE - STG 11 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	10
K156P24	BLADE - STG 11 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	27
K156P24	BLADE - STG 11 (WIDE)	CF6-80A, CF6-50 (LMCO)	NE	34
K157G01	BLADE - HPC RTR STG 1	CF6-80A	AR	1
K157G01	BLADE - HPC RTR STG 1	CF6-80A	AR	2
K157G01	BLADE - HPC RTR STG 1	CF6-80A	AR	1
K157G02	BLADE - HPC STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K157G02	BLADE - HPC STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K157G02	BLADE - HPC STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K159P05	BLADE - HPC RTR STG 1	CF6-80A, CF6-50	AR	2
K182P07	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K182P07	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	15
K182P07	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	11
K182P07	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K182P07	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K182P07	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K182P07	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
K182P07	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P07	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	13

Part Number	Part Description	Engine Type	Condition	Quantity
K182P07	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K182P07	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	21
K182P07	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P07	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P07	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
K182P07	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K182P07	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K182P07	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P07	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
K182P07	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K182P07	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	11
K182P07	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K182P07	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P07	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
K182P07	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	42
K182P07	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
K182P07	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	21
K182P07	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	25
K182P08	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K182P08	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	12
K182P08	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K182P08	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K182P08	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K182P08	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
K182P08	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	5

Part Number	Part Description	Engine Type	Condition	Quantity
K182P08	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
K182P08	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P08	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K182P08	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K182P08	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	15
K182P08	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
K182P08	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	23
K182P08	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	25
K182P08	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	12
K182P09	VANE - STG 11 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P09	VANE - STG 11 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P09	VANE - STG 11 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P09	VANE - STG 11 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P09	VANE - STG 11 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P09	VANE - STG 11 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P10	VANE - STG 11 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P10	VANE - STG 11 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P10	VANE - STG 11 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P10	VANE - STG 11 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P10	VANE - STG 11 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P10	VANE - STG 11 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P10	VANE - STG 11 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P10	VANE - STG 11 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P11	VANE - STG 11	CF6-50 (LMCO)	AR	1
K182P11	VANE - STG 11	CF6-50 (LMCO)	AR	1
K182P11	VANE - STG 11	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K182P11	VANE - STG 11	CF6-50 (LMCO)	AR	1
K182P11	VANE - STG 11	CF6-50 (LMCO)	AR	1
K182P11	VANE - STG 11	CF6-50 (LMCO)	AR	1
K182P11	VANE - STG 11	CF6-50 (LMCO)	AR	1
K182P12	VANE - STG 11	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P12	VANE - STG 11	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P12	VANE - STG 11	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P12	VANE - STG 11	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P12	VANE - STG 11	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P12	VANE - STG 11	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P12	VANE - STG 11	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P19	VANE - STG 11 (WIDE+)	CF6-50 (LMCO)	AR	1
K182P19	VANE - STG 11 (WIDE+)	CF6-50 (LMCO)	AR	3
K182P19	VANE - STG 11 (WIDE+)	CF6-50 (LMCO)	AR	1
K182P19	VANE - STG 11 (WIDE+)	CF6-50 (LMCO)	AR	1
K182P19	VANE - STG 11 (WIDE+)	CF6-50 (LMCO)	AR	4
K182P29	VANE - STG 11 (NARROW)	CF6-80A	AR	2
K182P29	VANE - STG 11 (NARROW)	CF6-80A	AR	16
K182P29	VANE - STG 11 (NARROW)	CF6-80A	AR	6
K182P29	VANE - STG 11 (NARROW)	CF6-80A	AR	9
K182P29	VANE - STG 11 (NARROW)	CF6-80A	AR	1
K182P29	VANE - STG 11 (NARROW)	CF6-80A	OH	1
K182P29	VANE - STG 11 (NARROW)	CF6-80A	AR	11
K182P29	VANE - STG 11 (NARROW)	CF6-80A	OH	7
K182P30	VANE - STG 11 (WIDE)	CF6-80A	AR	1
K182P30	VANE - STG 11 (WIDE)	CF6-80A	AR	6
K182P30	VANE - STG 11 (WIDE)	CF6-80A	AR	5
K182P31	VANE - STG 11 (BORESCOPE)	CF6-80A	AR	1
K182P31	VANE - STG 11 (BORESCOPE)	CF6-80A	AR	1
K182P31	VANE - STG 11 (BORESCOPE)	CF6-80A	AR	1
K182P31	VANE - STG 11 (BORESCOPE)	CF6-80A	AR	1
K182P31	VANE - STG 11 (BORESCOPE)	CF6-80A	AR	1
K182P31	VANE - STG 11 (BORESCOPE)	CF6-80A	AR	1
K182P32	VANE - STG 11 (BORESCOPE)	CF6-80A	AR	1
K182P32	VANE - STG 11 (BORESCOPE)	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K182P32	VANE - STG 11 (BORESCOPE)	CF6-80A	AR	1
K182P32	VANE - STG 11 (BORESCOPE)	CF6-80A	AR	1
K182P33	VANE - STG 11	CF6-80A	AR	1
K182P33	VANE - STG 11	CF6-80A	AR	1
K182P33	VANE - STG 11	CF6-80A	AR	1
K182P33	VANE - STG 11	CF6-80A	AR	1
K182P33	VANE - STG 11	CF6-80A	AR	1
K182P33	VANE - STG 11	CF6-80A	AR	1
K182P34	VANE - STG 11	CF6-80A	AR	1
K182P34	VANE - STG 11	CF6-80A	AR	1
K182P35	VANE - STG 11 (WIDE+)	CF6-80A	AR	1
K182P35	VANE - STG 11 (WIDE+)	CF6-80A	AR	1
K182P35	VANE - STG 11 (WIDE+)	CF6-80A	AR	1
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	31
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	37
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	42
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	17
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	46
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	39
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	49
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	23
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	37
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	43
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	17
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	22
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	28

Part Number	Part Description	Engine Type	Condition	Quantity
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	25
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	13
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	41
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	23
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	45
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	31
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	48
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	11
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	15
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	11
K182P43	VANE - STG 11 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	17
K182P44	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	21
K182P44	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	24
K182P44	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	33
K182P44	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	29
K182P44	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P44	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	19
K182P44	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
K182P44	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	24
K182P44	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
K182P44	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	15

Part Number	Part Description	Engine Type	Condition	Quantity
K182P44	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	33
K182P44	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	19
K182P44	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K182P44	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	15
K182P44	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
K182P44	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
K182P44	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	35
K182P44	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	26
K182P44	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	32
K182P44	VANE - STG 11 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	38
K182P45	VANE - STG 11 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K182P45	VANE - STG 11 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P46	VANE - STG 11 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P46	VANE - STG 11 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P46	VANE - STG 11 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P46	VANE - STG 11 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P46	VANE - STG 11 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P47	VANE - STG 11	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P47	VANE - STG 11	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K182P48	VANE - STG 11	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P48	VANE - STG 11	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P48	VANE - STG 11	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P55	VANE - STG 11 (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K182P56	VANE - STG 11 (NARROW)	CF6-80A	AR	17
K182P56	VANE - STG 11 (NARROW)	CF6-80A	AR	1
K182P56	VANE - STG 11 (NARROW)	CF6-80A	AR	16

Part Number	Part Description	Engine Type	Condition	Quantity
K182P56	VANE - STG 11 (NARROW)	CF6-80A	OH	6
K182P56	VANE - STG 11 (NARROW)	CF6-80A	AR	43
K182P56	VANE - STG 11 (NARROW)	CF6-80A	AR	6
K182P56	VANE - STG 11 (NARROW)	CF6-80A	AR	51
K182P56	VANE - STG 11 (NARROW)	CF6-80A	AR	10
K182P56	VANE - STG 11 (NARROW)	CF6-80A	OH	3
K182P56	VANE - STG 11 (NARROW)	CF6-80A	AR	18
K182P57	VANE - STG 11 (WIDE)	CF6-80A	AR	10
K182P57	VANE - STG 11 (WIDE)	CF6-80A	AR	7
K182P57	VANE - STG 11 (WIDE)	CF6-80A	AR	6
K182P57	VANE - STG 11 (WIDE)	CF6-80A	AR	2
K182P57	VANE - STG 11 (WIDE)	CF6-80A	OH	7
K182P57	VANE - STG 11 (WIDE)	CF6-80A	AR	1
K182P57	VANE - STG 11 (WIDE)	CF6-80A	OH	3
K182P58	VANE - STG 11 (BOREScope)	CF6-80A	AR	1
K182P58	VANE - STG 11 (BOREScope)	CF6-80A	AR	1
K182P58	VANE - STG 11 (BOREScope)	CF6-80A	AR	1
K182P58	VANE - STG 11 (BOREScope)	CF6-80A	AR	1
K182P58	VANE - STG 11 (BOREScope)	CF6-80A	AR	1
K182P58	VANE - STG 11 (BOREScope)	CF6-80A	AR	1
K182P58	VANE - STG 11 (BOREScope)	CF6-80A	AR	1
K182P58	VANE - STG 11 (BOREScope)	CF6-80A	AR	1
K182P59	VANE - STG 11 (BOREScope)	CF6-80A	AR	1
K182P59	VANE - STG 11 (BOREScope)	CF6-80A	AR	1
K182P59	VANE - STG 11 (BOREScope)	CF6-80A	AR	1
K182P59	VANE - STG 11 (BOREScope)	CF6-80A	AR	1
K182P59	VANE - STG 11 (BOREScope)	CF6-80A	AR	1
K182P59	VANE - STG 11 (BOREScope)	CF6-80A	AR	1
K182P59	VANE - STG 11 (BOREScope)	CF6-80A	AR	1
K182P59	VANE - STG 11 (BOREScope)	CF6-80A	AR	1
K182P59	VANE - STG 11 (BOREScope)	CF6-80A	AR	1
K182P60	VANE - STG 11	CF6-80A	NE	1
K182P60	VANE - STG 11	CF6-80A	AR	1
K182P60	VANE - STG 11	CF6-80A	AR	1
K182P60	VANE - STG 11	CF6-80A	AR	1
K182P60	VANE - STG 11	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K182P60	VANE - STG 11	CF6-80A	AR	1
K182P60	VANE - STG 11	CF6-80A	AR	1
K182P60	VANE - STG 11	CF6-80A	AR	1
K182P61	VANE - STG 11	CF6-80A	AR	1
K182P61	VANE - STG 11	CF6-80A	AR	1
K182P61	VANE - STG 11	CF6-80A	AR	1
K182P61	VANE - STG 11	CF6-80A	AR	1
K182P61	VANE - STG 11	CF6-80A	AR	1
K182P61	VANE - STG 11	CF6-80A	AR	1
K182P61	VANE - STG 11	CF6-80A	AR	1
K182P61	VANE - STG 11	CF6-80A	AR	1
K182P61	VANE - STG 11	CF6-80A	AR	1
K182P61	VANE - STG 11	CF6-80A	AR	1
K182P61	VANE - STG 11	CF6-80A	AR	1
K182P61	VANE - STG 11	CF6-80A	AR	1
K182P61	VANE - STG 11	CF6-80A	AR	1
K182P62	VANE - STG 11 (WIDE+)	CF6-80A	AR	1
K182P62	VANE - STG 11 (WIDE+)	CF6-80A	AR	6
K182P62	VANE - STG 11 (WIDE+)	CF6-80A	AR	1
K182P62	VANE - STG 11 (WIDE+)	CF6-80A	AR	1
K182P62	VANE - STG 11 (WIDE+)	CF6-80A	AR	2
K182P62	VANE - STG 11 (WIDE+)	CF6-80A	AR	2
K182P62	VANE - STG 11 (WIDE+)	CF6-80A	AR	1
K182P77	VANE - STG 11 (WIDE)	CF6-80C2	OH	2
K182P78	VANE - STG 11 (WIDE+)	CF6-80C2	OH	1
K182P81	VANE - STG 11 (NARROW)	CF6-80C2	OH	1
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	6
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	32
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	36
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	36

Part Number	Part Description	Engine Type	Condition	Quantity
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	35
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	32
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	32
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	36
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	36
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	36
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	35
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	33
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	26
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	17

Part Number	Part Description	Engine Type	Condition	Quantity
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	35
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	22
K186P03	VANE - STG 1	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	29

Part Number	Part Description	Engine Type	Condition	Quantity
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	19
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	14
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	25
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	35
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	22
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	17
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	18

Part Number	Part Description	Engine Type	Condition	Quantity
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	26
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	29

Part Number	Part Description	Engine Type	Condition	Quantity
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	36
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	14
K186P04	VANE - STG 1	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K200P13	VANE - STG 12 (WIDE)	CF6-80C2	OH	2
K212P03	BLADE - STG 2 HPC	CF6-80C2	AR	5
K215P02	HPC ROTOR BLADE STG 2	CF6-80C2	NE	4
K215P02	HPC ROTOR BLADE STG 2	CF6-80C2	OH	2
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	47
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	44
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	47
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	47
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	58
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	53
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	48

Part Number	Part Description	Engine Type	Condition	Quantity
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	50
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	43
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	50
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	58
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	51
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	66
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	53
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	53
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	39
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	53
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	45
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	39
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	52
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	57
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	6
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	60
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	63

Part Number	Part Description	Engine Type	Condition	Quantity
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	39
K284P07	VANE - STG 12 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	27
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	35
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	17
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	21
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	17
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	17
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	17
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	11
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	23
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	4

Part Number	Part Description	Engine Type	Condition	Quantity
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	23
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	37
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	22
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	19
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	6
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K284P08	VANE - STG 12 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	37
K284P09	VANE - STG 12 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P09	VANE - STG 12 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P09	VANE - STG 12 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P09	VANE - STG 12 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P09	VANE - STG 12 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P09	VANE - STG 12 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P09	VANE - STG 12 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P09	VANE - STG 12 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P09	VANE - STG 12 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P09	VANE - STG 12 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P09	VANE - STG 12 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P09	VANE - STG 12 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P09	VANE - STG 12 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P09	VANE - STG 12 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K284P09	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P09	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P09	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P09	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P09	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P09	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P09	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P09	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P09	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P09	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P09	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P09	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P09	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P10	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P10	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P10	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P10	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P10	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P10	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P10	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P10	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P10	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P10	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P10	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P10	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P10	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P10	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K284P10	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P10	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P10	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P10	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P10	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P10	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P10	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P10	VANE - STG 12 (BORESCOPE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P11	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P12	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P12	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P12	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P12	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P12	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P12	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P12	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P12	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P12	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P12	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P12	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P12	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P12	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P12	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P12	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P12	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P12	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P12	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P12	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K284P12	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P12	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P12	VANE - STG 12	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P13	VANE - STG 12 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K284P13	VANE - STG 12 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K284P13	VANE - STG 12 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K284P13	VANE - STG 12 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P13	VANE - STG 12 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K284P13	VANE - STG 12 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K284P13	VANE - STG 12 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P13	VANE - STG 12 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P13	VANE - STG 12 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P13	VANE - STG 12 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P13	VANE - STG 12 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K284P13	VANE - STG 12 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K284P13	VANE - STG 12 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K284P13	VANE - STG 12 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3

Part Number	Part Description	Engine Type	Condition	Quantity
K284P13	VANE - STG 12 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K284P13	VANE - STG 12 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K284P13	VANE - STG 12 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K284P13	VANE - STG 12 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K284P13	VANE - STG 12 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K284P13	VANE - STG 12 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K284P13	VANE - STG 12 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K284P13	VANE - STG 12 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K284P13	VANE - STG 12 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K284P13	VANE - STG 12 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K284P13	VANE - STG 12 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K284P13	VANE - STG 12 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
K284P14	VANE - STG 12 (NARROW)	CF6-80A	AR	5
K284P14	VANE - STG 12 (NARROW)	CF6-80A	AR	7
K284P14	VANE - STG 12 (NARROW)	CF6-80A	AR	8
K284P14	VANE - STG 12 (NARROW)	CF6-80A	AR	65
K284P14	VANE - STG 12 (NARROW)	CF6-80A	AR	47
K284P14	VANE - STG 12 (NARROW)	CF6-80A	AR	54
K284P14	VANE - STG 12 (NARROW)	CF6-80A	AR	54
K284P14	VANE - STG 12 (NARROW)	CF6-80A	AR	16
K284P14	VANE - STG 12 (NARROW)	CF6-80A	OH	12
K284P14	VANE - STG 12 (NARROW)	CF6-80A	OH	3
K284P14	VANE - STG 12 (NARROW)	CF6-80A	AR	1
K284P14	VANE - STG 12 (NARROW)	CF6-80A	OH	5
K284P14	VANE - STG 12 (NARROW)	CF6-80A	OH	35

Part Number	Part Description	Engine Type	Condition	Quantity
K284P14	VANE - STG 12 (NARROW)	CF6-80A	OH	2
K284P14	VANE - STG 12 (NARROW)	CF6-80A	OH	1
K284P14	VANE - STG 12 (NARROW)	CF6-80A	OH	8
K284P15	VANE - STG 12 (WIDE)	CF6-80A	OH	1
K284P15	VANE - STG 12 (WIDE)	CF6-80A	OH	20
K284P15	VANE - STG 12 (WIDE)	CF6-80A	OH	3
K284P15	VANE - STG 12 (WIDE)	CF6-80A	OH	2
K284P15	VANE - STG 12 (WIDE)	CF6-80A	OH	2
K284P15	VANE - STG 12 (WIDE)	CF6-80A	OH	22
K284P15	VANE - STG 12 (WIDE)	CF6-80A	OH	3
K284P16	VANE - STG 12 (BORESCOPE)	CF6-80A	AR	1
K284P16	VANE - STG 12 (BORESCOPE)	CF6-80A	AR	1
K284P17	VANE - STG 12 (BORESCOPE)	CF6-80A	AR	1
K284P17	VANE - STG 12 (BORESCOPE)	CF6-80A	AR	1
K284P17	VANE - STG 12 (BORESCOPE)	CF6-80A	AR	1
K284P17	VANE - STG 12 (BORESCOPE)	CF6-80A	AR	1
K284P17	VANE - STG 12 (BORESCOPE)	CF6-80A	OH	1
K284P21	VANE - STG 12	CF6-80A	AR	1
K284P21	VANE - STG 12	CF6-80A	AR	1
K284P21	VANE - STG 12	CF6-80A	AR	1
K284P21	VANE - STG 12	CF6-80A	AR	1
K284P21	VANE - STG 12	CF6-80A	AR	1
K284P21	VANE - STG 12	CF6-80A	OH	1
K284P22	VANE - STG 12	CF6-80A	AR	1
K284P22	VANE - STG 12	CF6-80A	AR	1
K284P22	VANE - STG 12	CF6-80A	AR	1
K285P02	BLADE - HPC RTR STG 2	CF6-80A, CF6-50 (LMCO)	AR	2
K285P02	BLADE - HPC RTR STG 2	CF6-80A, CF6-50 (LMCO)	AR	9
K285P03	BLADE - HPC RTR STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	11
K285P03	BLADE - HPC RTR STG 2	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	40

Part Number	Part Description	Engine Type	Condition	Quantity
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	12
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	33
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	31
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	17
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	12
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	40
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	32
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	27
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	40
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	39
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	39
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	40

Part Number	Part Description	Engine Type	Condition	Quantity
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
K286P03	VANE - STG 2	CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	37
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	22
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	11
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	12

Part Number	Part Description	Engine Type	Condition	Quantity
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	39
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	40
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	40

Part Number	Part Description	Engine Type	Condition	Quantity
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	39
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	24
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	32
K286P04	VANE - STG 2	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K289P07	HPC ROTOR BLADE STG 12 [NARROW]	CF6-80C2	OH	2
K314G04	VANE - STG 13 (END)	CF6-80C2	OH	1
K314G06	VANE - STG 13 (END)	CF6-80C2	AR	5
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	12
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	7

Part Number	Part Description	Engine Type	Condition	Quantity
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	6
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	15
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	11
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	15
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	12
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	13
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	16

Part Number	Part Description	Engine Type	Condition	Quantity
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	12
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	14
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K319P05	BLADE - STG 3 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K319P06	BLADE - STG 3 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P06	BLADE - STG 3 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P06	BLADE - STG 3 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P06	BLADE - STG 3 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P06	BLADE - STG 3 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P06	BLADE - STG 3 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
K319P06	BLADE - STG 3 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P06	BLADE - STG 3 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P06	BLADE - STG 3 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P06	BLADE - STG 3 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P06	BLADE - STG 3 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P06	BLADE - STG 3 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P06	BLADE - STG 3 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P06	BLADE - STG 3 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P06	BLADE - STG 3 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P06	BLADE - STG 3 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P06	BLADE - STG 3 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P06	BLADE - STG 3 (CONCAVE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P07	BLADE - STG 3 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P07	BLADE - STG 3 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P07	BLADE - STG 3 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P07	BLADE - STG 3 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P07	BLADE - STG 3 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
K319P07	BLADE - STG 3 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K319P07	BLADE - STG 3 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P07	BLADE - STG 3 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K319P07	BLADE - STG 3 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P07	BLADE - STG 3 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P07	BLADE - STG 3 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K319P07	BLADE - STG 3 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P07	BLADE - STG 3 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P07	BLADE - STG 3 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P07	BLADE - STG 3 (CONVEX)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K319P08	BLADE - STG 3 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K319P08	BLADE - STG 3 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K319P08	BLADE - STG 3 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
K319P08	BLADE - STG 3 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K319P08	BLADE - STG 3 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	14
K319P08	BLADE - STG 3 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	27

Part Number	Part Description	Engine Type	Condition	Quantity
K319P08	BLADE - STG 3 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	22
K319P08	BLADE - STG 3 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K319P08	BLADE - STG 3 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	25
K319P08	BLADE - STG 3 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	26
K319P08	BLADE - STG 3 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	32
K319P08	BLADE - STG 3 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
K319P08	BLADE - STG 3 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K319P08	BLADE - STG 3 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	24
K319P08	BLADE - STG 3 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	25
K319P08	BLADE - STG 3 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	7
K319P08	BLADE - STG 3 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	17
K319P08	BLADE - STG 3 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	18
K344P02	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K344P02	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K344P02	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
K344P02	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K344P02	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K344P02	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
K344P02	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	9

Part Number	Part Description	Engine Type	Condition	Quantity
K344P02	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	7
K344P02	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
K344P02	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K344P02	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	19
K344P02	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	46
K344P02	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	46
K344P02	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	29
K344P02	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	29
K344P02	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K344P02	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	37
K344P02	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
K344P02	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K344P02	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	OH	30
K344P02	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	24
K344P02	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	33
K344P02	VANE - STG 3	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	13
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	46
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	23
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	46
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	46
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	30
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	43
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	13
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	27
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	19
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	17
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	12
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	46

Part Number	Part Description	Engine Type	Condition	Quantity
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	27
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	22
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	13
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	46
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	45
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	13
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	33
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K344P03	VANE - STG 3	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	28
K344P04	VANE - STG 3	CF6-80C2	OH	14
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	6
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	50
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	46
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	61
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	5

Part Number	Part Description	Engine Type	Condition	Quantity
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	46
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	53
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	33
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	30
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	13
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	7
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	21
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	9
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	49
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	22
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	22
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	54
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	35
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	51
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	43
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	71
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	76

Part Number	Part Description	Engine Type	Condition	Quantity
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K363P11	VANE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
K363P12	VANE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	29
K363P12	VANE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K363P12	VANE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	24
K363P12	VANE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
K363P12	VANE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P12	VANE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K363P12	VANE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	13
K363P12	VANE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P12	VANE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	22
K363P12	VANE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	35
K363P12	VANE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P12	VANE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	27
K363P12	VANE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	22
K363P12	VANE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	41
K363P12	VANE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	39
K363P12	VANE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K363P12	VANE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	25
K363P12	VANE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	26
K363P12	VANE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K363P12	VANE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38
K363P12	VANE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	38

Part Number	Part Description	Engine Type	Condition	Quantity
K363P12	VANE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
K363P12	VANE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K363P12	VANE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
K363P12	VANE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K363P13	VANE - STG 13 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P13	VANE - STG 13 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P13	VANE - STG 13 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P13	VANE - STG 13 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P13	VANE - STG 13 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P13	VANE - STG 13 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P13	VANE - STG 13 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P13	VANE - STG 13 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P13	VANE - STG 13 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P13	VANE - STG 13 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P13	VANE - STG 13 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P13	VANE - STG 13 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P13	VANE - STG 13 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P13	VANE - STG 13 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P13	VANE - STG 13 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P13	VANE - STG 13 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P14	VANE - STG 13 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P14	VANE - STG 13 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P14	VANE - STG 13 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K363P14	VANE - STG 13 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P14	VANE - STG 13 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P14	VANE - STG 13 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P14	VANE - STG 13 (BOREScope)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K363P16	VANE - STG 13	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P16	VANE - STG 13	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P16	VANE - STG 13	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P16	VANE - STG 13	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P16	VANE - STG 13	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P16	VANE - STG 13	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P16	VANE - STG 13	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P16	VANE - STG 13	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P16	VANE - STG 13	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P21	VANE - STG 13 (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K363P21	VANE - STG 13 (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K363P21	VANE - STG 13 (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P21	VANE - STG 13 (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K363P21	VANE - STG 13 (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K363P21	VANE - STG 13 (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K363P21	VANE - STG 13 (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
K363P31	VANE - STG 13 (NARROW)	CF6-80A	AR	31
K363P31	VANE - STG 13 (NARROW)	CF6-80A	AR	40
K363P31	VANE - STG 13 (NARROW)	CF6-80A	AR	49
K363P31	VANE - STG 13 (NARROW)	CF6-80A	OH	37
K363P31	VANE - STG 13 (NARROW)	CF6-80A	OH	48
K363P31	VANE - STG 13 (NARROW)	CF6-80A	OH	2
K363P32	VANE - STG 13 (WIDE)	CF6-80A	AR	1
K363P32	VANE - STG 13 (WIDE)	CF6-80A	OH	27
K363P32	VANE - STG 13 (WIDE)	CF6-80A	AR	16
K363P32	VANE - STG 13 (WIDE)	CF6-80A	AR	26
K363P32	VANE - STG 13 (WIDE)	CF6-80A	AR	31
K363P32	VANE - STG 13 (WIDE)	CF6-80A	AR	32
K363P32	VANE - STG 13 (WIDE)	CF6-80A	AR	32
K363P32	VANE - STG 13 (WIDE)	CF6-80A	AR	32
K363P32	VANE - STG 13 (WIDE)	CF6-80A	AR	32
K363P32	VANE - STG 13 (WIDE)	CF6-80A	AR	33
K363P32	VANE - STG 13 (WIDE)	CF6-80A	OH	2

Part Number	Part Description	Engine Type	Condition	Quantity
K363P32	VANE - STG 13 (WIDE)	CF6-80A	OH	3
K363P32	VANE - STG 13 (WIDE)	CF6-80A	OH	24
K363P32	VANE - STG 13 (WIDE)	CF6-80A	OH	8
K363P33	VANE - STG 13 (BORESCOPE)	CF6-80A	AR	1
K363P33	VANE - STG 13 (BORESCOPE)	CF6-80A	AR	1
K363P33	VANE - STG 13 (BORESCOPE)	CF6-80A	AR	1
K363P33	VANE - STG 13 (BORESCOPE)	CF6-80A	AR	1
K363P33	VANE - STG 13 (BORESCOPE)	CF6-80A	AR	1
K363P33	VANE - STG 13 (BORESCOPE)	CF6-80A	AR	1
K363P33	VANE - STG 13 (BORESCOPE)	CF6-80A	AR	1
K363P33	VANE - STG 13 (BORESCOPE)	CF6-80A	AR	1
K363P33	VANE - STG 13 (BORESCOPE)	CF6-80A	AR	1
K363P33	VANE - STG 13 (BORESCOPE)	CF6-80A	AR	1
K363P33	VANE - STG 13 (BORESCOPE)	CF6-80A	AR	1
K363P33	VANE - STG 13 (BORESCOPE)	CF6-80A	AR	1
K363P33	VANE - STG 13 (BORESCOPE)	CF6-80A	AR	1
K363P33	VANE - STG 13 (BORESCOPE)	CF6-80A	OH	1
K363P34	VANE - STG 13 (BORESCOPE)	CF6-80A	AR	1
K363P34	VANE - STG 13 (BORESCOPE)	CF6-80A	AR	1
K363P34	VANE - STG 13 (BORESCOPE)	CF6-80A	AR	1
K363P34	VANE - STG 13 (BORESCOPE)	CF6-80A	AR	1
K363P34	VANE - STG 13 (BORESCOPE)	CF6-80A	AR	1
K363P34	VANE - STG 13 (BORESCOPE)	CF6-80A	AR	1
K363P34	VANE - STG 13 (BORESCOPE)	CF6-80A	AR	1
K363P34	VANE - STG 13 (BORESCOPE)	CF6-80A	AR	1
K363P34	VANE - STG 13 (BORESCOPE)	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K363P34	VANE - STG 13 (BORESCOPE)	CF6-80A	AR	1
K363P34	VANE - STG 13 (BORESCOPE)	CF6-80A	AR	1
K363P34	VANE - STG 13 (BORESCOPE)	CF6-80A	AR	1
K363P34	VANE - STG 13 (BORESCOPE)	CF6-80A	AR	1
K363P34	VANE - STG 13 (BORESCOPE)	CF6-80A	OH	1
K363P35	VANE - STG 13	CF6-80A	AR	1
K363P35	VANE - STG 13	CF6-80A	AR	1
K363P35	VANE - STG 13	CF6-80A	AR	1
K363P35	VANE - STG 13	CF6-80A	OH	1
K363P36	VANE - STG 13	CF6-80A	AR	1
K363P36	VANE - STG 13	CF6-80A	AR	1
K363P36	VANE - STG 13	CF6-80A	AR	1
K363P36	VANE - STG 13	CF6-80A	AR	1
K363P36	VANE - STG 13	CF6-80A	AR	1
K363P36	VANE - STG 13	CF6-80A	AR	1
K363P36	VANE - STG 13	CF6-80A	AR	1
K363P36	VANE - STG 13	CF6-80A	AR	1
K363P36	VANE - STG 13	CF6-80A	AR	1
K363P36	VANE - STG 13	CF6-80A	AR	1
K363P37	VANE - STG 13 (WIDE+)	CF6-80A	AR	2
K363P37	VANE - STG 13 (WIDE+)	CF6-80A	AR	5
K363P37	VANE - STG 13 (WIDE+)	CF6-80A	AR	2
K363P37	VANE - STG 13 (WIDE+)	CF6-80A	AR	3
K363P37	VANE - STG 13 (WIDE+)	CF6-80A	AR	3
K370P01	BLADE - STG 13 (NARROW)	CF6-50 (LMCO)	AR	47
K370P01	BLADE - STG 13 (NARROW)	CF6-50 (LMCO)	AR	44
K370P01	BLADE - STG 13 (NARROW)	CF6-50 (LMCO)	AR	15
K370P01	BLADE - STG 13 (NARROW)	CF6-50 (LMCO)	AR	15
K370P01	BLADE - STG 13 (NARROW)	CF6-50 (LMCO)	AR	8
K370P01	BLADE - STG 13 (NARROW)	CF6-50 (LMCO)	AR	1
K370P01	BLADE - STG 13 (NARROW)	CF6-50 (LMCO)	AR	41
K370P01	BLADE - STG 13 (NARROW)	CF6-50 (LMCO)	AR	1
K370P01	BLADE - STG 13 (NARROW)	CF6-50 (LMCO)	AR	45
K370P01	BLADE - STG 13 (NARROW)	CF6-50 (LMCO)	AR	1
K370P01	BLADE - STG 13 (NARROW)	CF6-50 (LMCO)	AR	38
K370P01	BLADE - STG 13 (NARROW)	CF6-50 (LMCO)	AR	46
K370P01	BLADE - STG 13 (NARROW)	CF6-50 (LMCO)	AR	37
K370P01	BLADE - STG 13 (NARROW)	CF6-50 (LMCO)	AR	42
K370P01	BLADE - STG 13 (NARROW)	CF6-50 (LMCO)	AR	41
K370P01	BLADE - STG 13 (NARROW)	CF6-50 (LMCO)	AR	43
K370P01	BLADE - STG 13 (NARROW)	CF6-50 (LMCO)	AR	30
K370P01	BLADE - STG 13 (NARROW)	CF6-50 (LMCO)	OH	2
K370P03	BLADE - STG 13 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
K370P03	BLADE - STG 13 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K370P03	BLADE - STG 13 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K370P03	BLADE - STG 13 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K370P03	BLADE - STG 13 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K370P03	BLADE - STG 13 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K370P03	BLADE - STG 13 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K370P03	BLADE - STG 13 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K370P03	BLADE - STG 13 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K370P04	BLADE - STG 13 (WIDE)	CF6-50 (LMCO)	AR	25
K370P04	BLADE - STG 13 (WIDE)	CF6-50 (LMCO)	OH	22
K370P04	BLADE - STG 13 (WIDE)	CF6-50 (LMCO)	AR	28
K370P04	BLADE - STG 13 (WIDE)	CF6-50 (LMCO)	OH	5
K370P04	BLADE - STG 13 (WIDE)	CF6-50 (LMCO)	AR	27
K370P04	BLADE - STG 13 (WIDE)	CF6-50 (LMCO)	AR	30
K370P04	BLADE - STG 13 (WIDE)	CF6-50 (LMCO)	AR	28
K370P04	BLADE - STG 13 (WIDE)	CF6-50 (LMCO)	AR	28
K370P04	BLADE - STG 13 (WIDE)	CF6-50 (LMCO)	OH	3
K370P05	BLADE - STG 13 (CONCAVE)	CF6-50 (LMCO)	AR	2
K370P05	BLADE - STG 13 (CONCAVE)	CF6-50 (LMCO)	AR	2
K370P05	BLADE - STG 13 (CONCAVE)	CF6-50 (LMCO)	AR	2
K370P05	BLADE - STG 13 (CONCAVE)	CF6-50 (LMCO)	AR	1
K370P05	BLADE - STG 13 (CONCAVE)	CF6-50 (LMCO)	AR	2
K370P05	BLADE - STG 13 (CONCAVE)	CF6-50 (LMCO)	AR	2
K370P05	BLADE - STG 13 (CONCAVE)	CF6-50 (LMCO)	AR	2
K370P05	BLADE - STG 13 (CONCAVE)	CF6-50 (LMCO)	AR	2
K370P05	BLADE - STG 13 (CONCAVE)	CF6-50 (LMCO)	AR	2
K370P05	BLADE - STG 13 (CONCAVE)	CF6-50 (LMCO)	OH	1
K370P06	BLADE - STG 13 (EXTRA WIDE)	CF6-50 (LMCO)	OH	1
K370P15	BLADE - STG 13 (NARROW)	CF6-80A	OH	2
K370P15	BLADE - STG 13 (NARROW)	CF6-80A	OH	2
K370P15	BLADE - STG 13 (NARROW)	CF6-80A	OH	2
K370P15	BLADE - STG 13 (NARROW)	CF6-80A	OH	4
K370P16	BLADE - STG 13 (CONCAVE)	CF6-80A	AR	2
K370P16	BLADE - STG 13 (CONCAVE)	CF6-80A	AR	1
K370P16	BLADE - STG 13 (CONCAVE)	CF6-80A	AR	1
K370P16	BLADE - STG 13 (CONCAVE)	CF6-80A	AR	2
K370P17	BLADE - STG 13 (CONVEX)	CF6-80A	AR	2
K370P18	BLADE - STG 13 (WIDE)	CF6-80A	AR	16
K370P18	BLADE - STG 13 (WIDE)	CF6-80A	OH	14

Part Number	Part Description	Engine Type	Condition	Quantity
K370P18	BLADE - STG 13 (WIDE)	CF6-80A	OH	36
K370P18	BLADE - STG 13 (WIDE)	CF6-80A	OH	2
K370P18	BLADE - STG 13 (WIDE)	CF6-80A	AR	5
K370P18	BLADE - STG 13 (WIDE)	CF6-80A	OH	2
K370P18	BLADE - STG 13 (WIDE)	CF6-80A	OH	2
K370P29	BLADE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K370P29	BLADE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K370P29	BLADE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
K370P29	BLADE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K370P29	BLADE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
K370P29	BLADE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	32
K370P29	BLADE - STG 13 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K370P30	BLADE - STG 13 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K370P30	BLADE - STG 13 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K370P31	BLADE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K370P31	BLADE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
K370P31	BLADE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K370P31	BLADE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K370P31	BLADE - STG 13 (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K370P32	BLADE - STG 13 (CONCAVE)	CF6-50 (LMCO)	OH	1
K370P34	BLADE - STG 13 (NARROW)	CF6-80A	AR	26
K370P34	BLADE - STG 13 (NARROW)	CF6-80A	AR	11
K370P34	BLADE - STG 13 (NARROW)	CF6-80A	OH	49
K370P34	BLADE - STG 13 (NARROW)	CF6-80A	OH	2
K370P34	BLADE - STG 13 (NARROW)	CF6-80A	OH	4
K370P34	BLADE - STG 13 (NARROW)	CF6-80A	OH	4
K370P35	BLADE - STG 13 (CONCAVE)	CF6-80A	AR	2
K370P35	BLADE - STG 13 (CONCAVE)	CF6-80A	AR	2
K370P35	BLADE - STG 13 (CONCAVE)	CF6-80A	AR	2
K370P35	BLADE - STG 13 (CONCAVE)	CF6-80A	AR	2
K370P35	BLADE - STG 13 (CONCAVE)	CF6-80A	AR	2
K370P35	BLADE - STG 13 (CONCAVE)	CF6-80A	AR	1
K370P35	BLADE - STG 13 (CONCAVE)	CF6-80A	AR	1
K370P35	BLADE - STG 13 (CONCAVE)	CF6-80A	AR	2
K370P35	BLADE - STG 13 (CONCAVE)	CF6-80A	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
K370P35	BLADE - STG 13 (CONCAVE)	CF6-80A	AR	2
K370P36	BLADE - STG 13 (CONVEX)	CF6-80A	AR	2
K370P37	BLADE - STG 13 (WIDE)	CF6-80A	AR	9
K370P37	BLADE - STG 13 (WIDE)	CF6-80A	AR	29
K370P37	BLADE - STG 13 (WIDE)	CF6-80A	OH	1
K370P37	BLADE - STG 13 (WIDE)	CF6-80A	AR	17
K406G01	VANE - OUTLET GUIDE	CF6-80A	AR	4
K406G01	VANE - OUTLET GUIDE	CF6-80A	AR	4
K406G01	VANE - OUTLET GUIDE	CF6-80A	AR	4
K406G01	VANE - OUTLET GUIDE	CF6-80A	AR	4
K406G01	VANE - OUTLET GUIDE	CF6-80A	AR	4
K406G01	VANE - OUTLET GUIDE	CF6-80A	AR	4
K406G01	VANE - OUTLET GUIDE	CF6-80A	OH	1
K406G02	VANE - OUTLET GUIDE	CF6-80C2	AR	4
K406G02	VANE - OUTLET GUIDE	CF6-80C2	AR	1
K406G03	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K406G03	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K406G03	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K406G03	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K406G03	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K406G04	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K406G04	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K406G04	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K406G04	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K406G04	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K406G04	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K406G04	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K406G04	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K406G04	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K406G04	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K406G04	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K406G04	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K406G05	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K406G05	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
K406G05	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K406G05	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K406G05	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K406G05	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K406G05	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K406G05	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K406G05	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K406G05	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K406G05	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K406G05	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K406G05	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K406G05	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K406G05	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K406G05	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K406G05	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K406G05	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K406G05	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K406G05	VANE - STG OGV	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K433P13	BLADE - STG 14 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	55
K433P13	BLADE - STG 14 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K433P13	BLADE - STG 14 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
K433P13	BLADE - STG 14 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	54
K433P13	BLADE - STG 14 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	57

Part Number	Part Description	Engine Type	Condition	Quantity
K433P13	BLADE - STG 14 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	55
K433P13	BLADE - STG 14 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	8
K433P13	BLADE - STG 14 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	53
K433P13	BLADE - STG 14 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K433P13	BLADE - STG 14 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	55
K433P13	BLADE - STG 14 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	57
K433P13	BLADE - STG 14 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	55
K433P13	BLADE - STG 14 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	43
K433P13	BLADE - STG 14 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	53
K433P13	BLADE - STG 14 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	51
K433P13	BLADE - STG 14 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K433P13	BLADE - STG 14 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	37
K433P15	BLADE - STG 14 (CONVEX)	CF6-50 (LMCO)	AR	2
K433P15	BLADE - STG 14 (CONVEX)	CF6-50 (LMCO)	AR	2
K433P15	BLADE - STG 14 (CONVEX)	CF6-50 (LMCO)	AR	2
K433P15	BLADE - STG 14 (CONVEX)	CF6-50 (LMCO)	AR	2
K433P15	BLADE - STG 14 (CONVEX)	CF6-50 (LMCO)	AR	2
K433P15	BLADE - STG 14 (CONVEX)	CF6-50 (LMCO)	AR	2
K433P15	BLADE - STG 14 (CONVEX)	CF6-50 (LMCO)	AR	2
K433P15	BLADE - STG 14 (CONVEX)	CF6-50 (LMCO)	AR	1
K433P15	BLADE - STG 14 (CONVEX)	CF6-50 (LMCO)	OH	2
K433P16	BLADE - STG 14 (WIDE)	CF6-50 (LMCO)	AR	5
K433P16	BLADE - STG 14 (WIDE)	CF6-50 (LMCO)	AR	15
K433P16	BLADE - STG 14 (WIDE)	CF6-50 (LMCO)	AR	6
K433P16	BLADE - STG 14 (WIDE)	CF6-50 (LMCO)	OH	5
K433P16	BLADE - STG 14 (WIDE)	CF6-50 (LMCO)	OH	12
K433P16	BLADE - STG 14 (WIDE)	CF6-50 (LMCO)	OH	1
K433P16	BLADE - STG 14 (WIDE)	CF6-50 (LMCO)	AR	17
K433P16	BLADE - STG 14 (WIDE)	CF6-50 (LMCO)	AR	17
K433P16	BLADE - STG 14 (WIDE)	CF6-50 (LMCO)	AR	19
K433P16	BLADE - STG 14 (WIDE)	CF6-50 (LMCO)	AR	19
K433P16	BLADE - STG 14 (WIDE)	CF6-50 (LMCO)	AR	16
K433P16	BLADE - STG 14 (WIDE)	CF6-50 (LMCO)	AR	20
K433P16	BLADE - STG 14 (WIDE)	CF6-50 (LMCO)	AR	23
K433P16	BLADE - STG 14 (WIDE)	CF6-50 (LMCO)	OH	1
K433P17	BLADE - STG 14 (CONCAVE)	CF6-50 (LMCO)	AR	2
K433P17	BLADE - STG 14 (CONCAVE)	CF6-50 (LMCO)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
K433P17	BLADE - STG 14 (CONCAVE)	CF6-50 (LMCO)	OH	1
K433P17	BLADE - STG 14 (CONCAVE)	CF6-50 (LMCO)	OH	1
K433P17	BLADE - STG 14 (CONCAVE)	CF6-50 (LMCO)	AR	2
K433P17	BLADE - STG 14 (CONCAVE)	CF6-50 (LMCO)	AR	2
K433P17	BLADE - STG 14 (CONCAVE)	CF6-50 (LMCO)	AR	2
K433P17	BLADE - STG 14 (CONCAVE)	CF6-50 (LMCO)	AR	2
K433P17	BLADE - STG 14 (CONCAVE)	CF6-50 (LMCO)	AR	2
K433P17	BLADE - STG 14 (CONCAVE)	CF6-50 (LMCO)	AR	2
K433P17	BLADE - STG 14 (CONCAVE)	CF6-50 (LMCO)	AR	2
K433P17	BLADE - STG 14 (CONCAVE)	CF6-50 (LMCO)	AR	2
K433P18	BLADE - STG 14 (EXTRA WIDE)	CF6-50 (LMCO)	AR	6
K433P18	BLADE - STG 14 (EXTRA WIDE)	CF6-50 (LMCO)	OH	6
K433P18	BLADE - STG 14 (EXTRA WIDE)	CF6-50 (LMCO)	AR	1
K433P27	BLADE - STG 14 (NARROW)	CF6-80A	AR	54
K433P27	BLADE - STG 14 (NARROW)	CF6-80A	OH	39
K433P27	BLADE - STG 14 (NARROW)	CF6-80A	AR	55
K433P27	BLADE - STG 14 (NARROW)	CF6-80A	OH	2
K433P27	BLADE - STG 14 (NARROW)	CF6-80A	OH	4
K433P28	BLADE - STG 14 (CONCAVE)	CF6-80A	AR	2
K433P28	BLADE - STG 14 (CONCAVE)	CF6-80A	AR	1
K433P28	BLADE - STG 14 (CONCAVE)	CF6-80A	AR	1
K433P29	BLADE - STG 14 (CONVEX)	CF6-80A	AR	2
K433P29	BLADE - STG 14 (CONVEX)	CF6-80A	AR	1
K433P30	BLADE - STG 14 (WIDE)	CF6-80A	OH	1
K433P41	BLADE - STG 14 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K433P41	BLADE - STG 14 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	61
K433P41	BLADE - STG 14 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
K433P41	BLADE - STG 14 (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	NE	95
K433P42	BLADE - STG 14 (CONVEX)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K433P44	BLADE - STG 14 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K433P44	BLADE - STG 14 (CONCAVE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K433P46	BLADE - STG 14 (NARROW)	CF6-80A	AR	58
K433P46	BLADE - STG 14 (NARROW)	CF6-80A	AR	1
K433P46	BLADE - STG 14 (NARROW)	CF6-80A	AR	60
K433P46	BLADE - STG 14 (NARROW)	CF6-80A	AR	62
K433P46	BLADE - STG 14 (NARROW)	CF6-80A	AR	25
K433P46	BLADE - STG 14 (NARROW)	CF6-80A	OH	19
K433P46	BLADE - STG 14 (NARROW)	CF6-80A	OH	54

Part Number	Part Description	Engine Type	Condition	Quantity
K433P47	BLADE - STG 14 (CONCAVE)	CF6-80A	AR	1
K433P47	BLADE - STG 14 (CONCAVE)	CF6-80A	AR	1
K433P47	BLADE - STG 14 (CONCAVE)	CF6-80A	AR	2
K433P47	BLADE - STG 14 (CONCAVE)	CF6-80A	AR	2
K433P47	BLADE - STG 14 (CONCAVE)	CF6-80A	AR	2
K433P47	BLADE - STG 14 (CONCAVE)	CF6-80A	AR	2
K433P47	BLADE - STG 14 (CONCAVE)	CF6-80A	AR	2
K433P48	BLADE - STG 14 (CONVEX)	CF6-80A	AR	1
K433P48	BLADE - STG 14 (CONVEX)	CF6-80A	AR	2
K433P48	BLADE - STG 14 (CONVEX)	CF6-80A	AR	2
K433P48	BLADE - STG 14 (CONVEX)	CF6-80A	AR	2
K433P49	BLADE - STG 14 (WIDE)	CF6-80A	AR	14
K433P49	BLADE - STG 14 (WIDE)	CF6-80A	AR	1
K433P49	BLADE - STG 14 (WIDE)	CF6-80A	OH	1
K433P49	BLADE - STG 14 (WIDE)	CF6-80A	OH	15
K445P02	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K445P02	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K445P02	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K445P02	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	10
K445P02	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K445P02	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K445P02	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K445P02	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	45
K445P02	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	50
K445P02	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	17
K445P02	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	21

Part Number	Part Description	Engine Type	Condition	Quantity
K445P02	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K445P02	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K445P02	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	11
K445P02	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	18
K445P03	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	25
K445P03	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	50
K445P03	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	50
K445P03	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	50
K445P03	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	50
K445P03	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K445P03	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K445P03	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K445P03	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K445P03	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	15
K445P03	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	37
K445P03	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3

Part Number	Part Description	Engine Type	Condition	Quantity
K445P03	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	50
K445P03	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	50
K445P03	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K445P03	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
K445P03	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	50
K445P03	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	44
K445P03	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	50
K445P03	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	50
K445P03	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K445P03	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	29
K445P03	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	50
K445P03	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K445P03	VANE - STG 4	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K445P04	VANE - STG 4	CF6-80C2	OH	36
K445P04	VANE - STG 4	CF6-80C2	OH	18
K461P03	HPC STATOR VANE STG 1	CF6-80C2	OH	9
K461P03	HPC STATOR VANE STG 1	CF6-80C2	OH	1
K461P03	HPC STATOR VANE STG 1	CF6-80C2	OH	36
K465P03	HPC STATOR VANE STG 5	CF6-80C2	OH	1
K466P02	HPC STATOR VANE STG 6 [NARROW]	CF6-80C2	OH	2
K466P02	HPC STATOR VANE STG 6 [NARROW]	CF6-80C2	OH	2

Part Number	Part Description	Engine Type	Condition	Quantity
K466P02	HPC STATOR VANE STG 6 [NARROW]	CF6-80C2	OH	2
K466P02	HPC STATOR VANE STG 6 [NARROW]	CF6-80C2	OH	2
K466P02	HPC STATOR VANE STG 6 [NARROW]	CF6-80C2	OH	14
K467P03	VANE - STG 7 (END)	CF6-80C2	OH	1
K469P02	HPC STATOR VANE STG 9 [WIDE]	CF6-80C2	OH	2
K469P04	HPC STATOR VANE STG 9 [BORESCOPE]	CF6-80C2	OH	1
K470P01	HPC STATOR VANE STG 10 [NARROW]	CF6-80C2	OH	3
K470P02	HPC STATOR VANE STG 10 [WIDE]	CF6-80C2	OH	1
K470P02	HPC STATOR VANE STG 10 [WIDE]	CF6-80C2	OH	3
K471P16	VANE - STG 11 (WIDE)	CF6-80C2	NS	1
K471P16	VANE - STG 11 (WIDE)	CF6-80C2	OH	1
K471P18	VANE - STG 11	CF6-80C2	OH	1
K472P01	HPC STATOR VANE STG 12 [NARROW]	CF6-80C2	OH	6
K472P01	HPC STATOR VANE STG 12 [NARROW]	CF6-80C2	OH	1
K472P02	HPC STATOR VANE STG 12 [WIDE]	CF6-80C2	OH	1
K472P02	HPC STATOR VANE STG 12 [WIDE]	CF6-80C2	OH	4
K488P07	HPC ROTOR BLADE STG 14 [NARROW]	CF6-80C2	OH	1
K488P07	HPC ROTOR BLADE STG 14 [NARROW]	CF6-80C2	OH	4
K488P10	HPC ROTOR BLADE STG 14 [WIDE]	CF6-80C2	OH	1
K488P10	HPC ROTOR BLADE STG 14 [WIDE]	CF6-80C2	OH	1
K488P14	HPC ROTOR BLADE STG 14 [WIDE]	CF6-80C2	OH	1
K546P02	VANE - STG 5	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K546P02	VANE - STG 5	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K546P02	VANE - STG 5	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K546P02	VANE - STG 5	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K546P02	VANE - STG 5	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
K546P02	VANE - STG 5	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K546P02	VANE - STG 5	CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
K546P02	VANE - STG 5	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K546P02	VANE - STG 5	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K546P02	VANE - STG 5	CF6-50 (LMCO), CF6-50 (Boeing)	AR	58
K546P02	VANE - STG 5	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K546P02	VANE - STG 5	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K546P02	VANE - STG 5	CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K546P02	VANE - STG 5	CF6-50 (LMCO), CF6-50 (Boeing)	AR	58
K546P02	VANE - STG 5	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K546P02	VANE - STG 5	CF6-50 (LMCO), CF6-50 (Boeing)	OH	9
K546P02	VANE - STG 5	CF6-50 (LMCO), CF6-50 (Boeing)	OH	13
K546P02	VANE - STG 5	CF6-50 (LMCO), CF6-50 (Boeing)	OH	29
K546P02	VANE - STG 5	CF6-50 (LMCO), CF6-50 (Boeing)	OH	12
K546P02	VANE - STG 5	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K546P02	VANE - STG 5	CF6-50 (LMCO), CF6-50 (Boeing)	AR	13
K546P02	VANE - STG 5	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K546P02	VANE - STG 5	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K546P02	VANE - STG 5	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K546P02	VANE - STG 5	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K546P02	VANE - STG 5	CF6-50 (LMCO), CF6-50 (Boeing)	AR	23
K546P02	VANE - STG 5	CF6-50 (LMCO), CF6-50 (Boeing)	AR	52
K546P03	VANE - STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K546P03	VANE - STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	58

Part Number	Part Description	Engine Type	Condition	Quantity
K546P03	VANE - STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	57
K546P03	VANE - STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	58
K546P03	VANE - STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K546P03	VANE - STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K546P03	VANE - STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K546P03	VANE - STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K546P03	VANE - STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	51
K546P03	VANE - STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K546P03	VANE - STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	49
K546P03	VANE - STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	57
K546P03	VANE - STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K546P03	VANE - STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	52
K546P03	VANE - STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
K546P03	VANE - STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	35
K546P03	VANE - STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	58
K546P03	VANE - STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	7

Part Number	Part Description	Engine Type	Condition	Quantity
K546P03	VANE - STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	6
K546P03	VANE - STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	18
K546P03	VANE - STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	58
K546P03	VANE - STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K546P03	VANE - STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	58
K546P03	VANE - STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	43
K546P03	VANE - STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K546P03	VANE - STG 5	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	44
K546P04	VANE - STG 5	CF6-80C2, CF6-50	OH	1
K575P02	VANE - STG 5	CF6-80C2	OH	52
K600P13	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P13	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K600P13	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K600P13	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K600P13	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P13	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K600P13	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K600P13	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	11

Part Number	Part Description	Engine Type	Condition	Quantity
K600P13	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P13	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P13	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K600P13	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K600P14	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K600P14	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
K600P14	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K600P14	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P14	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P14	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P14	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K600P14	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P14	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
K600P14	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	24
K600P15	VANE - STG 6 (BORESCOPE)	CF6-80A, CF6-50	AR	1
K600P15	VANE - STG 6 (BORESCOPE)	CF6-80A, CF6-50	AR	1
K600P15	VANE - STG 6 (BORESCOPE)	CF6-80A, CF6-50	AR	1
K600P16	VANE - STG 6 (BORESCOPE)	CF6-50 (LMCO)	AR	1
K600P16	VANE - STG 6 (BORESCOPE)	CF6-50 (LMCO)	AR	1
K600P19	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	2

Part Number	Part Description	Engine Type	Condition	Quantity
K600P19	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K600P19	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K600P19	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K600P19	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	2
K600P19	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K600P19	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	2
K600P19	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	3
K600P19	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K600P19	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO)	AR	1
K600P19	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO)	OH	1
K600P20	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	21
K600P20	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	12
K600P20	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	2
K600P20	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	5
K600P20	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K600P20	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K600P20	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K600P20	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	11
K600P20	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	2
K600P20	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	12
K600P20	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	16
K600P20	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	4
K600P20	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	13
K600P20	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	3
K600P20	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K600P20	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K600P20	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	1
K600P20	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO)	AR	2
K600P20	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO)	OH	1
K600P20	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO)	OH	2
K600P21	VANE - STG 6 (BORESCOPE)	CF6-80A	AR	1
K600P21	VANE - STG 6 (BORESCOPE)	CF6-80A	AR	1
K600P22	VANE - STG 6 (BORESCOPE)	CF6-50 (LMCO)	AR	1
K600P22	VANE - STG 6 (BORESCOPE)	CF6-50 (LMCO)	OH	1
K600P22	VANE - STG 6 (BORESCOPE)	CF6-50 (LMCO)	AR	1
K600P22	VANE - STG 6 (BORESCOPE)	CF6-50 (LMCO)	AR	1
K600P24	VANE - STG 6 (LOCKING)	CF6-80A, CF6-50 (LMCO)	AR	1
K600P24	VANE - STG 6 (LOCKING)	CF6-80A, CF6-50 (LMCO)	AR	1
K600P39	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K600P39	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K600P39	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K600P39	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K600P39	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K600P39	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K600P39	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K600P39	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	6
K600P39	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
K600P39	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K600P39	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K600P39	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K600P39	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K600P39	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	8
K600P39	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	7
K600P39	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
K600P39	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K600P39	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	7
K600P39	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K600P39	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K600P39	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K600P39	VANE - STG 6 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K600P40	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	37
K600P40	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	46
K600P40	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	42

Part Number	Part Description	Engine Type	Condition	Quantity
K600P40	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	14
K600P40	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K600P40	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P40	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	53
K600P40	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K600P40	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	52
K600P40	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K600P40	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
K600P40	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K600P40	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	7
K600P40	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K600P40	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	21
K600P40	VANE - STG 6 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	24
K600P41	VANE - STG 6 (BOREScope)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P41	VANE - STG 6 (BOREScope)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P41	VANE - STG 6 (BOREScope)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K600P41	VANE - STG 6 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P41	VANE - STG 6 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P41	VANE - STG 6 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P41	VANE - STG 6 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P41	VANE - STG 6 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P41	VANE - STG 6 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P41	VANE - STG 6 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P41	VANE - STG 6 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P41	VANE - STG 6 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P41	VANE - STG 6 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P41	VANE - STG 6 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P41	VANE - STG 6 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P41	VANE - STG 6 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P41	VANE - STG 6 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K600P41	VANE - STG 6 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K600P42	VANE - STG 6 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P42	VANE - STG 6 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P42	VANE - STG 6 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P42	VANE - STG 6 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P42	VANE - STG 6 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P42	VANE - STG 6 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P43	VANE - STG 6 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P43	VANE - STG 6 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P43	VANE - STG 6 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P43	VANE - STG 6 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P43	VANE - STG 6 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P43	VANE - STG 6 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P43	VANE - STG 6 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P43	VANE - STG 6 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P43	VANE - STG 6 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K600P43	VANE - STG 6 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P43	VANE - STG 6 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P43	VANE - STG 6 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P43	VANE - STG 6 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P44	VANE - STG 6 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P44	VANE - STG 6 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P44	VANE - STG 6 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P44	VANE - STG 6 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P44	VANE - STG 6 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P44	VANE - STG 6 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P44	VANE - STG 6 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P44	VANE - STG 6 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P44	VANE - STG 6 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K600P44	VANE - STG 6 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K600P45	VANE - STG 6 (WIDE)	CF6-80C2	AR	11
K600P45	VANE - STG 6 (WIDE)	CF6-80C2	AR	13
K600P45	VANE - STG 6 (WIDE)	CF6-80C2	AR	5
K600P45	VANE - STG 6 (WIDE)	CF6-80C2	AR	12
K600P45	VANE - STG 6 (WIDE)	CF6-80C2	OH	1
K600P45	VANE - STG 6 (WIDE)	CF6-80C2	OH	4
K600P46	VANE - STG 6 (NARROW)	CF6-80C2	AR	50

Part Number	Part Description	Engine Type	Condition	Quantity
K600P46	VANE - STG 6 (NARROW)	CF6-80C2	AR	43
K600P46	VANE - STG 6 (NARROW)	CF6-80C2	AR	44
K600P46	VANE - STG 6 (NARROW)	CF6-80C2	AR	47
K600P46	VANE - STG 6 (NARROW)	CF6-80C2	AR	47
K600P48	VANE - STG 6 (BOREScope)	CF6-80C2	OH	1
K600P49	VANE - STG 6 (LOCKING)	CF6-80C2	OH	1
K600P50	VANE - STG 6 (LOCKING)	CF6-80C2	OH	1
K602P01	BLADE - STG 6 (NARROW)	CF6-80A	AR	39
K602P01	BLADE - STG 6 (NARROW)	CF6-80A	OH	1
K602P01	BLADE - STG 6 (NARROW)	CF6-80A	OH	8
K602P01	BLADE - STG 6 (NARROW)	CF6-80A	OH	2
K602P01	BLADE - STG 6 (NARROW)	CF6-80A	OH	9
K602P01	BLADE - STG 6 (NARROW)	CF6-80A	AR	20
K602P01	BLADE - STG 6 (NARROW)	CF6-80A	AR	16
K602P01	BLADE - STG 6 (NARROW)	CF6-80A	AR	21
K602P01	BLADE - STG 6 (NARROW)	CF6-80A	AR	30
K602P01	BLADE - STG 6 (NARROW)	CF6-80A	AR	2
K602P01	BLADE - STG 6 (NARROW)	CF6-80A	AR	9
K602P01	BLADE - STG 6 (NARROW)	CF6-80A	AR	2
K602P02	BLADE - STG 6 (CONCAVE)	CF6-80A	AR	3
K602P02	BLADE - STG 6 (CONCAVE)	CF6-80A	AR	3
K602P02	BLADE - STG 6 (CONCAVE)	CF6-80A	AR	2
K602P02	BLADE - STG 6 (CONCAVE)	CF6-80A	AR	1
K602P02	BLADE - STG 6 (CONCAVE)	CF6-80A	AR	2
K602P02	BLADE - STG 6 (CONCAVE)	CF6-80A	AR	2
K602P02	BLADE - STG 6 (CONCAVE)	CF6-80A	OH	1
K602P03	BLADE - STG 6 (CONVEX)	CF6-80A	AR	3
K602P03	BLADE - STG 6 (CONVEX)	CF6-80A	AR	3
K602P03	BLADE - STG 6 (CONVEX)	CF6-80A	AR	2
K602P03	BLADE - STG 6 (CONVEX)	CF6-80A	OH	2
K602P04	BLADE - STG 6 (WIDE)	CF6-80A	OH	1
K602P05	BLADE - STG 6 (NARROW)	CF6-80A	AR	42
K602P05	BLADE - STG 6 (NARROW)	CF6-80A	AR	43
K602P05	BLADE - STG 6 (NARROW)	CF6-80A	AR	45
K602P05	BLADE - STG 6 (NARROW)	CF6-80A	AR	44
K602P05	BLADE - STG 6 (NARROW)	CF6-80A	AR	44
K602P05	BLADE - STG 6 (NARROW)	CF6-80A	AR	16
K602P05	BLADE - STG 6 (NARROW)	CF6-80A	AR	44
K602P05	BLADE - STG 6 (NARROW)	CF6-80A	AR	22
K602P05	BLADE - STG 6 (NARROW)	CF6-80A	AR	2
K602P06	BLADE - STG 6 (CONCAVE)	CF6-80A	AR	3
K602P06	BLADE - STG 6 (CONCAVE)	CF6-80A	AR	3
K602P06	BLADE - STG 6 (CONCAVE)	CF6-80A	AR	3
K602P06	BLADE - STG 6 (CONCAVE)	CF6-80A	AR	3
K602P06	BLADE - STG 6 (CONCAVE)	CF6-80A	AR	1
K602P06	BLADE - STG 6 (CONCAVE)	CF6-80A	AR	3
K602P07	BLADE - STG 6 (CONVEX)	CF6-80A	AR	3
K602P07	BLADE - STG 6 (CONVEX)	CF6-80A	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K615P01	HPC ROTOR BLADE STG 6 [NARROW]	CF6-80C2	OH	3
K615P01	HPC ROTOR BLADE STG 6 [NARROW]	CF6-80C2	OH	1
K615P01	HPC ROTOR BLADE STG 6 [NARROW]	CF6-80C2	OH	1
K615P01	HPC ROTOR BLADE STG 6 [NARROW]	CF6-80C2	OH	2
K615P01	HPC ROTOR BLADE STG 6 [NARROW]	CF6-80C2	OH	1
K615P01	HPC ROTOR BLADE STG 6 [NARROW]	CF6-80C2	OH	1
K615P01	HPC ROTOR BLADE STG 6 [NARROW]	CF6-80C2	OH	5
K615P01	HPC ROTOR BLADE STG 6 [NARROW]	CF6-80C2	OH	1
K615P01	HPC ROTOR BLADE STG 6 [NARROW]	CF6-80C2	OH	1
K615P01	HPC ROTOR BLADE STG 6 [NARROW]	CF6-80C2	OH	4
K615P01	HPC ROTOR BLADE STG 6 [NARROW]	CF6-80C2	OH	1
K615P01	HPC ROTOR BLADE STG 6 [NARROW]	CF6-80C2	OH	2
K615P01	HPC ROTOR BLADE STG 6 [NARROW]	CF6-80C2	OH	4
K615P02	HPC ROTOR BLADE STG 6 [CONCAVE]	CF6-80C2	OH	2
K615P02	HPC ROTOR BLADE STG 6 [CONCAVE]	CF6-80C2	OH	1
K615P03	HPC ROTOR BLADE STG 6 [CONVEX]	CF6-80C2	OH	1
K615P03	HPC ROTOR BLADE STG 6 [CONVEX]	CF6-80C2	OH	3
K615P04	HPC ROTOR BLADE STG 6 [WIDE]	CF6-80C2	OH	1
K615P04	HPC ROTOR BLADE STG 6 [WIDE]	CF6-80C2	OH	1
K615P04	HPC ROTOR BLADE STG 6 [WIDE]	CF6-80C2	OH	3
K615P04	HPC ROTOR BLADE STG 6 [WIDE]	CF6-80C2	OH	1
K615P04	HPC ROTOR BLADE STG 6 [WIDE]	CF6-80C2	OH	2
K615P04	HPC ROTOR BLADE STG 6 [WIDE]	CF6-80C2	OH	3
K643P17	HPC ROTOR BLADE STG 3 [NARROW]	CF6-80C2	OH	8
K643P17	HPC ROTOR BLADE STG 3 [NARROW]	CF6-80C2	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
K643P20	HPC ROTOR BLADE STG 3 [WIDE]	CF6-80C2	OH	2
K643P41	HPC ROTOR BLADE STG 3 [NARROW]	CF6-80C2	NS	1
K644P13	HPC ROTOR BLADE STG 4 [NARROW]	CF6-80C2	SV	1
K644P13	HPC ROTOR BLADE STG 4 [NARROW]	CF6-80C2	OH	2
K644P13	HPC ROTOR BLADE STG 4 [NARROW]	CF6-80C2	OH	6
K645P13	HPC ROTOR BLADE STG 5 [NARROW]	CF6-80C2	REP	1
K645P13	HPC ROTOR BLADE STG 5 [NARROW]	CF6-80C2	NE	3
K645P14	HPC ROTOR BLADE STG 5 [CONCAVE]	CF6-80C2	NE	2
K657P05	HPC ROTOR BLADE STG 7 [NARROW]	CF6-80C2	OH	1
K657P07	HPC ROTOR BLADE STG 7 [CONVEX]	CF6-80C2	OH	3
K658P05	HPC ROTOR BLADE STG 8 [NARROW]	CF6-80C2	OH	1
K658P08	HPC ROTOR BLADE STG 8 [WIDE]	CF6-80C2	OH	1
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	44
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	29
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	43
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	41
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	24
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	6
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	30
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	47

Part Number	Part Description	Engine Type	Condition	Quantity
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	46
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	45
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	33
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	48
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	18
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	38
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	19
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	47
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	29
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	7
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	8
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	37
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	43
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	42
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	55
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	54
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	41
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	44
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	6

Part Number	Part Description	Engine Type	Condition	Quantity
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	22
K688P09	VANE - STG OGV (NARROW)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
K688P10	VANE - STG OGV (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
K688P10	VANE - STG OGV (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	43
K688P10	VANE - STG OGV (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	39
K688P10	VANE - STG OGV (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K688P10	VANE - STG OGV (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K688P10	VANE - STG OGV (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K688P10	VANE - STG OGV (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
K688P10	VANE - STG OGV (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
K688P10	VANE - STG OGV (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	12
K688P10	VANE - STG OGV (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	36
K688P10	VANE - STG OGV (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K688P10	VANE - STG OGV (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	44
K688P10	VANE - STG OGV (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	18
K688P10	VANE - STG OGV (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	59
K688P10	VANE - STG OGV (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K688P10	VANE - STG OGV (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	51
K688P10	VANE - STG OGV (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K688P10	VANE - STG OGV (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K688P10	VANE - STG OGV (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	39
K688P10	VANE - STG OGV (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	34
K688P10	VANE - STG OGV (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	48
K688P10	VANE - STG OGV (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	55
K688P10	VANE - STG OGV (WIDE)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	66

Part Number	Part Description	Engine Type	Condition	Quantity
K688P25	VANE - STG OGV (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K688P25	VANE - STG OGV (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K688P25	VANE - STG OGV (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K688P25	VANE - STG OGV (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K688P25	VANE - STG OGV (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
K688P25	VANE - STG OGV (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	15
K688P25	VANE - STG OGV (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	14
K688P25	VANE - STG OGV (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K688P25	VANE - STG OGV (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K688P25	VANE - STG OGV (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K688P25	VANE - STG OGV (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K688P25	VANE - STG OGV (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K688P25	VANE - STG OGV (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K688P25	VANE - STG OGV (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
K688P25	VANE - STG OGV (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K688P25	VANE - STG OGV (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K688P25	VANE - STG OGV (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	6
K688P25	VANE - STG OGV (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K688P25	VANE - STG OGV (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K688P25	VANE - STG OGV (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K688P25	VANE - STG OGV (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K688P25	VANE - STG OGV (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K688P25	VANE - STG OGV (WIDE+)	CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K688P43	VANE - OUTLET GUIDE (NARROW)	CF6-80A	AR	85
K688P43	VANE - OUTLET GUIDE (NARROW)	CF6-80A	AR	86

Part Number	Part Description	Engine Type	Condition	Quantity
K688P43	VANE - OUTLET GUIDE (NARROW)	CF6-80A	AR	87
K688P43	VANE - OUTLET GUIDE (NARROW)	CF6-80A	AR	82
K688P43	VANE - OUTLET GUIDE (NARROW)	CF6-80A	AR	1
K688P43	VANE - OUTLET GUIDE (NARROW)	CF6-80A	OH	52
K688P43	VANE - OUTLET GUIDE (NARROW)	CF6-80A	OH	3
K688P43	VANE - OUTLET GUIDE (NARROW)	CF6-80A	OH	13
K688P45	VANE - OUTLET GUIDE (WIDE)	CF6-80A	AR	18
K688P45	VANE - OUTLET GUIDE (WIDE)	CF6-80A	AR	5
K688P45	VANE - OUTLET GUIDE (WIDE)	CF6-80A	OH	13
K688P45	VANE - OUTLET GUIDE (WIDE)	CF6-80A	OH	7
K688P45	VANE - OUTLET GUIDE (WIDE)	CF6-80A	OH	9
K688P45	VANE - OUTLET GUIDE (WIDE)	CF6-80A	AR	8
K688P45	VANE - OUTLET GUIDE (WIDE)	CF6-80A	AR	12
K688P45	VANE - OUTLET GUIDE (WIDE)	CF6-80A	AR	12
K688P45	VANE - OUTLET GUIDE (WIDE)	CF6-80A	OH	11
K688P45	VANE - OUTLET GUIDE (WIDE)	CF6-80A	AR	5
K688P45	VANE - OUTLET GUIDE (WIDE)	CF6-80A	OH	11
K715P05	HPC ROTOR BLADE STG 7 [NARROW]	CF6-80C2	OH	2
K715P05	HPC ROTOR BLADE STG 7 [NARROW]	CF6-80C2	OH	6
K715P05	HPC ROTOR BLADE STG 7 [NARROW]	CF6-80C2	OH	6
K715P05	HPC ROTOR BLADE STG 7 [NARROW]	CF6-80C2	OH	3
K715P05	HPC ROTOR BLADE STG 7 [NARROW]	CF6-80C2	AR	3
K715P05	HPC ROTOR BLADE STG 7 [NARROW]	CF6-80C2	OH	2
K715P05	HPC ROTOR BLADE STG 7 [NARROW]	CF6-80C2	OH	1
K715P05	HPC ROTOR BLADE STG 7 [NARROW]	CF6-80C2	OH	2

Part Number	Part Description	Engine Type	Condition	Quantity
K715P05	HPC ROTOR BLADE STG 7 [NARROW]	CF6-80C2	OH	6
K715P05	HPC ROTOR BLADE STG 7 [NARROW]	CF6-80C2	OH	3
K715P05	HPC ROTOR BLADE STG 7 [NARROW]	CF6-80C2	OH	1
K715P06	HPC ROTOR BLADE STG 7 [CONCAVE]	CF6-80C2	AR	3
K715P06	HPC ROTOR BLADE STG 7 [CONCAVE]	CF6-80C2	NE	1
K715P08	HPC ROTOR BLADE STG 7 [WIDE]	CF6-80C2	OH	2
K715P08	HPC ROTOR BLADE STG 7 [WIDE]	CF6-80C2	OH	2
K715P08	HPC ROTOR BLADE STG 7 [WIDE]	CF6-80C2	OH	2
K779P11	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
K779P11	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K779P11	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K779P11	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K779P11	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P11	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K779P11	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P11	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P11	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P11	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K779P11	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3

Part Number	Part Description	Engine Type	Condition	Quantity
K779P11	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	43
K779P11	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	64
K779P11	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K779P11	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
K779P11	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
K779P12	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P12	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K779P12	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P12	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K779P12	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K779P12	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P12	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P12	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P12	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K779P12	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K779P12	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2

Part Number	Part Description	Engine Type	Condition	Quantity
K779P12	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P12	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K779P12	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K779P12	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K779P12	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K779P12	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K779P12	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P12	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	72
K779P13	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P13	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P13	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P13	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P14	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO)	AR	1
K779P14	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO)	AR	1
K779P14	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO)	AR	1
K779P29	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	21
K779P29	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K779P29	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K779P29	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P29	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K779P29	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
K779P29	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K779P29	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K779P29	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	42
K779P29	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P29	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P29	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K779P29	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	27
K779P29	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K779P29	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K779P29	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K779P29	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K779P29	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	7

Part Number	Part Description	Engine Type	Condition	Quantity
K779P29	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	13
K779P29	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K779P30	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K779P30	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
K779P30	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K779P30	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K779P30	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
K779P30	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P30	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K779P30	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K779P30	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K779P30	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P30	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P30	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K779P30	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K779P30	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	6

Part Number	Part Description	Engine Type	Condition	Quantity
K779P30	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	15
K779P31	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO)	AR	1
K779P31	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO)	AR	1
K779P31	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO)	AR	1
K779P31	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO)	AR	1
K779P31	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO)	AR	1
K779P32	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO)	AR	1
K779P32	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO)	AR	1
K779P32	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO)	AR	1
K779P32	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO)	AR	1
K779P32	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO)	AR	1
K779P33	VANE - STG 7 (WIDE+)	CF6-80A, CF6-50 (LMCO)	AR	3
K779P35	VANE - STG 7 (WIDE)	CF6-80C2	OH	5
K779P57	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K779P57	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	19
K779P57	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	50
K779P57	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	12
K779P57	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	52
K779P57	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K779P57	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	51
K779P57	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	15
K779P57	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3

Part Number	Part Description	Engine Type	Condition	Quantity
K779P57	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K779P57	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K779P57	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K779P57	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K779P57	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	49
K779P57	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K779P57	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	70
K779P57	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	23
K779P57	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	44
K779P57	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K779P57	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K779P57	VANE - STG 7 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K779P58	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K779P58	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
K779P58	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	22
K779P58	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	7

Part Number	Part Description	Engine Type	Condition	Quantity
K779P58	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K779P58	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
K779P58	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	21
K779P58	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K779P58	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K779P58	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
K779P58	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	14
K779P58	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
K779P58	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	9
K779P58	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	18
K779P58	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
K779P58	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	12
K779P58	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K779P58	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	23
K779P58	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	25
K779P58	VANE - STG 7 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2

Part Number	Part Description	Engine Type	Condition	Quantity
K779P59	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P59	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P59	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P59	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P59	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P59	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P59	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P60	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P60	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P60	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P60	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P60	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P60	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P60	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P60	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P60	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P60	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K779P60	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P60	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P60	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P60	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P60	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P60	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P60	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P60	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P60	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P60	VANE - STG 7 (LOCKING)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P61	VANE - STG 7 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P61	VANE - STG 7 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K779P61	VANE - STG 7 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P61	VANE - STG 7 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P61	VANE - STG 7 (WIDE+)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K779P62	VANE - STG 7 (NARROW)	CF6-80C2	OH	5
K779P62	VANE - STG 7 (NARROW)	CF6-80C2	OH	3
K779P63	VANE - STG 7 (WIDE)	CF6-80C2	OH	3
K808P14	VANE - STG 8 (NARROW)	CF6-80C2	OH	2
K808P18	VANE - STG 8 (WIDE)	CF6-80C2	OH	1
K818P05	HPC ROTOR BLADE STG 8 [NARROW]	CF6-80C2	OH	2

Part Number	Part Description	Engine Type	Condition	Quantity
K818P05	HPC ROTOR BLADE STG 8 [NARROW]	CF6-80C2	OH	3
K818P05	HPC ROTOR BLADE STG 8 [NARROW]	CF6-80C2	OH	1
K818P05	HPC ROTOR BLADE STG 8 [NARROW]	CF6-80C2	NE	22
K818P05	HPC ROTOR BLADE STG 8 [NARROW]	CF6-80C2	NE	1
K818P06	HPC ROTOR BLADE STG 8 [CONCAVE]	CF6-80C2	AR	3
K818P06	HPC ROTOR BLADE STG 8 [CONCAVE]	CF6-80C2	OH	1
K818P08	HPC ROTOR BLADE STG 8 [WIDE]	CF6-80C2	NE	2
K818P08	HPC ROTOR BLADE STG 8 [WIDE]	CF6-80C2	OH	1
K818P08	HPC ROTOR BLADE STG 8 [WIDE]	CF6-80C2	OH	1
K818P08	HPC ROTOR BLADE STG 8 [WIDE]	CF6-80C2	NE	2
K871G30	VANE - STG 8 (NARROW)	CF6-50	AR	1
K871G31	VANE - STG 8 (WIDE)	CF6-50	AR	1
K900P08	VANE - STG 9 (NARROW)	CF6-80C2	OH	1
K900P08	VANE - STG 9 (NARROW)	CF6-80C2	OH	1
K900P08	VANE - STG 9 (NARROW)	CF6-80C2	OH	1
K900P08	VANE - STG 9 (NARROW)	CF6-80C2	OH	5
K900P11	VANE - STG 9	CF6-80C2	OH	1
K900P12	VANE - STG 9	CF6-80C2	OH	1
K900P14	VANE - STG 9 (BORESCOPE)	CF6-80C2	OH	1
K900P16	VANE - STG 9 (BORESCOPE)	CF6-80C2	OH	1
K919P05	HPC ROTOR BLADE STG 9 [NARROW]	CF6-80C2	OH	3
K919P05	HPC ROTOR BLADE STG 9 [NARROW]	CF6-80C2	OH	1
K919P05	HPC ROTOR BLADE STG 9 [NARROW]	CF6-80C2	OH	1
K919P08	HPC ROTOR BLADE STG 9 [WIDE]	CF6-80C2	OH	1
K919P08	HPC ROTOR BLADE STG 9 [WIDE]	CF6-80C2	OH	2
K919P09	HPC ROTOR BLADE STG 9 [NARROW]	CF6-80C2	OH	3
K919P09	HPC ROTOR BLADE STG 9 [NARROW]	CF6-80C2	OH	2
K919P09	HPC ROTOR BLADE STG 9 [NARROW]	CF6-80C2	OH	3
K919P09	HPC ROTOR BLADE STG 9 [NARROW]	CF6-80C2	OH	2

Part Number	Part Description	Engine Type	Condition	Quantity
K919P09	HPC ROTOR BLADE STG 9 [NARROW]	CF6-80C2	OH	1
K919P28	HPC ROTOR BLADE STG 9 [WIDE]	CF6-80C2	NE	8
K919P28	HPC ROTOR BLADE STG 9 [WIDE]	CF6-80C2	NE	7
K919P28	HPC ROTOR BLADE STG 9 [WIDE]	CF6-80C2	NE	4
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	21
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	24
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	16
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	15
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	28
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5

Part Number	Part Description	Engine Type	Condition	Quantity
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	13
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	14
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	14
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	21
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	13
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	22
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	SV	9
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	12
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	10

Part Number	Part Description	Engine Type	Condition	Quantity
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	15
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	7
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	35
K980P11	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	29
K980P12	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K980P12	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K980P12	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	15

Part Number	Part Description	Engine Type	Condition	Quantity
K980P12	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	2
K980P12	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K980P12	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	6
K980P12	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P12	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K980P12	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K980P12	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P12	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K980P12	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	10
K980P12	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P12	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P12	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K980P12	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	8
K980P13	VANE - STG 9 (BOREScope)	CF6-80A, CF6-50 (LMCO)	AR	1
K980P13	VANE - STG 9 (BOREScope)	CF6-80A, CF6-50 (LMCO)	AR	1
K980P13	VANE - STG 9 (BOREScope)	CF6-80A, CF6-50 (LMCO)	AR	1
K980P13	VANE - STG 9 (BOREScope)	CF6-80A, CF6-50 (LMCO)	AR	1
K980P13	VANE - STG 9 (BOREScope)	CF6-80A, CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K980P13	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO)	AR	1
K980P13	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO)	AR	1
K980P13	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO)	AR	1
K980P14	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P14	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P14	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P14	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P14	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P14	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P14	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P14	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P15	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P15	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P15	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P15	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P15	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P15	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P15	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K980P15	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K980P15	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P15	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P15	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P16	VANE - STG 9	CF6-80A, CF6-50	AR	1
K980P16	VANE - STG 9	CF6-80A, CF6-50	OH	1
K980P16	VANE - STG 9	CF6-80A, CF6-50	AR	1
K980P16	VANE - STG 9	CF6-80A, CF6-50	AR	1
K980P16	VANE - STG 9	CF6-80A, CF6-50	AR	1
K980P16	VANE - STG 9	CF6-80A, CF6-50	AR	1
K980P16	VANE - STG 9	CF6-80A, CF6-50	AR	1
K980P16	VANE - STG 9	CF6-80A, CF6-50	AR	1
K980P29	VANE - STG 9 (WIDE+)	CF6-50 (LMCO)	AR	1
K980P29	VANE - STG 9 (WIDE+)	CF6-50 (LMCO)	AR	1
K980P29	VANE - STG 9 (WIDE+)	CF6-50 (LMCO)	AR	4
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	60
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	43
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	52
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	31
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	31
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	45
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	50
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	29
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	60

Part Number	Part Description	Engine Type	Condition	Quantity
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	22
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	11
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	19
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	40
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	48
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	35
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	33
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	35
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	15
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	21
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	44
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	27

Part Number	Part Description	Engine Type	Condition	Quantity
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	25
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	51
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	55
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	46
K980P32	VANE - STG 9 (NARROW)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	5
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	21
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	17
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	5
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	20
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	3
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	20

Part Number	Part Description	Engine Type	Condition	Quantity
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	17
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	11
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	7
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	7
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	7
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	7
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	14
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	4
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	3

Part Number	Part Description	Engine Type	Condition	Quantity
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	9
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	5
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	7
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	12
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	2
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	21
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	4
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	27
K980P33	VANE - STG 9 (WIDE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	3
K980P34	VANE - STG 9 (BOREScope)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P34	VANE - STG 9 (BOREScope)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P34	VANE - STG 9 (BOREScope)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P34	VANE - STG 9 (BOREScope)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P34	VANE - STG 9 (BOREScope)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P34	VANE - STG 9 (BOREScope)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K980P34	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P34	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P34	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P34	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P34	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P34	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P34	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P34	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P35	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P35	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P35	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P35	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P35	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P35	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P35	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P35	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P35	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K980P35	VANE - STG 9 (BORESCOPE)	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P36	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P36	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P36	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P36	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P36	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P36	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P36	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P36	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P36	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P36	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P36	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P36	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P36	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P36	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P37	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P37	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P37	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
K980P37	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P37	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P37	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P37	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P37	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P37	VANE - STG 9	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
K980P38	VANE - STG 9 (WIDE+)	CF6-80A	AR	1
K980P38	VANE - STG 9 (WIDE+)	CF6-80A	AR	2
K980P38	VANE - STG 9 (WIDE+)	CF6-80A	AR	5
K980P38	VANE - STG 9 (WIDE+)	CF6-80A	OH	2
K980P38	VANE - STG 9 (WIDE+)	CF6-80A	OH	1
KT1277M66P01	SEAL	CF6-80C2	NE	1
KT1352	RETAINER - VANE	CF6-80C2	NE	4
KT1352	RETAINER - VANE	CF6-80C2	NS	18
KT1352	RETAINER - VANE	CF6-80C2	NE	4
KT1352	RETAINER - VANE	CF6-80C2	NE	49
KT1352	RETAINER - VANE	CF6-80C2	NE	930
KT1536M67P02	SPACER - COOLING MANIFOLD	CF6-80C2	NE	3
KT1885M63G02	BRACKET ASSY	CF6-80C2	NE	7
KT1885M63G02	BRACKET ASSY	CF6-80C2	NE	2
KT2083M12G01	SHROUD - LPT STG 2	CF6-80C2	OH	3
KT2083M14G01	SHROUD - LPT STG 4	CF6-80C2	OH	1
KT2083M14G01	SHROUD - LPT STG 4	CF6-80C2	OH	20
KT9125M65G06	ARM - VANE ACTUATOR	CF6-80A	NE	2
KT9382M62P01	RETAINER - BLADE	CF6-80C2	NE	2
KT9382M62P01	RETAINER - BLADE	CF6-80C2	NE	6
KT9382M62P01	RETAINER - BLADE	CF6-80C2	NE	1
KT9382M62P01	RETAINER - BLADE	CF6-80C2	NE	5
KT9382M63P01	RETAINER - BLADE	CF6-80C2	NE	7
KT9382M63P01	RETAINER - BLADE	CF6-80C2	NE	95
KT9382M63P02	RETAINER - BLADE	CF6-80C2	NE	7
KTJ1128P03	SEAL - RING	CF6-80C2, CF6-80A	NE	1
KTJ1128P03	SEAL - RING	CF6-80C2, CF6-80A	NE	1

Part Number	Part Description	Engine Type	Condition	Quantity
KTJ1128P05	SEAL - RING	CF6-80C2, CF6-80A	NE	1
KTJ1128P05	SEAL - RING	CF6-80C2, CF6-80A	NE	15
KTJ1128P05	SEAL - RING	CF6-80C2, CF6-80A	NE	20
KTJ1128P05	SEAL - RING	CF6-80C2, CF6-80A	NE	2
KTJ1128P05	SEAL - RING	CF6-80C2, CF6-80A	NE	1
KTJ1128P11	SEAL - RING	CF6-80C2	NE	1
KTJ1128P11	SEAL - RING	CF6-80C2	NE	3
KTJ1128P11	SEAL - RING	CF6-80C2	NE	12
KTJ1128P11	SEAL - RING	CF6-80C2	NE	1
KTJ1128P11	SEAL - RING	CF6-80C2	NE	1
KTJ1170P01	UNIBALL	CF6-80C2	NE	7
KTJ1170P01	UNIBALL	CF6-80C2	NE	1
KTJ1170P01	UNIBALL	CF6-80C2	NE	1
KTJ1170P02	BEARING - BALL	CF6-80C2	NE	10
KTJ1170P02	BEARING - BALL	CF6-80C2	NE	1
M1647M99P02	SEAL	CF6-80C2	NE	1
M25988-1-110	SEAL - O-RING	CF6-50 (LMCO)	NE	1
M25988-1-110	SEAL - O-RING	CF6-50 (LMCO)	NE	1
M25988-1-110	SEAL - O-RING	CF6-50 (LMCO)	NE	1
M25988-1-110	SEAL - O-RING	CF6-50 (LMCO)	NE	1
M27426-3166D	RING - RETAINING	CF6-80C2	AR	1
M27426-3166D	RING - RETAINING	CF6-80C2	NE	4
M27426-3166D	RING - RETAINING	CF6-80C2	NE	1
M6318-2	VALVE - AIR CONTROL	CF6-50 (LMCO)	SV	1
M6318-3	VALVE - AIR CONTROL	CF6-50 (Boeing)	AR	1
M6318-3	VALVE - AIR CONTROL	CF6-50 (Boeing)	OH	1
M6318-3	VALVE - AIR CONTROL	CF6-50 (Boeing)	OH	1
M83248-1-129	SEAL - O-RING	CF6-50	NE	1
M83248-1-129	SEAL - O-RING	CF6-50	NE	4
M83248-1-129	SEAL - O-RING	CF6-50	NE	2
M83248-1-129	SEAL - O-RING	CF6-50	NE	2
M83248-1-129	SEAL - O-RING	CF6-50	NE	2
M83248-1-129	SEAL - O-RING	CF6-50	NE	1
M83248-1-129	SEAL - O-RING	CF6-50	NE	1
M83248-1-129	SEAL - O-RING	CF6-50	NE	1
M83248-1-139	SEAL - O-RING	CF6-80C2, CF6-80A	NE	35
M83248-1-139	SEAL - O-RING	CF6-80C2, CF6-80A	NE	1
M83248-1-139	SEAL - O-RING	CF6-80C2, CF6-80A	NE	1
M83248-1-139	SEAL - O-RING	CF6-80C2, CF6-80A	NE	3

Part Number	Part Description	Engine Type	Condition	Quantity
M83248-1-139	SEAL - O-RING	CF6-80C2, CF6-80A	NE	2
M83248/1-217	SEAL - O-RING	CF6-50 (Boeing)	NE	6
M83248/1-217	SEAL - O-RING	CF6-50 (Boeing)	NE	27
M83248/1-217	SEAL - O-RING	CF6-50 (Boeing)	NE	4
M9283M70G07	RETAINER - HPT STTR SHROUD	CF6-80C2, CF6-80A	NE	53
M9283M70G07	RETAINER - HPT STTR SHROUD	CF6-80C2, CF6-80A	OH	31
M9392M79P03	BAFFLE- AIR COVER HPT	CF6-80C2	NE	8
M9392M79P03	BAFFLE- AIR COVER HPT	CF6-80C2	NE	2
M9397M81P02	SEAL - OUTER NOZZLE	CF6-80C2	NE	21
M9397M81P02	SEAL - OUTER NOZZLE	CF6-80C2	NE	2
M9397M81P02	SEAL - OUTER NOZZLE	CF6-80C2	NE	77
MISC 1	MISC 1	CF6-50	NE	1
MISC 1	MISC 1	CF6-50	NE	1
MISC 1	MISC 1	CF6-50	AR	1
MISC 1	MISC 1	CF6-50	AR	1
MISC 1	MISC 1	CF6-50	AR	1
MISC 1	MISC 1	CF6-50	AR	1
MISC 1	MISC 1	CF6-50	AR	1
MISC 1	MISC 1	CF6-50	AR	1
MISC 1	MISC 1	CF6-50	AR	1
MISC 1	MISC 1	CF6-50	AR	1
MISC 1	MISC 1	CF6-50	AR	1
MISC 1	MISC 1	CF6-50	AR	1
MISC 1	MISC 1	CF6-50	AR	1
MISC 1	MISC 1	CF6-50	AR	1
MISC 1	MISC 1	CF6-50	AR	1
MISC 1	MISC 1	CF6-50	SV	1
MISC 1	MISC 1	CF6-50	AR	1
MS14103-4	BEARING	CF6-80C2, CF6-80A, CF6-50	NS	19
MS14103-5	BEARING	CF6-80C2, CF6-80A, CF6-50	NE	2
MS18029-2L8	COVER	CF6-50 (LMCO)	NS	1
MS20995C32	LOCKWIRE	CF6-50 (LMCO)	NS	12
MS2106L3	PLATE - NUT	CF6-80C2	NE	1
MS21241-06C020	BEARING	CF6-80A	NE	1
MS21241-06C020	BEARING	CF6-80A	NE	1
MS21241-06C020	BEARING	CF6-80A	NE	2
MS21913-J6	PLUG - MACH THD	CF6-50	NS	2
MS21914-12J	CAP - SHIPPING	CF6-50	NS	1
MS21914-12J	CAP - SHIPPING	CF6-50	NS	2
MS21914-12J	CAP - SHIPPING	CF6-50	NS	7
MS21914-16C	CAP	CF6-50 (LMCO)	NE	1

Part Number	Part Description	Engine Type	Condition	Quantity
MS21914-6J	CAP ASSY	CF6-50 (LMCO)	NE	7
MS21914-6S	CAP	CF6-50	NS	1
MS21914-6S	CAP	CF6-50	NS	2
MS21916-6-4S	REDUCER	CF6-50	NS	1
MS21916-6-4S	REDUCER	CF6-50	AR	1
MS21916-8-6	REDUCER	CF6-50 (Boeing)	NE	6
MS21916J8-6	REDUCER	CF6-80C2	NE	1
MS21926J6	ELBOW - 90 DEGREE	CF6-80C2, CF6-80A	NE	2
MS21926J6	ELBOW - 90 DEGREE	CF6-80C2, CF6-80A	NS	1
MS21926J6	ELBOW - 90 DEGREE	CF6-80C2, CF6-80A	NE	1
MS21926J6	ELBOW - 90 DEGREE	CF6-80C2, CF6-80A	NE	1
MS24391D6L	PLUG	CF6-80C2	NS	18
MS25043-12DA	CAP - T49	CF6-80C2	NS	4
MS25043-12DA	CAP - T49	CF6-80C2	NS	1
MS25043-12DA	CAP - T49	CF6-80C2	NE	10
MS25083-2CC6	JUMPER ASSY	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	12
MS25083-5CC4	CABLE - JUMPER	CF6-80C2	NE	1
MS25224-3	SWITCH - GUARD	CF6-80C2	NE	2
MS25224-3	SWITCH - GUARD	CF6-80C2	NE	1
MS28774-214	RETAINER	CF6-80C2	NE	52
MS28774-214	RETAINER	CF6-80C2	NE	2
MS28777-4	RING - BACKUP	CF6-50 (Boeing)	NE	1
MS28777-8	SEAL - O-RING	CF6-50 (Boeing)	NE	27
MS28777-8	SEAL - O-RING	CF6-50 (Boeing)	NE	1
MS3105-16S	RECEPTACLE	CF6-50 (LMCO)	NS	3
MS8005G094CA	HOSE ASSY - HPT/LPTCC RETURN	CF6-80C2	NE	1
MS9015-04	PLUG - MACH	CF6-80C2	NE	1
MS9315-04	CAP ASSY - TUBE	CF6-80C2, CF6-80A, PW2000, CF6-50 (Boeing)	NE	4
MS9315-06	CAP ASSY - TUBE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	NS	36
MS9315-06	CAP ASSY - TUBE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
MS9315-06	CAP ASSY - TUBE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
MS9315-08	CAP ASSY - TUBE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	NS	4
MS9315-08	CAP ASSY - TUBE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
MS9315-08	CAP ASSY - TUBE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
MS9404-04	PLUG - MACH THD	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NS	2
MS9404-04	PLUG - MACH THD	CF6-80C2, CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
MS9404-05	PLUG - MACH THD	CF6-80C2, CF6-50 (Boeing)	NS	5
MS9404-06	PLUG - MACH THD	CF6-80C2, CF6-80A	NS	1
MS9404-06	PLUG - MACH THD	CF6-80C2, CF6-80A	NS	1
MS9404-12	PLUG - MACH THD	CF6-80C2, CF6-80A	NS	17
MS9552-010	BRACKET - FLAT	CF6-50 (LMCO), CF6-50 (Boeing)	NE	6
MS9552-010	BRACKET - FLAT	CF6-50 (LMCO), CF6-50 (Boeing)	SV	1
MS9552-110	PLATE	CF6-80C2	SV	1
MS9552-206	BRACKET - FLAT	CF6-80C2, CF6-80A	NE	6
MS9552-206	BRACKET - FLAT	CF6-80C2, CF6-80A	OH	1
MS9552-239	BRACKET - FLAT	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
MS9552-239	BRACKET - FLAT	CF6-50 (LMCO), CF6-50 (Boeing)	NS	3
MS9552-239	BRACKET - FLAT	CF6-50 (LMCO), CF6-50 (Boeing)	NS	4
MS9552-243	BRACKET - FLAT	CF6-80C2	NS	6
MS9592-027	BRACKET - ANGLE	CF6-80C2	AR	1
MS9592-027	BRACKET - ANGLE	CF6-80C2	NS	6
MS9592-062	BRACKET	CF6-50 (Boeing)	NS	3
MS9592-062	BRACKET	CF6-50 (Boeing)	SV	1
MS9592-062	BRACKET	CF6-50 (Boeing)	NS	1
MS9592-090	BRACKET	CF6-50 (LMCO)	SV	1
MS9592-090	BRACKET	CF6-50 (LMCO)	NS	2
MS9592-090	BRACKET	CF6-50 (LMCO)	NS	11

Part Number	Part Description	Engine Type	Condition	Quantity
MS9592-090	BRACKET	CF6-50 (LMCO)	NS	7
MS9592-172	BRACKET - ANGLE	CF6-80C2	NE	3
MS9592-210	BRACKET - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	NE	2
MS9592-210	BRACKET - ANGLE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	24
MS9593-010	BRACKET - ANGLE	CF6-80C2	NE	2
MS9593-010	BRACKET - ANGLE	CF6-80C2	NE	18
MS9593-012	BRACKET	CF6-50 (LMCO), CF6-50 (Boeing)	NS	14
MS9593-130	BRACKET - ANGLE	CF6-80C2	SV	1
MS9901-06	PLUG - MACH	CF6-80C2	NS	2
MS9901-06	PLUG - MACH	CF6-80C2	NS	1
MS9901-08	PLUG	CF6-80C2	NS	2
MS9901-08	PLUG	CF6-80C2	NS	1
MS9902-02	PLUG - MACH	CF6-80C2	NS	15
MS9902-02	PLUG - MACH	CF6-80C2	NS	10
MS9902-02	PLUG - MACH	CF6-80C2	NE	10
MS9902-02	PLUG - MACH	CF6-80C2	NS	2
MS9902-02	PLUG - MACH	CF6-80C2	NE	18
MS9902-02	PLUG - MACH	CF6-80C2	NE	10
MS9902-02	PLUG - MACH	CF6-80C2	SV	1
MS9902-02	PLUG - MACH	CF6-80C2	OH	1
MS9902-02	PLUG - MACH	CF6-80C2	NE	10
MS9902-04	PLUG - MACH	CF6-80C2, CF6-80A	NS	1
MS9902-04	PLUG - MACH	CF6-80C2, CF6-80A	NS	9
MS9902-05	PLUG - MACH	CF6-80C2	AR	2
MS9902-05	PLUG - MACH	CF6-80C2	OH	1
MS9902-06	PLUG - MACH THD	CF6-80C2, CF6-80A, PW2000	NE	6
MS9902-06	PLUG - MACH THD	CF6-80C2, CF6-80A, PW2000	NS	1
MS9902-06	PLUG - MACH THD	CF6-80C2, CF6-80A, PW2000	SV	2
MS9902-06	PLUG - MACH THD	CF6-80C2, CF6-80A, PW2000	NE	1
MS9902-08	PLUG - MACH	CF6-80C2, CF6-80A	NE	2
MS9902-08	PLUG - MACH	CF6-80C2, CF6-80A	OH	1
MS9902-08	PLUG - MACH	CF6-80C2, CF6-80A	AR	1
MS9902-08	PLUG - MACH	CF6-80C2, CF6-80A	NE	2
NAS1056C6-022	SPACER - SLEEVE	CF6-80A	NS	1
NAS1056C6-022	SPACER - SLEEVE	CF6-80A	NS	9
NAS1056C6-022	SPACER - SLEEVE	CF6-80A	NS	20

Part Number	Part Description	Engine Type	Condition	Quantity
NAS1056C8-075	SPACER - SLEEVE	CF6-80A	NS	7
NAS1056C8-125	SPACER - SLEEVE	CF6-80A	NS	47
NAS1056E6-055	SPACER	CF6-80C2	NS	30
NAS1056E6-055	SPACER	CF6-80C2	NS	8
NAS1056E8-075	SPACER - SLEEVE	CF6-80A	NS	14
NAS1056E8-125	SPACER - SLEEVE	CF6-80A	NS	1
NAS1056E8-125	SPACER - SLEEVE	CF6-80A	NS	1
NAS1056E8-125	SPACER - SLEEVE	CF6-80A	NS	2
NAS1056K8-044	SPACER	CF6-80C2	NS	1
NAS1056K8-044	SPACER	CF6-80C2	NS	3
NAS1057T3-030	SPACER	CF6-80C2	NE	19
NAS1057T3-050	SPACER - SLEEVE	CF6-80C2, CF6-50	NS	8
NAS1057T3-055	SPACER - SLEEVE	CF6-80A	NS	1
NAS1057T3-055	SPACER - SLEEVE	CF6-80A	NS	5
NAS1057T3B030	SPACER	CF6-80C2	NS	11
NAS1057T3B030	SPACER	CF6-80C2	NS	3
NAS1057T4-010	SPACER - SLEEVE	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
NAS1057T4-112	SPACER	CF6-50 (LMCO)	NE	7
NAS1057T4-112	SPACER	CF6-50 (LMCO)	NE	1
NAS1057T4-137	SPACER	CF6-50 (LMCO)	NS	28
NAS1057W3-030	SPACER	CF6-80C2	NE	7
NAS1057W3-030	SPACER	CF6-80C2	NE	1
NAS1057W3-040	SPACER	CF6-80A	NS	1
NAS1057W3-055	SPACER	CF6-80A	NE	2
NAS1057W3-055	SPACER	CF6-80A	NE	48
NAS1057W3-100	SPACER	CF6-80A	NS	34
NAS1057W3-225	SPACER	CF6-80A	NS	2
NAS1057W3-255	SPACER	CF6-80A	NS	1
NAS1057W3-395	SPACER	CF6-80A	NE	3
NAS1057W3-395	SPACER	CF6-80A	OH	2
NAS1057W3-395	SPACER	CF6-80A	OH	2
NAS1057W3-395	SPACER	CF6-80A	NS	1
NAS1057W3-395	SPACER	CF6-80A	NS	1
NAS1057W4-019	SPACER	CF6-80C2	NS	3
NAS1057W4-019	SPACER	CF6-80C2	NS	1
NAS1057X8-047	SPACER	CF6-50	NS	4
NAS1193K10C	LINK - DEVISE	CF6-80A, CF6-50 (Boeing)	AR	1
NAS1398B5-2	OVERSIZE - RIVET	CF6-80C2	NE	3
NAS1398B5-2	OVERSIZE - RIVET	CF6-80C2	NE	95
NAS1595-4	SEAL - O-RING	CF6-50	NE	99
NAS1595-4	SEAL - O-RING	CF6-50	NE	94
NAS1611-114	SEAL - O-RING	CF6-50 (Boeing)	NE	4
NAS1761J1010	ELBOW	CF6-80A	NS	1
NAS1761J1010	ELBOW	CF6-80A	NS	4
NAS1761T1010	ELBOW	CF6-80A	NS	1
NAS1762J0404	ELBOW - FITTING	CF6-80A	NS	1

Part Number	Part Description	Engine Type	Condition	Quantity
NAS1762J0606	ELBOW - SWIVEL	CF6-80A	NE	2
NAS1762T1010	ELBOW	CF6-80A	SV	1
NAS42HT3-4	SPACER - RIVET	CF6-50 (LMCO)	NS	5
NAS43DD3-111FC	SPACER	CF6-80C2, CF6-50 (Boeing)	NS	25
NAS43DD3-111FC	SPACER	CF6-80C2, CF6-50 (Boeing)	NS	1
NAS43DD3-111FC	SPACER	CF6-80C2, CF6-50 (Boeing)	NS	2
NAS43DD3-124	SPACER	CF6-50 (Boeing)	NS	2
NAS43DD3-128	SPACER	CF6-80C2, CF6-80A	NS	15
NAS43DD3-128	SPACER	CF6-80C2, CF6-80A	NS	3
NAS43DD3-128FC	SPACER	CF6-80C2, CF6-80A	NE	64
NAS43DD3-128FC	SPACER	CF6-80C2, CF6-80A	NE	3
NAS43DD3-132FC	SPACER	CF6-80C2	NE	8
NAS43DD3-132FC	SPACER	CF6-80C2	NE	1
NAS43DD3-135	SPACER	CF6-50 (Boeing)	NE	4
NAS43DD3-135	SPACER	CF6-50 (Boeing)	NS	33
NAS43DD3-136	SPACER	CF6-50 (Boeing)	NS	20
NAS43DD3-136	SPACER	CF6-50 (Boeing)	NS	1
NAS43DD3-136	SPACER	CF6-50 (Boeing)	NS	2
NAS43DD3-137FC	SPACER	CF6-80C2	NE	11
NAS43DD3-169	SPACER	CF6-50 (Boeing)	NE	8
NAS43DD3-182	SPACER	CF6-50 (Boeing)	NE	17
NAS43DD3-40	SPACER	CF6-80A	NE	14
NAS43DD3-52	SPACER	CF6-80A	NE	1
NAS43HT3-10	SPACER	CF6-50 (Boeing)	NS	195
NAS43HT3-16	SPACER	CF6-80A, CF6-50 (Boeing)	NS	37
NAS43HT3-24	SLEEVE SPACER	CF6-50 (Boeing)	NE	1
NAS43HT3-32	SPACER	CF6-50 (Boeing)	NE	163
NAS43HT3-32	SPACER	CF6-50 (Boeing)	NE	1
NAS43HT3-32	SPACER	CF6-50 (Boeing)	NE	1
NAS43HT3-32	SPACER	CF6-50 (Boeing)	NE	4
NAS43HT3-48	SPACER	CF6-50 (Boeing)	NS	192
NAS43HT3-51	SPACER	CF6-80A, CF6-50 (Boeing)	NS	1
NAS43HT4-142	SPACER	CF6-50 (Boeing)	NE	24
NAS553-4	ELBOW	CF6-50 (LMCO)	NS	2
NAS5703-9	CHANNEL - SCREW GANG	CF6-80A	NS	507
NSL6323-13	MOUNT ASSY - AFT ENGINE	CF6-50	OH	1
NSL6323-13	MOUNT ASSY - AFT ENGINE	CF6-50	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
NSL6323-13	MOUNT ASSY - AFT ENGINE	CF6-50	AR	1
NSL6323-13	MOUNT ASSY - AFT ENGINE	CF6-50	AR	1
NSL6323-13	MOUNT ASSY - AFT ENGINE	CF6-50	AR	1
OMP2505-2	COUPLING - 1/2 BHD HALF	CF6-80C2	NE	1
OMP2505-4	DUST CAP	CF6-50 (LMCO)	NS	1
OMP2505-6	CAP - 1/2 BHD PRESSURE	CF6-80C2	NE	3
OMP2506-4	DUST COVER	CF6-80A, CF6-50 (LMCO)	NS	1
OMP2506-4	DUST COVER	CF6-80A, CF6-50 (LMCO)	NE	2
OMP2506-4	DUST COVER	CF6-80A, CF6-50 (LMCO)	NS	3
P31730	ROD END ASSY	CF6-80C2	NS	1
P31730	ROD END ASSY	CF6-80C2	NS	1
P31930	ROD END	CF6-80C2	NS	5
P31930	ROD END	CF6-80C2	NS	1
P31930	ROD END	CF6-80C2	NS	1
P31930	ROD END	CF6-80C2	SV	1
P31931	BALL	CF6-80C2	NS	1
P32000	BEARING - ROD END	CF6-80C2	NS	2
P32060	BEARING - ROD END	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NE	11
P32060	BEARING - ROD END	CF6-80C2, CF6-80A, CF6-50 (LMCO)	NE	1
P35700	ROD END	CF6-80C2, CF6-80A	NS	1
P35700	ROD END	CF6-80C2, CF6-80A	NE	1
P35700	ROD END	CF6-80C2, CF6-80A	NE	1
P35700	ROD END	CF6-80C2, CF6-80A	NE	2
P38590	BEARING - ROD END	CF6-80C2	NS	1
P40560	LINK	CF6-80C2	NE	1
P40810	LINK ASSY	CF6-80C2	NE	1
P40830	LINK	CF6-80C2	NS	1
P40830	LINK	CF6-80C2	OH	1
P40840	LINK	CF6-80C2	NE	1
P40850	LINK	CF6-80C2	OH	1
P40860	LINK ASSY	CF6-80C2	AR	1
P40860	LINK ASSY	CF6-80C2	AR	1
P40860	LINK ASSY	CF6-80C2	AR	1
P40860	LINK ASSY	CF6-80C2	AR	1
P40870	LINK	CF6-80C2	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
PCT1347M95G02-1	BAFFLE - SHROUD STG 1	CF6-50 (LMCO)	AR	1
PCT1347M95G02-1	BAFFLE - SHROUD STG 1	CF6-50 (LMCO)	AR	1
PCT1347M95G02-1	BAFFLE - SHROUD STG 1	CF6-50 (LMCO)	AR	1
PCT1347M95G02-1	BAFFLE - SHROUD STG 1	CF6-50 (LMCO)	AR	1
PCT1347M95G02-1	BAFFLE - SHROUD STG 1	CF6-50 (LMCO)	AR	1
PCT1347M95G02-1	BAFFLE - SHROUD STG 1	CF6-50 (LMCO)	AR	1
PCT1347M95G02-1	BAFFLE - SHROUD STG 1	CF6-50 (LMCO)	AR	1
PCT1862M24P02	SHROUD - HPT STATOR STG 1 (PMA)	CF6-80C2	OH	1
PCT1862M24P02	SHROUD - HPT STATOR STG 1 (PMA)	CF6-80C2	OH	1
PCT1862M24P02	SHROUD - HPT STATOR STG 1 (PMA)	CF6-80C2	OH	1
PCT1862M24P02	SHROUD - HPT STATOR STG 1 (PMA)	CF6-80C2	OH	1
PCT1862M24P02	SHROUD - HPT STATOR STG 1 (PMA)	CF6-80C2	OH	1
PCT1862M24P02	SHROUD - HPT STATOR STG 1 (PMA)	CF6-80C2	OH	1
PCT1862M24P02	SHROUD - HPT STATOR STG 1 (PMA)	CF6-80C2	OH	1
PCT1862M24P02	SHROUD - HPT STATOR STG 1 (PMA)	CF6-80C2	OH	1
PCT1862M24P02	SHROUD - HPT STATOR STG 1 (PMA)	CF6-80C2	OH	1
PCT1862M24P02	SHROUD - HPT STATOR STG 1 (PMA)	CF6-80C2	OH	1
PCT1862M24P02	SHROUD - HPT STATOR STG 1 (PMA)	CF6-80C2	OH	1
PCT1862M24P02	SHROUD - HPT STATOR STG 1 (PMA)	CF6-80C2	OH	1
PCT1862M24P02	SHROUD - HPT STATOR STG 1 (PMA)	CF6-80C2	OH	1
PCT1862M24P02	SHROUD - HPT STATOR STG 1 (PMA)	CF6-80C2	OH	1
PCT1862M24P02	SHROUD - HPT STATOR STG 1 (PMA)	CF6-80C2	OH	1
PCT1862M24P02	SHROUD - HPT STATOR STG 1 (PMA)	CF6-80C2	OH	1
PCT1862M24P02	SHROUD - HPT STATOR STG 1 (PMA)	CF6-80C2	OH	1
PCT1862M24P02	SHROUD - HPT STATOR STG 1 (PMA)	CF6-80C2	OH	1
PCT9192M95G05-1	SHROUD ASSY - STG 2 STTR	CF6-50 (LMCO)	AR	1
PCT9192M95G05-1	SHROUD ASSY - STG 2 STTR	CF6-50 (LMCO)	AR	1
PCT9192M95G05-1	SHROUD ASSY - STG 2 STTR	CF6-50 (LMCO)	AR	1
PCT9192M95G05-1	SHROUD ASSY - STG 2 STTR	CF6-50 (LMCO)	AR	1
PCT9192M95G05-1	SHROUD ASSY - STG 2 STTR	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
PCT9192M95G05-1	SHROUD ASSY - STG 2 STTR	CF6-50 (LMCO)	AR	1
PCT9192M95G05-1	SHROUD ASSY - STG 2 STTR	CF6-50 (LMCO)	AR	1
PCT9192M95G05-1	SHROUD ASSY - STG 2 STTR	CF6-50 (LMCO)	AR	1
PCT9192M95G05-1	SHROUD ASSY - STG 2 STTR	CF6-50 (LMCO)	AR	1
PCT9192M95G05-1	SHROUD ASSY - STG 2 STTR	CF6-50 (LMCO)	AR	1
PCT9192M95G05-1	SHROUD ASSY - STG 2 STTR	CF6-50 (LMCO)	AR	1
PCT9192M95G05-1	SHROUD ASSY - STG 2 STTR	CF6-50 (LMCO)	AR	1
PCT9192M95G05-1	SHROUD ASSY - STG 2 STTR	CF6-50 (LMCO)	AR	1
PCT9192M95G05-1	SHROUD ASSY - STG 2 STTR	CF6-50 (LMCO)	AR	1
PCT9192M95G05-1	SHROUD ASSY - STG 2 STTR	CF6-50 (LMCO)	AR	1
PCT9315M75G08-1	SHROUD - HPT STATOR STG 2	CF6-80A	OH	1
PCT9315M75G08-1	SHROUD - HPT STATOR STG 2	CF6-80A	SV	1
PCT9315M75G08-1	SHROUD - HPT STATOR STG 2	CF6-80A	SV	1
PCT9315M75G08-1	SHROUD - HPT STATOR STG 2	CF6-80A	SV	1
PCT9315M75G08-1	SHROUD - HPT STATOR STG 2	CF6-80A	SV	1
PCT9315M75G08-1	SHROUD - HPT STATOR STG 2	CF6-80A	SV	1
PCT9315M75G08-1	SHROUD - HPT STATOR STG 2	CF6-80A	SV	1
PCT9315M75G08-1	SHROUD - HPT STATOR STG 2	CF6-80A	SV	1
PCT9315M75G08-1	SHROUD - HPT STATOR STG 2	CF6-80A	SV	1
PCT9315M75G08-1	SHROUD - HPT STATOR STG 2	CF6-80A	SV	1
PCT9315M75G08-1	SHROUD - HPT STATOR STG 2	CF6-80A	SV	1
PCT9315M75G08-1	SHROUD - HPT STATOR STG 2	CF6-80A	SV	1
PCT9315M75G08-1	SHROUD - HPT STATOR STG 2	CF6-80A	SV	1
PCT9315M75G08-1	SHROUD - HPT STATOR STG 2	CF6-80A	SV	1
PCT9315M75G08-1	SHROUD - HPT STATOR STG 2	CF6-80A	SV	1
PCT9315M75G08-1	SHROUD - HPT STATOR STG 2	CF6-80A	SV	1
PCT9315M75G08-1	SHROUD - HPT STATOR STG 2	CF6-80A	SV	1
PCT9315M75G08-1	SHROUD - HPT STATOR STG 2	CF6-80A	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
PCT9315M75G08-1	SHROUD - HPT STATOR STG 2	CF6-80A	OH	1
PCT9315M75G08-1	SHROUD - HPT STATOR STG 2	CF6-80A	OH	1
PCT9315M75G08-1	SHROUD - HPT STATOR STG 2	CF6-80A	OH	1
PCT9315M75G08-1	SHROUD - HPT STATOR STG 2	CF6-80A	OH	1
PCT9315M75G08-1	SHROUD - HPT STATOR STG 2	CF6-80A	OH	1
PCT9315M75G08-1	SHROUD - HPT STATOR STG 2	CF6-80A	OH	1
PCT9315M75G08-1	SHROUD - HPT STATOR STG 2	CF6-80A	OH	1
PCT9392M86G10-1	SHROUD ASSY - STG 2	CF6-80C2	NE	1
PCT9392M86G10-1	SHROUD ASSY - STG 2	CF6-80C2	NE	1
PCT9392M86G10-1	SHROUD ASSY - STG 2	CF6-80C2	NE	1
PCT9392M86G10-1	SHROUD ASSY - STG 2	CF6-80C2	NE	1
PCT9392M86G10-1	SHROUD ASSY - STG 2	CF6-80C2	NE	1
PCT9392M86G10-1	SHROUD ASSY - STG 2	CF6-80C2	NE	1
PCT9392M86G10-1	SHROUD ASSY - STG 2	CF6-80C2	NE	1
PCT9392M86G10-1	SHROUD ASSY - STG 2	CF6-80C2	NE	1
PCT9392M86G10-1	SHROUD ASSY - STG 2	CF6-80C2	NE	1
PCT9392M86G10-1	SHROUD ASSY - STG 2	CF6-80C2	NE	1
PCT9392M86G10-1	SHROUD ASSY - STG 2	CF6-80C2	NE	1
PCT9392M86G10-1	SHROUD ASSY - STG 2	CF6-80C2	NE	1
PT030021A07	RETAINER - HPT STTR SHROUD	CF6-80A	OH	1
PT030054D16	TUBE - AIR	CF6-80C2	NE	1
R119P510A	KEY - SQUARE AND FLAT	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	NS	8
R148P4C	PLUG - FLARED	CF6-80C2	NE	4
R148P6C	PLUG - FLARED	CF6-80C2	NS	4
R149P155	SEAL - O-RING	CF6-50	NS	2
R149P155	SEAL - O-RING	CF6-50	NS	4
R1834E107	BEARING - ROLLER	CF6-50	AR	1
R1834EJ103	BEARING - ROLLER	CF6-80A	AR	1
R1834EJ103	BEARING - ROLLER	CF6-80A	SV	1
R1835E111	BEARING - ROLLER	CF6-80A	AR	1
R1835E111	BEARING - ROLLER	CF6-80A	AR	1
R18782-5	ELASTOMER	CF6-80C2	NE	5
R18782-5	ELASTOMER	CF6-80C2	NE	1
R1933E103	BEARING - ROLLER	CF6-80A	OH	1
R1933E103	BEARING - ROLLER	CF6-80A	SV	1
R1933E103	BEARING - ROLLER	CF6-80A	SV	1
R1933E103	BEARING - ROLLER	CF6-80A	AR	1
R198P08	SLEEVE - WIRE	CF6-80A	NE	8

Part Number	Part Description	Engine Type	Condition	Quantity
RR34150G	PUMP - LUBE & SCAVENGE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
RR34150G	PUMP - LUBE & SCAVENGE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
RR34150G	PUMP - LUBE & SCAVENGE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
RR34150G	PUMP - LUBE & SCAVENGE	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
RR34150L	PUMP - LUBE & SCAVENGE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
RR34150L	PUMP - LUBE & SCAVENGE	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	OH	1
RR37100	PUMP - LUBE & SCAVENGE	CF6-80A	AR	1
RR37100	PUMP - LUBE & SCAVENGE	CF6-80A	REP	1
RR37100B	PUMP - LUBE & SCAVENGE	CF6-80C2	AR	1
RR37100B	PUMP - LUBE & SCAVENGE	CF6-80C2	SV	1
RR37100B	PUMP - LUBE & SCAVENGE	CF6-80C2	SV	1
RR37100B	PUMP - LUBE & SCAVENGE	CF6-80C2	SV	1
RR37100B	PUMP - LUBE & SCAVENGE	CF6-80C2	OH	1
S-146	NAMEPLATE	CF6-80A	NS	1
S2861-02	MANIFOLD - DRAIN	CF6-80C2	SV	1
S315T108-1	ACTUATOR - ECM	CF6-80A	OH	1
S315T251-2	SHROUD ASSY	CF6-80A	OH	1
S332T003-13	JOINT ASSY - FLEXIBLE	CF6-80A	SV	1
S332T100-2	DETECTOR - FIRE	CF6-80A	SV	1
S332T101-33	DETECTOR - FIRE FAN LH	CF6-50 (Boeing)	OH	1
S41506-0156L	HOSE - TEFLON	CF6-80C2	NS	1
S41612-0100L	HOSE - TEFLON	CF6-80C2	AR	1
S4932410-008	J - RING	CF6-80C2	NS	1
S4932410-008	J - RING	CF6-80C2	NS	1
S4932410-008	J - RING	CF6-80C2	NS	1
S700B0115P4C025	SPACER	CF6-80C2	NE	1
S700R0396J5-6	REDUCER	CF6-80C2	NS	1
S700R0396J5-6	REDUCER	CF6-80C2	NS	1
S7929552-6-0110	HOSE ASSY	CF6-50 (LMCO)	AR	1
S7929552-6-0110	HOSE ASSY	CF6-50 (LMCO)	NS	1
S7929552-6-0110	HOSE ASSY	CF6-50 (LMCO)	NS	1
S7929552-6-0110	HOSE ASSY	CF6-50 (LMCO)	AR	1
S7929552-6-0110	HOSE ASSY	CF6-50 (LMCO)	AR	1
S7929552-6-0167	HOSE ASSY	CF6-50 (LMCO)	NS	1
S7929552-6-0167	HOSE ASSY	CF6-50 (LMCO)	OH	1
S7929552-6-0167	HOSE ASSY	CF6-50 (LMCO)	AR	1
S7929552-6-0167	HOSE ASSY	CF6-50 (LMCO)	AR	1
S7929552-6-0167	HOSE ASSY	CF6-50 (LMCO)	AR	1
S7929552-6-0167	HOSE ASSY	CF6-50 (LMCO)	AR	1

Part Number	Part Description	Engine Type	Condition	Quantity
S7929552-6-0167	HOSE ASSY	CF6-50 (LMCO)	AR	1
SLR4013A	RETAINER	CF6-50 (Boeing)	NE	2
SLR4013A	RETAINER	CF6-50 (Boeing)	NE	2
SSCY1115256	KIT - HOUSING REPAIR	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
SSCY1115256	KIT - HOUSING REPAIR	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
SSCY1115256	KIT - HOUSING REPAIR	CF6-50 (LMCO), CF6-50 (Boeing)	NE	1
SSCY5255-3	RING - RETAINING	CF6-50 (LMCO), CF6-50 (Boeing)	NS	1
SSCY5256-1	SEAL - RING	CF6-50 (Boeing)	NS	3
SSCY5560-2	SEAL - WIND	CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
TA05F18-04	BRACKET	CF6-50 (LMCO)	NS	2
TA30500438	BLOCK ASSY - LINE	CF6-80C2	NS	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	SV	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	SV	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	SV	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	SV	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	OH	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	OH	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	OH	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	OH	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	OH	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	OH	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	OH	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	OH	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	OH	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	OH	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	OH	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	OH	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	OH	1

Part Number	Part Description	Engine Type	Condition	Quantity
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	OH	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	OH	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	OH	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	OH	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	OH	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	OH	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	OH	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	OH	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	OH	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	OH	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	OH	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	OH	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	OH	1
TSG1333M75P13	SHROUD - HPT STG 1 CF6-80A	CF6-80C2, CF6-80A	OH	1
U20212CD	COUPLING	CF6-80A, CF6-50 (LMCO), CF6-50 (Boeing)	AR	1
UA538297-6	COOLER - FUEL/OIL	CF6-80A	AR	1
UA538297-6	COOLER - FUEL/OIL	CF6-80A	AR	1
UA538297-6	COOLER - FUEL/OIL	CF6-80A	OH	1
UA538297-6	COOLER - FUEL/OIL	CF6-80A	OH	1
UA538297-6	COOLER - FUEL/OIL	CF6-80A	OH	1
UA538342-2	COOLER - IDG OIL	CF6-80A	SV	1
UA538342-2	COOLER - IDG OIL	CF6-80A	AR	1
UA538728-1	COOLER - FUEL/OIL	CF6-80C2	SV	1
UA538950-4	SERVO - HEAT EXCH FUEL	CF6-80C2, CF6-80A	AR	1
UA538950-4	SERVO - HEAT EXCH FUEL	CF6-80C2, CF6-80A	SV	1
UA538950-4	SERVO - HEAT EXCH FUEL	CF6-80C2, CF6-80A	SV	1
V14100-386	VALVE - AIR SIGNAL SOLENOID	CF6-80C2	SV	1

Part Number	Part Description	Engine Type	Condition	Quantity
V4-109N	RECEPTACLE	CF6-80C2, CF6-50 (LMCO), CF6-50 (Boeing)	NS	3
V4-201N	RING - RETAINER	CF6-80C2	NE	3
VC1145A-697-A	COUPLING	CF6-50 (Boeing)	NS	1
VC1145A-697-A	COUPLING	CF6-50 (Boeing)	NS	2
VL1054GE5	SCALLOP I.D RING	CF6-80C2	NE	2
VL1133GE19-05	SEAL - METALLIC	CF6-80C2, CF6-50 (LMCO)	NE	1
VL1133GE19-05	SEAL - METALLIC	CF6-80C2, CF6-50 (LMCO)	NE	1
VL1133GE19-05	SEAL - METALLIC	CF6-80C2, CF6-50 (LMCO)	NE	1
VL1133GE19-05	SEAL - METALLIC	CF6-80C2, CF6-50 (LMCO)	NE	1
VL1186GE25-09	RING	CF6-80C2	NE	10
VL1222GE27	SEAL - RING	CF6-80C2	NE	1
VPB0007P02	RETAINING - PIN THREADED	CF6-50 (LMCO)	OH	29
VT-O306D	TRANSMITTER - FUEL PRESS	CF6-50 (LMCO)	SV	1
VT-O306D	TRANSMITTER - FUEL PRESS	CF6-50 (LMCO)	SV	1
VT-O306D	TRANSMITTER - FUEL PRESS	CF6-50 (LMCO)	AR	1
VT0306D	TRANSMITTER - OIL PRESS	CF6-50 (LMCO)	AR	1
VT0306D	TRANSMITTER - OIL PRESS	CF6-50 (LMCO)	AR	1
VT0306D	TRANSMITTER - OIL PRESS	CF6-50 (LMCO)	AR	1
VT0306D	TRANSMITTER - OIL PRESS	CF6-50 (LMCO)	AR	1
VT0306D	TRANSMITTER - OIL PRESS	CF6-50 (LMCO)	AR	1
VT0306D	TRANSMITTER - OIL PRESS	CF6-50 (LMCO)	AR	1
VT0306D	TRANSMITTER - OIL PRESS	CF6-50 (LMCO)	AR	1
VT0306D	TRANSMITTER - OIL PRESS	CF6-50 (LMCO)	AR	1
VT0306D1	TRANSMITTER - PRESS T583	CF6-80A	AR	1
VT0306D1	TRANSMITTER - PRESS T583	CF6-80A	AR	1
VT0306D1	TRANSMITTER - PRESS T583	CF6-80A	AR	1
VTA01431	BALL	CF6-50 (LMCO)	NE	1
VTA01431	BALL	CF6-50 (LMCO)	NE	2
VTA01433	LINK - BODY	CF6-50 (LMCO)	NE	1
VTA01433	LINK - BODY	CF6-50 (LMCO)	NE	4
VTA02590	ROD END	CF6-50 (Boeing)	NS	4
VTA07400C	BEARING - ROD END	CF6-80C2	NE	1
VTA07400C	BEARING - ROD END	CF6-80C2	NE	1
VTB07190	BEARING ASSY	CF6-80C2	NE	1
VTB07220	BEARING	CF6-80C2	NE	1
VTB07220	BEARING	CF6-80C2	NE	2

Part Number	Part Description	Engine Type	Condition	Quantity
VTB07220	BEARING	CF6-80C2	NE	1
VTB07220	BEARING	CF6-80C2	NE	1
VTB07220	BEARING	CF6-80C2	NE	3
VTF00100	LINK	CF6-50 (LMCO)	NE	2