

Part Number	Description	Quantity
011809	Fan Assy, Tailcone	1
066-01146-1211	TCAS Processor	1
071-01548-0200	TCAS Antenna	1
071-01548-0200	TCAS Antenna	1
10550P04Y00	Control - Refueling Panel	1
10708	GPS Antenna	1
10708	GPS Antenna	1
10866A	Cooler	1
110-337	ELT Antenna	1
12045-548-007	Hinge Assy, Lower	1
12645-131-033	Cover Assy, Elevator Disconnect	1
12845-229-043	Panel Assy, Diode/fuse	1
12945-002-018	Ram Air Duct Assy	1
12945-002-021	Duct Assy, Ram Air	1
12945-048-003	Manifold Assy, Insulated, Cockpit	1
12945-048-011	DUCT ASSY PLENUM INLET	1
12945-078-001	Tube Assy, Anti-ice	1
12945-078-005	Tube Assy, Anti-ice	1
12945-078-013	Tube Assy, Anti-ice	1
12945-078-029	Tube Assy, Anti-ice	1
12945-078-033	Tube Assy, Anti-ice	1
12945-078-037	Tube Assy, Anti-ice	1
12945-082-001	Muffler Assy, Ecs-cabin	1
12945-085-023	Manifold Assy, Outbd (Lh)	1
12945-095-004	Plenum Assy, Cabin Muffler	1
1408-00-1	FMS Data (DTU) Transfer Unit	1
1625-1-1	Trim-In-Motion Detector	1
169CA-24-13A-2.25	Coupling Assy, Gasper	1
20011958	ENGINE MOUNT ROD	1
20011958	ENGINE MOUNT ROD	1
2119560-3	Electronic Control Unit, (ECU)	1
2203826-1	Duct Assy, Turbine Inlet	1
2203827-1	DUCT ASSY	1
2203828-1	Duct Assy	1
2203833-1	Duct Assy, Turbine Bypass	1
2269H000-003	Nose Landing Gear Uplock Mechanism	1
2269H080	Switch, Status	1
2301223-2	Duct Assy, Water Separator Outlet	1
2301224-2	Shell Assy, Water Separator Inlet	1
2317046-1	Rod Assy, Nose Gear Door	1
2317048-1	Torque Tube Assy, Nose Gear Door, Fwd	1
2317058-1	Pivot, Nose Gear Door Actuator	1
2317058-1	Pivot, Nose Gear Door Actuator	1
2317058-1	Pivot, Nose Gear Door Actuator	1

Part Number	Description	Quantity
2317058-1	Pivot, Nose Gear Door Actuator	1
23280-067	Starter/Generator	1
23280-067	Starter/Generator	1
244-12135	Element, Ht Sensing	1
274-220	Adaptor, Bleeder, Brake Assy	1
2D1200-1A-1011	Ac Inverter	1
3010-00-00	Terrain Awareness Warning (TAWS) Computer	1
3017-41-221	Flight Management Control Display CDU	1
3116-52-1110	Universal Lp/Lpv Monitor	1
3202738-1	Valve, Check	1
3202738-1	Valve, Check	1
3202738-1	Valve, Check	1
3202744-1	Emergency Pressurization Isolation Check Valve	1
3202744-1	Emergency Pressurization Isolation Check Valve	1
3215612-1	Bi-Level Pressure Regulating & Shutoff (L19) Valve	1
3225072-1	Valve, Shuttle	1
3225072-1	Valve, Shuttle	1
3291222-1	Cockpit Temperature Control Valve	1
3291222-1	Cockpit Temperature Control Valve	1
3291224-1	Emergency Pressure Shutoff Valve	1
3291224-1	Emergency Pressure Shutoff Valve	1
3291228-1	Valve Acm	1
3291230-1	Valve	1
3876322-1	Isolation Valve	1
3888000-7	Ignition, APU Unit	1
3A1-279A	Nose Wheel Steering Transducer	1
3A1-279A	Nose Wheel Steering Transducer	1
3A2-249A	Spoiler RVDT	1
4005842	Servo, Pitch Bracket	1
4005842	Servo, Pitch Bracket	1
4006719-908	Autopilot, Pitch Servo	1
4006719-948	Autopilot, Roll Servo	1
4011-14	Valve, APU Bleed Air Check	1
42756-200	Joint, Slide, Flex	1
42761-150	Joint, Flex, Slide	1
4520008048V18-001	Relay Box Assy, Nose (Lh)	1
4520008055V18-001	Relay Box Assy, Nose (Rh)	1
4520008405V45-001	Tail Cone Relay (P13) Panel	1
4521200025-001	Shroud Assy, Fan Exit (Lh)	1
4522208501-017	Panel Assy, Trim Switch	1
4523188545-081	LH Switch Panel	1

Part Number	Description	Quantity
4523558501-005	Panel Assy, Audio Control-cockpit	1
4524003015-005V1804	Box Assy, Landing Gear, Interconnect	1
4524088502-005	Ckt Brkr Pnl Assy, Aft-opt	1
45246080020p05x03	Pilot Circuit Breaker Panel	1
45246080030p05x03	Copilot Circuit Breaker Panel	1
4524608021V12-001	Panel Assy, Circuit Breaker	1
4525108092v55	Enviromental Control Panel	1
4525130004-001	Heel Plate Assy, Foot Warmer	1
4525130004-001	Heel Plate Assy, Foot Warmer	1
4525130004-001	Heel Plate Assy, Foot Warmer	1
4525130004-001	Heel Plate Assy, Foot Warmer	1
4525203191-005	TRIM, DOOR LATCH, ENTRY DOOR	1
4525500288-005	Support Assy, Lh	1
4525500288-006	SUPPORT BRACKET	1
4526208506-005	Tube Assy, Eng Fire Ext Sys	1
4526208506-005	Tube Assy, Eng Fire Ext Sys	1
4526208506-005	Tube Assy, Eng Fire Ext Sys	1
4526208506-005	Tube Assy, Eng Fire Ext Sys	1
4527202001V15-001	Pedal Assy, Rudder	1
4527202001V15-001	Pedal Assy, Rudder	1
4527202200-001	Shroud Assy, Rudder Pedal, Fwd	1
4527202202v3-001	Pedal Shroud Assy	1
4527302112-003	Shaft, Control Column (Rh)	1
4527408503-027	Forward Interface Unit	1
4528430002-815	Relay Box, Squat Switch	1
4529101001-007	Reservoir Assy, Hydraulic	1
4529102086-001	Tube Assy, Hydraulic Supply (Rh)	1
4529308000V5-001	P17, HYD GRND SERVICE PANEL	1
4531108502-035	Forward Quadrant Switch Panel (P6) Overlay	1
4531588538-001	Panel Assy, Switch, Elt	1
4531588544-001	Plate Assy, Mounting, Elt	1
4532403040-005	Brake Accumulator Assembly	1
4532430002-803	Adapter Plate	1
4532508502-003	Nose Wheel Steering Box Installation Filter	1
4533108543-011	Box Assy, Misc Relay	1
4533108552-007	Panel Assy, Fuse	1
4533488524-013	Relay Options Panel Assy	1
4533508501V3-001	Module Assy, Els Activation	1
4534508109-003	Plate, Mounting	1
453-5000-366	ELT Emergency Locator Transmitter	1
4536102027-009	Manifold Assy, Center	1
4536102041-003	Manifold Tube Assembly	1
4536102080V20-005	Tube, Assy	1
4536102090-001	Tube Assy, Sense Line (Rh)	1

Part Number	Description	Quantity
4549058029-001	TUBE ASSY	1
4549058044-001	Tube Assembly	1
4549058044-009	TUBE ASSY	1
4552800001-005	Nose Landing Gear Door	1
4552800002-005	Nose Landing Gear Door	1
4552803004-003	Main Landing Gear Door	1
4552803004-004	Main Landing Gear Door	1
4553208014-002	Plate	1
4555301000v6-001	Box Assy, Relay	1
4557000001V1087-1	Tube Assembly	1
4557000001V1087-3	TUBE ASSY	1
4557500118-003	Track Assy, Primary, Center Flap	1
4557500118-003	Track Assy, Primary, Center Flap	1
4571200011-003	Engine Forward Mount	1
4571200011-003	Mount, Engine, Fwd	1
4576108500-023	Engine Fuel Control (P7) Panel Assy	1
5273-00-5	Nacelle Inlet Anti-Ice Shutoff Valve	1
5273-00-7	Pressure Regulating Shutoff Valve	1
53A405-4	Engine Ozone Converter	1
53A405-4	Engine Ozone Converter	1
63024-1	GEARBOX 90 DEGREE	1
63024-1	GEARBOX 90 DEGREE	1
63026-1	ROTARY OUTPUT ELEMENT (LH)	1
63026-2	Output Element, Rotary (Rh)	1
641178-2	Switch, Overtemp, Compressor, Acn	1
641179-4	HP Over-Temp Switch	1
641179-4	HP Over-Temp Switch	1
650GC02Y03	Power Distribution Panel	1
650GC02Y03	Power Distribution Panel	1
6600245-3	Regulator, Pressure, Servo Air	1
6600504-2	Engine Accelerometer	1
6600504-2	Engine Accelerometer	1
6608295-3	Servo Air Check Valve	1
66157-02	Auxiliary Hydraulic Pump Assembly	1
6621000000-001	CHECK VALVE	1
6621000000-001	CHECK VALVE	1
6621000000-037	Cockpit Air Check Valve	1
6621000000-079/642019-3	SWITCH, PRESS-BLEED AIR	1
6621000000-087	Anti-Ice Pressure Regulating Shutoff (PRSOV L12) Valve	1
6621000000-087	Anti-Ice Pressure Regulating Shutoff (PRSOV L12) Valve	1
6621300000-019	Primary Outflow Valve	1
6621300000-021	Valve Assy, Outflow	1
6622500001-003	Yaw Force, Rudder Boost System. Sensor	1

Part Number	Description	Quantity
6626100000-003	Bleed Air Leak (A76) Detection Unit	1
6626100000-003	Bleed Air Leak (A76) Detection Unit	1
6626100000-003	Bleed Air Leak (A76) Detection Unit	1
6627308500-001	Angle Of Attack (AOA) Transmitter	1
6627308500-001	Angle Of Attack (AOA) Transmitter	1
6627308500-009	Stick Shaker	1
6627308500-009	Stick Shaker	1
6627308500-011	Angle Of Attack (AOA) Indicator	1
6627308500-013	Stall Warning Computer	1
6627401000-003	Horizontal Stab Actuator Control Box Assembly	1
6627503000-031	Flap Actuator	1
6627503000-031	Flap Actuator	1
6627503000-033	Flap Actuator	1
6627602002-005	Spoiler Shutoff Valve	1
6628200301-001	Fuel Main Ejector Pump Assembly	1
6628200301-001	Fuel Main Ejector Pump Assembly	1
6628200303-001	Fuel, Standby Pump	1
6628200303-001	Fuel, Standby Pump	1
6628408000-003	Fuel C2 Probe	1
6628408000-005	Fuel C3 Probe	1
6628408000-005	Fuel C3 Probe	1
6628408000-007	Fuel C4 Probe	1
6628408000-007	Fuel C4 Probe	1
6628408000-009	Fuel C12 Probe	1
6628408000-009	Fuel C12 Probe	1
6628408000-011	Fuel Probe	1
6628408000-011	Fuel Probe	1
6628408000-011	Fuel Probe	1
6628408000-011	Fuel Probe	1
6628408000-021	Fuel C15 Probe	1
6628408000-021	Fuel C15 Probe	1
6628408000-023	Fuel Quantity Signal Conditioner	1
6628408000-027	Fuel C2 Probe	1
6629001002-005	Control Module, Reservoir	1
6629101000-001	Hydraulic, Engine Driven Pump	1
6629101000-001	Hydraulic, Engine Driven Pump	1
6629101004-001	Auxiliary Pressure, Hydraulic System (S29) Switch	1
6629101004-001	Auxiliary Pressure, Hydraulic System (S29) Switch	1
6629201001-005	Manifold, Assy, Filter-aux	1
6631508501-001	Crew Warning Panel Assembly	1
6632302001-003	Landing Gear Control Valve	1
6632303004-003	Main Landing Gear Uplock Mechanism	1

Part Number	Description	Quantity
6632303004-004	Main Landing Gear Uplock Mechanism	1
6632401001-003	Transducer Assy, Right Pedal	1
6632401001-003	Transducer Assy, Right Pedal	1
6632401001-005	Transducer ASSY, Wheel Speed	1
6632401001-005	Transducer ASSY, Wheel Speed	1
6632401001-005	Transducer ASSY, Wheel Speed	1
6632401001-005	Transducer ASSY, Wheel Speed	1
6632401001-009	Anti-Skid Control Valve	1
6632401001-009	Anti-Skid Control Valve	1
6632401001-013	Hydraulic, Brake Fuse	1
6632401001-013	Hydraulic, Brake Fuse	1
6632401001-017	(M69) Pressure Brake Transducer Assembly	1
6632401001-019	(MT56) Pressure Brake Transducer Assembly	1
6632401001-019	(MT56) Pressure Brake Transducer Assembly	1
6632401002-011	Emergency/Park Brake Valve	1
6632401003-001	Shuttle Module, Anti-Skid, Brake	1
6633108500-001	Unit, Lighting Control	1
6633108500-001	Unit, Lighting Control	1
6633208504-013	Entry Control W/Pylon Light Panel	1
6636108500-3	Ecs Controller	1
6673308500-003	Dual Fuel Flow Convertor (DFFC)	1
6676101000-027	Module, Flap Control	1
6900135-001	Dimmer Control Box	1
7010133	Flux Valve	1
7010133	Flux Valve	1
7012098-902	Servo, Yaw Bracket	1
7012919-904	Autopilot, Yaw Servo	1
7013270-985	Radio Management (RMU) Unit	1
7013270-985	Radio Management (RMU) Unit	1
7013348-931	Data Acquisition (DAU) Unit	1
7014300-901	DISPLAY UNIT	1
7014331-715	Mfd Controller Bezel	1
7014331-715	Mfd Controller Bezel	1
7014332-831	Mfd Controller Bezel	1
7014700-606	Computer, Air Data	1
7014700-606	Computer, Air Data	1
7016986-733	EFIS Display Controller	1
7016986-733	EFIS Display Controller	1
7017000-82222	Integrated Computer	1
70210-2215150-2	ENVIRONMENTAL CONTROL UNIT	1
7021450-801	Weather Radar Transceiver	1
7088000-1	APU, Cockpit Control Panel	1

Part Number	Description	Quantity
71825-7	Aft Throttle Cable	1
71845-10	Fwd Throttle Cable	1
7510100-631	Integrated Navigation Unit	1
7510733-676	Unit, Vhf Communication	1
7510733-676	Unit, Vhf Communication	1
7511001-937	Audio Control Unit	1
7513000-835	Clearance Delivery Unit	1
7600020-1	Engine Nacelle Anti-Ice Pressure Switch	1
7600020-1	Engine Nacelle Anti-Ice Pressure Switch	1
7600021-001	Transducer, Fuel Flow	1
7624608500-017	Fwd Circuit Breaker Panel Overlay	1
7624608501-009	Aft Circuit Breaker Panel Overlay	1
7624608502-017	Ovrly Assy, Fwd Cb Pnl-cplt	1
7632401002-001	Brake Shuttle Valve	1
7632401002-001	Brake Shuttle Valve	1
7638300002-001	Toilet Service Panel	1
7653206201-010	Crew Floorboard Panel Assy, RH	1
7653206205-003	Crew Floorboard Panel Assy	1
7653206207-005	Crew Floorboard Panel Assembly LH	1
7676108500-007	Throttle Quadrant Overlay Panel	1
778D100-11	Elevator Override (L45) Actuator	1
877-01032	Fire Detect Control Unit	1
877-01032	Fire Detect Control Unit	1
88746-1	Main Hydraulic System Accumulator	1
90278-2	AC 5 KVA Alternator	1
90280-1	Qad Kit, Alternator	1
90280-1	Qad Kit, Alternator	1
91816/EM91-102-2	Fuel Supply (Defuel)(B24) Shutoff Valve Assembly	1
91816/EM91-102-2	Fuel Supply (Defuel)(B24) Shutoff Valve Assembly	1
91816/EM91-102-2	Fuel Supply (Defuel)(B24) Shutoff Valve Assembly	1
920040	Cabin Airshow Display Computer Unit	1
922000-2	Airshow Flight Deck Controller	1
980-6020-011	Cockpit Voice Recorder	1
AN824-4J	Tee, Flared Tube	1
AN834-4J	Tee, Flared Tube	1
APTE-196-1000-4000A	Hydraulic Pressure Transducer	1
AS117-04K0135	Hose Assy	1
C145159-1	Flap Position Indicator	1
C352	Portable Fire Extinguisher	1
C-38805-1	Angle Of Attack (AOA) Indicator	1
DMC60-17-1	Antenna ASSY	1

Part Number	Description	Quantity
DMN150-2-2	ATC Antenna	1
DMN150-2-2	ATC Antenna	1
DMN150-2-2	ATC Antenna	1
DMN150-2-2	ATC Antenna	1
DMN150-2-2	ATC Antenna	1
DMN27-3	Marker Beacon Antenna	1
DMN4-17-1/N	VOR/Localizer Antenna	1
DMN4-17-1/N	VOR/Localizer Antenna	1
EM91-102-2	Motorized Shutoff Valve	1
HG2010AC02	Attitude Heading Reference Computer (AHRS)	1
HG2010AC02	Attitude Heading Reference Computer (AHRS)	1
HTE460071	Fuel Supply Check Valve	1
LJ01212-002	Assembly, HP Nacelle Bleed Air Manifold	1
LJ01317-001	HP Bleed Air Tube Assembly	1
LJ7836701-5	Thrust Reverser Harness, Outbd	1
LJ7836706-3	T/R Control Unit	1
M6904/2-1	Horn, Warning	1
M850-5V-LA	DAVTRON CLOCK	1
M850-5V-LA	DAVTRON CLOCK	1
P12948	Air Call Antenna	1
P34110-003	AVANCE L3 LRU	1
P40-791	Valve, Shutoff, Hydraulic And Fuel	1
R23496D	Push Rod Assy, Rudder Control	1
R23496F	Push Rod Assy, Rudder Control	1
R23496F	Push Rod Assy, Rudder Control	1
S67-1575-109	Iridium Gps Antenna, Passive	1
S67-2002-4	Radar Altimeter Antenna	1
S67-2002-4	Radar Altimeter Antenna	1
SLOOT3.063X1.875	Hose, APU Starter	1
4557500006-008	RH Flap	1
4557700003-021	LH Spoiler	1
4557700003-022	RH Spoiler	1
2652000V25-001	LH Inlet	1
2652000V25-003	RH Inlet	1