

Part Number	Part Description	A/C Type	Condition	Quantity
335205040	COOLING FAN	B737	SVC	1
066-1123-00	ATC TRANSPONDER	B737	SVC	1
066-1123-00	ATC TRANSPONDER	B737	SVC	1
066-1123-00	ATC TRANSPONDER	B737	SVC	1
066-1123-00	ATC TRANSPONDER	B737	SVC	1
066-1123-00	ATC TRANSPONDER	B737	SVC	1
066-1123-00	ATC TRANSPONDER	B737	SVC	1
066-1123-00	ATC TRANSPONDER	B737	SVC	1
066-1123-00	ATC TRANSPONDER	B737	SVC	1
066-1123-00	ATC TRANSPONDER	B737	SVC	1
07311P000-02	FLAP SCREW ASSY	B737	OH	1
10033-0000-02	HYD OIL QTY INDICATOR	B737	REP/AR	1
10470-2	HYDRAULIC PUMP	B737	SVC	1
108032-8	AIR PRESSURE REGULATOR - RL	B737	SVC	1
124833	DC VOLTMETER	B737	SVC	1
124835	FEQUENCY METER - CSD, RPM	B737	SVC	1
124835	FEQUENCY METER - CSD, RPM	B737	SVC	1
124835	FEQUENCY METER - CSD, RPM	B737	SVC	1
124837	AC AMMETER	B737	SVC	1
1316200-3	BRAKE METERING VALVE	B737	REP/AR	1
1316200-3	BRAKE METERING VALVE	B737	SVC	1
1316200-3	BRAKE METERING VALVE	B737	REP/AR	1
1316200-3	BRAKE METERING VALVE	B737	SVC	1
152050-5-1	OIL COOLER	B737	SVC	1
162BL804A	ENGINE OIL T2 INDICATOR	B737	SVC	1
1697EA	SELSCT AEROFREIN	B737	SVC	1
170079-100	EVENT MONITORING UNIT	B737	SVC	1
170079-100	EVENT MONITORING UNIT	B737	SVC	1
17-12	ANTENA	B737	AR	1
172935-001	RELAY - AUDIO SWITCHING	B737	SVC	1
179625-1	START PURGE SOLENOID	B737	SVC	1
182936	INDICATOR - OXYGEN PRESS	B737	SVC	1
196K08-9	BEECH 1900 NOSE TYRE	B737	NS	29
196K08-9	BEECH 1900 NOSE TYRE	B737	NS	24
1U1065-2	COMPENSATOR HYD	B737	REP/AR	1
1U1065-2	COMPENSATOR HYD	B737	REP/AR	1
1U1065-2	COMPENSATOR HYD	B737	REP/AR	1
1U1065-2	COMPENSATOR HYD	B737	OH	1
1U1065-2	COMPENSATOR HYD	B737	OH	1
20043-0000-01	TRANS QTY HYD SYST A	B737	SVC	1
2041234-3446	VHF NAV RECEIVER	B737	SVC	1
2041237-4417	VHF COM TRANSCEIVER	B737	SVC	1
2041237-4417	VHF COM TRANSCEIVER	B737	SVC	1
2041237-4417	VHF COM TRANSCEIVER	B737	SVC	1
2041237-4417	VHF COM TRANSCEIVER	B737	SVC	1
2041600-6503	ATC CONTROL PANEL	B737	SVC	1
2056-01-1AF	ALTIMETER ELECTRIC	B737	REP/AR	1

2056-01-1AF	ALTIMETER ELECTRIC	B737	REP/AR	1
2070410-0101	RADAR	B737	SVC	1
2070410-0101	RADAR	B737	SVC	1
2229346-3	DISPLAY UNIT - ACARS	B737	REP/AR	1
2229346-3	DISPLAY UNIT - ACARS	B737	REP/AR	1
2229346-3	DISPLAY UNIT - ACARS	B737	REP/AR	1
2229346-3	DISPLAY UNIT - ACARS	B737	SVC	1
2229346-3	DISPLAY UNIT - ACARS	B737	REP/AR	1
2231000-3A	DIGIT. FLIGHT DATA ACQ UN	B737	SVC	1
2231600-3A	MANAGEMENT UNIT - ACARS	B737	REP/AR	1
2231600-3A	MANAGEMENT UNIT - ACARS	B737	REP/AR	1
2231600-3A	MANAGEMENT UNIT - ACARS	B737	SVC	1
2231600-3A	MANAGEMENT UNIT - ACARS	B737	SVC	1
2300-01-1	INDICATOR - FUEL QTY	B737	SVC	1
241YH35	PRIM MOTEUR AC	B737	SVC	1
247F02G1	TIRE 27X7.7 10PR DT 225MPH	B737	NS	26
2-541501-1A	SNUBBER ASSY	B737	OH	1
2661-03	GAUGE	B737	NS	10
30-0906-104	STROBE LIGHT RIGHT	B737	SVC	1
3105414-02	TUBER TRANSFER	B737	NS	2
310A1041-7	BOLT - CONE	B737	NS	1
320115	VALVE ASSY	B737	SVC	1
320115	VALVE ASSY	B737	OH	1
320115	VALVE ASSY	B737	OH	1
320115	VALVE ASSY	B737	OH	1
32-2861-001	VALVE - PURGE LINE SHUTOFF	B737	OH	1
335-302-402-0	GEAR SHAFT 62 AGB	B737	NS	1
3602310-32-1	FUEL CONTROL UNIT 85- 98CK	B737	AR	1
371380	ENGINE PUMP HYDRAULIC	B737	OH	1
371380	ENGINE PUMP HYDRAULIC	B737	OH	1
371380	ENGINE PUMP HYDRAULIC	B737	OH	1
371380	ENGINE PUMP HYDRAULIC	B737	OH	1
378201-12	POMPE CARBURANT	B737	SVC	1
4084042-911	YAW - DAMPER COUPLER	B737	AR	1
4084042-911	YAW - DAMPER COUPLER	B737	AR	1
4084042-911	YAW - DAMPER COUPLER	B737	AR	1
4084042-911	YAW - DAMPER COUPLER	B737	AR	1
409K02-2	MAIN WHEEL TIRE TIRE SIZE H40X14.0-19 20PR 225MPH	B737	NS	70
409K02-2	MAIN WHEEL TIRE TIRE SIZE H40X14.0-19 20PR 225MPH	B737	NS	5
417N3100-293H	PSU ASSY GAUCHE HP	B737	SVC	1
417N3100-293H	PSU ASSY GAUCHE HP	B737	SVC	1
417N3100-294H	PSU	B737	SVC	1

417N3100-294H	PSU	B737	SVC	1
417N3100-294H	PSU	B737	SVC	1
417N3100-296	PSU	B737	SVC	1
417N3100-331A	PSU	B737	SVC	1
417N3100-335A	PSU	B737	AR	1
417N3100-519C	PSU	B737	SVC	1
436-2	HYD PUMP CONTROLLER ASSY	B737	SVC	1
436-2	HYD PUMP CONTROLLER ASSY	B737	SVC	1
4500133	COOLING FAN	B737	SVC	1
4500133	COOLING FAN	B737	SVC	1
4500133	COOLING FAN	B737	SVC	1
452100-02-03	MODE SELECTOR UNIT	B737	SVC	1
458900-07	CDU-LTN 92	B737	REP/AR	1
458900-07	CDU-LTN 92	B737	REP/AR	1
473048	FUEL SUMMATION UNIT	B737	SVC	1
473048	FUEL SUMMATION UNIT	B737	SVC	1
5011166	MAIN WHEEL ASSY	B737		1
5060-3	BRAKE VALVE SHUTTLE	B737	NS	1
5060-3	BRAKE VALVE SHUTTLE	B737	NS	1
512776	AURAL WARNING BOX	B737	SVC	1
522-1501-000	HF.TRANSCEIVER	B737	SVC	1
522-1501-041	HF.TRANSCEIVER	B737	SVC	1
522-1859-003	INDIC DME 339D1	B737	SVC	1
522-1859-033	INDIC DME 339D1	B737	SVC	1
522-1859-033	INDIC DME 339D1	B737	SVC	1
522-2213-043	PANEL H F	B737	SVC	1
522-2213-047	PANEL H F	B737	OH	1
522-4538-002	PUBLIC ADDRESS AMPLIFIER	B737	SVC	1
522-4703-002	STEERING COMPUT 562A-5F5	B737	SVC	1
548376-6	PACK/ZONE TEMPERATUR CONT	B737	REP/AR	1
548376-6	PACK/ZONE TEMPERATUR CONT	B737	REP/AR	1
5865-656-8	BRAKE TEMPERATURE INDICATOR	B737	SVC	1
607400-1-1	CABIN TEMPERATURE SELECT	B737	SVC	1
607518-2	RAM AIR CONTROLLER	B737	REP/AR	1
607518-2	RAM AIR CONTROLLER	B737	SVC	1
622-8594-121	ATC CONTROL PANEL	B737	SVC	1
622-8594-121	ATC CONTROL PANEL	B737	SVC	1
623337	ENGINE PUMP HYDRAULIC	B737	SVC	1
623337	ENGINE PUMP HYDRAULIC	B737	SVC	1
623337	ENGINE PUMP HYDRAULIC	B737	SVC	1
65075-06	HYDRAULIC PUMP	B737	SVC	1
65-44503-5	ELEVATOR FEEL ACTUATOR	B737	SVC	1
65-44561-15	ACTUATOR	B737	REP/AR	1
65-44691-5	MLG MODULAR ASSY	B737	SVC	1
65-44691-5	MLG MODULAR ASSY	B737	SVC	1
65-44691-5	MLG MODULAR ASSY	B737	SVC	1
65-44691-5	MLG MODULAR ASSY	B737	SVC	1
65-44691-5	MLG MODULAR ASSY	B737	SVC	1
65-44691-6	NLG MODULAR ASSY	B737	SVC	1
65-44761-16	AIL EL POWER CONTROL UNIT	B737	SVC	1

65-44761-16	AIL EL POWER CONTROL UNIT	B737	SVC	1
65-44761-21	AIL EL POWER CONTROL UNIT	B737	SVC	1
65-44810-5	RIGHT MLG LOCK ACTUATOR	B737	SVC	1
65-44891-7	MODULE HYDR C.D.V.	B737	OH	1
65-44891-7	MODULE HYDR C.D.V.	B737	SVC	1
65-44891-7	MODULE HYDR C.D.V.	B737	SVC	1
65-44891-7	MODULE HYDR C.D.V.	B737	SVC	1
65-45121-77	COLUMN AND WHEEL ASSY	B737	SVC	1
65-46102-21	TORSION LINK LW	B737	SVC	1
65-46102-21	TORSION LINK LW	B737	SVC	1
65-46106-7	UNIVERSAL LWR SIDE STRUT	B737	REP/AR	1
65-46106-7	UNIVERSAL LWR SIDE STRUT	B737	OH	1
65-46108-17	ACTUATOR BEAM ASSY	B737	REP/AR	1
65-46108-3	ACTUATOR BEAM ASSY	B737	OH	1
65-46109-12	ACTUATOR BEAM ASSY	B737	OH	1
65-46109-18	ACTUATOR BEAM ARM ASSY	B737	OH	1
65-46112-30	SUPPORT LINK ASSY	B737	REP/AR	1
65-46141-10	MLG UP LOCK ASSY RH	B737	REP/AR	1
65-46141-12	MLG LOCK ASSY RH	B737	REP/AR	1
65-46245-8	LOCK LINK ASSY	B737	REP/AR	1
65-52801-31	APU CONTROL UNIT	B737	OH	1
65-52808-6	BOITE DETECTION SURCHAUFF	B737	SVC	1
65-52818-9	AUTO SLAT COMPUTER	B737	SVC	1
65-54200-12	AIR ART FEEL CENTERING	B737	SVC	1
65-63397-3	LOWER SIDE STRUT ASSY	B737	SVC	1
65-63663-3	BELLCRANK ASSY	B737	OH	1
65-6868-1	GIMBAL	B737	NS	1
65-79749-7	MODULE	B737	SVC	1
658385-001	P.R.B.C. VALVE	B737	OH	1
65-84161-4	NUT AFT TRUNNION	B737	OH	1
65C16839-122	BLOC SERVICE PAX	B737	REP/AR	1
65C26864-2	GROUND SPOILER ACTUATOR	B737	SVC	1
65C26864-2	GROUND SPOILER ACTUATOR	B737	SVC	1
65C26869-2	AUTO SLAT CTRL VALVE	B737	SVC	1
66030-5	VALVE-TIME CONTROLLED	B737	REP/AR	1
67-2905-001	BLEED AIR INSOLATION VALVE	B737	SVC	1
67-2905-001	BLEED AIR INSOLATION VALVE	B737	SVC	1
67-2905-001	BLEED AIR INSOLATION VALVE	B737	SVC	1
67-2905-001	BLEED AIR INSOLATION VALVE	B737	SVC	1
67-2905-001	BLEED AIR INSOLATION VALVE	B737	SVC	1
67-2905-001	BLEED AIR INSOLATION VALVE	B737	SVC	1
67940-2	VALVE DE VOLTS BF	B737	SVC	1

69-37314-28	MODU AC SYST GEN+APU P5-4	B737	SVC	1
69-37325-137	FLIGHT RECORD MODULEP5-19	B737	SVC	1
69-37325-168	FLIGHT RECORD MODULEP5-19	B737	REP/AR	1
69-37325-52	MOD ASSY FLIGHT P5-19	B737	SVC	1
69-37338-34	MODULE ASSY AUX VERT GYRO	B737	NS	1
69-37339-25	STALL WARNING COMPUTER	B737	SVC	1
69-37352-30	DOOR WARNING MODULE	B737	SVC	1
69-41248-3	RH TRUNNION PIN	B737	NS	1
69-54600-4	CYLINDER ASSEMBLY	B737	SVC	1
69-68151-1	BOLT ASSY LWR SIDE STRUT	B737	REP/AR	1
69-73176-2	FUSE BOLT FD.TRUNNION 77R	B737	OH	1
69-73713-15	IRS MODE SELECTOR MODULE	B737	SVC	1
711002-5	PRESSURE CONTROL PANEL	B737	REP/AR	1
711002-5	PRESSURE CONTROL PANEL	B737	REP/AR	1
711003-3	OUTFLOW VALVE ARRIERE	B737	REP/AR	1
7740-01	DETECTEUR DE FUMEE	B737	SVC	1
777-1493-004	A D F CONTROL PANEL	B737	SVC	1
787-6366-009	ADF CTRL PANEL	B737	SVC	1
838550-401	OVEN	B737	SVC	1
8921082G5	LAVATORY WATER HEATER	B737	SVC	1
8921082G5	LAVATORY WATER HEATER	B737	SVC	1
8921082G5	LAVATORY WATER HEATER	B737	SVC	1
8921082G5	LAVATORY WATER HEATER	B737	SVC	1
915F212-6	GENERATOR CONTROL UNIT	B737	REP/AR	1
93A152-20	MIC.MONITOR CONTROL PANEL	B737	SVC	1
9550169260	ANTI SURGE VALVE	B737	OH	1
9550169260	ANTI SURGE VALVE	B737	OH	1
965-0648-007	GPWC	B737	SVC	1
965-0648-007	GPWC	B737	SVC	1
965-0648-007	GPWC	B737	SVC	1
965-0648-007	GPWC	B737	SVC	1
965-0657-073	DFDAMU	B737	SVC	1
965-0657-073	DFDAMU	B737	SVC	1
976J498-1	AC GENERATOR	B737	SVC	1
980-6005-062	COCKPIT VOICE RECORDER	B737	SVC	1
A4619710004	ALTIMETER-STANDBY	B737	SVC	1
A61499A	VLV PRESS RELIEF STBY	B737	SVC	1
AV16E1167C	VALVE ASSY MOTOR EQ25	B737	SVC	1
C12377AC02	CONTROL PANEL-HUD	B737	SVC	1
C12377AC02	CONTROL PANEL-HUD	B737	REP/AR	1

C12377AC02	CONTROL PANEL-HUD	B737	REP/AR	1
C12377AC02	CONTROL PANEL-HUD	B737	REP/AR	1
C19004AA	OPTICAL PROJECTOR UNIT	B737	REP/AR	1
C19004AA	OPTICAL PROJECTOR UNIT	B737	REP/AR	1
C19004AA	OPTICAL PROJECTOR UNIT	B737	SVC	1
C19004AA	OPTICAL PROJECTOR UNIT	B737	REP/AR	1
C19006AA01	HEAD UP FLIGHT DISPLAY	B737	SVC	1
C19006AA01	HEAD UP FLIGHT DISPLAY	B737	REP/AR	1
C19006AA01	HEAD UP FLIGHT DISPLAY	B737	REP/AR	1
C19006AA01	HEAD UP FLIGHT DISPLAY	B737	REP/AR	1
C19009AA	COMBINER UNIT	B737	SVC	1
C19009AA	COMBINER UNIT	B737	REP/AR	1
C19009AA	COMBINER UNIT	B737	REP/AR	1
C19009AA	COMBINER UNIT	B737	REP/AR	1
C7088-1A	GEAR BOX, ASSEMBLY	B737	AR	1
CG1137AC01	MODE SELECT UNIT	B737	SVC	1
CG1137AC01	MODE SELECT UNIT	B737	REP/AR	1
ED41A200	DFDAMU	B737	SVC	1
G2581-03	SELCAL CTRL PANEL	B737	SVC	1
G6317-05	VHF/COM PANEL	B737	SVC	1
G6317-05	VHF/COM PANEL	B737	SVC	1
G6317-05	VHF/COM PANEL	B737	SVC	1
GP10-72	TIRE PRESSURE INDICATOR	B737	NS	3
H504A	DUAL CONTR SURF TRANSM	B737	REP/AR	1
H504A	DUAL CONTR SURF TRANSM	B737	REP/AR	1
H504A	DUAL CONTR SURF TRANSM	B737	REP/AR	1
MS9-3911-30ZE	IN & OUT FLAT HYD ACTUATO	B737	SVC	1
RDAX7010	TAPE REPRODUCER	B737	SVC	1
RDAX7010	TAPE REPRODUCER	B737	SVC	1
RDAX7670AF03	SSAR	B737	REP/AR	1
666000158	MOTOR	B737	NS	1
666000158-1	MOTOR	B737	NS	1
523223	INDICATOR	B737	SVC	1
70185-1	VALVE	B737	OH	1
2593191-804	RMI	B737	SVC	1
9B40-27A	TRANSPONDER	B737	SVC	1
114031002	ACTUATOR	B737	SVC	1
S2431005000100	INLET	B737	SVC	1
SEL0C4W	INDICATOR-OIL PRESSURE	B737	SVC	1
SEL0C4W	INDICATOR-OIL PRESSURE	B737	SVC	1
SEL0C4W	INDICATOR-OIL PRESSURE	B737	SVC	1
SRDL0C7E	INDICATOR-HYDR.PRESS.DUAL	B737	SVC	1
TK300001	TROLLEY	B737	NS	24
WL202EED4	INDICATOR-TEMPERATURE	B737	SVC	1

WL202EED4	INDICATOR-TEMPERATURE	B737	SVC	1
WL202EED4	INDICATOR-TEMPERATURE	B737	SVC	1