

Part Number	Part Description	A/C Type	Condition	Quantity
11787-103	POWER DRIVE UNIT	B747-200	ASR	1
11787-103	POWER DRIVE UNIT	B747-200	ASR	1
11787-103	POWER DRIVE UNIT	B747-200	ASR	1
11790-101	POWER DRIVE UNIT	B747-200	ASR	1
11790-201	POWER DRIVE UNIT	B747-200	ASR	1
11790-201	POWER DRIVE UNIT	B747-200	ASR	1
11790-201	POWER DRIVE UNIT	B747-200	ASR	1
65B2102-1	POWER DRIVE UNIT	B747-200	ASR	1
65B62106-11	POWER DRIVE UNIT	B747-200	ASR	5
65B63815-1	POWER DRIVE UNIT	B747-200	ASR	1
69B63080-1	POWER DRIVE UNIT	B747-200	ASR	1
938352518000-4	COWL DOOR ACTR T/R	B747-200	ASR	1
938352518000-4	COWL DOOR ACTR T/R	B747-200	ASR	1
719223-4	TURBINE BYPASS VALVE	B747-200	ASR	1
719223-4	TURBINE BYPASS VALVE	B747-200	ASR	1
60-72301-3	MOTOR IMPELLER SUB ASSY	B747-200	ASR	1
60-72301-3	MOTOR IMPELLER SUB ASSY	B747-200	ASR	1
60-72301-3	MOTOR IMPELLER SUB ASSY	B747-200	ASR	1
60-72301-3	MOTOR IMPELLER SUB ASSY	B747-200	ASR	1
ACREM1A	MEGAPHON	B747-200	ASR	1
L83A603	VALVE	B747-200	ASR	1
L83A603	VALVE	B747-200	ASR	1
L83A603	VALVE	B747-200	ASR	1
L83A603	VALVE	B747-200	ASR	1
L83A603	VALVE	B747-200	ASR	1
L83A603	VALVE	B747-200	ASR	1
L83A603	VALVE	B747-200	ASR	1
3320650-1	ACTUATOR SPOILER	B747-200	ASR	1
12129-101	CARGO LOADING CONTROLLER/AFT	B747-200	ASR	1
12129-101	CARGO LOADING CONTROLLER/AFT	B747-200	ASR	1
12129-101	CARGO LOADING CONTROLLER/AFT	B747-200	ASR	1
12129-101	CARGO LOADING CONTROLLER/AFT	B747-200	ASR	1

Part Number	Part Description	A/C Type	Condition	Quantity
12129-101	CARGO LOADING CONTROLLER/AFT	B747-200	ASR	1
12129-101	CARGO LOADING CONTROLLER/AFT	B747-200	ASR	1
12129-101	CARGO LOADING CONTROLLER/AFT	B747-200	ASR	1
12129-101	CARGO LOADING CONTROLLER/AFT	B747-200	ASR	1
12129-101	CARGO LOADING CONTROLLER/AFT	B747-200	ASR	1
12129-101	CARGO LOADING CONTROLLER/AFT	B747-200	ASR	1
12129-101	CARGO LOADING CONTROLLER/AFT	B747-200	ASR	1
60-72301-3	MOTOR IMPELLER SUB ASSY	B747-200	ASR	1
60-72301-3	MOTOR IMPELLER SUB ASSY	B747-200	ASR	1
60-72301-3	MOTOR IMPELLER SUB ASSY	B747-200	ASR	1
1387T100-7	ROTARY ACTUATOR	B747-200	ASR	1
2117180-2	CABIN PRESSURE CONT	B747-200	ASR	1
HG280D80	COMPUTER	B747-200	ASR	1
APE927	TIME BASE UNIT	B747-200	ASR	1
777-1492-003	ADF RECEIVER	B747-200	ASR	1
2070750-3301	RECEIVER	B747-200	ASR	1
3010-00-00	TAWS COMPUTER	B747-200	ASR	1
61040-102	AF & VLA COMPUTER	B747-200	ASR	1
614937-10	COMPASS SYSTEM RACK	B747-200	ASR	1
522-4088-203	VHF TR	B747-200	ASR	1
2041234-3445	RECEIVER - VOR/ILS 1	B747-200	ASR	1
2222601	EFDARS Flight Data Acquisition Unit	B747-200	ASR	1
822-1045-301	VHF TRANSCEIVER	B747-200	ASR	1
60B00025-40	Cabin Pressure Controller	B747-200	ASR	1
60B00013-483	Landing Control and Logic Unit	B747-200	ASR	1
2593360-908	Landing Control and Logic Unit	B747-200	ASR	1

Part Number	Part Description	A/C Type	Condition	Quantity
65B47572-39	Auto Flight Control Accessory Box	B747-200	ASR	1
7886800-151	PMS Computer Unit	B747-200	ASR	1
60B00026-31	Zone Temperature Controller	B747-200	ASR	1
617154-5	Window Heat Controller Unit	B747-200	ASR	1
617154-5	Window Heat Controller Unit	B747-200	ASR	1
60B00026-31	Zone Temperature Controller	B747-200	ASR	1
522-4538-002	AMPLIFIR	B747-200	ASR	1
65B47573-65	Auto Flight Control Accessory Box	B747-200	ASR	1
7891760-041	PMS Switching Unit	B747-200	ASR	1
42973001L028500	SHROUD	B747-200	ASR	4
42973002L028500	SHROUD	B747-200	ASR	4
372-012-001	Limit Indicator	B747-200	ASR	1
36154-1AJ25B1	Radio-Magnet Compass Indicator	B747-200	ASR	1
B4361710001	ALTIMETER - STANDBY	B747-200	ASR	1
69B46119-105	PACK CONTROL PANEL	B747-200	ASR	1
65B47501-12	LEADING EDGE FLAP DISPLAY LOGIC	B747-200	ASR	1
65B47505-53	LANDING GEAR PRIMARY SYS LOGIC	B747-200	ASR	1
65B47634-7	CARGO MASTER INTERCOM	B747-200	ASR	1
69B46237-4	BUS CONTROL PANEL	B747-200	ASR	1
69B46481-2	ENGINE IGNITION	B747-200	ASR	1
69B46763-15	ENGINE FUEL CONDITION INDICATOR	B747-200	ASR	1
69B46048-6	ANTI SKID CONTROL PANEL	B747-200	ASR	1
69B46105-7	FLIGHT RECORDER	B747-200	ASR	1
452100-02-03	MODE SELECTOR UNIT	B747-200	ASR	1
458900009-01	CONTROL DISPLAY UNIT	B747-200	ASR	1

Part Number	Part Description	A/C Type	Condition	Quantity
60B40151-21	CABIN INTERPHONE	B747-200	ASR	1
CA154-1	MARATHON NICAD BATTERY	B747-200	ASR	1
CA154-1	MARATHON NICAD BATTERY	B747-200	ASR	1
3200-6	FILTER	B747-200	ASR	1
69B46119-105	PACK CONTROL PANEL	B747-200	ASR	1
60B00013-308	Roll Computer	B747-200	ASR	1
65B47572-39	Auto Flight Control Accessory Box	B747-200	ASR	1
628T-2A	HF-Receiver Transmitter	B747-200	ASR	1
60B80099-115	Marconi-Elliott Avionic Autothrottle Comp.	B747-200	ASR	1
522-4538-002	AMPLIFIR	B747-200	ASR	1
622-4096-001	PASS.ADRS AMPLIFIER	B747-200	ASR	1
9599-607-11102	RADIO ALT.TRANSC.	B747-200	US	1
60B40003-6	Servoed Altitude Indicator	B747-200	ASR	1
60B00066-16	HORIZ SIT Indicator	B747-200	US	1
331A-8K	HORIZ SIT Indicator	B747-200	ASR	1
066-50003-0601	Traffic Display	B747-200	ASR	1
772-5005-001	Flight Director Indicator	B747-200	ASR	1
ED742951-3	FLIGHT DATA AQU UNIT	B747-200	ASR	1
710298-8	Outflow Value Selector Panel	B747-200	ASR	1
B8AM3	PITCH TRIM COMPUTER	B747-200	ASR	1
65B47511-92	INTERPHONE AUDIO ACC BOX	B747-200	ASR	1
60B00013-176	MODE SELECT PANEL	B747-200	ASR	1
B7AM1	CONVERTER	B747-200	ROBBED	1
60B50008-5	Water Cooler Thermoelectric	B747-200	ASR	1
21B73-1-2	CONTROL UNIT	B747-200	ASR	1
680-0021-320	WINDOW TEMP.REGUL.	B747-200	ASR	1
622-1233-001	DME TRANSCEIVER	B747-200	REP	1

Part Number	Part Description	A/C Type	Condition	Quantity
522-2996-011	MARKER BEACON REC	B747-200	ASR	1
066-01127-1602	ATC TRANS MODE S	B747-200	ASR	1
60B00026-31	Zone Temperature Controller	B747-200	ASR	1
NA134D2	Motorola SELCAL	B747-200	ASR	1
2070750-3307	VOR RECEIVER	B747-200	ASR	1
940-1	GROUND PWR CONT. PANEL	B747-200	ASR	1
980-6005-076	COCKPIT VOICE RECORD	B747-200	EXPIRED	1
965-1076-020	EGPWS	B747-200	ASR	1
772-5005-001	Flight Director Indicator	B747-200	ASR	1
60B00010-21	Generator Control Unit	B747-200	ASR	1
60B00068-4	CIWS Computer	B747-200	ASR	1
65B43701-4	AT Dimmer Accessory Box	B747-200	ASR	1
60B00026-31	Zone Temperature Controller	B747-200	ASR	1
4034241-974	COMPUTER-(DUAL DIGITAL FLIGHT GUIDANCE CONTROL SYSTEM 2)	B747-200	ASR	1
B3BM2	LONGITUDINAL ACOMPUTER	B747-200	ASR	1
20412224401	RADAR INDICATOR	B747-200	ASR	1
628T-2A	HF-Receiver Transmitter	B747-200	ASR	1
111CZ01Y01	STATIC CONTACTOR	B747-200	US	1
WL246ASMS3	INDICATR	B747-200	ASR	1
G2750-07	AUDIO CONROL PANEL	B747-200	ASR	1
F11QY3714	TRANSFORMER RECTIFIER	B747-200	ASR	1
264-006-001	Limit Selector Panel	B747-200	ASR	1
35-309-1009	MASTER WARNING BOX	B747-200	ASR	1
G3981	CONTROL UNIT-ADF	B747-200	ASR	1
K2AM0	COURSE MODULE	B747-200	ASR	1
58VU	58 VU, CARGO SMOKE DETECTION A300	B747-200	ASR	1
APE962	TIME DISPLAY UNIT	B747-200	ASR	1

Part Number	Part Description	A/C Type	Condition	Quantity
27VU	27 VU, INTERIOR LIGHTING CONTROL A300	B747-200	ASR	1
CP1600B	CONTROL PANEL	B747-200	ASR	1
DDT1P1291	MIKROPHN	B747-200	ASR	1
595-014-780	SMOKE DETECTOR	B747-200	ASR	1
31VU	31 VU, ARTIFICIAL FEEL PANEL A300	B747-200	ASR	1
15-0007-113	LIGHT ASSY-UTILITY	B747-200	ASR	1
87292280	ELECTRONIC BUFFER	B747-200	ASR	1
69-22682-3	LEADING EDGE LIGHT	B747-200	ASR	1
69-22682-3	LEADING EDGE LIGHT	B747-200	ASR	1
980-6020-001	CVR	B747-200	ASR	1
201EDP1-1	ENGINE DISP UNIT IND	B747-200	ASR	1
B05JB1041	NON RETURN VALVE	B747-200	NE	1
S122Z12-02	PICKOFF	B747-200	ASR	1
194550-1	WATER SEPARATOR	B747-200	RTS	1
CHA704-240	SHAFT-SLAT TRANSM.	B747-200	SV	1
7579078	RETURN MODULE FILTER	B747-200	ASR	1
65-44600-20	RESERVOIR	B747-200	SV	1
704-779-3	FUEL TANK NO 9	B747-200	SV	1
69-22682-3	LEADING EDGE LIGHT	B747-200	ASR	1
69-22682-3	LEADING EDGE LIGHT	B747-200	ASR	1
3214-41	EPSU	B747-200	EXPIRED	1
2156-2B	SMOKE DETECTOR SYSTEM	B747-200	ASR	1
503-7	ELECTRONICS	B747-200	ASR	1
425-0001-13	MAKER	B747-200	ASR	1
467-0001-7	COFFEE MAKER	B747-200	ASR	1
7886880-061	PMS Eng, Interface Unit	B747-200	ASR	1
60B40126-2	Central Air Data Digital Computer	B747-200	ASR	1
60B40126-5	Central Air Data Digital Computer	B747-200	ASR	1
60B00013-308	Roll Computer	B747-200	ASR	1
822-1045-301	VHF TRANSCEIVER	B747-200	ASR	1

Part Number	Part Description	A/C Type	Condition	Quantity
822-1045-301	VHF TRANSCEIVER	B747-200	ASR	1
777-1492-004	ADF RECEIVER	B747-200	ASR	1
777-1492-004	ADF RECEIVER	B747-200	ASR	1
1B1000-1G-F27	INVERTER	B747-200	ASR	1
40VU	40 VU, ENGINE STARTING CONTROL A300	B747-200	ASR	1
429VU	CTL PNL	B747-200	ASR	1
520464	INDICATOR TEMPERATURE NACELLE	B747-200	ASR	1
10-60011-2	TRANSFORMER RETIFIER	B747-200	ASR	1
28000-1	OXYGEN REGULATOR CONTROL	B747-200	ASR	1
28000-1	OXYGEN REGULATOR CONTROL	B747-200	ASR	1
65B46040-9	WING ANTI-ICE	B747-200	ASR	1
65B46101-20	BUS CONTROL PANEL	B747-200	ASR	1
65B46101-20	BUS CONTROL PANEL	B747-200	ASR	1
69B46117-1	MAIN GENERATOR CONTROL	B747-200	ASR	1
6905L0001-01	RUDDER CONTROL ASSY	B747-200	ASR	1
69B46004-9	YAW DAMPER	B747-200	ASR	1
69B46123-6	SQUIB TEST	B747-200	ASR	1
69B46126-5	AC METERS	B747-200	ASR	1
69B46223-18	AUX CONTROL	B747-200	ASR	1
69B46325-2	LEADING EDGE FLAPS	B747-200	ASR	1
69B46506-4	MAIN DECK CARGO	B747-200	ASR	1
69B46026-23	CONTROL SWITCH	B747-200	ASR	1
69B46100-9	PASSENGER OXYGEN CONTROL	B747-200	ASR	1
452100-02-03	MODE SELECTOR UNIT	B747-200	ASR	1
503-4	ELT REMOTE CONTROLLER	B747-200	ASR	1
60B00175-4	ENGINE FIRE SHUT OFF SWITCH	B747-200	ASR	1

Part Number	Part Description	A/C Type	Condition	Quantity
60B00175-4	ENGINE FIRE SHUT OFF SWITCH	B747-200	ASR	1
69B4610-11	AUTO BRAKE	B747-200	ASR	1
MS27997-D1	MICROWAVE SWICH CONTROLLER	B747-200	ASR	1
61VU	61 VU, CABIN PRESSURIZATION PANEL A300	B747-200	ASR	1
194110-1	HEAT EXCHANGER	B747-200	ASR	1
65-46360-7	MIXER BOX	B747-200	ASR	1
A271710600003000	ASSY	B747-200	ASR	1
60B40141-3	Fuel Flow Rate Indicator	B747-200	ASR	1
8DJ164LWV2	Fuel Flow Indicator	B747-200	ASR	1
60B40141-3	Fuel Flow Rate Indicator	B747-200	ASR	1
60B00133-39	EGT Indicator	B747-200	ASR	1
8DJ162LZL2	N2 Tachometer	B747-200	ASR	1
60B00302-11	EPR Indicator	B747-200	ASR	1
8DJ163LZD4	EGT Indicator	B747-200	ASR	1
60B00302-11	EPR Indicator	B747-200	ASR	1
8DJ162LZT2	Tachometer Indicator	B747-200	ASR	1
8DJ163LZD4	EGT Indicator	B747-200	ASR	1
60B00133-39	EGT Indicator	B747-200	ASR	1
8DJ162LZK2	N2 Tachometer Indicator	B747-200	ASR	1
60B00132-29	N2 Tachometer Indicator	B747-200	ASR	1
60B00046-4	Fuel Used Indicator	B747-200	ASR	1
60B40141-3	Fuel Flow Rate Indicator	B747-200	ASR	1
60B00300-107	Tachometer Indicator	B747-200	ASR	1
10106-03	Fuel Quantity Indicator	B747-200	ASR	1
10106-03	Fuel Quantity Indicator	B747-200	ASR	1
60B00131-16	Oil Pressure Indicator	B747-200	ASR	1
60B40013-4	TAT Indicator	B747-200	ASR	1
255003-1	Altitude Indicator	B747-200	ASR	1
10106-03	Fuel Quantity Indicator	B747-200	ASR	1

Part Number	Part Description	A/C Type	Condition	Quantity
60B92012-1	Fuel Temperature Indicator	B747-200	ASR	1
60B00019-18	Oil Quantity Indicator	B747-200	ASR	1
60B00046-4	Fuel Used Indicator	B747-200	ASR	1
60B00130-7	Engine Temperature Indicator	B747-200	ASR	1
200-099-001	Hydraulic Fluid Quantity Indicator	B747-200	ASR	1
10106-03	Fuel Quantity Indicator	B747-200	ASR	1
10106-03	Fuel Quantity Indicator	B747-200	ASR	1
60B00046-4	Fuel Used Indicator	B747-200	ASR	1
60B00131-16	Oil Pressure Indicator	B747-200	ASR	1
60B00237-12	Hydraulic Fluid Quantity Indicator	B747-200	ASR	1
60B00300-107	Tachometer Indicator	B747-200	ASR	1
60B00046-4	Fuel Used Indicator	B747-200	ASR	1
10106-03	Fuel Quantity Indicator	B747-200	ASR	1
60B00131-12	Oil Pressure Indicator	B747-200	ASR	1
60B00130-7	Engine Temperature Indicator	B747-200	ASR	1
10107-04	Fuel Quantity Indicator	B747-200	ASR	1
60B00132-29	N2 Tachometer Indicator	B747-200	ASR	1
10106-03	Fuel Quantity Indicator	B747-200	ASR	1
60B00130-7	Engine Temperature Indicator	B747-200	ASR	1
60B00130-7	Engine Temperature Indicator	B747-200	ASR	1
64050-860-1	Airspeed Indicator	B747-200	ASR	1
60B00108-4	Temperature Compt and Supply Duct Indicator	B747-200	ASR	1
60B00108-4	Temperature Compt and Supply Duct Indicator	B747-200	ASR	1

Part Number	Part Description	A/C Type	Condition	Quantity
60B00019-12	Oil Quantity Indicator	B747-200	ASR	1
200-007-006	Hydraulic Quantity Indicator	B747-200	ASR	1
DSF508-18M	Oil Quantity Indicator	B747-200	ASR	1
10106-03	Fuel Quantity Indicator	B747-200	ASR	1
60B00108-4	Temperature Compt and Supply Duct Indicator	B747-200	ASR	1
60B00108-4	Temperature Compt and Supply Duct Indicator	B747-200	ASR	1
8DJ162L2V2	N1 TACHOMETER INDICATOR	B747-200	ASR	1
G-5699A	INS APPROACH DISPLAY VHF NAV	B747-200	ASR	1
60B00302-11	EPR Indicator	B747-200	ASR	1
152100-02-03	MODE SELECTOR UNIT	B747-200	ASR	1
64070-760-1	Cabin Differential Indicator	B747-200	ASR	1
60B00502-11	ENG PRESSURE IND	B747-200	ASR	1
DSF508-12M	OIL QUANTITY INDICATOR	B747-200	ASR	1
60B00237-19	Hydraulic Fluid Quantity Indicator	B747-200	ASR	1
60B00109-1	Trim Airvalve Pos Indicator	B747-200	ASR	1
60B00108-4	Temperature Compt and Supply Duct Indicator	B747-200	ASR	1
10106-03	Fuel Quantity Indicator	B747-200	ASR	1
530236-901	ACM Outlet Temperature Indicator	B747-200	ASR	1
WL304RC-1	CABIN VERTICAL SPEED INDICATOR	B747-200	ASR	1
60B40003-6	Servoed Altitude Indicator	B747-200	ASR	1
522-2457-037	CTLUNIT	B747-200	ASR	1
60B80101-2	Flight Mode Annunciator	B747-200	ASR	1

Part Number	Part Description	A/C Type	Condition	Quantity
458900-09-01	Control Display Unit	B747-200	ASR	1
60B00131-16	Oil Pressure Indicator	B747-200	ASR	1
36154-1AJ25B1	Radio-Magnet Compass Indicator	B747-200	ASR	1
066-50002-8102	SPEED IND	B747-200	ASR	1
066-50002-8102	SPEED IND	B747-200	ASR	1
65B46099-30	WINDOW HEAT CONTROLLER UNIT	B747-200	ASR	1
2156-1	AMPLIFIER SMOKE DETECTOR	B747-200	ASR	1
2156-1	AMPLIFIER SMOKE DETECTOR	B747-200	ASR	1
87292280	ELECTRONIC BUFFER	B747-200	ASR	1
87292280	ELECTRONIC BUFFER	B747-200	ASR	1
69B46128-13	AFT CARGO HEAT	B747-200	ASR	1
69B46128-7	FWD CARGO HEAT	B747-200	ASR	1
69B46481-2	ENGINE IGNITION	B747-200	ASR	1
69B46029-23	ALT FLAPS TRAILING EDGE	B747-200	ASR	1
69B46106-18	ESS AC BUS CONTROL	B747-200	ASR	1
8DJ81	ELECTRICAL TACH IND.	B747-200	ASR	1
60-0304-51	BATTERY	B747-200	EXPIRED	1
CGAB1400-00	SMOKE DECT.	B747-200	ASR	1
2426-702-8	INDICATOR FREQUENCY	B747-200	ASR	1
60BA00A7-8	COMPUTER	B747-200	ASR	1
16008000-041	CONT DISPLAY UNIT	B747-200	ASR	1
614L-12	ADF	B747-200	ASR	1
614L-12	ADF	B747-200	ASR	1
5956888-511	CONTROL , LIGHT ASSY	B747-200	ASR	1
G5810A	INS Approach Display VHF NAV	B747-200	ASR	1
30-0627-3	LIGHT-RED,WING (LH)	B747-200	ASR	1
4034238-901	LATERAL ACCELEROMTR	B747-200	ASR	1
5655366-7L	ANTENNA	B747-200	ASR	1
TSG420-102	INVERTER	B747-200	ASR	1

Part Number	Part Description	A/C Type	Condition	Quantity
2223682	FLIGHT DATA ENTRY PANEL	B747-200	ASR	1
2041220-1413	WEATHER RADAR CONTROL	B747-200	ASR	1
65B46098-21	ENGINE FIRE HANDLES	B747-200	ASR	1
2156-1	AMPLIFIER SMOKE DETECTOR	B747-200	ASR	1
2156-10B	SMOKE DETECTOR	B747-200	ASR	1
2156-2B	SMOKE DETECTOR SYSTEM	B747-200	ASR	1
2156-2C	SMOKE DETECTOR	B747-200	ASR	1
65B46101-20	BUS CONTROL PANEL	B747-200	ASR	1
65B46112-18	AUX POWER	B747-200	ASR	1
2591200-901	COMPENSATOR- MAGNETIC	B747-200	ASR	1
65B46189-17	LOWER CARGO FIRE PROTECTION	B747-200	ASR	1
69B46127-15	DC BUS ISOLATION	B747-200	ASR	1
69B46137-6	QALL DEACTIVATED FAN	B747-200	ASR	1
69B46415-1	MODULE ASSY-ANTISKID	B747-200	ASR	1
704185D	LOAD CONTROLLER	B747-200	ASR	1
69B46013-30	MACH A/S WARN TEST	B747-200	ASR	1
892809-0400-02	FIRE DETECTION UNIT	B747-200	ASR	1
892809-0400-02	FIRE DETECTION UNIT	B747-200	ASR	1
8DW84LAN1	D.C. LOADMETER	B747-200	ASR	1
8DW84LBA1	D.C. LOADMETER	B747-200	ASR	1
AW2835AH01	CABIN PRESSURE IND.	B747-200	ASR	1
G-4092	CW TRANSMIT	B747-200	ASR	1
G-5811	RADIO CONTROL	B747-200	ASR	1
G-5811	RADIO CONTROL	B747-200	ASR	1
69B46116-11	DC METERS	B747-200	ASR	1
961-5059-002	WIND. TEMP.REGUL.	B747-200	ASR	1
5822-11	BATTERY POWER SUPPLY	B747-200	ASR	1
5822-11	BATTERY POWER SUPPLY	B747-200	ASR	1

Part Number	Part Description	A/C Type	Condition	Quantity
5898.581.8	BRAKE TEMP MONITOR	B747-200	ASR	1
5956889-511	OVHD CONSOLE LIGHT PANEL	B747-200	ASR	1
CGAB1400-00	SMOKE DECT.	B747-200	ASR	1
CGAB1400-00	SMOKE DECT.	B747-200	ASR	1
D8095	LOAD. AREA LIGHT	B747-200	ASR	1
2156-1	AMPLIFIER SMOKE DETECTOR	B747-200	ASR	1
565-5366-7L	L BAND ANTENNA	B747-200	ASR	1
5822-11	BATTERY POWER SUPPLY	B747-200	ASR	1
300498-747	VALVE POSITION CONTROL	B747-200	ASR	1
65B46125-24	FUEL JETTISON	B747-200	ASR	1
65B46128-34	BUS CONTROL PANEL	B747-200	ASR	1
65B46214-107	FUEL READ IN POUNDS	B747-200	ASR	1
379103C-17	DESCENT DEVICE	B747-200	ASR	8
DMC50-1	ANTENNA-VHF COM	B747-200	ASR	1
59VU	59 VU, AIR BLEED PANEL A300	B747-200	ASR	1
DMC50-1	ANTENNA-VHF COM	B747-200	ASR	1
2593742-41	VERTICAL GYRO	B747-200	ASR	1
65-73719-505A	LENSE	B747-200	ASR	1
189120-3	PRECOOLER-AIR BLEED	B747-200	US	1
110VU	FUEL PANEL	B747-200	ASR	1
55VU	55 VU, ENGINE SECONDARY INSTRUMENT A300	B747-200	ASR	1
28000-1	OXYGEN REGULATOR CONTROL	B747-200	ASR	1
65B461021-8	BUS CONTROL PANEL	B747-200	ASR	1
65B46102-8	BUS CONTROL PANEL	B747-200	ASR	1
65B46137-27	HYDRAULIC SYS CONTROL PANEL	B747-200	ASR	1
2566A-30A	ANGLE OF AIRFLOW SENSOR	B747-200	ASR	1
65B46180-9	PACK VALUE PANEL	B747-200	ASR	1
S1823502-03	ELT	B747-200	ASR	1

Part Number	Part Description	A/C Type	Condition	Quantity
65B47508-67	LANDING GEAR ALTERNATE SYS LOGIC	B747-200	ASR	1
65B47577-116	INSTRUMENT SWITCHING ACC BOX	B747-200	ASR	1
704185D	LOAD CONTROLLER	B747-200	ASR	1
40-0150-7	ANTI COLLISION LIGHT	B747-200	ASR	1
G-5811	RADIO CONTROL	B747-200	ASR	1
G-5811	RADIO CONTROL	B747-200	ASR	1
G-5811	RADIO CONTROL	B747-200	ASR	1
81840-175095-001	SELECTOR SWITCH	B747-200	ASR	1
81840-175095-001	SELECTOR SWITCH	B747-200	ASR	1
964-0076-004	COMPARATOR	B747-200	ASR	1
175096-001	RELAY	B747-200	ASR	14
522-2457-037	CTLUNIT	B747-200	ASR	1
30093-2022-02	FUEL QTY ASSEMBLY	B747-200	ASR	1
65B46101-20	BUS CONTROL PANEL	B747-200	ASR	1
65B46102-6	BUS CONTROL PANEL	B747-200	ASR	1
65B46122-62	BUS CONTROL PANEL	B747-200	ASR	1
65B46133	SNTI SKID MODULE PANEL	B747-200	ASR	1
69B46121-13	ENGINE VIBRATION	B747-200	ASR	1
65B46174-9	FUELING CONTROL	B747-200	ASR	1
6905L0001-01	RUDDER CONTROL ASSY	B747-200	ASR	1
69B46002-49	NACELLE ANTI-ICE	B747-200	ASR	1
69B46005-6	WINDSHIELD CONTROL	B747-200	ASR	1
69B46172-8	BODY GEAR STEERING CONTROL	B747-200	ASR	1
69B4622318	AUX RADIO CONTROL MIC	B747-200	ASR	1
69B46562-4	INS UPDATING	B747-200	ASR	1
69B46562-4	INS UPDATING	B747-200	ASR	1
69B466138-11	WING LC OVERHEAT	B747-200	ASR	1
69B46772-1	BUS CONTROL PANEL	B747-200	ASR	1

Part Number	Part Description	A/C Type	Condition	Quantity
69B46009-6	ALT GEAR EXTEND CONTROL	B747-200	ASR	1
69B46010-31	EMERGENCY LIGHT	B747-200	ASR	1
69B46104-10/9	EQUIPMENT COOLING CONTROL	B747-200	ASR	1
69B46107-13	ALT HORN CUTOUT PANEL	B747-200	ASR	1
69B46111-10	LIGHT CONTROL	B747-200	ASR	1
G-5808	SELCAL UNIT	B747-200	ASR	1
G-5811	RADIO CONTROL	B747-200	ASR	1
12156-101	CARGO ROLLER PANEL	B747-200	ASR	1
65B46041-16	MODULE HEATER PROBE	B747-200	ASR	1
2156-2B	SMOKE DETECTOR SYSTEM	B747-200	ASR	1
2156-2B	SMOKE DETECTOR SYSTEM	B747-200	ASR	1
2156-2B	SMOKE DETECTOR SYSTEM	B747-200	ASR	1
65B46102-6	BUS CONTROL PANEL	B747-200	ASR	1
65B46113-151	APO BLEED AIR CONTROL PANEL	B747-200	ASR	1
2591200-901	COMPENSATOR-MAGNETIC	B747-200	ASR	1
87292280	ELECTRONIC BUFFER	B747-200	ASR	1
65B47590-18	SPEAKER/MIC	B747-200	ASR	1
65B47622-9	SIDE DORR CONTROL	B747-200	ASR	1
704185D	LOAD CONTROLLER	B747-200	ASR	1
69B46014-9	FLT CONTROL HYD POWER	B747-200	ASR	1
69B46114-6	LANDING GEAR CONTROL PANEL	B747-200	ASR	1
12115-101	REMOTE MASTER CONTROL	B747-200	ASR	1
12121-101	MASTER CONTROL PANEL	B747-200	ASR	1
12241-107	POWER PANEL	B747-200	ASR	1
12132-105	PANEL	B747-200	ASR	1
12132-101	PANEL	B747-200	ASR	1
12132-111	PANEL	B747-200	ASR	1
12132-113	PANEL	B747-200	ASR	1

Part Number	Part Description	A/C Type	Condition	Quantity
12132-309	PANEL	B747-200	ASR	1
12132-103	PANEL	B747-200	ASR	1
3081-35	BALLAST	B747-200	ASR	125
3081-65	BALLAST	B747-200	ASR	35