

Part Number	Part Description	A/C Type	Condition	Quantity
B350AAM6	FCC	A-310	ASR	1
B350AAM6	FCC	A-310	ASR	1
1520S0000-000	CONTROL BOX	A-310	ASR	1
428VU	CTL PNL	A-310	ASR	1
627396-1	TEMPERATURE CONTROL	A-310	ASR	1
426VU	ANTI ICE PNL	A-310	ASR	1
400VU	400 VU, LDG GEAR WARN TEST PANEL A310	A-310	ASR	1
627396-1	TEMPERATURE CONTROL	A-310	ASR	1
066-01127-1101	ATC TRANS MODE S	A-310	ASR	1
30571004-502	AUDIO REPRODUCER	A-310	ASR	1
743-0238-001	HIS (R) VTR	A-310	ASR	1
170003-33	PASS.POWER AMPLIFIER	A-310	ASR	1
6664157	REGULTR	A-310	ASR	1
435VU	435 VU, OXYGEN MODULE A310	A-310	ASR	1
66501-003-1	CONVERTER-ANALOGIC DATA SYSTEM	A-310	ASR	1
224TS05Y	GEAR CONTROL SWITCH	A-310	ASR	1
822-0726-002	VOR RECEIVER	A-310	ASR	1
K157ABM5	FLIGHT CONTROL UNIT	A-310	ASR	1
822-0726-002	VOR RECEIVER	A-310	ASR	1
65-833-045-00	FMS CDU	A-310	ASR	1
C20101310-401	BSCU	A-310	ASR	1
30571004-502	AUDIO REPRODUCER	A-310	ASR	1
35-493-1006	IND. LIGHT DIMMER	A-310	ASR	1
622-5222-002	ADF # 2	A-310	ASR	1
SC2253A	ILS RECIEVER	A-310	ASR	1
788VU	788 VU, BOX-RELAY	A-310	ASR	1
B472AAM	D.I.L	A-310	ASR	1
35-0B5-3005-313	FLIGHT WARNING COMPU	A-310	ASR	1
B350AAM6	FCC	A-310	ASR	1
35-940-2001-201	RALTU UNIT	A-310	ASR	1
437VU	PANEL	A-310	ASR	1
471VU	CTL PANEL	A-310	ASR	1
SC2253A	ILS RECIEVER	A-310	ASR	1
406VU	406 VU, F/O SWITCHING PANEL A310	A-310	ASR	1
472VU	CTL PANEL	A-310	ASR	1
402VU	402 VU, CAPT. SWITCHING PANEL A310	A-310	ASR	1
402VU	402 VU, CAPT. SWITCHING PANEL A310	A-310	ASR	1
A9259198806400	742 VU UTILITY PANEL	A-310	ASR	1
A9259198806400	742 VU UTILITY PANEL	A-310	ASR	1

Part Number	Part Description	A/C Type	Condition	Quantity
F11QY3714	TRANSFORMER RECTIFIER	A-310	ASR	1
F11QY3714	TRANSFORMER RECTIFIER	A-310	ASR	1
513CA01C1-02Y1	THREE-POLE CONTACTOR	A-310	ASR	1
H301AKM1	GYRO	A-310	ASR	1
442VU	442 VU, FLIGHT RECORDER MODULE A310	A-310	ASR	1
45VU	45VU, PANEL EVAC SIGNAL A310	A-310	ASR	1
401VU	BRK PNL	A-310	ASR	1
683478-1	SWITCH	A-310	ASR	1
683478-1	SWITCH	A-310	ASR	1
461630-02	SELECTOR UNIT-MODE	A-310	ASR	1
461630-02	SELECTOR UNIT-MODE	A-310	ASR	1
683478-1	SWITCH	A-310	ASR	1
239TS05Y03	APU FIRE HANDLE MODULE	A-310	ASR	1
8101-01-4000	CTRL MODULE	A-310	ASR	1
796-354-1	ALTITUDE SENSOR	A-310	ASR	1
417VU	417 VU, PANEL ASSY, AUDIO A310	A-310	ASR	1
2739-02	CONTROL MODULE	A-310	ASR	1
101CC01A02	POLE CONTACTOR	A-310	ASR	1
2936C01Y0102	D CURRENT SENSORR	A-310	ASR	1
152CA01C102Y1	CONNECTOR	A-310	ASR	1
PR4237-1	SHAKER	A-310	ASR	1
861CAE1-0001	AOA SENSOR	A-310	ASR	1
SD9425-01	LAVATORY SMOKE DETEC	A-310	ASR	1
418VU	418 VU, PANEL A310	A-310	ASR	1
MSE101-27	CREW OXY MASK REG.	A-310	ASR	1
DM1601354-001	ANTENNA	A-310	ASR	1
SP3337-11	SWITCH-LIMIT	A-310	ASR	1
35-53	LIGHT-DOME	A-310	ASR	1
425VU	ELEC PNL	A-310	ASR	1
789VU	PANEL	A-310	ASR	1
438VU	VENT PNL	A-310	ASR	1
B40CF0401	FAN BATTERY COOLING	A-310	ASR	1
782-889-4	AIRFLOW DETECTOR	A-310	ASR	1
MSE101-27	CREW OXY MASK REG.	A-310	ASR	1
24E507009G01	WATER HEATER	A-310	ASR	1
DM1601354-001	ANTENNA	A-310	ASR	1
8101-01-4000	CTRL MODULE	A-310	ASR	1
8101-01-4000	CTRL MODULE	A-310	ASR	1
1X2-001517-1	CARGO LIGHT ASSY	A-310	ASR	1
8101-01-4000	CTRL MODULE	A-310	ASR	1
AR4709-3	CONT-COCKPIT SYSTEM	A-310	ASR	1
4189911	RH WING SCAN LT. ASSY	A-310	ASR	1

Part Number	Part Description	A/C Type	Condition	Quantity
4189934	AIR INTAKE INSP LT. (RH)	A-310	ASR	1
65205-230-2	ALTIMETER	A-310	ASR	1
513CA02F1-02Y1	THREE-POLE CONTACTOR	A-310	ASR	1
617512-3	CONT. TEMP. PACK	A-310	ASR	1
477CA01C15-02Y3	CONTACTOR	A-310	ASR	1
9028A0002-01	PICK OFF UNIT POSITI	A-310	ASR	1
64952-001-1	TEMPERATURE IND.	A-310	ASR	1
131CC01A02	CONTACTOR BUS	A-310	ASR	1
152	ATTRNSFR	A-310	ASR	1
729720	CURRENT TRANSFORMER	A-310	ASR	1
750T2112-8	HANDSET-CABIN INTERPHONE,TYPE D	A-310	ASR	1
627416-1	SENSOR-ZONE IN TEMP	A-310	ASR	1
8101-01-4000	CTRL MODULE	A-310	ASR	1
61	TRANSFORMER-LIGHTING	A-310	ASR	1
782-889-4	AIRFLOW DETECTOR	A-310	ASR	1
6068-1	ACTUATOR	A-310	ASR	1
1357VU	1357VU4, PATCHBOARD PANEL A310	A-310	ASR	1
513CA01C1-02Y1	THREE-POLE CONTACTOR	A-310	ASR	1
513CA01C1-02Y1	THREE-POLE CONTACTOR	A-310	ASR	1
9028A0002-01	PICK OFF UNIT POSITI	A-310	ASR	1
2TC14-1	CIRCUIT BREAKER	A-310	ASR	1
715445	VALVE-THERMAL RELIEF	A-310	ASR	1
8101-01-4000	CTRL MODULE	A-310	BER	1
235TS05Y03	#1 ENG FIRE HANDLE MODULE	A-310	ASR	1
8101-01-4000	CTRL MODULE	A-310	ASR	1
2LA002607-00	LIGHT	A-310	ASR	1
2LA002607-00	LIGHT	A-310	ASR	1
32D37-1	DIFF.PRESS SWITCH	A-310	ASR	1
ST-0109C	FLOW INDICATING TRANSMITTER	A-310	ASR	1
3905300101	E F C U	A-310	ASR	1
9612670320	ECAM SGU	A-310	ASR	1
2227000-27	DFDAU-DIGITAL FLIGHT DATA ACQUISITION UNIT	A-310	ASR	1
622-5132-105	WXR R/T	A-310	ASR	1
471VU	CTL PANEL	A-310	ASR	1
BDM300-3	PROX DET BOX	A-310	ASR	1
743-0129-008	SYSTEM CTRL UNIT	A-310	ASR	1
2117402-12	E.C.B	A-310	ASR	1
6664157	REGULTR	A-310	ASR	1
2LA003968-00	LIGHT	A-310	ASR	1
85-13-03417-01	HAND MICROPHONE	A-310	ASR	1

Part Number	Part Description	A/C Type	Condition	Quantity
8ES004117-00	LT. CTRL ASSY	A-310	ASR	1
2LA002607-00	LIGHT	A-310	ASR	1
33140-3	RATE OF CLIMB IND.	A-310	ASR	1
4189927	AIR INTAKE INSPC. LT. (LH)	A-310	ASR	1
9028A0002-01	PICK OFF UNIT POSITI	A-310	ASR	1
35008-13	CONTROLLER-CFD	A-310	ASR	1
9028A0002-01	PICK OFF UNIT POSITI	A-310	ASR	1
63540-040-1	RMI/ADF	A-310	ASR	1
EIA1533E	AUDIO INTEGRATING UNIT	A-310	ASR	1
WL353EED4	FUEL FLOW/USED INDICATOR	A-310	ASR	1
WL352EED6	INDICATOR	A-310	ASR	1
WL352EED6	INDICATOR	A-310	ASR	1
WL353EED4-1	FUEL FLOW/ USED INDICATOR	A-310	ASR	1
WL301EED3	N1 INDICATOR	A-310	ASR	1
WL351EED5	N2 INDICATOR	A-310	ASR	1
277VU	277 VU, CONTROL BOX A310	A-310	ASR	1
497VU	497 VU, TERRAIN SWITCH PANEL A310	A-310	ASR	1
56B17A6	SENSOR-TEMPERATURE	A-310	ASR	1
627416-1	SENSOR-ZONE IN TEMP	A-310	ASR	1
64040-861-1	STBY AIRSPEED IND	A-310	ASR	1
2LA002607-00	LIGHT	A-310	ASR	1
4237091	WIPER MOTOR	A-310	ASR	1
25811BOSHUNTKL	CONTACTOR-THREE POLE	A-310	ASR	1
700	ATTRNSFR	A-310	ASR	1
275VU	275 VU, JUNCTION BOX A310	A-310	ASR	1
2LA002607-00	LIGHT	A-310	ASR	1
459VU	459 VU, COCKPIT TEMP SENSOR A310	A-310	ASR	1
9028A0002-01	PICK OFF UNIT POSITI	A-310	ASR	1
683478-1	SWITCH	A-310	ASR	1
6574860400	SPEED BRAKE PANEL	A-310	ASR	1
498VU	498 VU, TERRAIN CONTROL PANEL A310	A-310	ASR	1
2LA002607-00	LIGHT	A-310	ASR	1
44-2261-241-143	PRES. REDUCING VALVE	A-310	ASR	1
1357VU	1357VU4, PATCHBOARD PANEL A310	A-310	ASR	1
DMC50-1	ANTENNA-VHF COM	A-310	ASR	1
DMC50-1	ANTENNA-VHF COM	A-310	ASR	1
DMC50-1	ANTENNA-VHF COM	A-310	ASR	1

Part Number	Part Description	A/C Type	Condition	Quantity
110-328-01A	E.L.T ANTENNA	A-310	ASR	1
35008-13	CONTROLLER-CFD	A-310	ASR	1
83002B0101	POSITION INDICATOR	A-310	ASR	1
787VU	787 VU, BOX-RELAY A310	A-310	ASR	1
6310-20	CONTROLLER INSTANT LT.	A-310	ASR	1
252CA01C1-02Y1	CONTACTOR-THREE POLE	A-310	ASR	1
B472AAM1	TCC-THRUST CONTROL COMPUTER	A-310	ASR	1
477CA01C15-02Y3	CONTACTOR	A-310	ASR	1
252CA01C1-02Y1	CONTACTOR-THREE POLE	A-310	ASR	1
64880-403-2	DUAL INDICATOR	A-310	ASR	1
617512-3	CONT. TEMP. PACK	A-310	ASR	1
4189911	RH WING SCAN LT. ASSY	A-310	ASR	1
001517-09	CARGO LIGHT ASSY	A-310	ASR	1
35-890-1001	ECAM CTRL PANEL	A-310	ASR	1
622-5130-207	CONTROL UNIT-WEATHER RADAR	A-310	ASR	1
899-2223-008	VOR DME CONTROL UNIT	A-310	ASR	1
345-6196NT	ELT TEST/ RESET MODULE	A-310	ASR	1
65-833-045-00	FMS CDU	A-310	ASR	1
740120B	GCU	A-310	ASR	1
6664157	REGULTR	A-310	ASR	1
980-0800-033	PRGMD ANNOUNCED REPRODUCER	A-310	ASR	1
066-01127-1101	ATC TRANS MODE S	A-310	ASR	1
627248-2	PNEU. SYS CONTROLLER	A-310	ASR	1
2227000-27	DFDAU-DIGITAL FLIGHT DATA ACQUISITION UNIT	A-310	ASR	1
622-5222-002	ADF # 2	A-310	ASR	1
622-5272-001	HF COM TRANSCEIVER	A-310	ASR	1
49-079-05	S F C C # 2	A-310	ASR	1
64250-005-1	TRANSFER UNIT	A-310	ASR	1
2739-02	CONTROL MODULE	A-310	ASR	1
WL353EED3	INDICATOR-FF/FU	A-310	ASR	1
CP2426FB	AUDIO CONTROL PANEL	A-310	ASR	1
224TS05Y	GEAR CONTROL SWITCH	A-310	ASR	1
617924-3	APU PACK TEMP. CTRL.	A-310	ASR	1
K158ABM1	PANEL	A-310	ASR	1
235TS05Y03	#1 ENG FIRE HANDLE MODULE	A-310	ASR	1
APE2652	CLOCK	A-310	ASR	1
4189911	RH WING SCAN LT. ASSY	A-310	ASR	1
63540-031-2	INDICATOR-RMI,ADF	A-310	ASR	1
MSE101-27	CREW OXY MASK REG.	A-310	ASR	1
477CA01C15-02Y3	CONTACTOR	A-310	ASR	1

Part Number	Part Description	A/C Type	Condition	Quantity
4045053-903	ADC	A-310	ASR	1
B471ABM5	FAC	A-310	ASR	1
477VU	477 VU, BUZZER PANEL A310	A-310	ASR	1
56B17A6	SENSOR-TEMPERATURE	A-310	ASR	1
61551-000-1	SLAT/FLAP PSTN INDICATOR	A-310	ASR	1
7525021773	MOTOR GENERATOR CONTROL	A-310	ASR	1
61	TRANSFORMER-LIGHTING	A-310	ASR	1
980-4595-003	BGM PANEL	A-310	ASR	1
K151ACM1	PITCH TRIM/YAW DAMPER SW. MODULE	A-310	ASR	1
WL352EED6	INDICATOR	A-310	ASR	1
45VU	45VU, PANEL EVAC SIGNAL A310	A-310	ASR	1
700	ATTRNSFR	A-310	ASR	1
DMN25-2	ANTENNA-GLIDE SLOPE	A-310	ASR	1
6310-20	CONTROLLER INSTANT LT.	A-310	ASR	1
G6201	HF CTRL PANEL	A-310	ASR	1
740147A	GPCU	A-310	ASR	1
WL301EED3	N1 INDICATOR	A-310	ASR	1
B350AAM6	FCC	A-310	ASR	1
745SUE4B4	F M C	A-310	ASR	1
B471ABM5	FAC	A-310	ASR	1
B472AAM	D.I.L	A-310	ASR	1
B471ABM5	FAC	A-310	ASR	1
3905300101	E F C U	A-310	ASR	1
DMN4-26	ANTENNA-LOCALIZER	A-310	ASR	1
DMN4-26	ANTENNA-LOCALIZER	A-310	ASR	1
65-46135-24	LINK AY	A-310	OH	1
354932002	DIMMER INTEGRAL LIGHT	A-310	ASR	1
49-079-05	S F C C # 2	A-310	ASR	1
792-6140-001	HF ANT. COUPLER	A-310	ASR	1
792-6140-001	HF ANT. COUPLER	A-310	ASR	1
740120B	GCU	A-310	ASR	1
35-840-1001	STATIC INVERTER	A-310	ASR	1
35-840-1001	STATIC INVERTER	A-310	ASR	1
9612660321	SGU	A-310	ASR	1
96-1267-03-20	ECAM SGU	A-310	ASR	1
A825100-3	EXTINGUISHER-FIRE	A-310	EXPIRED	1
B23521002000D00A00	HEAD SET PANEL	A-310	ASR	1
35008-13	CONTROLLER-CFD	A-310	ASR	1
782-889-4	AIRFLOW DETECTOR	A-310	ASR	1
9599-607-12333	LRRA ANTENNA	A-310	ASR	1

Part Number	Part Description	A/C Type	Condition	Quantity
784-793	FLOW DETECTOR	A-310	ASR	1
782-889-4	AIRFLOW DETECTOR	A-310	ASR	1
627396-1	TEMPERATURE CONTROL	A-310	ASR	1
700	ATTRNSFR	A-310	ASR	1
G6992-34	TCAS CTRL PANEL	A-310	ASR	1
9028A0002-01	PICK OFF UNIT POSITI	A-310	ASR	1
B235-21001-000D00	JACK PANEL	A-310	ASR	1
2739-02	CONTROL MODULE	A-310	ASR	1
56B17A6	SENSOR-TEMPERATURE	A-310	ASR	1
627416-1	SENSOR-ZONE IN TEMP	A-310	ASR	1
10-203-23-7	L BAND ANTENNA	A-310	ASR	1
627416-1	SENSOR-ZONE IN TEMP	A-310	ASR	1
CP2426FB	AUDIO CONTROL PANEL	A-310	ASR	1
CP2426FB	AUDIO CONTROL PANEL	A-310	ASR	1
DM1601354-001	ANTENNA	A-310	ASR	1
24-622300-004	VIDEO TRANSFER UNIT	A-310	ASR	1
ST-0109C	FLOW INDICATING TRANSMITTER	A-310	ASR	1
310ZN01Y01	SENSOR-CUR.UNBLNCE	A-310	ASR	1
G6201	HF CTRL PANEL	A-310	ASR	1
35-910-1000	PROTECTION UNIT-WINDOW HEAT	A-310	ASR	1
BC2065C	CODE SELECTION	A-310	ASR	1
293GC01Y02	CONTACTOR PROTECTION	A-310	ASR	1
AR4709-3	CONT-COCKPIT SYSTEM	A-310	ASR	1
428VU	CTL PNL	A-310	ASR	1
441VU	PANEL	A-310	ASR	1
683478-1	SWITCH	A-310	ASR	1
2739-02	CONTROL MODULE	A-310	ASR	1
SD9425-01	LAVATORY SMOKE DETEC	A-310	ASR	1
796-354-1	ALTITUDE SENSOR	A-310	ASR	1
DM1601354-001	ANTENNA	A-310	ASR	1
A9550049800195	498 VU	A-310	ASR	1
35-53	LIGHT-DOME	A-310	ASR	1
8DW84LBA1	D.C. LOADMETER	A-310	SV	1
35-53	LIGHT-DOME	A-310	ASR	1
622-4540-001	DME XCVR	A-310	ASR	1
9599-607-14901	FMC	A-310	ASR	1
9599-607-14901	FMC	A-310	ASR	1
6664157	REGULTR	A-310	ASR	1
241-137-000-301	CONDTR	A-310	ASR	1
4045053-903	ADC	A-310	ASR	1
622-4540-001	DME XCVR	A-310	ASR	1
35-315-2003	CONT UNIT	A-310	ASR	1
066-01127-1101	ATC TRANS MODE S	A-310	ASR	1

Part Number	Part Description	A/C Type	Condition	Quantity
822-1044-003	VHF R/T # 1	A-310	ASR	1
CP2426FB	AUDIO CONTROL PANEL	A-310	ASR	1
WL352EED6	INDICATOR	A-310	ASR	1
861CAE1-0001	AOA SENSOR	A-310	ASR	1
9599-607-12333	LRRR ANTENNA	A-310	ASR	1
412VU	412 VU, CFD CONTROL PANEL A310	A-310	ASR	1
431VU	431 VU, READING LT. & CTRL PANEL A310	A-310	ASR	1
S1823502-03	ELT	A-310	ASR	1
S1823502-03	ELT	A-310	ASR	1
746VU	863VU-746VU, BGM CONTROL PANEL A310	A-310	ASR	1
2021272-1	ACTUATOR	A-310	ASR	1
2739-02	CONTROL MODULE	A-310	ASR	1
449VU	449 VU, READING LIGHT PANEL A310	A-310	ASR	1
796-151-5	SENSOR	A-310	ASR	1
24-622300-003	AUDIO TFMR A310 PTV	A-310	ASR	1
DM1601354-001	ANTENNA	A-310	ASR	1
442VU	442 VU, FLIGHT RECORDER MODULE A310	A-310	ASR	1
423VU	CTL PNL	A-310	ASR	1
1046GT2102AY	BOOMSET	A-310	ASR	1
CG7P0	SMOKE DETECTOR	A-310	EXPIRED	1
CG7P0	SMOKE DETECTOR	A-310	EXPIRED	1
S1823502-03	ELT	A-310	EXPIRED	1
DMN27-3	ANTENNA-MARKER 1	A-310	ASR	1
A12SA	MEGAPHON	A-310	ASR	1
413VU	413 VU, CONTROL PANEL A310	A-310	ASR	1
35008-13	CONTROLLER-CFD	A-310	ASR	1
4273511	LIGHT	A-310	ASR	1
A12SA	MEGAPHON	A-310	ASR	1
425VU	ELEC PNL	A-310	ASR	1
7110-91-01P	CTRL PANEL	A-310	ASR	1
420VU	CTL PNL	A-310	ASR	1
AG1027AA01	LIGHT- NAV LIT	A-310	ASR	1
G6201	HF CTRL PANEL	A-310	ASR	1
400VU	400 VU, LDG GEAR WARN TEST PANEL A310	A-310	ASR	1
AR4709-3	CONT-COCKPIT SYSTEM	A-310	ASR	1
461630-02	SELECTOR UNIT-MODE	A-310	ASR	1
401VU	BRK PNL	A-310	ASR	1
2021272-1	ACTUATOR	A-310	ASR	1

Part Number	Part Description	A/C Type	Condition	Quantity
119VU	119VU, COCKPIT DOOR S/W MODULE A310	A-310	ASR	1
9028A0002-01	PICK OFF UNIT POSITI	A-310	ASR	1
2LA004626-00	MAP LIGHT ASSY.	A-310	ASR	1
627396-1	TEMPERATURE CONTROL	A-310	ASR	1
3289614-3	WING ANTI ICE VALVE	A-310	US	1
F11QY3714	TRANSFORMER RECTIFIER	A-310	ASR	1
F11QY3714	TRANSFORMER RECTIFIER	A-310	ASR	1
AG1027AA01	LIGHT- NAV LIT	A-310	ASR	1
2LA004626-00	MAP LIGHT ASSY.	A-310	ASR	1
435VU	435 VU, OXYGEN MODULE A310	A-310	ASR	1
310ZN01Y01	SENSOR-CUR.UNBLNCE	A-310	ASR	1
861CAE1-0001	AOA SENSOR	A-310	ASR	1
2739-02	CONTROL MODULE	A-310	ASR	1
3121-01	EMERGENCY SUPPLY UN.	A-310	SV	1
861CAS3	ANGLE AIRFLOW SENSOR	A-310	SV	1
CGDU2000-00	MAIN DECK SMOKEDETEC	A-310	BER	1
6314	MAGNETO	A-310	SV	1
6314	MAGNETO	A-310	SV	1
VT-0306D	FUEL TRANSMITTER	A-310	US	1
436VU	PANEL	A-310	ASR	1
A9252737100160Z	EFIS COMPLIMENTARY CTRL PANEL	A-310	ASR	1
RCGSK-10-02	SMOKE DETECTOR CNTRL UNIT	A-310	ASR	1
8ES004117-00	LT. CTRL ASSY	A-310	ASR	1
4189934	AIR INTAKE INSP LT. (RH)	A-310	ASR	1
56B17A6	SENSOR-TEMPERATURE	A-310	ASR	1
470VU	CTL PNL	A-310	ASR	1
506VU	506 VU, PANEL A310	A-310	ASR	1
96-126-096	EFIS CTRL. PANEL	A-310	ASR	1
96-126-096	EFIS CTRL. PANEL	A-310	ASR	1
627396-1	TEMPERATURE CONTROL	A-310	ASR	1
492146-0011	VIDEO DIST AMPLIFIER	A-310	ASR	1
9028A0002-01	PICK OFF UNIT POSITI	A-310	ASR	1
BC2065C	CODE SELECTION	A-310	ASR	1
8ES004118-00	FLASHER TIMING UNIT	A-310	ASR	1
RG1007AA-03	FLASHER TIMING UNIT	A-310	ASR	1
889-2625-004	ADF CONTROL PANEL	A-310	ASR	1
424VU	424 VU, ELECT PWR CTRL MOD A310	A-310	ASR	1
457400KB1901	RA/TA VSI	A-310	BER	1
3507972-1	CLAMP	A-310	NS	2
8101-01-4000	CTRL MODULE	A-310	ASR	1

Part Number	Part Description	A/C Type	Condition	Quantity
477CA01C1502Y3	CONTCTR	A-310	ASR	1
64161-230-1	ALTIMETER	A-310	ASR	1
459VU	459 VU, COCKPIT TEMP SENSOR A310	A-310	ASR	1
50-0122-1	TAXI & T/OFF LT. ASSY (LH)	A-310	ASR	1
7110-91-01P	CTRL PANEL	A-310	ASR	1
424VU	424 VU, ELECT PWR CTRL MOD A310	A-310	ASR	1
9599-607-12333	LRRA ANTENNA	A-310	ASR	1
64880-403-2	DUAL INDICATOR	A-310	ASR	1
389GC01Y03	BATTERY CHARGER	A-310	ASR	1
389GC01Y03	BATTERY CHARGER	A-310	ASR	1
64040-861-1	STBY AIRSPEED IND	A-310	ASR	1
512VU	512VU, COCKPIT DOOR BACKUP MOD. A310	A-310	ASR	1
24-622300-003	AUDIO TFMR A310 PTV	A-310	ASR	1
441VU	PANEL	A-310	ASR	1
429VU	CTL PNL	A-310	ASR	1
WL351EED5	N2 INDICATOR	A-310	ASR	1
152	ATTRNSFR	A-310	ASR	1
9028A0002-01	PICK OFF UNIT POSITI	A-310	ASR	1
WL351EED5	N2 INDICATOR	A-310	ASR	1
WL301EED3	N1 INDICATOR	A-310	ASR	1
461630-02	SELECTOR UNIT-MODE	A-310	ASR	1
700	ATTRNSFR	A-310	ASR	1
427VU	HYD PWR PNL	A-310	ASR	1
438VU	VENT PNL	A-310	ASR	1
3214-40	EPSU L2 DOOR	A-310	EXPIRED	1
345-6196NT	ELT TEST/ RESET MODULE	A-310	ASR	1
F11QY3714	TRANSFORMER RECTIFIER	A-310	ASR	1
861CAE1-0001	AOA SENSOR	A-310	ASR	1
617512-3	CONT. TEMP. PACK	A-310	ASR	1
432VU	PRESS PNL	A-310	ASR	1
472VU	CTL PANEL	A-310	ASR	1
436VU	PANEL	A-310	ASR	1
622-5132-105	WXR R/T	A-310	ASR	1
899-2223-008	VOR DME CONTROL UNIT	A-310	ASR	1
K159ADM1	MTP (AUTO LAND PANEL)	A-310	ASR	1
EIA1533E	AUDIO INTEGRATING UNIT	A-310	ASR	1
63540-170-2	DIGITAL DDRMI IND	A-310	ASR	1
627562-1	CONTLER-CARGO	A-310	ASR	1
680-0021-500	DETECT	A-310	ASR	1
437VU	PANEL	A-310	ASR	1
980-4100-BXUN	DFDR	A-310	ASR	1
B471ABM5	FAC	A-310	SV	1

Part Number	Part Description	A/C Type	Condition	Quantity
C20101610-003	BSCU	A-310	ASR	1
WL301EED3	N1 INDICATOR	A-310	ASR	1
700	ATTRNSFR	A-310	ASR	1
9599-607-12333	LRRRA ANTENNA	A-310	ASR	1
64040-861-1	STBY AIRSPEED IND	A-310	ASR	1
64880-403-2	DUAL INDICATOR	A-310	ASR	1
152CA01C1-02Y1	CONTACTOR-THREE POLE	A-310	ASR	1
SD9425-01	LAVATORY SMOKE DETEC	A-310	ASR	1
9028A0002-01	PICK OFF UNIT POSITI	A-310	ASR	1
24-622300-003	AUDIO TFMR A310 PTV	A-310	ASR	1
64902-065-1	HYDRAULIC QUANTITY IND.	A-310	ASR	1
2LA002607-12	CARGO LIGHT ASSY	A-310	ASR	1
35008-13	CONTROLLER-CFD	A-310	ASR	1
64880-403-2	DUAL INDICATOR	A-310	ASR	1
9599-607-12333	LRRRA ANTENNA	A-310	ASR	1
9599-607-12333	LRRRA ANTENNA	A-310	ASR	1
6310-01	CONTROLLER INSTANT LT.	A-310	ASR	1
64882-203-1	PRESSURE INDICATOR	A-310	ASR	1
BC2065C	CODE SELECTION	A-310	ASR	1
119VU	119VU, COCKPIT DOOR S/W MODULE A310	A-310	ASR	1
9028A0002-01	PICK OFF UNIT POSITI	A-310	ASR	1
2739-02	CONTROL MODULE	A-310	ASR	1
EVT3745A	BLOWER	A-310	ASR	1
A9251002700060Z	512 VU	A-310	ASR	1
2LA004626-00	MAP LIGHT ASSY.	A-310	ASR	1
241-137-000-301	CONDTR	A-310	ASR	1
35-467-2001	FLC	A-310	ASR	1
B473ACM4	CGGC	A-310	ASR	1
170003-333	PWR AMPLIFIER	A-310	ASR	1
622-5222-002	ADF # 2	A-310	ASR	1
104VU	PLATE INSTL-BLANKING, 104 VU	A-310	ASR	1
745SUE4B4	F M C	A-310	ASR	1
35-315-2003	CONT UNIT	A-310	ASR	1
35-0B5-3005-313	FLIGHT WARNING COMPU	A-310	ASR	1
822-0282-120	RECEIVER,ILS	A-310	ASR	1
740120B	GCU	A-310	ASR	1
3905300101	E F C U	A-310	ASR	1
743-0129-008	SYSTEM CTRL UNIT	A-310	ASR	1
622-5342-001	AMPLIFR	A-310	ASR	1
35-900-1010-011	COMPUTER - FEEL LIMITATION	A-310	ASR	1
607428-0001	HEAD END MODULATOR	A-310	ASR	1

Part Number	Part Description	A/C Type	Condition	Quantity
RCGSK-10-02	SMOKE DETECTOR CNTRL UNIT	A-310	ASR	1
622-5132-105	WXR R/T	A-310	ASR	1
49-079-05	S F C C # 2	A-310	ASR	1
1046GT2102AY	BOOMSET	A-310	ASR	1
389GC01Y03	BATTERY CHARGER	A-310	ASR	1
76VU	76 VU, L/G INDICATION MODULE A310	A-310	ASR	1
CP2426FB	AUDIO CONTROL PANEL	A-310	ASR	1
283VU	283 VU, STRUCTURE BOX A310	A-310	ASR	1
1357VU	1357VU4, PATCHBOARD PANEL A310	A-310	ASR	1
617512-3	CONT. TEMP. PACK	A-310	ASR	1
K159AEM0	MTP (AUTO LAND PANEL)	A-310	ASR	1
56B17A6	SENSOR-TEMPERATURE	A-310	ASR	1
F11QY3714	TRANSFORMER RECTIFIER	A-310	ASR	1
239TS05Y03	APU FIRE HANDLE MODULE	A-310	ASR	1
1046GT2102AY	BOOMSET	A-310	ASR	1
APE2652	CLOCK	A-310	ASR	1
389GC01Y03	BATTERY CHARGER	A-310	ASR	1
10-203-23-7	L BAND ANTENNA	A-310	ASR	1
96-126-096	EFIS CTRL. PANEL	A-310	ASR	1
96-126-096	EFIS CTRL. PANEL	A-310	ASR	1
889-2625-004	ADF CONTROL PANEL	A-310	ASR	1
627396-1	TEMPERATURE CONTROL	A-310	ASR	1
627396-1	TEMPERATURE CONTROL	A-310	ASR	1
617512-3	CONT. TEMP. PACK	A-310	ASR	1
G6201	HF CTRL PANEL	A-310	ASR	1
61551-000-1	SLAT/FLAP PSTN INDICATOR	A-310	ASR	1
4237091	WIPER MOTOR	A-310	ASR	1
5100017-1	HEADSET	A-310	ASR	1
TDH-39	HEADPHONE	A-310	ASR	1
253CA01F1-02Y1	CONTACTOR-THREE POLE	A-310	ASR	1
818VU	818 VU, PANEL-LIGHTING CONTROL A310	A-310	ASR	1
622-4540-001	DME XCVR	A-310	ASR	1
617924-3	APU PACK TEMP. CTRL.	A-310	ASR	1
980-0800-033	PRGMD ANNOUNCED REPRODUCER	A-310	ASR	1
863VU	863VU-746VU, BGM CONTROL PANEL A310	A-310	ASR	1
430VU	FUEL PNL	A-310	ASR	1
G7406-04	VHF CTRL PANEL	A-310	BER	1
700	ATTRNSFR	A-310	ASR	1

Part Number	Part Description	A/C Type	Condition	Quantity
433VU	PANEL	A-310	ASR	1
61551-000-1	SLAT/FLAP PSTN INDICATOR	A-310	ASR	1
419VU	419 VU, CAPT. LT. CTRL PANEL A310	A-310	ASR	1
431VU	431 VU, READING LT. & CTRL PANEL A310	A-310	ASR	1
85-13-03417-01	HAND MICROPHONE	A-310	ASR	1
617502-1	SENSOR	A-310	ASR	1
449VU	449 VU, READING LIGHT PANEL A310	A-310	ASR	1
6310-40	CONTROLLER INSTANT LT.	A-310	ASR	1
56B17A6	SENSOR-TEMPERATURE	A-310	ASR	1
SD9425-01	LAVATORY SMOKE DETEC	A-310	ASR	1
64902-052	HYDRAULIC QUANTITY IND.	A-310	ASR	1
293GC01Y0L	D CURRENT SENSORR	A-310	ASR	1
2936C51Y02	G. CURRENT SENSOR	A-310	ASR	1
119VU	119VU, COCKPIT DOOR S/W MODULE A310	A-310	ASR	1
CP2426FB	AUDIO CONTROL PANEL	A-310	ASR	1
700	ATTRNSFR	A-310	ASR	1
389GC01Y03	BATTERY CHARGER	A-310	ASR	1
9028A0002-01	PICK OFF UNIT POSITI	A-310	ASR	1
310ZN01Y01	SENSOR-CUR.UNBLNCE	A-310	ASR	1
AR4709-3	CONT-COCKPIT SYSTEM	A-310	ASR	1
82200A0101	SELECTOR	A-310	ASR	1
152CA01C1-02Y1	CONTACTOR-THREE POLE	A-310	ASR	1
24-622300-003	AUDIO TFMR A310 PTV	A-310	ASR	1
35-53	LIGHT-DOME	A-310	ASR	1
627416-1	SENSOR-ZONE IN TEMP	A-310	ASR	1
9599-607-12333	LRRA ANTENNA	A-310	ASR	1
GBC300-71	BRMTRC S	A-310	ASR	1
A923-20520-000-00-A-512	AUDIO SELECTOR PANEL	A-310	ASR	1
792-6140-001	HF ANT. COUPLER	A-310	ASR	1
4045053-903	ADC	A-310	ASR	1
822-1044-003	VHF R/T # 1	A-310	ASR	1
735234B	G P C U	A-310	ASR	1
740120B	GCU	A-310	ASR	1
627248-1	CONTLER, PNEU SYS.	A-310	ASR	1
627248-1	CONTLER, PNEU SYS.	A-310	ASR	1
35-493-2002	CTL UNIT	A-310	ASR	1
622-5342-001	AMPLIFR	A-310	ASR	1
423VU	CTL PNL	A-310	ASR	1
2228472-1	PRINTER	A-310	ASR	1
6664157	REGULTR	A-310	ASR	1

Part Number	Part Description	A/C Type	Condition	Quantity
822-1044-003	VHF R/T # 1	A-310	ASR	1
622-5222-002	ADF # 2	A-310	ASR	1
35-890-1001	ECAM CTRL PANEL	A-310	ASR	1
980-4595-003	BGM PANEL	A-310	ASR	1
427VU	HYD PWR PNL	A-310	ASR	1
432VU	PRESS PNL	A-310	ASR	1
627562-1	CONTLER-CARGO	A-310	ASR	1
627396-1	TEMPERATURE CONTROL	A-310	ASR	1
792-6140-001	HF ANT. COUPLER	A-310	ASR	1
792-6140-001	HF ANT. COUPLER	A-310	ASR	1
2LA002607-00	LIGHT	A-310	ASR	1
477VU	477 VU, BUZZER PANEL A310	A-310	ASR	1
861CAE1-0001	AOA SENSOR	A-310	ASR	1
289VU	289 VU, PANEL A310	A-310	ASR	1
APE2652	CLOCK	A-310	ASR	1
235TS05Y03	#1 ENG FIRE HANDLE MODULE	A-310	ASR	1
237TS05Y03	CONTROL PANEL-FIRE SHUTOFF ENG 2	A-310	ASR	1
899-2223-008	VOR DME CONTROL UNIT	A-310	ASR	1
G6201	HF CTRL PANEL	A-310	ASR	1
729720	CURRENT TRANSFORMER	A-310	ASR	1
WL301EED3	N1 INDICATOR	A-310	ASR	1
WL351EED5	N2 INDICATOR	A-310	ASR	1
414VU	414 VU, LIGHT PLATE A310	A-310	ASR	1
WL353EED4-1	FUEL FLOW/ USED INDICATOR	A-310	ASR	1
402VU	402 VU, CAPT. SWITCHING PANEL A310	A-310	ASR	1
97VU	PANEL	A-310	ASR	1
759VU	PANEL	A-310	ASR	1
700	ATTRNSFR	A-310	ASR	1
4037132	RUN WAY TURN OFF	A-310	ASR	1
6310-40	CONTROLLER INSTANT LT.	A-310	ASR	1
433VU	PANEL	A-310	ASR	1
63540-156-3	RMI/VOR/DME IND.	A-310	ASR	1
889-2625-004	ADF CONTROL PANEL	A-310	ASR	1
CP2426FB	AUDIO CONTROL PANEL	A-310	ASR	1
627396-1	TEMPERATURE CONTROL	A-310	ASR	1
50-0122-1	TAXI & T/OFF LT. ASSY (LH)	A-310	ASR	1
21B107-13	GCU STANDBY GENERATOR	A-310	ASR	1
K4CM0	ENGAGE MODULE	A-310	ASR	1
65-54807-3	COVER	A-310	NS	1
E-311P	DC UNDER VOLTAGE	A-310	SV	1

Part Number	Part Description	A/C Type	Condition	Quantity
2202286-2	DUCT	A-310	OH	1
A25315	VALVE-PARKING BRAKE	A-310	TEST	1
540604-4	AILERON TRIM ACT.	A-310	SV	1
RPP137-1A	CONT UNIT	A-310	US	1
3214-41	EPSU	A-310	ASR	1
3214-40	EPSU L2 DOOR	A-310	ASR	1
3214-41	EPSU	A-310	ASR	1
3214-40	EPSU L2 DOOR	A-310	ASR	1
3214-40	EPSU L2 DOOR	A-310	ASR	1
3214-41	EPSU	A-310	ASR	1
3214-40	EPSU L2 DOOR	A-310	ASR	1
A25315-1	Parking Brake Operated Valve	A-310	SV	1
3214-41	EPSU	A-310	EXPIRED	1
3214-41	EPSU	A-310	EXPIRED	1
528-0113-013	RF DATA TRANSLATOR	A-310	OH	1
572-510-9008	PLUG	A-310	NS	2
9315M16G17	HPT STG 2 SEAL	A-310	OH	1
9051M51G04	LINK-CONNECTING STG1	A-310	SV	7
C-07202-2	SHAKER	A-310	REP	1
64040-861-1	STBY AIRSPEED IND	A-310	REP	1
CGDU2000-00	MAIN DECK SMOKEDETEC	A-310	ASR	1
A25313-101	VALVE-PARKING BRAKE	A-310	SV	1
65205-230-3	ALTIMETER	A-310	SV	1
90G118-2	HYD PUMP PRESS. SW	A-310	SV	1
822-1044-003	VHF R/T # 1	A-310	SV	1
30-0621-9	TAIL POS. LIGHT	A-310	SV	1
2012-1	CHARGER ASSY-BATTERY	A-310	SV	1
A825100-3	EXTINGUISHER-FIRE	A-310	EXPIRED	1
35-900-1010-011	COMPUTER - FEEL LIMITATION	A-310	SV	1
129440-1	THERMOSTAT	A-310	SV	1
286467	A/S SERVOVALVE	A-310	SV	1
417T4205-66	OXYGEN MASK	A-310	ASR	1
69-54600-3	CYLINDER ASSY - HYDR TRANSFER MAIN GEAR	A-310	SV	1
521192	NACELLE TEMP. IND.	A-310	ASR	1
C24264004-1	PRESSURE LIMITER	A-310	SV	1
102EH2BH	SENSOR-TOTAL TEMP	A-310	SCRAP	1
129440-1	THERMOSTAT	A-310	SV	1
MS3410-D-28	BACKSHELL	A-310	SV	1
90G118-2	HYD PUMP PRESS. SW	A-310	OH	1
2670136	SHUT OFF VALVE	A-310	SV	1
102EH2BH	SENSOR-TOTAL TEMP	A-310	US	1
9-116-01	INDICATOR, FUEL USED	A-310	SV	1

Part Number	Part Description	A/C Type	Condition	Quantity
CG7G0	SMOKE DETECTOR	A-310	EXPIRED	1
CG7G0	SMOKE DETECTOR	A-310	EXPIRED	1
B41999-1	FITTING RELIEF PORT	A-310	NE	1
4057800-906	MACH AIRSPEED IND	A-310	SV	1
VD3800	FAN	A-310	ASR	1
VD3800	FAN	A-310	ASR	1
VD3800	FAN	A-310	ASR	1
VD3820	GALLEY LAV VENT FAN	A-310	ASR	1
066-50000-2120	TCAS PROCESSOR	A-310	SV	1
740120C	G.C.U	A-310	SV	1